

Instruction Manual Bluetooth® Wireless Audio Adapter

iWorld®

FEATURES

- Make any headphones or earbuds wireless! Works with all Bluetooth®-enabled audio devices.
- Stream audio wirelessly via Bluetooth technology in high quality from up to 33 ft. away.
- Integrated rechargeable battery provides hours of playing time wherever you go.

SPECIFICATIONS

- Power: Internal Li-Ion Rechargeable Battery
- Bluetooth Version: Bluetooth v4.2
- Wireless Capability: Up to 33 ft range
- Supply Voltage: DC 3.7V (not included)

CHARGING THE ADAPTER BATTERY

The internal battery must be fully charged before first use of the wireless adapter. To charge, use the included USB charge cable:

1. Insert the smaller micro-USB end of the cable into the CHARGE INPUT on the adapter unit.
2. Insert the larger USB end of the cable into the USB port of a computer OR into a compatible USB DC 3.7V wall charger (not included) to charge through a standard wall outlet. The indicator lights up red during charging and will turn blue when charging is complete. Unplug from the power source when charging is complete.

NOTE: Low adapter power and/or low audio device power may cause poor operation and/or no Bluetooth connection. Recharge as described above.

BLUETOOTH WIRELESS ADAPTER OPERATION

1. Make sure the battery is charged as explained above.
2. Insert the 3.5 mm connector plug of your headphones or earbuds into the headphones input jack on the adapter unit.
3. Press and hold the POWER/PLAY BUTTON for several seconds until the indicator light flashes blue and red – this means the Bluetooth function is active and ready to connect to your smartphone/Bluetooth audio device.
4. Activate Bluetooth function on your audio device – it should automatically recognize the receiver unit and allow you to select it using the name "iWorld". If required, enter the password "0000" to complete the wireless connection. When the receiver is connected, the indicator light will flash blue and you are now set to enjoy wireless audio from within a 33ft range of the audio device.
5. Before playback, first adjust the volume of your audio device to medium level as a safe starting point.
6. To play audio, click the POWER/PLAY BUTTON once.
7. To pause audio, click the POWER/PLAY BUTTON once.
8. To increase the volume, click + once. The adapter makes a chime sound when it reaches maximum volume. To decrease the volume, click - once.
9. To go to the next song, press and hold +. To go to the previous song, press and hold -.
10. To answer an incoming call, click the POWER/PLAY BUTTON once.
11. To hang up a phone call, click the POWER/PLAY BUTTON once.
12. To disconnect and shut off the earbuds unit, press and hold the POWER/PLAY BUTTON until the indicator light goes out.

NOTE: If there is no connection or recognition of the adapter unit on your device and the red/blue indicator lights have stopped flashing, shut off the adapter unit and then restart from step 4 to try again.

NOTE: Low adapter power and/or low audio device power may cause poor operation and/or no Bluetooth connection.

CONTENTS

- 1 Bluetooth Adapter Unit
- 1 USB Charging Cable
- 1 User Manual



Instruction Manual, Bluetooth® Wireless Audio Adapter (continued)

CAUTION

- **This is not a toy. Please keep away from small children.**
- **Please keep the unit away from water and heat.**
- **Do not over-charge the battery.**



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

TECHNICAL SUPPORT: Please do not attempt to fix the product yourself. If you are experiencing any problems with the product please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you may have. For assistance operating your product, please consult the User's Manual or feel free to contact iWorld technical support:

iWorld LLC
65 West 36th St., 11th Floor
New York, NY 10018, USA

www.iworldnyc.com
email: support@iworldnyc.com
Please keep instructions for further reference.

© 2017 iWorld Global Trading LLC

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by iWorld is under license. All other trademarks and trade names are those of their respective owners. Actual product may differ slightly from image shown. MADE IN CHINA.

INSTRUCTIONS CONTINUED ON THE OTHER SIDE →