

3D Printer User Manual

Important Statement



Thank You for choosing KOKONI 3D printer. We hope You enjoy the experience!

We strongly recommend you reading this manual carefully before operating your printer. Using the printer indicates that you have both read this manual and agreed to the safety instructions listed below.

KOKONI is dedicated to providing the best possible service. To reach our customer support, please feel free to contact us by phone or email provided at the end of this manual.

For better experience, please visit our official website www.kokoni3d.com for hardware and software related information, contact information, operating and maintenance information, and so on.

Moxin (Zhejiang) Technology Co., Ltd reserves the right to revise and construct this user manual.

IMPORTANT SAFETY INSTRUCTIONS



1. Do not attempt to use the printer for any other unintended purposes not mentioned in the manual, as doing so may result in personal injuries or property damage.
2. Do not position the printer near any combustibles, explosives or heat sources. A well-ventilated, cool and dustless environment would be preferred.
3. Do not place the printer in a vibrating or unstable environment. The shaking of machine may cause print quality issue.
4. Please use the power adapter we provide to connect the printer to a safe, properly accredited two-hole power outlet, don't use other adapters to connect the printer. To reduce the risk of fire or electric shock, do not expose the printer to rain or moisture.
5. Do not wear woven gloves while operating the printer as they could be rolled in via the moving parts, which could result in bodily injuries.
6. Keep any part of your body off the moving nozzle and the printing platform, while the printer is operating.
7. The models printed out by the printer are not edible.
8. Do not loosen any screws of the machine to prevent electric shock.
9. To guarantee the printing quality and a standard service life of the printer, please use the filament we recommend.
10. Maintain the printer on a regular time basis, switch off the printer to clean the site with a piece of dry cloth, clear up filament slag in the printing chamber by tweezers and check whether there are some foreign objects on the belt.
11. To avoid injuries, it is forbidden for children aged 10 or less to operate alone.
12. Users should strictly comply with the relevant local laws and regulations of any residing region or country, observe professional ethics and ensure safety while using this product. Otherwise, they should bear corresponding legal liability.

| Index

Please read this manual thoroughly before use it and keep it for further reference

Product Introduction	02
Product Specifications	03
Environmental Specifications	03
Printer Start-up	04
KODAK App Installation	05
Wi-Fi Network Configuration	06
Quick Print	07
3D Avatar Modeling	08
Object Modeling	09
Filament Replacement	10
Filament Replacement, Continued	11
Printer Maintenance	13
Cleaning Up	13
FAQ	17
Declaration Of Hazardous Substances	15
After-Sales Support	16
Warranty Card	17


| Product Introduction



1. Printing nozzle assembly
2. Printing platform
3. Filament outlet
4. Filament chamber
5. Network configuration button
6. Filament replacement switch
7. Power input
8. Power switch



Tweezer*1



Power adapter*1



Printing plate*1
(Pre-assembled)

Note: Please wait till the white indication light stop flashing before operating the device.


| Product Specifications



Description	Model No.	Dimensions	Printing size
KOKONI 3D Printer	KOKONI -FC1	189*92*231 mm	130*100*188 mm
Execution standard	Net weight	Rated voltage/Current	Rated power
GB 4943.1-2011	3.1 kg	DC12V/5A	60W
Forming technique	Number of nozzles	Nozzle diameter	Nozzle temperature
FDM/FFF	Single nozzle	0.4 mm	≤260°C
Printing speed	Printing layer thickness	Compatible filament	Raw material of filament
80 mm/s (MAX)	0.04~0.30 mm	STL, OBJ, etc.	Modified PLA

| Environmental Specifications

Environmental condition	Recommended value	Allowed value
temperature	18~25°C	10~27°C
Humidity	Relative humidity 20~60%	Relative humidity 10~70%
Altitude	Not applicable	0~2000 m



1. After turning on the Power switch, there will be a beep sound and the indicating light in white color will start to flash (to ensure better print quality, please place the printer on an flat and stable place).
2. Wait for the printer to perform its power-on self-test procedure. This may take about 30 to 60 seconds. Then, the white indicating light will stop flashing, and the printer is ready for use.

Tips:


You can download the printer control KOKONI App during the power-on self-test of the printer.

| Indicator status

Printer status	Indicator light	Status of indicators
Printer self-inspection	White	Flash
Printer network configuration	White	Off
Printer normal condition	White	On
Incorrect WiFi password	Orange	On
Filament replacement	Orange	On
Maintenance mode	Orange	On



1. Scan the QR code to download the KOKONI App




2. Register/Log in.

WiFi Network Configuration



>



>



>



1. Add a printer.

2. Press and hold the Network Configuration button (1), keep it down until you notice that the Network Configuration mode has been activated.

3. Print a hotspot defined for (2) through Settings-WiFi. It connects to the printer instead of (KOKONI Access), with the password of 123-5678.


4. Connection to your WiFi (Return to KOKONI App and enter the SSID and password of the current available WiFi close to the above KOKONI printer connected to the net).

Aention:

- For some phone models, it would take some time to search for a new spot, please wait/restart or just turn off the WiFi function and restart.
2. The following functions have to be activated for some phone models: WiFi Security Inspection, WiFi-N, Network Intelligent Selection, connect to the Best WLAN Network and Auto practically Switch the Cellular Network.

If you encounter problems in WiFi network configuration, please check the following diagnosis procedure:

1. Confirm the WiFi account and password, and make sure the WiFi entered is the current environment WiFi instead of KOKONI 3D hotspot.
2. Ensure the WiFi network environment is good. If the problem still exists, change to another network (e.g. WiFi), no compatible for the WiFi network configuration instructions designed for smart phones of various models, please refer to the Operation Guidance of the App.




1. I have a model:
 (1) Home - Start to Create - Scan your red model.
 (2) Home - Popular Models - Select a Model
2. Click 'Print' on the idle creation page.
3. Click 'Print' on the idle editing page.
4. Select the printer and Click 'Print' to print.
5. While printing, you can pause or cancel the printing task.

Aention:


1. After printing ends, the printer usually takes about 2 minutes to cool up. Please wait patiently.
2. Under no circumstance should you touch any moving parts as injuries could be inflicted. Be aware of the hot nozzle. If anything goes wrong in the printing process, click 'Cancel' to terminate printing or just unplug the power adapter. In such case, try not to make contact with either the nozzle or the printing bed.

| 3D Avatar Modeling


KOKONI



1. Home - Start in Create - 3D Avatar Modeling



2. Click 'Upload Photo'



3. Click 'Start Modeling'




4. 3D Avatar modeling
in progress or finished

Attention:


1. 3D Avatar modeling requires (1) 2D input selfie photos or uploading photos via smart phone; (2) when taking photos, keep up the person sufficiently and make sure the person's face towards the camera without being blocked; (3) don't put on hats, white clothing, glasses; (4) don't take profile photos; (5) Upload high definition photos; (6) Do not upload photos of more than one person.

Please be noted that it is currently only suitable for modeling living human beings' faces.

2. If you are prompted with 'No face', please change to a brighter environment, remove your gloves, and wear a mask when taking photo of your face.
3. If you are prompted with 'Image is not', is not suitable to successfully take photo with your camera and try to unlock action photo such as G Ex.



1. Home - Start to Create 3D Assets Modeling



2. Click 'Upload Photos'



3. Take photos around the object with each movement of the viewing angle less than 30 degrees and one overlaying another by more than 60%.




4. In input, less 20 photos and then click the left 'Start to Edit a Model'.

Attention:


Object modeling is based upon a precise 3-dimensional measurement of 20-300 images taken around the object with each movement of the viewing angle less than 30 degrees and one overlaying another by more than 60%.

The system will automatically verify whether the uploaded photos are qualified or not. At least 20 qualified photos are needed to modeling. As reconstructed via a computer algorithm, the modeling process takes about 1-2 hours in the background, and you can exit this page during the course of modeling. When finished, a message will pop up to notify you if the function of 'Push Notification' is activated on. You can then check the model in 'My Models'.


| Model Upload




1. Access the KOKONI model synchronization website:
<http://www.KOKONI.jp/mmc/#pages/modelSyncAndSync>



3. Click the record



2. Enter 'My Models' and click 'Update Model' in the right upper corner




4. Go to 'MyAccount' 'My Models' screen to check uploaded models.

Filament Replacement


KOKONI




>



>



>



1. Select the new filament reel you want to use.




>



2. The filament is being loaded by the printer.

3. Once the filament is loaded, select the "Done" button.


>




4. The filament is now properly loaded for printing.

| Filament Replacement Continued


KOKONI




9. Pull the white zip.




10. Press the black collar to remove the white printing tube as well as the remaining filament.



11. Turn the grey handle clockwise.




12. Remove filament from the filament box.




13. Swap the new filament box.



14. Insert the filament into the white handle once the white zip has been replaced.



15. Turn the grey handle clockwise again.




16. Push in the white zip.


| Printer Maintenance




In case the model is unable to be taken out from the printbed, or any foreign objects need to be removed from the printer; click "My Printer" in the App for maintenance. The printer will automatically heat up and push the printing bed outwards.



1. Select "My Printer"




2. Click "Maintenance"




3. Lift up the base plate with the handle until it's taken off from the printer and don't bend the handle of the lift to separate them (it's better suggested to change the base plate every 3-6 months).

| Cleaning Up



1. Clean the cavity w/ tweezers



2. At the nozzle needs to heat up to 230°C and wait before started operating. You can remove surplus materials from the hot end.

Q: How to make the surface of a model more smooth?

A: To make a model look shiny and feel smooth, you need to use sand paper or other tools to polish it. You can also select "High" in the precision setting to make better surface finishing. If the condition is irreparable and difficult to fix, contact the Customer Service Department.

Q: Is the printer compatible with other filaments?

A: Not yet, please use KOKONI modified PLA filament.

Q: How to change the filament?

A: Launch the KOKONI App and go through "My Printer" - "Replace Filament" to change it. More detailed instructions is shown on Pages 11-12 of the manual. Change the filament without KOKONI App could cause print quality issue or even damage the printer itself.

Q: Why doesn't the model stick onto the base plate?

A: When the first layer of a model doesn't stick to the base plate, apply a layer of glue to the base plate and do printing at a room temperature ranging from 20°C to 25°C as a proper temperature could prevent the base plate from bending over. Model warping is a normal phenomenon caused by the physical properties of the plastic. Itself, so printing in a warm environment can help to alleviate bottom warping.

Q: How many models can a roll of the filament make?

A: The roll of the filament is 70m, and the number of models it could make depends on the size of the models. Models in large size may need more filament. A more complicated model may consume more filament, too. On average, a roll of filament may print out about 20 simple models.

Q: Is it possible to resume the last printing task following a power failure?

A: Negative, once the power is out, the printing process ends.

Q: The connected printer becomes offline.

A: Reboot the printer and KOKONI App. If the printer still remains offline, delete it and reconnect the printer for network configuration.

Hazardous Substance Declaration



Component	Hazardous or toxic substance or element					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr ⁶⁺)	Polybrominated biphenyls (PBB)	PVC
Modified filament	○	○	○	○	○	○
Printed circuit board (PCB)	✗	○	○	○	○	○
Shell	○	○	○	○	○	○
Wire	○	○	○	○	○	○
Foam core	○	○	○	○	○	○
Power socket	○	○	○	○	○	○

The table above is compiled according to the standards of SJ/T 11364.

○ indicates that all homogeneous materials of the component in question contain the current hazardous substance less than the limit as provided in G 97/265/2.

✗ indicates that at least one of the homogeneous materials of the component in question contains the current hazardous substance above the limit as provided in G 97/265/2.

Notes: No batteries are needed by the printer.

Warranty Period

1-year Limited Warranty for the printer and power adapter from the date of purchase;

3-months Limited Part Warranty for the Vulnerable parts(-Extruder, Belt, Printing Platform Nozzle Module,e.c.);

No Warranty for the tools, Filaments, Printer Shell, User Manual , Warranty Card,etc.

What Is Not Covered?

1. The warranty period expires;
2. The purchase voucher is invalid or not identical with the product model;
3. Either the purchase voucher or the warranty card becomes unreadable due to man-made damage;
4. Use, maintain or repair the printer unintendedly, or dismantle the hardware or alter the software without KOKONI's permission;
5. The circuit board of the printer has been ruined due to crash, soaking, falling down or other human factors;
6. Use components not certified by the manufacturer;
7. Damage caused by force majeure such as fires, lightning and floods;
8. The product ages or discolors normally along the process of operation;
9. Product gifts.

After-sales Support

Please read the user manual and warranty card carefully before use. For any after-sales service, please priority contact local seller or contact us via Email:Support@kokoni3d.com or Call (+86)400-900-1360/ 0086-572-8219691.

Please provide product Serial Number when apply for technical support.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.

Maintenance service center		Date of delivery for repair	
Reason behind fault			
Fault description			
Return evidence			
Repairer (signature)		Repairer (seal)	



Moxin (Huzhou) Technology Co., Ltd

Address: 2F, B1, No. 926, Changhong East Str., Deqing County, Huzhou City, Zhejiang Prov., China.

Website: www.konkon3d.com

Hot line: (+86)400-900-1360

Email: Support@konkon3d.com



To better serve our customers, the manual may be updated from time to time,
we recommend scanning this QR code to view the latest manual. Thank you for your support.

Due to different models, the actual product and the picture may be a little different, please refer to the prevail product; Software update page may change, please refer to the actual software page instructions; Moxin (Huzhou) Technology Co., LTD reserved all the right for final explanation.