

Instruction Manual

MODEL: VTA-370B

Music Center with Bluetooth



The lightning flash with arrowhead within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**

**CAUTION: TO PREVENT
RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED
SERVICE PERSONNEL.**



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

CAUTION: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

WARNING: To prevent electric shock, do not use this (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.



WARNING: Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to laser beam.

Important Safety Instructions

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool, and the like.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiations, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug the apparatus during lighting storms or when unused for long periods of time.
14. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



15.



-This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

-Warning: To reduce the risk of electric shock, do not remove cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel.

-The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

16. The mains plug is used as disconnect device, the disconnect device shall remain readily operable.

17. **WARNING**

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall not be placed on apparatus.

18. The use of the equipment in moderate climate.

19. The ventilation should not be impeded by covering the ventilation openings with items such as, newspapers, tablecloths, curtains, etc.

20. No naked flame sources, such as lighted candles, should be placed on the apparatus.

21. The symbol with $\sim$ Indication AC voltage.

22. The symbol with $\equiv$ indicate DC voltage.


23. **CAUTION:** These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

24.



This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.


Product Overview



Front View

1. **POWER** : Toggle to turn the unit on or off.
2. **3.5mm AUX IN JACK**: Connect your external source to the AUX IN jack.
3. **3.5mm HEADPHONE JACK**
4. **STEREO SPEAKERS**
5. **DISC TRAY**
6. **OPEN/CLOSE** : In CD mode, use to open and close the disc tray.
7. **PLAY/PAUSE** : Press to start playback, press again to pause.
(Note: This button only works in CD, Bluetooth and USB mode.)
8. **PAIR**: Press to Pair a new Bluetooth device to the unit. Once the device is connected successfully, you can press the PAIR button to disconnect from your external device.
9. **STOP** : In CD or USB mode, press to stop playback or cancel the program setting. In recoding mode, press to cancel the recording.
10. **PLAY MODE**: In CD/USB mode, press to select the repeat or shuffle mode.
When the CD or USB is stopped, press to program mode.
11. **NEXT** : In CD/USB/Bluetooth mode, press once to skip the current track. In CD/USB mode, press and hold to forward.
12. **RECORD**: Press to record from CD/Bluetooth/AUX-IN/PHONO/TAPE onto USB memory.
13. **PREVIOUS TRACK** : In CD/USB/Bluetooth mode, press once to return to the beginning of the current track, press again to return to the previous track. In CD/USB mode, press and hold to rewind.
14. **RADIO TUNER KNOB**: In FM mode, turn to tune in a station.
15. **LED DISPLAY**
16. **VOLUME KNOB**: Turn to adjust volume.
17. **SELECTION KNOB (FM, CD, USB, BT, AUX, PHONO, TAPE)**: Rotate to select your desire function.

Left Side View




18. CASSETTE FF & EJECT:

Press halfway to fast forward, press all the way to end and eject the tape.

19. USB Port

Rear View



20. LINE OUT Jacks

For amplifier device with RCA auxiliary input sockets, insert the white and red plugs on the RCA cable into the unit. Insert the opposite end into the amplifier device. Be sure to connect the white plug to the white jack and the red plug to the red jack.

21. FM Antenna


While tuned to a station in FM mode, extend the wire and reposition to adjust for best reception.

22. AC Power Cord

Connect the AC plugs into a wall outlet.

You're strongly recommended that this product should be operated only from the type of power source indicated on the marking label.

Parts of the Turntable





- A. Turntable.
- B. **Safety Screw (for transport)** Before using the unit, turn the screw **clockwise** using a coin or screwdriver.
***Important:** When you transport the unit, turn the screw counterclockwise to secure the turntable.*
- C. **Speed Selector.**
- D. **Tone Arm holder.**
- E. **Tone Arm.** Before use, completely loosen the twist tie on the tone arm and uplift tone arm.
- F. **Stylus.**
- G. **45 RPM adaptor.**
- H. **Cue-lever.** Use this lever to lift the tone arm.

Setup / Basic Operation

Setup

1. Remove white protective needle cover by gently pulling towards front of unit.
2. Remove any packaging materials from the unit.
3. Connect the AC power cord to a wall outlet.



Note:

- It is strongly recommended that this product should be operated only from the type of power source indicated on the marking label.
- To prevent interference, avoid bundling audio signal cables together with the AC power cord.

Basic Operation

1. Move the POWER toggle to the ON position. The LED light around the radio dial will light up.
2. Select a play mode by rotating the function knob (FM/CD/USB/BT/AUX/PHONO/TAPE).
3. Rotate the VOLUME knob to adjust the desired level of sound.


Listening through RCA LINE OUT

For amplifier device listening, first reduce the volume level to minimum. Insert the white and red plugs on the RCA cable into the back of the unit, then insert the opposite end into your amplifier device. Be sure to connect the white plug into the white jack and the red plug into the red jack.

Listening through Earphones/Headphones (not included)

For private listening, first reduce the volume level to minimum. Insert your headphones' plug into the 3.5mm jack, then adjust the volume up by turning the VOLUME knob.

Note: The speakers will automatically be deactivated while headphones are plugged in.



CONDENSATION WARNING:

When the unit is moved from a cold or warm place, or is used following a sudden temperature change, there is the danger that water vapor in the air may condense on the unit, preventing proper operation. In such cases, leave the unit for 1-2 hours after plugging it into an AC outlet to allow it to stabilize at the temperature of its surroundings.

Listening to the FM Radio

1. Rotate the Function Knob to select "FM". The LED Display will display "rAd".
2. Tune to the desired station using the Radio Tuner Knob.

Listening to a CD/CD-MP3/WMA

1. Rotate the Function Knob to select CD. The LED Display will display "Cd--".
(Note: When no disc is set, "disc" will appear on the display.)
2. Press the OPEN/CLOSE (▲) button to open the tray.
(Note: This button only works in CD mode.)
3. Place a disc on the tray with the printed label face up.
4. Press the OPEN/CLOSE button (▲) to close the tray.
5. Then it will begin to playback from the first track automatically.
6. To temporarily pause playback, press the PLAY/PAUSE button (▶||). Press again to resume.
7. To return to the previous or skip tracks, press the corresponding button (◀◀ or ▶▶). Pressing



- ◀◀ once will restart the current track. Pressing ◀◀ twice in succession will return to the beginning of the previous track. Press ▶▶ once to skip the current track.
8. To Fast Forward / Rewind within a track, press and hold down the corresponding skip button until the desired position is reached.
 9. To stop playback, press the STOP ■ button

Important:

- Never place more than one disc on the tray.
- The disc must be placed in the center of the disc tray. An incorrectly loaded disc can permanently damage the tray door mechanism.
- Do not push the CD tray – always use the OPEN/CLOSE button.
- It takes a moment for the unit to load a disc, during which all buttons will be temporarily deactivated.

Repeat/Shuffle Playback

Each time the PLAY MODE button is pressed, the repeat mode will cycle through the following options:

REPEAT 1 (Repeat one track)

The "REPEAT 1" icon will appear on the display and the current track will be played repeatedly. If you press the (◀◀ or ▶▶) button to select another track, the track you select will be played repeatedly.

REPEAT FOLDER (Repeat one folder)

The "REPEAT FOLDER" icon will show on the display. In CD-MP3/WMA mode, you can select the folder to play.

REPEAT ALL (Repeat the entire CD)

The "REPEAT ALL" icon will show on the display and the entire CD/CD-MP3/WMA will be played repeatedly.

SHUFFLE

The "SHUFFLE" icon will appear on the display. Playing the tracks on a CD mode in a random sequence.

Notes:

- Repeat playback works with CD discs only.
- Pressing (▶▶) during shuffle playback will randomly select the next track.
- A track cannot be repeated during shuffle playback.
- Shuffle playback doesn't work during programmed playback.

To cancel the REPEAT or SHUFFLE mode, press the PLAY MODE button repeatedly till the icon disappears from the display.

Programmed Playback

You can program up to 20 tracks for CD disc and program up to 99 tracks for MP3 disc.

Notes:

- Shuffle playback does not work during programmed playback.
 - Programmed playback works with finalized disc only.
1. Select "CD" mode, then load a CD.
 2. While the CD is stopped, press the PLAY MODE button.
 3. "PROGRAM" icon will show and "P01" blinks on the display.
 4. Press (◀◀ or ▶▶) to select a track number.
 5. Press the PLAY MODE button again to set the next program track, "P02" appears and blinks. Repeat steps 4 through 5 to program the additional tracks.
 6. When the selection of track numbers has been finished, press the PLAY/PAUSE

button (▶||) to start program playback.

(Note: when all 20 or 99 program tracks are finalized, press the PROGRAM button once and "FI" will appear on the display)

7. Press the STOP (■) button twice to cancel the program mode and then the "PROGRAM" will disappear from the display.

To check the programmed order

In the stop mode, press (◀◀ or ▶▶) repeatedly to show the track numbers that have been programmed.

To add a track to the end of the programmed order:

In the stop mode, press the PLAY MODE button.

Select a track number by pressing (◀◀ or ▶▶), then press the PLAY MODE button.

The current track will be added to the end of the program.

Listening to an External Audio Device (BT Mode)

In BT (Bluetooth) mode, this unit can play music from external devices that have a built-in Bluetooth feature.

GETTING CONNECTED USING BLUETOOTH

1. Rotate to select "BT" function. The LED Display will display "BLUE" and  icon.
2. The "BLUE" LED Display and  icon will start flashing while searching for a device.
3. On your external device turn on the Bluetooth function.
NOTE: The effective distance between your external device and this apparatus is 10 meters (33ft).
4. Wait a moment for "VTA-370B" to appear on the devices list. Press "VTA-370B" to connect to the unit. If a window asks you for a password, fill in "0000" then press "OK" on your external device.
5. Once the Bluetooth connection is successful the "BT" Indicator will remain lit.
6. You can press BACK or NEXT button to skip the previous/next track or control on your device.

NOTE:

- The PAIR Button will allow you to disconnect from your external while remaining in BT mode. Simply press the PAIR button to disconnect. Press again to reconnect the device that has been connected before.
- Fast Forward / Rewind is only available on your external device.

Listening to an External Audio Device (AUX Mode)

Rotate to select "AUX" function. The LED Display will display "AUX"



In AUX (auxiliary) mode, this unit can play audio from an external device (iPod, MP3 Player, Portable CD Player, etc.)

There is an AUX IN jack on the front of the unit. When connecting a device that has a headphone jack, use a 3.5mm cable on both ends to connect the external device with the apparatus.

1. Plug one end of the 3.5mm cable (not included) into the AUX IN jack.
2. Plug the other end of the cable into the headphone jack of the external device.

NOTE: All operations are only available on your external device.

Listening to a Vinyl Record

1. Rotate to select "PHONO" function. The LED Display will display "PHON".
2. Gently open the top cover.
Note: Be careful not to pinch your finger when opening/closing the top cover.
3. Place a vinyl record on the turntable. When playing a 45 RPM record, use the included adaptor.
4. Select the appropriate speed.  
5. Remove the tone arm rest holder to release the tone arm.
6. Gently raise the arm by using the tone arm lever. Move the tone arm to the edge of the record (or the starting point of a track) and lower the arm onto the record using the tone arm lever. The turntable will begin to turn.
7. When the record reaches its end, tone arm will stop at the center of the record and you must lift and return the tone arm to the tone arm rest manually. Lock the tone arm in the rest holder to protect the tone arm.

Important:

- Closing the top cover will help prevent dust from settling on the turntable.
- Always relock the tone arm clip before transporting the unit.
- Do not place anything on top of the turntable cover, especially while playing a record.

Listening to a Cassette Tape

1. Rotate to select "TAPE" function. The LED Display will display "tAPE". Load an audio cassette tape into the unit (located on the right side of the unit). Playback will automatically begin.
2. Press button halfway to Fast Forward the tape. Press button lightly and playback will resume.
3. Press button completely down to end playback and eject tape.

USB Memory Stick Playback / Recording

1. Rotate selector knob to USB function. "USB" will appear on the display.
Note: When no USB is inserted, "NO" will appear on the display.
2. Insert the USB memory stick (not included) into the USB port and then it will begin playback automatically from the first track.
3. To pause playback, press the PLAY/PAUSE button (▶||). Press again to resume.
4. To skip tracks backward or forward, press the corresponding skip button (◀◀ or ▶▶). Press (◀◀) once will restart the current track. Press (◀◀) twice in succession will return to the beginning of the previous track. Press (▶▶) button to skip to the next track.
5. To fast forward/rewind within a track, press and hold down the corresponding skip button until the desired position is reached.
6. To stop playback, press the STOP (■) button.

Repeat/Shuffle Playback

Each time the PLAY MODE button is pressed, the repeat mode will cycle through the following options:

REPEAT 1 (Repeat one track)

The "REPEAT 1" icon will appear on the display and the current track will be played repeatedly. If you press the (◀◀ or ▶▶) button to select another track, the track you select will be played repeatedly.

REPEAT FOLDER (Repeat the folder)

The "REPEAT FOLDER" icon will show on the display and the folder will start to play repeatedly.

REPEAT ALL (Repeat the entire USB)

The "REPEAT ALL" icon will show on the display and the entire USB will start to play repeatedly.

SHUFFLE

The "SHUFFLE" icon will appear on the display. Playing the tracks on a USB mode in a random sequence.

Notes:

- Pressing (▶▶) during shuffle playback will randomly select the next track.
- A track cannot be repeated during shuffle playback.
- Shuffle playback doesn't work during programmed playback.

To cancel the REPEAT or SHUFFLE mode, press the PLAY MODE button repeatedly till the icon disappears from the display.

Programmed Playback

You can program up to 99 tracks for the USB.

Notes:

- Shuffle playback does not work during programmed playback.

1. Rotate to select USB function, then insert a USB memory stick into USB port.
2. While the USB is stopped, press the PLAY MODE button.
3. "PROGRAM" icon will show and "P01" blinks on the display.
4. Press (◀◀ or ▶▶) to select a track number.
5. Press the PLAY MODE button again to set the next program track, "P02" appears and blinks. Repeat steps 4 through 5 to program the additional tracks.
6. When the selection of track numbers has been finished, press the PLAY/PAUSE button (▶||) to start program playback.
(Note: when all 99 program tracks are finalized, press the PROGRAM button once and "FI" will appear on the display)
7. Press the STOP (■) button twice to cancel the program mode and then the "PROGRAM" will disappear from the display.

To check the programmed order

In the stop mode, press (◀◀ or ▶▶) repeatedly to show the track numbers that have been programmed.

RECORDING

Before Recording

Audio from the PHONO, TAPE, CD or AUX/BLUETOOTH sources can be recorded on the USB memory. Note: All sources record to USB, the format is MP3.

Record from BT/AUX/PHONE/TAPE

- 1) First Insert a USB memory stick into the USB port.
- 2) Pick the source of music and rotate the selector knob (BT/AUX/PHONO/TAPE)
 - a) If using a record, put the vinyl on the turntable.
 - b) Place the needle on the record. The unit will play automatically.
- 3) Start playing your music from your preferred source.
- 4) Press RECORD button to enter recording mode. "REC" and "USB" will appear on the display.



Note: It needs a few seconds to read the USB memory stick, the LED display will appear USB flashing →LOAD→BUSY.

- 5) After that it will start to recording automatically and the audio track will show on the display.



- 6) To stop recording, press the STOP (■) and REC and USB will disappear from the display.

Note:

- Recording volume is preset and cannot be adjusted. The listening volume does not affect the recording process.
- For manual track separation during the recording process, press the STOP button to end a track at your preferred location. To begin recording another track, press the RECORD button and then press the stop button when you want to end your next track.

Recording from CD to USB:

- 1) First Connect the USB memory stick into USB port.
- 2) Select CD Source mode, then put a CD on the tray and close the tray.
- 3) The unit will enter the CD mode, if the CD sources playing, press the STOP button to stop the track. The CD must be stopped before recording.
- 4) To record from the beginning of the CD:
 - a) Press the RECORD button to enter the recording mode and it will start recording from the first track.



- b) When recording is finished, it will exit the record mode automatically.
- 5) To record from a specific track:
 - a) Select the exact track you want to record using the BACK and NEXT buttons (◀◀ or ▶▶).
 - b) Then press RECORD to start recording from that specific track.
 - c) Press STOP to end the track recording.

- 6) Press the STOP button to cancel the recording and the number of tracks will appear on the display.



Note: When audio from CD is recording to USB, only the STOP button will work.

Recording from CD-MP3 to USB:

Please note: No audio will be heard when recording, this is normal.

When recording from CD-MP3 to USB, the recording starts from track one on the CD and will record until the entire CD is copied to the USB drive. You can press STOP to stop the recording process at any time, but this will limit the tracks shown on the USB. We recommend recording the entire CD-MP3 to USB and then deleting files that are not preferred.

- 1) First Connect the USB memory stick into USB port.
- 2) Select CD Source Mode, then put a CD-MP3 on the tray and close the tray.
- 3) The unit will enter the CD mode, if the CD-MP3 source is playing, press the STOP button to stop the track. The CD must be stopped to begin recording.
- 4) Press the RECORD button to enter the recording mode and it will start to copy the entire CD-MP3 onto the USB.



- 5) When recording is finished, it will exit the record mode automatically.
- 6) Press the STOP button to cancel the recording and the number of tracks will appear on the display.



Note: When audio from CD-MP3 is recording to USB, only the STOP button will work.

Erasing the Last Track or All Tracks:

1. With an USB memory stick inserted, select the USB function by rotating the selector knob.
2. In stop mode, press and hold the STOP ■ button, "dEL 1" will appear on the display.
3. Press the BACK or NEXT (◀ or ▶) to select delete one track ("dEL 1") or delete all tracks ("dEL A").
4. Press the PLAY/PAUSE (▶||) button twice to confirm delete.
5. If you select to delete one track, the display will appear with the numbers of track at the end.
6. If you select to delete all tracks, the display will show "no FO" at the end.

Please note: After recording is complete (depending on the length of the recording), button operation might be disabled briefly while the recording is finalized internally. If the buttons do not operate, please wait 30 seconds to 1 minute for the unit to finish processing the recording. Unit will then return to normal operation.

Compact Disc Handling

- Always place the disc on the disc tray with the label side facing upward (compact discs can be played/recorded only on one side)
- To remove a disc from its storage case, press down on the center of the case and lift the disc upward, holding it carefully by its edges.
- To clean a disc, wipe the surface from the center hole outward towards the outer edge with a soft, dry cloth.
- Never use such chemicals as record spray, antistatic sprays or fluid, benzine or thinner to clean discs; they will irreparably damage the disc's plastic surface.
- Discs should be returned to their cases after use to protect from dust and scratches.
- Do not expose discs to direct sunlight, high humidity, or high temperature for extended periods of time.
- Printable CD-R and CD-RW discs are not recommended, as the label side may become sticky and damage the unit.
- Use a soft oil-based felt-tipped pen to write information on the label side. Never use a ball-point or hard-tipped pen, as doing so may damage the recorded side.
- Do not use irregularly-shaped CDs (octagonal, heart shaped, business card size, etc), as they will damage the unit.
- Read all precautions supplied with any CD-R or CD-RW disc
- Never handle a disc with dirty fingers.
- Never insert a disc that has a crack on the surface.

Handling Vinyl Records

- Do not touch the record's grooves. Only handle records by the edges or the label with clean hands. Touching the record surface will cause your record's quality to deteriorate.
- To clean a record, use a soft anti-static cloth to gently wipe the record surface.
- Keep records in their protective sleeves when not in use.
- Always store records upright on their edges
- Avoid placing records in direct sunlight, close to a heat source (radiators, stoves, etc.), or in a location subject to vibration, excessive dust, heat, cold or moisture.

General Care

- When removing the power plug from the wall outlet, always pull directly on the plug. Never pull the cord.
- To keep the laser pickup clean, do not touch it, and do not forget to close the disc tray.
- Do not attempt to clean the unit with chemical solvents as this might damage the finish.
- For cleaning, only use a clean, dry cloth.
- In order to shut off the power to this product completely, unplug the power cord from the wall outlet. Be sure to unplug the unit if you do not intend to use it for an extended period of time.

How to Replace the Turntable Stylus/Replacement Needle # ITNP-LC1)

The stylus should last about 50 hours under normal use. However, it is recommended that the stylus be replaced as soon as you notice a change in sound quality. Prolonged use of a worn-out stylus may damage the record. The highest speed of 78 RPM records would wear out the stylus more quickly.

Removing the old stylus:

1. Set a screwdriver at the tip of the stylus and push downward (A).
2. Remove the stylus by pulling it simultaneously downward and forward.

Installing a new stylus:

1. Hold the front tip of the stylus and insert its rear edge (B) first.
2. Push the stylus upwards (C) until the tip locks into place.

Caution:

- Do not bend the stylus.
- Do not touch the needle to avoid injury your hand.
- Turn off the unit's power before you replace the stylus.
- Keep out of reach of children.



Specifications

GENERAL

Power Requirements	AC 120 V~60 Hz
Power Consumption	40W
Dimensions (W x H x D)	18.9 in x 15 in x 7.87 in (approx.)
	480 mm x 380 mm x 200 mm (approx.)
Weight	18.15 lbs (approx.)
	8.25 kg (approx.)

AMPLIFIER

Output Power	5 W + 5 W
Frequency Response	60 to 20,000 Hz

SPEAKER SYSTEM

Type	2-way
Impedance	8 ohms
Input Power	Max.6W

FM RADIO

Range	88 to 108 MHz
-------------	---------------

CD PLAYER

Frequency Response	60 to 20,000 Hz +/-4 dB
Signal-to-Noise Ratio	55 dB (IEC-A)

CASSETTE PLAYER

Track System	4 Track, 2 channel stereo
Tape Speed	4.8 cm/sec
Wow and Flutter	0.4% (WRMS)
Frequency Response	125 to 6300 Hz +/-6 dB

RECORD PLAYER

Motor	DC servo motor
Drive System	Belt Drive
Speeds	33-1/3rpm, 45 rpm and 78 rpm
S/N Ratio	More than 50 dB
Cartridge Type	Ceramic Stereo Cartridge
Stylus	ITNP-LC1

BLUETOOTH

Bluetooth Version	Bluetooth V4.2
Bluetooth Profiles	A2DP, AVRCP
Bluetooth Frequency range	2.402GHz-2.480GHz
Operating Distance	10 meters
The maximum RF Power	10dBm

USB

Type	USB series B connector
Recording	USB record from vinyl record, CD/CD-MP3, Cassette, AUX, and Bluetooth.
Full-Speed	USB 2.0 full speed

Troubleshooting Guide

	Symptom	Possible Cause	Solution
GENERAL	• Unit will not power on.	• Unit is unplugged.	• Connect the unit to the AC power supply.
	• No sound output from speakers.	• The volume level is set too low. • The input selector does not match the playback source.	• Adjust the volume. • Select the correct input source.
	• Noise/Distortion in sound output.	• The unit is too close to a TV set or another interfering device.	• Turn off the TV or other appliance, and relocate the unit.
	• Unit fails to respond.	• It might result from external factors such as ESD (Electro-static discharge).	• Disconnect the power cord and external audio device. Re-plug the power cord after one minute.
TAPE	• The tape does not play.	• The cassette tape is not inserted properly. • The tape has reached the end.	• Insert the cassette tape correctly. • Flip the cassette.
FM RADIO	• Cannot listen to any station, or signal appears weak.	• The station is not tuned-in properly. • A TV set is being used nearby and is interfering with the radio reception.	• Properly tune-in the desired station. • Turn-off the interfering TV set.
	• The sound is distorted.	• The antenna is not oriented properly.	• Re-orient the antenna until reception improves.
CD PLAYER	• CD stops immediately after starting, or unit pauses or stops during play.	• The CD is inserted upside down. • The CD is dusty or dirty or there is condensation on the CD.	• Insert the CD with the printed side right-side up. • Carefully clean and dry the CD.
	• No sound.	• The CD player is paused.	• Press the PLAY/PAUSE button.
	• CD playback is noisy, or playback stops or skips.	• The CD is scratched, damaged or warped. • The disc is very dirty.	• Replace CD with an undamaged one. • Carefully clean the CD.
	• CD tray will not open.	• FM/USB/BLEETOOTH/AUX/PHONO/TAPE mode is selected.	• Select CD mode.
	• Buttons are not functioning correctly.	• The unit is processing information ("--- Busy" is displayed). • The unit needs to be restarted.	• Wait until the unit finishes processing. • Turn the unit off, then on again.
PHONO	• Decline in turntable audio performance.	• The turntable stylus is worn out.	• Replace the stylus.

AUX	No sound output with external audio device plugged into AUX in jack.	The unit is not on AUX mode.	Ensure the unit is switched to AUX mode.
Bluetooth	No sound.	- The unit is not switch to Bluetooth mode. - Your device's and/or the unit's volume not turn up. - Your device is too far from the unit or there're some obstacle between your device and the unit.	- Ensure the unit is switched to BT mode. - Move your Bluetooth device closer to unit. - Turn up the volume on your portable device and/or the unit. - Turn off your Bluetooth device and unit then power them both back on.
	Sound is garbled.	Your device's and/or the unit's volume not adjust properly.	Turn down the volume on your device/phone and the unit.
	Unable to pair with a Bluetooth device.	- Your device doesn't have Bluetooth connectivity. - The Bluetooth pairing is not successful.	- Confirm that your device is Bluetooth compatible. - Repair the unit and device again.
USB	The USB drive does not play.	- The USB drive is not inserted properly. - The USB drive has no MP3 file.	Insert the USB drive correctly.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

IC Statement

This device complies with RSS247 of Industry Canada. Cet appareil se conforme à RSS247 de Canada d'Industrie. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

The device must not be co-located or operating in conjunction with any other antenna or transmitter. L'appareil ne doit pas être localisé ou fonctionner avec d'autres antennes ou transmetteurs. This device complies with IC radiation exposure limits set forth for an uncontrolled environment. Cet appareil est conforme aux limites d'exposition aux rayonnements de la IC établies pour un incontrôlé environnement.

The device should be installed and operated with a minimum distance of 20cm between the radiator and your body. L'appareil doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.

California PROP 65 Warning



WARNING: This product can expose you to chemicals including lead which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.