

EN USER INSTRUCTIONS

Twintalker

PIC 01

1

PIC 02

2

EN~ Instructions for use

This set includes 2 walkie-talkie units: these are communication devices which operate on mobile radio frequencies. They come with 22(option) channels as well as a back-lit LCD screen, enabling you to communicate over several kilometres free-of-charge (up to 3 km in open areas)



NOTE: Please read these user instructions carefully before using the equipment and retain for future consultation!

SPECIFIC RECOMMENDATIONS

- If you carry any kind of personal medical device, consult a doctor before use.
- To avoid the risk of burns, do not use the device if the aerial is damaged in any way.
- Do not use the device in a potentially explosive setting (e.g. around petrol pumps, on the lower deck of a boat or around a fuel storage installation or chemical products)
- If travelling in a car or by bike, stop before using the device. Switch off the device if on an aeroplane or in a hospital.
- Never use the device in close proximity to a radio to avoid interference.
- Remove the batteries if the device is not in use for an extended period of time. Never mix used and new batteries.
- Position the transmitter and antenna at least 5 cm from your face. Direct the antenna upwards and speak normally.
- Clean the device with a damp cloth. Avoid the use of cleaning agents and solvents.
- Do not modify the device in any way. In the event of damage occurring, ensure that the device is checked by a qualified professional.
- The device cannot be used to contact the emergency services.

3

ITEM DESCRIPTION (Pic 01, 02)

1. Antenna
2. RX icon  - Displayed when receiving
- TX icon  - Displayed when transmitting
3. Volume level indicator
4. Adjustor button Up (▲)
5. Continued reception (MON)
6. On / off button (⓪)
7. Adjustor button Down (▼)
8. Earphone socket
9. Loud speaker
10. Microphone
11. Menu
 - Enter the menu settings
12. Call button (CALL)
13. Keypad lock indicator
14. Battery level indicator
15. Push to talk (TALK) button
16. VOX indication
 - Displayed during scan mode
18. Channel / Menu item indication
19. CTCSS / Menu option - value
20. Lamp Button
21. Scan Button
22. Lamp
23. Belt attachment clip
24. Belt attachment
25. Batteries (not supplied)
26. Battery compartment

4

BEFORE USE (Pic 02)

To insert batteries into the devices, first remove the belt attachment: lift the attachment clip (23) and press the belt attachment upwards (24).

Open the battery compartment (26) and insert 4 AAA batteries (25) (not supplied), ensuring that the poles are correctly aligned. Then close the lid.

USING THE TWINTALKER





1. Turning the device on/off: To turn the devices on or off, hold down the on/off button (6) for 3 seconds a BEEP sound will be played to confirm.

2. Adjusting the volume: To increase the volume, press the Up adjustor button ▲ (4) and press the Down ▼ (7) button to decrease volume.

Note: The volume level (3) is displayed on the screen.

3. Battery Charge Level / Low Battery Indication

The battery charge level is indicated by the number of squares present inside the battery icon on the LCD Screen.

-  Battery Full
-  Battery 2/3 charged
-  Battery 1/3 charged
-  Battery empty

When the battery charge level is low, the battery icon will flash and a beep will be heard to indicate that the batteries need to be replaced or recharged.

5

4. Receiving/transmitting communications:

The devices are in 'Reception' mode when lit up, i.e. they are ready to receive a call or sound transmitted on the activated frequency.

· When you press the Call tone button (12), the device switches to 'Transmission' mode. You are then transmitting a sound signal to the other device.

· To send a voice message, press the TALK button (15) and speak into the microphone (10). Continue to press the button until you have finished transmitting your message.

Hold the microphone a minimum of 5 cm from your face.

Note:

- The other device must be set to the same channel and have set the same CTCSS code (see point 7)
- When the transmission is complete and the TALK button (15) is no longer held down, the other device will emit a sound (BEEP) to indicate that this device is ready to transmit.

5. Changing Channels

- Press the MENU button (11) once, the current channel number flashes on the display.
- Press the ▲ button (4) or the ▼ button (7) to change the channel.
- Press the TALK - button to (15) confirm and return to stand-by Mode.

Note: If no button is pressed within 15 seconds during setting, the unit will return to standby.

6. CTCSS (Continuous Tone Coded Squelch System)

License free radio's operating on the 400~470 MHz frequency band, like the Twintalker, have 8/20/22 available radio channels. If there are many radio's users in your neighborhood, there is a chance that

6