

# Technical Manual Board Computer Model MAG-100R



## Sumário

1.	Mechanic Characteristic.....	4
1.1.	Technical Characteristic.....	4
1.2.	GPRS, 3G Communication.....	4
1.3.	Characteristics.....	5
1.4.	Data Transmission:.....	5
1.5.	Communication XBEE.....	6
1.6.	Characteristics:.....	7
1.7.	Characteristics of the XBee 900-HPS3B for Peru.....	7
1.8.	Data Transmission.....	8
1.9.	Transmission Power:.....	8
1.10.	GPS MODULE MADE BY UBLOX.....	9
2.	MAG-100 Transshipment Configuration.....	11
2.1	APK sCBConfigMag100R.....	11
1.1.1.	Open sCBConfig app.....	11
1.1.2.	Configuring type of equipment.....	12
1.1.3.	Transshipment Parameters Configuration.....	14
1.1.4.	Standard Setting:.....	15
1.1.5.	Configuration Step-by-Step:.....	15
1.1.6.	RPM Factor Settings.....	20
1.1.7.	Signal test screen.....	21
1.1.8.	CAN BUS screen.....	23
1.1.9.	Download Contingency Option.....	25
3.	APK sCB Transshipment.....	26
1.11.	sCBTransshipment App.....	26
1.12.	Importing Registers.....	28
1.13.	Configuring the Operational Parameters of the Transshipment.....	29
1.14.	Configuration of the Work shifts.....	30
1.15.	Zigbee Communication Test.....	31
1.16.	Import Records.....	31
1.17.	Load Map.....	32
1.18.	Request release code.....	33
1.19.	Enable go-return.....	34
1.20.	Save commands in log.....	34
1.21.	CDT Planting.....	35
1.22.	Active FLOW.....	35
1.23.	CDT active.....	36

1.24.	Basket type .....	37
1.25.	Enter Implements .....	37
1.26.	Allow access to Tire Screen .....	38
1.27.	Maximum number of digits on a trailer.....	38
1.28.	Max. Trailers GR .....	38
1.29.	Exit the application .....	39
4.	Transshipment Firmware Configuration .....	40
4.1	Parameters of the Transshipment Firmware Configuration .....	40
5.	Transshipment records registration.....	44
4.1	Formatting the records on the transshipment memory card CF.....	44
5.2	File Register to the Transshipment APK.....	47
5.3	Update of the files registered on the tablet using a flash drive. ....	50
6.	Commands used on the Transshipment remote update .....	52
6.1	Parameters that can be updated remotely on the transshipment .....	52

## 1. Mechanic Characteristic

### 1.1. Technical Characteristic

<b>Width (mm) x height (mm) x comprimento (mm)</b>	<b>73 mm x 33 mm x 165 mm</b>
<b>Box material</b>	<b>ABS (plastic)</b>

- a) Feeding\_of 12 – 35 volts
- b) Four digital input 0-30 volts
- c) Two digital output 0-30 volts
- d) Three analogue input 0-10 volts,4-20 mA
- e) Two pulse input (RPM and pulse)
- f) One serial port (RS 232)
- g) GRPS,3G Communication
- h) Communication Zigbee (mesh net) 7 km/ 35 km (optional)
- i) Communication Bluetooth (optional)
- j) Optional – Canbus parameters reading (it depends on the vehicle model)
- k) Global Positioning System (GPS)
- l) Removable storage system (Intern Compact flash, up to 2gb)
- m) IP66

The Mag100R has an internal battery (optional), that works as a backup, with a minimum autonomy of 2 working hours, if it were unplugged from the main battery. It is important to highlight that; this machine is out of the operator's range and all the antennas are external.

<b>Storage Temperature</b>	<b>0 - 50°</b>
<b>Relative Humidity</b>	<b>5 – 85%</b>

### 1.2. GPRS, 3G Communication



Figure 1 - Module HE910 - D

Module HE910-D Made by TELIT.  
Address: Via Stazione di Prosecco, 5/B, I-34010 Sgonico(Trieste), Italy,  
Zip Code: 34010

Telephone: +39 040 4192, Fax: +39 040 4192 333  
Information Contact and technical assistance.  
TS-EMEA@telit.com  
TS-AMERICAS@telit.com  
TS-APAC@telit.com  
TS-SRD@telit.com  
Alternative Use: <http://www.telit.com/support>  
Official Page: <http://www.telit.com>

### 1.3. Characteristics

- 4 range GSM/GPRS/EDGE: 850/900/1800/1900MHz
- 3 range UTMS/HSPA: 850/900/2100MHz
- WCDMA Multi-band (I, II, IV, V, VI, VIII and XIX)
- HSDPA up to 21.0Mbps (high range; up to 7.2 Mbps for other)
- HSUPA up to 5.76Mbps
- WCDMA 384kbps downlink/uplink
- DTM (double transfer module)
- Reception Diversity, tipo3i Interference Canceling Receptor
- CPC (DRX/DTX) (Continuous package connection)
- Control using AT according with 3GPP TS27.005, 27.007 and other Telit modules.
- Multiplexed serial port 3GPP TS27.010
- SIM card interface 1.8/3V (Automatic detection 3GPP TS 51.014)

#### Power Consumption (Conventional Values)

- Quiescent current -by 2G, DRX5, 1.1 mA
- Stand-by current- 3G, DRX7, 1.2 mA

#### Transmission Power:

- Class 4 (2W) @ 850 / 900 MHz, GSM
- Class 1 (1W) @ 1800 / 1900 MHz, GSM
- Class E2 (0.5W) @ 850/900 MHz, EDGE
- Class E2 (0.4W) @ 1800/1900 MHz, EDGE
- Class 3 (0.25W) @ 850/900/1700/1900/2100 MHz

#### Sensitivity Reception:

- GSM 850/900MHz - 109 dBm
- GSM 1800/1900MHz - 110 dBm
- WCDMA 850/900/1700/1900MHz - 111 dBm

### 1.4. Data Transmission:

- HSPA: category 14 in downlink and category 6 in uplink
- DL to 21.0Mbps
- UL to 5.76Mbps
- WCDMA: to 384kbps downlink/uplink
- EDGE: DL to 296kbps, UL to 236.8kbps
- GPRS: DL to 107kbps, UL to 85.6kbps
- GPRS class 10 to Global and variables NAX; class 33 for variables EUx
- EDGE class 10 for Global and variables NAX; class 33 for variables EUx

- Not transparent asynchronous CSD up to 9.6kbps
- Code outline from 1 to 4 (GPRS) and codification outline module from 1 to 9 (EDGE)

Antenna Perform	
Frequency	880 – 1600 mhz
Efficiency	82%
Impedance	50 ohm
Irradiation	Omnidirectional
Polarization	Lineal
Temperature of the Operation	0 - 85°

FCC ID: RI7 HE910  
 FCC REGISTER NUMBER (FRN): 0020384608

### 1.5. Communication XBEE



Figure 2 - Module XBEE-PRO S3B

Module XBEE-PRO 900HP S3B Made by Digi International.  
 Address: 11001 Bren Road East  
 Minnetonka, MN 55343  
 Telephone: 1-877-912-3444  
 Telephone :952-912-3444  
 Fax: 952-912-4952  
 Technical Support.  
 Telephones: (866) 765-9885 toll-free U.S.A and Canada  
 (801) 765-9885 Worldwide  
 Online Support: [www.digi.com/support](http://www.digi.com/support)  
 Email: [tech.support@digi.com](mailto:tech.support@digi.com)

The RF Xbee-pro 900HP is ideal for smaller power consumption, from point to multipoint on low latency net application. It is used on peer to peer and net from point to multiple point. The XBee-900 module has a higher selectable transmission power of 250 mW. This higher Tx power allows a line-of-sight range up to 28 miles with antenna right. This one is ideal for situations in which the RF penetration and absolute transmission distance are of extreme importance for the implementation.

As part of the RF XBee line, this module is easy to use, includes drop-in gateways nets, and uses Digi and Adapters. The RF does not need any out-of-the-box configuration and any necessary advance configuration can be replaced with simple commands.

### 1.6. Characteristics:

Processor: transceiver ADF7023, Cortex-M3 EFM32G230 @ 28 MHz

Includes Programmable: Freescale MC9S08QE32

Frequency range: 902 to 928 MHz, selectable software for the interference resistance.

Frequency Intervals, Power and Type of Modulation

Frequency Interval (MHz)	Tx	Output Maximum Power (W)	Emission Designation	Technology	Type of Modulation
920.0 928.0	a	0.23878	290KF7D	LEAP IN FREQUENCY	FSK
902.0 907.5	a	0.20701	255KF7D	LEAP IN FREQUENCY	FSK
902.0 907.5	a	0.24266	360KF7D	LEAP IN FREQUENCY	FSK
915.0 928.0	a	0.20701	255KF7D	LEAP IN FREQUENCY	FSK
915.0 928.0	a	0.24266	360KF7D	LEAP IN FREQUENCY	FSK

In the specific case of Peru, the modules were configured to work on a 915,5 a 927,7 MHz frequency, setting the **cm** register (Channel Mask) with a value of **FFFFFFFFE00000000**, that same value is defined during the production of mag-100R and it is storage on the inter flash of the XBee 900-HP.

The starting process of the Mag-100R is configured following the next steps. If the XBee 900-HP radio module is changed, then the correct configuration is ensured.

### 1.7. Characteristics of the XBee 900-HPS3B for Peru

- Working Frequency: 915.5 MHz to 927.7 MHz
- Channels: 31
- Main Frequency of the main channel: 915.600 MHz
- Channel division: 400 kHz

- Transmission range length: 200 kHz
- Modulation: GFSK
- Channel Leap: Yes (pseudo-random)
- Maximum Power Transmission: 24 dBm (250 mW)
- Baudrate on the air: 200 kbps
- Sensitivity: -101 dBm

### 1.8. Data Transmission

- Data Speed: RF: 10 Kbps o 200 Kbps
- Interior/Urban range: 10 Kbps: to 2000 feet (610 m); 200 Kbps: to 1000 feet (305 m), outdoor/Line-Of-Sight Range: 10 Kbps: to 9 miles (14 km); 200 Kbps: to 4 miles (6.5 km) (w/2.1 dipole antenna dB)

### 1.9. Transmission Power:

- to 24 dBm (250 mW) selectable by software

Receptor Sensitivity:

- -101 dBm a 200 Kbps,
- -110 dBm a 10 Kbps

Interface

- Data Interface: UART (3 V), SPI
- GPIO: to 15 E/S Digital, 4 adc input of \$ number bits, 2 PWM outputs
- Network Topology: DigiMesh, repeater, point to point, peer to Multipoint, Peer-to-Peer
- Spread Spectrum: FHSS (Selectable Channel Software)

Program Capacity

- memory: N/A 32 KB
- CPU/Clock Speed: N/A

Feeding Tension

Feeding Tension 2.1 a 3.6 V CC C

Current in transmission 215 mA typical (290 mA max)

Current in reception 29 mA typical a 3.3V (35 mA max)

Current Sleep 2.5 uA typical

Temperature on the Operation -40 °C to 85 ° C (industrial)

Physical Property

Weight: de 5 a 8 g depending on the antenna option

Size: 3.3 cm x 2.5 cm (4.5x2.5 cm with connector)

Antenna Performance	
<b>VSWR</b>	<= 2,0 : 1
<b>Maximum Power</b>	20 Watts
<b>Impedance</b>	50 ohm
<b>Irradiation</b>	Omnidirectional
<b>Earnings</b>	6 dBi

Homologated by countries:

Country	Approved
United States (FCC Part 15.247)	MCQ-XB900HP
Industry Canada (IC)	1846A-XB900HP
Australia	RCM
Brazil	ANATEL 3727-12-1209
Singapore	License No. DA105737 (XB900HP only)
Mexico	IFETEL (XB900HP only)
RoHS2	Compliant

FCC ID: MCQ-XBPS3B  
FCC REGISTER NUMBER(FRN): 0010283307

#### 1.10. GPS MODULE MADE BY UBLOX



Figure 3 - LEA-6S Module

Model LEA-6S

Contacts

HQ Switzerland: +41 44 722 7444 [info@u-blox.com](mailto:info@u-blox.com)

America +1 703 483 3180 [info\\_us@u-blox.com](mailto:info_us@u-blox.com)

APAC – Singapore +65 6734 3811 [info\\_ap@u-blox.com](mailto:info_ap@u-blox.com)

China +86 10 68 133 545 [info\\_cn@u-blox.com](mailto:info_cn@u-blox.com)

Taiwan +886 2 2657 1090 [info\\_tw@u-blox.com](mailto:info_tw@u-blox.com)

- U-blox 6 position engine:
  - Navigate up to-162 dBm and-148 dBm coldstart
  - Faster Acquisition with AssistNow Autonomous

- Configurable energy Management
- Hybrid gps/sbas (waas, egnos, msas)
- Anti-jamming Technology
- Simple Integration with unwired u-blox modules
- A-gps: AssistNow ON-LINE and off-line AssistNow services, OMA SUPL compliant
- Compatible (hardware and firmware); easy migration to LEA-5 or LEA-4 family
- LCC package for trustable manufacture and effective cost
- Compatible with u-blox GPS for Android
- Based on the GNSS chips qualified according to the aec-q100
- Made on iso/ts 16949 production facility
- Qualified according to ISO 16750

Hot starting and initial auxiliary position for the first time in less than a second.

Tracking capture and sensitivity of 160dBm

Kickstart function, the model can attain an acceleration when the signal level is low at the beginning.

GPS, Galileo, SBAS (WAAS and EGNOS and MSAS, and GAGAN) hybrid motor  
4 Hz update range of the position.

Receptor with 50 channels, frequency L1 code C/A (1575 MHz).

Search sensitivity during navigation -162 dBm

Reacquisition sensitivity -160 dBm

Sensitivity on the cold starting without help -148 dBm.

Maximum Updating interval during navigation 5 Hz

Horizontal Position of without help precision 2,5 m e SBAS 2 m

Configurable interval frequency of leap-time 0,25 Hz a 1 kHz

Speed Precision 0,1 m/s

Orientation Precision 0,5 degrees

Operational Limits: Dynamic  $\leq 4$  g, Altitude 50,000 m , speed 500 m/s

Source tension 2.7 V – 3.6 V

Consumption of continuous potency 121 mW.

Consumption of potency on Save mode 36 mW.

Support of Antenna active and passive.

Serial Interface: 1 UART, 1 USB V2.0 full speed 12 Mbit/s, 1 DDC (I2 C compliant)


<b>Antenna Performance</b>	
<b>Impedence</b>	50 ohm
<b>Central Frequency</b>	1575.42 mhz
<b>Range length</b>	10 mhz
<b>Earnings</b>	27 db
<b>Mitigation for output filter range (db)</b>	Dielectric fo = 1575.42 mhz 7 typ. Fo +/- 20 mhz 20 typ. Fo +/- 50 mhz 30 typ. Fo +/- 100 mhz
<b>Power Consumption</b>	10 mA (max)

## 2. MAG-100 Transshipment Configuration.

### 2.1 APK sCBConfigMag100R


#### 1.1.1. Open sCBConfig app.

The sCBConfig app is used for the initial configurations of the MAG100 in any machine. On this document, it is explained the configuration process of the Transshipment.




First, it must be selected the sCBConfigMag app.

#### Opening of the configuration serial port




Each item on the screen will be explained one by one with all its functionalities. The configuration main screen by default has no machine configured and has the serial port closed:

To enable the serial port, it is necessary to click on the “**MENU**”. After, that a tab will appear on the lower part of the screen with the option of “**Configuration**”.




Once the Configuration option is selected, a portal serial tab will appear on the screen. Then, it is important to enter the valid address which is `(/dev/ttyS1)` and select the option “**OPEN**”. To return to the main screen click the “**BACK**” or “**HOME**” bottom




### 1.1.2. Configuring type of equipment


The first step on the configuration of the computer on board, it is to specify the type of equipment used on the option “**Type of Equipment**”.



In this case, the equipment will be "Transshipment"



### 1.1.3. Transshipment Parameters Configuration





After that, the app will return immediately to the main screen. Then, the equipment can be configured

The desired setting can be selected:


**Standard:** There is complete freedom to change the parameters.

**Step-by-Step:** It will be changed a field at a time, on the following order.




#### 1.1.4. Standard Setting:

This option gives more liberty on the field selection. The desired option can be selected at any time and the virtual keyboard will appear to enter the data. To move around on the screen, it is just a matter of sliding the finger.



#### 1.1.5. Configuration Step-by-Step:

In this case, it must be configured field by field following the order on the screen and changing them using the arrow highlighted on the image:



After that, it is necessary to make some changes which are explained in detail:

←
🏠
🌐 Configuration Transshipment
☰ Menu

## Transshipment

Number of equipment:	<input type="text" value="1234"/>	
Hodometer/Hour Meter:	<input type="text" value="85446.2"/>	km or h
Motor signal:	<input checked="" type="radio"/> RPM <input type="radio"/> Digital input	
Type modem GPRS:	<input type="radio"/> G24 <input type="radio"/> G30 <input type="radio"/> GL865 <input checked="" type="radio"/> HE910	
Factor rpm:	<input type="text" value="10"/>	
Time monitoring sending:	<input type="text" value="300"/>	seconds
Distance to send monitoring:	<input type="text" value="500"/>	meters
IP server GPRS:	<input type="text" value="121.215.241.199"/>	
Server port GPRS:	<input type="text" value="60021"/>	
Operator GPRS:	vivo ▼	
Maximum speed alarm:	<input type="text" value="110"/>	km/h
Maximum RPM alarm:	<input type="text" value="1800"/>	rpm
Stopped time:	<input type="text" value="90"/>	seconds
Can bus:	<input checked="" type="radio"/> not active <input type="radio"/> active	
Kind of box:	1 large box ▼	
Tipping sign:	<input type="radio"/> It has separate signal <input checked="" type="radio"/> It has no separate signal	
RPM tilting:	<input type="text" value="2000"/>	rpm
Capacity per box:	<input type="text" value="21"/>	tons
Cutting group:	<input type="text" value="3"/>	
Serial number:	<input type="text" value="123456"/>	
Patrimony:	<input type="text" value="123456"/>	
Maximum RPM on stopped:	<input type="text" value="1800"/>	rpm
Maximum RPM on tipping:	<input type="text" value="1800"/>	rpm
Model:	Case Puma 1xx ▼	

SAVE
LOAD SETTINGS
SEND

## Description of Fields


<b>Machine Number</b>	<b>Machine number registered by the farm.</b>
<b>Odometer/Hour Meter</b>	Odometer and Hour Meter (depends on the machine) usually on the transshipment panel analyzed by the CAN BUS network.
<b>Engine Signal</b>	RPM: Engine signal is measured by the alternator or the CAN BUS network. Digital Input: The engine signal is measured by the ignition point or (fixed RPM).
<b>Type of Modem</b>	Specify the type of hardware used (modem GPRS).
<b>RPM Factor</b>	It will be configured afterwards
<b>Monitoring Sending Time</b>	Time measured in seconds for the register of the monitoring.
<b>Monitoring Sending Distance</b>	Distance in meters for the register of the monitoring
<b>IP server GPRS</b>	IP of the server that will receive the CB info.
<b>Server Port GPRS</b>	The server port will receive the CB info.
<b>GPRS Operator</b>	Operator of the SIM card used on the transmission of the CB info.
<b>Maximum Speed Alarm</b>	If the Maximum speed is exceeded an alarm is generated and registered.
<b>RPM maximum alarm</b>	If the maximum RPM speed is exceeded an alarm is generated and registered.
<b>Stop Time</b>	If the Maximum time is exceeded, it will ask for a code with the reason of the stop.
<b>Can bus</b>	It enables or disables de Can Bus network.
<b>Type of truck *</b>	No configured 1 small truck box 2 small truck boxes 3 small truck boxes 1 big truck box 2 big truck boxes 3 big truck boxes Small together Big together 2 middle truck boxes 2 extra big truck box
<b>Overturning Signal</b>	There is or not case selection (overturning signal)
<b>Truck bed Capacity</b>	Case capacity in ton.
<b>Harvesting Code</b>	Harvesting team machine code.
<b>Serial number</b>	Serial number fixed on the computer on board by Solinftec
<b>Assets</b>	Identity number of the computer on board fixed by the client
<b>Maximum RPM Stop</b>	Maximum RPM allowed to the machine when there is no speed
<b>Maximum overturning RPM</b>	Maximum RPM allowed to machine during overturning

## Fields configuration detail


<b>Case Type*</b>	<b>Distance between the GPS antenna and the center of the 1<sup>st</sup> truck crate</b>	<b>Distance between the GPS antenna and the center of the 2<sup>nd</sup> truck crate</b>	<b>Distance between the GPS antenna and the center of the 3<sup>rd</sup> truck crate</b>
-------------------	--	--	--

1 small crate	3.7 meter		
2 small crates	3.7 meter	7 meters	
3 small crates	3.7 meter	7meters	12.5 meter
1 large crate	7 meters		
2 large crates	5.5 meter	12 meters	
3 large crates	5.5 meter	12 meters	22.5 meter
Small Attached	3.7 meter	7 meters	
Large Attached	5.5 meter	12 meters	
2 medium truck	4.2 meter	10.8 meter	
2 extra-large truck crates	6.3 meter	13.3 meter	


After clicking on the option Save, the following confirmation message will appear:  
 Indicating that it is necessary to fill all the fields before saving the settings




If settings were previously saved on the S7 tablet, those can be loaded on the option “**Loading Settings**”



Then, it is necessary to send such data to the MAG100 computer on board using the option **Send**.




After that, the user must return to the main screen using the bottoms return or home




#### 1.1.6. RPM Factor Settings


The option **RPM Configuration** allows to calibrate the RPM measurements by means of the RPM Factor:



Only equipment without Can Bus net reading need de RPM calibration. Once selected the field rpm factor, a virtual keyboard will appear to make the necessary value changes:




Once the info is saved, the next screen will appear confirming the previous action.



### 1.1.7. Signal test screen


The option **test screen** allows to see the state of the equipment, as well as the value of all the measurements made by the computer on board and the status of it peripherals



### Test Screen Description


Computer on Board	
<b>Machine Number:</b>	Number of the machine configured.
<b>Odometer/Hours meter:</b>	The odometer and hours meter configured on the CAN BUS.
<b>Speed:</b>	Equipment speed.
<b>RPM:</b>	Actual RPM of the equipment measured by the computer on board, by the CAN BUS net.
<b>Status:</b>	Actual status of the machine: F: Stopped C: Harvest  M: Maneuver D: Moving
<b>CF card:</b>	Actual state of memory card Compact Flash: Error or OK.
ENTRYS	
<b>Digital Input:</b>	Digital Input activated by the computer on board (0000 → ED1, ED2, ED3, ED4).
<b>Pulse Input:</b>	Pulse input values (00 → EP1, EP2).
<b>External Input:</b>	Feed.
<b>Analogue 1:</b>	Value measured by the computer on board on the EA1.
<b>Analogue 2:</b>	Value measured by the computer on board on the EA2.
<b>Analogue 3:</b>	Value measured by the computer on board on the EA3.
GPS	
<b>GSP valid:</b>	Actual GPS – Valid or not valid
<b>Latitude:</b>	Equipment Actual Latitude.
<b>Longitude:</b>	Actual Longitude of the equipment.
MODEM GPRS	
<b>Status:</b>	It shows the status of the connectivity process of the modem GPRS (0 – 11).

<b>Message:</b>	7 (MAG200, RECOK, ALOHA): Modem connected on the monitoring system. 6 (ERROR) IP and/or wrong Input or communication problem with the server. 5 (ERROR) Problem with the signal connection with the operator. 1 (ERROR) Problem with the SIM card.
<b>Monitoring time:</b>	Time spent since the last monitoring register.
<b>Monitoring Distance:</b>	Distance travelled since the last monitoring register.
<b>Aloha Time:</b>	Time spent since the last communication with the server.
<b>Alarms:</b>	Alarms actives on the computer on board.




### 1.1.8. CAN BUS screen

Option “can bus screen” allows to access the screens with all the info of the Can Bus net, as long as that option is active on the equipment settings.




To return to the main screen, you can select the home bottom and the back option.




### 1.1.9. Download Contingency Option


On this option the appointment and monitoring info is downloaded from the CF memory card into a flash drive on the tablet.



If there is no flash drive the system will display the following warning:




If the flash drive is on the tablet after the info is downloaded the following text will appear:




#### Closing of the Setting Serial Port

After the configuration process is finished, it is necessary to close the APK sCBConfig communication port. This process can be done on the main screen **Menu/Configuration**.



To exit the app used the back bottom.




### 3. APK sCB Transshipment

#### 1.11. sCBTransshipment App


The sCBTransshipment app is used on to register and monitor using the MAG 100. In this part of the document, it will be explained in detail the transshipment configuration process.

The first step is to open the app:




### Opening the MAG100 communication serial port


The first time the app is opened there will appear a warning, of the serial port being closed, on the main screen. In order to open it, you must click on the “**MENU**” , “**Configuration**” option.



For security reasons, the configuration process has a password only known by those authorized to configure the computer on board:




After introducing the password select the open bottom and the correct serial port will appear as a pre-established (**/dev/ttyS1**):



### 1.12. Importing Registers

Once the serial port is opened, the files registered and saved on the tablet on the file "**data/Trabalho/Cadastrros**" will be imported automatically




If there is any change on the register files saved on the tablet, it will be necessary to select the option import records without any need of opening the serial port again. If there is any file missing during this process the following message will appear.




In this case, follow the steps on the option **“Updating the register files on the tablet”**

### 1.13. Configuring the Operational Parameters of the Transshipment.

Some of the configurations done on the app **sCBCConfig** can be seen and modified on this app on the option **“General”**




The **General** option will show the machine code, the GPRS operator, the monitoring time among other info that cannot be changed. Other modifiable parameters such as, minimum and maximum speed and RPM stop time will appear on this option. Whenever a modifiable field is activated the virtual keyboard will appear. All modification must be saved using the corresponding option: **“Save”**




#### 1.14. Configuration of the Work shifts

The transshipment option will allow to alter the configuration of item such as TAG's type of crate, lifting signal, crates and cutting capacity as well as configuring the crates with or without password.




### 1.15. Zigbee Communication Test

The option “Zigbee Communication” allows to test the Zigbee on the computer on board. Once it is selected, a communication internal test is done. If the test is successful, the message “**Zigbee Communication Ok**” will appear. If the message to appear were “**Zigbee Communication Fail**” the CB must be sent to maintenance.



### 1.16. Import Records


This option imports the registers saved on the tablet on the file “**data/Trabalho/Cadastrros**”. If there is any change on these files saved on the tablet, it is necessary to select this option to enable the changes. After that, the message “**Records imported successfully**” will appear.




If there is any record missing on the import process the following message will appear “**Records not found on file /data/Trabalho/Cadastrros**”: If this were the case, the steps on section “**Update the records registered on the tablet**” must be followed.

### 1.17. Load Map

This option loads on the APK transshipment main screen the harvesting area maps supplied by the farm and saved on the file “**data/Trabalho/Mapas**”.



Once this option is selected, on the **Menu /Option Map** on the main screen of the Transshipment will appear the harvesting area map of the farm




When this option is not selected, then it will return to the main screen of the Transshipment APK and will show the Solinftec logo:




### 1.18. Request release code

This option is active on any contingency measure. For example, if a transshipment doesn't detect the harvester the computer on board will request the cut order of the harvest.




### 1.19. Enable go-return

This option is used to the transshipment to send information to the coordinator. If the firmware or the “Transshipment coordinator” item0 is active, then this option will also activate the transshipment to act as a coordinator, in case of the CDC:




### 1.20. Save commands in log

In this case, all the commands given will be saved for further analysis using USB cable.




### 1.21. CDT Planting


Using this option, the planting features will be activated, if the firmware allows it to



### 1.22. Active FLOW



A confirmation check box will appear whenever this option is activated.





### 1.23. CDT active

A confirmation check box will appear whenever this option is activated.




### 1.24. Basket type

This option allows to enter the **Crate Code** if necessary:




### 1.25. Enter Implements

This option enables to select any implement.




### 1.26. Allow access to Tire Screen

This option is currently on development, therefore, has not been activated on the transshipment:




### 1.27. Maximum number of digits on a trailer.

This option shows a range between 10 to 12 digits, depending on the farms configuration and the maximum number of trailers allowed.




### 1.28. Max. Trailers GR

This option shows the maximum number of trailers to be storage on the go- return option.



### 1.29. Exit the application

Through this option the Transshipment APK can be exit and access other apps installed on android.



Once this option is selected, you can return to the main screen of the transshipment App and exit the app using the bottom Return.



## 4. Transshipment Firmware Configuration

### 4.1 Parameters of the Transshipment Firmware Configuration

Every MAG 100 Transshipment firmware will be accompanied by the “**Config.txt**” file which has all the current settings of the firmware. In this section will be explained every parameter and its use on the computer on board.

TRANSSHIPMENT	
APP DESCRIPTION	
<b>MODOTESTE</b>	Defines the Firmware test mode. 0: Test Mode disable. 1: Test Mode activated (with the ED4 active, a fixed speed of (5Km/h) and RPM of 640 (Engine on).
<b>FUT</b>	Defines the activation of the FLOW app on Firmware. 0: FLOW app disables. 1: FLOW app active.
<b>ATIVACCT</b>	Defines the activation of the CDT app on the Firmware. 0: Applicative CDT disable (identifies the harvester and changes the status. It doesn't send lifting register ZIG22). 1: App CDT active
<b>ATIVACCTPLANTIO</b>	Defines the activation of the CCT PLANTING app on the Firmware. 0: CCT PLANTING APP disable. 1: CCT PLANTING APP active.
<b>SEMCOORD</b>	Defines the activation of the Transshipment Coordinator Function. 0: Disables the Transshipment Coordinator Function.

	1: Activates Transshipment Coordinator Function.
<b>CERCAELETRONICA</b>	Defines the activation of the Transshipment Electronic Fence. 0: Disables Transshipment Electronic Fence. 1: Activates Transshipment Electronic Fence. (file COORD_CERCAS).
<b>ATIVARRFID</b>	Defines the RFID usage activation. 0: Disables the RFID scanner. 1: Activates the RFID scanner.
<b>PRIORIZASOLINFNET</b>	Defines priority of the data traffic into the system. 0: Prioritizes the GPRS/3G mode for the data traffic. 1: Prioritizes the SOLINFNET for the data traffic.
<b>HARDWARE DESCRIPTION</b>	
<b>ENTRADAX7</b>	Defines the interface on the MAG100. 0: Interface by Bluetooth. 1: Interface on the S7 screen.
<b>VALIDAEMX7</b>	Defines the validation of the digital data. 0: Uses the CF register on the validation of the digital data. 1: Uses the S7 register on the validation of the digital data.
<b>LIMITAPULOS</b>	Configuration of the jumps on the registers send by the Zigbee. 0: Doesn't limit the number of jumps on the Zigbee net. 1: Limits on 2 the number of jumps of the Zigbee.
<b>TAGBASCULAMENTO</b>	Defines the activation of the Lifting Tag use. 0: Activates the lifting status of the crates on the digital input. 1: Activates the lifting status of the crates on the Lifting Tag.
<b>RPMPELACAN</b>	Defines the activation of the RPM Reading on the CAN net 0: Activates the RPM reading signal. 1: Activates the RPM reading signal on the CAN net
<b>HODOMHORIMCAN</b>	Defines the activation of the Odometer/Hour meter on the CAN net. 0: The Odometer/Hour meter info will be calculated by the CB. 1: Activates the Odometer/Hour meter Info Reading by the CAN net.
<b>RTKPORCX3</b>	Defines the activation of the RTK signal Reading of the crate 3 (pin 7/ED4). 0: Activates the lifting Reading signal of crate 3 on the digital input 4 (pin 7).

	1: Activates the RTK Reading signal on the digital entry 4 (pin 7).
<b>BAUDRATEZB</b>	Defines the communication speed with the ZIGBEE. 9600: Speed Pattern. 15200: Speed Test.
<b>OPERATION DESCRIPTION</b>	
<b>VALIDAIMPL</b>	Defines the validation of the digital implement codes on the register. 0: Doesn't validate the implement code on the file registered C_IMPLEMENTO. 1: Validates the implement code in the file registered C_IMPLEMENTO.
<b>VALIDAEQUP</b>	Defines the validation of the digital equipment codes on the register. 0: Doesn't validate the equipment code on the register C_EQUIP. 1: Validates the equipment code on the register C_EQUIP.
<b>PRIORIZAPARADA</b>	Activates the function that prioritizes the call of Harvesters on the FLOW app. 0: Transshipment doesn't prioritize the stopped harvesters on the FLOW calls. 1: Transshipments prioritize the stopped harvesters on the FLOW calls (identifier 17 on the zig call).
<b>GRUPOSFUT</b>	Activates the Group work function on the FLOW app. 0: Doesn't send coordinates to the ZIG 29. 1: Sends coordinates to the ZIG 29 to work on group only to harvesters with MAG100.
<b>DESLOCAC1T</b>	Activates the function maintain Harvester assigned with ZOG1T register on the FLOW app 0: Transshipment maintain Harvester assigned when receives the ZOG1T register of that harvester with a different transshipment. 1: Transshipment release the harvester assigned when it receives the ZIG1T from that harvester with a transshipment waiting.
<b>COLHEDORA300</b>	Defines the ZIG29 answer time on the FLOW app. 0: Harvester MAG100. 1: Changes the (zig29) answer time to the calling of the harvester, it sends ok to the zig 17.
<b>CARRETA12DIG</b>	Defines the number of digits of the codes on the crates. 0: Works with 10 digits crates codes. 1: Works with the 12 digits code crate.
<b>PREGQUANTOSQ</b>	Activates the lifted crates request on the FLOW app. 0: When the FLOW code is entered, it

	<p>doesn't ask: "How many crates were lifted.?"</p> <p>1: When the FLOW code is entered, it asks: "How many crates were lifted.?"</p>
<b>NOFUTDESLOCCARR</b>	<p>Defines the usage of the stop time "Transshipment Line".</p> <p>0: Enters on Transshipment Line on any condition the stop time code with identifiers is entered. ador "H".</p> <p>1: It doesn't enter on Transshipment Line when the stop time code identifies with and H if it was previously on moving for loading stage.</p>
<b>CORRIGEDATAHFUT</b>	<p>Data and time correction using FLOW.</p> <p>0: Doesn't correct date or time using FLOW.</p> <p>1: Corrects the date and time using FLOW.</p>
<b>DATALIMITEFUT</b>	<p>Defines the validity activation data on the FLOW app.</p> <p>0: The FLOW app will be active indefinitely.</p> <p>170720 (aammdd): The FLOW app will be active until July 20, 2017.</p>
<b>TPARADABASC</b>	<p>Defines the stop time of the lifting stage to ask for the stop time code (in seconds).</p> <p>180: When the transshipment passes the 180 second on lifting stop time, it asks for a stop time code.</p>
<b>NOBASCMANOBRA</b>	<p>Defines the possibility to enter on lifting state on the status of loading cane and maneuver.</p> <p>0: It sends records of the lifting process when loading cane and maneuver.</p> <p>1: It doesn't send lifting records on the status of Loading and Maneuver.</p>
<b>BASCLEVANTACX</b>	<p>It Defines a time filter to start the lifting status.</p> <p>0: Applies 5 seconds filter to start the lifting status when the crate is lifted.</p> <p>1: it starts the lifting status immediately when the crate is lifted.</p>
<b>LIMITABASC</b>	<p>Defines the lifting limit event for crate.</p> <p>0: It doesn't limit the lifting for crate.</p> <p>1: It limits the lifting for the selected crate.</p>
<b>NOCOLHEDCARREG</b>	<p>Defines the condition that recognizes the harvester.</p> <p>0: Recognizes the harvester without condition</p> <p>1: It doesn't recognize the first 5 minutes loading.</p>
<b>HODOMETRO</b>	<p>Defines the info to be send on the orometer and hour meter records.</p> <p>0: It sends the orometer kijos (standard).</p> <p>1: It sends hour meters kijos.</p>

<b>KIJOSCAN</b>	Defines the info system of the CAN net. 0: It doesn't send Can records even if it is active. 1: It sends records of the CAN.
<b>DEFINIÇÕES DE ALAMES</b>	
<b>TOCIOSO</b>	Defines the idle engine time (in seconds). 300: The engine must maintain the alarm condition for 300 consecutive second on stop state to generate the alarm.
<b>REDE ZIGBEE FIRMWARE</b>	
<b>REDEZBH</b>	High address of the e Zigbee (H).
<b>REDEZBL</b>	Low address of the Zigbee (L) net – All together with the high address form the Zigbee (HHLL).
<b>VERSÃO FIRMWARE</b>	
<b>VERSIONE</b>	Development year of the firmware version.
<b>VERSIOND</b>	Sequence of the firmware.
<b>OUTROS CULTIVOS</b>	
<b>MAPASANALITICOS</b>	
<b>CAMBIOCONDICAO</b>	
<b>RELATORIOPOR33</b>	

## 5. Transshipment records registration

### 4.1 Formatting the records on the transshipment memory card CF.

The CF memory card installed on the MAG100 needs to be formatted, using the app "CF Formatting" given by Solinftec, using some files to ensure the functioning of the computer on board. Below, there is a description of the necessary files for the transshipment:

On the transshipment CF there will be storage the following files:

- C\_CHECKLIST;
- C\_CHECKLIST\_ITEM;
- C\_FUNC;
- operacoes\_manutencao;
- operacoes\_paradas;
- operacoes\_produtivas;
- C\_EQUIP;
- C\_COORDENADAS;
- C\_COORD\_CERCAS
- fazendas;
- C\_FAZENDAS.

Below there is the description of each of the files.

**C\_CHECKLIST:**

In this case, there is a code register of the groups in which every checklist is framed

Example: 01;S

<b>Field</b>	<b>Description</b>
<b>01</b>	Checklist item code
<b>S</b>	Checklist implement indicator

Whenever a checklist is not necessary, that file can be registered on one line.

C\_CHECKLIST\_ITEM:

Checklist Item ordered by group:

Example: 01;001;CHECK FUEL LEVEL

Field	Description
<b>01</b>	Team code
<b>001</b>	Item code
<b>CHECK FUEL LEVEL</b>	Item description

Whenever a checklist is not necessary, that file can be registered on one empty line:

01;001;VAZIO

C\_FUNC:

The employee record order from the small to the biggest registration code

Example: 140292;RENATO RUY;O;140292;1

Field	Description
<b>140292</b>	Employee registration
<b>RENATO RUY</b>	Name of the employee
<b>O</b>	Employee Role (O = Operator; M = Mechanic)
<b>140292</b>	Employee registration
<b>1</b>	Reserved field

operacoes\_manutencao:

The maintenance operations record order from the small to the biggest registration operation code

Example: 999, MANUT HID, 0

Field	Description
<b>999</b>	Operation code
<b>MANUT HID</b>	Operation description
<b>0</b>	Reserved

Whenever the maintenance operation is not necessary, that file can be registered on one empty line:

0001;VAZIO;0

operacoes\_paradas:

The unproductive operations record ordered from the small to the biggest registration operation code

Example: 104;Treinamento/Orientação;N;N;S

Field	Description
<b>104</b>	Operation Code
<b>Treinamento/Orientação</b>	Operation Description
<b>N</b>	Maximum operation time (minutes), if the maximum time isn't stated, it must remain in N
<b>N</b>	Special code linked to the operation*
<b>S</b>	Reserved Field

Transshipment special codes\* and their functionality:

Field	Description
1	Operation Refueling, immediately, the amount of fuel necessary will be asked.
2	Shift change, the register of the next operator will be asked.
4	Transshipment assigned to a harvester. From the FLOW
0	No special code
N	Stop without special code
S	Maintenance Operation– Enter the maintenance code
X	Maintenance Operation– Does not need to enter the maintenance code
L	Indicates the operation to start the lifting
H	Stop on transshipment line (empty) – FLOW
C	Waiting for lifting (full) – FLOW
5	Moving on board
6	Increasing the Alarm of Idle engine
A	Cleaning assistance on the courtyard– available only on ZIG19 calls
D	Enters on Moving for dumping status
B	Enters on lifting status– for contingencies if there is no CDC
7	Mandatory, stays on this operation until a new stop code is entered

operacoes\_produtivas:

The productive operations record ordered from the small to the biggest registration operation code

Example: 1000;COLHENDO CANA;N;N;N

Field	Description
1000	Code operation
COLHendo	Description of the Operation
N;N;N	Reserved Field

C\_EQUIP:

This field is used only on the CF card. The equipment records ordered from lowest to highest operation code.

Example: 1111;COLHEDORA

Field	Description
1111	Code/ equipment number
COLHEDORA	Equipment description

C\_COORDENADAS:

This option deals with necessary record of the point that identify a controlled area.

Example: PATIO;25.356587;47.547896

Field	Description
<b>PATIO</b>	Coordinates description
<b>25.356587</b>	Latitude
<b>47.547896</b>	Longitude

If it is not needed, that field can be registered with a null line.

**C\_COORD\_CERCAS:**

This option deals with necessary record of the coordinates from ambiances that need to be controlled.

Example: 2152.28788,05026.17930, CERCA\_1,1,300, 0

Field	Description
<b>2152.28788</b>	Latitude
<b>05026.17930</b>	Longitude
<b>CERCA_1</b>	Field description
<b>1</b>	Fence code
<b>300</b>	Fence diameter
<b>0</b>	Special code

If it is not needed, that field can be registered with a null line.

It deals with the register of farms, sector, and field. These are registered by the code of the farm, follows the zone code and finally the field code.

Example: 0002;FAZENDA TANGARA,0011,0204

Field	Description
<b>0002</b>	Farm Code
<b>FAZENDA TANGARA</b>	Farm Description
<b>0011</b>	Sector Code
<b>0204</b>	Field Code

If it is not needed, that field can be registered with a null line.

**C\_FAZENDAS**

It deals with the register of farms, ordered from the lowest to the highest operation code.

Example: 0002;FAZENDA TANGARA

Field	Description
<b>0002</b>	Farm Code
<b>FAZENDA TANGARA</b>	Farm Description

## 5.2 File Register to the Transshipment APK

The Transshipment APK installed on the S7 tablet need some files on the register of information to avoid typing errors.

The following files must be on the S7 memory.

- C\_CHECKLIST\_ITEM;
- C\_FUNC;
- operacoes\_manutencao;
- operacoes\_paradas;

- operacoes\_produtivas;
- C\_IMPLMENTO;

Below there is a more detailed explanation of the previous files.

**C\_CHECKLIST\_ITEM:**

It deals with the checklist items organized by the team.

Example: 01;001;VERIFICAR O NIVEL DE ÓLEO

Field	Description
<b>01</b>	Team description
<b>001</b>	Code of the item
<b>VERIFICAR NIVEL DE ÓLEO</b>	Description of the item

If it is not needed, that field can be registered with an empty line as follows:

01;001;VAZIO

**C\_FUNC:**

It deals with the register of the employees organized from the lowest to the highest registration code.

Example: 140292;RENATO RUY;O;140292;1

Field	Description
<b>140292</b>	Employee register
<b>RENATO RUY</b>	Name of the employee
<b>O</b>	Role of the employee (O = Operator; M = Mechanic)
<b>140292</b>	Register of the employee
<b>1</b>	Reserved Field

**operacoes\_manutencao:**

it deals with the maintenance operation organized from the lowest to the highest operation code.

Example: 999, MANUT HID, 0

Field	Description
<b>999</b>	Operation code
<b>MANUT HID</b>	Description of the operation
<b>0</b>	Reserved

If it is not needed, that field can be registered with an empty line as follows:

0001;VAZIO;0

**operacoes\_paradas:**

It deals with the unproductive operation organized from the lowest to the highest operation code.

Example: 104;Treinamento/Orientação;N;N;S

Field	Description
<b>104</b>	Operation Code
<b>Treinamento/Orientação</b>	Description of the operation
<b>N</b>	Maximum operation time (minutes), if the maximum time isn't stated, it must remain in N
<b>N</b>	Special codes linked to the operation
<b>S</b>	Reserved fields

Transshipment special codes\* and their functionality:

Code	Description
1	Operation Refueling, immediately, the amount of fuel necessary will be asked.
2	Shift change, the register of the next operator will be asked.
4	Transshipment assigned to a harvester. From the FLOW
0	No special code
N	Stop without special code
S	Maintenance Operation– Enter the maintenance code
X	Maintenance Operation– Does not need to enter the maintenance code
L	Indicates the operation to start the lifting
H	Stop on transshipment line (empty) – FLOW
C	Waiting for lifting (full) – FLOW
5	Moving on board
6	Increasing the Alarm of Idle engine
A	Cleaning assistance on the courtyard– available only on ZIG19 calls
D	Enters on Moving for dumping status
B	Enters on lifting status– for contingencies if there is no CDC
7	Mandatory, stays on this operation until a new stop code is entered

operacoes\_produtivas:

It deals with the register of productive operations organized from lowest to highest operation code.

Example: 1000;COLHENDO CANA;N;N;N

Field	Description
1000	Operation Code
COLHENDO CANA	Description of the operation
N;N;N	Reserved fields

C\_IMPLEMENTO:

It deals with the implement register organized from lowest to highest implement code.


Example: 234;IMPLEMENTO;6

Field	Description
234	Implement code
IMPLEMENTO	Description of the implement
6	Length of the implement


### 5.3 Update of the files registered on the tablet using a flash drive.

This procedure is used to upload the files registered on the S7 using a flash drive


- Firstly, a file with the name “**Cadastrros**” must be created on the flash drive. All the registers will be updated there.
- Connect the flash drive using the USB-mini on the serial port on the right side of the S7 tablet.
- Exit the transshipment APK following the steps described on the item “**2.20 Allow to exit the App**”.
- Access the S7 menu entering the password to enter the configuration area on Android.




- Opening app “S7Tools”.



Select the option “Import flash drive file”.



Select the option “Register” and click on the option “IMPORT”.



- Open the “sCBTransshipment” app again and enter on the “Menu/Configuration” path option “Import Records” .

## 6. Commands used on the Transshipment remote update

### 6.1 Parameters that can be updated remotely on the transshipment

The MAG100 Transshipment firmware are ready to receive remote commands to update the parameters already registered by the SGPA:

Command	Description
<b>Update Crate</b>	Update crate records
<b>Update Employee</b>	Register a new employee code on the computer on board.
<b>Update Farm, Field</b>	Register FZT on the computer on board
<b>Update Productive Operation</b>	Register new productive operation code on the computer on board.
<b>Update Unproductive Operation</b>	Register new unproductive operation code on the computer on board.
<b>Update Productive Operation (MAG100)</b>	Register new ´productive operation code on the computer on board MAG100.
<b>Port Lock</b>	Update the lock used for security matters on the (MAG50R)
<b>Start lock</b>	Update the start lock (MAG50R)
<b>Update Unproductive Record</b>	Update the instant stop code of the machine
<b>Text message (64 Characters)</b>	Send text messages to the computer on board up to 64 characters.
<b>Text message Characters (32)</b>	Send text messages to the computer on boar up to 32 characters.
<b>Machine Code</b>	Change the cut code in which the machine is working.

<b>Update Computer on board parameters password</b>	Change the access password to access the computer on board parameters.
<b>Moving Speed</b>	Change the maximum speed allow.
<b>GPRS transmission time</b>	Change the monitoring sending time.
<b>Idle engine time</b>	Change the minimum time for the computer on board to show the idle engine alarm.
<b>Maximum RPM alarm</b>	Change the maximum RPM for the computer on board to generate an alarm.
<b>Maximum Speed Alarm</b>	Change maximum speed for the computer on board to generate an alarm.

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:**  
**(1) this device may not cause harmful interference, and**  
**(2) this device must accept any interference received, including interference that may cause undesired operation.**

**Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.**

**However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

**FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.**