

Preface

Thanks for your favor in our product. This manual is helpful for you to quickly know how to use the product. For detailed features and operations, please refer to the Feature Book along with the product.

This manual is applicable to the following product:

MD78X/MD78XG Digital Mobile Radio

(X may represent 2, 5, 6 or 8)

Instructional Icons

-  : Indicates functions that are available on digital channel only.
-  : Indicates functions that are available on analog channel only.

Functions marked with neither the above icons are available on both analog and digital channels.

Disclaimer

Hytera Communications Corporation Limited (the Company) endeavors to achieve the accuracy and completeness of this manual, but no warranty of accuracy or reliability is given. All the specifications and designs are subject to change without notice due to continuous technology development. No part of this manual may be copied, modified, translated, or distributed in any manner without the express written permission of us.

We do not guarantee, for any particular purpose, the accuracy, validity, timeliness, legitimacy or completeness of the Third Party products and contents involved in this manual.

If you have any suggestions or would like to learn more details, please visit our website at:

<http://www.hytera.com>.

RF Radiation Information

This product must be restricted to operations in an occupational/controlled RF exposure environment. Users must be fully aware of the hazards of the exposure and able to exercise control over their RF exposure to qualify for the higher exposure limits.

RF Radiation Profile

Radio Frequency (RF) is a frequency of electromagnetic radiation in the range at which radio signals are transmitted. RF technology is widely used in communication, medicine, food processing and other fields. It may generate radiation during use.

RF Radiation Safety

In order to ensure user health, experts from relevant industries including science, engineering, medicine and health work with international organizations to develop standards for safe exposure to RF radiation. These standards consist of:

- United States Federal Communications Commission, Code of Federal Regulations; 47CFR part 2 sub-part J;
- American National Standards Institute (ANSI)/Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992;
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999;

- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998;

FCC Regulations

Federal Communication Commission (FCC) requires that all radio communication products should meet the requirements set forth in the above standards before they can be marketed in the U.S, and the manufacturer shall post a RF label on the product to inform users of operational instructions, so as to enhance their occupational health against exposure to RF energy.

Warning

This DIGITAL MOBILE RADIO generates RF electromagnetic energy during transmit mode. This radio is designed for and classified as “Occupational Use Only”.

Operational Instructions and Training Guidelines

To ensure optimal performance and compliance with the occupational/controlled environment RF energy exposure limits in the above standards and guidelines, users should transmit not more than 50% of the time and always adhere to the following procedures:

- Antenna gain must not exceed 5dBi for UHF.
- The antenna installation must comply with the requirements of manufacturer or supplier, and it must be 0.6 meter away from human body.

EU Regulatory Conformance

As certified by the qualified laboratory, the product is in compliance with the essential requirements and other relevant provisions of the Directive 2014/53/EU.




Please note that the above information is applicable to EU countries only.

Contents

1. Items in the Package	1
2. Product Overview	2
2.1 Front Panel	2
2.2 Rear Panel	3
2.3 Programmable Keys	3
3. Before Use	4
3.1 Instructions	4
3.2 Installation	4
4. Status Indication	7
4.1 LCD Icon	7
4.2 LED Indicator	8
5. Menu Navigation	10
6. Basic Operations	11
6.1 Powering On/Off	11
6.2 Adjusting the Volume	11
6.3 Selecting a Zone	12
6.4 Selecting a Channel	12
6.5 Inputting via Keypad	12
6.6 Managing the Contacts	13
7. Call Service	14
7.1 Private Call 	14
7.2 Group Call 	15
7.3 Call on Analog Channel (No Signaling) 	16
7.4 Emergency Call	16
8. Message Service 	17
9. Troubleshooting	18
10. Care and Cleaning	20
11. Optional Accessories	21
12. PMR	22
13. RF radiation safety warnings and the following:	23

1. Items in the Package

Please unpack carefully and check that all items listed below are received. If any item is missing or damaged, please contact your dealer.

		
Radio Unit	Palm Microphone	Microphone Hanger and Screws
		
Mounting Bracket Kit	Fuse	GPS Antenna
		
Power Cord	Documentation Kit	




Note:

- The GPS antenna is the standard accessory for the MD78XG. The descriptions related to the GPS feature in this manual are applicable to MD78XG only
- You need to purchase a palm microphone with keypad for inputting the alias, ID or text message. For details, please go to “Optional Accessories” in this manual .


2. Product Overview

2.1 Front Panel



No.	Part Name	No.	Part Name
1	Volume Control/Channel Selector Knob	7	Up Key
2	LED Indicator	8	Down Key
3	LCD Display	9	Speaker
4	OK/Menu Key	10	Programmable Keys
5	Back Key	11	Microphone Connector
6	Power On/Off Key	12	Microphone Installation Index

2.2 Rear Panel



No.	Part Name	No.	Part Name
1	RF Antenna Connector (BNC female)	3	Accessory connector
2	Power Inlet	4	GPS Antenna Connector (SMA female)



Note: The GPS antenna connector is only available for MD78XG Mobile Radio.

2.3 Programmable Keys

For enhanced convenience, you may request your dealer to program the seven keys (TK() , P1, P2, P3, P4, P5() and P6()) as shortcuts to the functions introduced in the Owner's Manual. Please refer to the corresponding Feature Book for more details.



Caution: The TK is programmed with emergency feature by default (short press: Emergency On; long press: Emergency Off). It is programmable by your dealer. Short press of the P5 key is programmed with the Contact List feature, and short press of the P6 key programmed with the Home Screen feature.

3. Before Use

3.1 Instructions

Before you install the radio in a vehicle, be sure to read the following instructions carefully:

- The radio must work with a $13.6V \pm 15\%$ negative ground electrical system only. And ensure to check the ground polarity and voltage of the vehicle power supply prior to installation.
- Check how long the screws will extend from the bottom surface of the radio before installation. Drill the mounting hole cautiously to avoid damage to the vehicle wiring and other parts.
- Connect the antenna and power cord to the radio, before you install it in the bracket. And make sure the antenna and power cord are dedicated for Hytera digital radios.
- Install the radio with Hytera supplied mounting bracket, to avoid radio looseness in case of accidents. The loose radio may cause bodily injury.
- Install the radio in a location where it's easy to reach the front panel controls.
- Keep sufficient clearance at the back of the radio for wiring.
- Be sure to use the fuse with the same specification for DC power cord upon replacement.
- If there are any other device in the vicinity of this radio, the distance between the antenna of this radio and the antenna of such RF device shall be no less than 10 meters.

3.2 Installation

Installation Tools

- Electric drill
- Cross head screwdriver
- Hex socket sleeve (for $4.8 \times 20\text{mm}$ self-tapping screws)


Installation Procedure

To install the radio, do as follows:

1. Install the **bracket** in a location where it's easy to operate the radio.
2. Connect accessories such as the **antenna** and **power cord** to the radio.
3. Slide the **radio** into the properly mounted bracket and secure it using the locking knobs.
4. Install the **microphone hanger** in a location where it can be reached conveniently.
5. Plug the **palm microphone** into the radio, but at first align the triangle index on the palm microphone with the microphone installation index. Place the palm microphone on the hanger when you do not

use it.

The parts of the radio are illustrated below:



No.	Part Name	No.	Part Name
1	Radio Unit	8	Power Inlet
2	Locking Knobs	9	Power Cord (black)
3	Mounting Bracket	10	Power Cord (red)
4	4.8×20mm Self-tapping Screws	11	Fuse

No.	Part Name	No.	Part Name
5	Palm Microphone	12	RF Antenna Connector
6	4×16mm Self-tapping Screws	13	GPS Antenna Connector
7	Palm Microphone Hanger	/	/

4. Status Indication

4.1 LCD Icon

Name	Icon	Radio Status
DTMF Keypad Icon		The DTMF keypad is enabled.
GPS Icon		The GPS feature is enabled, and valid GPS data is received.
		The GPS feature is enabled, but no valid GPS data is received.
TX Power Icon		Low TX power for the current channel.
		High TX power for the current channel.
Work Order Icon		One or more new work orders are received.
Operation Mode Icon		Direct Mode: Under this mode, the radio communicates with other radios directly.
		Repeater Mode: Under this mode, the radio communicates with other radios via a repeater.
Monitor Icon		The Monitor feature is enabled.
Emergency Icon		The Emergency mode (except secret emergency) is activated or an emergency alarm is received.
Roam Icon		The radio is roaming.
Scrambler/Encrypt Icon		The Scrambler/Encrypt feature is enabled.
Scan Icon		The radio is scanning.
		Scanning stays on a non-priority channel.
		Scanning stays on Priority Channel 1.
		Scanning stays on Priority Channel 2.

Name	Icon	Radio Status
VOX Icon		The VOX feature is enabled.
Missed Call Icon		Missed call(s).
Message Icon		Unread message(s).
		Inbox is full.
RSSI Icon		More bars indicate better signal strength.
Knob Operation		The knob is used for channel selection currently.
Mode Icon		The knob is used for volume control currently.
LQO Icon		The LQO feature is enabled.
Call/Contact Icon		● Indicates Private Call during a call. ● Indicates Private Contact in the contact list.
		● Indicates Group Call during a call. ● Indicates Group Contact in the contact list.
		● Indicates All Call during a call. ● Indicates All Call Contact in the contact list.

4.2 LED Indicator

LED Indication	Radio Status
The LED indicator flashes green	Powering on.
The LED indicator glows red	Transmitting.

LED Indication	Radio Status
The LED indicator glows green	Receiving.
The LED indicator flashes orange slowly	Scanning or Roaming.
The LED indicator flashes orange rapidly	Emergency.
The LED indicator glows orange	Call hung. During a call, you can hold down the PTT key to talk to the other party before the call hang time expires.




Note: Unless otherwise specified, the **PPT** key mentioned in this manual indicates that of the palm microphone.

5. Menu Navigation

The following diagram outlines the menu structure of the radio. You can personalize menu option displayed in the radio via your dealer.


To select and confirm the options shown in the menu, press the **Menu** key and then press the **Up/Down** key to select the appropriate option, finally press the **OK** key. This manual only describes the paths to the menus in terms of menu operations, for example, to access the contact list, go to “Contact -> Contact List”.

The radio supports menu reset function. If you do not operate the menu for a preset time period configured by the dealer, the radio will automatically return to the home screen. You may request the dealer to change the auto reset time or disable the feature.



6. Basic Operations


6.1 Powering On/Off



6.2 Adjusting the Volume

You can adjust the volume of output voice, side tone and group notification tone by rotating the **Volume Control Knob**. For other tones, the volume will be configured by the dealer.

Press the **Volume Control/Group Call Selector Knob** to switch the radio to volume adjustment mode (the radio displays the icon ) , and then rotate the knob to adjust the volume.



6.3 Selecting a Zone


A zone is a group of channels exhibiting the same property, which is programmed by your dealer and can facilitate convenient management over the channel. The radio supports up to 64 zones, each with a maximum of 16 channels. You may select a zone through any of the following methods:

- Via the menu: Go to the menu “Zone”, then use the **Up/Down** key to select the appropriate zone and press the **OK** key to confirm.
- Via the programmable key: You may quickly toggle to the appropriate zone by pressing the programmed **Zone Up** or **Zone Down** key.

6.4 Selecting a Channel

Press the **Volume Control/Channel Selector** knob to switch the radio to channel selection mode (the radio displays the icon , and then rotate the knob to select the appropriate channel. You can also switch to the designated channel by pressing the programmed **Preset Channel** key preset by your dealer.

If the Channel Notify feature is enabled, you will hear the corresponding channel number when switching to any channel.



6.5 Inputting via Keypad

You can input alias, call numbers and messages via the keypad on the palm microphone.

- To switch input method: 

- To input special characters:
- To input space:



Note: If not particularly specified, the keypad mentioned in this manual indicates that of the palm microphone with keypad.

6.6 Managing the Contacts

You can manage the contacts via the “Contact” menu.

6.6.1 Contact List

The Contact List is used to save information of private call contacts. You can access the “Contact List” menu via the “Contact” menu or by pressing the programmed **Contact List** key.

In the “Contact List” menu, you can view the contact information, edit or delete private contacts. You can send to a private call contact the following commands: Alert Call, Radio Check, Remote Monitor, Radio Enable or Radio Disable.

6.6.2 New Contact

You can add and save a new contact to the contact list. The ID and alias of each contact must be unique.



Note: Except for adding a new contact, you can also save the numbers in Call Logs, ReDial List and BackDial List into the contact list.

7. Call Service

After the radio is powered on, you can make and receive calls. To ensure optimal volume of the receiving radio, keep the palm microphone about 2.5 to 5 centimeters away from your mouth when speaking.



7.1 Private Call

7.1.1 Initiating a Private Call

When initiating a private call, the radio will display the icon . You can make a private call through the following ways:

Preset Contact

In the home screen, hold down the **PTT** key on the palm microphone to initiate a Private Call to the Private Call contact preset for the current channel.

You may request your dealer to preset a regular Private Call contact, Group Call contact or an All Call contact for each digital channel.

Contact List or Call Log

Step 1 Go to "Menu -> Contact" or "Menu -> Call Logs" and access the "Contact List" submenu.

Step 2 Use the **Up/Down** key to select an appropriate contact.

Step 3 Hold down the **PTT** key to initiate a Private Call.

Manual Dial

Step 1 Go to "Menu -> Contact -> Manual Dial".

Step 2 Input a Private Call number you want to call via the keypad.

Step 3 Hold down the **PTT** key to initiate a Private Call.



Note:

- If both the Private Call Manual Dial and Group Call Manual Dial are available, you can press  to switch between the two dialing methods, and the radio will display the call type (private call ID/ group call ID).
- If the Default Numeric Key Selection feature is enabled by your dealer, you can enter a private call number in the home screen, and then press the **PTT** key to transmit the call. However, if the DTMF keypad is enabled, the number entered in the home screen is a phone number. You can dial the private call number through the menu “Manual Dial” only.

7.1.2 Receiving and Responding to a Private Call

After receiving a private call, the radio will display the icon , then you can listen without any operation. You can hold down the **PTT** key to call back within the preset time. If you do not respond to it, the radio will provide appropriate indications.

7.2 Group Call

7.2.1 Initiating a Group Call

When initiating a group call, the radio will display the icon . You can make a group call through the following ways and the operation is similar to Initiating a Private Call.

Preset Contact

In the home screen, hold down the **PTT** key on the palm microphone to initiate a Group Call to the Group Call contact preset for the current channel.

Contact List

Step 1 Go to “Menu -> Contact -> Contact List”.

Step 2 Use the **Up/Down** key to select an appropriate contact.

Step 3 Hold down the **PTT** key to initiate a Group Call.

Manual Dial

Step 1 Go to “Menu -> Contact -> Manual Dial”.

Step 2 Input a Group Call number you want to call via the keypad.

Step 3 Hold down the **PTT** key to initiate a Group Call.

7.2.2 Receiving and Responding to a Group Call

After receiving a group call, the radio will display the icon . You can hold down the **PTT** key to call back within the preset time.

7.3 Call on Analog Channel (No Signaling)

On an analog channel, you can hold down the **PTT** key and talk to the microphone to transmit, and release the **PTT** key to receive.

7.4 Emergency Call

In case of an emergency, you can use this feature to ask for help from your companion or the control center. The Emergency Call has the highest priority which can terminate the ongoing calls with lower priorities on the current channel. You can make an emergency call even when your radio is transmitting or receiving.

This feature needs to be configured and enabled by your dealer. Please refer to the corresponding Feature Book for details.

8. Message Service

This feature enables you to edit and send a new message, to directly send a quick text message and to forward the messages in the Inbox, Outbox and Drafts.

Sending a Message

Step 1 Go to “Menu -> Message -> New Msg” to enter the relevant interface.

Step 2 Type the text and then press the **OK** key. Save it to Drafts, or send it to a private call contact or a group call contact.

Step 3 Select the contact or input the contact number manually.

Step 4 Press the **OK** key to send the message. When the message is sent successfully, the prompt “Send Success!” will appear on the LCD.

Quick Text

The radio supports quick text message preset by your dealer. You can directly send the message or edit it prior to sending.

Inbox

The radio saves the received messages into the Inbox and marks every message with a corresponding icon to indicate its status.

- : Read message.
- : Unread message.

When the Inbox is full, the radio will display the icon , and the earliest message will be overwritten by the latest one automatically.

Outbox

The radio saves the sent messages into the Outbox and marks every message with a corresponding icon to indicate its status.

- : The message is sent successfully.
- : The message is not sent successfully. In this case, you can resend it.

When the Outbox is full, the earliest message will be overwritten by the latest one automatically.

Drafts

The radio saves the edited messages into the Drafts. When the Drafts is full, the earliest message will be overwritten by the latest one automatically. After the message in the Drafts is sent successfully, it will be removed from the Drafts and be saved into the Outbox. If not sent successfully, the message will be saved into the Drafts and the Outbox.

9. Troubleshooting

Phenomena	Analysis	Solution
The radio fails to power on.	The power cord may be disconnected.	Connect the power cord properly.
During receiving, the voice is weak, discontinuous or totally inactive.	The volume level may be low.	Increase the volume by rotating the Volume Control Knob .
	The antenna may be loosened or improperly installed.	Power off the radio and reattach the antenna.
	The speaker may be blocked or damaged.	Clean the surface of the speaker. If the problem cannot be solved, contact your dealer or our authorized service center for inspection and repair.
You cannot communicate with other members in analog mode.	The frequency or signaling may not match that of other members.	Set your TX/RX frequency and signaling to the same as that of other members.
	You may be too far away from the group members.	Move towards other members.
In digital mode, there's RX indication on the radio, you cannot communicate with other members.	The digital carrier may be received but may not be demodulated due to inconsistent ID with that of other members.	Sets the same ID of other members.
Irrelevant communication or noise is heard on the channel.	You may be interrupted by radios using the same frequency.	Adjust the squelch level.
	The radio may be set with no signaling.	Set your radio with signaling to avoid interference at the same frequency, and make sure that all members share the same signaling.

Phenomena	Analysis	Solution
The noise is too loud.	You may be too far away from other members.	Move towards other members, and restart the radio to try again.
	You may locate in an unfavorable position. For example, your communication may be blocked by high buildings or frustrated in the underground areas.	Move to an open and flat area, and restart the radio to try again.
	You may suffer from external disturbance (such as electromagnetic interference).	Stay away from equipment that may cause interference.
You cannot use the keys.	The keypad may fail to function temporarily.	Restart the radio.
The LCD does not display any information.	The LCD may fail to function temporarily.	Restart the radio.
GPS positioning fails.	The GPS antenna may be connected improperly.	Connect the GPS antenna properly.
	GPS signals may not be received due to unfavorable position.	Move to an open and flat area to try again.

If the above solutions cannot fix your problems, or you may have some other queries, please contact us or your local dealer for more technical support.

10. Care and Cleaning

To guarantee optimal performance as well as a long service life of the product, please follow the tips below.

Product Care

- Do not pierce or scrape the product.
- Keep the product far away from substances that can corrode the circuit.
- Do not hold the product by its antenna or earpiece cable directly.
- Attach the accessory connector cover when the accessory is not in use.

Product Cleaning



Caution: Power off the product and disconnect the power supply before cleaning.

- Clean up the dust and fine particles on the product surface and charging piece with a clean and dry lint-free cloth or a brush regularly.
- Use neutral cleanser and a non-woven fabric to clean the keys, control knobs and front case after long-time use. Do not use chemical preparations such as stain removers, alcohol, sprays or oil preparations, so as to avoid surface case damage.
- Make sure the product is completely dry before use.

11. Optional Accessories

The following items are the main optional accessories for the radio. For more information of other accessories, please consult your local dealer.

 **Caution:** Use the accessories specified by the Company only. If not, the Company shall not be liable for any loss or damage arising out of use of unauthorized accessories.

- Power Supply: PS16001 Power Supply of Base Station Cabinet, PS22002 Power Supply for Mobile Radio(220W, Backup Power Supply applicable)
- Audio: SM09D1 External Speaker, SM10A1 Desktop Microphone, SM19A1 Keypad Microphone, SM20A1 Telephone Style Handset
- Cable: PC37 DB26-connector Programming Cable (USB port), PC40 DB26-connector Data Cable (USB port), PC43 DB26-connector Dispatching Cable with USB Port & Dual Audio Jack, PC46 Data Cable(COM Port), PC47 Programming Cable (USB Port), PC48 Data Cable(COM Port)(6 meters), and PC49 Back-to-back Data Cable (DB26 to DB26)
- Others: RCC04 Mobile Radio Remote Mount Kit (3 meters)(IP54), RCC04 Mobile Radio Remote Mount Kit (3 meters)(IP67), RCC05 Mobile Radio Remote Mount Kit (6 meters)(IP54), RCC05 Mobile Radio Remote Mount Kit (6 meters)(IP67), and Omni-directional Antenna

12. PMR

Frequency Range: 210MHz to 270MHz;

RF Output Power: High Power: 25W, Low Power: 5W;

Modulation Type:

Analog Voice: FM, Digital Data: 4FSK;

Channel Separation: Analog Voice: 12.5kHz, Digital Data: 12.5kHz;

Antenna gain: 5.0dBi

13. RF radiation safety warnings and the following:

Antenna	Safe Distance, R_{safe} , (cm)
	FCC Part 2.1091
	Controlled RF Exposure
TQC-230CII	60