

Quick installation guide

Basic step by step cloud and box manual

ver.2.7 date: 10.08.2018.







Content

1	Revi	ision history	3
2	Clou	ud log in	4
3	Inpu	ıt basic data to cloud	4
4	Crea	ate machine on cloud	4
5	Add Televend configuration & Choose payment systems		
6	Add products to machine		
7	Ante	enna types	6
8	Plug	in the box to machine and payment system	7
E	Explan	nation of connection scheme possible functionalities	7
N	MDB b	prain:	8
E	BRAIN	l:	8
E	EXE b	rain	9
E	BDV B	BRAIN:	9
I	MPOF	RTANT MECHANICAL PROTECTION NOTES:1	0
9	Mac	hine Online – push product list1	0
10	Ва	asic test check1	1
11	Τe	elevend buttons1	1
1	11.1	Selling (normal) mode – confirmation of visit actions	1
1	11.2	Button functions in Service mode	2
1	11.3	I FDs	3









1 Revision history

Version	Date	Author(s)	Change
2.4	14.09. 2017	Nikola Runjavec	BDV protocol connection
2.5	13.12.2017	Romana Rožić	Antenna types description
2.6	29.06.2018	Vedran Plavec	Enhanced LED behavioral
2.7	10.08.2018	Nikola Runjavec	







2 Cloud log in

Log in to the cloud with given credentials. Recommended browsers are Google Chrome or Mozilla Firefox.

a. Link: http://televendcloud.com/en/login

b. Username: your e - mail

c. Password: your given password

3 Input basic data to cloud


When logged in go to "ADMINISTRATION" and create the following in this order > Region, Location, Tax Rate, Products.

If you have a coffee product first create Components – for example Sugar, Cups, Coffee beans etc. When creating a coffee product click "Add recipe".

4 Create machine on cloud

Before connecting the box to the machine create the machine on cloud in Administration > Machines > "Add new machine".

In machine settings PID is the serial number printed on the Televend box.











In Televend configuration select wanted Televend operation mode Brain, MDB brain, EXE brain etc.



Scroll below to choose active payment systems:












Add products to machine

Add products which you have created in the first step to the machine in products tab. Note: column numbers must match the selections (button numbers) defined on the machine. For example:



Antenna types

There are four antenna types that can be delivered with the Televend box set:

- a) AN01-BT- 2,1 dBi external antenna type, mounted directly on Televend box, next to GSM antenna, can be used for offline data collection or Wallet
- b) AN02-2,1 dBi the so called inner antenna, should be placed on plastic surface inside of the machine
- c) AN03-5,0 dBi external antenna type, used in places with very bad signal strength
- d) AN03S- 2,2 dBi external antenna type, used in places with lower signal strength












8 Plug in the box to machine and payment system

Explanation of connection scheme possible functionalities



- Transactions (vends) in real time approving transaction as master device. Cashless device in MDB, or Coin changer in EXE
- 2. Errors
 - Machine inhibited when machine is out of service it inhibits payment system
 - 2. EVA-DTS error code readout
- 3. Prices management
 - 1. Price hold display & ETL when Exe
 - 2. Price on VMC when MDB
 - 3. Eva-dts write prices through Eva
- 1. Cash status real time insight into tube status, cashbox, BNA
- Errors MDB error codes: coin jam, sensor problem, stacker removed etc.
- 3. Payment type cash, cashless 1&2, token, free vend, test vend, mobile etc.
- P machine processor (controller)
- C coin changer
- C1,C2 cashless devices (address 1, address 2)
- BNA banknote acceptor











MDB brain:



Recommended settings of machine and box:

- Make sure machine and payment systems are set to MDB
- In this configuration machine recognizes Televend box as cashless device make sure cashless is enabled in the machine settings
- Recommended price setting of Televend box is "Price on VMC"

BRAIN:



NOTE! - AC CABLE (power supply) also needed in this configuration

Recommended settings of machine and box:

- Make sure machine is set to EXE and payment systems are set to MDB
- In this configuration machine recognizes Televend box as a coin changer make sure coin changer is enabled in machine settings
- Recommended price setting of Televend box is "Price hold display"

NOTE: In EXE brain and BRAIN configuration, in some machines prices and selection numbers need to be defined like following in order to control prices over cloud and dial selections:








Selection -	Pricelist num.	Pricelist num	Price
1	1	1	0.01
2	2	2	0.02
Etc	Etc	Etc	Etc

EXE brain




NOTE! - AC CABLE (power supply) also needed in this configuration

Recommended settings of machine and box:

- Make sure machine and payment systems are set to EXE
- In this configuration machine recognizes Televend box as a coin changer make sure coin changer is enabled in machine settings
- Recommended price setting of Televend box is "Price hold display"

BDV BRAIN:











Recommended settings of machine and box:

- Make sure machine is set to BDV and payment systems are set to MDB
- In this configuration machine recognizes FTU as a coin changer make sure coin changer is enabled in machine settings

Recommended price setting of FTU is "Price hold display"




MECHANICAL PROTECTION NOTES:

Take care of mechanical stability, avoid placement near heat sources, enable free air flow, protect box and cables from dripping liquids, ensure that box is galvanically isolated from all metal parts of the machine and from other devices, arrange cable traces to avoid any stress to cables, find position for antenna which is distanced from metal parts as much as possible and ensure proper mechanical stability, cables connection and disconnection must be done only in power-off condition of the cables.

If box is used with AC power supply be sure that power supply has overcurrent protection while otherwise use Televend-cable with built-in overcurrent protection.

9 Machine Online – push product list

When you get online status on the cloud & the blue lamp on box is stabile blue – go to the machine in cloud in "PRODUCTS" and push product list. Check in events when the product list is successfully downloaded to the machine.










10 Basic test check

- Sales buy something on machine and check vend list on cloud.
- Cash collection create cash collection route on the cloud and check Cash flow on cloud after pressing "i" button on the box
- Create refill route and fill the machine
- Events check event list on cloud.

11 Televend buttons

11.1 Selling (normal) mode – confirmation of visit actions

Button functions



11.1.1.1 Cloud Prekitting or Real time routes:

IMPORTANT NOTE! In this model button press is taken into account and visit confirmed only if route on cloud is created. Outside route presses won't be taken into account.

- Machine refill refill if refill route only; refill and cash collection if combined route
- i Cash collection Cash collection if cash collection route only; refill and cash collection if combined route






11.1.1.2 Mobile routing or no routes:

IMPORTANT NOTE! In this model button press is taken into account every time it is pressed.

- Machine refill refill confirmed
- i Cash collection cash collection confirmed

11.2 Button functions in Service mode

Button functions - Inside Service mode




To enter or exit the service mode, button has to be held for 3 seconds. While in service mode, the Service mode LED is blinking, and the buttons have different actions

- Configuration download then exit service mode (3 sec again) NOTE: restart of the box will also pick up the configuration from the cloud.
- **Product list download** then exit service mode (3 sec again) NOTE: it is also possible to push product list online.





11.3 LEDs



11.3.1.1 Server LED

Server LED gives the status of GSM and GPRS connection. There are 5 statuses:


1.	Modem is off						
	OFF						

Check if the cables are properly connected (chapter 8) and that the box has power. If everything is connected properly and still no blinking, please contact Televend support team and prepare PID number.

2. Connecting to the GSM network



If this status lasts for more than 5 minutes, please check have you properly connected antennas (chapter 7). If you have ordered ANO3 or ANO3S antenna types, try to connect those. If status persists, please contact Televend support team and prepare PID number.





4.

5.

Televend Quick Installation



The modem is connecting to APN and can take some time till it connects. If the status persists, please contact Televend support team and prepare PID number.

Connecting to Cloud
ON0.5secOFF0.5sec
The box is trying to connect to the Cloud (servers) and to map with the predefined machine. If
the status continues for more than 5 mins, please connect to cloud application
(https://televendcloud.com), log into the correct company and find the machine with the same
PID as the one on the box. If the status persists, please contact Televend support team and
prepare PID number.
Connected to Cloud
ON
The box has successfully connected to the cloud.

11.3.1.2 Attention LED

LED blinking fast – Televend sends data, keyboard input is disabled

LED blinking slow - Televend waiting for Cloud response, keyboard input is disabled

11.3.1.3 Service mode LED

Blinking while Televend is in service mode