



WLTGFC Gemtek TDD LTE Small Cell User Guide

| Date | Version |
|-----------|---------|
| 2019/11/5 | V2.8 |

Table of Contents

| | |
|--|----------|
| Table of Contents | 2 |
| Copyright Notice | 4 |
| 1. Overview | 5 |
| 2. Gemtek Small Cell Installation and Test Environment | 7 |
| 3. Accessing Web Management Interface | 9 |
| 3.1 System Requirement | 9 |
| 3.2 Getting Started | 9 |
| 3.2.1 Login | 10 |
| 3.2.2 Modify Configuration | 11 |
| 3.2.3 Reconfiguration Reboot | 14 |
| 4. Web Management Interface Reference Manual | 15 |
| 4.1 Status | 15 |
| 4.1.1 Status System Status | 15 |
| 4.1.2 Status Network Status | 16 |
| 4.1.3 Status LTE Status | 17 |
| 4.1.4 Status UEs Status | 18 |
| 4.2 LTE Configuration | 19 |
| 4.2.1 LTE Configuration General | 19 |
| 4.2.2 LTE Configuration Radio Access Network | 20 |
| 4.2.3 LTE Configuration Neighbor List | 21 |
| 4.2.4 LTE Configuration Measurement Report Triggers | 23 |
| 4.2.5 CBRS Configuration | 24 |
| 4.3 Syslog | 26 |
| 4.3.1 Syslog Operation Log | 26 |
| 4.3.2 Syslog Configuration Log | 26 |
| 4.3.3 Syslog Alarm Log | 26 |
| 4.3.4 Syslog Export Log Files | 26 |
| 4.4 Management | 27 |
| 4.4.1 Management Network Configuration | 27 |
| 4.4.2 Management IPsec Configuration | 27 |
| 4.4.3 Management System Configuration | 28 |
| 4.4.4 Management Routing Configuration | 28 |
| 4.4.5 Management Configuration File | 29 |
| 4.4.6 Management Firmware Utility | 32 |
| 4.4.7 Management Change Login Password | 36 |
| 4.4.8 Management Software Package Management | 37 |
| 4.4.9 Management Time Setting | 38 |

| | | |
|--------|---|----|
| 4.4.10 | Management CSFB Configuration | 39 |
| 4.4.11 | Management Reset to Factory Default | 39 |
| 4.4.12 | Management Reboot System | 40 |
| 4.5 | Logout..... | 41 |
| 4.6 | LED Definition..... | 42 |
| 4.6.1 | LED Behavior | 42 |
| 5. | All-In-One Small Cell (X-Cell)Web Management Interface Reference Manual | 43 |
| 5.1 | EPC..... | 43 |
| 5.1.1 | EPC EPC-MME Configuration..... | 43 |
| 5.1.2 | EPC HSS-KEY Configuration..... | 44 |
| 5.2 | X-Cell Network Planning..... | 46 |
| 5.3 | Cell Phone APN Settings:..... | 47 |
| 5.4 | Small Cell Wall Mount Accessory Installation..... | 52 |
| 6 | Federal Communication Commission Interference Statement | 54 |
| | IMPORTANT NOTE: | 54 |
| | FCC Radiation Exposure Statement: | 54 |
| | Professional installation instruction | 55 |
| 1). | Installation personal | 55 |
| 2). | Installation location | 55 |
| 3). | External antenna..... | 55 |
| 4). | Installation procedure..... | 55 |
| 5). | Warning | 55 |

Copyright Notice

Copyright© 2015 Gemtek Technology Co., Ltd.

All rights reserved.

No part of this publication may be reproduced, transmitted, transcribed, or translated into any language without the written permission of Gemtek Technology Co., Ltd. or its suppliers or affiliate companies. Gemtek Technology Co., Ltd. reserves the right to change specifications without prior notice. To obtain this permission write to the attention of Legal counsel, Gemtek Technology Co., Ltd., No.15-1 Zhonghua Road, Hsinchu Industrial Park, Hukou, Hsinchu, Taiwan (R.O.C.) ,30352.

1. Overview

This document will lead you to learn more about Web Management Interface features of Gemtek LTE Small Cell. The Web Management Interface is an intuitive Web GUI used to configure, monitor and perform diagnostics on Gemtek LTE Small Cell. It can be run as a stand-alone application, or as part of the management system.

The available features include:

A. Status

- *System Status*: Display Model Name, RF/BB Temperature, Memory, System Up Time, etc.
- *Network Status*: Display Small Cell IP Address, MAC Address, Default/Security Gateway, NTP/SON Server information, and IPSec Status.
- *LTE Status*: Display the LTE general configuration about information of Frequency band, PLMN, MME/eNodeB IP address, Bandwidth, EARFCN, and, etc.
- *UEs Status*: Show the UL/DL MCS Selection, Throughput and BLER.

B. LTE Configuration

- *General*: Configure eNodeB basic setting including, eNodeB type, Cell ID, Physical Cell/Group Cell ID, PLMN, MME IP and its SCTP Port.
- *Radio Access Network*: Configure RF Bandwidth, Tx Power and EARFCN.
- *Neighbor List*: Set Neighbor List for Intra-Frequency and Inter-Frequency usage.
- *Measurement Report Triggers*: Set Trigger conditions for A1/A2/A3/A4/A5 events.

C. Syslog

- *Alarm Log*
- *Operation Log*
- *Configuration Log*
- *Export Log Files*

D. Management

- *Network Configuration*: Configure eNodeB IP, DNS, DHCP.
- *IPsec Configuration*: Configure IPsec status and Certificate.
- *System Configuration*: Configure NTP and Syslog Servers.
- *Routing Configuration*: Configure Route Type 、 Destination 、 Mask 、 Gateway 、 Interface.
- *Configuration File*: Provide configuration file Export, Import and Restore functions.
- *Firmware Utility*: Support Firmware Upgrade and Rollback utilities.
- *Change Login Password*: Reset Web GUI password.
- *Software Package Manager*: To install debug utility.
- *Time Setting*: Configure TimeZone.
- *CSFB Configuration* :Configure Circuit Switch Fallback Priority.(3G 、 4G)
- *Reset to Factory Default* : Select reset default type.
- *Reboot*: Reboot eNodeB.

E. Logout

- Logout the Small Cell Web GUI

F. LED Behavior

Before starting accessing the Gemtek LTE Web Management Interface, we will show you how to install the Gemtek LTE Small Cell first in the next Chapter.

2. Gemtek Small Cell Installation and Test Environment

Shown below are the features of Gemtek LTE Small Cell and POE (Power over Ethernet).








Figure below shows us how to install the Gemtek LTE Small Cell in overall test environment.



3. Accessing Web Management Interface

This chapter introduce the requirements and procedures for accessing the Web Management Interface of Gemtek LTE Small Cell. The following information is covered in this chapter:

- System Requirements
- Getting Started

3.1 System Requirement

Web Management Interface has been tested on the following platforms:

- Microsoft Windows XP/7/10
- Red Hat Enterprise Linux 6.3

The suggested Web browsers are:

- Google Chrome 40.0 or higher
- Firefox 10.0 or higher
- Windows Internet Explorer 8.0 or higher

3.2 Getting Started

This section covers how to start Gemtek LTE Small Cell Web Management. Before accessing the Web GUI, make sure that your PC must follows the network setting listed below.

- A. Set the network card to use static IP address as <10.102.81.X>
- B. Set the subnet mask as <255.255.255.0>

3.2.1 Login


Open Web browser to login Gemtek LTE Small Cell Web Management

- Default Login Website: <https://10.102.81.59>
- Username/Password: **admin/admin**



The login page features the Gemtek logo at the top center, followed by the text 'WLTGFC-105 Login'. Below this is a login form with two input fields: 'Username' and 'Password'. A checkbox labeled 'Keep me logged in' is positioned to the left of a blue 'Login' button. At the bottom center of the page, there is a small copyright notice: 'Copyright© 2015 Gemtek Technology Co., Ltd.'



- Homepage





The homepage displays the Gemtek logo and version information (2.1.1878.562-wltgfc105-gemtek-tdd-X) at the top. A navigation bar includes links for 'Status', 'LTE Configuration', 'Syslog', 'Management', and 'Logout'. The main content area is divided into two sections. On the left is a sidebar with a list of status categories: 'System Status', 'Network Status', 'LTE Status', and 'UEs Status'. The 'System Status' category is selected, and its details are shown in a table on the right.

| System Status | |
|---------------------|---------------------------|
| Model Name | WLTGFC-105 |
| Serial Number | |
| Baseband HW Version | V00 |
| RF HW Version | V01 |
| Temperature | RF: 40, BB: 47 |
| CPU Loading | 1.66% 2.21% 2.38% |
| Current Date/Time | 2015-05-17 22:12:19 |
| System Up Time | 0 Day 0 Hour 13 Min 9 Sec |
| LTE Service Up Time | 0 Day 0 Hour 0 Min 0 Sec |
| Total Memory | 516476 KB |
| Used Memory | 188000 KB |
| Free Memory | 328600 KB |
| Sync Source | Internal |
| Sync Status | N/A |


3.2.2 Modify Configuration

If you want to edit any configurations (except **reboot**, **firmware upgrade/rollback** or **export/import/restore configuration files**), you should **lock** eNodeB first by clicking the button  on top-right corner of the page and then you can edit what you want when the button become . At this time, you must allow all UEs to be disconnected (if any UE attached at any time).



Shown below is an example of how “General Configuration” was modified and saved. All other configurations will be dealt with in detail in Chapter 3.



Once finish editing the configuration, you have to click **Update** button.




The screenshot shows the Gemtek LTE Configuration web interface. The top navigation bar includes 'Status', 'LTE Configuration', 'Syslog', 'Management', and 'Logout'. The left sidebar lists 'General', 'Radio Access Network', 'Neighbor List', and 'Measurement Report Triggers'. The main content area displays the 'General Configuration' form with the following fields:

| General Configuration | |
|---|-------------------------------------|
| ENodeB Type | Home eNodeB ▼ |
| Cell Identity | 10 |
| PHY Cell Group ID | 10 |
| PHY Cell ID | 1 |
| PLMN Identity(MCC+MNC) | 00101 |
| Tracking Area Code | 1 |
| MME IP | 10.102.81.101 |
| MME SCTP Port | 36412 |
| Keep local GTP-U Tunnel IP same as eNB IP | <input checked="" type="checkbox"/> |
| local GTP-U Tunnel IP | 10.102.81.59 |
| UE Inactivity Timer | More than 30 days ▼ |
| DSCP Control | 0 |
| DSCP Data | 0 |

The 'Update' button at the bottom of the form is highlighted with a red box. In the top right corner, there is a button with a green circle icon, also highlighted with a red box.


Before saving the configuration, be sure to **unlock** eNodeB by clicking the button  to make it turn green . Hence, the result shows that all fields can't be edited anymore when finishing unlock.

Then click the button  on the top-right corner to save the configuration.





This screenshot is identical to the one above, showing the Gemtek LTE Configuration web interface. The 'Update' button at the bottom of the form is highlighted with a red box. In the top right corner, the button with the green circle icon is now highlighted with a red box, indicating it has been clicked.

If you ever **FORGOT** to unlock NodeB and save the configuration, you will see the pop-up message to inform you that **“Saving configuration when eNodeB locked will cause eNodeB stop radiating after next reboot, are you sure?”** In this situation, go back to **unlock** eNodeB and save again.



3.2.3 Reconfiguration Reboot

To validate reconfiguration, you should **reboot** eNodeB via the “Management” menu and click “Reboot”.



4. Web Management Interface Reference Manual

4.1 Status

4.1.1 Status | System Status

Select list item – Status | System Status, you can see the information about model name, RF/BB temperature, system up time, memory status, and etc.

| System Status | |
|---------------------|---------------------------|
| Model Name | WLTGFC-105 |
| Serial Number | |
| Baseband HW Version | V00 |
| RF HW Version | V01 |
| Temperature | RF: 41, BB: 49 |
| CPU Loading | 4.22% 2.68% 2.38% |
| Current Date/Time | 2015-05-17 22:02:31 |
| System Up Time | 0 Day 0 Hour 3 Min 21 Sec |
| LTE Service Up Time | 0 Day 0 Hour 0 Min 0 Sec |
| Total Memory | 516476 KB |
| Used Memory | 186828 KB |
| Free Memory | 329788 KB |
| Sync Source | internal |
| Sync Status | N/A |
| CBRS Status | (null),(null) |
| Location | N/A |

These two blocks can check the sync. status if the cell boots with GPS mode.

4.1.2 Status | Network Status

Select list item – Status | Network Status, you can see Small Cell Local/MAC IP address and other Ethernet related information.

| Network Status | |
|------------------------------|-------------------|
| Small Cell Local IP Address | 10.102.81.59 |
| Small Cell Local MAC Address | 1C:49:7B:FB:1C:D1 |
| Default Gateway | 10.102.81.254 |
| DNS Server | 8.8.4.4 |
| IEEE-1588v2 Grand Master | N/A |
| NTP Server | Disabled |
| EMS/ACS Server | N/A |
| SON Server | N/A |
| Security Gateway | Disabled |
| IPSec Status | |
| status | |

4.1.3 Status | LTE Status

Select list item – Status | LTE Status, you can get the LTE general configuration about information of Frequency band, PLMN, MME/eNodeB IP address, Bandwidth, EARFCN, and, etc.

| General Configuration | |
|------------------------|-------------------|
| Cell State | UP |
| Frequency Band | 48 |
| MME IP address | 10.102.81.100 |
| Small Cell IP address | 10.102.81.59 |
| ENodeB Type | Home eNodeB |
| Cell Identity | 10 |
| PHY Cell Group ID | 10 |
| PHY Cell ID | 1 |
| PLMN Identity(MCC+MNC) | 00101 |
| EARFCN | 55990 |
| Bandwidth | 10MHz |
| Current TX Power | 9.780000000000001 |
| FDD/TDD Mode | TDD |

4.1.4 Status | UEs Status

Select list item – Status | UEs Status shown as bellow, you will see here were 2 UEs attached in this case. The DL/UL throughput and MCS index of UE#1 were 7,903/8,465 Kbps and 19/27. And the DL/UL throughput and MCS index of UE#2 were 8,417/5,018 Kbps Kbps and 20/27.

| UEs Status | | | | | | | | |
|------------|--------|------------|------------|--------|----------|------------|------------|--------|
| | UpLink | | | | DownLink | | | |
| 1 | RNTI | BLER(%) | Tput(Kbps) | MCSIdx | RNTI | BLER(%) | Tput(Kbps) | MCSIdx |
| | 101 | 0.02(0.08) | 7903 | 19 | 101 | 0.00(0.01) | 8465 | 27 |
| 2 | RNTI | BLER(%) | Tput(Kbps) | MCSIdx | RNTI | BLER(%) | Tput(Kbps) | MCSIdx |
| | 138 | 0.00(0.10) | 8417 | 20 | 138 | 0.00(0.01) | 5018 | 27 |

4.2 LTE Configuration

4.2.1 LTE Configuration | General

Select list item – LTE Configuration | General, you will see that eNodeB Type have 2 selections to choose, Marco eNodeB and Home eNodeB. As for the other parameters, you can input the responding values to configure your eNodeB.

| General Configuration | |
|---|-------------------------------------|
| ENodeB Type | Home eNodeB ▼ |
| Cell Identity | Marco eNodeB |
| PHY Cell Group ID | Home eNodeB |
| PHY Cell ID | 10 |
| PLMN Identity(MCC+MNC) | 1 |
| Tracking Area Code | 00101 |
| MME IP | 1 |
| MME SCTP Port | 10.102.81.100 |
| Keep local GTP-U Tunnel IP same as eNB IP | 36412 |
| local GTP-U Tunnel IP | <input checked="" type="checkbox"/> |
| UE Inactivity Timer | 10.102.81.59 |
| DSCP Control | More than 30 days ▼ |
| DSCP Data | 0 |
| Update | |

| General Configuration | |
|---|-------------------------------------|
| ENodeB Type | Home eNodeB ▼ |
| Cell Identity | 10 |
| PHY Cell Group ID | 10 |
| PHY Cell ID | 1 |
| PLMN Identity(MCC+MNC) | 00101 |
| Tracking Area Code | 1 |
| MME IP | 10.102.81.100 |
| MME SCTP Port | 36412 |
| Keep local GTP-U Tunnel IP same as eNB IP | <input checked="" type="checkbox"/> |
| local GTP-U Tunnel IP | 10.102.81.59 |
| UE Inactivity Timer | More than 30 da |
| DSCP Control | 0 |
| DSCP Data | 0 |
| Update | |

SCTP Port default is 36412, if it is X-Cell, the SCTP Port will change to 36413

4.2.2 LTE Configuration | Radio Access Network

Select list item – LTE Configuration | Radio Access Network, you will see that Bandwidth can be configured as to 5, 10, 15 and 20 MHz. As for Tx Power, its maximum value is 20. You can also configure the DL EARFCN to what you want, as for the responding UL EARFCN, the system will automatically help you finish it. And RX gain is to adjust the receiver gain of RF.

| Radio Access Network | |
|---------------------------------------|-----------|
| Frequency Band | 48 |
| Bandwidth | 10 ▼ MHz |
| RS Power | -7 dBm |
| Path Loss | 1 dBm |
| Antenna Gain | 5 dBm |
| TX Power | 17.78 dBm |
| EIRP | 21.78 dBm |
| DL EARFCN | 55990 |
| RX Gain | 35 |
| Uplink Downlink Configuration | 2 ▼ |
| Special Subframe Configuration | 7 ▼ |
| <input type="button" value="Update"/> | |

TDD has an additional mode, you can change “Uplink Downlink Configuration” to setup the UL/DL ratio according to your requirement. We support configuration 1~5.

Note that the following chapters (4.2.3 & 4.2.4) are the settings with multiple small cells. Thus, if you are X-cell, you can ignore these parts.

4.2.3 LTE Configuration | Neighbor List

Before adding neighbors, you first have to check the frequency is intra or inter. If the neighbor is an intra-frequency neighbor, you can directly add a neighbor cell under the frequency of the eNodeB. If no cells are added, ANR will still be working to add any neighbor cell that UE reports to the neighbor relation table of this eNodeB.

Neighbor List

Intra Frequency

| | |
|-----------|-------|
| EARFCN | 55990 |
| QRxLevMin | -60 |

Add New Cell

Add New Frequency

Update

Edit the information of the neighbor cell, especially the Cell ID, PHY cell group ID, PHY Cell ID, and Bandwidth. If X2 HO is not needed, IP, Port, eNB Type, eNB ID, MCC, MNC, and MME CGI can be ignored. After edited, press the **Update** button to apply the changes. And don't forget to save your changes.

Neighbor List

Intra Frequency

| | |
|-----------|-------|
| EARFCN | 55990 |
| QRxLevMin | -60 |

Cell 0[Delete]

| | | | |
|-------------------|---------------|-------------|------------|
| Cell Identity | 100 | TAC | 123 |
| PHY Cell Group ID | 10 | PHY Cell ID | 1 |
| Include in SIB5 | Enabled ▾ | QOffset | 15 |
| Allow HO | Enabled ▾ | Force S1-HO | Disabled ▾ |
| IP | 192.168.1.1 | Port | 36422 |
| eNB Type | Home eNodeB ▾ | eNB ID | 100 |
| MCC | 123 | MNC | 45 |

Add New Cell

Add New Frequency

Update

If the neighbor cell is inter-frequency, press the “Add New Frequency” button to add a new EARFCN. The “Delete” link can be used to delete this frequency. Press the “Add New Cell” button under this inter-frequency to add a new neighbor cell. If no cells are added, ANR will still be working to add any neighbor cell that UE reports to the neighbor relation table of this eNodeB.

Neighbor List

Intra Frequency

| | |
|-----------|-------|
| EARFCN | 55990 |
| QRxLevMin | -60 |

Add New Cell

Inter Frequency

| | |
|---------------------------------|-------|
| EARFCN [Delete] | 56090 |
| QRxLevMin | -60 |

Add New Cell

Add New Frequency

Update

Edit the information of the neighbor cell. The “Delete” link can be used to delete the cell. After edited, press the **Update** button to apply the changes. And don’t forget to save your changes.

Intra Frequency

| | |
|-----------|-------|
| EARFCN | 55990 |
| QRxLevMin | -60 |

Add New Cell

Inter Frequency

| | |
|---------------------------------|-------|
| EARFCN [Delete] | 56090 |
| QRxLevMin | -60 |

Cell 0 [\[Delete\]](#)

| | | | |
|-------------------|-------------|-------------|----------|
| Cell Identity | 100 | TAC | 123 |
| PHY Cell Group ID | 10 | PHY Cell ID | 1 |
| Include in SIB5 | Enabled | QOffset | 15 |
| Allow HO | Enabled | Force S1-HO | Disabled |
| IP | 192.168.1.1 | Port | 36422 |
| eNB Type | Home eNodeB | eNB ID | 100 |
| MCC | 123 | MNC | 45 |

Add New Cell

Add New Frequency

Update

4.2.4 LTE Configuration | Measurement Report Triggers

Select list item – LTE Configuration | Measurement Report Triggers, you can edit the A1/A2/A3/A4/A5 trigger conditions.

| Measurement Report Triggers | |
|---------------------------------------|---------------------------------------|
| A1 event | |
| RSRP Threshold | <input type="text" value="70"/> |
| Hysteresis | <input type="text" value="2"/> |
| Time to Trigger | <input type="text" value="640"/> ms |
| Max Report Cells | <input type="text" value="4"/> |
| Report Interval | <input type="text" value="2048ms"/> |
| Report Amount | <input type="text" value="Infinity"/> |
| A2 event | |
| RSRP Threshold | <input type="text" value="60"/> |
| Hysteresis | <input type="text" value="2"/> |
| Time to Trigger | <input type="text" value="640"/> ms |
| Max Report Cells | <input type="text" value="4"/> |
| Report Interval | <input type="text" value="2048ms"/> |
| Report Amount | <input type="text" value="Infinity"/> |
| A3 event | |
| Offset | <input type="text" value="6"/> |
| Report on Leave | <input type="text" value="False"/> |
| Hysteresis | <input type="text" value="4"/> |
| Time to Trigger | <input type="text" value="320"/> ms |
| Max Report Cells | <input type="text" value="4"/> |
| Report Interval | <input type="text" value="480ms"/> |
| Report Amount | <input type="text" value="Infinity"/> |
| A4 event | |
| RSRP Threshold | <input type="text" value="80"/> |
| Hysteresis | <input type="text" value="6"/> |
| Time to Trigger | <input type="text" value="640"/> ms |
| Max Report Cells | <input type="text" value="8"/> |
| Report Interval | <input type="text" value="1min"/> |
| Report Amount | <input type="text" value="64"/> |
| A5 event | |
| RSRP Threshold 1 | <input type="text" value="70"/> |
| RSRP Threshold 2 | <input type="text" value="70"/> |
| Hysteresis | <input type="text" value="2"/> |
| Time to Trigger | <input type="text" value="640"/> ms |
| Max Report Cells | <input type="text" value="4"/> |
| Report Interval | <input type="text" value="480ms"/> |
| Report Amount | <input type="text" value="Infinity"/> |
| <input type="button" value="Update"/> | |

4.2.5 CBRS Configuration

✖Please make sure that the time of the eNB is the same as the time of the SAS Server. Otherwise, the certificate will fail.

| CBRS Configuration | |
|-----------------------|---------------------|
| CBRS Enable | Enabled ▼ |
| SAS Server | 10.102.81.66 |
| SAS Server port | 443 |
| SAS Version | v1.2 |
| SAS Host | www.gemteks.com.tw |
| Load Certificate | Enabled ▼ |
| Cert Authentication | Enabled ▼ |
| CA Bundle Certificate | 選擇檔案 未選擇任何檔案 Upload |
| Issuer: Subject: | |
| Client Certificate | 選擇檔案 未選擇任何檔案 Upload |
| Issuer: Subject: | |
| Client Private Key | 選擇檔案 未選擇任何檔案 Upload |
| Status: | |
| CRL Check | Disabled ▼ |
| CRL File | 選擇檔案 未選擇任何檔案 Upload |
| Update | |

CBRS Enable: Enable CBRS Function

SAS Server: SAS Server's IP Address or Domain Name

SAS Server port: SAS Service Port Number

SAS Version: SAS-CBSD protocol version

SAS Host: SAS Server's host name

Load Certificate: Use certificate (default is enable)

Cert Authentication: Enable mutual authentication (client side)

CRL Check: enable CRL check

※This page is visible when CBRS Enable = Enable.

User can set CBRS protocol parameter using this page.

| Registration Request Parameter | |
|---------------------------------------|--|
| userId | <input type="text" value="gtkUser01"/> |
| fccId | <input type="text" value="gtkCbsd01"/> |
| cbsdSerialNumber | <input type="text" value="gtkCbsdSn01"/> |
| callSign | <input type="text"/> |
| cbsdCategory | <input type="text" value="A"/> |
| cbsdInfo | <input type="text"/> |
| airInterface | <input type="text" value="E_UTRA"/> |
| measCapability | <input type="text" value="RECEIVED_POWER_WITH"/> |
| installationParam(Optional) | |
| latitude | <input type="text" value="44"/> |
| longitude | <input type="text" value="-93"/> |
| height | <input type="text" value="9"/> |
| heightType | <input type="text" value="AGL"/> |
| horizontalAccuracy | <input type="text"/> |
| verticalAccuracy | <input type="text"/> |
| indoorDeployment | <input type="text" value="1"/> |
| antennaAzimuth | <input type="text"/> |
| antennaDowntilt | <input type="text"/> |
| antennaGain | <input type="text" value="5"/> |
| eirpCapability | <input type="text"/> |
| antennaBeamwidth | <input type="text"/> |
| antennaModel | <input type="text"/> |
| groupingParam(Optional) | |
| groupType | <input type="text"/> |
| groupId | <input type="text"/> |
| cpiSignatureData(Optional) | |
| protectedHeader | <input type="text"/> |
| encodedCpiSignedData | <input type="text"/> |
| digitalSignature | <input type="text"/> |
| SpectrumInquiry Request Parameter | |
| inquiredSpectrum | <input type="text" value="3680000000,3690000000;3"/> |
| <input type="button" value="Update"/> | |

4.3 Syslog

4.3.1 Syslog | Operation Log

```
Jan 1 00:00:23 (none) local1.info root: [MSG_CENTER] : Operation Normal
Jan 1 00:00:23 (none) local1.info root: [CMS] : Operation Normal
Jan 1 00:00:24 (none) local1.info root: [Network Static ip] : Operation Normal
Dec 31 16:00:24 (none) local1.info root: [NTP] : Operation Disable
Jan 2 00:00:00 LSM local1.info root: [Telnet] : Operation Normal
Jan 2 00:00:00 LSM local1.info root: [Zabbix] : Operation Disable
Jan 2 00:00:35 LSM local1.info root: [MIF] : Operation Normal
Jan 2 00:00:48 LSM local1.info root: [GEMTEK-RF] : Operation Normal
```

4.3.2 Syslog | Configuration Log

```
Jan 2 00:05:25 LSM local2.info root: admin login to web management console success
Jan 2 00:11:13 LSM local2.info root: admin login to web management console success
Jan 2 00:16:12 LSM local2.info root: adminstate changed to 0
Jan 2 00:22:44 LSM local2.info root: adminstate changed to 1
```

4.3.3 Syslog | Alarm Log

```
Jan 2 00:00:50 LSM local3.info gtkSwitch: SFP0 link state change to [down]
Jan 2 00:00:50 LSM local3.info gtkSwitch: SFP1 link state change to [down]
Jan 2 00:00:50 LSM local3.info gtkSwitch: ETH link state change to [up]
```

4.3.4 Syslog | Export Log Files

| Export Log File | |
|-----------------|---------------------------------------|
| Export Log File | <input type="button" value="Export"/> |

4.4 Management

4.4.1 Management | Network Configuration

Below is the default setting. Here, you can edit eNodeB static IP、VLAN and DNS.

| Network Configuration | |
|---|---|
| DHCP | Disabled ▼ |
| VLAN | Disabled ▼ |
| IP <input data-bbox="252 566 284 600" type="button" value="+"/> | <input type="text" value="10"/> . <input type="text" value="102"/> . <input type="text" value="81"/> . <input type="text" value="59"/> |
| Netmask | <input type="text" value="255"/> . <input type="text" value="255"/> . <input type="text" value="255"/> . <input type="text" value="0"/> |
| Default Gateway | <input type="text" value="10"/> . <input type="text" value="102"/> . <input type="text" value="81"/> . <input type="text" value="254"/> |
| Primary DNS | <input type="text" value="8"/> . <input type="text" value="8"/> . <input type="text" value="8"/> . <input type="text" value="8"/> |
| Secondary DNS | <input type="text" value="8"/> . <input type="text" value="8"/> . <input type="text" value="4"/> . <input type="text" value="4"/> |
| <input type="button" value="Update"/> | |

4.4.2 Management | IPsec Configuration

Below is the default setting. you can edit eNodeB Server IP、Client IP and fill in the empty blocks.

| IPsec Configuration | |
|---------------------------------------|--|
| IPsec Function | Disabled ▼ |
| Server IP | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> |
| Client ID | Default ▼ <input type="text"/> |
| Server ID | Same as IP ▼ <input type="text"/> |
| Authentication | Pre-shared Key ▼ |
| Remote Subnet | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> / <input type="text"/> |
| Pre-shared Key | <input type="text"/> |
| Root CA Certificate | <input type="button" value="選擇檔案"/> 未選擇任何檔案 <input type="button" value="Upload"/> |
| Issuer: | |
| Subject: | |
| Client Certificate | <input type="button" value="選擇檔案"/> 未選擇任何檔案 <input type="button" value="Upload"/> |
| Issuer: | |
| Subject: | |
| Client Private Key | <input type="button" value="選擇檔案"/> 未選擇任何檔案 <input type="button" value="Upload"/> |
| Status: | |
| <input type="button" value="Update"/> | |

4.4.3 Management | System Configuration

Below is the default setting.

| System Configuration | |
|---------------------------------------|------------|
| Redirect to Syslog Server | Disabled ▼ |
| ReEst Function | Disabled ▼ |
| ANR Function | Enabled ▼ |
| SON Function | Disabled ▼ |
| EMS Function | Disabled ▼ |
| Bootstrap Function | Disabled ▼ |
| Logdisp Function | Disabled ▼ |
| <input type="button" value="Update"/> | |

4.4.4 Management | Routing Configuration

Below is the default setting. You can edit the Route Type, Destination, Mask, Gateway, Interface and fill in the empty blocks.

| Routing Configuration | | | |
|---|---|---------|-------|
| Route Type | net ▼ | | |
| Destination | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> | | |
| Mask | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> | | |
| Gateway | <input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> | | |
| Interface | <input type="text"/> | | |
| <input type="button" value="Update"/> <input type="button" value="Delete"/> | | | |
| Destination | Gateway | Genmask | Iface |


4.4.5 Management | Configuration File

Here provide “Export Configuration”, “Import Configuration” and “Restore Last Configuration” functions to manage your eNodeB configuration files.

| Configuration File | |
|----------------------------|---|
| Export Configuration | <input type="button" value="Export"/> |
| Import Configuration | <input type="button" value="選擇檔案"/> 未選擇任何檔案 <input type="button" value="Import"/> |
| Restore Last Configuration | <input type="button" value="Restore"/> |

a. Export Configuration:

Click **Export** button and select “Download Link”, your browser will download “config.tar.gz” file



to your computer.


| Configuration File | |
|----------------------------|--|
| Export Configuration | <input type="button" value="Export"/> <input type="button" value="Download Link"/> |
| Import Configuration | <input type="button" value="選擇檔案"/> 未選擇任何檔案 <input type="button" value="Import"/> |
| Restore Last Configuration | <input type="button" value="Restore"/> |

b. Import Configuration:


Select a backup “config.tar.gz” and press **Import** button. You will change the configuration files on your eNodeB (Pop-up message will show: Import success).

| Configuration File | |
|----------------------------|---|
| Export Configuration | <input type="button" value="Export"/> |
| Import Configuration | <input type="button" value="選擇檔案"/> 未選擇任何檔案 <input type="button" value="Import"/> <input type="button" value="activate"/> |
| Restore Last Configuration | <input type="button" value="Restore"/> |

| Configuration File | |
|----------------------------|---|
| Export Configuration | <input type="button" value="Export"/> |
| Import Configuration | <input type="button" value="選擇檔案"/> config.tar.gz <input type="button" value="Import"/> <input type="button" value="activate"/> |
| Restore Last Configuration | <input type="button" value="Restore"/> |




Click the 'active' button to activate the new configuration file.



Then **reboot** eNodeB to validate the reconfiguration.

c. Restore Last Configuration:

This function can help you recover eNodeB to the last version of configuration. You should just select **Restore** button and get “Restore success” pop-up message. But you should also **reboot** eNodeB to get recovery.



4.4.6 Management | Firmware Utility

The Web GUI provides “Firmware Rollback” and “Core Firmware” functions for customer to change image. You will see below eNodeB having dual images, now, Dual Block 1 is in Active and Dual Block 2 is in Inactive. In this case, the image saved in Dual Block 2 will become active (1) to recover your eNodeB if you run “Firmware Rollback”, or (2) to be replaced by new image if you run “Firmware Upgrade”.

a. Firmware Rollback:

Once press the **Firmware Rollback** button, the Small cell will rollback to another block immediately.

Core Firmware

選擇檔案 未選擇任何檔案

Firmware Upgrade

| | | |
|--------------|-------------------------------------|----------|
| Dual Block 1 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Inactive |
| Dual Block 2 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Active |

Firmware Rollback

Boot Loader

← → ↺

⚠ 不安全 | 10.102.81.59/main.html

10.102.81.59 顯示

Do you want to perform eNodeB firmware rollback?

確定

取消

Gemtek

2.1.1878.562-wltgfc105-gemtek-tdd-X

Status

LTE Configuration

Syslog

Management

Logout

Network Configuration

IPsec Configuration

System Configuration

Routing Configuration

Configuration File

Firmware Utility

Change Login Password

Software Package Manager

Time Settings

CSFB Settings

Reset to Factory Default

Core Firmware

選擇檔案 未選擇任何檔案

Firmware Upgrade

| | | |
|--------------|-------------------------------------|----------|
| Dual Block 1 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Inactive |
| Dual Block 2 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Active |

Firmware Rollback

Boot Loader

選擇檔案 未選擇任何檔案

Firmware Upgrade

| | |
|---------|------------|
| Version | svn1335.v4 |
|---------|------------|

| Core Firmware | | |
|------------------------------------|-------------------------------------|----------|
| Dual Block 1 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Active |
| Dual Block 2 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Inactive |
| Firmware rolled back. Rebooting... | | |
| Boot Loader | | |

Here, you can see the Dual Block 1 image become “Active”.

b. Firmware Upgrade:

Choose a new image from PC directory that contains the new image and press **Firmware Upgrade** button.


| Core Firmware | | |
|-------------------|-------------------------------------|------------------|
| 選擇檔案 | 未選擇任何檔案 | Firmware Upgrade |
| Dual Block 1 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Active |
| Dual Block 2 | | Inactive |
| Firmware Rollback | | |
| Boot Loader | | |
| 選擇檔案 | 未選擇任何檔案 | Firmware Upgrade |
| Version | svn1335.v4 | |

This process need several seconds loading new image and then show the below information for you to check.

| Core Firmware | | |
|----------------------------|-------------------------------------|------------------|
| Uploading...Please Wait... | | |
| Dual Block 1 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Active |
| Dual Block 2 | | Inactive |
| Firmware Rollback | | |
| Boot Loader | | |
| 選擇檔案 | 未選擇任何檔案 | Firmware Upgrade |
| Version | svn1335.v4 | |

Check the image and click **Upgrade** button to upgrade firmware.
Wait a few minutes for the process to finish.

| Core Firmware | |
|---------------|--|
| Version | 2.1.1878.562-wltgfc105-gemtek-tdd-X |
| Signature | 19138DA0E00EBF80281392D62237DD1A 17C4BFAAAE73C3DE1A2CCBAD0B148236 B597CFD0A5582786374A3882B1FA0626 E1DD22E4F31B0DF28C0865BB672DE24C FE66FF05A43D170BF7D0555EF9931DAE 0CA133A67EC08D2B0B34DF24C91434AE 32751CD99CF3C8A86872B3F627685F0C E840E3DDFE87B306903CBBE435A224AD |
| Kernel | 4011129 bytes |
| Software | 40378404 bytes |
| Upgrade | |



After finishing firmware upgrade and login Web GUI, you will find that the upgrade process results in Dual Block 2 become “Active” and the older one saved on Dual Block 1 was marked as “Inactive”.

| Core Firmware | | |
|---|-------------------------------------|----------|
| <div>選擇檔案 未選擇任何檔案</div> <div>Firmware Upgrade</div> | | |
| Dual Block 1 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Inactive |
| Dual Block 2 | 2.1.1878.562-wltgfc105-gemtek-tdd-X | Active |
| <div>Firmware Rollback</div> | | |

4.4.7 Management | Change Login Password

- Default password: admin (length is 5 characters long)
- New password length should be 6-10 characters long.

| Change Login Password | |
|---------------------------------------|--------------------------|
| Old Password | <input type="password"/> |
| New Password | <input type="password"/> |
| Confirm New Password | <input type="password"/> |
| <input type="button" value="Update"/> | |

- Once “Update” the new password, you will be asked to login with new password again as follows.

Gemtek

WLTGFC-105 Login

Username

Password


☐ Keep me logged in

Login

Copyright© 2015 Gemtek Technology Co., Ltd.

4.4.8 Management | Software Package Management

Normally, customer will not use this function. This feature is used to install some utilities to debug Small Cell issues and will be under Gemtek engineer authorization and manipulation.



The screenshot displays the 'Management' section of the Gemtek TDD LTE Small Cell User Guide. The left sidebar contains a list of navigation links, with 'Software Package Manager' highlighted by a red box and a red arrow pointing to the main content area. The main content area shows the 'Software Package Manager' interface, which includes a table of installed packages and an 'Install' button.

| Software Package Manager | |
|--|--------|
| Free space: 6.5M | |
| Name | Status |
| tcpdump[Remove] | Valid |
| telnetd[Remove] | Valid |
| <div>選擇檔案 未選擇任何檔案</div> <div>Install</div> | |

4.4.9 Management | Time Setting

1) **1588 Function:** Enable/Disable

2) **Protocol:** 802.3/udp

802.3 is ethernet's protocol.

Udp is ipv4's protocol.

Before using 1588, please make sure your eNodeB can access 1588 server via ping operation without issue.

3) **1588 Type:** multicast/unicast

⊙ **multicast** is group communication where data transmission is addressed to a group of destination computers simultaneously. Multicast can be one-to-many or many-to-many distribution

⊙ **unicast** refers to a one-to-one transmission from one point in the network to another point; that is, one sender and one receiver, each identified by a network address.

4) **NTP Function:** Disable/Enable

The Network Time Protocol (NTP) is a networking protocol for clock synchronization between computer systems over packet-switched, variable-latency data networks.

5) **Timezone:** Please select the time of your location.

6) **NTP Server Name:** Default setting is 2015-5-17 14:0:0 (year-month-day hr:min:sec).

* Not required to lock eNodeB to change settings at this page

| Time Setting | |
|----------------------------|--------------------------|
| 1588 Function | Enabled ▾ |
| 1588 Protocol | 802.3 ▾ |
| 1588 Type | multicast ▾ |
| NTP Function | Disabled ▾ |
| Timezone | (GMT+08:00) Taipei ▾ |
| Initial System Time (UTC)? | 2015 - 5 - 17 14 : 0 : 0 |

Update

4.4.10 Management | CSFB Configuration

Below is the default setting. You can select the different modes of priority

* Not required to lock eNodeB to change settings at this page

| CSFB Configuration | |
|-----------------------------------|----------------------|
| Normal Priority RatType | DEFAULT ▼ |
| Normal Priority Action | Cell Redir ▼ |
| Normal Priority UltraFDD_DL_Arfcn | <input type="text"/> |
| High Priority RatType | DEFAULT ▼ |
| High Priority Action | Cell Redir ▼ |
| High Priority UltraFDD_DL_Arfcn | <input type="text"/> |




| Geran CSFB Configuration | |
|--------------------------|-----------|
| Band Indicator | DCS1800 ▼ |
| Number of GSM Arfcn | 0 ▼ |

4.4.11 Management | Reset to Factory Default

Factory default mode, there are three modes. Please select the operating mode.

| Reset to Factory Default | |
|-----------------------------------|--|
| Keep network settings | Reset all settings ▼ |
| <input type="button" value="Go"/> | <div>Reset all settings</div> <div>Keep network settings</div> <div>Keep all configurable settings</div> |

4.4.12 Management | Reboot System



4.5 Logout

You can click "Logout" tab in any window to log out and then go back to Login page.

Gemtek

2.1.1878.562-wltgfc105-gemtek-tdd-X

[Status](#)
[LTE Configuration](#)
[Syslog](#)
[Management](#)
[Logout](#)

System Status

Network Status

LTE Status

UEs Status

| System Status | |
|---------------------|---------------------------|
| Model Name | WLTGFC-105 |
| Serial Number | |
| Baseband HW Version | V00 |
| RF HW Version | V01 |
| Temperature | RF: 45, BB: N/A |
| CPU Loading | (null)% (null)% (null)% |
| Current Date/Time | 2015-05-17 22:00:35 |
| System Up Time | 0 Day 0 Hour 1 Min 25 Sec |
| LTE Service Up Time | N/A |

Gemtek

WLTGFC-105 Login

Username


Password

☐ Keep me logged in

Login

4.6 LED Definition

4.6.1 LED Behavior



LED ON/OFF Sequence:

Uboot LED light Process :

LTE user LED ON ->LTE LED ON ->Power LED ON ->LTE user LED OFF ->LTE LED OFF ->Power LED OFF

| LED display | Behavior |
|--------------------|--|
| Power & System LED | Green : Power ready and system ready(default) |
| | Red : 1. Power ok during booting the device |
| | 2. System Error or Alarm. |
| LTE User LED | On : UEs attached. |
| | Blink :UE's Traffic Tx/Rx |
| | Off : No active UE on line |
| LTE LED | On : Cell Setup successfully, LTE service is ready. |
| | Blink : Tx/Rx LTE Traffic |
| | Off : No LTE server. |
| Ethernet LED | On : Ethernet connected |
| | Blink : Under Ethernet traffic |
| | Off : No Ethernet can be connected |
| GPS sync. LED | On : GPS source is ready |
| | Blink : Under Synchronization |
| | Off : No GPS can be detected |

5. All-In-One Small Cell (X-Cell) Web Management Interface Reference Manual

Since the web management of the All-In-One small cell (X-cell) is the same except for the “EPC” icon. Please follow “Chapter 3.2.2 Modify Configuration” to modify the X-cell configuration parameters. **The following part is the settings of the embedded EPC.**

5.1 EPC

5.1.1 EPC | EPC-MME Configuration

Select list item – EPC | EPC-MME Configuration, You can set MME code, APN and UE Start IP for EPC. Then, you can select LTE MQTT status and Time Zone.

The screenshot displays the Gemtek web management interface for EPC-MME Configuration. The interface includes a sidebar with 'EPC-MME Configuration' and 'User Configuration' links. The main configuration area contains the following fields:

- MME Code:** A text input field containing the value '1'.
- APN:** A text input field containing the value 'internet'. A red callout box points to this field with the text: "This field name must be the same as the cell phone's APN".
- UE Start IP:** A series of four text input fields containing the values '10', '59', '0', and '2' respectively.
- LTE MQTT:** A dropdown menu currently set to 'Enabled'.
- LTE NAT:** A dropdown menu currently set to 'Disabled'.
- Time Zone:** A dropdown menu showing '+', a spinner set to '8', and another dropdown set to '0'.

An 'Update' button is located at the bottom of the configuration form.

1. Click 'EPC' tag.
2. Click 'EPC-MME' Configuration
3. Please base on your test environment to configure these parameters for MME.
 - i. MME Code : 1~255
 - ii. APN : The max length is 64
 - iii. UE Start IP : UE IP Address
 - iv. LTE MQTT: **This is for special application use only. Please don't enable it.** If enable it, it will reduce the system throughput performance.
 - v. Time Zone: The value is assigned to UEs after UEs have attached completed.
4. If you update the value, you must reboot the system.

5.1.2 EPC | HSS-KEY Configuration

Select list item – EPC | HSS-KEY Configuration, You can check IMSI list.

| HSS-KEY Configuration | | |
|---------------------------------------|--------------------------------------|---------------------------------------|
| <input type="button" value="Update"/> | <input type="button" value="Clear"/> | <input type="button" value="Delete"/> |
| IMSI | <input type="text"/> | |
| KEY | <input type="text"/> | |
| OP | <input type="text"/> | |
| IMSI | | |
| 001010000001318 | 001010000002004 | |

When you click IMSI number, you can see the information of KEY and OP.

| HSS-KEY Configuration | | |
|---------------------------------------|---|---------------------------------------|
| <input type="button" value="Update"/> | <input type="button" value="Clear"/> | <input type="button" value="Delete"/> |
| IMSI | <input type="text" value="001010000001318"/> | |
| KEY | <input type="text" value="5639F31C279C36EF00DEAB6E5354A14E"/> | |
| OP | <input type="text" value="3883BA4151FCC2C26437A5D4DE0BB09C"/> | |
| IMSI | | |
| 001010000001318 | 001010000002004 | |

You can add IMSI by input IMSI, KEY and OP field and click Update button.

| HSS-KEY Configuration | | |
|---------------------------------------|---|---------------------------------------|
| <input type="button" value="Update"/> | <input type="button" value="Clear"/> | <input type="button" value="Delete"/> |
| IMSI | <input type="text" value="001010000001319"/> | |
| KEY | <input type="text" value="5639F31C279C36EF00DEAB6E5354A14E"/> | |
| OP | <input type="text" value="3883BA4151FCC2C26437A5D4DE0BB09C"/> | |
| IMSI | | |
| 001010000001318 | 001010000002004 | |

| HSS-KEY Configuration | | |
|---------------------------------------|--------------------------------------|---------------------------------------|
| <input type="button" value="Update"/> | <input type="button" value="Clear"/> | <input type="button" value="Delete"/> |
| IMSI | <input type="text"/> | |
| KEY | <input type="text"/> | |
| OP | <input type="text"/> | |
| IMSI | | |
| 001010000001318 | 001010000002004 | 001010000001319 |


You can delete IMSI by input IMSI, KEY and OP field and click Delete button.

| HSS-KEY Configuration | | |
|---------------------------------------|---|---------------------------------------|
| <input type="button" value="Update"/> | <input type="button" value="Clear"/> | <input type="button" value="Delete"/> |
| IMSI | <input type="text" value="001010000001319"/> | |
| KEY | <input type="text" value="5639F31C279C36EF00DEAB6E5354A14E"/> | |
| OP | <input type="text" value="3883BA4151FCC2C26437A5D4DE0BB09C"/> | |
| IMSI | | |
| 001010000001318 | 001010000002004 | 001010000001319 |

| HSS-KEY Configuration | | |
|---------------------------------------|--------------------------------------|---------------------------------------|
| <input type="button" value="Update"/> | <input type="button" value="Clear"/> | <input type="button" value="Delete"/> |
| IMSI | <input type="text"/> | |
| KEY | <input type="text"/> | |
| OP | <input type="text"/> | |
| IMSI | | |
| 001010000001318 | 001010000002004 | |

5.2 X-Cell Network Planning

- For Example



1. The X-Cell need to setup the Default Gateway to **Router**.

Ex: In the Figure, the IP of Router is 10.102.81.1. We must setup the GW to 10.102.81.1. How to set the Default Gateway, you can reference [4.4.1 **Management | Network Configuration**].

2. The **Router** must set a static routing rule:

Ex: The X-Cell assigns the IP 10.200.59.X to UEs. We must set a routing rule for this router.

Linux cmd: **route add -net 10.200.59.0/24 gw 10.102.81.59**

10.200.59.0 is UE's IP

24 is the mask of UE's IP and this value = **255.255.255.0**

10.102.81.59 is X-Cell's IP

3. If the Router has a web management. You can reference the User's Guild of the router to add a static routing rule. You can set the ip **10.200.59.0**, mask **255.255.255.0**, and GW is **10.102.81.59**.

5.3 Cell Phone APN Settings:

iOS (Please follow these operating steps by taking iPhone7 as an example)



Step1: Settings → Cellular → Cellular Data Options → Cellular Data Network



Step2: Please enter 「internet」 for the APN field (other fields just left as blank)

Step3: Back to Setting → Carrier → Network Selection → Turn on "Automatic"

Step4: After a few seconds or minutes, it will be connected to the small cell automatically.

※If not, please reboot and let the phone to search signal again.







Android (Please follow these operating steps by taking Samsung as an example)





Step1: Settings → Connections → Mobile networks → Access Point Names → ADD

Step2: Edit access point → Edit Name (input "internet" in the field) → Edit APN (input "internet" in the field) → Press the top right corner of the screen to save (Other fields just left as blank)

Step3: After a few seconds or minutes, it will be connected to the small cell automatically.

※If not, please reboot and let the phone to search signal again.





4G 31% 02:14

< Edit access point

Name
internet

APN
internet

Proxy
Not set

Port
Not set

Username
Not set

Password
Not set

Server
Not set

MMSC
Not set

Multimedia message proxv

4G 31% 02:14

< Edit access point

Save

Discard

Name
internet

APN
internet

Proxy
Not set

Port
Not set

Username
Not set


Password
Not set

Server
Not set

MMSC
Not set

Multimedia message proxv


5.4 Small Cell Wall Mount Accessory Installation



<Gemtek Small Cell Standard Wall Mount Equipment Installation>



<Gemtek Small Cell Wall Mount Equipment Installation Example>




<Installation Steps>

● About Gemtek Small Cell Grounding Construction

- (1) The position of the grounding rod and the Gemtek Small Cell must be the shortest position of the grounding wire.
- (2) The grounding rod needs at least 8 inches from the ground.
- (3) Connect the grounding clip to the grounding rod. You will use this grounding clip to provide a grounding band connection between the Small Cell and the outdoor antenna, refer to the ground connection diagram.
- (4) Connect the grounding band to the grounding wire.
- (5) Remove the ground screw of Gemtek Small Cell. Position the ground screw through the grounding band and reinstall the Gemtek Small Cell.
- (6) Connect the grounding band to the grounding clamp and refer to the ground connection diagram.
- (7) Gemtek Small Cell grounding construction is completed.



<Gemtek Small Cell Grounding Point Diagram>



<Ground Connection Diagram>

6 Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Professional installation instruction

Please be advised that due to the unique function supplied by this product, the device is intended for use with our interactive entertainment software and licensed third-party only. The product will be distributed through controlled distribution channel and installed by trained professional and will not be sold directly to the general public through retail store.

1). Installation personal

This product is designed for specific application and needs to be installed by a qualified personal who has RF and related rule knowledge. The general user shall not attempt to install or change the setting.

2). Installation location

The product shall be installed at a location where the radiating antenna can be kept 20 cm from nearby person in normal operation condition to meet regulatory RF exposure requirement.

3). External antenna

Use only the antennas which have been approved by Gemtek. The non-approved antenna(s) may produce unwanted spurious or excessive RF transmitting power which may lead to the violation of FCC limit and is prohibited.

4). Installation procedure

Please refer to user's manual for the detail.

5). Warning

Please carefully select the installation position and make sure that the final output power does not exceed the limit set force in relevant rules. The violation of the rule could lead to serious federal penalty.

Since WLTGFC-105/CBRS is a Category A device the product can only be installed outdoors below 6m height AGL or indoors.