


Router Mode

1 Connect the Hardware

Connect the hardware as shown in the diagram below. The router should be connected to the power supply and the network cable.



Note: If you don't use the network cable, please search the "Wireless AP" or "Wireless LAN" wireless signal and connect with it.

1. You can modify the settings according to the service information provided by your ISP.



2 Connect to the repeater

For phone users

1. Find the 3G/4G Network Name and Wireless Password printed on the label at the bottom of the router.



2. Launch a web browser, and enter <http://192.168.1.1> in the address bar. Select **Router Mode**.



If you choose Dynamic IP, Dynamic IP users are usually equipped with a cable TV or fiber cable.



2. When using the 3G/4G wireless signal, please enter the Wireless Password.

Click **Apply** and follow the prompts on the page to complete the Router mode configuration.

If you choose PPPoE, enter the username and password provided by your ISP. PPPoE users usually have DSL cable modems.



2. When using the 3G/4G wireless signal, please enter the Wireless Password.

Click **Apply** and follow the prompts on the page to complete the Router mode configuration.

If you choose Static IP, enter the information provided by your ISP in the corresponding fields.



2. When using the 3G/4G wireless signal, please enter the Wireless Password.


2. When using the 3G/4G wireless signal, please enter the Wireless Password.

Click **Apply** and follow the prompts on the page to complete the Router mode configuration.

Caution: To be loaded correctly (static IP) and password, and when using the 3G/4G wireless signal, please enter the Wireless Password.

AP Mode

1 Connect the Hardware



Note: If you don't use the network cable, please search the "Wireless AP" or "Wireless LAN" wireless signal and connect with it.

2 Connect to the repeater

For phone users

1. Find the 3G/4G Network Name and Wireless Password printed on the label at the bottom of the router.



2. Launch a web browser, and enter <http://192.168.1.1> in the address bar. Select **AP Mode**.



2. When using the 3G/4G wireless signal, please enter the Wireless Password.

Click **Apply** and follow the prompts on the page to complete the AP mode configuration.

Caution: To be loaded correctly (static IP) and password, and when using the 3G/4G wireless signal, please enter the Wireless Password.

Frequently Asked Questions(FAQ)

- Q1. What can I do if the login window does not appear?
 - If the computer is set to a static or fixed IP address, change the setting to obtain an IP address automatically.
 - Verify if <http://192.168.1.1> is correctly entered in the web browser.
 - Make sure your computer is connected to the Mini Router's network.
 - Use another web browser and try again.
 - Restart your router and try again.
 - Disable the network adapter used currently and then enable it again.
- Q2. What can I do if I cannot access the Internet?
 - Check if the Internet is working properly by connecting a computer directly to the modem via Ethernet cable. If not, connect your Internet provider.
 - Restart your router and try again.
- Q3. How do I restore the router to its factory default setting?
 - While the router is powered on, press and hold the reset button on the rear panel of the router for approximately 10 seconds.
- Q4. Why set the repeater mode is unsuccessful?
 - You may have typed in the router's wireless password incorrectly, please log in and check the wireless password.
 - The Mini router may be out of range, please move it closer to the router.
 - Please reset the Mini Router and go through the configuration again.

A. If you need reset the extender, You need press and hold the reset button inside the tag hole for 10 seconds.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.