

FCC ID: 2AG32MBS3100190



LTE Base Station
mBS31001

Installation Guide

About This Document

This document is a guidance of mBS31001 hardware installation for installation personnels, including the preparation of installation tools and supporting materials, the demands for installation environment, installation procedure, cable connection and power on.

Accomplish the installation of the device according to this guide, the installation personnel can avoid potential damage to the device during the installation procedure, which makes sure the subsequent good running of the device.

Copyright Notice

Baicells copyrights this specification. No part of this specification may be reproduced in any form or means, without the prior written consent of Baicells.

Disclaimer

This specification is preliminary and is subject to change at any time without notice. Baicells assumes no responsibility for any errors contained herein. For more information, please consult our technical engineers.

Disposal of Electronic and Electrical Waste



Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

Revision Record

Date	Version	Description
22 June, 2018	01	Initial Released.

Contact Us

Baicells Technologies Co., Ltd.

Address: 3F, Hui Yuan Development Building, No.1 Shangdi Information

Industry Base, Haidian Dist., Beijing, China

E-mail: support_cn@baicells.com (Non-North American region)

support_na@baicells.com (North American region)

Website: <http://www.baicells.com/>

Table of Contents

1. Product Overview	1
1.1 Introduction	1
1.2 Features	1
1.3 Appearance	2
1.4 Technical Specification.....	3
1.4.1 Hardware Specification	3
1.4.2 Software Specification.....	4
1.4.3 Environment Specification.....	5
1.4.4 FCC Compliance.....	5
2. Installation Preparation	7
2.1 Support Materials	7
2.2 Installation Tools	7
2.3 Installation Environment.....	8
2.3.1 Locational Requirements.....	8
2.3.2 Environmental Requirements	8
2.4 Personnel Requirements.....	8
2.5 Against Lightening and Grounding Protection	8
2.6 Weatherproof Protection	9
3. Base Station Installation.....	10
3.1 Unpacking.....	10
3.2 Installation Procedure	10
3.3 Install GPS Antenna	10
3.4 Install on Pole	11
3.5 Install on Wall.....	13
3.6 Connect Cable	13
3.6.1 Requirement for Cable Laying.....	13

3.6.2	Connect RF Cable	14
3.6.3	Connect Power Connector	15
3.6.4	Connect Ground Cable	16
3.7	Antenna Feeder System.....	16
	Install	
3.7.1	Install Omnidirectional Antennas.....	16
3.7.2	Install Directional Antennas.....	18
4.	Power On.....	20

List of Figures

Figure 1-1	Appearance	2
Figure 1-2	Interfaces and Indicators.....	2
Figure 3-1	Installation Procedure	10
Figure 3-2	Location of Grounding Screws.....	16
Figure 3-3	Omnidirectional Antenna Installation (1).....	17
Figure 3-4	Omnidirectional Antenna Installation (2).....	18
Figure 3-5	Assembling Procedure of Directional Antennas	18
Figure 3-6	Transportation the Antennas in the Height	19
Figure 3-8	Directional Antenna Installation	19
Figure 4-1	LED Indicators.....	20

List of Tables

Table 1-1	Interface Description	3
Table 1-2	Interface Indicators	3
Table 2-1	Support Materials for Installing Base Station	7
Table 2-2	Environmental Requirements of the Base Station	8
Table 4-1	Indicator Description	20

1. Product Overview

1.1 Introduction

mBS31001 is a high performance outdoor micro base station based on LTE TDD technology, which is developed by Baicells. The mBS31001 supports wired backhaul connections to backbone networks, and provides LTE access to user terminals, implemented voice and data service transmissions.

The mBS31001 makes use of the current transmission resources to reduce the operator's investment, implement the low-cost construction of LTE networks and enhance indoor coverage, thereby providing high-speed broadband access for users in assembly occupations.

The mBS31001 can be widely used by telecom operators, broadband operators, enterprises, and so on.


1.2 Features

- Adopt the integration design of baseband and RF.
- Citizens Broadband Radio Service (CBRS) band covers with dual carrier.
- Based on 3GPP international standard TDD LTE technology; provide high speed data service; support a maximum transfer rate of DL: 220Mbit/s, UL: 14Mbit/s with 2x20MHz spectrum.
- Support flexible uplink and downlink time slot ratio: 1(2:2), 2(1:3), and high speed data transmission.
- Support 5MHz/10MHz/15MHz/20MHz operation bandwidth.
- Support four ports antenna or two antennae with two ports.
- Support copper (RJ-45) and optical port backhaul, flexible to deploy.
- Security services to provide timely protection against potential security risks and illegal intrusion.
- Support simple and convenient local and remote web management.
- Integration as required, easy to installation and deployment, accurate coverage and improved network capacity.
- Support network management functions, which includes the management, monitoring and maintenance.

1.3 Appearance


The mBS31001 base station appearance is shown in Figure 1-1.

Figure 1-1 Nova-436Q Appearance



The mBS31001 interfaces and indicators are shown in Figure 1-2.

Figure 1-2 mBS31001 Interfaces and Indicators



The mBS31001 interfaces are described in Table 1-1.

The mBS31001 interface indicators are described in Table 1-1.

Table 1-1 mBS31001 Interface Indicators

Identity	Color	Status	Description
PWR	Green	Steady On	Power On
		OFF	No Power Supply
CELL2	Green	Fast flash: 0.125s on, 0.125s off	CELL 2 inactivated
		Slow flash: 1s on, 1s off	CELL 2 activated
CELL1	Green	Fast flash: 0.125s on, 0.125s off	CELL 1 inactivated
		Slow flash: 1s on, 1s off	CELL 1 activated
ALM	Red	Steady On	Hardware alarm, e.g. VSWR alarm
		OFF	No alarm

1.4 Technical Specification

1.4.1 Hardware Specification

Item	Description
LTE Mode	LTE TDD
LTE Frequency	3655-3695MHz
Model	mBS31001

Item	Description
Receive Sensitivity	-100 dBm
Backhaul	1 Optical (SFP) and 1 RJ-45 Ethernet interface (1 GE)
MIMO	DL 2 x 2 on each carrier
Dimension	310mm(H) x 239 mm(W) x 105 mm(D)
Installation Type	Pole, wall
Antenna	External high gain antenna
Overall Power	< 60 W
Power	48V DC, AC adaptor (multi-national standards)
Weight	About 5.5kg

Note:

The test method of receiving sensitivity is proposed by the 3GPP TS 36.104, which is based on 5MHz bandwidth, FRC A1-3 in Annex A.1 (QPSK, $R=1/3$, 25RB) standard.

1.4.2 Software Specification

Item	Description
LTE Standard	3GPP Release 12
Peak Rate	2x20 MHz: SA1: DL 80 Mbps, UL 28 Mbps (per cell) SA2: DL 110 Mbps, UL 14 Mbps (per cell) 2x10MHz: SA1: DL 40 Mbps, UL 14 Mbps (per cell) SA2: DL 55 Mbps, UL 7 Mbps (per cell)
User Capacity	96 concurrent users per cell/carrier 192 concurrent users per eNodeB
Modulation	UL: QPSK, 16QAM, 64QAM DL: QPSK, 16QAM, 64QAM
Voice Solution	CSFB, VoLTE, eSRVCC
Traffic Offload	LIPA (Local IP Access) SIPTO (Selected IP Traffic Offload)
SON	Automatic setup ANR (Automatic Neighbor-cell Recognition) PCI confliction detection
Spectrum Scanning	Supported
UL Interference Detection	Supported
RAN Sharing	Supported
Network Management Interface	TR069 interface protocol

Item	Description
MTBF	≥ 150000 hours
MTTR	≤ 1 hour
Maintenance	Support remote/local maintenance, based on SSH protocol
	Support remote maintenance
	Support online status management
	Support performance statistics
	Support failure management
	Support configuration management
	Support local or remote software upgrading and loading
	Support log
	Support connectivity diagnosis
	Support automatic start and configuration
	Support alarm reporting
	Support KPI Recording
	Support user information tracing
	Support signaling trace

1.4.3 Environment Specification

Item	Description
Operating Temperature	-40°C to 55°C
Storage Temperature	-45°C to 70°C
Humidity	5% to 95%
Atmospheric Pressure	70 kPa to 106 kPa
Ingress Protection Rating	IP66
Power Interface Lightning Protection	Differential mode: $\pm 10\text{KA}$ Common mode: $\pm 20\text{KA}$

1.4.4 FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 40cm between the radiator & your body.

2. Installation Preparation

2.1 Support Materials

Prepare the following support materials accordingly, as given in Table 2-1.

Table 2-1 Support Materials for Installing Base Station

Item	Description
Power cable	< AWG16 e.g. AWG14 Shorter than 100m (330 feet)
Antenna RF cable	50 ohm feeder
Optical fiber	Single mode optical fiber
Ethernet cable	Outdoor CAT6 Shorter than 100m (330 feet)
Antenna	Omnidirectional, or directional antenna
Ground cable	16mm ² yellow-green wire

2.2 Installation Tools

The following tools are needed during the installation.

				
Level bar	Marking pen	Knife	Vise	Wrench
				
Percussion drill and some drill heads	hammer	Cross screw driver	Cable vice	Tape measure
				
5mm L-shape Allen wrench	T7 screwdriver head	Ladder		

2.3 Installation Environment

2.3.1 Locational Requirements

Environments with high-temperatures, harmful gases, unstable voltages, volatile vibrations, loud noises, flames, explosives, and electromagnetic interference (large radar stations, transmitting stations, transformer substations) are not suitable for the operation of mBS31001, and thus should be avoided.

Places prone to have impounded water, soaking, leakage, or condensation, should also be avoided.

Factors like climate, hydrology, geology, earthquake, electric power, and transportation should be taken into consideration in the construction process so that a proper location can be chosen to meet the communication engineering environmental requirements, as well as the technical requirements of network planning and communication equipment.

2.3.2 Environmental Requirements

Table 2-2 gives the base station's environmental requirements with regards to temperature, humidity, and voltage.

Table 2-2 Environmental Requirements of the Base Station

Item	Range	Typical value
Temperature	-40°C to 55°C	25°C
Relative humidity (no condensation)	0% to 100%	5% to 95%
Safety voltage	42V to 60V	48V

2.4 Personnel Requirements

The installation personnel must master the basic safe operation knowledge, through the training, and having the corresponding qualifications.

2.5 Against Lightening and Grounding Protection



CAUTION:

It is unlikely to happen but since the LTE base station is very sophisticated equipment so we would recommend you to test it on the ground to make sure everything is functioning before install on the tower.

Grounding Notes:


- The ground wire adopts yellow-green wire that is no smaller than 16 mm².
- Grounding principle: as near as possible.
- The base station connects to the reliable outdoor grounding point (earth) through one ground screw.
- The connection of the grounding points and the ground bar need to be tight and reliable. Rustproofing the terminals is required. This can be done with rust preventing paint, anti-oxidation coatings, grease, and so on.

2.6 Weatherproof Protection


The mBS31001 adopts cold shrink tube for weatherproof protection. Before installing the cold shrink tube, clean up the interface first. The weatherproof protection steps are as follows:

1. Insert cable into cold shrink tube.
2. Tighten the connector.
3. Push the cold shrink tube to the top joint and pull out the strip.
4. Check whether the cold shrink tube tight connect with the connection.






3. As the following figure, hung the two pins on the base station bracket to the installation bracket, push the base station until the hook block to the base station bracket.



3.5 Install on Wall

The wall must bear four times of the base station weight.

1. Take apart the assembled installation bracket kit to get the installation bracket
2. Fit the installation bracket on the wall, and mark the drilling locations.



Caution:

The arrow of the installation bracket must be upward.

3. Drill two 10mm diameter and 70mm depth holes in the wall by following the marked locations.
4. Check the up/down direction of the installation rack, and then fix base station to the wall using M8*80 expansion screws.
5. Refer to the installation steps on pole, fix base station on wall.

3.6 Connect Cable

3.6.1 Requirement for Cable Laying

General requirements:

- Bending radius requirement of feeder cable: 7/8" > 250mm, 4/5" > 380mm
- Bending radius requirement of jumper cable: 1/4" > 35mm, 1/2" (super soft) > 50mm, 1/2" (ordinary) > 127mm
- Bending radius requirement of power cable and grounding cable: > tripled of the diameter of cable
- The minimum bend radius of the optical fiber is the 20 times of the diameter of optical fiber.
- Binding the cables according the type of the cable, the intertwining and crossing is forbidden.

3. Lay optical fibers along the wire groove, and stretch out the wiring cavity from **OPT** hole.

The redundant fiber should wind neatly.

3.6.2 Connect Ethernet Cable

1. Connect the Ethernet cable to **ETH** interface in the wiring cavity.
2. Lay Ethernet cable along the wire groove, and stretch out the wiring cavity from **ETH** hole.

3.6.3 Connect Power Connector

Because it is not sure that the distance between the installation site and the power supply device, the two ends of power adapter are bare terminal end. The operators need to make power cable according to the actual conditions on installation site, and assemble power plug and power terminal on two ends of power adapter.

Strip 12mm insulating layer with wire stripper, which is used for connection to connector. It is recommended that the power cord length is kept below 100m (330 feet).

The connection steps of power cable is as follows.

1. Assemble power plug.

The power plug will be installed on the end of input direction. Refer to the identification on power plug, connect live wire, neutral wire, and ground wire to corresponding terminals separately, and tighten screws.

2. Assemble power terminal.

The power terminal will be installed on the end of output direction. Refer to the following figure to connect live wire and neutral wire.



3. Connect the power cable to **PWR** interface in the wiring cavity.
4. The power cable lays along the lint slot, and stretch out the wiring cavity from **PWR** hole.
5. The input of the power adaptor connects to the outlet.
 - If the outlet is indoors, place the power adaptor indoors.


- If the outlet is outdoors, place the power adaptor in a water proof box.
6. After the cable connection is complete in the wiring cavity, tighten the screws on the cover to close the wiring cavity using M4 cross screwdriver.

3.6.4 Connect Ground Cable

Make the grounding cable according the actual situation of the installation site.

The Nova-436Q provides two grounding screws, which is located on the bottom of the base station, as shown in Figure 3-3.

Figure 3-3 Location of Grounding Screws



1. Unscrew one grounding screw, connect one end of the grounding cable to the grounding screw, and fasten it again.
2. The other end of the ground cable needs to connect to a good grounding point.

3.7 Install Antenna Feeder System

There are two kinds of outdoor antennas, omnidirectional outdoor antennas and directional outdoor antennas, whose installation will be introduced in the following, respectively.


3.7.1 Install Omnidirectional Antennas

One should pay attention to the followings while installing the omnidirectional outdoor antenna:

- The diameter of the pole for omnidirectional outdoor antennas is required to be 35mm ~ 50mm. A typical case is to use the 50mm-diameter round-steel-made pole (with details depending on the specific antenna type).


- Make sure that the top of pole and the clamp beneath the antenna are at the same level, after installing the omnidirectional outdoor antenna on the pole.
- Make sure that the antenna is high enough to meet the coverage requirement, and that the antenna top falls within the 45 degrees safety angle towards the lightning rod, as shown in Figure 3-4. In principle, no lightning rod can be welded to pole (no metal object is allowed within 1m of the horizontal direction of the omnidirectional antennas), when installing the omnidirectional antennas. Instead, an independent lightning rod should be settled between the two poles, where the lightning rod must be high enough to keep all antennas under its protection cover.

Figure 3-4 Omnidirectional Antenna Installation (1)



In case is impossible to install an independent lightning rod due to environmental limitations, the installation method shown in Figure 3-5 can be used. Be aware that the pole supporting the lightning rod should be kept at least 1m away from the omnidirectional outdoor antennas.

Figure 3-5 Omnidirectional Antenna Installation (2)



3.7.2 Install Directional Antennas


1. First, assemble the antennas, as shown in Figure 3-6.

Figure 3-6 Assembling Procedure of Directional Antennas




2. To install it on the iron tower, use a pulley to transport the antenna assembled to the platform on the iron tower, as shown in Figure 3-7. Following the safety rules when working at these heights.

Figure 3-7 Transportation the Antennas in the Height



3. Fix the pole vertically to the ground or concrete pillars on the rooftop using expansion screws, and fasten it with steel wires. Then, mount the directional outdoor antenna onto the pole using the installation rack, as shown in Figure 3-8.

Figure 3-8 Directional Antenna Installation




4. When the base station has been installed in a proper position, connect all the cables and wires.
5. Run tests, then seal and weatherproof all the connections after the testing has successfully completed. Refer to 2.6 Weatherproof Protection.

4. Power On

Power on the Nova-436Q, and the indicators will light up, as shown in Figure 4-1.

Figure 4-1 LED Indicators



The explanation of the indicator signal is given in Table 4-1.

Table 4-1 Nova-436Q Indicator Description

Identity	Color	Status	Description
PWR	Green	Steady On	Power On
		OFF	No Power Supply
CELL2	Green	Fast flash: 0.125s on, 0.125s off	CELL 2 inactivated
		Slow flash: 1s on, 1s off	CELL 2 activated
CELL1	Green	Fast flash: 0.125s on, 0.125s off	CELL 1 inactivated
		Slow flash: 1s on, 1s off	CELL 1 activated
ALM	Red	Steady On	Hardware alarm, e.g. VSWR alarm
		OFF	No alarm

Caution:

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

This radio transmitter (identify the device by certification number or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 40cm between the radiator and your body.