

CU 241

Dual pump unit

Installation and operating instructions



CU 241

English (GB)

Installation and operating instructions	4
---	---

English (GB) Installation and operating instructions

Original installation and operating instructions

Table of contents

1. General information	4	5.14.1 Overheat protection	11
1.1 Hazard statements	4	5.14.2 Overload protection	11
1.2 Notes	5	5.14.3 Moisture protection	11
2. Installing the product	5	5.14.4 Setting the motor protection with Grundfos GO Remote	11
2.1 Location	5	5.15 Alarm reset	12
2.2 Mechanical installation	5	5.15.1 Resetting alarms and warnings manually with Grundfos GO Remote	12
2.2.1 Mounting the control unit	5	5.15.2 Setting the automatic alarm reset with Grundfos GO Remote	12
2.2.2 Installing a communication interface module	5	5.15.3 Resetting alarms and warnings on the operating panel	12
2.3 Electrical connections	6	5.16 Setting the buzzer with Grundfos GO Remote	12
2.3.1 Connecting the power supply	6	5.17 Setting units for Grundfos GO Remote	12
3. Starting up the product	6	5.18 Setting units for the operating panel with Grundfos GO Remote	12
3.1 Setting the product	6	5.19 GENIbus	12
3.1.1 Connecting to Grundfos GO Remote	6	5.19.1 Setting the GENIbus address with Grundfos GO Remote	12
3.1.2 Startup wizard on Grundfos GO Remote	7	5.20 Security	12
3.1.3 Startup wizard on the operating panel	7	5.20.1 Locking the operating panel	12
3.1.4 How to enable Bluetooth on the operating panel	7	5.20.2 Unlocking the operating panel	12
3.1.5 How to disable Bluetooth on the operating panel	7	5.20.3 Locking Grundfos GO Remote	12
3.1.6 Setting the service interval with Grundfos GO Remote	7	5.20.4 Unlocking Grundfos GO Remote	13
3.2 Testing the product	7	5.21 Starting the startup wizard with the operating panel	13
4. Product introduction	7	6. Operating the product	13
4.1 Operating panel	7	6.1 Manual operation	13
4.2 Terminals	8	6.1.1 Starting and stopping the pump manually with Grundfos GO Remote	13
4.3 Product description	8	6.1.2 Automatic operation	13
4.4 Intended use	8	6.1.3 Starting and stopping the pump manually with the operating panel	13
4.5 Features	8	6.1.4 Choosing what the pump must do after manual start	13
4.6 Identification	8	7. Servicing the product	13
4.6.1 Nameplate	8	7.1 Updating the product software	13
4.6.2 Type key	8	7.2 Replacing the control unit	13
4.7 Supported communication interface modules and protocols	9	7.3 Replacing the CIM module	13
5. Control functions	9	7.4 Replacing the battery	14
5.1 Application types	9	8. Fault finding the product	14
5.1.1 Setting the application type with Grundfos GO Remote	9	8.1 Overview of alarm and warning codes	14
5.2 Setting the sensor type	9	8.2 Code 2 (Power phase missing)	14
5.2.1 Setting the sensor type with Grundfos GO Remote	9	8.3 Code 4 (Too many motor restarts)	14
5.2.2 Setting the sensor type using the operating panel	9	8.4 Code 9 (Power phase sequence wrong)	14
5.3 Setting the start level	10	8.5 Code 12 (Service needed)	14
5.3.1 Setting the start level with Grundfos GO Remote	10	8.6 Code 22 (Moisture in motor of pump)	15
5.3.2 Setting the start level with the operating panel	10	8.7 Code 25 (Wrong configuration)	15
5.4 Setting the stop level	10	8.8 Code 48 (Motor is overloaded)	15
5.4.1 Setting the stop level with Grundfos GO Remote	10	8.9 Code 57 (Missing water in the application)	15
5.4.2 Setting the stop level with the operating panel	10	8.10 Code 69 (Winding temperature too high)	15
5.5 Setting the high level	10	8.11 Code 84 (Memory storage media faulty)	15
5.5.1 Setting the high level with Grundfos GO Remote	10	8.12 Code 117 (Door opened)	15
5.5.2 Setting the high level with the operating panel	10	8.13 Code 159 (Communication error CIMxxx)	15
5.6 Stop delay	10	8.14 Code 165 (Signal fault)	15
5.6.1 Setting the stop delay with Grundfos GO Remote	10	8.15 Code 191 (High water level)	16
5.7 Power-on delay	10	8.16 Code 205 (Level switch inconsistency)	16
5.7.1 Setting the power-on delay with Grundfos GO Remote	10	8.17 Code 225 (Communication error pump module)	16
5.8 Dry-running protection	10	8.18 Code 226 (Communication error IO module)	16
5.8.1 Setting the dry-running level with Grundfos GO Remote	11	8.19 Code 229 (Water on floor)	16
5.8.2 Setting the dry-running level with the operating panel	11	9. Technical data	16
5.9 Using the same level switch for the start and stop level	11	10. Disposing of the product	16
5.10 "Multipump settings"	11	1. General information	
5.10.1 Setting "multipump settings" with Grundfos GO Remote	11	1.1 Hazard statements	
5.11 "Antiseizing"	11	The symbols and hazard statements below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.	
5.11.1 Setting the "Anti-seizing" function with Grundfos GO Remote	11		
5.12 Signal detection time	11		
5.12.1 Setting the signal detection time with Grundfos GO Remote	11		
5.13 Setting the maximum number of restarts with Grundfos GO Remote	11		
5.14 Motor protection	11		

STATUS-NOT-SET | Hazard-statements-(co)-eGZvhS8.dita

**DANGER**

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.

**WARNING**

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.

**CAUTION**

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The hazard statements are structured in the following way:

**SIGNAL WORD****Description of the hazard**

Consequence of ignoring the warning

- Action to avoid the hazard.

1.2 Notes

The symbols and notes below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



Observe these instructions for explosion-proof products.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.

2. Installing the product**2.1 Location**

Install the product in a location that meets the following requirements:

- Place the product in a flood-safe place.
- Make sure that the ambient temperature is within the limits.
- Install the product as close as possible to the connected pumps, sensors, and accessories.
- The product must be protected from direct sunlight.
- The product must be easily accessible.
- Outdoor installation: the product must be installed in a protective shed or enclosure, class IP 54.
- Indoor installation: The product must be installed in a well-ventilated room to ensure cooling of its components.

2.2 Mechanical installation**2.2.1 Mounting the control unit**

- Fasten the control unit with the four screws (1), M4 x 12, supplied with the unit. Torque value: 0.5 Nm.




Fig. Mounting the control unit


Related information[7.2 Replacing the control unit](#)**2.2.2 Installing a communication interface module**

You can fit a communication interface module (CIM) in the control unit to enable communication with external systems. The module is optional and is not delivered with the product.




Use an antistatic service kit when handling electronic components. This prevents static electricity from damaging the components.

- Remove the screw in the back cover of the CU product.



- Remove the back cover.




TM072345

TM071905


TM071906

3. Break off the tap.




TM071977

4. Fit the CIM module.




TM071907

5. If supplied, place the labels on the back cover.



6. Refit the back cover to the CU product and secure it with the mounting screw. Secure cables using the cable tie holders.

TM071908




TM071909

2.3 Electrical connections

2.3.1 Connecting the power supply

STATUS-NOT-SET | Connecting-the-power-supply-(ta)-Vw6L.brdE.dita

1. Check that the supply voltage corresponds with the needed 24 VDC and ensure that the polarity is connected correctly according to the label on the product itself.
2. Connect the power cables and pump cables according to the relevant electrical diagram.



TM070570

Connecting a wire to a terminal with spring clamps

3. Starting up the product

3.1 Setting the product

STATUS-NOT-SET | Connecting-to-Grundfos-GO-Remote-(ta)-Zrs6BU.dita

3.1.1 Connecting to Grundfos GO Remote

1. Open Grundfos GO Remote on your device. Make sure that Bluetooth is enabled.
Your device must be within reach of the product to establish Bluetooth connection.
2. Press the Bluetooth **CONNECT** button on Grundfos GO Remote.
3. Press the connect button on the operating panel. The blue LED above the connect button is flashing blue until your device is connected.
Grundfos GO Remote is now loading the data for the product.

Related information

3.1.4 How to enable Bluetooth on the operating panel

3.1.5 How to disable Bluetooth on the operating panel

3.1.2 Startup wizard on Grundfos GO Remote

The product is designed for Bluetooth communication with Grundfos GO Remote.

Once you have connected your product to Grundfos GO Remote, a startup wizard appears. Follow the instructions to make your settings.

Grundfos GO Remote enables you to set functions and gives you access to status overviews, technical product information and current operating parameters.

Related information

7.2 Replacing the control unit

3.1.3 Startup wizard on the operating panel

The first time the control unit is switched on, a startup wizard will guide you through the basic settings. You can select the sensor type and sensor levels. For some products, you can also set the nominal pump current and number of phases.

If you have an analog sensor, select **S-1** and set the height of the different levels, from dry running to high level.

If you have a digital sensor, select **S-2** and enable or disable the dry-running level, the start level for pump 2, if available and the high level.

To change settings, use the **Up** and **Down** buttons on the operating panel.

Use the **OK** button to confirm each setting and navigate to the next setting.

For filling applications, you must use Grundfos GO Remote.

Units can only be changed with Grundfos GO Remote.

Designation	Description
S-1	Analog sensor
S-2	Digital sensor

Related information

5.21 Starting the startup wizard with the operating panel

3.1.4 How to enable Bluetooth on the operating panel

If the Bluetooth signal on the operating panel has been disabled for some reason, you are not able to connect with Grundfos GO Remote. You must enable Bluetooth first.

- Press and hold the connect button on the operating panel for 15 seconds. Wait for the blue LED to light up.
- Press the Bluetooth **CONNECT** button on Grundfos GO Remote.
- Press the connect button on the operating panel. The blue LED above the connect button is flashing blue until your device is connected.
Grundfos GO Remote is now loading the data for the product.

Related information

3.1.1 Connecting to Grundfos GO Remote

3.1.5 How to disable Bluetooth on the operating panel

In some installation areas it is not allowed to have a Bluetooth signal enabled during operation. After installation, the Bluetooth signal must be disabled manually.

- Press and hold the connect button on the operating panel for 15 seconds. Wait for the blue LED to switch off.
Grundfos GO Remote is not connected to the product anymore.

Related information

3.1.1 Connecting to Grundfos GO Remote

3.1.6 Setting the service interval with Grundfos GO Remote

You can set a time in Grundfos GO Remote in order to get a reminder that the pump needs service when the time comes.

- Go to **Settings > Service > State**
- Select **Enable** and press **OK**.
- Select the pump.
- Enter the number of hours until next service and press **OK**.

3.2 Testing the product

When you have made all the electrical installations and completed the startup wizard, you can test the system.

For emptying applications:


- Fill the pit with water and check that the pump starts automatically at the defined level.
- Test the dry-running function by starting the pump manually and wait while the pit with the pump is emptied. Check that the control unit indicates an alarm and stops the pump when the defined level is reached.
- Test the high-level function by stopping the pump manually and continue to fill the pit with water. Check that the control unit indicates an alarm when the defined level is reached. Set the pump to **Auto** and observe that the pump starts and stops when the stop level has been reached.

For filling applications:

- Start by draining the tank to be filled. When the tank is empty and the start level is reached, the pump must start. When the tank is full and the stop level is reached, the pump must stop.
- Test the high-level function by stopping the pump manually and continue to fill the tank without the pump with water. Check that the control unit indicates an alarm when the defined level is reached.
- Test the dry-running function by starting the pump manually and wait while the tank with the pump is emptied. Check that the control unit indicates an alarm and stops the pump when the defined level is reached. If the pump is placed in a well, this test may not be possible since the pump cannot empty the well. Alternatively, pull the dry-run level switch up to simulate a dry-run situation. The same can be done with a pressure level sensor.

4. Product introduction

4.1 Operating panel




Pos.	Symbol	Description
1	◁	High level
2	◁	Start level, pump 2
3	◁	Start level, pump 1
4	◁	Stop level, pump 1 and 2

Pos.	Symbol	Description
5		Dry-running level
6		Up / Down buttons: Press these buttons to navigate between submenus or change the value settings.
7	OK	OK button: Press this button to save changed values.
8		Connect button: Press this button to connect the control unit to Grundfos GO Remote via Bluetooth.
9	Reset	Reset button: Press this button during startup to reset settings and start over or to reset an alarm or warning.
10		Operating mode for the pump: - On: The pump has been switched on manually. - Off: The pump has been switched off manually. - Auto: The pump is running automatically based on settings.
11	Display	The display shows the pump status.
12		Lock symbol: If the symbol is lit, the control unit is locked from making changes.
13		Alarm and warning symbol: Red: Alarm Yellow: Warning

The control unit enables manual setting and monitoring of the system.

4.2 Terminals



Pos.	Description
1	Terminal for a CIM module, optional
2	Cable tie holders
3	Terminal for the power supply
4	GENIbus, for internal use between modules.
5	USB port
6	Service connection
7	Nameplate

4.3 Product description

The level-control unit switches the pump on and off according to the liquid level measured by float switches or a pressure sensor. When the start level is reached, the pump starts, and when the liquid level

has been lowered to the stop level, the pump is stopped by the control unit. An alarm is indicated in case of for example high-water level in the tank or sensor failure.

Basic settings are configured via the operating panel and advanced settings are configured with Grundfos GO Remote. Furthermore, you can read important operating parameters with Grundfos GO Remote.

4.4 Intended use

The control unit is designed to control two pumps.

The product can be configured for two purposes: emptying a wastewater pit or filling a pit or tank. The product can be used for network pumping stations, main pumping stations, commercial buildings and municipal systems.

The control unit is only intended for use in control panels.


4.5 Features

The control unit features among others the following functions:

- support of up to two pumps
- manual and automatic control of the pump
- Bluetooth pairing with Grundfos GO Remote
- operating indication, such as power on and pump running
- alarm and warning indication, such as power phase missing and high-water level
- motor and phase failure protection
- setting of stop delays matching the actual operating conditions.
- automatic alternation of pumps.

4.6 Identification

4.6.1 Nameplate



Pos.	Description
1	Production code, year and week
2	Serial number
3	Enclosure class
4	Max. ambient temperature
5	Max. power consumption
6	Factory code
7	Markings and approvals
8	Production site
9	Supply voltage
10	Version number
11	Product name

4.6.2 Type key

Example	CU 241	1
Pos.	1	2

Pos.	Description
1	Type CU 241
2	Number of pumps supported

STATUS-NOT-SET | Supported-communication-interface-modules-and-protocols-(re)-0fwnkCa.dita

4.7 Supported communication interface modules and protocols

The following Grundfos communication interface modules can be added to the product.

Communication interface module	Protocol
CIM 050	GENIbus
CIM 150	PROFIBUS DP
CIM 200	Modbus RTU
CIM 260	3G/4G
CIM 270	GRM
CIM 280	Grundfos iSolution Cloud (GiC)
	Modbus TCP
CIM 500	PROFINET IO
	GRM IP

5. Control functions

STATUS-NOT-SET | Application-types-(co)-yKqYumk.dita


5.1 Application types

You can choose between two application types:

- Empty
- Fill

You can set the application type with Grundfos GO Remote.

Empty



TM0713341

Pos.	Description
1	High level
2	Start level P2: start level for pump 2
3	Start level P1: start level for pump 1
4	Stop level
5	Dry-running level

The pump will start to empty the tank or pit when **Start level P1** is reached.

A second pump will start if the liquid level reaches **Start level P2**.


The pump stops when the liquid level is lowered to **Stop level**.

If the inflow of liquid exceeds the capacity of the installed pump, the level in the tank or pit will rise. Eventually, the **High level** sensor will register a high liquid level in the tank or pit. If set, the signal from

the **High level** sensor can be used to activate an output relay which can then be used to indicate a visual or acoustic alarm or send a signal to a SCADA system.

If the pump is running and the liquid level in the tank or pit falls below the dry-running level, the dry-running protection will stop the pump to ensure that it is not damaged mechanically.

Fill



TM0713351

Designation	Description
1	High level
2	Stop level
3	Start level P1: start level for pump 1
4	Start level P2: start level for pump 2
5	Dry-running level

In the filling application, the pump is installed in a tank or well from where it pumps the liquid. The liquid is pumped into a second tank where the level sensors are installed.

The pump will start to fill the second tank when **Start level P1** is reached.

A second pump will start if the liquid level reaches **Start level P2**.

The pump stops when the liquid level reaches **Stop level**.

If the pump for some reason does not stop at **Stop level** and the liquid level keeps rising, the **High level** sensor will eventually register this. If set, the signal from the **High level** sensor can be used to activate a relay output which can then be used to indicate a visual or acoustic alarm or send a signal to a SCADA system via a communication interface.

If the pump is running and the liquid level in the tank falls below the dry-running level, the dry-running protection will stop the pump to ensure that it is not damaged.

Related information

6.1.2 Automatic operation

STATUS-NOT-SET | Setting-the-application-type-with-Grundfos-GO-Remote-(ta)-nyfFSE.dita

5.1.1 Setting the application type with Grundfos GO Remote

- Go to **Settings > Level control > Application type**.
- Select the type.
 - Empty
 - Fill

5.2 Setting the sensor type

STATUS-NOT-SET | Setting-the-sensor-type-with-Grundfos-GO-Remote-(ta)-06rs8BU.dita

5.2.1 Setting the sensor type with Grundfos GO Remote

- Go to **Settings > Level control > Sensor type**.
- Select the type.
 - Analog sensors
 - Digital sensors

STATUS-NOT-SET | Setting-the-sensor-type-using-the-operating-panel-(ta)-ywwzApi.dita

5.2.2 Setting the sensor type using the operating panel

- Press and hold **OK** until **S-1** or **S-2** starts flashing.
- Select the sensor type using the **up** or **down** button.
 - S-1**: Analog sensors
 - S-2**: Digital sensors.
- Press **OK** to confirm the setting.

- Continuously press **OK** to confirm all other settings and to exit the setup.

5.3 Setting the start level

STATUS-NOT-SET | Setting the start level with Grundfos GO Remote-(ta)-PCpUL6.dita

5.3.1 Setting the start level with Grundfos GO Remote

The settings apply to analog sensors. For digital sensors, the setting is automatically activated.


- Go to **Settings > Level Control > Start level P1**.
- Set the start level for pump 1.
- Go to **Settings > Level control > Start level P2**.
- Set the start level for pump 2.

STATUS-NOT-SET | Setting the start level with the operating panel-(ta)-jAKwS6.dita


5.3.2 Setting the start level with the operating panel

The settings apply to analog sensors. For digital sensors, the setting is automatically activated.

- Press and hold **OK** until the display and dry running start flashing.
- Continuously press **OK** until the indicator light for the start level for pump 1 starts flashing.



- Set the start level for pump 1 by using the **Up** and **Down** buttons.
- Press **OK**.
The indicator light for the start level for pump 2 starts flashing.



- Set the start level for pump 2 by using the **Up** and **Down** buttons.
- Continuously press **OK** until the display stops flashing.
The settings have now been stored.

5.4 Setting the stop level

STATUS-NOT-SET | Setting the stop level with Grundfos GO Remote-(ta)-nBcN8w.dita

5.4.1 Setting the stop level with Grundfos GO Remote

The settings apply to analog sensors. For digital sensors, the setting is automatically activated.

The stop level is the same for pump 1 and pump 2.

- Go to **Settings > Level control > Stop level**
- Set the stop level.

If you are using the same level for start and stop, remember to set a stop delay. It will prevent the pump from starting and stopping too frequently.

5.4.2 Setting the stop level with the operating panel

STATUS-NOT-SET | Setting the stop level with the operating panel-(ta)-u717A4.dita

The settings apply to analog sensors. For digital sensors, the setting is automatically activated.

The stop level is the same for pump 1 and pump 2.

- Press and hold **OK** until the display starts flashing.
- Press **OK** once.
The current stop level is indicated on the display.
- Set the stop level using the **Up** and **Down** buttons.
- Continuously press **OK** to confirm all other settings and to exit the setup.

If you are using the same level for the start and stop level, remember to set a stop delay. This will prevent the pump from starting and stopping too frequently.

5.5 Setting the high level

STATUS-NOT-SET | Setting the high level with Grundfos GO Remote-(ta)-bQn9FM.dita

5.5.1 Setting the high level with Grundfos GO Remote

- For analog sensors, go to **Settings > Level control > High level**.
- Set the high level.
- For digital sensors, go to **Settings > LC 231 IO terminals**.
- Select which terminal to configure.

STATUS-NOT-SET | Setting the high level with the operating panel-(ta)-Sj-ckE.dita

5.5.2 Setting the high level with the operating panel

The settings apply to analog sensors.

- Press and hold **OK** until the display starts flashing.
- Press **OK** four times.
The current high level is indicated on the display.
- Set the high level using the **Up** and **Down** button. For digital sensors, enable or disable the setting.
- Press **OK** once to complete the setting.

5.6 Stop delay

STATUS-NOT-SET | Stop delay-(co)-xWhQ6d0.dita

The stop delay is the time from when the stop level is reached until the pump stops. The stop delay prevents the pump from starting and stopping too frequently and reduces water hammer in long pipes.

STATUS-NOT-SET | Setting the stop delay with Grundfos GO Remote-(ta)-rez8KE.dita

5.6.1 Setting the stop delay with Grundfos GO Remote

- Select **Settings > Level control > Stop delay > State**
- Select **Stop delay time**.
- Set the **Stop delay time**.

STATUS-NOT-SET | Power-on delay-(co)-yuzZjoo.dita

5.7 Power-on delay

With this function it is possible to delay the startup of the pump after the power supply has been switched on. The purpose is to avoid disturbing the main power network which could happen if several pumps start up immediately when the power supply is switched on.

STATUS-NOT-SET | Setting the power-on delay with Grundfos GO Remote-(ta)-42Hq6d0.dita

5.7.1 Setting the power-on delay with Grundfos GO Remote

- Go to **Settings > Power-on delay**.
- Set the function to **Enabled**.
- Set the time delay.

STATUS-NOT-SET | Dry-running protection-(co)-yjADxMQ.dita

5.8 Dry-running protection

If the pump is running and the liquid level in the tank or pit becomes lower than the dry-running level, the dry-running protection will stop the pump to ensure that it is not damaged.

Dry-running protection is dependent on a feedback signal from a level sensor installed in the tank or pit.

5.8.1 Setting the dry-running level with Grundfos GO Remote

STATUS-NOT-SET | Setting the dry-running level with Grundfos GO Remote (ta)-RKTgTY.dita

1. Go to **Settings > Level control > Dry-running level**.
2. Set the dry-running level.



The dry-running level must be set to a value which ensures that the pump is not damaged due to dry-running. The specific level depends on the installed pump type. See the installation and operating instructions for the product.

5.8.2 Setting the dry-running level with the operating panel

STATUS-NOT-SET | Setting the dry-running level with the operating panel (ta)-NwmwMs.dita

1. Press and hold **OK** until the display starts flashing.
2. Set the dry-running level using the **Up** or **Down** button.
3. Continuously press **OK** to confirm all other settings and to exit the setup.

5.9 Using the same level switch for the start and stop level

STATUS-NOT-SET | Using the same level switch for the start and stop level (ta)-GB0H3e.dita

1. Set one digital input to **Start pump 1** or **Stop**. All other digital inputs must be disabled.
2. Set a stop delay.
This will prevent the pump from starting and stopping too frequently.

5.10 "Multipump settings"

The control unit enables start and stop of the two pumps alternately. The pump with the lowest number of running hours is always started first. The function ensures that the running hours of the pumps are the same.

It is possible to set a time delay before the next pump is started.

STATUS-NOT-SET | Multipump settings (co)-yqTZnr1.dita

5.10.1 Setting "multipump settings" with Grundfos GO Remote

STATUS-NOT-SET | Setting multipump settings with Grundfos GO Remote (ta)-YyGSi4.dita

1. Go to **Settings > Multi pump settings**
2. Set **Inter pump delay**.
This is the starting delay between the pumps ensuring that they do not start at the same time.
3. Set **Max number of running pumps**.
This is the maximum number of pumps which are allowed to run at the same time.

5.11 "Antiseizing"

The **Antiseizing** function prevents a pump from choking or seizing up as a result of deposits buildup. **Antiseizing** is used in pits that have had no inlet flow for a long period. The **Antiseizing** function ensures that the pump starts as often as set in **Antiseizing > interval**. The pump will operate for the number of seconds indicated by the user.

STATUS-NOT-SET | Antiseizing (co)-y6B8-8s.dita

5.11.1 Setting the "Anti-seizing" function with Grundfos GO Remote

STATUS-NOT-SET | Setting the Anti-seizing function with Grundfos GO Remote (ta)-A38ouE.dita

1. Go to **Settings > Anti-seizing**.
2. Set the function to **Enabled**.
3. Set the time interval.
4. Set the operating time.

5.12 Signal detection time

The signal detection time is the minimum time a level has to be active before the control unit initiates an action, such as starting or stopping a pump.

STATUS-NOT-SET | Signal-detection-time (co)-yWYQag.dita

5.12.1 Setting the signal detection time with Grundfos GO Remote

STATUS-NOT-SET | Setting the signal-detection-time with Grundfos GO Remote (ta)-4bS1s.dita

1. Go to **Settings > Level control > Signal detection time**.
2. Set the signal-detection time.

5.13 Setting the maximum number of restarts with Grundfos GO Remote

STATUS-NOT-SET | Setting the maximum number of restarts with Grundfos GO Remote (ta)-QrsAGY.dita

If the pump is seized up as a result of deposits build-up, it will be stopped automatically due to overheating, provided that the motor protection has been set. When the motor has cooled down, the control unit will unsuccessfully try to restart the pump and this scenario will be repeated.

In order to prevent this, it is possible to set a maximum number of restart attempts within a set interval.

1. Go to **Settings > Max number of restarts**.
2. Enable the function.
3. Set the interval within which the allowed number of restarts are to be counted.
4. Set the maximum number of pump restarts which are allowed during the set interval.

Related information

[5.14.4 Setting the motor protection with Grundfos GO Remote](#)

[8.3 Code 4 \(Too many motor restarts\)](#)

5.14 Motor protection

STATUS-NOT-SET | Overheat-protection (co)-yTgZohk.dita

5.14.1 Overheat protection

The control unit offers thermal protection for the connected motors. Two types of thermal-protection sensor can be connected to the control unit: a PTC sensor (analog) and a thermal switch (digital). Under normal running conditions, the sensor will act as a short circuit, but when its temperature limit is reached, it will open and tell the control unit that the temperature is too high, and the pump is stopped. When the temperature has dropped to the sensor-trigger level, the pump will return to normal running conditions. It will not be possible to start the pump manually as long as the temperature is too high.

Related information

[8.10 Code 69 \(Winding temperature too high\)](#)

5.14.2 Overload protection

STATUS-NOT-SET | Overload-protection (co)-ymryFSE.dita

The pump is protected by an external motor-protection relay. The nominal current draw must be set manually on the motor-protection relay. See the specific documentation for the relay on how to set the trigger level. If the current exceeds the trigger level, the relay will switch off the pump and the controller will give an alarm. The alarm has to be manually reset directly on the motor protection relay.

Related information

[8.8 Code 48 \(Motor is overloaded\)](#)

5.14.3 Moisture protection

STATUS-NOT-SET | Moisture-protection (co)-yNwmwMs.dita

When a moisture sensor is installed in series with the thermal sensor, the control unit needs to know how to determine whether there is a high temperature or moisture in the pump. If the temperature is too high, normally the temperature sensor will go back to its normal stage when the temperature has dropped to its trigger level. If there is moisture in the pump, then the moisture sensor will keep the series connection open until the pump is opened and serviced.

To determine which sensor has been active, a **cool down time** must be entered. This is the time that will normally pass until the temperature has dropped enough for the temperature sensor to return to its normal stage. If the cool down time is exceeded, the control unit will assume that there is moisture in the pump, and it will send a moisture alarm.

Related information

[5.14.4 Setting the motor protection with Grundfos GO Remote](#)

5.14.4 Setting the motor protection with Grundfos GO Remote

STATUS-NOT-SET | Setting the motor-protection with Grundfos GO Remote (ta)-4Cvfcg.dita

You can set the current, temperature and moisture protection via a setup wizard.

1. Go to **Settings > Motor protection pump 1** or **Motor protection pump 2**.
2. Follow the on-screen wizard to set the following:
 - **Nominal pump current**
 - **Trip IEC class**
 - **Pump connection**
 - **Overheat protection.**

Related information

[5.13 Setting the maximum number of restarts with Grundfos GO Remote](#)

[5.14.3 Moisture protection](#)

5.15 Alarm reset

5.15.1 Resetting alarms and warnings manually with Grundfos GO Remote

STATUS-NOT-SET | Resetting-alarms-and-warnings-manually-with-Grundfos-GO-Remote-(ta)-o51pht.dita

1. Go to **Alarms and warnings**.
2. Press **Reset alarm**.
All current alarms and warnings have been reset. However, if the fault causing the alarm or warning has not been removed, the alarm or warning will appear again.
3. If you want to delete all alarms and warnings from the history log, press **Show log > Reset alarm and warning logs**.

5.15.2 Setting the automatic alarm reset with Grundfos GO Remote

STATUS-NOT-SET | Setting-the-automatic-alarm-reset-with-Grundfos-GO-Remote-(ta)-o51pht.dita

1. Go to **Settings > Automatic alarm reset**.
2. Select one of the following:

Option	Description
No automatic reset	The control unit does not reset any alarm or warning. You must do it manually.
All except pump critical	The control unit resets alarms and warnings unless the related fault can damage the pump.
All alarms	The control unit resets alarms and warnings, regardless of the fault.

5.15.3 Resetting alarms and warnings on the operating panel

STATUS-NOT-SET | Resetting-alarms-and-warnings-on-the-operating-panel-(ta)-k21sjo.dita

You can manually reset alarms and warnings on the operating panel. However, if the fault causing the alarm or warning has not been removed, the alarm or warning will appear again.

1. Press **Reset** on the operating panel to reset the alarm or warning.

5.16 Setting the buzzer with Grundfos GO Remote

STATUS-NOT-SET | Setting-the-buzzer-with-Grundfos-GO-Remote-(ta)-Dx6Bsg.dita

The internal buzzer is used to give an acoustic sound if there is a warning or an alarm.

1. Go to **Settings > Buzzer settings**.
2. Select when the buzzer is to be activated:
 - **All alarms**
 - **All alarms and warnings.**

5.17 Setting units for Grundfos GO Remote

STATUS-NOT-SET | Setting-units-for-Grundfos-GO-Remote-(ta)-cbCrys.dita

Changing units as described here will only change the units shown in Grundfos GO Remote. It will not affect the units shown on the operating panel of products connected to Grundfos GO Remote.

1. Press the **Menu** button in the upper left corner of Grundfos GO Remote.



TM070084

2. Go to **General > Settings > Products > Units**.
3. Select **US** or **Grundfos default units**.

5.18 Setting units for the operating panel with Grundfos GO Remote

STATUS-NOT-SET | Setting-units-for-the-operating-panel-with-Grundfos-GO-Remote-(ta)-o5YVkg.dita

Changing units as described below changes the units shown in the operating panel of the product connected to Grundfos GO Remote. It does not affect the units shown in Grundfos GO Remote.

1. Go to **Settings > Display units**.
2. Select the units to be used on the operating panel.
 - **SI Units**
 - **US Units.**

STATUS-NOT-SET | GENIbus-(co)-adwmwMIs.dita

5.19 GENIbus

GENIbus, the Grundfos Electronics Network Intercommunications bus, is a fieldbus developed by Grundfos to meet the need for data transfer in all typical Grundfos motor or pump applications. Grundfos devices with GENIbus can be wired together in networks and integrated in automation systems. Each device on the network must have a unique GENIbus address. GENIbus is based on the RS485 hardware standard and typically operates at a baud rate of 9600 bits/s.

STATUS-NOT-SET | Setting-the-GENIbus-address-with-Grundfos-GO-Remote-(ta)-o53Q.dita

5.19.1 Setting the GENIbus address with Grundfos GO Remote

If CU 241 is used in a GENIbus network, a CIM 050 must be installed to add a GENIbus connection.

1. Go to **Settings > GENI bus address**
2. Set the GENIbus address.

The GENIbus address is a unique identifier for the product on the network.

5.20 Security

STATUS-NOT-SET | Locking-the-operating-panel-(ta)-Y5B9wo.dita

5.20.1 Locking the operating panel

The operating panel can only be locked with Grundfos GO Remote.

1. Go to **Settings > Security > Local HMI Security**.
2. Select **Enabled** and press **Next**.
3. Select if you want to restrict access to **Settings only** or **Settings and operation**.
4. Press **Done**.

The lock symbol on the operating panel is now lit.

STATUS-NOT-SET | Unlocking-the-operating-panel-(ta)-Mq5V4.dita

5.20.2 Unlocking the operating panel

The operating panel can only be unlocked with Grundfos GO Remote.

1. Go to **Settings > Security > Local HMI Security**.
2. Select **Disabled** and press **Next**.

The lock symbol on the operating panel is switched off.

STATUS-NOT-SET | Locking-Grundfos-GO-Remote-(ta)-nQ2mk.dita

5.20.3 Locking Grundfos GO Remote

1. Go to **Settings > Security > Go Remote Security**.
2. Select **Enabled** and press **Next**.
3. Enter a four digit PIN code and press **CONFIRM**.

A lock symbol indicates which menus are locked. To view or change settings, you must enter the PIN code.

5.20.4 Unlocking Grundfos GO Remote

STATUS-NOT-SET | Unlocking-Grundfos-GO-Remote-(ta)-dpl-a9c.dita

1. Go to **Settings** > **Security**.
2. Enter the four digit PIN code.
3. Select **Go Remote Security**.
4. Select **Disabled** and press **Next**.

All menus in Grundfos GO Remote are unlocked.

5.21 Starting the startup wizard with the operating panel

STATUS-NOT-SET | Starting-the-setup-wizard-with-the-operating-panel-(ta)-YZpWCG.dita

- Press and hold the **OK** button for 8 seconds until **S-1** or **S-2** starts flashing.

Related information

[3.1.3 Startup wizard on the operating panel](#)

6. Operating the product

6.1 Manual operation

STATUS-NOT-SET | Starting-and-stopping-the-pump-manually-with-Grundfos-GO-Remote-(ta)-qbl-DY.dita

6.1.1 Starting and stopping the pump manually with Grundfos GO Remote

1. Go to **Settings** > **Control, pump 1** or **Control, pump 2**.
2. Start the pump by selecting **On** and pressing **OK**.
3. Stop the pump by selecting **Off** and pressing **OK**.

Related information

[6.1.4 Choosing what the pump must do after manual start](#)

STATUS-NOT-SET | Automatic-operation-(co)-cDLyLUK.dita

6.1.2 Automatic operation

In automatic operating mode, the control unit starts and stops the pump based on the signals it receives from the connected level sensors and the corresponding level settings within the control unit.

Related information

[5.1 Application types](#)

STATUS-NOT-SET | Starting-and-stopping-the-pump-manually-with-the-operating-panel-(ta)-OTUPQc.dita

6.1.3 Starting and stopping the pump manually with the operating panel

1. To start a pump manually, press and hold the **Pump** button until the pump starts.
The **On** indicator light is lit when the pump is operating in manual mode.
2. Stop the pump by pressing the **Pump** button.
The **Off** indicator light is lit when the pump is stopped.

Related information

[6.1.4 Choosing what the pump must do after manual start](#)

STATUS-NOT-SET | Choosing-what-the-pump-must-do-after-manual-start-(ta)-ISAD1s.dita

6.1.4 Choosing what the pump must do after manual start

The following can be configured:

- **Automatic return**
Here you select if the pump must automatically return to a defined operating mode when the manual start ends.
 - **Return to**
Here you select whether the pump must return to automatic operating mode or stop when the manual start ends and **Automatic return** has been enabled.
 - **Forced start time**
Here you set the time period in which the pump must run in manual operating mode.
1. Go to **Settings** > **Manual start**.
 2. Select **Automatic return** and choose one of the following options:
 - **Disabled**
 - **Enabled**.

3. Go one step back in the menu and select **Return to**.
4. Choose one of the following options:
 - **Auto**
 - **Off**.
5. Go one step back in the menu and select **Forced start time**.
6. Set the time period in which the pump must run in manual operating mode.

Related information

[6.1.1 Starting and stopping the pump manually with Grundfos GO Remote](#)

[6.1.3 Starting and stopping the pump manually with the operating panel](#)

STATUS-NOT-SET | Service-(co)-x-7B76M.dita

7. Servicing the product

DANGER

Electric shock

Death or serious personal injury



- Switch off the incoming power supply before you start any work on the product or connected pumps.
- Make sure that the power supply cannot be switched on accidentally.

7.1 Updating the product software

STATUS-NOT-SET | Updating-the-product-software-(ta)-zmZYHqU.dita

New features and functions can be made available during the product's life cycle.

1. Contact Grundfos to get your product software updated.

7.2 Replacing the control unit

STATUS-NOT-SET | Replacing-the-control-unit-(ta)-lyChqRk.dita

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply before making any electrical connections.
- Make sure that the power supply cannot be switched on accidentally.

Remember to save the controllers settings in Grundfos GO Remote under **Settings**. The settings can then be transferred to the new control unit when installed.

1. Switch off the power supply to the product and other components with external supply.
2. Write down the terminal connection of each wire to ensure correct re-connection.
3. Disconnect all wires.
4. Remove the control unit from the panel or cabinet.
5. Fit the new unit.
6. Connect all wires.
7. Configure the new control unit using Grundfos GO Remote.

Related information

[2.2.1 Mounting the control unit](#)

[3.1.2 Startup wizard on Grundfos GO Remote](#)

STATUS-NOT-SET | Replacing-the-CIM-module-(ta)-cYQpZY.dita

7.3 Replacing the CIM module

DANGER

Electric shock

Death or serious personal injury



- Switch off the power supply before making any electrical connections.
- Make sure that the power supply cannot be switched on accidentally.

1. Switch off the power supply to the product and other components with external supply.
2. Write down the terminal connection of each wire to ensure correct re-connection.
3. Disconnect all wires connected to the CIM module.
4. Remove the screws that holds the module.
5. Remove the module from the control unit.
6. Fit the new module.
7. Connect all wires.

STATUS-NOT-SET | Replacing-the-battery-(ts)-9yYWEig.dita

7.4 Replacing the battery

CAUTION

Fire and chemical leakage

Minor or moderate personal injury

- Risk of explosion if the battery is replaced by an incorrect type.



To replace the battery, do the following:

1. Remove the back cover.
2. Gently grab around the battery without touching it too much.
3. Pull the battery up.
4. Insert a new battery of the correct type.

Related information

9. Technical data

8. Fault finding the product

STATUS-NOT-SET | Fault-finding-the-product-(re)-Accab9M.dita

DANGER

Electric shock

Death or serious personal injury

- Switch off the power supply before you start any work on the product.
- Make sure that the power supply cannot be switched on accidentally.



Fault finding and fault correction must be carried out by qualified persons.

STATUS-NOT-SET | List-with-alarm-and-warning-codes-(re)-ywT41JG.dita

8.1 Overview of alarm and warning codes

Code number	Description
Code 2	The power phase is missing.
Code 4	Too many motor restarts.
Code 9	The power-phase sequence is wrong.
Code 12	Service is needed.
Code 22	Moisture in motor of pump.
Code 25	Wrong configuration.
Code 48	The motor is overloaded.
Code 57	Missing water in the application.
Code 69	The winding temperature is too high.
Code 84	The memory-storage media is faulty.
Code 117	The door is opened.
Code 159	Communication error CIMxxx.
Code 165	Signal fault.
Code 191	High water level.

Code number	Description
Code 205	Level-switch inconsistency.
Code 225	Communication error pump module.
Code 226	Communication error IO module.
Code 229	Water on the floor.

STATUS-NOT-SET | Code-2-(Power-phase-missing)-(ts)-AAccP2M.dita

8.2 Code 2 (Power phase missing)

- Alarm code 2 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Power phase missing** is displayed in Grundfos GO Remote.

Cause One of the power supply phases is not connected.

Remedy • Connect the phase.

Cause The fuse is blown somewhere on the incoming power line.

Remedy • Replace the fuse.

STATUS-NOT-SET | Code-4-(Too-many-motor-restarts)-(ts)-AFxJ8ac.dita

8.3 Code 4 (Too many motor restarts)

- Alarm code 4 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Too many motor restarts** is displayed in Grundfos GO Remote.

Cause The pump has been blocked or partly blocked causing overload in the motor.

Remedy • Remove the blockage from the pump.

Related information

[5.13 Setting the maximum number of restarts with Grundfos GO Remote](#)

STATUS-NOT-SET | Code-9-(Power-phase-sequence-wrong)-(ts)-AFvxRCE.dita

8.4 Code 9 (Power phase sequence wrong)

- Alarm code 9 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Power phase sequence wrong** is displayed in Grundfos GO Remote.

Cause The power supply phase is set incorrectly.

Remedy • Interchange two phases.

STATUS-NOT-SET | Code-12-(Service-needed)-(ts)-ALLIL8g.dita

8.5 Code 12 (Service needed)

- Warning code 12 is shown on the display if you press the **Up** or **Down** button.
- The warning symbol on the display turns yellow and the pump's operating mode is unchanged.
- Warning code **Service needed** is displayed in Grundfos GO Remote.

Cause The pump requires service based on time to next service countdown.

Remedy

- Contact Grundfos or an authorised service workshop.
- In order for the product to determine the service time, you must have enabled the service countdown with Grundfos GO Remote: **Settings > Service**.

8.6 Code 22 (Moisture in motor of pump)

STATUS-NOT-SET | Code-22 (Moisture in motor of pump) (ts)-AKmwWVA.dita

- Alarm code 22 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Moisture in motor of pump** is displayed in Grundfos GO Remote.

Cause Moisture is detected in the motor of the pump.

Remedy • Service is needed on the pump. Contact Grundfos.

8.7 Code 25 (Wrong configuration)

STATUS-NOT-SET | Code-25 (Wrong configuration) (ts)-ABufzyQ.dita

- Alarm code 25 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Wrong configuration** is displayed in Grundfos GO Remote.

Cause The level control is not configured correctly.

Remedy • Check and adjust the level control configuration with Grundfos GO Remote.

Cause The IO terminal is not configured correctly.

Remedy • Select which IO terminal to change in Grundfos GO Remote and adjust the configuration.

8.8 Code 48 (Motor is overloaded)

STATUS-NOT-SET | Code-48 (Motor is overloaded) (ts)-ALBdS1s.dita

- Alarm code 48 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Motor is overloaded** is displayed in Grundfos GO Remote.

Cause The pump is clogged.
The blockage causes the motor current to rise, which could damage the pump.

Remedy • Remove the blockage.
• Check the pit conditions to ensure blockage is not possible again.

Related information

[5.14.2 Overload protection](#)

8.9 Code 57 (Missing water in the application)

STATUS-NOT-SET | Code-57 (Missing water in the application) (ts)-AEd1sjo.dita

- Alarm code 57 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Dry Run** is displayed in Grundfos GO Remote.

Cause Low water level in the pit and the pump stops due to the dry-running function.

Remedy • Check and configure the sensor for stop level.

8.10 Code 69 (Winding temperature too high)

STATUS-NOT-SET | Code-69 (Winding temperature too high) (ts)-ALJcK6Q.dita

- Alarm code 69 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Winding temperature too high** is displayed in Grundfos GO Remote.

Cause The pump is clogged, causing the pump to use more current and thereby overheat.

Remedy • Remove the blockage.

Cause The pump has run for too long.

Remedy • Allow the pump to cool down.
• Adjust the distance between start and stop levels.

Related information

[5.14.1 Overheat protection](#)

8.11 Code 84 (Memory storage media faulty)

STATUS-NOT-SET | Code-84 (Memory storage media faulty) (ts)-AAFdH3w.dita

- Warning code 84 is shown on the display if you press the **Up** or **Down** button.
- The warning symbol on the display turns yellow and the pump's operating mode is unchanged.
- Warning code **Memory storage media faulty** is displayed in Grundfos GO Remote.

Cause An error in the internal memory has been detected.

Remedy • Replace the control unit.
• Contact Grundfos or an authorised service workshop.

8.12 Code 117 (Door opened)

STATUS-NOT-SET | Code-117 (Door opened) (ts)-AM3fuSU.dita

- Warning code 117 is shown on the display if you press the **Up** or **Down** button.
- The warning symbol on the display turns yellow and the pump's operating mode is unchanged.
- Warning code **Door opened** is displayed in Grundfos GO Remote.

Cause The door to the control-unit room has been opened.

Remedy • Check the room with the control unit.

8.13 Code 159 (Communication error CIMxxx)

STATUS-NOT-SET | Code-159 (Communication error CIMxxx) (ts)-ACb2ApI.dita

- Warning code 159 is shown on the display if you press the **Up** or **Down** button.
- The warning symbol on the display turns yellow and the pump's operating mode is unchanged.
- Warning code **Communication error CIMxxx** is displayed in Grundfos GO Remote.
- The CIM module is unable to communicate with the product.

Cause The CIM module is installed incorrectly.

Remedy • Ensure that the module, including cables, is fitted correctly.

Cause The CIM module is defective.

Remedy • Contact Grundfos.

8.14 Code 165 (Signal fault)

STATUS-NOT-SET | Code-165 (Signal fault) (ts)-AHFcN8w.dita

- Alarm code 165 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Signal fault** is displayed in Grundfos GO Remote.

Cause The signal from the sensor is out of the configured range.

Remedy • Go to **Settings > Level Control** in Grundfos GO Remote and ensure that the configured range corresponds to the physical application type.
• Change the sensor, if needed.

8.15 Code 191 (High water level)

STATUS-NOT-SET | Code-191-(High-water-level)-(ts)-AONKraA.dita

- Alarm code 191 is shown on the display.
- The alarm symbol on the display turns red, but the pump's operating mode is unchanged.
- Alarm code **High water level** is displayed in Grundfos GO Remote.

Cause The defined start level did not start the pump.

Remedy • Check and configure the sensor for start level.

Cause The pump is not big enough to remove the water.

Remedy • Contact Grundfos or an authorised service workshop.

8.16 Code 205 (Level switch inconsistency)

STATUS-NOT-SET | Code-205-(Level-switch-inconsistency)-(ts)-ADPyUk.dita

- Alarm code 205 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Level switch inconsistency** is displayed in Grundfos GO Remote.

Cause A float switch could be defective or stuck.

Remedy • Check the functionality of each float switch.

8.17 Code 225 (Communication error pump module)

STATUS-NOT-SET | Code-225-(Communication-error-IO-module)-(ts)-R65D68.dita

- Alarm code 225 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Communication error** is displayed in Grundfos GO Remote.
- The pump module is unable to communicate with the product.

Cause The pump module is installed incorrectly.

Remedy • Ensure that the module, including cables, is fitted correctly.

Cause The pump module is defective.

Remedy • Contact Grundfos.

8.18 Code 226 (Communication error IO module)

STATUS-NOT-SET | Code-226-(Communication-error-IO-module)-(ts)-SC5b33.dita

- Alarm code 226 is shown on the display.
- The alarm symbol on the display turns red and the pump stops.
- Alarm code **Communication error** is displayed in Grundfos GO Remote.
- The pump module is unable to communicate with the product.

Cause The IO module is installed incorrectly.

Remedy • Ensure that the module, including cables is fitted correctly.

Cause The IO module is defective.

Remedy • Contact Grundfos.

8.19 Code 229 (Water on floor)

STATUS-NOT-SET | Code-229-(Water-on-floor)-(ts)-AP98vml.dita

- Warning code 229 is shown on the display if you press the **Up** or **Down** button.
- The warning symbol on the display turns yellow and the pump's operating mode is unchanged.
- Warning code **Water on floor** is displayed in Grundfos GO Remote.

Cause The sensor detects water on the floor.

Remedy • Check for water leakage.

STATUS-NOT-SET | Technical-data-for-CU-241-(re)-Rw2Pw4.dita

9. Technical data

Supply voltage

24 VDC, - 10 %/+ 10 %.

Power supply is required to be class 2.

Check that the supply voltage corresponds to the values stated on the nameplate.

Maximum power dissipation

Object	Maximum power dissipation
99347488	9.4 W

Enclosure class

IP54, 3R for CU 241 built into panel of similar or higher enclosure class.


GENIbus terminal

- 7 VDC to + 12 VDC.

Nominal current condition: 4 mADC.

Short-circuit current condition: 328mA.

Dimensions



TM072339

Related information

[7.4 Replacing the battery](#)

STATUS-NOT-SET | Disposing-the-product-(ts)-Qjaor1.dita

10. Disposing of the product

This product or parts of it must be disposed of in an environmentally sound way.

- Use the public or private waste collection service.
- If this is not possible, contact the nearest Grundfos company or service workshop.
- Dispose of the waste battery through the national collective schemes. If in doubt, contact your local Grundfos company.

See also end-of-life information at www.grundfos.com/product-recycling.

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Centro
Industrial Garin
1619 - Garin Pcia. de B.A.
Tel.: +54-3327 414 444
Fax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Tel.: +61-8-8461-4611
Fax: +61-8-8340-0155

Austria

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Fax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boommesteinweg 81-83
B-2630 Aartselaar
Tel.: +32-3-870 7300
Fax: +32-3-870 7301

Belarus

Представительство ГРУНДФОС в Минске
220125, Минск, ул. Шафарнянская, 11,
оф. 56, БЦ «Порт»
Tel.: +7 (375 17) 286 39 72, 286 39 73
Fax: +7 (375 17) 286 39 71
E-mail: minsk@grundfos.com

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaj od Bosne 7-7A
BiH-71000 Sarajevo
Tel.: +387 33 592 480
Fax: +387 33 590 465
www.ba.grundfos.com
E-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castelo Branco,
630
CEP 09850 - 300
São Bernardo do Campo - SP
Tel.: +55-11 4393 5533
Fax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztocna Tangenta street no. 100
BG - 1592 Sofia
Tel.: +359 2 49 22 200
Fax: +359 2 49 22 201
E-mail: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada Inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Tel.: +1-905 829 9533
Fax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106 PRC
Tel.: +86 21 612 252 22
Fax: +86 21 612 253 33

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Tel.: +385 1 6595 400
Fax: +385 1 6595 499

Czech Republic

GRUNDFOS Sales Czechia and Slovakia
s.r.o.
Čajkovského 21
779 00 Olomouc
Tel.: +420-585-716 111

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tel.: +45-87 50 50 50
Fax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel.: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB
Trukkikuja 1
FI-01360 Vantaa
Tel.: +358-(0) 207 889 500

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacombe
F-38290 St. Quentin Fallavier (Lyon)
Tel.: +33-4 74 82 15 15
Fax: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schlüterstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Fax: +49-(0) 211 929 69-3799
E-mail: infoservice@grundfos.de
Service in Deutschland:
kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Tel.: +0030-210-66 83 400
Fax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor, Siu Wai Industrial
Centre
29-33 Wing Hong Street & 68 King Lam
Street, Cheung Sha Wan
Kowloon
Tel.: +852-27861706 / 27861741
Fax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Tópark u. 8
H-2045 Törökbálint
Tel.: +36-23 511 110
Fax: +36-23 511 111

India

GRUNDFOS Pumps India Private Limited
118 Old Mahabalipuram Road
Thoraiakkam
Chennai 600 097
Tel.: +91-44 2496 6800

Indonesia

PT GRUNDFOS Pompa
Graha Intirub Lt. 2 & 3
Jln. Cililitan Besar No.454. Makasar,
Jakarta Timur
ID-Jakarta 13650
Tel.: +62 21-469-51900
Fax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Tel.: +353-1-4089 800
Fax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Fax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
1-2-3, Shin-Miyakoda, Kita-ku
Hamamatsu
431-2103 Japan
Tel.: +81 53 428 4760
Fax: +81 53 428 5005

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Tel.: +82-2-5317 600
Fax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznesa centrs
Augusta Deglava ielā 60
LV-1035, Rīga,
Tel.: + 371 714 9640, 7 149 641
Fax: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel.: + 370 52 395 430
Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguam U1/25
Glenmarie Industrial Park
40150 Shah Alam, Selangor
Tel.: +60-3-5569 2922
Fax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México
S.A. de C.V.
Boulevard TLC No. 15
Parque Industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Tel.: +52-81-8144 4000
Fax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwezoom 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-88-478 6336
Fax: +31-88-478 6332
E-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrice Tinsley Crescent
North Harbour Industrial Estate
Albany, Auckland
Tel.: +64-9-415 3240
Fax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tel.: +47-22 90 47 00
Fax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznania
PL-62-081 Przeźmierowo
Tel.: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet de Magalhães, 241
Apartado 1079
P-2770-153 Paço de Arcos
Tel.: +351-21-440 76 00
Fax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
Bd. Biruintei, nr 103
Pantelimon county Ilfov
Tel.: +40 21 200 4100
Fax: +40 21 200 4101
E-mail: romania@grundfos.ro

Russia

ООО Грундфос Россия 109544
ул. Школьная, 39-41 Москва, RU-109544,
Russia
Tel.: (+7) 495 564-88-00 (495) 737-30-00
Fax: (+7) 495 564 8811
E-mail: grundfos.moscow@grundfos.com

Serbia

Grundfos Srbija d.o.o.
Omladinskih brigada 90b
11070 Novi Beograd
Tel.: +381 11 2258 740
Fax: +381 11 2281 769
www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
25 Jalan Tukang
Singapore 619264
Tel.: +65-6681 9688
Fax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
Prievozská 4D 821 09 BRATISLAVA
Tel.: +421 2 5020 1426
sk.grundfos.com

Slovenia

GRUNDFOS LJUBLJANA, d.o.o.
Leskoškova 9e, 1122 Ljubljana
Tel.: +386 (0) 1 568 06 10
Fax: +386 (0) 1 568 06 19
E-mail: tehnika-si@grundfos.com

South Africa

GRUNDFOS (PTY) LTD
Corner Mountjoy and George Allen Roads
Wilbart Ext. 2, Bedfordview 2008
Tel.: (+27) 11 579 4800
Fax: (+27) 11 455 6066
E-mail: lsmart@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
Camino de la Fuenteçilla, s/n
E-28110 Algete (Madrid)
Tel.: +34-91-848 8800
Fax: +34-91-628 0465

Sweden

GRUNDFOS AB
Box 333 (Lunnagårdsgatan 6)
431 24 Mölndal
Tel.: +46 31 332 23 000
Fax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fällanden/ZH
Tel.: +41-44-806 8111
Fax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Tel.: +886-4-2305 0868
Fax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloeam Phrakiat Rama 9 Road
Dokmai, Pravej, Bangkok 10250
Tel.: +66-2-725 8999
Fax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.
Gezbe Organize Sanayi Bölgesi
İhsan dede Caddesi
2. yol 200. Sokak No. 204
41490 Gebze/ Kocaeli
Tel.: +90 - 262-679 7979
Fax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

Бізнес Центр Європа
Столичне шосе, 103
м. Київ, 03131, Україна
Tel.: (+38 044) 237 04 00
Fax: (+38 044) 237 04 01
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone, Dubai
Tel.: +971 4 8815 166
Fax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 4TL
Tel.: +44-1525-850000
Fax: +44-1525-850011

U.S.A.

GRUNDFOS Pumps Corporation
17100 West 118th Terrace, Olathe
Kansas 66061
Tel.: +1-913-227-3400
Fax: +1-913-227-3500

Uzbekistan

Grundfos Tashkent, Uzbekistan
The Representative Office of Grundfos
Kazakhstan in Uzbekistan
38a, Oybek street, Tashkent
Tel.: (+998) 71 150 3290 / 71 150 3291
Fax: (+998) 71 150 3292

Revision Info

Last revised on 13-10-2016

99506145 xx18
ECM 1239476