

1. Read these instructions.
3. Keep these instructions.
- Heed all Warnings.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any of the ventilation openings. Install in accordance with the Manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the plug does not fit into your outlet. Consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when preparing for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to drops or splashes. Do not place objects filled with water, such as a vase, on the apparatus.
- The AC mains plug is used as the power disconnect device and it should remain readily accessible and operable during intended use. In order to completely disconnect the apparatus from power, the mains plug should be completely removed from the AC outlet socket. The apparatus should be locked close enough to the AC outlet so that you can easily reach the power cord plug at any time.
- CAUTION:** To reduce the risk of fire or explosion, do not expose batteries to excessive heat such as sunshine, fire or other heat sources.
- Do not install this apparatus in a confined space such as a book case or similar unit.



PORTABILITY CART WARNING  
(printed provided by RE-TAC)

## Important Safety Information

<b>WARNING:</b> TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.
<b>CAUTION:</b> TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT AND FULLY INSERT.
operate the equipment responsible for compliance could void the user's authority to
<b>CAUTION:</b> Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to
<b>CAUTION:</b> Avoid exposure to beam. Invisible laser radiation when open and interlocks defeated.
<b>CAUTION:</b> shall not be impeded for intended use.
<b>VENTILATION WARNING:</b> The normal ventilation of the product
vases, shall be placed on the product.
<b>DIPPING WARNING:</b> This product shall not be exposed to dripping or splashing, and no objects filled with liquids, such as
accompanying this product.
antennae (servicing) instructions in the literature
the presence of important operating and
<b>ATTENTION:</b> The examination point within an equilateral triangle is intended to alert the user to
constitute a risk of electric shock to persons.
enclosure that may be of sufficient magnitude to
intended to alert the user to the presence of
armoured symbol within an equilateral triangle is
<b>DANGEROUS VOLTAGE:</b> The lightning flash with

<b>CAUTION:</b> TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.
<b>CAUTION</b>
<b>RISK OF ELECTRIC SHOCK</b>
<b>DO NOT OPEN</b>

## Warnings

Supplier's Declaration of Conformity  
Model number: SD1485BK/SD1485W/REMIX, SD1366/N/BE, SD19055/CARNAVAL, SD19037/REISTA, SD19039/REISTA PLUS, SD19040/REISTA VOICE, SD19050/Festival Trade name: The Singing Machine Company, Inc. Address: 6301 NW 5th Way, Suite 2900, Fort Lauderdale, FL 33309, USA. Telephone number: 954-596-1000

**INDUSTRY CANADA NOTICE:** This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following conditions: (1) This device may not cause interference that may cause undesirable operation of the device. (2) The user is encouraged to try to correct the interference by one or more of the following measures: Increase the separation between the equipment and receiver. Reorient or relocate the receiving antenna. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

**INDUSTRIE CANADA REMARQUE:** L'appareil est conforme aux CNR d'innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage. (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Can ICS-3(B)/NMB-3(B)

1. Connect microphone(s) to the Mic Jack(s)
2. Connect power adapter to machine and then plug in to power outlet
3. Power on machine

## GET STARTED



[www.SingingMachine.com/KaraokeParty](http://www.SingingMachine.com/KaraokeParty)

and stay in touch and get all kinds of cool perks!

## REGISTER YOUR MACHINE!



shop for accessories at

[www.singingmachine.com](http://www.singingmachine.com)



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks and logos by The Singing Machine Company, Inc. is under license. Other trademarks and trade names are those of their respective owners.

### THE SINGING MACHINE COMPANY INC.

Is a registered trademark of The Singing Machine Company, Inc.

4060 E Jurupa Street, Unit B, Ontario, CA 91761-1413, USA  
COPYRIGHT © 2019



**singing machine®**

creating Joy through music™

## QUICK START GUIDE

# LET'S GET SINGING

To view a detailed product manual visit...

[www.SingingMachine.com/Manuals](http://www.SingingMachine.com/Manuals)



## JUST ADD MUSIC

Your new Singing Machine provides several ways to connect to your favorite music!



It is also compatible with all your favorite music and karaoke apps!



## TO AUX CORD CONNECT

1. Connect an AUX cord (not included) from device to Singing Machine LINE IN port



2. Press FUNCTION button until light around USB glows green



3. Select your favorite music and sing!



Notes: Lyrics will be displayed on mobile device screen. Volume can be adjusted from both mobile device and machine.



## TO BLUETOOTH® PAIR

1. Put Singing Machine in Bluetooth® Mode.

Bluetooth® mode can be easily accessed by pressing FUNCTION button until Bluetooth® indicator light blinks blue and light around USB port glows blue.

If your machine has a Bluetooth button, that can also be pressed to go to Bluetooth® mode



2. Go to Bluetooth® settings on phone and select SINGING MACHINE to connect



3. Select your favorite music and sing!



Notes: Lyrics will be displayed on mobile device screen. Volume can be adjusted from both mobile device and machine.



## TO PLAY USB FILES

1. Insert USB into Singing Machine USB port



2. Put Singing Machine into USB mode. To easily access USB mode press FUNCTION button until light around USB glows orange.



3. Press ENTER to view playlist



Notes: If your machine has a built-in screen, lyrics will display on screen. HDMI cord (not included) can be used to output lyrics to TV. We offer a huge selection of HD karaoke videos available for purchase. Just visit [singingmachine.com/app](http://singingmachine.com/app) to complete download instructions.