

BreezeACCESS MMDS

Subscriber Units

SU-A-D-MMDS Series

SU-E-D-MMDS Series

Installation Manual

July, 2000

Cat. No. 213100

© 2000 by BreezeCOM Ltd. All rights reserved.

No part of this publication may be reproduced in any material form without the written permission of the copyright owner.

Trade Names

BreezeACCESS, BreezeNET, BreezeLINK, BreezeVIEW, BreezeMANAGE and WIX are trade names of BreezeCOM Ltd. Other brand and product names are registered trademarks or trademarks of their respective companies.

Statement of Conditions

The information contained in this manual is subject to change without notice. BreezeCOM shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or equipment supplied with it.

Warranty

In the following warranty text, “the Company” shall mean:

- BreezeCOM Ltd., for products located outside the USA.
- BreezeCOM Inc., for products located in the USA.

This BreezeACCESS product is warranted against defects in material and workmanship for a period of one year from date of purchase. During this warranty period the Company will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, the product must be returned to a service facility designated by the Company. Authorization to return products must be obtained prior to shipment. The buyer shall pay all shipping charges to the Company and the Company shall pay shipping charges to return the product to the buyer.

The Company warrants that the firmware designed by it for use with the unit will execute its programming instructions when properly installed on the unit. The Company does not warrant that the operation of the unit or firmware will be uninterrupted or error-free.

Limitations of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by the buyer, buyer supplied interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance. No other warranty is expressed or implied. The Company specifically disclaims the implied warranties of merchantability and fitness for any particular purpose.

BreezeCOM shall not be liable to any person for any special or indirect damages, including, but not

limited to, loss of profits or revenues, loss of use or damage to any associated equipment, cost of capital, cost of substitute products, facilities or services, downtime costs or claims resulting from any cause whatsoever arising from or in any way connected with the manufacture, sale, handling, service, repair, maintenance or use of the products. In no event shall the company's liability exceed the purchase price denoted on the invoice.

Information to User

Any changes or modifications of equipment not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Safety Considerations

For the following safety considerations, "Instrument" means the BreezeACCESS Subscriber Unit components and its cables.

Caution

To avoid shock, do not perform any servicing unless you are qualified to do so.

Line Voltage

Before connecting this instrument to the power line, make sure that the voltage of the power source matches the requirements of the instrument: 100-240VAC, 50-60Hz.

Radio

The instrument transmits radio energy during normal operation. To avoid possible harmful exposure to this energy, do not stand or work for extended periods of time in front of its antenna. The long-term characteristics or the possible physiological effects of Radio Frequency Electromagnetic fields have not been yet fully investigated.

Antenna Installation and Grounding

Be sure that the Outdoor unit, the antenna and the supporting structure are properly installed to eliminate any physical hazard to either people or property. Verify that the antenna mast is grounded so as to provide protection against voltage surges and static charges. Make sure that the installation of the antenna and cable is performed in accordance with all relevant national and local building and safety codes.

Table of Contents

1. INTRODUCTION	1
2. BASIC INSTALLATION	2
2.1 Packing List.....	2
2.2 Other Items Required for Installation.....	2
2.3 General Installation Scheme.....	3
2.4 Guidelines for Selection of Equipment Locations	5
2.5 Installing the Outdoor Unit	7
2.5.1 Pole Mounting the Outdoor Unit	7
2.5.2 Connecting the Antenna Cable (SU-RE)	10
2.5.3 Connecting the Ground and IF Cables.....	10
2.6 Installing the SU-NI Indoor Unit	10
3. CONFIGURING SYSTEM PARAMETERS.....	12
3.1 Getting Started with the Local Terminal.....	12
3.2 Configuration Parameters.....	14
3.3 Reset Unit.....	16
4. ALIGNING THE ANTENNA	17
5. VERIFYING CORRECT OPERATION OF THE OUTDOOR UNIT.....	19
6. RSSI MEASUREMENT AND MAXIMUM DATA RATE CONFIGURATION	20
6.1 Performing the RSSI Measurement.....	20
6.2 Configuring The Maximum Data Rate.....	21
7. VERIFYING CORRECT OPERATION	22
7.1 General	22

7.2 Verifying Data Connectivity	22
8. SPECIFICATIONS	23
8.1 Radio	23
8.2 Data Communication	24
8.3 Outdoor Unit to Indoor Unit Communication.....	24
8.4 Configuration and Management.....	24
8.5 Interfaces	25
8.6 Electrical, Mechanical and Environmental	25
8.7 Standards Compliance, General	25
Appendix A. Using Telnet	

Table of Figures

Figure 2-1. SU-A General Installation Scheme.....	3
Figure 2-2. SU-E General Installation Scheme	4
Figure 2-3. Holes/Grooves/Screw holes.....	8
Figure 2-4. SU-RA 2" Pole Mounting Installation Using the Supplied Brackets	8
Figure 2-5. SU-RE 3" Pole Mounting Installation Using the Supplied Brackets.....	9
Figure 2-6. SU-NI Rear Panel	11
Figure 2-7. SU-NI Front Panel.....	11
Figure 3-1. Main Menu	13
Figure 3-2. Basic Configuration Menu	15
Figure 4-1. SU-RA/RE Outdoor Unit Bottom Panel.....	17

Table of Tables

Table 1: IF Cables	5
Table 2: SU-RA/RE Outdoor Unit LEDs.....	19
Table 3: RSSI vs. Maximum Data Rate	21
Table 4: SU-NI LEDs.....	22

1. INTRODUCTION

This manual describes installation guidelines for BreezeACCESS MMDS SU-A and SU-E series of Subscriber Units.

The BreezeACCESS IP Broadband Wireless Local Loop (WLL) system allows access service providers to provide high-speed IP connectivity services to their subscribers. To effectively support IP-based services BreezeACCESS systems employ wireless packet data switching technology.

The BreezeACCESS MMDS line of products uses Frequency Hopping Spread Spectrum radios that operate in Time Duplex Division (TDD) mode in the 2.500GHz – 2.686GHz frequency range.

SU-A and SU-E series Subscriber Units are comprised of an indoor unit (SU-NI) and an outdoor unit. In the SU-A product line, the outdoor unit (SU-RA) contains the radio module and an integral flat antenna. In the SU-E series, the outdoor unit (SU-RE) contains the radio module and an interface to an external antenna (not included). The indoor unit provides the interface to the user's equipment and is powered from the mains via its SU-PS power supply unit. The SU-NI also contains an IF (Intermediate Frequency) module and is connected to the outdoor unit via a 50-ohm coaxial IF cable. The IF cable serves for transmission of the 440MHz IF signal between the indoor and the outdoor units. It also serves for transferring power (12VDC), management and control signals from the indoor unit to the outdoor unit.

The SU-A/E-D-MMDS series include the following products:

- SU-A/E-1D-MMDS: supports a single Ethernet device
- SU-A/E-8D-MMDS: supports up to 8 Ethernet workstations/PCs
- SU-A/E-BD-MMDS: supports a LAN (a bridge functionality)

Note: *The information contained in this manual is applicable to BreezeACCESS MMDS units with software release 2.3.*

2. BASIC INSTALLATION

2.1 Packing List

- SU-NI Indoor unit
- Outdoor unit
 - ⇒ SU-RA with integral antenna
 - or
 - ⇒ SU-RE with a connector to an external antenna (not included)
- SU-PS power supply with a mains power cord
- Pole mounting kit for the Outdoor unit (with two brackets, four sets of screws, nuts and washers)
- Wall mounting kit for the SU-NI unit

2.2 Other Items Required for Installation

- IF cable* (available from BreezeCOM in different lengths)
- Grounding cable with an appropriate termination
- Antenna* and RF cable* (SU-E only)
- Ethernet cable (straight)
- A portable PC with terminal emulation software
- Monitor cable* (supplied with the base station equipment)
- Installation tools and materials.

Items marked with an asterisk () are available as options from BreezeCOM.*

2.3 General Installation Scheme

Figure 2-1 depicts the general installation scheme for BreezeACCESS SU-A MMDS Subscriber Units; Figure 2-2 depicts the general installation scheme for BreezeACCESS SU-E MMDS Subscriber Units.




Figure 2-1. SU-A General Installation Scheme




Figure 2-2. SU-E General Installation Scheme

2.4 Guidelines for Selection of Equipment Locations

Select appropriate locations for the Outdoor unit and for the Indoor unit using the following guidelines.

SU-RA

- The SU-RA Outdoor unit should be mounted on a pole and should be installed on a rooftop or a side-wall where a direct line of sight with the Base Station antenna can be established. The higher the unit, the better the achievable link quality.
- The antenna (integrated on the front side of the SU-RA Outdoor unit) should be directed towards the Base Station. The unit should be installed in a way that allows optimal alignment towards the Base Station. The location should also be selected to allow easy access to the unit for installation and testing.

SU-RE

- The SU-RE outdoor unit should be installed as near as possible to its antenna.

SU-RA/RE

- The SU-RA/RE is connected to the SU-NI by means of an IF cable carrying signaling, control signals and power. The IF frequency is 440 MHz. The maximum allowed attenuation of the IF cable connecting the Outdoor unit to the Indoor unit is 15dB and the maximum allowed DC resistance (the sum of the DC resistance of the inner and outer conductors) is 1.5 ohm. This allows for cable length of up to 30m when using the standard RG 58 cable.

If longer cables are required, a cable with lower attenuation and/or DC resistance should be used. Table 1 provides details regarding some popular cables such as the RG 58 and RG 213. If the spectral environment is polluted with noise in the 440 MHz band, it is recommended to use a higher quality double-shielded cable such as the LMR 240 or LMR 400 (manufactured by *Times Communications*).

Table 1: IF Cables

Cable Type	RG 58	RG 213	LMR 240	LMR 400
------------	-------	--------	---------	---------

Maximum cable Length (m)	30	100	65	150
--------------------------	----	-----	----	-----

- The Indoor unit should be installed in as close as possible to the building's entry point of the IF cable. The location of the Indoor unit should also take into account the need to connect it to a power mains outlet and to the CPE.

Note: *Outdoor units and antennas should be installed ONLY by experienced installation professionals who are familiar with local building and safety codes and, wherever applicable, are licensed by the appropriate government regulatory authorities.*

The system complies with the ETS 300 385 standard and is protected against secondary lightning strikes when its outdoor unit is properly grounded according to the applicable country-specific industry standards for protection of structures against lightning.

Failure to do so may void the BreezeACCESS product warranty and may expose the end user or the service provider to legal and financial liabilities. BreezeCOM and its resellers or distributors are not liable for injury, damage or violation of regulations associated with the installation of outdoor units or antennas.

2.5 Installing the Outdoor Unit

2.5.1 Pole Mounting the Outdoor Unit

The Outdoor unit can be secured to the pole using one of the following options:

- Special brackets (supplied with each unit). There are two pairs of screw holes, allowing use of the special brackets with various pole widths.
- U-bolts – size A (inner installation holes, up to 2” pole).
- U-bolt – size B (outside installation holes, up to 3” pole).
- Metal bands (9/16” wide, minimum 12” long).

Figure 2-3 shows the locations of the holes, grooves and screw holes on the rear side of the Outdoor unit.

Figure 2-4 illustrates the method of installing an SU-RA Outdoor unit on a pole, using the brackets.

Figure 2-5 illustrates the method of installing an SU-RE Outdoor unit on a pole, using the brackets.

Note: *Make sure to install the unit with the bottom panel (the panel with the IF connector) facing downward.*




Figure 2-3. Holes/Grooves/Screw holes




Figure 2-4. SU-RA 2" Pole Mounting Installation Using the Supplied Brackets




Figure 2-5. SU-RE 3" Pole Mounting Installation Using the Supplied Brackets

2.5.2 Connecting the Antenna Cable (SU-RE)

Connect an RF cable between the ANT connector (located on the top panel of the SU-RE unit) and the antenna.

2.5.3 Connecting the Ground and IF Cables

The Ground terminal (marked $\oplus$) and the IF cable connector (marked IF) are located on the bottom panel of the SU-RA Outdoor unit, shown in Figure 4-1.

1. Connect one end of the ground cable to the Ground terminal and connect the other end to a good ground connection.
2. Connect the coaxial cable to the IF connector. Verify that the length of the IF cable is sufficient and that it can easily reach the Indoor unit.

Note: *Make sure to switch OFF the power of the SU-NI unit prior to connecting/disconnecting the IF cable.*

2.6 Installing the SU-NI Indoor Unit

1. Place the SU-NI unit in an appropriate location on a shelf or a table. The unit can be wall mounted using the installation materials provided with the unit. Use a 6mm (1/4") drill and the supplied template plate for easy and accurate marking of the holes.
2. Connect the SU-PS power cord to the DC In jack (marked DC-12V) located on the rear panel of the Indoor unit (shown in Figure 2-6).
3. Connect the IF cable to the IF connector (marked IF) on the rear panel of the Indoor unit. The other side of the IF cable should already be connected to the Outdoor unit.
4. Connect the other end of the mains power cord to the SU-PS. Connect the mains power plug to a mains power outlet.




Figure 2-6. SU-NI Rear Panel

5. Verify that the Power LED (marked PWR) located on the front panel of the Indoor Unit is turned ON.




Figure 2-7. SU-NI Front Panel

6. Use a straight Ethernet 10baseT cable to connect a PC (SU-A/E -1D), or a hub (SU-A/E-8D or SU-A/E-BD) to the Ethernet port (marked ETH) located on the rear panel of the SU-NI unit.

3. CONFIGURING SYSTEM PARAMETERS

After completing the installation process, as described in the preceding section, proceed with the configuration of the basic system parameters.

This section covers the configuration of basic installation parameters. Refer to the Administration Manual for information related to other parameters.

Note: *Optionally, the product can be configured using Telnet over the Ethernet port, after setting IP address. For further information, see Appendix A.*

3.1 Getting Started with the Local Terminal

1. Connect one end of the Monitor cable to the MON jack on the front panel of the SU-NI Indoor unit. Connect the second end of the cable to the COM port of the terminal. The COM port connector on the Monitor cable is a 9 pin D-type plug.
2. Run a terminal emulation program (e.g., ProComm or Windows HyperTerminal) using the following setup.

<i>Baud rate</i>	9600
<i>Data bits</i>	8
<i>Stop bits</i>	1
<i>Parity</i>	None
<i>Flow Control</i>	Xon/Xoff
<i>Connector</i>	Available Com Port

3. Press **Enter**. The *Select Access Level* menu appears. Select the access level according to your authorized access level. You will be requested to enter your password. After entering the correct password press enter. The main menu appears (refer to Figure 3-1).




Figure 3-1. Main Menu

The appearance of the displayed *Main Menu* varies in accordance with the access level.

- For users with read only access rights, only the *Info Screens* option is displayed. Users with this access level cannot access the *Unit Control*, *Basic Configuration*, *Site Survey* and *Advanced Configuration* menus.
- For users with Installer access rights, the first four menu items (*Info Screens*, *Unit Control*, *Basic Configuration* and *Site Survey*) are displayed. Users with this access level cannot access the *Advanced Configuration* menu.
- For users with Administrator access rights, the full *Main Menu* will be displayed. These users can access all the menu items.

4. Operate the monitor program as follows:

- Type an option number to open/activate the option. You may need to press the Enter key in some cases.
- Press the Esc key to exit a menu or an option.
- You can log-out and exit the monitor program at any time by simultaneously pressing the **Ctrl** and **X** keys.
- Reset the unit after making configuration changes for the new values to take effect.
- You can view the current parameters' configuration by selecting 1 in the Main Menu to Access the Info Screens menu, and then selecting 2 in the Info Screens menu to view the Basic Configuration parameters.

3.2 Configuration Parameters

The following system parameters must be configured for each specific installation:

- *ESSID*
- *IP Address*
- *Subnet Mask*
- *Default Gateway Address*
- *Hopping Band*
- *Frequency Offset*
- *Maximum Data Rate* (Depending on results of RSSI measurement)

Note: You must select *Reset Unit* in the *Unit Control* menu for the changes to take effect.

1. From the *main menu*, type **3** to access the *Basic Configuration* menu.

```
BreezeACCESS (SU-1D)
Official Release Version - 2.1.1
Release Date: Tue Mar 07 11:21:22 2000

Basic Configuration
=====
1 - IP Address
2 - Subnet Mask
3 - Default Gateway Address
4 - ESSID
5 - Maximum Data Rate
6 - Frequency Offset
7 - Hopping Band
X - Transmit Power Control
Y - Receive Attenuation Control
S - Show Basic Configuration
BreezeACCESS >>>
```

Figure 3-2. Basic Configuration Menu

2. From the *Basic Configuration* menu, type 1 to access the *IP Address* selection screen. Enter the required IP address.
3. Type 2 to access the *Subnet Mask* selection screen. Enter the required subnet mask.
4. Type 3 to access the *Default Gateway Address* selection screen. Enter the required default gateway address.
5. Type 4 to access the *ESSID* selection screen. Enter the required ESSID.
6. Type 6 to access the *Frequency Offset* selection screen. Enter the required offset.
7. Type H to access the *Hopping Band* selection screen. Enter the required bandwidth.

3.3 Reset Unit

1. From the *main menu*, type **2** to access the *Unit Control* menu.
2. Type **1** to access the *Reset Unit* menu. Type **1** to reset the unit so that new configuration settings are applied.

Note: *Should you make any mistakes during configuration or encounter any problems associated with system configuration parameters, you may configure the unit back to the factory defaults, as follows:*

Type 2 in the Unit Control menu to access the Set Factory Defaults menu. Type in 2 (Set Factory defaults-Full) to load the default values. Reset the unit for the factory defaults values to take effect.

4. ALIGNING THE ANTENNA

Note: Antenna alignment using the RSSI bar display is possible only after the Access Unit you wish to associate with is operational and the ESSID, Hopping Band and Frequency Offset parameters were properly configured. Otherwise the unit will not be able to synchronize and associate with the Access Unit. As the RSSI measurement is performed on received frames, its results are meaningless as long as the unit is not associated with an AU.

1. Verify that the Power indication (the Yellow LED of the BSSI bar display) is ON.




Figure 4-1. SU-RA/RE Outdoor Unit Bottom Panel

2. Align the antenna (integrated into the front side of the SU-RA Outdoor unit, or separate if the unit is an SU-RE) to point towards the general direction of the base station.
3. The RSSI bar display is located on the bottom panel of the Outdoor unit (refer to Figure 4-1). The 8 green RSSI LEDs are used for reading the Received Signal Strength Indication. The higher the number of green LEDs that are ON, the higher the level of the received signal. Rotate the antenna left and/or right until you reach the point of maximum RSSI reading. Make sure that at all times, the front of the antenna faces the general direction of the base station.

4. For proper operation, at least one green LED should be ON. If you cannot reach a point where at least one green LED is ON, try to improve the reception quality by placing the antenna at a higher point or in a different location.

Note: *In some cases (e.g., when the Subscriber Unit is very close to the Base Station), the antenna might have to be installed at an appropriate angle, in order to ensure that it is directed towards the Base Station antenna).*

5. Tighten the bracket screws (or the U-bolts/metal band), firmly securing the unit to the pole.

5. VERIFYING CORRECT OPERATION OF THE OUTDOOR UNIT

To verify correct operation, view the LED indicators located on the bottom panel of the Outdoor unit as shown in Figure 4-1 on page 17.

The following table lists the various LED states.

Table 2: SU-RA/RE Outdoor Unit LEDs

Name	Description	Functionality
ALARM	Alarm Indication	On – A problem with the power amplifier or in the locking process of any of the synthesizers Off – Normal operation
WLNK	Wireless link activity	Blinking – Receiving packet from the wireless link Off – No reception of packets from the wireless link
ETH	Ethernet activity	Blinking – Data received from or transmitted to Ethernet LAN Off – No activity on the Ethernet LAN
RSSI	Bar display	Displays the Received Signal Strength Indication. The higher the number of green LEDs that are ON, the higher the level of the received signal.
	Yellow LED	On - Power On Off – Power is not received from the Indoor unit
	8 Green LEDs	RSSI in 4 dB resolution starting at –91dBm
	Red LED	Received signal strength is –40dBm or higher

Note: Verifying proper operation of the Outdoor unit using the LEDs as described above is possible only after completion of the configuration and alignment processes.

6. RSSI MEASUREMENT AND MAXIMUM DATA RATE CONFIGURATION

6.1 Performing the RSSI Measurement

The Average RSSI Continuous Display test allows a continuously updated display of the average Received Signal Strength Indication. As the test measures only the desired signal of properly received frames, it is a good indication to the quality of the received signal.

Note: *As the RSSI bar indicator is not accurate, it is recommended always to perform the Average RSSI Continuous Display test after the antenna was optimally aligned.*

1. Start the Monitor program as described in Section 3.1.
2. From the *Main Menu* Type 4 to access the *Site Survey* menu.
3. Type 4 to activate the Average RSSI Continuous Display selection screen.
4. On the screen you will get a continuously updated display of RSSI measurements. To stop the test, press the Esc key.

6.2 Configuring The Maximum Data Rate

5. Use the following table to determine the recommended Maximum Data Rate.

Table 3: RSSI vs. Maximum Data Rate

RSSI	Maximum Data Rate
Higher than 97	3 Mbps
From 86 to 97	2Mbps
Lower than 86*	1 Mbps

* If the RSSI is lower than 80 units the link quality is too low and should be improved through installing the antenna in a different and/or a higher location.

2. If the measured average RSSI is less than 97 units, the default Maximum Data Rate of 3 Mbps is to high and should be decreased.
3. From the *Basic Configuration* menu select 5 to access the *Maximum Data Rate* selection menu.
4. Configure the Maximum Data Rate according to Table 3 above.
5. Reset the unit for the new configuration to become effective.

7. VERIFYING CORRECT OPERATION

7.1 General

After completing the installation as described above, the system starts operation. To verify correct operation, view the LED indicators located on the front panel of the SU-NI Indoor unit as shown in Figure 2-7 on page 11.

Table 4 lists the various LED states.

Table 4: SU-NI LEDs

Name	Description	Functionality
PWR	Power supply	On – After successful power up Off – Power off
WLNK	Wireless link activity	Blinking –Receiving packet from the wireless link Off – No reception of packets from the wireless link
ETH connector embedded yellow LED	Ethernet activity	On- Receive/Transmit on Ethernet port Off- No Receive/Transmit on Ethernet port
ETH connector embedded green LED	ETH Link Integrity	On- Unit is connected to Ethernet segment Off- Unit is not connected to Ethernet segment

7.2 Verifying Data Connectivity

From the user's PC or from a portable PC connected to the unit, Ping the unit or try to connect it to the Internet.

8. SPECIFICATIONS

8.1 Radio

Frequency	2.500GHz – 2.686GHz	
Radio Access Method	FH-CDMA or TDMA	
Operation Mode	Time Duplex Division	
Sub-Channel Bandwidth	1 MHz	
Frequency Setting Resolution	1 MHz	
Antenna Gain (SU-RA)	17dBi, 20°	
Output Power (at antenna port)	27 dBm typical. Power Control range: 20 dB	
Sensitivity (dBm at antenna port, BER 1E10 ⁻⁶)	1Mbps 2Mbps 3Mbps	-87 -80 -71
Data Rate	3Mbps max	
Modulation	Multilevel GFSK	

8.2 Data Communication

Standard Compliance	IEEE 802.3 CSMA/CD
---------------------	--------------------

8.3 Outdoor Unit to Indoor Unit Communication

IF Frequency	440 MHz
IF cable Impedance	50 ohm
Maximum IF cable Attenuation	15dB
Maximum IF cable DC Resistance	1.5 ohm

8.4 Configuration and Management

Local Management	Via MON port, Monitor program using terminal emulation
Remote Management	SNMP, Telnet, TFTP
Remote Management Access	From Wired LAN, Wireless Link
SNMP Agents	MIB II, Bridge MIB, Private MIBs
Accounting	RADIUS compatible client
Security	Authentication and filtering
Software upgrade	TFTP download

8.5 Interfaces

Interface	Outdoor unit	SU-NI indoor unit
IF	TNC jack, lightning protected	TNC jack, lightning protected
RF (SU-E)	N-Type jack	
Ethernet		10Base-T (RJ-45) with 2 embedded LEDs
Monitor		3-pin low profile
Power	12 VDC via the IF cable	DC Plug for the SU-PS power supply

8.6 Electrical, Mechanical and Environmental

	Outdoor Unit	SU-NI Indoor Unit
Power	12 VDC from SU-NI via the IF cable	SU-NI: 12VDC/MMDSA from SU-PS SU-PS: 100 – 240 VAC, 47-63 Hz
Mechanical	SU-RA: 30cm x 30cm x 7.2 cm, 3 kg SU-RE: 30cm x 12cm x 5 cm, 2.2 kg.	SU-NI: 13cm x 8.6cm x 3cm, 0.5 kg. SU-PS: 10cm x 6.5cm x 3.5cm, 0.4 kg.
Operating Temperature	-40 ⁰ C to 60 ⁰ C	0 ⁰ C to 40 ⁰ C
Operating Humidity	5%-95% non condensing, Weather protected	5%-95% non condensing

8.7 Standards Compliance, General

EMC	EN300 385:1998 (including EN55022:1994 and EN50082-1:1992)
Safety	EN 60950
Environmental	ETS 300 019

APPENDIX A. USING TELNET

Use the following procedure to connect to BreezeACCESS MMDS units via a Telnet session.

1. Connect the PC to the Ethernet port of the unit (or the hub to which the unit is connected) using a straight Ethernet cable. If you connect the PC directly to a unit that is normally connected to a hub, use a crossed Ethernet cable. You may also connect the PC to any Ethernet port on the network and communicate with the unit to be managed via the wired or wireless media.
2. Make sure that the IP parameters of the PC are configured to enable connectivity with the unit.
3. Run a Telnet application and use the IP address of the unit to be managed as the Host Name.
4. Set Port to *Telnet* (this is the default).
5. Set Terminal Type to *VT100* (this is the default).
6. Enter the Service Provider password.
7. When the password is recognized, the following message is displayed:

You have entered.

8. Press **Enter**, the Breeze ACCESS Monitor is displayed on the screen.

To exit the Telnet session, choose *Disconnect* from the *Connect* menu. (The session is terminated automatically, after a specific time of inactivity determined by the Log-out Timer).