

VISTATECH

INSTRUCTION MANUAL




Rechargeable QUADCOPTER DRONE

User-Friendly & Designed For Beginner


*Please read this manual carefully before operation and keep it for future reference.

KNOW YOUR DRONE
With 2.4G frequency band for long remote control distance. Drone allows multiple flights of the same time without any interference. User can control it to fly, hover and take photos/videos with APP and WiFi connection on smart phone.



1

ACCESSORIES



2

PRE-FLIGHT PREPARATION

1. FLIGHT ENVIRONMENT



Indoor: spacious spaces away from barriers, crowds or pets are preferred.



Outdoor: sunny & windless weather are preferred.



Please keep the drone in sight during the flight and keep it away from barriers, high-tension cables, trees and people.



Do not fly in extreme weather such as very hot temperature, very cold temperature, strong winds or raining.





User Manual x1

3

2. OPEN THE WINGS

OPENING STEPS:
① Open the front arm/clese to camera.
② Open the back arm.
To close the wings reverse the steps.



Notes:


Red LED light is on when charging. Red LED light is off when fully charged. Charging time is about 150 minutes. Play time is about 7 minutes.

The red and blue light on the drone will start flashing which indicates the battery is low. The battery needs to be charged fully before operating again.

4

3. CHARGE THE DRONE

A. Remove the rechargeable battery from the bottom of the drone.



Notes:

Red LED light is on when charging. Red LED light is off when fully charged. Charging time is about 150 minutes. Play time is about 7 minutes.

The red and blue light on the drone will start flashing which indicates the battery is low. The battery needs to be charged fully before operating again.

5

4. BATTERY CAUTIONS

There is a certain risk when using lithium batteries. It may cause fire, body injury or property loss. Users must be aware of the risks and take full responsibility of using battery improperly.



Please remove the plug immediately if you sense any peculiar smell, noise or smoke.



Battery Charging

① Please use the original USB charging cable provided from the manufacturer to ensure your safe usage.

② Do not over charge battery. Please unplug the charger once fully charged.

③ Do not charge overnight.

④ Do not charge the battery next to inflammables, such as carpet, timber floor or wood furniture or on the surface of electro-conductive objects. Please always keep an eye on the battery when charging.

⑤ Do not charge battery when it is hot or warm.

⑥ The charging temperature should be between 32 °F to 104 °F.



⑦ Red LED light is on when charging. Red LED light is off when fully charged. Charging time is about 150 minutes. Play time is about 7 minutes.

⑧ The red and blue light on the drone will start flashing which indicates the battery is low. The battery needs to be charged fully before operating again.

6

5. KNOW YOUR REMOTE CONTROL

1. Parts of remote control



Notes:

① Make sure the battery are loaded correctly according to the polarity indications on the battery compartment.




② Please do not mix old and new batteries together.

③ Please do not mix different types of batteries together.

7

6. REPLACING BATTERY OF THE REMOTE CONTROL

① Open the remote control battery cover




8

7. PAIRING THE REMOTE CONTROL AND THE DRONE

① Press the ON/OFF button on the drone for 2 seconds.

To turn on the drone. The indicator light on the drone will start flashing. Place it on a flat surface.




9

8. START YOUR FLIGHT

1. One-key take off

Press the One-key take off button, the drone will fly to about 5 feet height.




10

9. 2. Basic Flight

Use left joystick to control the flight altitude and turn left / right.

Right joystick to control the forward, backward, left and right side flight directions.





11

10. Left joystick

Ascend

Descend





12

11. Turn left

Turn right

Turn left






13

12. Hover

When you release the left joystick after the ascent / descent action, the drone will hover at a certain height.

Left joystick




14

13. 360° Flip & Roll

Make sure the drone is reaching over 9.8 feet height. Press 360° Flip & Roll button and move the right joystick to left or right direction. The drone will rotate in that direction.

Right joystick




15

14. FAQ

PROBLEMS

CAUSES

SOLUTIONS



16

15. USE WITH SMART DEVICE (NOT INCLUDED)

1. TO INSTALL THE APP IN YOUR SMART DEVICE

Scan the corresponding QR code to download and install the APP iFun_Pro.

17

16. 3. MAIN INTERFACE INSTRUCTIONS

1. START

- To enter the flight interface

① ? HELP - Quick start guide and list of icon function

18

17. 4. INTERFACE OPERATION INSTRUCTIONS

① Gravity Control

To control the drone forward / backward / left side flight / right side flight by controlling the gravity of the smart device.

Note: it may not work with some old version or without gravity sensor smart devices.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. (For:2.4G RC DRONE WITH 0.3MP WIFI CAMERA)

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. (For:2.4G RC DRONE WITH 0.3MP WIFI CAMERA-Remote Control)