



802.11ax-HE20 - Ant 3 (Nss = 1)


Channel 37 (6135MHz)




Channel 53 (6215MHz)




Channel 69 (6295MHz)




Channel 85 (6375MHz)




Channel 101 (6455MHz)




Channel 117 (6535MHz)



Channel 133 (6615MHz)




Channel 149 (6695MHz)




802.11ax-HE20 - Ant 3 (Nss = 1)


Channel 165 (6775MHz)




Channel 181 (6855MHz)




Channel 197 (6935MHz)



Channel 213 (7015MHz)




Channel 229 (7095MHz)




802.11ax-HE40 - Ant 3 (Nss = 1)


Channel 35 (6125MHz)




Channel 51 (6205MHz)




Channel 67 (6285MHz)




Channel 83 (6365MHz)




Channel 99 (6445MHz)




Channel 115 (6525MHz)



Channel 131 (6605MHz)




Channel 147 (6685MHz)




802.11ax-HE40 - Ant 3 (Nss = 1)


Channel 163 (6765MHz)




Channel 179 (6845MHz)




Channel 195 (6925MHz)



Channel 211 (7005MHz)




Channel 211 (7085MHz)




802.11ax-HE80 - Ant 3 (Nss = 1)


Channel 39 (6145MHz)




Channel 55 (6225MHz)




Channel 71 (6305MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)




Channel 119 (6545MHz)



Channel 135 (6625MHz)




Channel 151 (6705MHz)




802.11ax-HE80 - Ant 3 (Nss = 1)


Channel 167 (6785MHz)




Channel 183 (6865MHz)



Channel 199 (6945MHz)




Channel 215 (7025MHz)




802.11ax-HE160 - Ant 3 (Nss = 1)


Channel 47 (6185MHz)




Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11ax-HE20 - Ant 0 (Nss = 4)


Channel 37 (6135MHz)




Channel 53 (6215MHz)




Channel 69 (6295MHz)




Channel 85 (6375MHz)




Channel 101 (6455MHz)




Channel 117 (6535MHz)



Channel 133 (6615MHz)




Channel 149 (6695MHz)




802.11ax-HE20 - Ant 0 (Nss = 4)


Channel 165 (6775MHz)




Channel 181 (6855MHz)




Channel 197 (6935MHz)



Channel 213 (7015MHz)




Channel 229 (7095MHz)




802.11ax-HE40 - Ant 0 (Nss = 4)


Channel 35 (6125MHz)




Channel 51 (6205MHz)




Channel 67 (6285MHz)




Channel 83 (6365MHz)




Channel 99 (6445MHz)




Channel 115 (6525MHz)



Channel 131 (6605MHz)




Channel 147 (6685MHz)




802.11ax-HE40 - Ant 0 (Nss = 4)


Channel 163 (6765MHz)




Channel 179 (6845MHz)




Channel 195 (6925MHz)



Channel 211 (7005MHz)




Channel 227 (7085MHz)




802.11ax-HE80 - Ant 0 (Nss = 4)


Channel 39 (6145MHz)




Channel 55 (6225MHz)




Channel 71 (6305MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)



Channel 119 (6545MHz)



Channel 135 (6625MHz)



Channel 151 (6705MHz)

