

# CHCNAV i89 GNSS User Guide



Make your work more efficient

# Table of Content

<b>Table of Content .....</b>	<b>2</b>
<b>Preface .....</b>	<b>5</b>
Copyright .....	5
Safety Warnings .....	5
FCC Interference Statement .....	6
CE Interference Statement .....	6
Conformity to Japanese regulations .....	6
<b>1 Introduction .....</b>	<b>7</b>
1.1 Safety Information .....	7
1.1.1 Warnings and Cautions .....	7
1.2 Regulations and Safety .....	7
1.2.1 Use and Care .....	8
1.3 Technical Support .....	8
1.4 Disclaimer .....	8
1.5 Your Comments .....	8
<b>2 Getting Started with I89 .....</b>	<b>9</b>
2.1 About the Receiver .....	9
2.2 Parts of the Receiver .....	9
2.2.1 Front Panel .....	9
2.2.2 Lower Housing .....	11
2.2.3 Receiver Ports .....	12
2.3 Batteries and Power .....	13
2.3.1 Batteries .....	13
2.3.2 The Internal Battery .....	13
2.3.3 Battery Safe .....	14
2.4 Product Basic Supply Accessories .....	15
2.4.1 Base Kit Basic Supply .....	15
2.4.2 Rover Kit Basic Supply .....	16
2.5 Connecting to an Office Computer .....	17
2.6 Connecting to a Controller .....	18
2.6.1 Connecting via Wi-Fi with LandStar 8 Software .....	18
2.6.2 Connecting via Bluetooth with LandStar 8 Software .....	20
2.7 Downloading Logged Data .....	22
2.7.1 FTP Download .....	22
2.7.2 Web Server Download .....	23
2.7.3 USB Download .....	24

<b>3 Equipment Setup and Operation</b>	<b>26</b>
3.1 Post-processing Base Station Setup	26
3.2 Real-Time Base Station Setup	28
3.2.1 Internal Cellular or UHF	28
3.2.2 External UHF	30
3.3 Real-Time Rover Station Setup	32
3.4 Working with the Tilt Compensation	34
3.4.1 Operation Steps for first IMU initialization	34
3.4.2 Notes of using tilt measurement	36
3.5 Visual Survey	38
3.5.1 Survey point mode	38
3.5.2 Modeling mode	42
<b>4 Configuring Through a Web Browser</b>	<b>44</b>
4.1 Status Menu	46
4.1.1 Position Submenu	46
4.1.2 Activity Submenu	46
4.1.3 Google Map Submenu	47
4.2 Satellites Menu	48
4.2.1 Tracking Table Submenu	48
4.2.2 Tracking Info. Table Submenu	49
4.2.3 Tracking Skyplot Submenu	49
4.2.4 Satellite Activation Submenu	50
4.3 Receiver Configuration Menu	51
4.3.1 Description	51
4.3.2 Antenna Configuration Submenu	52
4.3.3 Reference Station Settings Submenu	52
4.3.5 Receiver Reset Submenu	55
4.3.6 Languages Submenu	55
4.3.7 User Management Submenu	56
4.3.8 HCPPP Settings	56
4.4 Data Recording Menu	57
4.4.1 Log Settings Submenu	57
4.4.2 FTP Push Settings Submenu	59
4.4.3 FTP Push Log Submenu	60
4.4.4 Data Download Submenu	61
4.5 IO Settings Menu	63
4.5.1 IO Settings Submenu	63
4.6 Network Setting Menu	70
4.6.1 Description Submenu	70
4.6.2 Mobile Network Setting Submenu	71
4.6.3 Email Alarm Submenu	71

4.6.4 HTTP Submenu .....	72
4.6.6 HTTPS Submenu .....	73
4.6.7 FTP Service Submenu .....	73
4.7 Module Setting Menu .....	74
4.7.1 Description Submenu .....	74
4.7.2 WiFi Submenu .....	74
4.7.3 Bluetooth Settings Submenu.....	75
4.7.4 Radio Settings Submenu.....	76
4.8 Firmware Menu.....	77
4.8.1 Firmware Info Submenu .....	77
4.8.2 Hardware Version Submenu .....	77
4.8.3 Config File Submenu.....	78
4.8.4 System Log Download Submenu.....	78
4.8.5 User Log Submenu.....	78
4.8.6 Firmware Update Submenu.....	79
4.8.7 GNSS Board Upgrade Submenu.....	80
4.8.8 Radio Upgrade Submenu.....	80
4.8.9 Upgrade Online Submenu .....	80
4.8.10 GNSS Registration Submenu .....	81
4.9 Cloud Service Setting Menu .....	82
4.9.1 Cloud Service Setting Submenu.....	82

---

## Preface

## Copyright

### Copyright 2023-2024

CHCNAV | Shanghai Huace Navigation Technology Ltd. All rights reserved. The CHCNAV are trademark of Shanghai Huace Navigation Technology Limited. All other trademarks are the property of their respective owners.

### Trademarks

All product and brand names mentioned in this publication are trademarks of their respective holders.

## Safety Warnings

GNSS (Global Navigation Satellite System) receivers are electronic devices that use signals from satellites to determine location, speed, and time. While GNSS receivers are generally safe to use, there are some safety considerations that users should keep in mind:

**Do not rely solely on GNSS for navigation:** GNSS signals can be disrupted by various factors such as tall buildings, trees, and bad weather. It is important to use other navigation aids such as maps, compasses, and visual landmarks.

**Keep GNSS receivers away from other electronic devices:** Electronic devices such as mobile phones, radios, and computers can emit electromagnetic interference (EMI) that can disrupt GNSS signals. Keep GNSS receivers away from such devices to avoid EMI.

**Do not tamper with GNSS receivers:** Tampering with GNSS receivers or modifying their software can cause them to malfunction or produce inaccurate readings. Only use GNSS receivers that are certified and authorized for use.

**Follow manufacturer instructions:** Follow the manufacturer's instructions regarding the safe use and handling of GNSS receivers. This includes instructions for charging, cleaning, and storing the device.

**Dispose of GNSS receivers properly:** When disposing of GNSS receivers, follow local regulations for electronic waste disposal to avoid harming the environment.

It is important to use GNSS receivers safely to avoid accidents or injury. If you experience any issues or concerns with your GNSS receiver, contact the manufacturer or a qualified technician for assistance.

## FCC Interference Statement

This equipment has been designed to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules in the Portable Mode. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

## CE Interference Statement

Declaration of Conformity: Hereby, Shanghai Huace Navigation Technology Ltd. declares that this i93 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

## Conformity to Japanese regulations

Japanese Radio Law and Japanese Telecommunications Business Law Compliance.

- This device is granted pursuant to the Japanese Radio Law and the Japanese Telecommunications Business Law.
- This device should not be modified (otherwise the granted designation number will become invalid).

# 1 Introduction

The i93 GNSS Receiver User Guide describes how to set up and use the CHC® i93 GNSS receiver. In this manual, “the receiver” refers to the i93 GNSS receiver unless otherwise stated. Even if you have used other Global Navigation Satellite Systems (GNSS) products before, CHC recommends that you spend some time reading this manual to learn about the special features of this product. If you are not familiar with GNSS, go to [www.chcnav.com](http://www.chcnav.com) for an interactive look at CHC and GNSS.

## 1.1 Safety Information

### 1.1.1 Warnings and Cautions

An absence of specific alerts does not mean that there are no safety risks involved.

A Warning or Caution information is intended to minimize the risk of personal injury and/or damage to the equipment.



**WARNING** - A Warning alerts you to a potential misused or wrong setting of the equipment.



**CAUTION** - A Caution alerts you to a possible risk of serious injury to your person and/or damage to the equipment.

## 1.2 Regulations and Safety

The receivers contain a built-in wireless modem for signal communication through Bluetooth® wireless technology or through external communication data link. Regulations regarding the use of the wireless modem vary greatly from country to country. In some countries, the unit can be used without obtaining an end-user license. However, in some countries, the administrative permissions are required. For license information, consult your local dealer. Bluetooth® operates in license-free bands.

Before operating a i93 GNSS receiver, determine if authorization or a license to operate the unit is required in your country. It is the responsibility of the end-user to obtain an operator's permit or license for the receiver for the location or country of use.

### 1.2.1 Use and Care

This receiver is designed to withstand the rough environment that typically occurs in the field. However, the receiver is high-precision electronic equipment and should be treated with reasonable care.



CAUTION - Operating or storing the receiver outside the specified temperature range will cause irreversible damage.

## 1.3 Technical Support

If you have a problem and cannot find the information you need in this manual or CHC website ([www.chcnav.com](http://www.chcnav.com)), contact your local CHC dealer from which you purchased the receiver(s).

If you need to contact CHC technical support, please contact us by email ([support@chcnav.com](mailto:support@chcnav.com)) or Skype (chc\_support).

## 1.4 Disclaimer

Before using the receiver, please make sure that you have read and understood this User Guide, as well as the safety information. CHC holds no responsibility for the wrong operation by users and for the losses incurred by the wrong understanding about this User Guide. However, CHC reserves the rights to update and optimize the contents in this guide regularly. Please contact your local CHC dealer for new information.

## 1.5 Your Comments

Your feedback about this user guide will help us to improve it in future revision. Please email your comments to [support@chcnav.com](mailto:support@chcnav.com).

## 2 Getting Started with I89

### 2.1 About the Receiver

The new CHCNAV i93 GNSS receiver offers integrated IMU-RTK technology to provide a robust and accurate GNSS positioning in any circumstances. Unlike the standard MEMS based GNSS receivers, the i93 GNSS IMU-RTK combines state-of-the-art GNSS RTK engine, calibration-free professional IMU sensor and advanced GNSS tracking capabilities. Survey projects are achieved with high productivity and reliability pushing the boundaries of conventional GNSS RTK survey.

The LCD panel enables user to check satellite-tracking status, internal battery status, Wi-Fi status, working mode, data logging status and basic receiver information. Bluetooth and Wi-Fi technology provides cable-free communication between the receiver and controller.

The receiver can be used as the part of an RTK GNSS system with CHC LansStar7 software. Moreover, user can download the GNSS data that recorded in the internal memory of receiver to a computer.

The receiver can be used as the part of an RTK GNSS system with CHC LandStar 8 software. And you can download the GNSS data that recorded in the internal memory of receiver to a computer.

To configure the receiver for performing a wide variety of functions, you can use the web interface by connecting the receiver with PC or smartphone through Wi-Fi.

### 2.2 Parts of the Receiver

The operating controls are all located on the front panel. SIM card slot is on the backside. Serial ports and connectors are located on the bottom of the unit.

#### 2.2.1 Front Panel

The following figure shows a front view of the receiver.



The front panel contains two indicator LEDs and two buttons.



Name	Description
Correction LED (Yellow/Green)	<ul style="list-style-type: none"> <li>Indicates whether the receiver is transmitting/receiving differential data.</li> <li>As a Base station: successfully transmitting differential data, flash yellow light.</li> <li>As a Rover station: successfully receiving differential data from Base station will flash yellow light when it is single or float, flash green light when it is fixed.</li> </ul>
Satellite LED (Blue)	<ul style="list-style-type: none"> <li>Shows the number of satellites that the receiver has tracked.</li> <li>When the receiver is searching satellites, the blue LED flashes once every 5 seconds.</li> <li>When the receiver has tracked N satellites, the blue LED will flash N times every 5 seconds.</li> </ul>
Power LED (Red)	<ul style="list-style-type: none"> <li>Under normal conditions red power light</li> <li>The power light shows orange when charging</li> <li>The power light shows green when fully charged</li> </ul>
Static LED (Yellow)	<ul style="list-style-type: none"> <li>Flash means static is on.</li> </ul>



Power button (White)	<ul style="list-style-type: none"><li>• Works as a Power button:</li><li>• Press and hold this button for 3 seconds to turn on or turn off the receiver.</li><li>• Works as a Confirm button</li><li>• Hold Fn button and press this button for 5 times continuously to reset the mainboard.</li></ul>
Fn button (White)	<ul style="list-style-type: none"><li>• Move to next line of the menus or options.</li><li>• Move to next character of the value that you want to make change.</li><li>• Cancel the change you make on a function.</li></ul>

### 2.2.2 Lower Housing

The lower housing contains one SIM card slot, one TNC radio antenna connector, one communication and power port and one USB type C communication and power port.



### 2.2.3 Receiver Ports

Port	Name	Description
	USB port	<ul style="list-style-type: none"><li>• This port is a type-C USB connector that supports USB communications.</li><li>• Users can use USB Cable supplied with the system to download the logged data to a computer but can't upload the data.</li><li>• USB port can used to charge the i93 GNSS receiver</li></ul>
	Radio antenna connector	<ul style="list-style-type: none"><li>• Connect a radio antenna to internal radio of the receiver. And this connector is not used if you are using an external radio.</li></ul>

## 2.3 Batteries and Power

### 2.3.1 Batteries

The receiver has an built-in non-removable Lithium-ion battery.

### 2.3.2 The Internal Battery

The rechargeable Lithium-ion battery is supplied partially charged.



**WARNING** – Charge and use the rechargeable Lithium-ion battery only in strict accordance with the instructions. Charging or using the battery in unauthorized equipment can cause an explosion or fire and can result in personal injury and/or equipment damage.

To prevent injury or damage:

- Do not charge or use the battery if it appears to be damaged or leaking.
- Charge the Lithium-ion battery only in a CHC product that is specified to charge it. Be sure to follow all instructions that are provided with the battery charger.
- Discontinue charging a battery that gives off extreme heat or a burning odor.
- Use the battery only in CHC equipment that is specified to use it.
- Use the battery only for its intended use and according to the instructions in the product documentation.

### 2.3.3 Battery Safe



**WARNING** – Do not damage the rechargeable Lithium-ion battery. A damaged battery can cause an explosion or fire and can result in personal injury and/or property damage.

To prevent injury or damage:

- Do not use or charge the battery if it appears to be damaged. Signs of damage include, but are not limited to discoloration, warping, and leaking battery fluid.
- Do not expose the battery to fire, high temperature, or direct sunlight.
- Do not immerse the battery in water.
- Do not use or store the battery inside a vehicle under hot weather condition.
- Do not drop or puncture the battery.
- Do not open the battery or short-circuit its contacts.












**WARNING** – Avoid contact with the rechargeable Lithium-ion battery if it appears to be leaking. Battery fluid is corrosive and contact with it can result in personal injury and/or property damage.

To prevent injury or damage:








- If the battery leaks, avoid with the battery fluid.
- If battery fluid gets into your eyes, immediately rinses your eyes with clean water and seek medical attention. Please do not rub your eyes!
- If battery fluid gets onto your skin or clothing, immediately use clean water to wash off the battery fluid.

## 2.4 Product Basic Supply Accessories

### 2.4.1 Base Kit Basic Supply

Item	Picture
i89 GNSS Receiver	
UHF Whip Antenna	
Power Adapter	
USB Type-C	
H.I. Tape	
Extension pole	
Tribrach with optical plummet	
Auxiliary H.I. Tool	
Transport Hard Case	


## 2.4.2 Rover Kit Basic Supply

Item	Picture
I89 GNSS Receiver	
UHF	
Power Adapter	
USB Type-C	
2M Range Pole w/bag	
Auxiliary H.I. Tool	
Transport Hard Case	

## 2.5 Connecting to an Office Computer

The receiver can be connected to an office computer for serial data transfer or settings via a HCE600 USB Type-C. Before you connect to the office computer, ensure that the receiver is powered on by internal battery or external power.

The following figure shows how to connect to the computer for serial data transfer or settings:



## 2.6 Connecting to a Controller

### 2.6.1 Connecting via Wi-Fi with LandStar 8 Software

Turn on the controller → run LandStar 8 → go to **Config** main menu → tap **Connect**.


In the *Connect* screen, select **CHC** for the *Manufacture* field, **i93** for *Device Type* field, **WIFI** for *Connection Type* field.



Tap the Wireless Lan icon on the right side to select the hot spot → Switch on the WiFi module by the top switch → select the target device in the list.



Tap **Connect** to link to the hot spot. If the first-time connection to this hot spot, user may type in the password.



Tap the **Connect** button to build the connection.




## 2.6.2 Connecting via Bluetooth with LandStar 8 Software

Turn on the controller → run LandStar 8 → go to **Config** main menu → tap **Connect**.


In the *Connect* screen, select **CHC** for the *Manufacture* field, **i93** for *Device Type* field, **Bluetooth** for *Connection Type* field.



Tap the **Bluetooth Manager** and turn on the **Bluetooth** function to search Bluetooth device around → select the target device in the list → Tap back button → select the target device in the Bluetooth manager list.



Tap the **Connect** button to build the connection.




## 2.7 Downloading Logged Data

Data logging involves the collection of GNSS measurement data over a period at a static point or points, and subsequent post-processing of the information to accurately compute baseline information. Data logging using receivers requires access to suitable GNSS post-processing software such as the CHC Geomatics Office (CGO) Software.

### 2.7.1 FTP Download

The procedures of downloading logged data through FTP are as follows:


- (1) Switch on the receiver, search its Wi-Fi in the computer and connect.
- (2) After the successful connection, open the file manager in the computer and input “ftp:\\192.168.1.1” in the address box.



- (3) Input user name and password, the default user name and password are “ftp”.




- (4) Double click the folder “repo\_receiver SN” (take 3411955 as example), you will see 9 folders. The “push\_log” folder is used to save the log files, and the other 8 folders represent different logging sessions and are used for store static data.



(5) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i93 system automatically and named by the date which is decided by GPS time when you start to log data.



(6) Select the destination folder and double click it, two folders named as different data format (hcn and rinex) will be displayed.



(7) Select the data format that you configured to save the static data, you will find the static raw data.



**Notes:** For hcn files, the name of the file is represented as XXXXXXDDDNN, where XXXXXX is the SN of the receiver, DDD is day of year, and NN is the recording session.



WARNING – The static data will be saved in the first logging session, the “record\_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.


## 2.7.2 Web Server Download

The procedures of downloading logged data through web server refer to [5.4.4 Data Download Submenu](#).

### 2.7.3 USB Download

The procedures of downloading logged data in the receiver are as follows:

(1) Switch on the receiver and connect it with a computer by HCE600 Type-C. After the successful connection, a removable disk named as the Serial Number (SN) of the receiver will appear on the computer.



(2) Double click the removable disk and you will see the folder named as “repo”.




(3) Double click this folder, you will see 9 folders. The “push\_log” folder is used to save the log files, and the other 8 folders represent different logging session and are used for store static data.



(4) Double click the folder that you have configured to store the static data, you will see the folder(s) created by the i93 system automatically and named by the date which is decided by GPS time when you start to log data.



(5) Select the destination folder and double click it, and then two folders named as different data format (hcn and rinex) will be displayed.



(6) Select the data format that you have configured to save the static data, you will find the static raw data.



Tip – For hcn files, the name of the file is represented as XXXXXXDDDNN, where XXXXXX is the SN of the receiver, DDD is day of year, and NN is the recording session.




**WARNING** – The static data will be saved in the first logging session, the “record\_1” folder, by default. Old files will be deleted if the storage space is full. If you configure not to auto delete old files when the memory is low, the receiver will stop data logging.

## 3 Equipment Setup and Operation

### 3.1 Post-processing Base Station Setup

For good performance, the following base station setup guidelines are recommended:

**Components:**



No.	Name
a	I89 GNSS receiver
b	Extension pole (30 cm)
c	Tribrach adaptor
d	Tribrach w/ Opti
e	Aluminum tripod

**Steps:**

- (1) Put tripod in the target position, center and level it roughly.
- (2) Place and lock the tribrach in the tripod.

- (3) Screw the receiver onto the tribrach.
- (4) Center and level the receiver more precisely.
- (5) Connect the receiver to external battery by using external power cable if necessary.
- (6) Connect the receiver to external storage disk by using USB cable if necessary.
- (7) Turn on the receiver by pressing the power button for 3 s.
- (8) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- (9) Press the function button to select Data to start recording static raw.

**If work with a data controller:**

- (10) Switch on the data controller and connect it to the receiver.
- (11) Use software to configure the receiver as static mode.

## 3.2 Real-Time Base Station Setup

### 3.2.1 Internal Cellular or UHF

For good rover operation, the following base station setup guidelines are recommended:

#### Components:



No.	Name
a	i93 GNSS receiver
b	UHF whip antenna
c	Extension pole (30 cm)
d	Tribrach adaptor
e	Tribrach w/ Opti
f	Aluminum tripod
g	Micro SIM card (12 mm x 15 mm)

**Steps:**

- (1) Put tripod in the target position, center and level it roughly.
- (2) Place and lock the tribrach in the tripod.

**If work as a cellular base station**, the SIM card need to be inserted

- (3) Screw the receiver onto the tribrach.
- (4) Center and level the receiver more precisely.


**If work as a UHF base station**, the UHF whip antenna need to be connected to the receiver.

- (5) Connect the receiver to external battery by using external power cable if necessary.
- (6) Connect the receiver to external storage disk by using USB cable if necessary.
- (7) Turn on the receiver by pressing the power button for 3 s.
- (8) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- (9) Switch on the data controller and connect it to the receiver.
- (10) Use software to configure the receiver as cellular base or UHF base mode.

### 3.2.2 External UHF

For good performance, the following base station setup guidelines are recommended:

---

**Components:**

No.	Name
a	i93 GNSS receiver
b	Extension pole (30 cm)
c	Tribrach adaptor
d	Tribrach w/ Opti
e	GPS to datalink cable (power cable)
f	Aluminum tripod
h	Whip antenna
i	3 m cable for datalink antenna 3m
j	Pole mounting
k	External 410-470 datalink

---

**Steps:**

- (11) Put tripod in the target position, center and level it roughly.
- (12) Place and lock the tribrach in the tripod.
- (13) Screw the receiver onto the tribrach.
- (14) Center and level the receiver more precisely.
- (15) Connect the receiver to external datalink by using GPS to datalink cable.
- (16) Hang the external datalink on the tripod leg.
- (17) Connect the receiver to external battery by using external power cable if necessary.
- (18) Connect the receiver to external storage disk by using USB cable if necessary.
- (19) Turn on the receiver by pressing the power button for 3 s.
- (10) Measure the antenna height by using H.I. tape and auxiliary H.I. tool.
- (11) Turn on the external datalink and configure it as need.

**If work with a data controller:**

- (12) Switch on the data controller and connect it to the receiver.
- (13) Use software to configure the receiver as cellular base or UHF base mode.

### 3.3 Real-Time Rover Station Setup

For good performance, the following rover station setup guidelines are recommended:

**Components:**



No.	Name
a	I89 GNSS receiver
b	whip antenna
c	2M range pole w/bag
d	Micro SIM card (12 mm x 15 mm)

**Steps:**

(1) Keep the receiver fully charged.

**If work as a cellular rover station**, the SIM card need to be inserted before the batteries.

(2) Screw the receiver onto the pole.

**If work as a UHF rover station**, the UHF whip antenna need to be connected to the receiver.

(3) Turn on the receiver by pressing the power button for 3 s.

(4) Switch on the data controller and connect it to the receiver.

(5) Use software to configure the receiver as cellular rover or UHF rover mode.

(6) Center and level the receiver more precisely.

(7) Use software to start survey.

### 3.4 Working with the Tilt Compensation


The auto-IMU need to be calibrated at the first time when users get a new i93 GNSS receiver. After initializing the sensor successfully, the i93 GNSS receiver will record the calibration parameters, and the user do not need to calibrate it manually any more. After enable the tilt survey, the i93 IMU can be ready after a few steps walk or a bit movement automatically.


#### 3.4.1 Operation Steps for first IMU initialization

(1) Open Landstar8-> Tap PT Survey-> Tap  to activate tilt measurement.




(2) Hold the pole vertical for a while and shake according to the procedures in the interface to do initialization.




(3) This icon  will appear when the initialization is successful.



(4) Enter the Name and Antenna, then tap , point will be collected and store to Points automatically.

(5) When this icon  appears, the text will show “Tilt is not available, please measure in alignment” at the bottom of interface.



(6) Tap  to close tilt compensation.

### 3.4.2 Notes of using tilt measurement

1. At the beginning of initialization, the pole height of the instrument should be the same as that antenna height in the software.
2. In the process of tilt measurement, if the controller shows that “Tilt is not available, please measure in alignment” (red), please shake RTK slightly from left to right or back to front until the reminder disappears.
3. The controller will prompt “Tilt is not available, please measure in alignment” when the receiver is stationary over 30 seconds or the pole hit the ground toughly.
4. The pole cannot be shaken when point is collected.
5. Initialization is required:

- when the RTK is turned on every time;
- when IMU module is turned on every time;
- when receiver drops at working;
- when the pole is tilted more than 65 degree;
- when the receiver is stationary more than 10 minutes;
- when the RTK rotates too fast on the matching pole (2 rounds per second);
- when the pole hit the ground toughly.

## 3.5 Visual Survey

### 3.5.1 Survey point mode

The survey point mode means that by taking video survey of the target to be surveyed and solving the survey result in real time, and selecting the point to be surveyed on the photo than you can get the coordinate value of the point.

(1) Finish the IMU initialization, enter the visual survey, do as it prompts;



(2) Choose the For measurement mode;




(3) Create a new task, and aim at which point you want to survey, click the button to record the video;




**Note:** Keeping constant speed when shooting, the length of the video must not be less than 5 seconds, the

route of walking can refer to the following picture, walking in a straight line or around the shooting.



(4) Click the icon of End Recording to finish recording and confirm the solved data, and the software will automatically perform data solving;



(5) Select the photo which the point to be surveyed is located, capture the corresponding point location, click [Select], and the latitude, longitude and plane coordinates of the point will be displayed below.



**Note:** The 2D quality represents the resolution accuracy of the surveyed point. Capturing the same point position on multiple photos will improve the accuracy of the surveyed point, and the 2D value of the point decreases gradually.


(6) Click [Save] and enter the point name to save the surveyed points in the point management. After saving successfully, you can click on the point library and go to the point management to view the coordinates you just saved. If additional points are needed, you can continue to select points for solving and saving data.

### 3.5.2 Modeling mode


Modeling mode means that video surveys can be taken from multiple angles, distances and heights of the target to be surveyed, and then the observed image data can be exported and later imported into the modeling software for modeling.

(1) The same operation with the point mode, finish the IMU initialization;

(2) Choose the Modeling mode;



(3) Create a new task, and aim at which building you want to model, click the button to record the video;



**Note:** When filming, keep a constant speed, the length of the video should not be less than 5 seconds, the

route of travel can refer to the example, it is recommended that from different heights, different angles, different distances to survey the target for multi-sided shooting. If the target to be surveyed is single-sided, it is recommended to use straight shooting; if the target to be surveyed is a panorama of building, it is recommended to shoot around, and the camera is recommended to have a certain angle ( $30^{\circ}$ - $45^{\circ}$ ) with the target to be surveyed when shooting. The schematic diagram is as follows.

(4) Click the end icon to finish recording and make sure that the data has been saved to exit LandStar.

## 4 Configuring Through a Web Browser

Supported browsers:

- Google Chrome
- Microsoft Internet Explorer® version 10, or higher To

connect to the receiver through a web browser:

1. Turn on the Wi-Fi of the receiver.
2. Search the wireless network named as GNSS-XXXXXXX (the SN of your receiver) on your computer, and then establish the connection.
3. After the successful connection between your computer and the receiver, enter the IP address (192.168.1.1) of the receiver into the address bar of the web browser on your computer:



4. The web browser prompts you to enter a login account and password:



The default login account for the receiver is:

- Login Account: admin
- Password: password

**Note** – Tick **remember me** option, and then the browser will remember the Login Account and Password you entered.

5. Once you log in, the web page appears as follows:




This web page shows the configuration menus on the left of the browser window, and the setting on the right. Each configuration menu contains the related submenus to configure the receiver and monitor receiver performance.

This chapter describes each configuration menu.

To view the web page in another language, select the corresponding language name from the dropdown list on the upper right corner of the web page.

Currently, three languages are available:



## 4.1 Status Menu

This menu provides a quick link to review the receiver's position information, satellites tracked, runtime, current data log status, current outputs, available memory, and more.

### 4.1.1 Position Submenu

This page shows the relevant position information about the receiver's position solution which including the position, DOP values, satellites used and tracked, and the receiver clock information.



### 4.1.2 Activity Submenu

Lists several important items to help you understand how the receiver is being used and its current operating condition. Items include the identities of currently tracked satellites, internal and external storage usage rate, how long the receiver has been operational, state of the internal battery, power source state, files being logged, and data streams being output. With this information, it is easy to tell exactly what functions the receiver is performing



Recording Number	File Name	Activated	Log Status
1	record1	Yes	Recording
2	record2	No	Not Recording
3	record3	No	Not Recording
4	record4	No	Not Recording
5	record5	No	Not Recording
6	record6	No	Not Recording
7	record7	No	Not Recording
8	record8	No	Not Recording

Type	Description	Range
1	GPS Card	100-1000000
2	GPS Card	100-1000000
3	GPS Card	100-1000000
4	GPS Card	100-1000000
5	GPS Card	100-1000000
6	GPS Card	100-1000000
7	GPS Card	100-1000000
8	GPS Card	100-1000000
9	GPS Card	100-1000000
10	GPS Card	100-1000000
11	GPS Card	100-1000000
12	GPS Card	100-1000000
13	GPS Card	100-1000000
14	GPS Card	100-1000000
15	GPS Card	100-1000000
16	GPS Card	100-1000000
17	GPS Card	100-1000000
18	GPS Card	100-1000000
19	GPS Card	100-1000000
20	GPS Card	100-1000000


### 4.1.3 Google Map Submenu

Tap this submenu to show the location of the receiver on Google map.



## 4.2 Satellites Menu

Use the Satellites menu to view satellite tracking details and enable/disable GPS, GLONASS, BDS and Galileo constellations. These menus include tabular and graphical displays to provide all required information on satellite tracking status.




### 4.2.1 Tracking Table Submenu

Provides the status of satellites tracked in general, such as the satellite ID, satellite type, attitude angle, azimuth angle, L1 SNR, L2 SNR, L5 SNR and enable/disable status of each one.

Tracking Table									
<input checked="" type="radio"/> All <input type="radio"/> GPS <input type="radio"/> GLONASS <input type="radio"/> BDS <input type="radio"/> GALILEO <input type="radio"/> SBAS <input type="radio"/> QZSS									
SV	Type	Elevation Angle	Azimuth Angle	L1 SNR	L2 SNR	L5 SNR	B1C SNR	B2A SNR	Enabled
3	GPS	21	262	40.000	40.899	30.880	0.000	0.000	Yes
4	GPS	15	316	40.000	36.809	27.800	0.000	0.000	Yes
10	GPS	46	242	44.000	39.450	0.000	0.000	0.000	Yes
26	GPS	74	316	48.720	43.430	38.180	0.000	0.000	Yes
27	GPS	12	188	34.660	35.899	26.250	0.000	0.000	Yes
28	GPS	23	50	41.370	36.580	0.000	0.000	0.000	Yes
31	GPS	55	44	45.450	41.870	0.000	0.000	0.000	Yes
32	GPS	35	140	42.040	38.490	30.140	0.000	0.000	Yes
1	GLONASS	52	211	41.780	46.170	0.000	0.000	0.000	Yes
2	GLONASS	40	313	47.100	46.320	0.000	0.000	0.000	Yes
8	GLONASS	14	174	36.530	40.730	0.000	0.000	0.000	Yes
12	GLONASS	41	300	45.760	49.280	0.000	0.000	0.000	Yes
21	GLONASS	22	94	37.000	44.190	0.000	0.000	0.000	Yes
1	BDS	45	140	39.630	42.710	44.870	0.000	0.000	No
2	BDS	35	235	35.420	43.410	42.250	0.000	0.000	No
3	BDS	50	190	40.270	44.410	43.470	0.000	0.000	Yes


### 4.2.2 Tracking Info. Table Submenu

The following figure is an example of satellite track diagram page. Users can determine the satellite types and the corresponding SNR of L-band carriers to be displayed in any combination.




### 4.2.3 Tracking Skyplot Submenu

The following figure is an example of Skyplot page.




## 4.2.4 Satellite Activation Submenu

Use this menu to enable or disable satellites.



## 4.3 Receiver Configuration Menu

Use this menu to configure settings such as the antenna type and height, elevation mask and PDOP setting, the reference station coordinates, receiver resetting and web interface language:



### 4.3.1 Description

This submenu shows the receiver information and reference station information, including antenna related information, elevation mask angle, reference station work mode and position, etc.




### 4.3.2 Antenna Configuration Submenu

Use this screen to configure all the items related to the GNSS antenna. You must enter the correct values for all antenna-related fields, because the choices you make affect the accuracy for logged data and broadcast correction data significantly:



### 4.3.3 Reference Station Settings Submenu

Use this screen to configure settings such as the station coordinates and the broadcast station identifiers. You must enter accurate information in these fields, as this data affects the accuracy of logged data files and broadcast correction data significantly:



For Reference Station Mode, there are three modes available:

- Auto Rover:** The receiver will serve as a rover after this mode is enabled, and then receive correction data through the working mode set last time.
- Auto Base:** The receiver will serve as a base after this mode is enabled, and then broadcast correction data based on coordinate inputted by user or obtained through autonomous positioning automatically.

Reference Station Settings

Reference Station Mode: Auto Base  
Base Station Name: 0000001  
Base Station ID: 0000001  
Reference Latitude: 0 0 0.0000000 N S  
Reference Longitude: 0 0 0.0000000 E W  
Reference Height: 0.000  
Save

Sample for Average:  
Monitoring Constant: Single Solution Coordinates Fixed Solution Coordinates  
Sampling Interval: 300 0%  
Save Cancel

Coordinates transfer threshold value(meter): 0  
Save

Base list

ID	Height	Latitude	Longitude
1	15.8179	118.23844155	118.23844155
2	15.8888	118.18817579	118.40653506
3	14.3043	118.0718849	118.9848881
4	14.7267	118.8432288	118.7912204
5	14.5000	118.3948236	118.91399424
6	17.2323	118.35769549	118.88117362
7	14.8052	118.34889024	118.44724738
8	15.9986	118.82883736	118.82876462
9	17.5118	118.82504863	118.67087178
10	17.2042	118.29888326	118.67673858

- c) **Manual Base:** The receiver will serve neither as a base nor a rover after this mode is enabled. Users need to configure the receiver manually

For **Reference Latitude** and **Reference Longitude**:

There are mainly three methods to enter the reference coordinates and shown as follows:

- Acquire Current Position:** Click this button to acquire current position obtained through autonomous positioning automatically.
- Manual Input:** Manually input the coordinate of a control point.
- From CORS:** After the receiver logging in CORS, the software can record the coordinate of current position based on fix solution.

For **Sample for Average**:

Users can determine the positioning limit and sampling amount. The positioning limit falls into two types:


- Single Solution Coordinates:** Collect the coordinates of receiver obtained through autonomous positioning.
- Fixed Solution Coordinates:** Only collect coordinates of receiver with a fixed solution.

After the configuration of positioning limit and sampling amount, click to carry out sampling and averaging → the progress bar will show the progress → the result will be served as the coordinate of current position.

If users need to save the changes, please tap button.


### 4.3.5 Receiver Reset Submenu

Use this screen to completely or partially reset the receiver:



### 4.3.6 Languages Submenu

Use this screen to select the web interface language:



### 4.3.7 User Management Submenu

User Management ×

**User Management**  
 Add  Save  Delete  Modify Anti-theft password

ID	User Name	Password
1	<input type="text" value="admin"/>	<input type="password" value="*****"/>
2	<input type="text" value="admin1"/>	<input type="password" value="*****"/>
3	<input type="text" value="admin2"/>	<input type="password" value="*****"/>


### 4.3.8 HCPPP Settings

HCPPP Settings ×

HCPPP Range:   Save

## 4.4 Data Recording Menu

Use the Data Logging menu to set up the receiver to log static GNSS data and to view the logging settings. You can configure settings such as observable rate, recording rate, continuous logging limit, and whether to auto delete old files when memory is low. This menu also provides the controls for the FTP push feature:



### 4.4.1 Log Settings Submenu

Here shows the data logging status, including internal and external storage usage and data logging status of each session. Also, users can configure the data logging settings for each session, including recording name, store location, storage limit, store formats, start time, etc



To edit the settings of each session, click the **Modify** button to the right of the required session, and then the *Recording Edit* screen appears:

The **Recording Edit** window displays the following settings:

- Auto Record:** ☐ Yes ☒ No
- Sample Interval:** 5s
- Elevation Mask:** 10 (\*)
- Duration Time:** 1440 (Minute)
- Site Name:** 3411955
- Antenna Height:** 0.0000
- Measure Way:** Antenna Phase
- Storage Format:** HCN
- RINEX Version:** OFF
- Advanced:** (button)

At the bottom are **Save** and **Back** buttons.

Click advanced to see more settings.

The **Recording Edit** window displays the following settings:

- Auto Record:** ☐ Yes ☒ No
- Sample Interval:** 5s
- Elevation Mask:** 10 (\*)
- Duration Time:** 1440 (Minute)
- Site Name:** 3411955
- Antenna Height:** 0.0000
- Measure Way:** Antenna Phase
- Storage Format:** HCN
- RINEX Version:** OFF
- Advanced:** (button)
- Start Date:** ☐ Yes ☒ No
- Apply Time:** ☐ Yes ☒ No
- Integral Point Store:** ☐ Yes ☒ No
- Circulating Memory:** ☒ Yes ☐ No  
the data overwritten first file after storage space is full
- Repeat Observations:** ☒ Yes ☐ No  
Turn on to record a single observation. Turn off to record repeated observations.
- Store Location:** Internal Storage
- Assigned Storage:** 6000 (MB)
- Observer:** CHC
- Observe Agency:** CHC
- FTP Push:**
  - ☒ Close
  - ☐ 1 ftp server 1
  - ☐ 2 ftp server 2
  - ☐ 3 ftp server 3


At the bottom are **Save** and **Back** buttons.

In this screen, you can configure all the data logging parameters, and determine whether the recording files will be affected by the FTP Push. The parameters are mainly as follows:

- **Auto Record:** on or off.

- **Sample Interval:** Select the observable rate from the dropdown list.
- **Elevation Mask:** Enter the elevation mask.
- **Duration Time:** Set the duration of data logging.
- **Site Name:** Enter the name of the site.
- **Antenna Height:** the measured height value.
- **Measure way:** Antenna Phase Center, Vertical Height, Slant Height
- **Storage Format:** Select the format of the data store.
- **RINEX Version:** OFF, 3.02, 2.11
- **Start Date:** Select **Yes** or **No** option to determine whether to auto record start date.
- **Apply Time:** Select **Yes** or **No** option to determine whether to auto record apply time.
- **Integral Point Store:** Select **Yes** or **No** option to determine whether to allow receiver to save data every hour.
- **Circulating Memory:** Select **Yes** or **No** option to determine whether to auto delete old files if the storage space is full.
- **Repeat Observations:** Select **Yes** or **No** option to determine whether to turn on to record a single observation.
- **Store Location:** Internal Storage, External Storage.
- **Assigned Storage:** The assigned memory size of current thread(for example, Record 1) is 10000MB
- **Observer:** Enter the name of observer.
- **Observer Agency:** Enter the name of observer agency.
- **FTP Push:** Decide whether to push the stored files to the FTP server of your choice.

Tap  button to save the settings and back to the *Log Settings* screen.

Also, users can click  to abandon the changed settings and back to *Log Settings* screen.

**Note** – To modify data logging parameters, make sure the data logging session is switched off.

To switch on or off **ANY** data logging session, tap the **ON** or **OFF** button on the right of the required session.

To delete the recorded files of **ANY** data logging session, tap the **Clear** button on the right of the required session.



To delete the recorded files of **ALL** data logging sessions, tap the **Clear ALL Accounts** button.

#### 4.4.2 FTP Push Settings Submenu

Use this screen to configure the receiver to push stored files to the FTP server of your choice. Only files that are configured to use FTP push are transmitted.

FTP Push Settings				
Record Info				
Server ID	Server IP	Remote Directory	Server Description	Modify
1	192.168.3.72	repo/first	ftp server 1	<button>Modify</button>
2	192.168.3.72	repo/second	ftp server 2	<button>Modify</button>
3	192.168.3.72	repo/third	ftp server 3	<button>Modify</button>


Tap **Modify** button on the right of the required FTP server and the *FTP Push Settings* screen appears:

 **FTP Push Settings** 

Server IP:

Port:


Remote Directory:


Local directory:  

Server Description:

User Name:

Password:

 **Save**

 **Back**

#### 4.4.3 FTP Push Log Submenu

Shows the related information about the recorded files that will be pushed. And users can tap **Clear Ftp Send Log** button in the upper right corner to clear the log of FTP Push operations.



#### 4.4.4 Data Download Submenu

In this submenu, users can download the data files that recorded in the internal storage through the internal FTP site. Please note that Chrome, EDGE and Firefox version higher than year 2020 version remove the FTP support through the browser.

1. Click this submenu, and then the log on dialogue box will prompt you to enter a user name and password:

Sign in

ftp://192.168.1.1

Your connection to this site is not private

Username

Password

The default logon account for the internal FTP site is:

- User name: ftp
  - Password: ftp
2. Click the directory named as “repo” to view and download the files currently stored on the receiver:



3. To find the file need to be downloaded, click the name of data logging session → the


date of file that be recorded → the format of the file → the name of the target file.



 [parent directory]		
Name	Size	Date Modified
 <a href="#">push_log/</a>		7/16/19, 1:17:00 PM
 <a href="#">record_1/</a>		8/15/19, 10:22:00 AM

4. To download a file, left click the name of the target file → download the file according to the prompts.

## 4.5 IO Settings Menu



Use the IO Settings menu to set up all receiver outputs and inputs. The receiver can output CMR, RTCM, Raw data, Ephemeris data, GPGLGA, GPGLSV, on TCP/IP, UDP, serial port, or Bluetooth ports.


### 4.5.1 IO Settings Submenu

The following figure shows an example of the screen that appears when you select this submenu.

I/O Settings					
	Type	Description	Output	Connection Status	Modify
1	RTK Client	211 1A4 118 5 2103	---	Unconnected	Connect Disconnect De
2	TCP/UDP_ClientNTRIP Serv	192 168 3 18 0000	---	Unconnected	Connect Disconnect De
3	TCP/UDP_ClientNTRIP Serv	192 168 3 18 0001	---	Unconnected	Connect Disconnect De
4	TCP/UDP_ClientNTRIP Serv	192 168 3 18 0002	---	Unconnected	Connect Disconnect De
5	TCP/UDP_ClientNTRIP Serv	192 168 3 18 0003	---	Unconnected	Connect Disconnect De
6	TCP/UDP_ClientNTRIP Serv	192 168 3 18 0004	---	Unconnected	Connect Disconnect De
7	TCP/UDP_ClientNTRIP Serv	192 168 3 18 0005	---	Unconnected	Connect Disconnect De
8	TCP ServerNTRIP Caster1	8001	---	Closed	Connect Disconnect De
9	TCP ServerNTRIP Caster2	8002	---	Closed	Connect Disconnect De
10	TCP ServerNTRIP Caster3	8003	---	Closed	Connect Disconnect De
11	TCP ServerNTRIP Caster4	8004	---	Closed	Connect Disconnect De
12	Serial Port	115200	---	---	Settings
13	Bluetooth	GNSS-3411V05	GPGLGA file	---	Settings
14	Radio	402 3500MHz	---	---	Settings

In this submenu, users can configure 6 types of input and output settings.

#### 1. RTK Client

After configuring the settings of RTK client, users can log on CORS or APIS. Tap the **Connect** button to the right → the *IO Settings* screen will appear → choose one of the connection protocols among the NTRIP, APIS\_BASE and APIS\_ROVER → configure the related parameters → click  to log on CORS or APIS.

- Connection Protocol: NTRIP




The screenshot shows the 'RTK Client' window with the following settings:

- Connection Protocol: NTRIP
- Server IP: 211.144.110.5
- Port: 2102
- Mount Point: asd (with a green checkmark and 'Get' button)
- User Name: zc
- Password: zc

At the bottom, there are 'Confirm' and 'Back' buttons.

- Connection Protocol: APIS\_BASE



The screenshot shows the 'RTK Client' window with the following settings:

- Connection Protocol: APIS\_BASE
- Server IP: 111.111.111.1
- Port: 9901
- Differential Data: OFF

At the bottom, there are 'Confirm' and 'Back' buttons.

- Connection Protocol: APIS\_ROVER



The screenshot shows the 'RTK Client' window with the following settings:


- Connection Protocol: APIS\_ROVER
- Server IP: 210.14.66.58
- Port: 9902
- Base ID: 1010023

At the bottom, there are 'Confirm' and 'Back' buttons.

- Connection Protocol: TCP



## 2. TCP/UDP\_Client/NTRIP Server

Tap the **Connect** button on the right of required TCP/UDP Client → the *IO Settings* screen will appear → select the connection protocol from TCP, UDP, NTRIP1.0 and NTRIP2.0 → enter the IP and Port of the target server → configure messages that you want to output to the target server → click  **Confirm** to save and complete the connection.

- Connection Protocol: TCP



- Connection Protocol: UDP





### 3. TCP Server/NTRIP Caster

Tap the **Connect** button to the right of required TCP Server/NTRIP Caster → the **IO Settings** screen will appear → select one of the connection protocols between NTRIP and TCP → configure the other related parameters → click **Confirm** to save the settings and open the server.

- Connection Protocol: TCP



➤ Connection Protocol: NTRIP

Auto connect: ☐ Connection Protocol: NTRIP

User Name:  Password:

Port: 8051 Mount Point:

Differential Data: OFF

HCPRP Data: OFF

GPQGA: OFF

GPQMC: OFF

GPQST: OFF

GPQSA: OFF

Retransmit: RTK OFF

Raw Data: OFF

HRC Data: OFF

GPQSV: OFF

GPQDA: OFF

GPVTS: OFF

#### 4. Serial Port

Tap the **Settings** button on the right of Serial Port → the *Serial Port Setup* screen will appear  
 → select Baud Rate used to transmit data → configure the messages that you want to output through the serial port → click  to save the settings and start to transmit.

Baud Rate: 115200

Differential Data: OFF

HCPRP Data: OFF

GPQGA: OFF

GPQMC: OFF

GPQST: OFF

GPQSA: OFF

Retransmit: RTK OFF

Raw Data: OFF


HRC Data: OFF


GPQSV: OFF

GPQDA: OFF


GPVTS: OFF


## 5. Bluetooth

Tap the **Settings** button to the right of Bluetooth → the *Bluetooth Set* screen will appear → configure the messages that you want to transmit through Bluetooth → click  to save the settings and start to transmit.




## 6. Radio

Tap the **Settings** button to the right of Radio → the *Radio Settings* screen will appear → select the format of differential data that you want to transmit through radio from the dropdown list → click  to save the settings and start to transmit.



## 4.6 Network Setting Menu

Use this menu to view network information, configure the receiver's mobile network, set email alert for specific situation, configure HTTP or HTTPS port, and the username and password of internal FTP site:



### 4.6.1 Description Submenu

Use this submenu to check the information of network setting.



## 4.6.2 Mobile Network Setting Submenu

Use this submenu to configure GPRS model, network module and modify dialing status.

The screenshot displays the 'Mobile Network Setting' window. At the top, there's a title bar and a 'Network Settings' tab. The main content area is divided into several sections. The first section shows 'GPRS Model Status' set to 'ON', with toggle buttons for 'CM' and 'GPRS'. Below this is an 'Auto Start' section with radio buttons for 'Yes' and 'No'. The second section is 'Network Mode', featuring radio buttons for '2G Only', '3G Only', '2G/3G Auto', '4G Only', and '2G/3G/4G Auto'. The third section shows 'SIM Type' set to 'E-SIM' with a 'Switch' button. The fourth section shows 'Dialing Status' set to 'Offline', with 'Dial' and 'Cancel' buttons, and 'Auto Connect' with 'Yes' and 'No' radio buttons. The final section contains input fields for 'APN' (set to '3gnet'), 'Dialing String' (set to '\*\*\*'), 'User Name' (set to 'user'), and 'Password' (masked with asterisks). A 'Save' button is located at the bottom of the window.

## 4.6.3 Email Alarm Submenu

Use this submenu to choose which situation of receiver will be alerted and input the email address.

Email Alarm x

TO

Email Address 1: test@huacenav.com

Email Address 2: test1@huacenav.com

Email Address 3: test2@huacenav.com

Save

From

Account:

Password:

Server Address:

Save

Email Alert

☐ Receiver is powered on

☐ External power is off

☐ Battery level is low

☐ Ftp push is failed

☐ Reciever(license) will be expired in 7 days.

Save

#### 4.6.4 HTTP Submenu

Use this submenu to configure HTTP port.

HTTP x

HTTP Port: 80

Save

### 4.6.6 HTTPS Submenu

Use this submenu to configure HTTPS port.



The screenshot shows the 'HTTPS' configuration submenu. At the top, there is a tab labeled 'HTTPS'. Below it, a teal button labeled 'HTTPS' is visible. The main configuration area contains the following elements:

- 'Enable HTTPS:' with two radio buttons: 'Yes' (selected) and 'No'.
- 'HTTPS Port:' with a text input field containing the value '443'.
- A teal 'Save' button at the bottom right.

### 4.6.7 FTP Service Submenu

Use this submenu to configure the user name and password of internal FTP site.




The screenshot shows the 'FTP Service' configuration submenu. At the top, there is a tab labeled 'FTP Service'. Below it, a teal button labeled 'FTP Service' is visible. The main configuration area contains the following elements:

- 'User Name:' with a text input field containing the value 'ftp'.
- 'Password:' with a text input field containing three asterisks '\*\*\*'.
- A teal 'Save' button at the bottom right.

## 4.7 Module Setting Menu

Use this menu to check module information, configure WiFi, bluetooth, radio related settings, and turn on/off static voice of buzzer:



### 4.7.1 Description Submenu

Use this submenu to check the information of WiFi module, bluetooth module and radio module.



### 4.7.2 WiFi Submenu

Use this submenu to turn on/off WiFi function and modify password.



### 4.7.3 Bluetooth Settings Submenu

Use this submenu to turn on/off bluetooth function and modify PIN number.



The screenshot displays the 'Bluetooth Settings' submenu. At the top, there is a tab labeled 'Bluetooth Settings'. Below the tab, the settings are as follows:

- Local Name: GNSS-3411955
- MAC Address: 81:D2:10:04:FF:D2
- PIN: 1234 (with a text input field)
- A green 'Save' button with a floppy disk icon is located at the bottom.

#### 4.7.4 Radio Settings Submenu


Use this submenu to turn on/off radio function and configure radio parameters.

The screenshot shows the 'Radio Settings' submenu. At the top, there's a tab labeled 'Radio Settings'. Below it, a green button labeled 'Radio Settings' is visible. The main area contains the following settings:

- Radio Status:** OFF. There are two buttons: a green 'ON' button and a red 'OFF' button.
- Auto Start:** Radio button options for 'Yes' and 'No'. The 'No' option is selected.
- Radio Protocol:** A dropdown menu showing 'CHC'.
- Channel Bandwidth:** A dropdown menu showing '25' with '(kHz)' to its right.
- OTA Baud Rate:** A dropdown menu showing '9600'.
- Radio Power:** A dropdown menu showing '1W'.
- Radio Frequency:** A dropdown menu showing '9' with a range of '462 5500 (410MHz--470MHz)' to its right.
- Save:** A green button at the bottom.


## 4.8 Firmware Menu

Use this menu to check the current firmware information, download the system log, update the receiver firmware, download or update the configuration file and register the receiver, and more:



### 4.8.1 Firmware Info Submenu

Use this submenu to check the current firmware information. The following figure shows an example of the firmware information.



### 4.8.2 Hardware Version Submenu

Use this submenu to check the hardware information, including main board version and core board version:




Hardware Version ×


Main Board: 1.0.1  
Core Board: 1.0.1  
PN: A19318430901060002  
Board Firmware Version Number: 21893


### 4.8.3 Config File Submenu


Use this submenu to update Configuration File.



Config File ×


Download Configuration File :  **Download**

Update Configuration File:  **Browse**


 **Confirm**


### 4.8.4 System Log Download Submenu

Use this submenu to download the system log of the receiver.




System Log ×

System Log Type:  

 **Download**


### 4.8.5 User Log Submenu

Use this submenu to download the user log. Tap **Download** to download current user log; Tick items that you want to see on the user log and tap confirm button to confirm selected user log.



#### 4.8.6 Firmware Update Submenu

Use this submenu to load new firmware to the receiver across the network. Tap the **Browse** button to locate the upgrade file → tap **Confirm** button to confirm the selected upgrading file and start upgrading.




#### Notes

- It may take about 3 or 4 minutes to complete the firmware upgrading. Do not touch the power button or unplug the power until the upgrading process finishes, or damage will be caused to the receiver.
- The receiver will restart after the firmware upgrading is done, so users need to reconnect the receiver with your computer via Wi-Fi, and then log-in the receiver through a web browser to continue the configuration.


### 4.8.7 GNSS Board Upgrade Submenu

Use this submenu to upgrade GNSS Board. Use this submenu to load new board to the receiver across the network. Tap the **Browse** button to locate the upgrade file → tap **Confirm** button to confirm the selected upgrading file and start upgrading.



### 4.8.8 Radio Upgrade Submenu

Use this submenu to browse upgrade file and upgrade radio. Use this submenu to load new radio to the receiver across the network. Tap the **Browse** button to locate the upgrade file → tap **Confirm** button to confirm the selected upgrading file and start upgrading.



### 4.8.9 Upgrade Online Submenu

Use this submenu to input Server Address and upgrade online.



#### 4.8.10 GNSS Registration Submenu

Use this submenu to register the receiver. Paste or enter the registration code to the *Registration Code* field → tap **Registration** button to complete the registration.


The screenshot displays the 'GNSS Registration' submenu. It features three input fields with labels to their left: 'Serial Number' with the value '3411955', 'Registration Limit' with the value '2022-4-24', and 'Registration Code' with the value 'XpHTmdQ4mSo'. Below these fields is a green button with a white 'P' icon and the text 'Registration'.

Serial Number:	3411955
Registration Limit:	2022-4-24
Registration Code:	XpHTmdQ4mSo

**P Registration**

## 4.9 Cloud Service Setting Menu

### 4.9.1 Cloud Service Setting Submenu



Use this submenu to turn on or turn off Cloud Service, Auto Start, Remote Control and configure other settings.





## CHC Navigation

Shanghai Huace Navigation Technology Ltd.  
CHCNAV | Smart Navigation & Geo-Spatial Technology Park,  
577 Songying Road, 201703, Shanghai, China  
Tel: +86 21 542 60 273 | Fax: +86 21 649 50 963  
Email: [sales@chcnav.com](mailto:sales@chcnav.com) | [support@chcnav.com](mailto:support@chcnav.com)  
Skype: [chcnav\\_support](https://www.skype.com/name/chcnav_support)  
Website: [www.chcnav.com](http://www.chcnav.com)

*This document is intended for general information purposes  
only. It does not consider the reader's specific circumstances  
and environmental constraints of use of GNSS*

**Make** your work more efficient

## **FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 40cm between the radiator & your body.