

IMPORTANT INFORMATION

Remove all packaging before use. Retain this information, addresses and phone numbers for future reference. Content may vary from pictures. An adult should periodically check this toy to ensure no damage or hazards exist, if so, remove from use. Children should be supervised during play.

NOTE: If normal function of the product is disturbed or interrupted, strong electro-magnetic interference may be causing the issue. To reset product, turn it completely off, then turn it back on. If normal operation does not resume, move the product to another location and try again. To ensure normal performance, change the batteries, as low batteries may not allow full function.

Care and Maintenance: Always remove batteries from the toy when it is not being used for a long period of time. Wipe the toy gently with a clean damp cloth. Keep the toy away from direct heat. Do not submerge the toy in water. This can damage the electronic assemblies.

Special Note to Adults: Parental guidance is recommended when installing or replacing batteries. Regularly examine the toy for damage. In the event of any damage, the toy must not be used until the damage has been repaired. This toy is not intended for children under 3 years old.




6+
YEARS

SECRET RADAR MOTION DETECTOR™

USER GUIDE

CONTENTS: 1 Secret Radar Motion Detector™, 1 User guide



© 2018 Tastemakers LLC. All rights reserved. • Tous droits réservés.
980 Avenue of the Americas, New York, NY 10018
www.tastemakersllc.com | 212-967-5091



© 2018. All rights reserved. SPY GEAR™ and the Spin Master logo are trademarks of Spin Master Ltd., used under license.

MADE IN CHINA

Meets CPSC Safety Requirements.



3 AAA (LR3) 1.5 V
Not included

WARNING:
CHOKING HAZARD – Small parts.
Not for children under 3 years.




FCC STATEMENT

FCC Statement: This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation. This equipment has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this toy does cause interference to radio or television reception (you can check this by turning the toy off and on while listening for the interference), one or more of the following measures may be useful. • Reorient or relocate the receiving antenna • Increase the separation between the toy and the radio or the TV • Consult the dealer or an experienced TV-radio technician for help. **NOTE:** Changes, adjustments or modifications to this unit, including but not limited to, replacement of any transmitter component (crystal, semiconductor, etc.) could result in a violation of FCC rules under part 15 and/or 95 and must be expressly approved by Spin Master Ltd. or they could void the user's authority to operate the equipment.

HOW TO INSTALL BATTERIES

1. Open the battery door with a screwdriver.
2. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery. DO NOT remove or install batteries using sharp or metal tools.
3. Install new batteries as shown in the polarity diagram (+/-) inside the battery compartment.
4. Replace battery door securely.
5. Check your local laws and regulations for correct recycling and/or battery disposal. Recommend to isolate terminals with electrical tape.



BATTERY SAFETY INFORMATION

BATTERY SAFETY INFORMATION: Requires 3 x AAA (LR03) alkaline batteries (not included). Batteries are small objects - Replacement of batteries must be done by adults. - Follow the polarity (+/-) diagram in the battery compartment. - Promptly remove dead batteries from the toy. - Dispose of used batteries properly, ensure terminals are covered by electrical tape. - Remove batteries for prolonged storage. - Only batteries of the same or equivalent type as recommended are to be used. - DO NOT incinerate used batteries. - DO NOT dispose of this product in fire, as batteries inside may explode or leak. - DO NOT dispose of batteries in fire, as batteries may explode or leak. - DO NOT mix old and new batteries or types of batteries (i.e. alkaline/standard). - DO NOT use rechargeable batteries. - DO NOT recharge non-rechargeable batteries. - DO NOT short-circuit the supply terminals.


NOTICE

When changing settings on SECRET RADAR MOTION DETECTOR (WATCH DOG to/from HANDHELD, SOUND ON to/from SOUND OFF) device will reset for 10 seconds. Use this time to set up your detector and move out of the Detection Zone.

HOW TO USE YOUR SECRET RADAR MOTION DETECTOR™


WATCH DOG MODE:

- 1) Move WATCH DOG/HANDHELD SWITCH to WATCH DOG position. (A)
- 2) Fold legs into Tripod Position.



Tripod Position

- 3) Move ON/OFF SWITCH to the ON position. (I)
- 4) SECRET RADAR MOTION DETECTOR default mode is SILENT MODE.
- 5) Place SECRET RADAR MOTION DETECTOR on table or floor.
- 6) **SECRET MOTION RADAR DETECTOR is one of the most powerful motion detectors with 360 degrees of Motion Detection! You have 10 seconds to move out of Detection Zone.**
- 7) Green LED Blinks and there is a 5 beep count down.
- 8) When RED MOTION INDICATOR LED light up from left to right SECRET RADAR MOTION DETECTOR is ready to detect motion.
- 9) GREEN POWER LED and RED MOTION INDICATOR LED all flash when motion is detected in range of detection area.
- 10) To **activate** SOUND ALARM mode, press and hold SOUND MODE button (M) for 1 second.
- 11) To **stop** SOUND ALARM, press SOUND MODE button. (M)
- 12) Any tie SOUND MODE button is pressed, you have 10 seconds to move out of the Detection Zone - 5 beep count down will sound



Sound Mode Button Watchdog/Handheld Switch

HANDHELD MODE:

- 1) Move WATCH DOG/HANDHELD SWITCH to HANDHELD (≡) position.
- 2) Fold legs into hand held position.
- 3) Move ON/OFF SWITCH to the ON (I) position.
- 4) GREEN LED Blinks During Warm Up.
*Warm up takes 10 seconds
- 5) When RED MOTION INDICATOR LED light up from left to right SECRET RADAR MOTION DETECTOR is ready to detect motion.
- 6) Hold very still. SECRET MOTION RADAR DETECTOR **detects all motion.**
- 7) Press and hold HAND HELD DETECTION (≡) button to activate radar to detect motion.
- 8) GREEN POWER LED and RED MOTION INDICATOR LED all flash when motion is detected in range of detection area.
- 9) RELEASE HAND HELD DETECTOR BUTTON (≡) to stop motion detection.
- 10) To active SOUND ALARM mode, press SOUND MODE BUTTON (M) for 1 second
- 11) Allow 10 seconds for SECRET RADAR DETECTOR to restart.




DIAGRAM OF BACK OF UNIT:

