

ALIGNMENT PROCEDURE & SPECIFICATIONS

ALIGNMENT PROCEDURE FORM-8

DATE ISSUED FEB. 05 2001

UNIDEN No UH-053ZL
BUYER'S MDL VMMS

APPRO	CHECK	ISSUE	WRITTEN

DOCUMENT No.

TABLE OF CONTENTS	PAGE
INITIALIZE	2
PRE-ADJUST	5
PRE CHECK	8
UNIT ADJUSTMENT	11
FUNCTION CHECK	14
ESN WRITING	17
SPECIFICATIONS	20
	-
	-
	-
	-
	-
	-
	-
	-
	-

NO.OF PAGES 21 W/ COVER PAGE

ISSUER'S STAMP

JIG REQUIREMENT

JIG NAME	JIG NO. (PRODUCTION ASSIGNED)	ADAPTER NUMBER
INTERFACE JIG (MODIFIED)	UH - 041Z - 4497 - 042Z	
LEVEL SHIFTER JIG	UA - 378	
CONNECT JIG	UH - 052ZP - 4582	

ALIGNMENT PROCEDURE		FORM-1	EQUIPMENT SETTING		PAGE	2
MODEL		UNIT		BLOCK	ISSUE DATE	ISSUED
UH-053ZL		MAIN PCB			FEB. 05 2001	H.KAMBARA
TITLE		MAIN PCB INITIALIZE		SUB TITLE		
REQUIRED EQUIPMENT AND JIG						
NO.	JIG / EQUIPMENT NAME		JIG/EQUIP. MODEL NO.	QTY	REMARKS	
1	MAIN PCB INITIAL JIG			1		
2	PC			1	COM1	
3	LEVEL SHIFTER JIG		UA - 378	1	WITH AC ADAPTER	
4	INTERFACE JIG		UH - 041Z - 4497 - 042Z	1		
5	DC SUPPLY			1		
6	CABLE		WZ - 1176	1		
7	RS-232C CABLE			1		
8	CURRENT METER			1	MAX. 1.0A	
9	CONNECT JIG		UH - 052ZP - 4582	1		
JIG AND EQUIPMENT SETTING						
TOOLS / EQPT REQ'D FOR ADJUSTMENT						
EQUIPMENT / JIG CONNECTION DIAGRAM						
The diagram illustrates the connection setup for the equipment. A PCB is connected to a PC via an RS-232C cable. The PC is connected to a UA-378 level shifter, which is connected to an AC adapter. The AC adapter provides DC 13.7V (BLK) to the Interface Jig. The Interface Jig is connected to a DC Supply (DC 5.5V +/-0.01V) and a Current Meter. The DC Supply provides DC 13.7V (BLK) to the Interface Jig. The Current Meter is connected to the PCB via a cable with (+) and (-) terminals. The Interface Jig is connected to a CONNECT JIG, which is connected to the PCB. The PCB is also connected to a PC via an RS-232C cable. Legend: ○ (RED) CURRENT ○ (RED) DC13.7V ● (BLK) ● (BLK) INTERFACE JIG (REAR PANEL)						

ALIGNMENT PROCEDURE FORM - 3				PAGE	3																						
MODEL	UNIT	BLOCK	ISSUE DATE	ISSUED																							
UH-053ZL	MAIN PCB		FEB. 05 2001	H.KAMBARA																							
TITLE	MAIN PCB INITIALIZE		SUB TITLE	REF DIAGRAM																							
<table><tr><td>STEP</td><td>CHECK POINT</td><td>SPEC</td><td>PROCEDURE</td></tr><tr><td>1</td><td>CURRENT METER</td><td>LESS THAN 0.05mA.</td><td>CONNECT CLIPS TO BATTERY TERMINALS OF PCB. CHECK THE CURRENT.</td></tr><tr><td>2</td><td></td><td></td><td>REMOVE CLIP FROM PCB AND CONNECT TO THE CONNECT JIG.</td></tr><tr><td>2</td><td>CURRENT METER</td><td>MORE THAN 40mA LESS THAN 80mA</td><td>CHECK THE CURRENT AFTER POWER ON BEEP.</td></tr><tr><td rowspan="2">4</td><td rowspan="2">SCREEN OF PC</td><td>OK</td><td>PCB CAN BE INITIALIZED CORRECTLY</td></tr><tr><td>NG</td><td>PCB CAN NOT BE INITIALIZED</td></tr></table>						STEP	CHECK POINT	SPEC	PROCEDURE	1	CURRENT METER	LESS THAN 0.05mA.	CONNECT CLIPS TO BATTERY TERMINALS OF PCB. CHECK THE CURRENT.	2			REMOVE CLIP FROM PCB AND CONNECT TO THE CONNECT JIG.	2	CURRENT METER	MORE THAN 40mA LESS THAN 80mA	CHECK THE CURRENT AFTER POWER ON BEEP.	4	SCREEN OF PC	OK	PCB CAN BE INITIALIZED CORRECTLY	NG	PCB CAN NOT BE INITIALIZED
STEP	CHECK POINT	SPEC	PROCEDURE																								
1	CURRENT METER	LESS THAN 0.05mA.	CONNECT CLIPS TO BATTERY TERMINALS OF PCB. CHECK THE CURRENT.																								
2			REMOVE CLIP FROM PCB AND CONNECT TO THE CONNECT JIG.																								
2	CURRENT METER	MORE THAN 40mA LESS THAN 80mA	CHECK THE CURRENT AFTER POWER ON BEEP.																								
4	SCREEN OF PC	OK	PCB CAN BE INITIALIZED CORRECTLY																								
		NG	PCB CAN NOT BE INITIALIZED																								

ALIGNMENT PROCEDURE		FORM-1	EQUIPMENT SETTING		PAGE	5
MODEL		UNIT		BLOCK	ISSUE DATE	ISSUED
UH-053ZL		MAIN PCB			FEB. 05 2001	H.KAMBARA
TITLE		PRE-ADJUST		SUB TITLE		
REQUIRED EQUIPMENT AND JIG						
NO.	JIG / EQUIPMENT NAME		JIG/EQUIP. MODEL NO.	QTY	REMARKS	
1	HP8920A			1	WITH OPT 003(103),004,005, 008,011,014,050	
2	PC WITH GPIB INTERFACE			1	GPIB:HP82335B	
3	LEVEL SHIFTER JIG		UA - 378Z	1	WITH AC ADAPTOR	
4	INTERFACE JIG		UH - 041Z - 4497 - 042Z	1		
5	DC SUPPLY			1		
6	RS-232C CABLE			1		
7	GPIB CABLE			1		
8	CABLE		WZ - 1176	1		
9	RF CABLE			1		
10	CONNECT JIG		UH - 052ZP - 4582	1		
JIG AND EQUIPMENT SETTING						
TOOLS / EQPT REQ'D FOR ADJUSTMENT						
EQUIPMENT / JIG CONNECTION DIAGRAM						
AC ADAPTER LEVEL SHIFTER UA-378Z PC DC SUPPLY DC 5.5V DC13.7V (BLK) INTERFACE JIG CONNECT JIG PCB HP8920A WZ-1176 RS-232C GP-IB TX EXT IN RX OUT Audio out Audio in RF out RF CABLE ANT CURRENT (+) (BLK) (-) DC13.7V (BLK) ○ (RED) CURRENT ● (BLK) ○ (RED) DC13.7V ● (BLK) INTERFACE JIG (REAR PANEL)						

ALIGNMENT PROCEDURE FORM - 3				PAGE	6														
MODEL	UNIT	BLOCK	ISSUE DATE	ISSUED															
UH-053ZL	MAIN PCB		FEB. 05 2001	H.KAMBARA															
TITLE	PRE-ADJUST		SUB TITLE	REF DIAGRAM															
<table><tr><td>STEP</td><td>CHECK POINT</td><td>SPEC</td><td>PROCEDURE</td></tr><tr><td>1</td><td></td><td></td><td>RUN THE PRE-ADJUST PROGRAM OF PC</td></tr><tr><td rowspan="2">2</td><td rowspan="2">SCREEN OF PC</td><td>OK</td><td>PCB CAN BE PRE-ADJUSTED CORRECTLY</td></tr><tr><td>NG</td><td>PCB CAN NOT BE PRE-ADJUSTED</td></tr></table>						STEP	CHECK POINT	SPEC	PROCEDURE	1			RUN THE PRE-ADJUST PROGRAM OF PC	2	SCREEN OF PC	OK	PCB CAN BE PRE-ADJUSTED CORRECTLY	NG	PCB CAN NOT BE PRE-ADJUSTED
STEP	CHECK POINT	SPEC	PROCEDURE																
1			RUN THE PRE-ADJUST PROGRAM OF PC																
2	SCREEN OF PC	OK	PCB CAN BE PRE-ADJUSTED CORRECTLY																
		NG	PCB CAN NOT BE PRE-ADJUSTED																

ALIGNMENT PROCEDURE		FORM-1	EQUIPMENT SETTING		PAGE	8
MODEL		UNIT		BLOCK	ISSUE DATE	
UH-053ZL		MAIN PCB			FEB. 05 2001	
ISSUED		H.KAMBARA				
TITLE		PRE CHECK		SUB TITLE		
REQUIRED EQUIPMENT AND JIG						
NO.	JIG / EQUIPMENT NAME		JIG/EQUIP. MODEL NO.	QTY	REMARKS	
1	NJZ-900A WITH H/S			1		
2	DC SUPPLY			2		
3	INTERFACE JIG		UH - 041Z - 4497 - 042Z	1		
4	RF CABLE			1		
5	CONNECT JIG		UH - 052ZP - 4582	1		
6	CURRENT METER			1	MAX 1.0A	
7						
8						
9						
JIG AND EQUIPMENT SETTING						
TOOLS / EQPT REQ'D FOR ADJUSTMENT						
EQUIPMENT / JIG CONNECTION DIAGRAM						
DC SUPPLY1 DC 13.8V NJZ-900A ANT RF CABLE PCB CONNECT JIG INTERFACE JIG CURRENT METER DC SUPPLY DC 5.5V O (RED) CURRENT ● (BLK) O (RED) DC13.7V ● (BLK) INTERFACE JIG (REAR PANEL)						

ALIGNMENT PROCEDURE FORM - 3				PAGE	9																																	
MODEL	UNIT	BLOCK	ISSUE DATE	ISSUED																																		
UH-053ZL	MAIN PCB		FEB. 05 2001	H.KAMBARA																																		
TITLE	PRE CHECK	SUB TITLE		REF DIAGRAM																																		
<table><tr><td>STEP</td><td>CHECK POINT</td><td>SPEC</td><td>PROCEDURE</td></tr><tr><td>1</td><td>PANIC SIREN CURRENT</td><td>100 - 300mA (WITHOUT SIREN SPEAKER)</td><td>PUSH LEFT AND RIGHT KEY FOR MORE THAN 1 SEC. THEN CHECK THE CURRENT. PUSH LEFT AND RIGHT KEY FOR MORE THAN 1 SEC TO STOP THE SIREN.</td></tr><tr><td>2</td><td>NJZ-900A (INITIAL ONLY)</td><td></td><td>SET CH & MIN OF NJZ900A IN AUTO TEST MODE. PRESS NJZ900A "RESET" "CALL PROCESS" & "START". IDLE LED WILL FLASHING LCD DISPLAY SHOWS MIN No. " MIN=1234567890 "</td></tr><tr><td rowspan="3">3</td><td>LED's</td><td>IN USE LED</td><td>PRESS 911 KEY OF PCB. INUSE LED WILL FLASH AND WILL BE STILL AFTER CONNECTED TO NJZ900A.</td></tr><tr><td rowspan="2">CONNECTION</td><td>CONNECTION OK</td><td>NJZ900A ORIGINATION LED WILL BE ON AND LCD DISPLAY SHOW FOLLOWS. "0123456789000000 SN=1A5FC897 " AND RING WILL COME APPEAR</td></tr><tr><td>CONNECTION NG</td><td>NJZ900A ORIGINATION WILL NOT BE ON, NOR BEEP COME APPEAR. PRESS "RESET" OF NJZ900A.</td></tr><tr><td>4</td><td>NJZ-900A</td><td>TALK FUNCTION</td><td>PRESS SEND KEY OF NJZ900A H/S. CHECK TALK FUNCTIONS WHILE TALK MODE LED IS BLINKING</td></tr><tr><td>5</td><td>CURRENT EAR SP OF NJZ-900A'S H/S</td><td>LESS THAN 700mA NO UNUSUAL NOISE</td><td>CHECK CURRENT. CHECK EAR SPEAKER NOISE</td></tr><tr><td>6</td><td></td><td></td><td>PRESS 911 KEY MORE THAN 1 SEC. CHECK CONNECTION WILL BE RELEASE.</td></tr></table>						STEP	CHECK POINT	SPEC	PROCEDURE	1	PANIC SIREN CURRENT	100 - 300mA (WITHOUT SIREN SPEAKER)	PUSH LEFT AND RIGHT KEY FOR MORE THAN 1 SEC. THEN CHECK THE CURRENT. PUSH LEFT AND RIGHT KEY FOR MORE THAN 1 SEC TO STOP THE SIREN.	2	NJZ-900A (INITIAL ONLY)		SET CH & MIN OF NJZ900A IN AUTO TEST MODE. PRESS NJZ900A "RESET" "CALL PROCESS" & "START". IDLE LED WILL FLASHING LCD DISPLAY SHOWS MIN No. " MIN=1234567890 "	3	LED's	IN USE LED	PRESS 911 KEY OF PCB. INUSE LED WILL FLASH AND WILL BE STILL AFTER CONNECTED TO NJZ900A.	CONNECTION	CONNECTION OK	NJZ900A ORIGINATION LED WILL BE ON AND LCD DISPLAY SHOW FOLLOWS. "0123456789000000 SN=1A5FC897 " AND RING WILL COME APPEAR	CONNECTION NG	NJZ900A ORIGINATION WILL NOT BE ON, NOR BEEP COME APPEAR. PRESS "RESET" OF NJZ900A.	4	NJZ-900A	TALK FUNCTION	PRESS SEND KEY OF NJZ900A H/S. CHECK TALK FUNCTIONS WHILE TALK MODE LED IS BLINKING	5	CURRENT EAR SP OF NJZ-900A'S H/S	LESS THAN 700mA NO UNUSUAL NOISE	CHECK CURRENT. CHECK EAR SPEAKER NOISE	6			PRESS 911 KEY MORE THAN 1 SEC. CHECK CONNECTION WILL BE RELEASE.
STEP	CHECK POINT	SPEC	PROCEDURE																																			
1	PANIC SIREN CURRENT	100 - 300mA (WITHOUT SIREN SPEAKER)	PUSH LEFT AND RIGHT KEY FOR MORE THAN 1 SEC. THEN CHECK THE CURRENT. PUSH LEFT AND RIGHT KEY FOR MORE THAN 1 SEC TO STOP THE SIREN.																																			
2	NJZ-900A (INITIAL ONLY)		SET CH & MIN OF NJZ900A IN AUTO TEST MODE. PRESS NJZ900A "RESET" "CALL PROCESS" & "START". IDLE LED WILL FLASHING LCD DISPLAY SHOWS MIN No. " MIN=1234567890 "																																			
3	LED's	IN USE LED	PRESS 911 KEY OF PCB. INUSE LED WILL FLASH AND WILL BE STILL AFTER CONNECTED TO NJZ900A.																																			
	CONNECTION	CONNECTION OK	NJZ900A ORIGINATION LED WILL BE ON AND LCD DISPLAY SHOW FOLLOWS. "0123456789000000 SN=1A5FC897 " AND RING WILL COME APPEAR																																			
		CONNECTION NG	NJZ900A ORIGINATION WILL NOT BE ON, NOR BEEP COME APPEAR. PRESS "RESET" OF NJZ900A.																																			
4	NJZ-900A	TALK FUNCTION	PRESS SEND KEY OF NJZ900A H/S. CHECK TALK FUNCTIONS WHILE TALK MODE LED IS BLINKING																																			
5	CURRENT EAR SP OF NJZ-900A'S H/S	LESS THAN 700mA NO UNUSUAL NOISE	CHECK CURRENT. CHECK EAR SPEAKER NOISE																																			
6			PRESS 911 KEY MORE THAN 1 SEC. CHECK CONNECTION WILL BE RELEASE.																																			

ALIGNMENT PROCEDURE		FORM-1	EQUIPMENT SETTING		PAGE	11
MODEL		UNIT		BLOCK	ISSUE DATE	ISSUED
UH-053ZL		MAIN UNIT			FEB. 05 2001	H.KAMBARA
TITLE		UNIT ADJUSTMENT		SUB TITLE		
REQUIRED EQUIPMENT AND JIG						
NO.	JIG / EQUIPMENT NAME		JIG/EQUIP. MODEL NO.	QTY	REMARKS	
1	HP8920A			1	WITH OPT 003(103),004,005, 008,011,014,050	
2	PC WITH GPIB INTERFACE			1	GPIB:HP82335B	
3	LEVEL SHIFTER JIG		UA - 378Z	1	WITH AC ADAPTER	
4	INTERFACE JIG		UH - 041Z - 4497 - 042Z	1		
5	DC SUPPLY			1		
6	RS-232C CABLE			1		
7	GPIB CABLE			1		
8	CABLE		WZ - 1176	1		
9	RF CABLE			1		
10	CONNECT JIG		UH - 052ZP - 4582	1		
11	SHIELD ROOM			1	(RECOMMENDED TO USE)	
JIG AND EQUIPMENT SETTING						
TOOLS / EQPT REQ'D FOR ADJUSTMENT						
EQUIPMENT / JIG CONNECTION DIAGRAM						
AC ADAPTER LEVEL SHIFTER UA-378Z PC HP8920A UNIT DC SUPPLY DC 5.5V DC13.7V (BLK) INTERFACE JIG CONNECT JIG TX EXT IN RX OUT Audio out Audio in RF out ANT ○ (RED) ○ (RED) CURRENT DC13.7V ● (BLK) ● (BLK) INTERFACE JIG (REAR PANEL)						

ALIGNMENT PROCEDURE FORM - 3				PAGE	12														
MODEL	UNIT	BLOCK	ISSUE DATE	ISSUED															
UH-053ZL	MAIN UNIT		FEB. 05 2001	H.KAMBARA															
TITLE	UNIT ADJUSTMENT		SUB TITLE	REF DIAGRAM															
<table><tr><td>STEP</td><td>CHECK POINT</td><td>SPEC</td><td>PROCEDURE</td></tr><tr><td>1</td><td></td><td></td><td>RUN ADJUSTMENT SOFTWARE.</td></tr><tr><td rowspan="2">2</td><td rowspan="2">SCREEN OF PC</td><td>OK</td><td>PCB CAN BE ADJUSTED CORRECTLY</td></tr><tr><td>NG</td><td>PCB CAN NOT BE ADJUSTED</td></tr></table>						STEP	CHECK POINT	SPEC	PROCEDURE	1			RUN ADJUSTMENT SOFTWARE.	2	SCREEN OF PC	OK	PCB CAN BE ADJUSTED CORRECTLY	NG	PCB CAN NOT BE ADJUSTED
STEP	CHECK POINT	SPEC	PROCEDURE																
1			RUN ADJUSTMENT SOFTWARE.																
2	SCREEN OF PC	OK	PCB CAN BE ADJUSTED CORRECTLY																
		NG	PCB CAN NOT BE ADJUSTED																

ALIGNMENT PROCEDURE		FORM-1	EQUIPMENT SETTING		PAGE	14
MODEL		UNIT		BLOCK	ISSUE DATE	ISSUED
UH-053ZL		MAIN UNIT			FEB. 05 2001	H.KAMBARA
TITLE		FUNCTION CHECK		SUB TITLE		
REQUIRED EQUIPMENT AND JIG						
NO.	JIG / EQUIPMENT NAME		JIG/EQUIP. MODEL NO.	QTY	REMARKS	
1	NJZ-900A WITH H/S			1		
2	DC SUPPLY			2		
3	INTERFACE JIG		UH - 041Z - 4497 - 042Z	1		
4	CONNECT JIG		UH - 052ZP - 4582	1		
5	CURRENT METER			1	MAX 1.0A	
6	ANTENNA			1	for NJZ-900A	
7	SPL METER			1		
8	SHIELD ROOM			1	(RECOMMENDED TO USE)	
9						
JIG AND EQUIPMENT SETTING						
TOOLS / EQPT REQ'D FOR ADJUSTMENT						
EQUIPMENT / JIG CONNECTION DIAGRAM						
DC SUPPLY1 NJZ-900A DC 13.8V ANT UNIT CONNECT JIG INTERFACE JIG CURRENT (BLK) CURRENT METER DC SUPPLY DC 5.5V SPL METER O (RED) CURRENT ● (BLK) O (RED) DC13.7V ● (BLK) INTERFACE JIG (REAR PANEL)						

ALIGNMENT PROCEDURE FORM - 3				PAGE	15																																				
MODEL	UNIT	BLOCK	ISSUE DATE	ISSUED																																					
UH-053ZL	MAIN UNIT		FEB. 05 2001	H.KAMBARA																																					
TITLE	FUNCTION CHECK	SUB TITLE		REF DIAGRAM																																					
<table><tr><td>STEP</td><td>CHECK POINT</td><td>SPEC</td><td>PROCEDURE</td></tr><tr><td>1</td><td>PANIC SIREN CURRENT SPL</td><td>100 - 300mA 90dBSPL</td><td>PUSH LEFT AND RIGHT KEY FOR 1 SEC. CHECK THERE IS NO BUZZ SOUND. CHECK CURRENT. CHECK MAX. SOUND PRESSURE LEVEL AT DISTANCE OF 1m.</td></tr><tr><td>2</td><td>NJZ-900A (INITIAL ONLY)</td><td></td><td>SET CH & MIN OF NJZ900A IN AUTO TEST MODE. PRESS NJZ900A "RESET" "CALL PROCESS" & "START". IDLE LED WILL FLASHING LCD DISPLAY SHOWS MIN No. " MIN=1234567890 "</td></tr><tr><td rowspan="3">3</td><td>LED's</td><td>IN USE LED</td><td>PRESS 911 KEY OF PCB. INUSE LED WILL FLASH AND WILL BE STILL AFTER CONNECTED TO NJZ900A.</td></tr><tr><td rowspan="2">CONNECTION</td><td>CONNECTION OK</td><td>NJZ900A ORIGINATION LED WILL BE ON AND LCD DISPLAY SHOW FOLLOWS. "0123456789000000 SN=1A5FC897 " AND RING WILL COME APPEAR</td></tr><tr><td>CONNECTION NG</td><td>NJZ900A ORIGINATION WILL NOT BE ON, NOR BEEP COME APPEAR. PRESS "RESET" OF NJZ900A.</td></tr><tr><td>4</td><td>NJZ-900A</td><td>TALK FUNCTION</td><td>PRESS SEND KEY OF NJZ900A H/S. CHECK TALK FUNCTIONS WHILE TALK MODE LED IS BLINKING</td></tr><tr><td rowspan="2">5</td><td>CURRENT EAR SP OF UNIT VOLUME</td><td>LESS THAN 700mA NO UNUSUALNOISE VOLUME CHANGE</td><td>CHECK CURRENT. CHECK EAR SPEAKER NOISE CHECK EAR SPEAKER VOLUME WILL BE CHANGE EVERY LEFT KEY PUSH.</td></tr><tr><td>EAR SP OF NJZ-900A'S H/S</td><td>NO UNUSUALNOISE</td><td>CHECK EAR SPEAKER NOISE</td></tr><tr><td>6</td><td></td><td></td><td>PRESS 911 KEY MORE THAN 1 SEC. CHECK CONNECTION WILL BE RELEASE.</td></tr></table>						STEP	CHECK POINT	SPEC	PROCEDURE	1	PANIC SIREN CURRENT SPL	100 - 300mA 90dBSPL	PUSH LEFT AND RIGHT KEY FOR 1 SEC. CHECK THERE IS NO BUZZ SOUND. CHECK CURRENT. CHECK MAX. SOUND PRESSURE LEVEL AT DISTANCE OF 1m.	2	NJZ-900A (INITIAL ONLY)		SET CH & MIN OF NJZ900A IN AUTO TEST MODE. PRESS NJZ900A "RESET" "CALL PROCESS" & "START". IDLE LED WILL FLASHING LCD DISPLAY SHOWS MIN No. " MIN=1234567890 "	3	LED's	IN USE LED	PRESS 911 KEY OF PCB. INUSE LED WILL FLASH AND WILL BE STILL AFTER CONNECTED TO NJZ900A.	CONNECTION	CONNECTION OK	NJZ900A ORIGINATION LED WILL BE ON AND LCD DISPLAY SHOW FOLLOWS. "0123456789000000 SN=1A5FC897 " AND RING WILL COME APPEAR	CONNECTION NG	NJZ900A ORIGINATION WILL NOT BE ON, NOR BEEP COME APPEAR. PRESS "RESET" OF NJZ900A.	4	NJZ-900A	TALK FUNCTION	PRESS SEND KEY OF NJZ900A H/S. CHECK TALK FUNCTIONS WHILE TALK MODE LED IS BLINKING	5	CURRENT EAR SP OF UNIT VOLUME	LESS THAN 700mA NO UNUSUALNOISE VOLUME CHANGE	CHECK CURRENT. CHECK EAR SPEAKER NOISE CHECK EAR SPEAKER VOLUME WILL BE CHANGE EVERY LEFT KEY PUSH.	EAR SP OF NJZ-900A'S H/S	NO UNUSUALNOISE	CHECK EAR SPEAKER NOISE	6			PRESS 911 KEY MORE THAN 1 SEC. CHECK CONNECTION WILL BE RELEASE.
STEP	CHECK POINT	SPEC	PROCEDURE																																						
1	PANIC SIREN CURRENT SPL	100 - 300mA 90dBSPL	PUSH LEFT AND RIGHT KEY FOR 1 SEC. CHECK THERE IS NO BUZZ SOUND. CHECK CURRENT. CHECK MAX. SOUND PRESSURE LEVEL AT DISTANCE OF 1m.																																						
2	NJZ-900A (INITIAL ONLY)		SET CH & MIN OF NJZ900A IN AUTO TEST MODE. PRESS NJZ900A "RESET" "CALL PROCESS" & "START". IDLE LED WILL FLASHING LCD DISPLAY SHOWS MIN No. " MIN=1234567890 "																																						
3	LED's	IN USE LED	PRESS 911 KEY OF PCB. INUSE LED WILL FLASH AND WILL BE STILL AFTER CONNECTED TO NJZ900A.																																						
	CONNECTION	CONNECTION OK	NJZ900A ORIGINATION LED WILL BE ON AND LCD DISPLAY SHOW FOLLOWS. "0123456789000000 SN=1A5FC897 " AND RING WILL COME APPEAR																																						
		CONNECTION NG	NJZ900A ORIGINATION WILL NOT BE ON, NOR BEEP COME APPEAR. PRESS "RESET" OF NJZ900A.																																						
4	NJZ-900A	TALK FUNCTION	PRESS SEND KEY OF NJZ900A H/S. CHECK TALK FUNCTIONS WHILE TALK MODE LED IS BLINKING																																						
5	CURRENT EAR SP OF UNIT VOLUME	LESS THAN 700mA NO UNUSUALNOISE VOLUME CHANGE	CHECK CURRENT. CHECK EAR SPEAKER NOISE CHECK EAR SPEAKER VOLUME WILL BE CHANGE EVERY LEFT KEY PUSH.																																						
	EAR SP OF NJZ-900A'S H/S	NO UNUSUALNOISE	CHECK EAR SPEAKER NOISE																																						
6			PRESS 911 KEY MORE THAN 1 SEC. CHECK CONNECTION WILL BE RELEASE.																																						

ALIGNMENT PROCEDURE		FORM-1	EQUIPMENT SETTING		PAGE	17
MODEL		UNIT		BLOCK	ISSUE DATE	ISSUED
UH-053ZL		MAIN PCB			FEB. 05 2001	H.KAMBARA
TITLE		ESN WRITING		SUB TITLE		
REQUIRED EQUIPMENT AND JIG						
NO.	JIG / EQUIPMENT NAME		JIG/EQUIP. MODEL NO.	QTY	REMARKS	
1	MAIN PCB INITIAL JIG			1		
2	PC			1	COM1	
3	LEVEL SHIFTER JIG		UA - 378	1	WITH AC ADAPTER	
4	INTERFACE JIG		UH - 041Z - 4497 - 042Z	1		
5	DC SUPPLY			1		
6	CABLE		WZ - 1176	1		
7	RS-232C CABLE			1		
8	CONNECT JIG		UH - 052ZP - 4582	1		
9						
JIG AND EQUIPMENT SETTING						
TOOLS / EQPT REQ'D FOR ADJUSTMENT						
EQUIPMENT / JIG CONNECTION DIAGRAM						
UNIT CONNECT JIG ↑ INTERFACE JIG CURRENT (BLK) (+) DC SUPPLY DC 5.5 V DC13.7V (BLK) (-) PC RS-232C UA-378 AC ADAPTER WZ-1176 ○ (RED) CURRENT ● (BLK) ○ (RED) DC13.7V ● (BLK) INTERFACE JIG (REAR PANEL)						

ALIGNMENT PROCEDURE FORM - 3				PAGE	18														
MODEL	UNIT	BLOCK	ISSUE DATE	ISSUED															
UH-053ZL	MAIN PCB		FEB. 05 2001	H.KAMBARA															
TITLE	ESN WRITING		SUB TITLE	REF DIAGRAM															
<table><tr><td>STEP</td><td>CHECK POINT</td><td>SPEC</td><td>PROCEDURE</td></tr><tr><td>1</td><td>SERIAL NO.</td><td></td><td>CHECK THE SERIAL NO. OF UNIT CKECK THE SERIAL NO. INDICATED ON THE PC MONITOR.</td></tr><tr><td rowspan="2">2</td><td rowspan="2">SCREEN OF PC</td><td>OK</td><td>ESN WILLBE WRITTEN CORRECTLY</td></tr><tr><td>NG</td><td>ERROR MESSAGE WILL COME APPEAR.</td></tr></table>						STEP	CHECK POINT	SPEC	PROCEDURE	1	SERIAL NO.		CHECK THE SERIAL NO. OF UNIT CKECK THE SERIAL NO. INDICATED ON THE PC MONITOR.	2	SCREEN OF PC	OK	ESN WILLBE WRITTEN CORRECTLY	NG	ERROR MESSAGE WILL COME APPEAR.
STEP	CHECK POINT	SPEC	PROCEDURE																
1	SERIAL NO.		CHECK THE SERIAL NO. OF UNIT CKECK THE SERIAL NO. INDICATED ON THE PC MONITOR.																
2	SCREEN OF PC	OK	ESN WILLBE WRITTEN CORRECTLY																
		NG	ERROR MESSAGE WILL COME APPEAR.																

ALIGNMENT PROCEDURE FORM - 3						PAGE 20																																																																																																																																																																																														
MODEL		UNIT		BLOCK		ISSUE DATE		ISSUED																																																																																																																																																																																												
UH-053ZL		MAIN UNIT				FEB. 05 2001		H.KAMBARA																																																																																																																																																																																												
TITLE	SPECIFICATIONS			SUB TITLE				REF DIAGRAM																																																																																																																																																																																												
BUYER'S SPEC REFERENCE ONLY. (cf. SPECIFICATIONS SHEETS) STANDARD CONDITION (FOR LINE) VOLTAGE DC 5.50 +/- 0.02V TEMP. 25 DEGREE C +/- 5 CH. 993, 384, 797																																																																																																																																																																																																				
<table><tr><td colspan="4"></td><td colspan="2">FOR LINE</td><td colspan="2">FOR BUYER'S</td><td colspan="2"></td></tr><tr><td>No.</td><td colspan="2">DESCRIPTION</td><td>UNIT</td><td>MIN.</td><td>MAX.</td><td>MIN.</td><td>MAX.</td><td colspan="2">NOTE</td></tr><tr><td>1</td><td colspan="2">TX FREQUENCY ERROR</td><td>ppm</td><td>-2.2</td><td>2.2</td><td>-2.5</td><td>2.5</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td rowspan="6">2</td><td rowspan="6">TX POWER</td><td>PL2</td><td>dBm</td><td>23.8</td><td>29.3</td><td>23.8</td><td>29.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td>PL3</td><td>dBm</td><td>20.3</td><td>25.3</td><td>19.8</td><td>25.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td>PL4</td><td>dBm</td><td>16.3</td><td>21.3</td><td>15.8</td><td>21.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td>PL5</td><td>dBm</td><td>12.3</td><td>17.3</td><td>11.8</td><td>17.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td>PL6</td><td>dBm</td><td>8.3</td><td>13.3</td><td>7.8</td><td>13.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td>PL7</td><td>dBm</td><td>4.3</td><td>9.3</td><td>3.8</td><td>9.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td rowspan="2">3</td><td>TX AUDIO</td><td>300Hz</td><td>dB</td><td>-15.5</td><td>-8.5</td><td>-15.5</td><td>-8.5</td><td colspan="2" rowspan="2">REFERENCE 1 kHz</td></tr><tr><td>FREQ. RES</td><td>3kHz</td><td>dB</td><td>4.5</td><td>10.5</td><td>4.5</td><td>10.5</td></tr><tr><td>4</td><td>TX MOD LIMITING</td><td></td><td>kHz</td><td></td><td>11.0</td><td></td><td>12.0</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td>5</td><td colspan="2">DATA DEVIATION</td><td>kHz</td><td>7.5</td><td>8.5</td><td>7.2</td><td>8.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td rowspan="3">6</td><td rowspan="3">SAT DEVIATION</td><td>5970Hz</td><td>kHz</td><td rowspan="3">1.90</td><td rowspan="3">2.10</td><td rowspan="3">1.80</td><td rowspan="3">2.20</td><td colspan="2" rowspan="3">-30 TO +60 DEG.C</td></tr><tr><td>6000Hz</td><td>kHz</td></tr><tr><td>6030Hz</td><td>kHz</td></tr><tr><td>7</td><td colspan="2">ST. DEVIATION</td><td>kHz</td><td>7.5</td><td>8.5</td><td>7.2</td><td>8.8</td><td colspan="2">-30 TO +60 DEG.C</td></tr><tr><td rowspan="3">8</td><td rowspan="3">SAT FREQUENCY</td><td>5970Hz</td><td>Hz</td><td>5969</td><td>5971</td><td>5969</td><td>5971</td><td colspan="2"></td></tr><tr><td>6000Hz</td><td>Hz</td><td>5999</td><td>6001</td><td>5999</td><td>6001</td><td colspan="2"></td></tr><tr><td>6030Hz</td><td>Hz</td><td>6029</td><td>6031</td><td>6029</td><td>6031</td><td colspan="2"></td></tr><tr><td>9</td><td colspan="2">ST. FREQUENCY</td><td>kHz</td><td>9.999</td><td>10.001</td><td>9.999</td><td>10.001</td><td colspan="2"></td></tr><tr><td>10</td><td colspan="2">TX DISTORTIN & NOISE</td><td>dB</td><td></td><td></td><td>26.0</td><td></td><td colspan="2">-30 TO +60 DEG.C</td></tr></table>														FOR LINE		FOR BUYER'S				No.	DESCRIPTION		UNIT	MIN.	MAX.	MIN.	MAX.	NOTE		1	TX FREQUENCY ERROR		ppm	-2.2	2.2	-2.5	2.5	-30 TO +60 DEG.C		2	TX POWER	PL2	dBm	23.8	29.3	23.8	29.8	-30 TO +60 DEG.C		PL3	dBm	20.3	25.3	19.8	25.8	-30 TO +60 DEG.C		PL4	dBm	16.3	21.3	15.8	21.8	-30 TO +60 DEG.C		PL5	dBm	12.3	17.3	11.8	17.8	-30 TO +60 DEG.C		PL6	dBm	8.3	13.3	7.8	13.8	-30 TO +60 DEG.C		PL7	dBm	4.3	9.3	3.8	9.8	-30 TO +60 DEG.C		3	TX AUDIO	300Hz	dB	-15.5	-8.5	-15.5	-8.5	REFERENCE 1 kHz		FREQ. RES	3kHz	dB	4.5	10.5	4.5	10.5	4	TX MOD LIMITING		kHz		11.0		12.0	-30 TO +60 DEG.C		5	DATA DEVIATION		kHz	7.5	8.5	7.2	8.8	-30 TO +60 DEG.C		6	SAT DEVIATION	5970Hz	kHz	1.90	2.10	1.80	2.20	-30 TO +60 DEG.C		6000Hz	kHz	6030Hz	kHz	7	ST. DEVIATION		kHz	7.5	8.5	7.2	8.8	-30 TO +60 DEG.C		8	SAT FREQUENCY	5970Hz	Hz	5969	5971	5969	5971			6000Hz	Hz	5999	6001	5999	6001			6030Hz	Hz	6029	6031	6029	6031			9	ST. FREQUENCY		kHz	9.999	10.001	9.999	10.001			10	TX DISTORTIN & NOISE		dB			26.0		-30 TO +60 DEG.C	
				FOR LINE		FOR BUYER'S																																																																																																																																																																																														
No.	DESCRIPTION		UNIT	MIN.	MAX.	MIN.	MAX.	NOTE																																																																																																																																																																																												
1	TX FREQUENCY ERROR		ppm	-2.2	2.2	-2.5	2.5	-30 TO +60 DEG.C																																																																																																																																																																																												
2	TX POWER	PL2	dBm	23.8	29.3	23.8	29.8	-30 TO +60 DEG.C																																																																																																																																																																																												
		PL3	dBm	20.3	25.3	19.8	25.8	-30 TO +60 DEG.C																																																																																																																																																																																												
		PL4	dBm	16.3	21.3	15.8	21.8	-30 TO +60 DEG.C																																																																																																																																																																																												
		PL5	dBm	12.3	17.3	11.8	17.8	-30 TO +60 DEG.C																																																																																																																																																																																												
		PL6	dBm	8.3	13.3	7.8	13.8	-30 TO +60 DEG.C																																																																																																																																																																																												
		PL7	dBm	4.3	9.3	3.8	9.8	-30 TO +60 DEG.C																																																																																																																																																																																												
3	TX AUDIO	300Hz	dB	-15.5	-8.5	-15.5	-8.5	REFERENCE 1 kHz																																																																																																																																																																																												
	FREQ. RES	3kHz	dB	4.5	10.5	4.5	10.5																																																																																																																																																																																													
4	TX MOD LIMITING		kHz		11.0		12.0	-30 TO +60 DEG.C																																																																																																																																																																																												
5	DATA DEVIATION		kHz	7.5	8.5	7.2	8.8	-30 TO +60 DEG.C																																																																																																																																																																																												
6	SAT DEVIATION	5970Hz	kHz	1.90	2.10	1.80	2.20	-30 TO +60 DEG.C																																																																																																																																																																																												
		6000Hz	kHz																																																																																																																																																																																																	
		6030Hz	kHz																																																																																																																																																																																																	
7	ST. DEVIATION		kHz	7.5	8.5	7.2	8.8	-30 TO +60 DEG.C																																																																																																																																																																																												
8	SAT FREQUENCY	5970Hz	Hz	5969	5971	5969	5971																																																																																																																																																																																													
		6000Hz	Hz	5999	6001	5999	6001																																																																																																																																																																																													
		6030Hz	Hz	6029	6031	6029	6031																																																																																																																																																																																													
9	ST. FREQUENCY		kHz	9.999	10.001	9.999	10.001																																																																																																																																																																																													
10	TX DISTORTIN & NOISE		dB			26.0		-30 TO +60 DEG.C																																																																																																																																																																																												

ALIGNMENT PROCEDURE FORM - 3						PAGE 21																																																																																																																																																						
MODEL		UNIT		BLOCK		ISSUE DATE		ISSUED																																																																																																																																																				
UH-053ZL		MAIN UNIT				FEB. 05 2001		H.KAMBARA																																																																																																																																																				
TITLE		SPECIFICATIONS			SUB TITLE		REF DIAGRAM																																																																																																																																																					
UNIT<table><thead><tr><th colspan="3"></th><th colspan="2">FOR LINE</th><th colspan="2">FOR BUYER'S</th><th></th></tr><tr><th>No.</th><th>DESCRIPTION</th><th>UNIT</th><th>MIN.</th><th>MAX.</th><th>MIN.</th><th>MAX.</th><th>NOTE</th></tr></thead><tbody><tr><td>11</td><td>CARRIER ON STATE</td><td>dBm</td><td></td><td></td><td></td><td>-60.0</td><td></td></tr><tr><td>12</td><td>CONDUCTED SPURIOUS EMISSION</td><td>dB</td><td></td><td></td><td></td><td>-40.7</td><td></td></tr><tr><td rowspan="2">13</td><td>RX AUDIO FREQ</td><td>300Hz</td><td>9.0</td><td>23.0</td><td>9.0</td><td>23.0</td><td rowspan="2">REFERENCE 1 kHz</td></tr><tr><td>RESPONSE</td><td>3kHz</td><td>-31.0</td><td>-17.0</td><td>-31.0</td><td>-17.0</td></tr><tr><td>14</td><td>RX HUM & NOISE</td><td>dB</td><td></td><td></td><td></td><td>-32.0</td><td></td></tr><tr><td>15</td><td>RX DISTORTION</td><td>%</td><td></td><td>4.0</td><td></td><td>5.0</td><td></td></tr><tr><td rowspan="2">16</td><td rowspan="2">RX 12dB SINAD (INPUT 8kHz DEV. 1kHz)</td><td rowspan="2">dBm</td><td></td><td></td><td>-116.0</td><td></td><td>-20 TO +50 DEG.C</td></tr><tr><td></td><td></td><td>-113.0</td><td></td><td>-30 TO +60 DEG.C</td></tr><tr><td>17</td><td>RX SINAD @ -116dBm</td><td>dB</td><td>12.0</td><td></td><td></td><td></td><td>INPUT 8kHz DEV. 1kHz</td></tr><tr><td>18</td><td>I.M.D</td><td>dB</td><td></td><td></td><td>65.0</td><td></td><td>+/-60&120Hz</td></tr><tr><td>19</td><td>SPURIOUS INTERFERENCE</td><td>dB</td><td></td><td></td><td>60.0</td><td></td><td></td></tr><tr><td>20</td><td>CONDUCTED SPURIOUS EMISSION</td><td>dBm</td><td></td><td></td><td></td><td>-47.0</td><td></td></tr><tr><td>21</td><td>ADJACENT CHANNEL DESENSITIZATION</td><td>dB</td><td></td><td></td><td>16.0</td><td></td><td></td></tr><tr><td>22</td><td>ALTERNATE CHANNEL DESENSITIZATION</td><td>dB</td><td></td><td></td><td>60.0</td><td></td><td></td></tr><tr><td>23</td><td>STBY CURRENT</td><td>mA</td><td></td><td>0.1</td><td></td><td>0.1</td><td>DC 5.50V+/-0.1V</td></tr><tr><td>24</td><td>TALK CURRENT</td><td>mA</td><td></td><td>700</td><td></td><td>730</td><td>DC 5.50V+/-0.1V ch=383</td></tr><tr><td>25</td><td>SIREN SOUND LEVEL</td><td>dBspl</td><td></td><td></td><td>90</td><td></td><td>at 100cm, A Range</td></tr></tbody></table>													FOR LINE		FOR BUYER'S			No.	DESCRIPTION	UNIT	MIN.	MAX.	MIN.	MAX.	NOTE	11	CARRIER ON STATE	dBm				-60.0		12	CONDUCTED SPURIOUS EMISSION	dB				-40.7		13	RX AUDIO FREQ	300Hz	9.0	23.0	9.0	23.0	REFERENCE 1 kHz	RESPONSE	3kHz	-31.0	-17.0	-31.0	-17.0	14	RX HUM & NOISE	dB				-32.0		15	RX DISTORTION	%		4.0		5.0		16	RX 12dB SINAD (INPUT 8kHz DEV. 1kHz)	dBm			-116.0		-20 TO +50 DEG.C			-113.0		-30 TO +60 DEG.C	17	RX SINAD @ -116dBm	dB	12.0				INPUT 8kHz DEV. 1kHz	18	I.M.D	dB			65.0		+/-60&120Hz	19	SPURIOUS INTERFERENCE	dB			60.0			20	CONDUCTED SPURIOUS EMISSION	dBm				-47.0		21	ADJACENT CHANNEL DESENSITIZATION	dB			16.0			22	ALTERNATE CHANNEL DESENSITIZATION	dB			60.0			23	STBY CURRENT	mA		0.1		0.1	DC 5.50V+/-0.1V	24	TALK CURRENT	mA		700		730	DC 5.50V+/-0.1V ch=383	25	SIREN SOUND LEVEL	dBspl			90		at 100cm, A Range
			FOR LINE		FOR BUYER'S																																																																																																																																																							
No.	DESCRIPTION	UNIT	MIN.	MAX.	MIN.	MAX.	NOTE																																																																																																																																																					
11	CARRIER ON STATE	dBm				-60.0																																																																																																																																																						
12	CONDUCTED SPURIOUS EMISSION	dB				-40.7																																																																																																																																																						
13	RX AUDIO FREQ	300Hz	9.0	23.0	9.0	23.0	REFERENCE 1 kHz																																																																																																																																																					
	RESPONSE	3kHz	-31.0	-17.0	-31.0	-17.0																																																																																																																																																						
14	RX HUM & NOISE	dB				-32.0																																																																																																																																																						
15	RX DISTORTION	%		4.0		5.0																																																																																																																																																						
16	RX 12dB SINAD (INPUT 8kHz DEV. 1kHz)	dBm			-116.0		-20 TO +50 DEG.C																																																																																																																																																					
					-113.0		-30 TO +60 DEG.C																																																																																																																																																					
17	RX SINAD @ -116dBm	dB	12.0				INPUT 8kHz DEV. 1kHz																																																																																																																																																					
18	I.M.D	dB			65.0		+/-60&120Hz																																																																																																																																																					
19	SPURIOUS INTERFERENCE	dB			60.0																																																																																																																																																							
20	CONDUCTED SPURIOUS EMISSION	dBm				-47.0																																																																																																																																																						
21	ADJACENT CHANNEL DESENSITIZATION	dB			16.0																																																																																																																																																							
22	ALTERNATE CHANNEL DESENSITIZATION	dB			60.0																																																																																																																																																							
23	STBY CURRENT	mA		0.1		0.1	DC 5.50V+/-0.1V																																																																																																																																																					
24	TALK CURRENT	mA		700		730	DC 5.50V+/-0.1V ch=383																																																																																																																																																					
25	SIREN SOUND LEVEL	dBspl			90		at 100cm, A Range																																																																																																																																																					