说明书规格描述

工艺: 风琴折 材质: 80g哑粉

颜色: Pantone 286C 专色加单黑印刷

尺寸: 129*54mm

FreeYond



Charge the smartwatch to activate it before first use.





Press and hold the power button on the side to power on.



Download The App

Scan the QR code to download FY Watch (Android) or FY Fit (iOS).

Click "ADD DEVICE" in APP to add the device: 1. Scan the QR code on the watch screen; 2. Search the watch Bluetooth for pairing.



Set Up And Pair

- Swipe On Home Screen Shortcuts and settings
- Notifications
- Fitness data, weather and music control



Power On: Press and hold till screen lights up; Power Off: Press and hold and choose Power Off;

Home Button:

Wake the Watch: Press once;

Back to Home Screen: Press once.



To charge the watch, place the watch flat and make sure that the two metal holes on the back are aligned with the metal tip of the charging head.

Charging



to the watch.

Change Straps

Slide the spring pin and hold it to remove a strap from the watch or attach a strap

received, including interference that may cause undesired operation.

the following measures:

-Reorient or relocate the receiving antenna.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) this device must accept any interference

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

-Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is

-Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Input rating: 5V=0.2A Sensor: 3-axis acceleration sensor, HRM and SpO2 sensor Battery capacity: 260mAh

Parameters

Resolution: 240*240 pixels Display: 1.39 inch TFT Operating temperature: 0°C ~ 45°C Operating frequency: 2402MHz ~ 2480MHz Bluetooth transmit power: ≤ 8dBm

Sync mode: Bluetooth 5.2

Product Name: Smart Watch Model: 2308003W

Ingress protection level: IP68

FCC ID: 2A8FE-WS1A

Contents

Smart Watch Charging Cable User Manual

Certification

notice.

Important Information:

Please read the instructions before use:

Some features may vary in different software versions.

1. The product should be charged for more than 2 hours before use, but avoid prolonged charging.
2. Please use a charger of 5V/1A or 5V/2A along with the original charging cable from

 \bullet The Company reserves the right to change the terms and conditions without prior

Thank you for purchasing FreeYond products. If any manufacturing defect problems occur within 12 months from the date of purchase, user can enjoy our company's warranty service.

1. When you buy the product, the sales unit will issue a valid proof of purchase.
2. The warranty card and the proof of purchase should be kept by the user properly, and it will not be

- replaced if lost. If the product fails due to non-human factors, the user can present the warranty card and proof of purchase to any FreeYond customer service centres for free maintenance during the warranty period.
- Non-warranty Situation: This warranty does not cover the following cases:

 1. Out of warranty period.

 2. Damage caused by use not in accordance with the instructions.

 3. Damage caused by man-made causes.

 4. Failure caused by unauthorized disassembly, maintenance, or modification of the product.

 5. Damage caused by force majeure factors (such as floods, earthquakes, lightning, etc.).

 6. There is no warranty card, invoice, or warranty card that does not match the invoice information.

 7. The product wears naturally.

 8. Other failures and damages that are not caused by the quality of the product itself.

Website: www.ifreeyond.com

Warranty Card (Stub Copy) Dear user, thank you for using the product of our company. Please read and keep the warranty card properly after purchasing the product so that we can provide better services to you.

User Information Sales Information User's Name _ Purchase Date _ Phone Number___ __ Invoice Number _

Address Product Information Product Model. Product Serial Number _

Phone Number_

Sales Information

Dear user, thank you for using the product of our company.
Please read and keep the warranty card properly after purchasing the product so that we can provide better services to you. User Information User's Name_

Warranty Card (Customer Copy)

Purchase Date . Phone Number___ Invoice Number _ Phone Number___ Address _ Product Information Product Model __

Warnings

- 1. Using an incorrect type of battery that can bypass safety measures during replacement. (for example, in the case of some lithium battery types);
 2. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;

 3. Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;

 4. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.



User Guide