

ALPS

CONTENTS

1. PREFACE	2
2. PASSIVE ACCESS ENTRY FUNCTIONALITY	3
2.1. Door Unlocking.....	3
2.2. Engine Start.....	4
2.3. Engine Stop.....	4
2.4. Door Locking (Push switch)	5
3. ACTIVE ACCESS ENTRY FUNCTIONALITY	6
3.1. Door Unlocking.....	6
3.2. Engine Start.....	6
3.3. Engine Stop.....	6
3.4. Door Locking	6
4. SYSTEM CHARACTERISTICS.....	7
4.1. Antenna Areas	7
4.2. Exciter Locations.....	8
4.3. Switch Input Locations (Door handle, Touch sensor)	9

**FCC WARNING
NOTICE**

ALPS

1. Preface

This document describes the requirements and operation of the Passive Entry System. However, this document is especially for the Entry system ECU (acronym for Electric Control Unit) and the FOB.

The FOB consists the following functionality for passive access and active access:

- Door unlocking / locking (however, only for request by means of switch operation)
- Trunk unlocking / locking (however, only for request by means of switch operation)
- LF decoding
- RF encoding
- Communication data encryption (cryptograph, anti-collision, rolling code and stuff)

And the entry system ECU consists of the following functionality:

- Door unlocking / locking
- Trunk unlocking / locking
- Engine start (/ stop)
- LF encoding
- RF encoding
- Communication data encryption (cryptograph, anti-collision, rolling code and stuff)
- LF antenna unit control
- Communication with the node ECUs connected to the body bus (e.g. CAN, J1850, customer dependent bus)

As a further function, both the FOB and the entry system ECU provides the following function:

- Learning mode for programming the manufacturing data and stuff
- Data locking and password protection
- Diagnostic (based upon ISO9141 if required)

ALPS

2.Passive Access Entry Functionality

A proximity sensor located on, for example the door handles, mirrors and trunk lid will be used for proximity check if user is in neighborhood of the vehicle. The switch input will trigger for unlocking and open the doors and trunk.



Figure 1

2.1.Door Unlocking

- User pull / touch the door handle (sensing of door handle switch).
- ECU sends LF-challenge via exterior antenna.
- FOB sends RF-response to the ECU.
- Door unlocking status is engaged.
- Doors are opened.




Figure 2

ALPS

2.2.Engine Start

- User pushes / operate the engine start button / knob.
- ECU sends LF-challenge via interior antenna.
- FOB sends RF-response to the ECU.
- Immobilizer ECU receives and authorizes the response.
- Engine controller ECU receives the authorization for engine start.
- Start the engine.




Figure 3

2.3.Engine Stop

- User pushes / operate the engine stop button / knob.
- ECU communicates with the other ECU for engine start request.
- Engine controller ECU receives the request.
- Stop the engine



Figure 4

ALPS

2.4.Door Locking (Push switch)

- User closes the door and pushes the switch (sensing of door locking switch).
- ECU sends LF-challenge via exterior antenna.
- FOB sends RF-response to the ECU.
- Door locking status is engaged.
- Doors are locked.
- (Indicates the door locking status by means of Flasher / Buzzer or stuff)



Figure 5

ALPS

3.Active Access Entry Functionality

3.1.Door Unlocking

Same functionality as the current one.

3.2.Engine Start

This function does not effect on the active entry system.

3.3.Engine Stop

This function does not have influence on the active entry system.

3.4.Door Locking

Same functionality as the current one.

ALPS

4. System Characteristics

4.1. Antenna Areas

Exterior operating range: 0.8m to 1.5m
Interior operating range: Only inside the car

Number of the exterior exciters: max. 5 (min. 2), however, it is depending on the type of the vehicle.
Number of the interior exciters: 1 (1-Dimension) or 2 (2-Dimension required)




Figure 6

Exterior antenna functionality:

- Unlock / lock doors and trunk.
- Activate / deactivate alarm system.
- Activate immobilizer

Interior antenna functionality:

- Deactivate immobilizer
- Engine start

ALPS

4.2.Exciter Locations

Exterior exciters: 2 doors and 1 trunk
Interior exciters: 1 driver's seat
2 column / shift lever (X-Y 2-Dimension)




Figure 7

Antenna location can be different among of type of the vehicle (e.g. coupe, sedan, mini and stuff).

ALPS

4.3.Switch Input Locations (Door handle, Touch sensor)

There are some kind of sensors, for instance the door handle contact switch and touch sensor, will be used as a triggering for unlocking and open the door.

Switch inputs: 2 doors and 1 trunk




Figure 8

Switch inputs can be different among of type of the vehicle (e.g. coupe, sedan, mini and stuff).

ALPS

- FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.