

Doorbell



User Manual

EN


- Doorbell Receiver x 1
- Push Button x 1
- User Manual x 1
- Double-sided Tape x 1
- Screw x 2
- Luminous Signs Card x 1

① Volume Setup Button ④ LED Light
② Previous Tune ⑤ Push Button
③ Next Tune ⑥ Detach the Battery Cover Here

Input Voltage: AC100-240V 50/60Hz
Power consumption: 1.5 W

Battery:	DC 3V (CR2032 x1)
Working Current:	17mA
Transmission Power:	10dBm

1. Remove the battery isolation strip on the back of the push button before use.
2. Use the included double-sided tape to stick the push button to the wall.



1. Press the Volume Setup Button to switch between 5 volume levels (mute - max volume). Press and hold the Volume Setup Button for over 3 seconds to turn the LED light mode on or off.
2. Press the Next Tune or Previous Tune button to select a doorbell tune.

- 3.1. Select your favorite tune.
- 3.2. Press and hold the Previous Tune button for at least 3 seconds until the LED light turns on.
- 3.3. Press the Push Button once, and the receiver will beep. Wait for the LED light to go out and the pairing is complete.

4. Press and hold the Next Tune button for at least 3 seconds until the LED light turns on. Wait for the light to turn off, and the pairing record is cleared.

5. There is a prompt tone when the receiver is plugged in for the first time. This indicates the power is on.

6. Indicator light: The light will flash while the tune is playing on the receiver. The LED light on the push button will light up when it is pushed.

1. **RETAIN THESE INSTRUCTIONS** - This sheet contains important safety and operating instructions.
2. Before using the product, read **all** instructions and caution markings on the product, accessories, and device.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, **unless** they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
4. Children should be supervised to ensure that they do not **play** with the appliance.
5. Keep the product away from the fire to avoid an explosion.
6. For proper insertion, please observe **polarity** indicators (+/-).
7. Do not **place** the product in or near an inflammable, explosive, or hazardous object.
8. Do not operate the product with a damaged cord or plug.
9. Do not operate the product if it has been damaged in any way.
10. Do not disassemble the product. Disassembly may result in a risk of safety hazards.
11. Do not throw or shake the product.
12. Do not **place** the product in or near water, rain, excess moisture, or extreme heat.

Shenzhen Unichain Technology Co., LTD. (Manufacturer: "Unichain") warrants to the original purchaser of this TECKNET product that the product shall be free of defects in design, assembly, material, or workmanship.

Unichain warrants the TECKNET product for **12 Months**.

Unichain will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

All above warranties are null and void if the TECKNET product is not provided to Unichain for inspection upon Unichain's request at the sole expense of the purchaser, or if Unichain determines that the TECKNET product has been improperly installed, altered in any way, or tampered with. The TECKNET Product Warranty does not protect against acts of God such as flood, earthquake, lightning, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (e.g. brownouts or sags), non-authorized program, or system equipment modification or alteration.



Please contact retailers or visit TECKNET website or email support@tecknetonline.com for more information. To extend the warranty period, please visit TECKNET website and register your TECKNET products within **90 days** of purchase.

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned herein.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television

(Waste Electrical & Electronic Equipment)



This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household use should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Hereby, Shenzhen Unichain Technology Co., Ltd. declares that the product type TK-WD006 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
<https://eu.tecknetonline.com/>

红色是刀模线,无需印刷)

正面

反面

