

Chapter		
1	Precautions	5
1.1	Overview	5
1.2	Limitation	5
1.3	Danger in Use	5
1.4	Laser	8
2	Preparation	12
2.1	Storage	12
2.2	Setup	12
2.3	Battery	14
2.4	Tribrach	15
2.5	Power On	16
2.6	Registration Code	17
2.7	Calibrate APR+Prism Search	18
3	Introduction	20
3.1	Instrument Components	20
3.2	Keys	21
7	Station	36

3.3	Screen	21
3.4	Tool Bar(Quick Access)	22
3.5	Abbreviation	23
3.6	Star Key	24
3.7	Hot Keys	25
4	Menu	26
5	Job	27
5.1	Creating a New Job	27
5.2	Editing a Job	28
6	Measure	29
6.1	Measure	28
6.2	Prism Search	30
6.3	APR	31
6.4	LocknTRack	32
6.5	File	33
6.6	Point Stake Out	34
6.7	Graph	35
8.9	Sag Measure	58

7.1	Known Point	36	8.10	Traverse	62
7.2	Multiple Orient	37	8.11	Cable Height	71
7.3	Height Transfer	39	8.12	Point Projection	72
7.4	Backsight Check	40	9 Stake Out		75
7.5	Resection	41	9.1	Overview	75
7.6	Point to Line	43	9.2	Point	78
7.7	Free Station	44	9.3	CAD Stake Out	80
7.8	Station Setup without CP	46	9.4	Angle&Distance	85
8 Collect		48	9.5	Direction Line	86
8.1	Point	48	9.6	Line	87
8.2	Distance Offset	49	9.7	Reference Line	88
8.3	Plane Offset	51	9.8	Arc	92
8.4	Column Offset	52	10 Data Management		96
8.5	REM	53	10.1	Point Management	96
8.6	MLM	55	10.2	Code Management	100
8.7	Line & Extend Point	56	10.3	Q-Code Management	101
8.8	Line & Extend Angle	57	10.4	Map Management	102
10.5	Import Data	103	13 Setting		134

10.6	Export & Copy Data	107		
11	COGO	113	14	Inspection & Adjustment 137
11.1	Reduction	114	14.1	Plate Vial 137
11.2	Traverse Adjustment	115	14.2	Circular Vial 138
11.3	Calc.XYZ	115	14.3	Tilt-Sensor 138
11.4	Inverse	117	14.4	Reticle Unit 139
11.5	Area & Girth	118	14.5	2C 140
11.6	Included Angle	119	14.6	Horizontal Axis 141
11.7	Distance Conversion	120	14.7	Vertical Index 142
11.8	Angle Conversion	120	14.8	Vertical 0 (I - Angle) 142
11.9	Average	121	14.9	Combined Adjustment 144
11.10	Equidistant Point	121	14.10	Constant K 144
11.11	Triangle Calculation	122	14.11	Sight of View& Emitting Axis 145
11.12	Calculator	123	14.12	Adjustment for APR+PS 146
12	Road	124		Appendix A. Menu Tree 147
12.1	Road Design	124		Appendix B. Data Format 148
12.2	Road Stake Out	131		Appendix C. Traverse Level 151
Appendix D. Comm Port		152		Appendix E. Specification 154

Copyright. South Surveying and Mapping Technology CO.,LTD all right reserved.

1. PRECAUTIONS

1.1 OVERVIEW

Congratulations on the purchase of SOUTH NS30 Total Station!

The following safety instructions specify the responsibilities of the product owner and user.

The product owner must ensure that all users of the instrument know and follow these regulations or instructions.

1.2 LIMITATION

Environment	The environmental conditions of the instrument are similar to those that people can adapt to: it is not suitable for corrosive, flammable and explosive occasions.
Danger	When working in dangerous areas, or any areas close to electric devices, the user must ask for local safety authority in advance.

1.3 DANGER IN USE

Caution	After the instrument is collided, re-assembled, stored for a long time and transported, please check and calibrate the equipment.
----------------	---

Prevention:

Check the instrument regularly according to the instructions in the user manual, especially before and after the important measurement tasks.

Danger

It is very dangerous to use prism pole near the electrical equipment such as electrified cables or electrified railways.

Prevention:

Keep a safe distance from power facilities. If you must work in this environment, please contact the safety department responsible for these electrical equipment and follow their instructions.

Caution

If the instrument is used to observe the sun directly, the eyes and optical system might be damaged because of the magnifying effect.

Prevention:

Don't aim the telescope directly at the sun without a sun filter.

Warning

In measurement, if users do not pay attention to the surrounding conditions, there will be a risk of accidents, such as obstacles, or traffic vehicles in the setting out process.

Prevention:

The product owner must ensure that all the users are aware of possible hazards.

Warning

If the survey site does not have enough safety facilities and signs, it may cause

dangerous situations.

Prevention:

Always ensure the safety of the work site. Always check the safety and accident prevention regulations and traffic rules.

Caution

If the accessories are not firmly connected to the instrument, it might be damaged.

Prevention:

When installing the instrument, ensure that the accessories are correctly, properly and safely fixed in place.

Warning

If the instrument is used with accessories, such as centering rod, the risk of lightning stroke will be increased.

Prevention:

Do not survey in the field under thunderstorm days.

Caution

During the transportation of battery, the improper mechanical influence may cause fire.

Prevention:

Discharge the battery before transportation.

During battery transportation, the product owner must comply with domestic and international regulations and guidelines.

Warning	Strong mechanical pressure, high temperature or falling into liquid may cause battery leakage, fire or explosion. Prevention: Protect the battery from mechanical impact and high temperature environment. Do not drop the battery or immerse the battery in liquid.
Warning	If the battery is short circuited, such as touching jewelry, keys, metal pieces or metal, the battery may be overheated and damaged or catch fire, such as when the battery is put in a pocket. Prevention: Make sure that the battery end is not in contact with metal objects
Warning	Only the distributor who authorized by South is qualified to repair the products.

1.4 LASER

Warning	The EDM rangefinder built in the total station will emit a visible red laser through the objective lens. which is identified by the following signs: A warning label "LASER 3R" is attached above the vertical tangent screw, and the same label is attached on the opposite side.
----------------	---

This product belongs to Class 3R laser product, according to the standards

GB7247.1-2012: Safety of Laser Products.

Warning

From the perspective of safety, Class 3R laser products are potentially dangerous.

Prevention:

- 1) Avoid direct eye contact with the laser beam.
- 2) Do not irradiate others with laser beam.

Warning

The potential safety is not only the direct viewing laser beam, but also the laser beam reflected by prism, window, mirror and metal surface.

Prevention:

- 1) Do not aim at objects that reflect strongly, such as mirrors, or objects that emit unnecessary reflected light.
- 2) When the laser is turned on and in the laser aiming or distance measurement mode, do not look at the laser beam near to the target. The prism can only be aimed through the telescope of the total station.

Warning

It is dangerous to use Class 3R laser equipment incorrectly.

Prevention:

The user should take effective safety precautions and control the possible danger within the distance (according to GB7247.1-2012).

Class 3R

Class 3R laser products are used outdoors and on construction sites (surveying, alignment, leveling)

A. Only trained and certified personnel can install, commission and operate the laser equipment.

B. Set up laser warning signs within the operation area.

C. Prevent directly looking at the laser beam with eyes or using optical instruments to watch the laser beam.

D. In order to prevent the damage, the laser beam shall be blocked at the end of the working route. When the laser beam passes through the restricted area (in harmful distance*) or when someone is moving in this area, the laser must be stopped.

E. The path of the laser beam must be set above or below the line of sight of people.

F. When the laser product is not in use, it shall be properly kept and stored.

G. Prevent the laser beam reflected from the mirror, metal, window, etc.

*Harmful distance refers to the maximum distance from the starting point of the laser beam to the point where the laser beam weakens without harm.

A built-in rangefinder product equipped with a Class 3R laser has a harmful distance of 1000m (3300ft). Beyond this distance, the laser intensity will be reduced to Class 1 (It won't be harmful directly to the eyes).

Description	Value			
	Auto Prism Following	Auto Search	Laser Plummet	EDM
Wavelength	785nm	905nm	635nm	635nm
Max. Radiant Power	6mW	3.5mW	3.5mW	6.5mW
Divergence Angle	± 1.5°	± 17°	1mrad	0.4mrad
Transmission Frequency	Continuous Laser		Continuous Laser	
Half-peak Width of Transmitting Pulses				
Pulse Repetition Rate				

2. PREPARATION

2.1 STORAGE

Unpacking

Lay down the case lightly with the cover upward.
Unlock the case, and take out the instrument.

Storage of Instrument

Cover the cap, put the instrument into the case with the vertical clamp screw and circular bubble to the upwards (lens towards tribrach).

2.2 SETUP

Setting up the tripod

- A. Loosen the screws on the tripod legs, pull out to the required length and tighten the screws.
- B. Make the center of tripod and the occupied point approximately on the same plumb line.
- C. Step on the tripod to make sure if it is well stationed on the ground.

Instrument setup (with Laser Plummets)


- A. Place and lock the instrument carefully on the tripod
- B. Turn on the instrument and activate the laser plummet. Hold the two legs which are not fixed

on the ground and decide the position to fix according to the laser dot. When the laser dot is roughly on the station point, fix those 2 legs.

C. Leveling the instrument by circular vial.

a) Rotate the foot-screw A and B to move the bubble in the circular vial, in which case the bubble is located on a line perpendicular to a line running through the centers of the two leveling screw being adjusted .

b) Rotate the foot-screw C to move the bubble to the center of the circular vial.




D. Precisely leveling by plate vial

a) Rotate the instrument horizontally by loosening the horizontal clamp unit and place

the plate vial parallel to the line connecting rotating the foot-screw A and B, and then bring the bubble to the center of the plate vial by rotating the foot-screw A and B.

b) Rotate the instrument in 90° (100gon) around its vertical axis and turn the remaining leveling screw or leveling C to center the bubble once more.

c) Repeat the steps and check whether the bubble is correctly centered in all directions.



If the laser dot doesn't stay at the center position, please slightly loosen the screw under the tripod head and move the instrument (don't rotate the instrument) until the laser dot is

on the station point. Tighten the screw and level the instrument again. Repeat these steps until

Electronic Bubble


To ensure a precise angle measurement, you can also level the instrument by E-bubble.

[Tilt-X]: Tilt compensation in X-direction

[Tilt-XY]: Tilt compensation in XY-direction.

[Tilt-Off]: Turn off the tilt sensor.

the instrument is precisely centered and leveled.



2.3 BATTERY

Initial Use/Charging

The battery should be charged only by the official charger NC-10. The battery must be charged before the first time operation.

Indicator: Red - Charging;

Green - Completed;

Green Flashes - Error

Input: 70V-240V 50/60Hz;

Output: 7.4V-1.2A)

The allowable charging temperature range is 0 °C to +40 °C . For optimum charging, we recommend charging the battery at +10 °C to +20 °C .

It is normal for the battery to become hot during charging. If the temperature is too high, the

charger will not work.

For new batteries or batteries that have not been used for a long time (over three months), it will be more effective to have a complete charge and discharge before the work.

Remained Capacity

When the remaining voltage is less than one grid, please stop your operation and charge it as soon as possible.

Working time depends on the environmental conditions, such as ambient temperature, charging times. For safety reasons, please charge in advance or prepare some backup batteries.

The remaining capacity is related to the current measurement mode. In angle measurement mode, the capacity is sufficient, which cannot ensure that the battery can also be used in distance measurement mode.


2.4 TRIBRACH

Dismounting

Turn the locking knob in 180° counter-clockwise to disengage anchor jaws, and take off the instrument.

Mounting

Insert three anchor jaws into holes of tribrach and



line up the directing stub. Turn the locking knob about 180° clockwise to mounting the instrument.

2.5 POWER ON

Power On

Press and hold the power key in 2 seconds until the screen lights up.


Power Off

Press and hold the power key in 1 seconds until the shut down menu pops up. Please keep the normal shut down steps to avoid the data lost.

2.6 REGISTRATION CODE

2.6.1 Check the Status in TServer.

Description	Before working, the user needs to check whether the device connection in the TServer App is correct and whether the registration time has expired or not.
Access	Select [TServer] : [Connect] or [Disconnect] ; [Settings]\[Register]
Registration Status	



- If the instrument is blocked, please reconnect the TServer.
- Do not change the settings without authorization.
- If the angle value is not displayed, or the value does not change when the instrument is rotated, the registration code might be expired.

-
- If the laser pointer and plummet can not be activated, the problem might be caused by register code, too.
-

2.6.2 Registration Code


Description

Registration code for Survey Star onboard.

Access

- Auto: Connect 4G/WIFI network, select **[TServer]** for auto registration.
 - Manual: **[TServer]\[Setting]\[Register]\Input codes\[Register]**
-

Registration Code



2.7 CALIBRATION FOR APR + Prism Search

Description

When calibrating and compensating the absolute position error of the instrument, the coordinate transforming between the measuring system and the

instrument basic system should be considered.

In order to solve this problem, the instrument will calculate the absolute position accuracy by the distance accuracy between 2 points, which will largely simplify the measure steps.

Access

Select **[TServer]: [Setting] \ [Initial Set] \ [Calibration]**

Calibration Step-by-Step

4:47

< Calibration



HA	VA
Hz Parameter	Vt Parameter
Hz Parameter please enter HA parameter	Vt Parameter please enter VA parameter

Enter Calibration Mode Input Parameter Enter Laser debug mode

Steps	Description
1.	Set and aim a prism at 35-50m.
2.	Press [Enter Calibration Mode] , waiting for the parameters in horizontal and vertical direction.
3.	Type the parameters in [Hz Parameter] and [Vz Parameter] , the value is valid in 5 digits.
4.	Press [Input Parameter] in 3 times to ensure the data is written.
5.	Restart the program to activate the functions

3. INTRODUCTION

3.1 INSTRUMENT COMPONENTS



- a) Antenna
- b) Handle
- c) Collimator
- d) Central Mark
- e) Function Keys
- f) Endless Drive (Horizontal)
- g) Eyepiece Unit
- h) Plate Vial
- i) USB/Card Slot
- j) Circular Vial
- k) Auto Search Window
- l) Objective Lens
- m) Endless Drive (Vertical)
- n) Battery
- o) Display Unit


3.2 KEYS

Key	Description
1-9 / . / -	Numeric keys, which can be defined by user.
BS	Backspace

21

Key	Description
F _n	Function key, which can be defined by user.
	Sub-menu

3.3 SCREEN



The screen of **NS30** is separate into four parts:

- a) Status bar (e.g. time, setting, download, location, WIFI connection, battery.)
- b) Quick access
- c) Measure mode (e.g. mode, target, tilt sensor)
- d) Current job
- e) Main menu

3.4 TOOL BAR (QUICK ACCESS)

Icons	Description
	Quick access to star key.
	Quick access to data manage.
	Quick access to measure mode (Single/N Times/Continuous/ Tracking)

3.5 ABBREVIATION

Icon	Description
V/VA	Vertical angle
V%	Vertical angle (%)
HL/HR	Horizontal left/ right
SD	Slope distance

Icon	Description
STN	Station
BS	Backsight
R.Ht	Reflector height
Ins.Ht	Instrument height

3.6 STAR KEY

Description	Star keys provide a quick access to the settings and functions of total station
Access	1) Select [Survey Star]: [★] 2) Slide the left edge of the screen to the right

Star Keys

Key	Description
1.Laser Pointer	Open the laser pointer.
2.Reticle Backlight	Open the reticle (crosshair) backlight in telescope.
3.Laser Plummet	Open the laser plummet.
4.Temp.&Pressure	Set temperature, pressure, PPM. 20 °C /1013hPa in default.
5.Prism Constant	Set prism constant, -30.0mm in default.
6.Face 2	Turn and aim the target in the second face.
7.Prism Search	Activate the Prism Search.
8.APR	Activate the Auto Prism Recognition in sight of view
9.LocknTRack	Activate the LocknTRack.
10.Demo Mode	Enter the demo mode to simulate the data.

3.7 HOT KEYS

Description

Hot keys provide a shortcut to user-defined functions or applications assigned to the keys.

Access


Select **[Survey Star]: [Setting]\[Function Key]**\Select the keys

Hot Keys

Key	Description
Measure Button	Measure / all (measure + save)
Fn	Undefined / laser pointer / reticle / laser plummet / soft-keypad
[0]-[9], [.), [-]	Undefined / laser pointer / reticle / laser plummet / known point / free station / point / point stake out.

4. MAIN MENU

Main Menu



Description

Main Menu	Description
Measure	To simply survey, select and stake out a point with graphics.
Station	To setup the station before works.
Collect	To collect a point, as well as select and start an application.
Stake Out	To stake out a point.
Job	To manage job.
COGO	To start a coordinated geometry application.
Program	To design and stake out a road.
Setting	To make settings regarding the software and the display unit


5. JOB

5.1 CREATING A NEW JOB

Access

Select Main Menu:[Job]\[+]\Enter the job name, operator, time\[Done]

Create a new job

A screenshot of a mobile application interface for creating a new job. The screen has a dark header with a back arrow and the text '< New'. Below the header, there are four input fields: 'Job:' with the value '20230113-1', 'Time:' with the value '2023-01-13 17:14:33', 'Operator:' which is empty, and 'Note:' with the value 'V 2.00.221226'. A brown 'Done' button is located to the right of the 'Note' field. The status bar at the top shows signal strength, Wi-Fi, and the time 5:14.


Keys	Descriptions
Job	A unique name for a new job.
Time	Display only. Time and date.
Operator	Editable field. Operator's name.
Note	Editable field. The software version is filled.

5.2 EDITING A JOB

Access

Select Main Menu:[Job]\Select a job\[Open], [Delete] or [View]

Edit a new job



Keys	Descriptions
[Open]	Open the selected job.
[Delete]	Delete the selected job.
[View Info]	Check the job properties. Includes job name, storage location, time, operator and note.

6. MEASURE

6.1 MEASURE

Description

[Measure] is used for point measurement.

Access

Select Main Menu: [Measure] \ {Meas.} Page \ [Meas.] \ [Save]

Measure Page

Meas.	File	Point S.O	Graph
V:	050°00'19"	HR:	315°25'51"
N:	1.158 m	SD:	2.123 m
E:	-1.142 m	HD:	1.627 m
Z:	1.365 m	VD:	1.365 m

Buttons: 0 Set/H Set, In Ht/ R. Ht, STN setup, Meas., Save

Key	Description
0 Set/ H Set	Set the current horizontal angle to 0 or a certain value.
In Ht/ R. Ht	Set the instrument height and reflector height.
STN Setup	Setup the station by two known points.
Meas.	Measure
Save	Save the data with point name and code.


6.2 PRISM SEARCH

Description

When Prism Search is activated, the station starts to rotate 360 degrees around the vertical axis in anti-clockwise direction.

Then, the automatic prism search in the vertical direction ($\pm 18^\circ$) is performed.

The transmitter (a) emits a laser beam in vertical direction, and if the laser swatch is detected by the receiver (b), the rotation will stop immediately. Otherwise, it will stop after a full-360 degree rotation.



Access

- 1) Press **[★]** or slide from the left, activate **[6. Prism Search]**
- 2) Back to the measure page, press **[Meas]** to start searching.
- 3) When Prism Search is activated, the icon  shows on the status bar.



6.3 APR - AUTO PRISM RECOGNITION

Description

APR (Auto Prism Recognition) is used to recognize and measure the prism automatically in the sight of view (± 1.5 degrees).

The automatic aiming window will scan the prism from the center of the current telescope position, in anti-clockwise direction.

If the prism is founded, the crosshair will automatically positioned to the prism center.



Access

- 1) Press **[★]** or slide from the left, activate the **[7. APR]**
 - 2) Back to the measure page, press **[Meas]** to start recognition.
 - 3) When APR is activated, the icon[] shows on the status bar.
-

6.4 FOLLOW THE MOVING PRISM - LOCKNTRACK

Description

LocknTRack enables an automatic prism recognition and lock to a moving prism.

Eliminating the need for standing around and waiting when data collect or stake out.

The first measurement should be stable fixed on the ground, otherwise, the prism might not be successfully locked.

The lock may be lost if the movement of prism is too fast or invisible in the sight.

Access

- 1) Press **[★]** or slide from the left, activate the **[9. LocknTRack]**
 - 2) Back to the measure page, press **[Meas]** to activate LocknTRack mode.
 - 3) If the prism is successfully locked, the icon [] shows on the status bar.
 - 4) If it is unlocked, the icon [] shows. Press **[Meas]** again to re-lock the prism.
-

6.5 FILE


Description

Select the point from the other files.

Access

Select Main Menu: **[Measure]**\{File} Page

File Page



Keys	Description
New	Create a new job.
Delete	Delete the selected job.
Current	Set the selected job as current job.
Send	Send data via MSMT.

Keys	Description
1st	First point.
Last	Last point.
Next	Next point.
Last Pt	Last point in the job.
Receive	Receive data via MSMT.

6.6 POINT STAKE-OUT

Description

Stake out points by coordinate, please refers to Chapter 9.2

Access

Select Main Menu: **[Measure]\{Point S.O}** Page

Stake Out Page

The screenshot shows the 'Measure' application interface for 'Point S.O.'. It features a circular diagram on the left with a blue arrow pointing to a point. On the right, there are input fields for 'Pt N:' (rd02), 'Pcode', 'N:' (1.275), 'E:' (-0.012), 'Z:' (1.372), and 'R.Ht:' (0.000). Buttons for 'Last', 'Next', 'Meas.', and 'Storage' are visible. The top bar shows the time 5:06 and various status icons.

Display	Description
E-Compass	Direction of the target
dHA	HA difference
Front/Back	Move to the front/back
Left/Right	Move to the left/right
Fill/Dig	Move to the up/down

Keys	Description
+	Add point
Last	Last point
Next	Next point
Meas.	Measure the prism
Storage	Save the point

6.7 GRAPH

Description


Graph is an interactive display feature embedded in Survey Star. It offers a graphical display of the survey elements with base map, which allows a better understanding of the measurement. Normally it will be loaded automatically.

Access

Select Main Menu: **[Measure]\{Graph}** page.

Use two fingers on the screen to zoom in or zoom out.

Graph Page



Keys	Description
	Change the layers screen. It is possible to make layers from the CAD file visible or invisible in map.
	Click to locate the current station to the center of screen.

7. STATION

7.1 KNOWN PT

Description

The coordinates of station point are required for setup. The instrument can be oriented by a known point, or an unknown point with assumed azimuth.

Access

1) Select Main Menu: **[Station]**\ **[Known Pt]**. Press **[+]** to select a station.

Step-by-step

2) Select orientation method: by known backsight point or by assumed azimuth.

3) Input instrument height and reflector height. Aim at the target, press **[Setting]**.

Known Point

Keys	Description
BS Pt	Select a known backsight point.
Azimuth	Select an assumed azimuth for orientation.

7.2 MULTIPLE ORIENT

Description

The instrument can be oriented by more than one backsight points.


Note: A maximum of 10 points can be measured and used for the calculation. This program is similar to Resection (Chapter 7.5), the difference is whether the coordinates of station is known or not. In multiple orientation, it's known.

Access

Step-by-step


- 1) Select Main Menu:[**Station**]\ [**Known Pt**]. Add a station point.
- 2) Click [**Multiple Orient**]\ [**Setting**] to enter the point list for multiple orient.
- 3) Press [**Meas.1st Pt**]\ [**+**]\ [**Angle**] or [**Ang.& Dist**] to measure the backsight.
- 4) Press [**Done**] to save it in point list. Repeat the steps for the others.
- 5) Press [**COGO**]\ [**Set**] to see the calculated station.

Multiple Orient





The screenshot shows the 'Multiple Orient' data entry screen. At the top, there are icons for back, home, and a menu. Below the title 'Multiple Orient', there are tabs for 'Meas.', 'Data', and 'Graph'. The 'Data' tab is active, displaying a table with four columns: 'No.', 'Item', 'N', and 'E'. The table contains four rows of data for points BBS1, BBS2, BBS3, and BBS4. At the bottom of the screen, there are two buttons: 'Meas. 6 Pt' and 'COGO'.

No.	Item	N	E
1	BBS1	23.115	113.192
2	BBS2	23.050	113.799
3	BBS3	23.005	114.397
4	BBS4	22.455	113.746



The screenshot shows the 'Multiple Orient' setting screen. At the top, there are icons for back, home, and a menu. Below the title 'Multiple Orient', there are three input fields: 'Pt N:' with a plus sign button, 'HR:' with the value '349°38'57"', and 'Angle' button. Below these are 'Ins.Ht:' with the value '0.000 m' and 'VA:' with the value '053°38'32"', and 'Ang.&Dist.' button. At the bottom are 'R.Ht' with the value '0.000 m' and 'SD:' with a blank space and 'm', and a 'Done' button.

Keys	Description
Meas.1 Pt	Measure the known points one by one (max.10 points).
COGO	Calculate the coordinate of station after measurements.
Angle	Measure angles only.
Ang. & Dist.	Measure angles and distances.
Done	Confirm the measurement.



Keys	Description
N/E/Z	Coordinates of station.
dHz	Difference of horizontal angle.
Height	Height of station.

Next Step

Height Transfer (Refers to Chapter 7.3) if necessary.

7.3 HEIGHT TRANSFER

Description

Calculate the station height by measuring a point with known height. Only the height of station will be updated.

Access

1) Select Main Menu:[Station]\[STN.Ht].

Step-by-step

2) Press **[+]**, input or select the height of known points, Ins.Ht, R.Ht.

3) Press **[Meas.]** and **[Setting]** to measure and update the height of station.

Height Transfer

The screenshot shows the 'STN.Ht' menu with the following data:

Field	Value	Unit
Height	1.378	m
Ins.Ht	1.500	m
R.Ht	1.000	m
VD	1.353	m
Calcu.Ht	-0.475	m
STN.Ht	0.004	m

Display	Description
VD	Vertical distance between the station and known point.
Calcu.H	Calculated height of station.
STN Ht	Updated height of station.

7.4 BACKSIGHT CHECK

Description

Check the residual of backsight after station setup.

Access

1) Select Main Menu:[**Station**]\[**BS Check**].

Step-by-step

2) Aim at the backsight, press [**Meas.**] to see the coordinate and difference.

3) Press [**Reset**] to set the current point as backsight.

Backsight Check

BS Check

STN Pt: 2

BS Pt: BBS6

Azimuth: 356°13'39"

HR: 356°13'39"

dHA: 000°00'00"

Meas.

Reset

Result

Coordinate	Difference
N: 22.872 m	dN: 0.002 m
E: 113.208 m	dE: 0.000 m
Z: 3.030 m	dZ: 0.001 m
	dSD: -0.002 m

Cancel

Reset

Display	Description
Azimuth	Azimuth of backsight
HR/HL	HA of measured point
dHA	Difference of HA

Display	Description
N/E/Z	Coordinate of target
dN/dE/dZ	Difference of coordinate
dSD	Difference of SD

7.5 RESECTION

Description

Resection is used to determine the instrument position from measurements of at least two known points (maximum 7 points). Only angles or both angles and distances can be measured.

The calculation requires at least three angle data or two distance data.


Access

1) Select Main Menu: **[Station]\[Resection]**

Step-by-step


- 2) Press **[Meas No.1 Pt]\[Angle][Ang.&Dist]\[Done]** to measure the known points
- 3) Press **[COGO]\[STN Setup]\[Stn Set]** to calculate and set the station.

Resection



Meas. No.	Data Item	N	E
1	pt01	1.756	-0.349
2	pt02	1.748	0.253
3	pt03	1.740	0.862

Meas. 4 Pt COGO



Pt N: pt01 + HR: 348°40'37.5" Angle

Ins.Ht: 1.500 m VA: 308°15'17.6" Ang.&Dist.

R.Ht: 1.000 m SD: 2.250 m Done

Display	Description
Meas.1 Pt	Measure the known points one by one (max. 7 points).

COGO	Calculate the coordinate of station after measurements.
Angle	Measure angles only.
Ang. & Dist.	Measure angles and distances.
Done	Confirm the measurement.

3:09

Resection

Meas. Data Graph

	Stn.Pt	Standard Deviation
N:	-0.018 m	dN: 0.000 m
E:	0.013 m	dE: 0.000 m
Z:	-0.011 m	dZ: 0.000 m

STN Setup

3:13

STN: stn01 Code: stn

N: -0.018 m

E: 0.013 m

Z: -0.011 m

Stn Set

Display	Description
N/E/Z	Calculated coordinates.
dN/dE/dZ	The difference between given and calculated coordinates.

Note: If the angles between the known points are too small or too large, the accuracy will be effected. The station height is calculated by the distance. If only angles are measured, the height will be determined by the angle of known points.

7.6 POINT TO LINE

Description

Point to Line can be used to calculate the local coordinates for the station. The result is calculated from distance and angle measurements of two target points (A and B). Point A will be defined as the origin point, while point B will be defined as North direction.

Access

1) Select Main Menu: **[Station]\[Point to Line]**.

Step-by-step

2) Press **[Meas.] \[Meas.]** to measure point A and point B.

3) Press **[Next]\[Next]\[Stn Set]** to calculate and set the station.

Point To Line

The image displays two screenshots of the 'Point to Line' measurement interface on a handheld device. The left screenshot shows the input stage where 'Ins.Ht' is set to 1.500 m and 'R.Ht' is set to 1.000 m. Below these, 'A-HD' is calculated as 2.210 m and 'B-HD' as 2.144 m. There are 'Meas.' buttons next to the A-HD and B-HD values, and a 'Next' button at the bottom right. The right screenshot shows the results stage. It displays 'A-B' at the top, followed by 'dHD' (2.061 m), 'dVD' (0.040 m), and 'dSD' (2.061 m). A 'Next' button is located at the bottom right.

Display	Description
A-HD	HD from station to 1 st point
B-HD	HD from station to 2 nd point
dHD	Difference of HD for A-B

Display	Description
dVD	Difference of VD for A-B
dSD	Difference of SD for A-B
N/E/Z	Coordinates of station

7.7 FREE STATION

Description

In Free Station, the coordinate system will be settled by it's local coordinate system.

Normally, the workflow is:

Station setup - Backsight oriented - Data collect.

With Free Station, it is:

Station setup - Data collect - Reduction with backsight.

After reduction, the local coordinates will convert to the real coordinates.

Access

- 1) Select Main Menu: **[Station]\[Free Station]**.
 - 2) Press **[+]\[Setting]**.
-

Free Station

Display	Description
STN	Select or type a point as station
HR	Horizontal angle for current direction. It will be settled as 0.
Ins. Ht	Instrument height
R.Ht	Reflector height
[Backsight Checking]	Define the backsight direction. It can be set before or after the station setup.

Next Step

Data Collect. Refers to Chapter 8.1.

Reduction for Free Station. Refers to Chapter 11.1.1

7.8 STATION SETUP WITHOUT CONTROL POINT


Description

This function is used to setup the station when you don't have any control points.

All those local coordinates, which are measured under two different stations (A & B), can be converted to correct coordinates if there is a public point C exists.

Workflow:

Set station at A - Data collect (including a public point C) - Move station at B - Data collect (including a public point C) - Reduction



Access

**Station Setup
without Control
Point**

Select Main Menu:[Station]\[STN Setup without CP]\[+]\[Setting]

Display	Description
STN	Select or type a point as station
HR	Horizontal angle for current direction. It will be settled as 0.
Ins. Ht	Instrument height
R.Ht	Reflector height

Next Step

Data Collect. Refers to Chapter 8.1

Reduction for Station Setup without CP. Refers to Chapter 11.1.2

8. COLLECT

8.1 POINT

Description

Measure and save the points.

Access

Select Main Menu: **[Collect]** \ **[Point]** \ **[Meas.]** or **[All]**

Collect Points

Display	Description
Pt N	Point name.
Code	Code. Press [+] \ Qcode [+] to select the code. The position and links is marked for Southmap, it will not display on the map of total station.
R.Ht	Reflector height.


HR/HL	Horizontal left or right
V	Vertical angle
N/E/Z	North, east and zenith coordinates
HD/VD/SD	Horizontal / Vertical / Slope Distance
[Meas.]	Measure the target.
[Save]	Save the data.
[All]	Measure and save the coordinates in once.

8.2 DISTANCE OFFSET

Description

The distance offset calculates from measurement or coordinates with longitudinal, parallel offset and height differences of the target point relative to the known point.

Note: All directions are correspondent to the visual side of operator.



Access

- 1) Select Main Menu: **[Collect]** \ **[Dist.Offset]**.
- 2) Input lateral, longitudinal and altitude offset.
- 3) Press **[Dist]** or **[All]** to measure and calculate the offset coordinates.

Distance Offset

4:34 Dist.Offset

Meas. Data Graph

Pt N: o1 Code: R.Ht: 1.000 m

☐ Left ☒ Right 2.000 m ☐ Front ☒ Back 2.000 m ☐ Up ☒ Down 2.000 m

Dist. Save All

4:34 Dist.Offset

Meas. Data Graph

Pt N: o1 Code:

N: 120.770 m HD: 2.007 m

E: 26.853 m VD: 0.642 m

Z: 19.858 m SD: 2.107 m

HR: 067°25'39.3"

V: 107°44'57.9"

Display	Description
Pt N	Input the ID of offset point.
Left/Right	Input lateral deviation, from offset point to prism.
Front/Back	Input longitudinal deviation, from offset point to prism.
Up/Down	Input altitude deviation, from offset point to prism.
[Dist]	Measure the target.
[Save]	Save the data.
[All]	Measure and save the coordinates of offset point.

8.3 PLANE OFFSET

Description

This function calculates the points which cannot be measured directly.

Access

- 1) Select Main Menu: **[Collect]\ [Plane Offset]**.
- 2) Press **[Meas.]** to measure three points in a same plane
- 3) Rotate the telescope, aim at the unreachable point in this plane.
- 4) press **[Save]** to save the coordinate.

Distance Offset

The screenshot shows the 'Plane Offset' application interface. At the top, there are navigation icons and a title bar. Below the title bar, there are tabs for 'Meas.', 'Data', and 'Graph'. The 'Meas.' tab is active. The interface includes input fields for 'Pt N' (set to 3), 'Code' (a dropdown menu), and 'R.Ht' (set to 0.000 m). Below these, there are three rows of buttons for points A, B, and C. Each row has a green 'Done' button, an orange 'Meas.' button, and a yellow 'View' button. To the right of these buttons, the horizontal level (HL) and vertical angle (V) are displayed for point A: HL: 255°04'40" and V: 64.45%. A large orange 'Save' button is located at the bottom right of the screen.

Display	Description
[Meas.]	Measure three points in a same plane to define a plane.
[View]	Check the coordinate of measured point.
[Save]	Save the coordinate of calculated point.


Unmeas.	Display only. When the measurement is not completed.
Done	Display only. When the measurement is completed.

8.4 COLUMN OFFSET

Description

Column offset is widely used in measuring a hidden point that is not directly visible, for example the center of column as picture shown.

Measure the left and right edge (P2&P3) of column. Then measure the center point P1 in surface.



Access

Step-by-step

- 1) Select Main Menu: **[Collect]\[Column Offset]**.
- 2) Press **[Angle]\[Angle]\[Meas.]** to measure the edges and surface center.
- 3) Press **[Data]\[Save]** to check and save the coordinates of P0.

Column Offset

Keys	Description
[Angle]	Measure the angle of left and right edge.
[Meas.]	Measure the distance of surface center.
Unmeas.	Display only. When the measurement is not completed.
Done	Display only. When the measurement is completed.
[Save]	Save the coordinates.

8.5 REM

Description

When the target is hard to reach or hang in the air, for example, the electric cables, REM (Remote Height) can help you measure the point.

Access

1) Select Main Menu: **[Collect]\[REM]**.

Step-by-step

- 2) Set a prism vertically under the target.
- 3) Input reflector height, press **[Ang.&Dist]** to measure the prism.
- 4) Rotate the telescope to the target.

REM

The screenshot shows the REM application interface. At the top, there is a status bar with the time 3:22 and various icons. Below the status bar, there is a navigation bar with a back arrow, a star icon, a menu icon, and the text 'REM'. To the right of the navigation bar are three icons: a square, a magnifying glass, and a camera. The main display area shows the following data:

R.Ht:	0.000	m
V:	032°30'21"	
dVD:	3.799	m
VA:	094°49'02"	
HD:	2.297	m

There are two buttons on the right side of the display: 'Reset BL' and 'Ang.&Dist.'.

Display	Description
V	Vertical angle of target
dVD	Vertical distance of prism or the target
VA	Vertical angle of prism
HD	Horizontal distance of prism
[Ang&Dist]	Measuring the prism which is vertically under the target
[Reset BL]	When R.HT is unknown, aim at the pinpoint, press [Reset BL] to set the vertical distance to 0. Then rotate the telescope to target.

8.6 MLM

Description

MLM, is mainly used to compute the HD/VD/ SD/azimuth between two points.

- 1) MLM Radial(A-B, A-C) , lock the start point
- 2) MLM Cont. (A-B, B-C) , unlock the start point.

Access

1) Select Main Menu: **[Collect]** \ **[MLM]**.

Step-by-step

2) Press **[Meas]** \ **[Ang.&Dist]** \ **[Save]**.

3) Select calculation mode, lock or unlock the start point. Press **[COGO]**

MLM

Meas. No.	Data Item	N	E
P1	A	2564800.839	440308.701
P2	B	2564801.384	440306.333
P3	C	2564791.013	440305.732

HR: 102°58'18" Pt N: A

V: 028°06'36"

SD: 1.526 m R.Ht: 0.000 m

N: 2564800.839 m

E: 440308.701 m

Z: 22.846 m

Ang.&Dist. OK Save


Keys	Description
[Meas.]	Measure points.
[COGO]	Calculate the result base on points in data list.

[Lock]	Lock (A-B, A-C, A-D, etc.) or unlock (A-B, B-C, C-D) mode.
[Ang & Dist]	Measure the angle, distance and coordinate.
[Save]	Save the measured point in data list.

8.7 LINE & EXTEND POINT

- Description** It calculate the coordinates of an unknown point from a line defined by two points (P1, P2) with an inputted distance (calculated from P2).
- Access** 1) Select Main Menu: **[Collect] \ [Line & Extend Point]**.
- Step-by-step** 2) Enter the reflector height, press **[Meas]** to measure P1 and P2 as a baseline.
3) Press **[Dist.Set]** to enter the extend distance. Press **[Save]**.

Line & Extend Point



Keys	Description
[Meas.]	Measure points (P1, P2).
[View]	Check the coordinates for P1 and P2.
[Dist Set]	Set the extend distance which is based on P2.
[+]	Extend direction from P1-P2.
[-]	Extend direction from P2-P1.
[Save]	Calculate and save the coordinates of extend point.

8.8 LINE & EXTEND ANGLE

Description	It calculate the coordinates of an unknown point from a line defined by two points (P1, P2) with an azimuth (calculated from P2).
Access	1) Select Main Menu: [Collect]\[Line & Extend Angle] .
Step-by-step	2) Press [Meas] to measure P1 & P2 as a base line. 3) Press [Meas]\[Save] to measure and save the coordinates of extend point.

Line & Extend Angle

Line & Extend Angle

Meas. Data Graph


Pt N: pt03 Code: R.Ht: 0.000 m

HR: 031°49'38" V: 024°03'36"

P1: 10.322 m [Meas.] [View]

P2: 5.211 m [Meas.] [View]

Azimuth: 031°51'30" [Meas.] [Save]



Keys	Description
[Meas.]	Measure points (P1, P2 and extend azimuth).
[View]	Check the coordinates for P1 and P2.
[Save]	Calculate and save the coordinates of extend point.

8.9 SAG MEASURE

Description


The sag measure is able to ensure the sufficient safety distance from the hanging cable to the ground, or to the object to be crossed.

The sag control and sag measure are calculated from measuring the horizontal distance of lower cable, the span or the observation of sag point.

Diagram


1. Sag Begin Method.

Set the station under one side of the tower (A).




2. Sag In Method

Set the station between the location of two towers.




3. Sag Out Method

Set the station at the outside of two towers.



4. Sag Interval Method



8.9.1 Sag Measure

Access

1) Select Main Menu: **[Collect]\[Sag Measure]**

Step-by-step

2) Select the method.

3) Enter or press **[Meas]** to measure the data for each item.

4) Press **[Calc.]** to calculate the observation angle of sag point (θ).

The screenshot shows the "Sag Measure" application interface. The title bar displays the time "10:44" and various status icons. The main menu on the left includes "Sag Begin Method", "Sag In Method", "Sag Out Method", and "Sag Interval Method". The "Sag Angle:" field is set to "Legend >". The "Span:" field is set to "0.000 Meas m". The "Nominal Ht of Station:" field is set to "0.000 Meas m". The "Sag:" field is set to "0.000 m". The "Value at Pulley (Clamp):" field is set to "000°00'00 Meas". The "InsHt:" field is set to "0.000 m". There are two buttons: "g Control" and "Calc.".

Sag Begin

Item	Description	
Sag Angle	θ	Observation angle of sag (unknown)
Span	L	Distance of span
Sag	f	Sag value in the middle of span.
Nominal Ht of Station		= Nominal height - length of insulation string
Value of Pulley (Clamp)	β	Observation angle of pulley/clamp.

Sag In/Out

Item	Description	
HD of lower level	L'	Distance between the station to A.
Nominal Ht of Station		= Nominal height - length of insulation string
Value of Pulley (Clamp)	β	Observation angle of pulley/clamp.
Span	L	Distance of span
Sag	f	Sag value in the middle of span.

Sag Interval

Item	Description	
Span L1	L1	Distance of span.
Span L2	L2	Distance of span.
Sag	f	Sag value in the middle of span.
Angle α of lower level	α	the observation angle to the nearer pulley.
Angle β of lower level	β	the observation angle to the further pulley.

8.9.2 Sag Control

Access

- 1) Select Main Menu: **[Collect]\[Sag Measure]\[Sag Control]**.
 - 2) Select the method. Enter the instrument height.
 - 3) Press **[Meas]** to measure. Press **[Calc.]** to calculate the sag value f.
-

8.10 TRAVERSE

8.10.1 Overview


Description

Traverse is used to establish a control point system when you have to work further than the first orientation or when the target is not visible.


It needs at least two known points to open or end the traverse.

Types of traverse

1. Open Traverse. Apply for Roads, Railways, etc



2. Closed Traverse, Apply for Buildings, Gardens, etc



Access

Measure

Sequence

Select Main Menu: **[Collect]\[Traverse]**


B¹B²F¹	Backsight point is measured in face 1, face 2 order; Foresight point is measured in reverse order.
B¹B²F¹F²	Backsight point is measured in face 1, face 2 order; Foresight point is measured in same order.
B¹F¹B²F²	Backsight and foresight points are measured in face 1, then measured backsight and foresight again in face 2.
B¹F¹F²B²	Backsight and foresight points are measured in face 1, then reverse the order, foresight point is measured firstly in face 2.

8.10.2 Create a New Traverse

Access

Press **[+]**\Type the name**[OK]**

Traverse



The screenshot shows a mobile application interface with a dark background. At the top, there's a status bar with the time 2:55 and various icons. Below it, a header bar contains a back arrow, the text '< Traverse Template', and a plus icon. The main content area shows a list with 'Total 0'. Overlaid on this is a light gray 'Add' dialog box. Inside the dialog, there's a text field labeled 'Template Name:' with 'job01' entered. Below it, a label 'Type:' is followed by 'Closed Traverse'. Then, a label 'Level:' is followed by a dropdown menu showing 'First Class'. At the bottom, a label 'Direction:' is followed by two radio buttons: 'Left' (which is selected) and 'Right'. At the very bottom of the dialog are 'Cancel' and 'OK' buttons. A large plus icon is visible in the bottom right corner of the screen, outside the dialog box.


Display	Description
Template Name	Name of the traverse.
Type	Traverse type, closed traverse or open traverse. The software will recognize it automatically.
Level	Select the measure level. (Refers to Appendix.C)
Angle Direction	The direction is in the left or right side of traverse.

8.10.3 Edit an Existed Traverse

Access


Press the traverse name\[**Measure**], [**Edit**] or [**Delete**]\[**OK**]

Traverse



Display	Description
Measure	Continue the measurement of traverse points.
Traverse Adjustment	Adjust the results of traverse.
Export Survey Table	Export the data.
Edit	Edit the name of traverse.
Delete	Delete the data in this traverse.

8.10.4 Traverse Step in Step



Step	Description
1	Setup total station at the first station(P2) which is known.
2	[New STN] to select or type the coordinates of first station (P2). [OK] to access the measure page for 1 st round.
3	[Target] to select the ID of backsight (P1) and foresight points (P3).
4	[Meas] to measure and record. (Measure sequence: B ¹ B ² F ² F ¹ / B ¹ B ² F ¹ F ² / B ¹ F ¹ B ² F ² / B ¹ F ¹ F ² B ²)
	{Ang}\{Dist} to check the data of traverse. Horizontal angle, calculated azimuth from the foresight to the backsight, distance measured by face1 and face 2 are displayed.

5	[+], [-] to add or delete the measure rounds.
6	Move to the foresight point (P3) as the next station.
7	[New STN] to type the name of traverse point. [OK] to access the measure page.
8	[Target] to select the ID of backsight (P2) and foresight points (P4).
9	[Meas] to measure and record. Move to the foresight point (P4) as the next station .
10	Repeat the steps to set the station at the other points (P4 ,P5). Then traverse is closed.
11	[Done] to save the data and back to the job list.

eee-Traverse Survey

1 round trip

Station	Target	H disk reading	One way angle value
Left	bs	249°20'37"	075°43'35"
	stn2	325°04'11"	
Right	stn2	145°16'42"	074°27'18"
	bs	070°49'24"	

New STN

eee-Traverse Survey

Edge Name	N times round trip	Left	Right	Average
1 - bs	1	2.055	2.062	2.058
1 - stn2	1	1.695	1.696	1.695

New STN

Page	Display	Description
------	---------	-------------

Angle	Vertical Angle	Horizontal angle of current position
	Horizontal Angle	Vertical angle of current position
	Average Angle	Average angle among several rounds
	1 round trip	Measure rounds.
	Location	Left: Face 1; Right: Face 2
	Target	Target ID for backsight and foresight.
	H Dist Reading	Horizontal angle of backsight & foresight (F1/F2)
	One Way Angle	Angle from foresight to backsight
	Round Trip Angle	Average angle in this round
Dist	Edge Name	Edge from backsight - station, station - foresight
	N Times Round	1 st , 2 nd , or 3 rd ... rounds
	Left	Distance in Face 1 (Left)
	Right	Distance in Face 2 (Right)
	Average	Average distance between F1 and F2

8.10.5 Traverse Adjustment

Description


A traverse adjustment can be performed on coordinates of traverse points, angles and distances.

Access

Traverse

Adjustment

Press the traverse name \[Traverse Adjustment]

A screenshot of the 'Calculate Traverse Adjustment' screen. It has a title bar with '< eee-Calculate Traverse Adjustment' and an 'Export' button. The screen displays a table with 5 columns: 'Pt N', 'Observation Angle', 'Correction Value', 'Correct Angle', and 'Coordinate Azimuth'. The data rows are for points 'bs', '1', 'stn2', and 'stn3'. Below the table, there are summary statistics for 'Assistant' including angle closure error, coordinate incremental closing error, and traverse closure error.

Pt N	Observation Angle	Correction Value	Correct Angle	Coordinate Azimuth
bs				201°48'05"
1	075°05'27"	-000°00'00"	075°05'27"	096°31'59"
stn2	075°05'27"	-000°00'00"	075°05'27"	096°31'59"
stn3				

Assistant
Angle closure difference fb:000°00'00"
Angle closure error fb_limit:000°00'00"
Coordinate incremental closing error fx:0.000m
Coordinate incremental closing error fy:0.000m
Traverse Closure error f:0.000m
Traverse Relative Closing Error k:infininm

Display	Description
Pt N	Point ID
Observation Angle	Original observed angle
Correction Value	Correction value of horizontal angle
Correct Angle	Corrected angle after adjustment
Coordinate Azimuth	Azimuth of each points
Distance	Distance between two points
Incremental Value	Incremental X and Y for traverse points
Corrected Increment	Corrected X and Y for traverse points
Last Coordinate	Coordinates for each points

8.10.6 Export Survey Table

Access

Press the traverse name \[**Export Survey Table**\] Select the location of storage \[**OK**\]

Default location: **[File manager]\ [Internal Storage]\ [com_southgnss_surveystar Expand]\ [Export]**. The file can be transferred by USB OTG, Bluetooth or Micro SD Card. Refers to Chapter 10.6.3


Survey Table

STN	Vertical Disk Location	Target	H disk reading	One way angle value	Round trip angle value	Average Angle
1	Face 1	bsc1	045°00'00"	164°22'38"	164°15'30"	164°15'30"
		3	209°22'37"			
	Face 2	3	029°09'05"	164°08'23"		
		bsc1	225°00'43"			
Edge Name	N times round trip	Face 1	Face 2	Average	Average value	
1-bsc1	1	10.555	10.550	10.553	10.553	
1-3	1	10.671	10.637	10.654	10.654	
3	Face 1	1	052°07'36"	205°09'13"	205°04'31"	205°04'31"
		4	257°16'49"			
	Face 2	4	077°17'56"	204°59'49"		
		1	232°18'08"			
Edge Name	N times round trip	Face 1	Face 2	Average	Average value	
3-1	1	10.686	10.675	10.680	10.680	
3-4	1	12.068	12.066	12.067	12.067	
4	Face 1	3	218°43'21"	333°23'45"	333°21'14"	333°21'14"
		5	192°07'06"			
	Face 2	5	012°02'27"	333°18'43"		
		3	038°43'44"			
Edge Name	N times round trip	Face 1	Face 2	Average	Average value	
4-3	1	12.095	12.100	12.098	12.098	
4-5	1	10.861	10.851	10.856	10.856	
5	Face 1	4	149°14'54"	208°28'05"	208°24'04"	208°24'04"
		1	357°42'59"			
	Face 2	1	177°35'12"	208°20'03"		
		4	329°15'08"			
Edge Name	N times round trip	Face 1	Face 2	Average	Average value	
5-4	1	10.824	10.805	10.815	10.815	
5-1	1	12.081	12.082	12.082	12.082	

8.11 CABLE HEIGHT

Description

This function is used to measure the height (**LH**) from a target (**L**) hanging in the air to the lower reference plane (**G**). (like the overhang of channel)



Access

Step-by-step

- 1) Select Main Menu: **[Collect]\[Cable Height]**
 - 2) Press **[Setting]** to enter the instrument height and reflector height.
 - 3) Press **[Meas]\[Save]** to measure prism A & B, define a reference plane.
 - 4) Press **[Next]**, Aim at the target L, press **[Meas.]**.
 - 5) Aim at the base point G on the ground, press **[Meas.]**.
-

3:10

Cable Height S

Tips: Measure Prism A and B.
Click Next. Legend >

HD (A): 0.619 m Meas. Save HR: 088°33'00"

HD (B): 1.598 m Meas. Save V: 048°50'28"

Setting Next

3:15

Cable Height S

Tips: Measure Target L on the Hanging Cables.
Rotate the Vertical Tangent Unit. Legend >

VD: -0.084 m Meas. Save HR: 075°38'46"

HD: 0.265 m Meas. Save

Off: 0.695 m Meas. Save V: 237°50'48"

LH: 0.441 m Meas. Save Last

Off: 0.695 m


Item	Description
HD(A)	Horizontal distance to prism A.
HD(B)	Horizontal distance to prism B.
VD	Vertical distance from prism A to target L.
HD	Horizontal distance of target L.
Off	Offset between prism A and target L
LH	Height from target L to the ground G.

8.12 POINT PROJECTION

Description

It is used to calculate the coordinates of a point projected onto a line.

Diagram



P1: Start Point
P2: End Point
P3: Measured Point
P4: Projected Point

Access

Step-by-step

- 1) Select Main Menu: **[COGO]\[Point Projection]**
- 2) Press **[+]**, select or measure two points to define a line. Press **[Next]**.
- 3) Press **[Meas]** to measure a point to be projected.
- 4) Press **[COGO]** to calculate projected coordinate. Press **[Data]** to check result.

Point Projection

9:25

Point Projection

StartPt: {Meas.} EndPt: {Meas.}

Nb1: 1.742 Nb2: -0.097

Eb1: 0.392 Eb2: 2.765

Zb1: 2.403 Zb2: 2.385

9:37

Point Projection

Projection Point Data

HR: 346°12'02" Pt N:

V: 046°56'06"

N: 1.442 m Code:

E: -0.354 m R.Ht: 0.000 m




Z: 2.387 m

Item	Description
Start Pt	Start point, defining a line.
Nb1/Eb1/Zb1	Coordinates of the start point.
End Pt	End point, defining a line.
Nb2/Eb2/Zb2	Coordinates of the end point.
N/E/Z	Coordinates of the measured point.
SD/VD/HD	Slope, vertical, horizontal distance of the measured point.


Result	Description
Np/Ep/Zp	Coordinates of the projected point.
L	Length from start point to projected point.
Off	Horizontal offset from measured point to projected point.
VD	Vertical distance from measured point to projected point.

9. STAKE OUT

9.1 OVERVIEW

Description	Stakeout application is used to place marks or find locations in the field.	
Program	Diagram	
Point		F/B: Forward / Backward L/R: Left / Right F/C: Fill / Cut S.O Pt: Selected, measured or typed by manual, which is known.
CAD		F/B: Forward / Backward L/R: Left / Right F/C: Fill / Cut S.O Pt: Selected from CAD files
Angle & Distance		α: Horizontal angle HD: Horizontal distance Z: Height difference\Vertical distance

Direction Line




α : Horizontal angle\Azimuth

HD: Horizontal distance

Z: Height difference\Vertical distance

P1: Known.

Line




F/B: Forward / Backward

L/R: Left / Right

U/D: Up / Down

Start Pt & End Pt: Known

Reference Line



BL: Baseline, defined by two known points.


RL: Reference line, rotated (α) and moved by latitudinal (**Off¹**) and longitudinal (**Off²**) offset.

Off³: Left or right, backward or forward from the start point' of reference line.

Off⁴: Cut or fill from the start point'.

Arc S.O

Point




d1: Arc distance

d2: Radius distance (+)

P3: The point to be staked.

Arc




d1: Arc length

d2: Radius distance (+)

P3/P4....: The points to be staked.

String




d3: String length

d2: Radius distance (-)

P3/P4....: The points to be staked.

Central Angle



α : Central angle

d2: Radius distance (0)

P3/P4/P5....: The points to be staked.

9.2 POINT

Description

The points can be selected from job, entered by manual or measured directly.


Access

1) Select Main Menu: **[Stake Out] \ [Point S.O] \ [+]**

2) Rotate the telescope based on the guidance of E-compass, press **[Meas.]**

3) When all the distance becomes 0, press **[Storage]**.

Point Stake Out



Display	Description
Pt N	Point ID to be staked.
E-Compass	Direction of the stakeout points.
dHA	Difference of horizontal angle
F/B	Forward or backward

L/R	Left or right
F/C	Fill or cut, move the target up or down.
P1	Display the HA/N/E/Z/HD/VD/SD of measured target.
P2	Slide the screen to check the information of points to be staked. Click the triangle mark to set the display items.
Keys	Description
[Last]	Last point to be staked.
[Next]	Next point to be staked.
[Meas.]	Measure the target.
[Storage]	Save the point into storage

9.3 CAD STAKE OUT

Description



The points to be staked can be uploaded and selected from DXF/DWG files.

Access

1) Select Main Menu: **[Stake Out]\[CAD Stake Out]**.

2) Press   **[Done]** to upload the map in DXF/DWG files.

CAD Stake Out



Icons	Description
	Explore the features into sections.
	Select the features by cursor.
	Upload a map or layer in DXF/DWG files; Select the layer for display; Select the color of background.
	Display the full map.

	Locate the station.
	Check all the lines. Select the line to be staked. Including 1) Line stake out, refers to Chapter 9.6 Line. 2) Start point stakeout, refers to Chapter 9.2 Point. 3) End point stakeout, refers to Chapter 9.2 Point. 4) start point extraction, and 5) end point extraction, to extract and save points.
	Last
	Next
	Select the feature, click it to stake out. Including 1) Line stake out, refers to Chapter 9.6 Line. 2) Start point stakeout, refers to Chapter 9.2 Point. 3) End point stakeout, refers to Chapter 9.2 Point. 4) Pile stake out, 5) Interval stakeout, 6) Offset stakeout.

9.3.1 Pile Stakeout

Description

Staking out the piles on the selected features.

Access

- 1) Select the feature, press [F] \ **[Pile Stake Out]**.
 - 2) Press [Up] [Down] to select the last or next pile.
 - 3) Press [F] again to stake out the selected pile.
-

Pile Stake Out



Icons	Description
Reverse	Reverse the stake out direction.
Exit	Exit the program.

9.3.2 Interval Stakeout


Description

Staking out the points by the inputted interval.

Access

- 1) Select the feature, press  \ **[Interval Stake Out]**.
- 2) Enter the interval mileage, press **[Modify]**. It will calculate the location of points by the inputted interval, on the selected feature.
- 3) Press   to select the last or next point.
- 4) Press  again to stake out the selected point.

Pile Stake Out



Icons	Description
Interval Mileage	Enter the intervals to be staked.
Reverse	Reverse the stake out direction.
Exit	Exit the program.

9.3.3 Offset stakeout


Description

Staking out the points by the inputted offsets.

Access

- 1) Select the feature, press [**Offset Stake Out**].
 - 2) Enter the offsets, press [**Modify**]. It will move the selected feature horizontally for staking out.
 - 3) Press [**Up**]/[**Down**] to select the last or next point.
 - 4) Press [**Offset Stake Out**] again to stake out the selected point.
-

Pile Stake Out



Icons	Description
Offset	Enter the offsets to be staked. Positive: Move right, Negative: Move left.
Reverse	Reverse the stake out direction.

9.4 ANGLE & DISTANCE

Description Stake-out the points by angle (HA), horizontal distance(HD) or height (Z).

Access 1)Select Main Menu:[Stake Out]\[Angle & Distance S.O]

2)Enter HA, HD, Z\[Next]\[Meas.]

Angle & Distance S.O

Parameter

HA: 000°00'00"

HD: 0.000 m

DZ: 0.000 m

Next

Stake Out Data Graph

R.Ht: 0.000 m

Meas. Storage

dHA : -000°00'05" M HA: 359°59'55"

Back : 153.158 m ea HD: 1.842 m

Left : 0.004 m s. VD: 1.100 m

Dig : 1.100 m Pt Z: 51.100 m


Items	Descriptions
HA	Horizontal angle from stake out point to station.
HD	Horizontal distance from stake out point to station.
Z	Height difference from stake out point to station.

9.5 DIRECTION LINE

Description

Stake-out the points by angle (Azimuth), horizontal distance(HD) or height (VD), based on a known point, along the direction of azimuth.

Diagram



α : Azimuth

HD: Horizontal distance

Z: Vertical distance

P1: Known

Access

- 1)Select Main Menu: **[Stake Out]\[Direction Line]**.
- 2)Enter the point ID, azimuth, HD and VD, press **[Next]**.
- 3)Stake out the points, press **[Meas]\[Storage]**.

Direction Line

The screenshot shows the 'Direction Line' input screen. It has a title bar with navigation icons and a 'Direction Line' title. Below the title is a 'Parameter' section with the following fields:

- Pt N: [] +
- Azimuth: 000°00'00"
- HD: 0.000 m
- VD: 0.000 m

A 'Next' button is located at the bottom right of the input area.


Items	Descriptions
Pt N	Point ID of the known point.
Azimuth	Horizontal angle from stake out point to the known point.
HD	Horizontal distance from stake out point to the known point.
VD	Vertical difference from stake out point to the known point.

9.6 LINE

Description

The points are staked by a base line (defined by two known points) and the offset is calculated from the start point, move along the direction of baseline.

Diagram



F/B: Forward / Backward

L/R: Left / Right

U/D: Up / Down

Start Pt & End Pt: Known points

Access

1) Select Main Menu: **[Stake Out]\[Line]**

Step-by-step

2) Enter two points and offsets, press **[Next]**

3) Stake out the points, press **[Meas]\[Storage]**.

Line Stake Out

The screenshot shows a mobile application interface for 'Line Stake Out'. At the top, there's a navigation bar with a back arrow, a star icon, and a menu icon. The title 'Line' is in the center, and on the right are icons for settings, a home button, and a camera. Below the navigation bar is a 'Parameter' section. It contains two input fields for 'StartPt' (value 1) and 'EndPt' (value 2), each with a yellow '+' button to its right. Underneath are three rows of offset settings. Each row has two radio buttons (one selected with a yellow dot) and a text input field followed by a unit 'm'. The first row is 'Left/Right' with a value of 20.000. The second row is 'Front/Back' with a value of 0.000. The third row is 'Up/Down' with a value of 0.000. A yellow 'Next' button is located at the bottom right of the parameter section.

Items	Descriptions
Start/End Pt	Define a line by two known points.
Left/Right	Longitudinal offset (Left or right).
Front/Back	Latitudinal offset (front or back).
Up/Down	Altitude offset (Up or down).

9.7 REFERENCE LINE

Description


Reference Line application can be used to stake out or measure points relative to a line.

The points are staked from a reference line (shifted from a baseline), and the

related offset.

The reference line can be offset either longitudinally or latitudinally to the baseline (defined by two known points), or be rotated around the first base point as required.

Diagram



BL: Baseline, defined by two known points.

RL: Reference line, rotated (**α**) and moved by latitudinal (**Off¹**) and longitudinal (**Off²**) offset.

Off³: Left or right, backward or forward from the start point¹ of reference line.

Off⁴: Cut or fill from the start point¹.

Access

Step-by-step

Step 1. Define a baseline from two known points.

Press **[+]** to select, create, input or measure points.

Step 2. Define a reference line.

Type the offsets or angle to shift the baseline. Press **[Next]**.

Step 3. Stake out points

Enter the offsets from the start point of reference line, press **[Next]** to stake out the points.

Press **[Meas]\[Storage]** to measure and save.

Reference line

Items	Descriptions
Start/End Pt	Define a baseline by two known points.
Left/Right	Longitudinal offset (Left or right) to define a reference line.
Front/Back	Latitudinal offset (front or back) to define a reference line.
Angle	This term must always be considered to mean as Bearing. The bearing angle from the baseline to define a reference line.
Up/Down	Vertical offset to define a reference line.

The screenshot shows a mobile application interface for setting stakeout parameters. At the top, there's a status bar with the time 4:00 and various icons. Below that, a navigation bar contains a back arrow, a star icon, a list icon, the title 'Reference Line', and three action icons (a square with 'S', a camera, and a location pin). The main content area is titled 'Stakeout Parameters' and contains three input fields, each with a value of 0.000 and a unit of 'm'. The fields are labeled 'Left/Right:', 'Front/Back:', and 'Up/Down:'. A yellow 'Next' button is positioned to the right of the 'Up/Down' field.

Items	Descriptions
Left/Right	Longitudinal offset (Left or right) from the start point of reference line.
Front/Back	Latitudinal offset (front or back) from the start point of reference line.
Up/Down	Vertical offset from the start point of reference line.

Next Step

Stake out points (Refers to Chapter 9.2)


9.8 ARC

Description

Calculate and stake out the points related to an arc.


Elements that must be known to define the arc are:

- coordinate of central point
- coordinate of a start point




OR

- coordinates of start point and end point
- radius



OR

- coordinates of three points on the arc.



Access

1) Select Main Menu: **[Stake Out]\ [Arc S.O]**

Step-by-step


2) Define an arc by: Arc center & Start point; Two points & Radius; Three points. Press **[Next]**.

3) Enter the offsets on the arc. Press **[Next]**.

4) Stake out the points, press **[Meas]\ [Storage]**.

Step 1.

Define an arc



Methods	Descriptions
Center	Central point of the arc.
Start Pt	The start point of the arc. Available for define an arc using: Arc center & Start point, 3 points and 2 points & radius.
End Pt	The end point of the arc. Available for define an arc using: 3 points and 2 points & radius.
Arc Pt	The 3rd point of the arc. Available for define an arc using: 3 points.
Radius	The radius of the arc. Available for define an arc using: 2 points & radius.

Step 2:

Stake out an arc

Methods	Elements Must Known	Diagram
Point	Arc D (d_1): Distance along the arc in anti-clockwise direction. Radius D (d_2): Radius distance in ($d_2 < 0$), on ($d_2 = 0$) or outside ($d_2 > 0$) the arc.	
Arc	Closed Differ: ● Equally: Divide the closing error equally to each parts. ● End Pt: Add the closing error to the end point. ● Start Pt: Add the closing error to the start point.	

	Arc L (d1): Divide arc into several parts by the arc length. Radius D (d2): Radius distance in ($d2 < 0$), on ($d2 = 0$) or outside ($d2 > 0$) the arc.	
String	Closed Differ: Equally, End Point or Start Point. String L (d3): Divide arc into several parts by the string length. Radius D (d2): Radius distance in ($d2 < 0$), on ($d2 = 0$) or outside ($d2 > 0$) the arc.	
Central Angle	Closed Differ: Equally, End Point or Start Point. Center Angle (α): Divide arc into several parts by the angle. Radius D (d2): Radius distance in ($d2 < 0$), on ($d2 = 0$) or outside ($d2 > 0$) the arc.	


Next Step

Stake out the points based on the arc.
(Refers to Chapter 9.2 Point.)

10. DATA MANAGEMENT

10.1 POINT MANAGEMENT

Overview



The screenshot shows a mobile application interface titled 'Data'. It features a table with columns: Item, Type, Code, N, and E. The table contains three rows of data. A yellow 'Multi-Del.' button is visible on the right side of the table. A yellow circular button with a white plus sign is located at the bottom right of the table.

Item	Type	Code	N	E
22	Meas.Pt		111.198	111.198
21	Meas.Pt		113.021	113.021
1	Inp.Pt	stn	100.000	100.000


Field	Descriptions
Item	Point ID. Click the triangle to reorder the points.
Type	Display all or several types of points. e.g. Station point, measured point, inputted point, imported point, stake out point, known point, calculated point.
Code	Code of points.
N/E/Z	North, East and Zenith.
Time	Recording time.

10.1.1 Creating a New Point

Access

Select [

Create a New Point



Field	Descriptions
Pt N	Name of the new point.
Code	Code of the new point. It can be selected from code list or typed by manual.
N/E/Z	North, east and zenith.


10.1.2 Editing a Point

Description

Edit the point ID or coordinates.

Access

Select [



Type	Descriptions
Stn.Pt	Not editable.
Meas.Pt	Available to edit Pt N only.
Inputted Pt	Available to edit Pt N, code and coordinates.
Imp. Point	Available to edit Pt N, code and coordinates.
S.O Point	Not editable.
Known Pt	Available to edit.
Calc.Pt	Available to edit Pt N, code and coordinates.

10.1.3 Deleting Points

Access

Points can be deleted by three methods:

- Single: Select a point\ **[Delete]**
- Multiple: Press **[Multi-Delete]**\ Tick the points\ **[Delete]**
- All: Press **[⋮]** \ **[Clear]**

Delete Points

Data	Code	Qcode	Data	Graph
23	Stn.Pt	station	30.000	0.000
23	Inp.Pt	stn	30.000	0.000
22	Meas.Pt		111.198	111.198
21	Meas.Pt		113.021	113.021
1	Inp.Pt	etc	100.000	100.000

10.1.4 View Points

Access

Select **[📁]** \ **{Data}** page \ Select a point \ **[View]**.

Including point name, type, code, R.ht, HA, VA, N, E, Z, HD, dVD and SD.

10.1.5 Searching a Point

Access


Press **[🔍]** \ Type the keyword of point name \ **[Enter]**

10.2 CODE MANAGEMENT

Access

Select [] \ {Code} page

Overview



Display	Description
Q-Code	Quick code, must be created in Southmap or CAD. Otherwise, please enter the full code here to record the codes in raw data or coordinate data. Maximum 16 digits.
Code	Code, which is created in southmap or CAD.
Color	Color, which is created in southmap or CAD.
Name	Note, which is created in southmap or CAD.

**Code
Management**

Operate	Access
Create	[+]\Type the information\[OK]
Edit	Select a code\[Edit]\[OK]
Delete	Select a code\[Delete]. [Multi-Del.]\Tick the codes\[Delete]. Press []\[Clear].
Search	Press []\Type the keyword of codes\[Enter]
Import	Press []\[Import Code]. Refers to Chapter 10.5.2.
Export	Press []\[Export Code]. Refers to Chapter 10.6.2.

10.3 QCODE MANAGEMENT

Quick codes must be created in Southmap or CAD.

10.4 MAP MANAGEMENT


Description

Upload the map or layers for graphical display.

Access

- 1) There are two methods to access map.
 - Press [📄] from the tool bar \{Graph} page.
 - Select Main Menu: [Measure]\{Graph} page.
- 2) Press [📁] to access the map management.

Map Page



Keys	Description
	Change the layers screen.
	Make layers from the CAD file visible or invisible in map.
	Select a CAD file or offline map to the job.

10.5 IMPORT DATA

Description

The data to import must be stored in the internal memory.

Formats

Type	File Extension
Coordinate	*.txt, *.dat
Code	*.xls
Map	*.map, *.mbtiles, *.kml, *.shp, *.dwg, *.tif, *.tiff, *.dxf
CAD Stake Out	*.dwg, *.dxf
Road	*.rd, *.ip, *.xlsx, *.rod, *.pm, *.jd

10.5.1 Importing Coordinates

Description

Point Name,code,N,E,Z

Example: imp5,building,-0.286,29.757,1.424

imp2,tree,29.757,-0.286,1.424

Access

1) Press [] in tool bar\{Data} Page \[


Step-by-step

2) Select type (*.txt or *.dat) and file from the internal memory.

3) Select and drag the item (Pt N, Code, N, E, Z) to change the imported order.

4) Press [OK]

Import Coordinates



Keys	Descriptions
Type	All files with extension *.txt and *.dat can be selected.
ESC	Escape to the root directory.
Back	Back to the last page.
←/→	Change the order of data.
OK	To import the data.
Cancel	To exit the screen.

10.5.2 Importing Codes

Description

Example:



Q-code	Code	Color	Name
K05	204201	1	

(Header Lines to be skipped)

Access

- 1) Press  in tool bar\{Code} Page \[ \[Import Code].
- 2) Select type (*.xls) and file from the internal memory.

Import Codes





Keys	Descriptions
Type	All files with extension *.xls can be selected.
ESC	Escape to the root directory.
Back	Back to the last page.

10.5.3 Importing Maps

Description In normal, when instrument is online, the map will be loaded automatically. Meanwhile, the layers and maps can be imported for offline users.
*It is a kind of reference in work, the deviation might be existed.

- Access**
- 1) Press  in tool bar\{**Graph**} Page.
Or select main menu: [**Measure**]\{**Graph**} page.
 - 2) Press  \  to select a CAD file or offline map to the job.
 - 3) Choose type and file from the internal memory. Press [**Done**].

Import Maps



Type	Description
*.map, *.mbtiles	Map related files
*.kml	Map related files

*.kmz	Map related files
*.shp	Shape files
*.tif, *.tiff	Tagged image files
*.dxf	Drawing exchange files
*.dwg	Drawing files

10.5.4 Importing Data for CAD Stake Out



Description

Easy-to-Stake out the base map from a CAD file. Refers to Chapter 9.3.

Access

- 1) Select main menu: **[Stake Out]\[CAD Stake Out]**.
- 2) Press [ | \ [] to select a CAD file to the job.
- 3) Choose type (DWG/DXF) and file from the internal memory. Press **[Done]**.

Import Data for CAD Stake Out



Keys	Descriptions
Type	All files with extension *.dwg and *.dxf can be selected.
ESC	Escape to the root directory.
Back	Back to the last page.

10.6 EXPORT & COPY DATA

Description

The data can be exported to the internal memory.

Copy it to the data storage device (Micro SD card, USB OTG) or transfer it by Bluetooth.

Overview

Type	File Extension	
Points	Coordinate	*.txt, *.dxf, *.dat, *.csv, *.txt (FC-6/GTS-7)
	Raw Data	*.txt, *.txt (FC-6/GTS-7)
	Side & Angle Data	*.txt
Codes	*.xls	
Traverse	*.xls	

Next Step

Please check the data format in Appendix B.