



7368 Intelligent Services Access Manager CPE

A-020W-A WiFi

7368 ISAM CPE A-020W-A Product Guide

3FE-47511-AAAA-TCZZA

Issue: 01

Nokia is a registered trademark of Nokia Corporation. Other products and company names mentioned herein may be trademarks or tradenames of their respective owners.

The information presented is subject to change without notice. No responsibility is assumed for inaccuracies contained herein.

© 2018 Nokia.

Contains proprietary/trade secret information which is the property of Nokia and must not be made available to, or copied or used by anyone outside Nokia without its written authorization. Not to be used or disclosed except in accordance with applicable agreements.

1 Preface

This preface provides general information about the documentation set for CPEs.

1.1 Scope

This documentation set provides information about safety, features and functionality, ordering, hardware installation and maintenance, and software installation procedures for the current release.

1.2 Audience

This documentation set is intended for planners, administrators, operators, and maintenance personnel involved in installing, upgrading, or maintaining the CPEs.

1.3 Required knowledge

The reader must be familiar with general telecommunications principles.

1.4 Acronyms and initialisms

The expansions and optional descriptions of most acronyms and initialisms appear in the glossary (3FE-47157-AAAA-TCZZA).

1.5 Assistance and ordering phone numbers

Nokia provides global technical support through regional call centers. Phone numbers for the regional call centers are available at the following URL: <http://support.alcatel-lucent.com>. If this link does not work, copy and paste it directly into your web browser.

For ordering information, contact your Nokia sales representative.

1.6 Nokia quality processes

Nokia's CPE quality practices are in compliance with TL 9000 requirements. These requirements are documented in the Fixed Networks Quality Manual 3FQ-30146-6000-QRZZA. The quality practices adequately ensure that technical requirements and customer end-point requirements are met. The customer or its representatives may be allowed to perform on-site quality surveillance audits, as agreed upon during contract negotiations

1.7 Safety information

For safety information, see the appropriate safety guidelines chapter.

1.8 Documents

Documents are available using ALED or OLCS.

Procedure 1 To download a ZIP file package of the customer documentation

- 1 Navigate to <http://support.alcatel-lucent.com> and enter your user name and password. If you are a new user and require access to this service, please contact your Nokia sales representative.
 - 2 From the Technical Content for drop-down menu, choose the product.
 - 3 Click on Downloads: Electronic Delivery.
 - 4 Choose Documentation from the drop-down menu and click Next.
 - 5 Select the image from the drop-down menu and click Next.
 - 6 Follow the on-screen directions to download the file.
-

Procedure 2 To access individual documents

Individual PDFs of customer documents are also accessible through the Nokia Customer Support website.

- 1 Navigate to <http://support.alcatel-lucent.com> and enter your user name and password. If you are a new user and require access to this service, please contact your Nokia sales representative.
 - 2 From the Technical Content for drop-down menu, choose the product.
 - 3 Click on Manuals and Guides to display a list of customer documents by title and part number. You can filter this list using the Release drop-down menu.
 - 4 Click on the PDF to open or save the file.
-

1.9 Special information

The following are examples of how special information is presented in this document.



Danger — Danger indicates that the described activity or situation may result in serious personal injury or death; for example, high voltage or electric shock hazards.



Warning — Warning indicates that the described activity or situation may, or will, cause equipment damage or serious performance problems.



Caution — Caution indicates that the described activity or situation may, or will, cause service interruption.



Note — A note provides information that is, or may be, of special interest.

1.9.1 Procedures with options or substeps

When there are options in a procedure, they are identified by letters. When there are required substeps in a procedure, they are identified by roman numerals.

Procedure 3 Example of options in a procedure

At step 1, you can choose option a or b. At step 2, you must do what the step indicates.

-
- | | |
|---|---|
| 1 | This step offers two options. You must choose one of the following: |
| a | This is one option. |
| b | This is another option. |
-

- | | |
|---|-----------------------------|
| 2 | You must perform this step. |
|---|-----------------------------|
-

Procedure 4 Example of required substeps in a procedure

At step 1, you must perform a series of substeps within a step. At step 2, you must do what the step indicates.

-
- | | |
|-----|---|
| 1 | This step has a series of substeps that you must perform to complete the step. You must perform the following substeps: |
| i | This is the first substep. |
| ii | This is the second substep. |
| iii | This is the third substep. |
-

- | | |
|---|-----------------------------|
| 2 | You must perform this step. |
|---|-----------------------------|
-

1.10 Multiple PDF document search

You can use Adobe Reader Release 6.0 and later to search multiple PDF files for a common term. Adobe Reader displays the results in a single display panel. The results are grouped by PDF file, and you can expand the entry for each file.



Note — The PDF files in which you search must be in the same folder.

Procedure 5 To search multiple PDF files for a common term

-
- 1 Open Adobe Acrobat Reader.

 - 2 Choose Edit→Search from the Acrobat Reader main menu. The Search PDF panel appears.

 - 3 Enter the search criteria.

 - 4 Click on the All PDF Documents In radio button.

 - 5 Select the folder in which to search using the drop-down menu.

 - 6 Click on the Search button.

Acrobat Reader displays the search results. You can expand the entries for each document by clicking on the + symbol.

Table of contents

1	Preface	9
1.1	Scope	9
1.2	Audience.....	9
1.3	Required knowledge.....	9
1.4	Acronyms and initialisms	9
1.5	Assistance and ordering phone numbers	9
1.6	Nokia quality processes.....	10
1.7	Safety information.....	10
1.8	Documents	10
1.9	Special information	11
1.9.1	Procedures with options or substeps.....	12
1.10	Multiple PDF document search	13
2	ANSI safety guidelines	9
2.1	Safety instructions	9
2.1.1	Safety instruction boxes in customer documentation	9
2.1.2	Safety-related labels.....	10
2.2	Safety standards compliance	11
2.2.1	Responsible party	11
2.2.2	Energy-related products standby and off modes compliance.....	12
2.2.3	FCC statement	12
2.2.4	FCC Radiation Exposure Statement	13
2.2.5	Resistibility requirements compliance	13
2.3	Electrical safety guidelines	13
2.3.1	Power supplies	14
2.3.2	Cabling	14
3	ETSI safety guidelines.....	15
3.1	Safety instructions	15
3.1.1	Safety instruction boxes	15
3.1.2	Safety-related labels.....	16
3.2	Safety standards compliance	17
3.2.1	Responsible party	17
3.2.2	Energy-related products standby and off modes compliance.....	18
3.2.3	EMC and RED compliance.....	18
3.2.4	Equipment safety standard compliance.....	18
3.2.5	Environmental standard compliance	19
3.2.6	Resistibility requirements compliance	19
3.3	Electrical safety guidelines	19
3.3.1	Power supplies	19
3.3.2	Cabling	19
4	ETSI environmental guidelines	21
4.1	Environmental requirements.....	21
4.1.1	Transportation	21
4.1.2	EU RoHS	21
4.1.3	End-of-life collection and treatment	22

5	A-020W-A unit data sheet	23
5.1	A-020W-A part numbers and identification	23
5.2	A-020W-A general description	24
5.2.1	TR-069 object support for WiFi parameters	26
5.2.2	Independent TR69 session with SaaS	26
5.2.3	TR69 authentication using TLS and CA certificates	26
5.3	A-020W-A software and installation feature support	27
5.4	A-020W-A interfaces and interface capacity	27
5.4.1	A-020W-A connections and components	27
5.5	A-020W-A LEDs	28
5.6	A-020W-A detailed specifications	30
5.7	A-020W-A functional blocks	30
5.8	A-020W-A standards compliance	31
5.9	A-020W-A special considerations	31
5.9.1	WiFi service	32
5.9.1.1	WiFi standards and certifications	32
5.9.1.2	WiFi GUI features	32
5.9.2	A-020W-A considerations and limitations	32
6	Install a A-020W-A	33
6.1	Purpose	33
6.2	General	33
6.3	Prerequisites	33
6.4	Recommended tools	33
6.5	Safety information	34
6.6	Procedure	35
7	Replace a A-020W-A	37
7.1	Purpose	37
7.2	General	37
7.3	Prerequisites	37
7.4	Recommended tools	37
7.5	Safety information	38
7.6	Procedure	39
8	Configure a A-020W-A	41
8.1	GUI configuration	41
8.1.1	Login	41
8.1.2	Device and connection status	42
8.1.3	Network configuration	53
8.1.4	Security configuration	71
8.1.5	Application configuration	82
8.1.6	Maintenance	88
8.1.7	RG troubleshooting counters	98

List of figures

2	ANSI safety guidelines	9
Figure 1	A-020W-A sample safety label	11
3	ETSI safety guidelines	15
Figure 2	A-020W-A sample safety label	17
4	ETSI environmental guidelines	21
Figure 3	Recycling/take back/disposal of product symbol	22
5	A-020W-A unit data sheet	23
Figure 4	A-020W-A CPE.....	25
Figure 5	A-020W-A physical connections.....	28
Figure 6	A-020W-A LEDs	29
Figure 7	Single-residence WiFi CPE with Gigabit Ethernet.....	31
6	Install a A-020W-A	33
Figure 8	A-020W-A connections.....	35
7	Replace a A-020W-A	37
Figure 9	A-020W-A connections.....	39
8	Configure a A-020W-A.....	41
Figure 10	Web login window.....	42
Figure 11	Device Information window.....	43
Figure 12	LAN status window	45
Figure 13	WAN Status window	47
Figure 14	WAN Status IPv6 window.....	49
Figure 15	Home Networking information window	51
Figure 16	Statistics window (LAN port statistics shown)	53
Figure 17	LAN settings window	54
Figure 18	LAN IPv6 network window.....	56
Figure 19	WAN window	58
Figure 20	WAN DHCP window	59
Figure 21	Wireless (2.4GHz) network window.....	61
Figure 22	Wireless (5GHz) network window.....	63
Figure 23	Wireless Schedule window.....	65
Figure 24	DNS network window	66
Figure 25	TR-069 network window	68
Figure 26	QoS Config window (L2).....	69
Figure 27	QoS Config window (L3).....	70
Figure 28	Firewall window	72
Figure 29	MAC filter window	74
Figure 30	IP filter window	76
Figure 31	URL Filter window	77
Figure 32	Parental Control window.....	78
Figure 33	DMZ and ALG window.....	80
Figure 34	Access Control window	81
Figure 35	Port forwarding window	83

Figure 36	Port Triggering window	84
Figure 37	DDNS window	86
Figure 38	NTP window	87
Figure 39	UPnP and DLNA window	88
Figure 40	Password window	90
Figure 41	Device Management window	91
Figure 42	Backup and Restore window	92
Figure 43	Firmware Upgrade window	93
Figure 44	Reboot Device window	94
Figure 45	Factory Default window	95
Figure 46	Diagnostics window	96
Figure 47	Log window	97
Figure 48	RG Troubleshooting Counters window	99

List of tables

2	ANSI safety guidelines	9
Table 1	Safety labels	10
Table 2	Responsible party contact information	11
3	ETSI safety guidelines	15
Table 3	Safety labels	16
Table 4	Responsible party contact information	17
5	A-020W-A unit data sheet	23
Table 5	Identification of A-020W-A	23
Table 6	A-020W-A interface connection capacity	27
Table 7	A-020W-A physical connections	28
Table 8	A-020W-A LEDs	29
Table 9	A-020W-A physical specifications	30
Table 10	A-020W-A power consumption specifications	30
Table 11	A-020W-A environmental specifications	30
8	Configure a A-020W-A	41
Table 12	Device Information parameters	43
Table 13	LAN status parameters	46
Table 14	WAN Status parameters	47
Table 15	WAN status IPv6 parameters	49
Table 16	Home Networking parameters	51
Table 17	LAN parameters	54
Table 18	LAN IPv6 network parameters	56
Table 19	WAN parameters	58
Table 20	WAN DHCP parameters	60
Table 21	Wireless 2.4GHz network parameters	61
Table 22	Wireless 5GHz network parameters	64
Table 23	DNS network parameters	67
Table 24	TR-069 network parameters	68
Table 25	QoS Config parameters	71
Table 26	Firewall parameters	73
Table 27	MAC filter parameters	75
Table 28	IP filter parameters	76
Table 29	URL Filter parameters	78
Table 30	Parental control parameters	79
Table 31	DMZ and ALG parameters	80
Table 32	Access control parameters	82
Table 33	Port forwarding parameters	83
Table 34	Port triggering parameters	84
Table 35	DDNS parameters	86
Table 36	Password parameters	90
Table 37	Device Management parameters	91
Table 38	RG Troubleshooting Counters parameters	99

2 ANSI safety guidelines

This chapter provides information about the mandatory regulations that govern the installation and operation of A-020W-A CPE equipment in the North American or ANSI market.

2.1 Safety instructions

This section describes the safety instructions that are provided in the customer documentation and on the equipment.

2.1.1 Safety instruction boxes in customer documentation

The safety instruction boxes are provided in the customer documentation. Observe the instructions to meet safety requirements.

The following is an example of the Danger box.



Danger — Possibility of personal injury.

The Danger box indicates that the described activity or situation may pose a threat to personal safety. It calls attention to a situation or procedure which, if not correctly performed or adhered to, may result in death or serious physical harm.

Do not proceed beyond a Danger box until the indicated conditions are fully understood and met.

The following is an example of the Warning box.



Warning 1 — Possibility of equipment damage.

Warning 2 — Possibility of data loss.

The Warning box indicates that the described activity or situation may, or will, cause equipment damage, loss of data, or serious performance problems. It identifies a possible equipment-damaging situation or provides essential information to avoid the degradation of system operations or data.

Do not proceed beyond a warning until the indicated conditions are fully understood and met.

The following is an example of the Caution box.



Caution 1 — Possibility of service interruption.

Caution 2 — Service interruption.

The Caution box indicates that the described activity or situation may, or will, cause service interruption.

Do not proceed beyond a caution until the indicated conditions are fully understood and met.

The following is an example of the Note box.



Note — Information of special interest.

The Note box provides information that assists the personnel working with A-020W-A CPE equipment. It does not provide safety-related instructions.

2.1.2 Safety-related labels

The A-020W-A CPE equipment is labeled with specific safety compliance information and instructions that are related to a variant of the A-020W-A. Observe the instructions on the safety labels.


Table 1 provides examples of the text in the various A-020W-A CPE safety labels.

Table 1 **Safety labels**

Label text	Description
ETL compliance	Communication service equipment US listed.
ESD warning	Caution: This assembly contains electrostatic sensitive device.
FCC standards compliance	Tested to comply with FCC standards for home or office use.

Figure 1 shows a sample safety label for the A-020W-A CPE, located on the base of the unit.

Figure 1 A-020W-A sample safety label



2.2 Safety standards compliance

This section describes the A-020W-A CPE compliance with North American safety standards. The A-020W-A is compliant with CE, FCC, CB and ETL requirements.



Warning — Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2.2.1 Responsible party

Table 2 lists the party in the US responsible for this device.

Table 2 Responsible party contact information

Legal Company name	Nokia USA Inc.
Address	2301 SUGAR BUSH RD. STE 300, RALEIGH, NC 27612
Phone, Fax	+1 866 582-3688

2.2.2 Energy-related products standby and off modes compliance

Hereby, Nokia declares that the A-020W-A CPE devices are in compliance with the essential requirements and other relevant provisions of Directive 2009/125/EC together with Commission Regulation (EC) No 1275/2008 and Commission Regulation (EC) No 801/2013.

The A-020W-A CPE devices qualify as high network availability (HiNA) equipment. Since the main purpose of A-020W-A devices is to provide network functionality with HiNA 7 days /24 hours, the modes Off/Standby, Power Management, and Networked Standby are inappropriate.

For information about the type and number of network ports, see [“A-020W-A interfaces and interface capacity”](#) in chapter 5.

For information about power consumption, see [“A-020W-A detailed specifications”](#) in chapter 5.

2.2.3 FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2.2.4 FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1 this device may not cause harmful interference, and
- 2 this device must accept any interference received, including interference that may cause undesired operation.



Caution — Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2.2.5 Resistibility requirements compliance

The A-020W-A CPE equipment complies with the requirements of ITU Recommendation K.21 for resistibility of telecommunication equipment installed in customer premises to overvoltage and overcurrents.

2.3 Electrical safety guidelines

This section provides the electrical safety guidelines for the A-020W-A CPE equipment.



Note — The devices comply with the U.S. National Electrical Code. However, local electrical authorities have jurisdiction when there are differences between the local and U.S. standards.

2.3.1 Power supplies

The use of any non-Nokia approved power supplies or power adapters is not supported or endorsed by Nokia. Such use will void any warranty or support contract with Nokia. Such use greatly increases the danger of damage to equipment or property.

2.3.2 Cabling

The following are the guidelines regarding cables used for the A-020W-A CPE equipment:

- Use only cables approved by the relevant national electrical code.

3 ETSI safety guidelines

This chapter provides information about the mandatory regulations that govern the installation and operation of A-020W-A CPE equipment.

3.1 Safety instructions

This section describes the safety instructions that are provided in the customer documentation and on the equipment.

3.1.1 Safety instruction boxes

The safety instruction boxes are provided in the customer documentation. Observe the instructions to meet safety requirements.

The following is an example of the Danger box.



Danger — Possibility of personal injury.

The Danger box indicates that the described activity or situation may pose a threat to personal safety. It calls attention to a situation or procedure which, if not correctly performed or adhered to, may result in death or serious physical harm.

Do not proceed beyond a Danger box until the indicated conditions are fully understood and met.

The following is an example of the Warning box.



Warning 1 — Possibility of equipment damage.

Warning 2 — Possibility of data loss.

The Warning box indicates that the described activity or situation may, or will, cause equipment damage, loss of data, or serious performance problems. It identifies a possible equipment-damaging situation or provides essential information to avoid the degradation of system operations or data.

Do not proceed beyond a warning until the indicated conditions are fully understood and met.

The following is an example of the Caution box.



Caution 1 — Possibility of service interruption.

Caution 2 — Service interruption.

The Caution box indicates that the described activity or situation may, or will, cause service interruption.

Do not proceed beyond a caution until the indicated conditions are fully understood and met.

The following is an example of the Note box.



Note — Information of special interest.

The Note box provides information that assists the personnel working with A-020W-A CPE equipment. It does not provide safety-related instructions.

3.1.2 Safety-related labels

The A-020W-A CPE equipment is labeled with the specific safety instructions and compliance information that is related to a variant of the A-020W-A. Observe the instructions on the safety labels.


Table 3 provides sample safety labels on the A-020W-A CPE equipment.

Table 3 **Safety labels**

Label Text	Description
ESD warning	Caution: This assembly contains an electrostatic sensitive device.
CE marking	Indicates compliance to the European Council Directives, including the EN60950-1 safety

Figure 2 shows a sample safety label for the A-020W-A CPE, located on the base of the unit.

Figure 2 A-020W-A sample safety label



3.2 Safety standards compliance

This section describes the device compliance with European safety standards.



Warning — Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

3.2.1 Responsible party

Table 4 lists the party in the US responsible for this device.

Table 4 Responsible party contact information

Legal Company name	Nokia USA Inc.
Address	2301 SUGAR BUSH RD. STE 300, RALEIGH, NC 27612
Phone, Fax	+1 866 582-3688

3.2.2 Energy-related products standby and off modes compliance

Hereby, Nokia declares that the A-020W-A CPE devices are in compliance with the essential requirements and other relevant provisions of Directive 2009/125/EC together with Commission Regulation (EC) No 1275/2008 and Commission Regulation (EC) No 801/2013.

The A-020W-A CPE devices qualify as high network availability (HiNA) equipment. Since the main purpose of A-020W-A devices is to provide network functionality with HiNA 7 days /24 hours, the modes Off/Standby, Power Management, and Networked Standby are inappropriate.

For information about the type and number of network ports, see [“A-020W-A interfaces and interface capacity”](#) in chapter 5.

For information about power consumption, see [“A-020W-A detailed specifications”](#) in chapter 5.

3.2.3 EMC and RED compliance

The A-020W-A CPE equipment complies with the following EMC, EMI, and ESD requirements:

- EN 300-386: Electromagnetic Compatibility and Radio Spectrum Matters (ERM): Telecommunications Network Equipment; Electromagnetic Compatibility (EMC) requirements; Electrostatic Discharge (ESD) requirements
- European Council Directive 2014/30/EU
- European Council Directive 2014/53/EU
- EN300328: Wide band transmission systems; data transmission equipment operating in the 2.4 GHz ISM band using wide band modulation techniques
- EN301893: 5 GHz RLAN
- EN50385: Compliance of base station equipment with a radio frequency of electromagnetic field exposure limits (110MHz-100GHz)

3.2.4 Equipment safety standard compliance

The A-020W-A CPE equipment complies with the requirements of EN 62368-1, Safety of Information Technology Equipment for use in a restricted location.

3.2.5 Environmental standard compliance

The A-020W-A CPE equipment complies with the following EN 300 019 European environmental standards:

- ETS 300 019-2-1 Storage Class T1.1
- ETS 300 019-2-2 Transport Class T2.3
- ETS 300 019-2-3 Stationary Class T3.1E

3.2.6 Resistibility requirements compliance

The A-020W-A CPE equipment complies with the requirements of ITU Recommendation K.21 for resistibility of telecommunication equipment installed in customer premises to over voltage and overcurrents.

3.3 Electrical safety guidelines

This section provides the electrical safety guidelines for the A-020W-A CPE equipment.



Note — The devices comply with BS EN 61140.

3.3.1 Power supplies

The use of any non-Nokia approved power supplies or power adapters is not supported or endorsed by Nokia. Such use will void any warranty or support contract with Nokia. Such use greatly increases the danger of damage to equipment or property.

3.3.2 Cabling

The following are the guidelines regarding cables used for the A-020W-A CPE equipment:

- All cables must be approved by the relevant national electrical code.

4 ETSI environmental guidelines

This chapter provides information about the ETSI environmental regulations that govern the installation and operation of A-020W-A CPE equipment. This chapter also includes environmental operation parameters of general interest.

This section describes the environmental instructions that are provided with the customer documentation, equipment, and location where the equipment resides.

4.1 Environmental requirements

See the technical specification documentation for more information about temperature ranges.

4.1.1 Transportation

According to EN 300-019-1-2 - Class 2.3, transportation of the equipment must be in packed, public transportation with no rain on packing allowed.

4.1.2 EU RoHS

European Union (EU) Directive 2011/65/EU, "Restriction of the use of certain Hazardous Substances" (RoHS), restricts the use of lead, mercury, cadmium, hexavalent chromium, and certain flame retardants in electrical and electronic equipment. Nokia products shipped to the EU comply with the EU RoHS Directive. Nokia has implemented a material/substance content management process. The process is described in: Nokia process for ensuring RoHS Compliance (1AA002660031ASZZA). This ensures compliance with the European Union Directive 2011/65/EU on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment.

4.1.3 End-of-life collection and treatment

Electronic products bearing or referencing the symbol shown in Figure 3, when put on the market within the European Union (EU), shall be collected and treated at the end of their useful life, in compliance with applicable EU and local legislation. They shall not be disposed of as part of unsorted municipal waste. Due to materials that may be contained in the product, such as heavy metals or batteries, the environment and human health may be negatively impacted as a result of inappropriate disposal.



Note — In the European Union, a solid bar under the symbol for a crossed-out wheeled bin indicates that the product was put on the market after 13 August 2005.

Figure 3 Recycling/take back/disposal of product symbol



About mark is used in compliance to European Union WEEE Directive (2012/19/EU).

There can be different requirements for collection and treatment in different member states of the European Union.

In compliance with legal requirements and contractual agreements, where applicable, Nokia will offer to provide for the collection and treatment of Nokia products bearing the logo shown in Figure 3 at the end of their useful life, or products displaced by Nokia equipment offers. For information regarding take-back of equipment by Nokia, or for more information regarding the requirements for recycling/disposal of product, contact your Nokia account manager or Nokia take back support at sustainability.global@nokia.com.

5 A-020W-A unit data sheet

5.1 A-020W-A part numbers and identification

5.2 A-020W-A general description

5.3 A-020W-A software and installation feature support

5.4 A-020W-A interfaces and interface capacity

5.5 A-020W-A LEDs

5.6 A-020W-A detailed specifications

5.7 A-020W-A functional blocks

5.8 A-020W-A standards compliance

5.9 A-020W-A special considerations

5.1 A-020W-A part numbers and identification

Table 5 provides part numbers and identification information for the A-020W-A CPE.

Table 5 Identification of A-020W-A

Ordering part number	Provisioning number	Description	CLEC	CPR	ECI/ Bar code
3FE 47471 AA	3FE 47511 AA	CPE with WiFi Wi-Fi Access Point and range extender, 2 Gigabit Ethernet UNI, dual bands 802.11ac 2x2 and 802.11n 2x2 WiFi; 12V/1A AC/DC US plug external power supply variant. The following accessories are included: <ul style="list-style-type: none"> CA_RJ45: 1 1.5m Yellow Power adapter: 1 1.5m Black Packing list: 1 A6 Normal 	—	—	—
3FE 47471 BA	3FE 47511 BA	CPE with Wi-Fi Access Point and range extender, 2 Gigabit Ethernet UNI, dual bands 802.11ac 2x2 and 802.11n 2x2 WiFi; 12V/1A AC/DC EU plug, 2-pin external power supply variant. The following accessories are included: <ul style="list-style-type: none"> CA_RJ45: 1 1.5m Yellow Power adapter: 1 1.5m Black Packing list: 1 A6 Normal 	—	—	—

(1 of 2)

Ordering part number	Provisioning number	Description	CLEC	CPR	ECI/ Bar code
3FE 47471 CA	3FE 47511 BA	CPE with Wi-Fi Access Point and range extender, 2 Gigabit Ethernet UNI, dual bands 802.11ac 2x2 and 802.11n 2x2 WiFi; 12V/1A AC/DC UK plug, 3-pin external power supply variant. The following accessories are included: <ul style="list-style-type: none"> CA_RJ45: 1 1.5m Yellow Power adapter: 1 1.5m Black Packing list: 1 A6 Normal 	—	—	—
3FE 47471 DA	3FE 47511 DA	CPE with Wi-Fi Access Point and range extender, 2 Gigabit Ethernet UNI, dual bands 802.11ac 2x2 and 802.11n 2x2 WiFi; 12V/1A AC/DC AU plug external power supply variant. The following accessories are included: <ul style="list-style-type: none"> CA_RJ45: 1 1.5m Yellow Power adapter: 1 1.5m Black Packing list: 1 A6 Normal 	—	—	—

(2 of 2)

5.2 A-020W-A general description


WiFi is abundantly deployed in home networks. Users require a seamless experience at home to connect their devices. Traditional WiFi networks require unique SSIDs for each of the access points or WiFi extenders, which complicated the user experience. The Nokia WiFi network simplifies the user experience by providing a seamless network and automating network optimization.

The Nokia WiFi solution includes a Nokia WiFi gateway, one or more Nokia WiFi beacons, the WiFi Care Portal for the customer care team of the operator, and a mobile application for end-user self care.

The A-020W-A CPE is an Ethernet residential gateway and WiFi beacon in the Nokia WiFi solution. The residential gateway is the central controller of the network while the beacon can extend the WiFi coverage to every corner of the home, providing seamless roaming to the connected devices.

The A-020W-A CPE has built-in concurrent dual-band WiFi 802.11b/g/n and 802.11ac networking with triple-play capability. A-020W-A devices can be configured using the Nokia WiFi Mobile App, which can be downloaded on both iOS and Android devices.

Figure 4 shows the A-020W-A CPE in its stand.

Figure 4 A-020W-A CPE

28229

A-020W-A CPEs provide the following functions:

- GE Ethernet uplink
- Concurrent 802.11n 2x2 MIMO in 2.4GHz and 802.11ac 2x2 MIMO in 5GHz
- auto-negotiation for speed and duplex on a port by port basis
- MDI/MDIX Ethernet auto-negotiation or manual configuration
- routed mode per LAN port
- Advanced data features: VLAN tag manipulation, classification, and filtering
- Traffic classification and QoS capability
- Internal Switch
- Line Rate L2 traffic
- UPnP IGD2.0 support
- Internal DHCP server, with configurable DHCP pool and gateway
- 64/128 WEP encryption
- WPA, WPA-PSK/TKIP
- WPA2, WPA2-PSK/AES
- support for multiple SSIDs (private and public instances); contact your Nokia representative for further details.
- WPS on/off button
- Ethernet-based Point-to-Point (PPPoE) and IP over Ethernet (IPoE)
- Network Address Translation (NAT)
- Network Address Port Translation (NAPT)

- TR-069 management
- ALG and UPnP port forwarding
- DMZ
- IP/MAC filter
- Multi-level firewall
- DNS server
- DHCP client/server
- support for HT40 and VHT80 modes for increased channel bandwidth
- support for up to 32 simultaneous wireless connections
- remote software image download

5.2.1 TR-069 object support for WiFi parameters

The A-020W-A CPE supports the status retrieval and configuration of the following WiFi parameters via TR-069:

- channel
- SSID
- password for WPA and WEP
- Tx power (transmission rate in dBm)

These are the same TR-069 object parameters that are supported in the GUI. For more information, see Tables 21 and 22 in the chapter “[Configure a A-020W-A](#)”.

5.2.2 Independent TR69 session with SaaS

The prime communication between the Nokia cloud management solution and the A-020W-A CPE is TR-069.

To keep the Nokia Home WiFi management independent from the ACS of the carrier, The device can establish an independent TR-069 session with the SaaS.

The SaaS WiFi Care URL and credentials can be programmed from the ACS solution of the carrier, or they can be incorporated in the device pre-configuration.

5.2.3 TR69 authentication using TLS and CA certificates

A-020W-A CPE devices support encrypted remote TR-069 management using TLS, as well as ACS authentication using SHA-256 pre-installed certificates.

If the ACS URL is set to the https://... format, by default, the connection will use TLS without authentication mode. The A-020W-A CPE can also authenticate the ACS using a pre-installed CA certificate.

5.3 A-020W-A software and installation feature support

For information on installing or replacing the A-020W-A CPE, see:

- [Install a A-020W-A](#)
- [Replace a A-020W-A](#)

5.4 A-020W-A interfaces and interface capacity


Table 6 describes the supported interfaces and interface capacity for A-020W-A CPE devices.

Table 6 A-020W-A interface connection capacity

Type and model	Maximum capacity								
	POTS	10/ 100 BASE-T	10/ 100/1000 1000 BASE-T	RF video (CATV)	MoCA	VDSL2	E1/T1	Local craft	GE uplink
A-020W-A	—	—	2	—	—	—	—	—	1

5.4.1 A-020W-A connections and components

Figure 5 shows the physical connections for A-020W-A CPE devices.

Figure 5 A-020W-A physical connections

28230

Table 7 describes the physical connections for A-020W-A CPE devices.


Table 7 A-020W-A physical connections

Connection	Description
On/Off button	This button powers the unit on or off.
LAN 1/LAN 2	This connection is provided through Ethernet RJ-45 connectors. Up to two 10/100/1000 Base-T Ethernet interfaces are supported. The Ethernet ports can support both data and in-band video services on both interfaces.
WAN port	This connection is provided through an RJ-45 Gigabit Ethernet interface. One 10/100/1000 Base-T Ethernet interface is supported.
WPS ON/Off button	This button is used to start the WiFi Protected Setup (WPS) of new WiFi devices.
Reset button	Pressing the Reset button for less than 10 seconds reboots the device; pressing the Reset button for 10 seconds resets the device to the factory defaults.
Power input	This connection is provided through the power connector. A power cable fitted with a barrel connector is used to make the connection.

5.5 A-020W-A LEDs

Figure 6 shows the A-020W-A CPE LEDs.

Figure 6 A-020W-A LEDs



28229

Table 8 provides LED descriptions for the A-020W-A CPE.

Table 8 A-020W-A LEDs

Indicator	LED color and behavior	LED behavior description
Power	Green Off Red (default until software is running)	Power on Power off Failed on startup (for example corrupt flash), self test failed on startup, or self test failed during regular operation.
WPS (2.4G and 5G)	Green solid Green flashing Off Solid Red	WPS is successful (light turns off five minutes after successful WiFi setup) WPS is in progress (light turns off after two minutes if WPS is unsuccessful) WPS is not in progress WPS error or overlapped (lights for 20 s and then turns off)
INTERNET	Green solid Green flashing Red	RG mode: Internet is up, IP address is assigned Beacon mode: Connection to the access point is good, IP address is assigned RG mode: Attempting to connect to the Internet RG mode: Gateway has no Internet connection Beacon mode: No or poor connection to the access point

5.6 A-020W-A detailed specifications

Table 9 lists the physical specifications for the A-020W-A CPE.

Table 9 A-020W-A physical specifications

Description	Specification
Width	42.2 mm (1.66 in.)
Height	123.22 mm (4.85 in.)
Depth	112.64 mm (4.43 in.)
Weight [within ± 0.5 lb (0.23 kg)]	230g (0.5 lb)

Table 10 lists the power consumption specifications for the A-020W-A CPE.

Table 10 A-020W-A power consumption specifications

Maximum power (Not to exceed)	Condition	Minimum power	Condition
8 W	2 10/100/1000 Base-T Ethernet, WiFi operational	2 W	interfaces/services not provisioned

Table 11 lists the environmental specifications for the A-020W-A CPE.


Table 11 A-020W-A environmental specifications

Mounting method	Temperature range and humidity	Altitude
On desk or shelf	Operating: -5°C to 45°C (-23°F to 113°F) ambient temperature 5% to 95% relative humidity, non-condensing	Contact your Nokia technical support representative for more information
	Storage: -20°C to 85°C (-4°F to 185°F)	

5.7 A-020W-A functional blocks

A-020W-A CPE devices are single-residence units that support Wireless (WiFi) service. WiFi service on these devices is compliant with the IEEE 802.11 standard. In addition to the WiFi service, these devices transmit Ethernet packets to two RJ-45 Ethernet ports.

Figure 7 shows the functional blocks for the A-020W-A CPE.

Figure 7 Single-residence WiFi CPE with Gigabit Ethernet

28228

5.8 A-020W-A standards compliance

A-020W-A CPE devices are compliant with the following standards:

- IEEE 802.1D (bridging), 802.1p (QoS), 802.1q (VLAN)
- IEEE 802.3 (2012) (Ethernet standard)
- IEEE 802.11n/ac 2x2 (WiFi 5G) and 802.11b/g/n 2x2 (WiFi 2.4G)

5.9 A-020W-A special considerations

This section describes the special considerations for A-020W-A CPE devices.

5.9.1 WiFi service

A-020W-A CPE devices feature WiFi service as well as data services. WiFi is a wireless networking technology that uses radio waves to provide wireless HSI and network connections. This device complies with the IEEE 802.11 standards, which the WiFi Alliance defines as the basis for WiFi technology.

5.9.1.1 WiFi standards and certifications

The WiFi service on A-020W-A CPE devices support the following IEEE standards and WiFi Alliance certifications:

- compliant with IEEE 802.11 standards
- certified for IEEE 802.11b/g/n/ac standards
- WPA support including WPA-PSK
- certified for WPA2-Personal and WPA2-Enterprise

5.9.1.2 WiFi GUI features

A-020W-A CPE devices have HTML-based WiFi configuration GUIs.

In addition to the traditional web-based GUI, the home user can download and use a mobile app for managing the A-020W-A CPE.

5.9.2 A-020W-A considerations and limitations

None.

6 Install a A-020W-A

6.1 Purpose

6.2 General

6.3 Prerequisites

6.4 Recommended tools

6.5 Safety information

6.6 Procedure

6.1 Purpose

This chapter provides the steps to install a A-020W-A CPE.

6.2 General

The steps listed in this chapter describe mounting and cabling for a A-020W-A CPE.

6.3 Prerequisites

You need the following items before beginning the installation:

- all required cables

6.4 Recommended tools

You need the following tools for the installation:

- RJ-45 Ethernet cable
- paper clip

6.5 Safety information

Read the following safety information before installing the unit.



Danger 1 — Hazardous electrical voltages and currents can cause serious physical harm or death. Always use insulated tools and follow proper safety precautions when connecting or disconnecting power circuits.

Danger 2 — Make sure all sources of power are turned off and have no live voltages present on feed lines or terminals. Use a voltmeter to measure for voltage before proceeding.

Danger 3 — Always contact the local utility company before connecting the enclosure to the utilities.



Caution — Keep indoor devices out of direct sunlight. Prolonged exposure to direct sunlight can damage the unit.



Note 1 — Observe the local and national laws and regulations that may be applicable to this installation.

Note 2 — Observe the following:

- The device should be installed in accordance with the applicable requirements of the NEC or CEC. Local authorities and practices take precedent when there is conflict between the local standard and the NEC or CEC.
- The device must be installed by qualified service personnel.
- Indoor units must be installed with cables that are suitably rated and listed for indoor use.
- See the detailed specifications in the [A-020W-A unit data sheet](#) for the temperature ranges for these devices.

6.6 Procedure

Use this procedure to install a A-020W-A CPE.

-
- 1 Place the unit on a flat surface, such as a desk or shelf.




Note — The A-020W-A CPE cannot be stacked with another A-020W-A or with other equipment. The installation requirements are:

- allow a minimum 100 mm clearance above the top cover
- allow a minimum 50 mm clearance from the side vents
- do not place any heat source directly above the top cover or below the bottom cover

-
- 2 Review the connection locations as shown in Figures 8.

Figure 8 **A-020W-A connections**



28230

-
- 3 Connect the Ethernet cables to the RJ-45 ports; see Figure 8 for the location of the RJ-45 ports.
 - 4 Connect the WAN cable to the RJ-45 WAN port; see Figure 8 for the location of the RJ-45 WAN port.

5 Connect the power cable to the power connector.



Note — Observe the following:

- Units must be powered by a Listed or CE approved and marked limited power source power supply with a minimum output rate of 12 V dc, 1 A. The polarity of the power adapter plug must match the A-020W-A CPE.

6 Power up the unit by using the On/Off power switch.

7 Verify the LEDs and voltage status.

8 Activate and test the services.

9 If necessary, reset the A-020W-A CPE.



Note — Resetting the device will return all settings to factory default values; any configuration customization will be lost.

- Locate the Reset button as shown in Figure 8.
- Insert the end of a straightened paper clip or other narrow object into the hole in the Reset button to reset the device.

10 STOP. This procedure is complete.

7 Replace a A-020W-A

7.1 Purpose

7.2 General

7.3 Prerequisites

7.4 Recommended tools

7.5 Safety information

7.6 Procedure

7.1 Purpose

This chapter provides the steps to replace a A-020W-A CPE.

7.2 General

The steps listed in this chapter describe mounting and cabling for a A-020W-A CPE.

7.3 Prerequisites

You need the following items before beginning the installation:

- all required cables

7.4 Recommended tools

You need the following tools for replacing the A-020W-A CPE:

- RJ-45 Ethernet cable
- paper clip

7.5 Safety information

Read the following safety information before replacing the unit.



Danger 1 — Hazardous electrical voltages and currents can cause serious physical harm or death. Always use insulated tools and follow proper safety precautions when connecting or disconnecting power circuits.

Danger 2 — Make sure all sources of power are turned off and have no live voltages present on feed lines or terminals. Use a voltmeter to measure for voltage before proceeding.

Danger 3 — Always contact the local utility company before connecting the enclosure to the utilities.



Caution — Keep indoor devices out of direct sunlight. Prolonged exposure to direct sunlight can damage the unit.



Note 1 — Observe the local and national laws and regulations that may be applicable to this installation.

Note 2 — Observe the following:


- The device should be installed in accordance with the applicable requirements of the NEC or CEC. Local authorities and practices take precedent when there is conflict between the local standard and the NEC or CEC.
- The device must be installed by qualified service personnel.
- Indoor units must be installed with cables that are suitably rated and listed for indoor use.
- See the detailed specifications in the [A-020W-A unit data sheet](#) for the temperature ranges for these devices.

7.6 Procedure

Use this procedure to replace a A-020W-A CPE.

-
- 1 Power down the unit by using the on/off power switch. See Figure 9 for the connections on the A-020W-A CPE.

Figure 9 A-020W-A connections



28230

-
- 2 Disconnect the WAN, Ethernet, and power cables from the A-020W-A CPE; see Figure 9 for the connector locations on the A-020W-A.
 - 3 Replace the A-020W-A CPE with the new A-020W-A. The device can be placed on any flat surface, such as a desk or shelf.
 - 4 Connect the Ethernet cables directly to the RJ-45 ports; see Figure 9 for the location of the RJ-45 ports.
 - 5 Connect the WAN cable directly to the RJ-45 port; see Figure 9 for the location of the RJ-45 WAN port.

6 Connect the power cable to the power connector.



Note — Observe the following:

- Units must be powered by a Listed or CE approved and marked limited power source with a minimum output rate of 12 V dc, 1 A. The polarity of the power adapter plug must match the A-020W-A CPE.

7 Power up the unit by using the On/Off power button.

8 Verify the LEDs and voltage status.

9 Activate and test the services.

10 If necessary, reset the A-020W-A CPE.



Note — Resetting the device will return all settings to factory default values; any configuration customization will be lost.

- Locate the Reset button on a A-020W-A CPE, as shown in Figure 9.
- Insert the end of a straightened paper clip or other narrow object into the hole in the Reset button to reset the device.

11 STOP. This procedure is complete.

8 Configure a A-020W-A

8.1 GUI configuration

8.1 GUI configuration

Use the procedures below to use the web-based GUI for the A-020W-A CPE.

The A-020W-A CPE is used as an Ethernet gateway to connect devices in the home to the Internet. The GUI provides a variety of features for the home network including routing and firewall capability. By using the GUI, users can configure the right network connectivity for all equipment in their home, including personal computers, set-top boxes, mobile phones, and other consumer electronics devices, to the Internet.

8.1.1 Login

Use the procedure below to login to the web-based GUI for the A-020W-A CPE.

Procedure 6 Login to web-based GUI


-
- 1 Open a web browser and enter the IP address of the A-020W-A CPE in the address bar.

The login window appears.

The default gateway IP address is `http://192.168.18.1`. You can connect to this IP address using your web browser after connecting your PC to one of Ethernet ports of the A-020W-A CPE. The static IP address of your PC must be in the same 192.168.18.x subnet as the A-020W-A.

-
- 2 Enter your username and password in the Log in window, as shown in Figure 10.

The default user name is admin. The default password is a random number, which is included in the A-020W-A CPE kit.

Figure 10 Web login windowThe image shows a web login window titled "Ethernet Gateway". It has a teal header bar with the title. Below the header, there are two input fields: "Username" and "Password", each with a corresponding text box. At the bottom of the window, there are two buttons: "Login" and "Reset".

Ethernet Gateway	
Username	<input type="text"/>
Password	<input type="password"/>
<div>Login Reset</div>	



Caution — If you forget the current username and password, press the reset button for 10s and the default values for the username and password will be recovered at startup.

Pressing the Reset button for less than 10 seconds reboots the A-020W-A CPE; pressing the Reset button for 10 seconds resets the A-020W-A to the factory defaults.

3 Click Login. The Device Information screen appears.



Note — To help protect the security of your Internet connection, the application displays a pop-up reminder to change both the WiFi password and the A-020W-A CPE password.

To increase password security, use a minimum of 10 characters, consisting of a mix of numbers and upper and lowercase letters.

4 STOP. This procedure is complete.

8.1.2 Device and connection status

The A-020W-A CPE supports the retrieval of a variety of device and connection information, including:

- device information
- LAN status
- WAN status
- WAN status IPv6

- home networking information
- statistics

Procedure 7 Device information retrieval

- 1 Select Status > Device Information from the top-level menu in the Ethernet Gateway window, as shown in Figure 11.

Figure 11 Device Information window




Table 12 describes the fields in the Device Information window.

Table 12 Device Information parameters

Field	Description
Device Name	Mnemonic of the A-020W-A CPE
Vendor	Name of the vendor
Serial Number	Serial number of the A-020W-A CPE
Hardware version	Hardware version of the A-020W-A CPE
Boot version	Boot version of the A-020W-A CPE
Software version	Software version of the A-020W-A CPE
Chipset	Chipset of the A-020W-A CPE

(1 of 2)

Field	Description
Device Running Time	Amount of time the device has run since last reset in hours, minutes, and seconds

(2 of 2)

2 Click Refresh to update the displayed information.

3 STOP. This procedure is complete.

Procedure 8 LAN status retrieval

- 1
- Select Status > LAN Status from the top-level menu in the Ethernet Gateway window, as shown in Figure 12.

Figure 12 LAN status window




Table 13 describes the fields in the LAN status window.

Table 13 LAN status parameters

Field	Description
Wireless Information	
Wireless Status	Indicates whether the wireless is on or off
Wireless Channel	Wireless channel number
SSID Name	Name of each SSID
Wireless Encryption Status	Encryption type used on the wireless connection
Wireless Rx Packets	Number of packets received on the wireless connection
Wireless Tx Packets	Number of packets transmitted on the wireless connection
Wireless Rx Bytes	Number of bytes received on the wireless connection
Wireless Tx Bytes	Number of bytes transmitted on the wireless connection
Power Transmission (mW)	Power of the wireless transmission, in mW
Ethernet Information	
Ethernet Status	Indicates whether the Ethernet connection is on or off
Ethernet IP Address	IP address of the Ethernet connection
Ethernet Subnet Mask	Subnet Mask of the Ethernet connection
Ethernet MAC Address	MAC address of the Ethernet connection
Ethernet Rx Packets	Number of packets received on the Ethernet connection
Ethernet Tx Packets	Number of packets transmitted on the Ethernet connection
Ethernet Rx Bytes	Number of bytes received on the Ethernet connection
Ethernet Tx Bytes	Number of bytes transmitted on the Ethernet connection

2 Click Refresh to update the displayed information.

3 STOP. This procedure is complete.

Procedure 9 WAN status retrieval

- 1
- Select Status > WAN Status from the top-level menu in the Ethernet Gateway window, as shown in Figure 13.

Figure 13 WAN Status window




Table 14 describes the fields in the WAN Status window.

Table 14 WAN Status parameters

Field	Description
WAN connection list	Drop-down menu listing all WAN connections. The connection shown is the connection for which WAN status will be shown.
Connection Mode	Connection mode of the WAN connection
Enable/Disable	Select this checkbox to enable the WAN connection
VLAN	VLAN ID

(1 of 2)

Field	Description
WAN Link Status	Whether the WAN link is up or down
IPv4 Address	IPv4 address
Netmask	Netmask
Gateway	IPv4 gateway address
Primary DNS	Primary Domain Name Server
Second DNS	Secondary Domain Name Server
Ethernet Link Status	Whether the PON link is up or down
Tx Packets	Number of packets transmitted on the WAN connection
Rx Packets	Number of packets received on the WAN connection
Tx Dropped	Number of packets dropped on the transmit WAN connection
Rx Dropped	Number of packets dropped on the receive WAN connection
Err Packets	Number of errored packets on the WAN connection

(2 of 2)

2 Click Refresh to update the displayed information.

3 STOP. This procedure is complete.

Procedure 10 WAN status IPv6 retrieval

- 1 Select Status > WAN Status IPv6 from the top-level menu in the Ethernet Gateway window, as shown in Figure 14.

Figure 14 WAN Status IPv6 window




Table 15 describes the fields in the WAN status IPv6 window.

Table 15 WAN status IPv6 parameters

Field	Description
WAN connection list	Drop-down menu listing all WAN connections. The connection selected is the connection for which WAN status will be shown.
Enable/Disable	Select this check box to enable the WAN connection
VLAN	VLAN ID
WAN Link Status	Whether the WAN link is up or down
IPv6 Address	IPv6 address that identifies the device and its location
IPv6 Prefix	IPv6 prefix

(1 of 2)

Field	Description
IPv6 Gateway	IPv6 gateway address
Primary DNS	Primary Domain Name Server address
Second DNS	Secondary Domain Name Server address
Ethernet Link Status	Whether the link is up or down
Tx Packets	Number of packets transmitted on the WAN connection
Rx Packets	Number of packets received on the WAN connection
Tx Dropped	Number of packets dropped on the transmit WAN connection
Rx Dropped	Number of packets dropped on the receive WAN connection
Err Packets	Number of errored packets on the WAN connection

(2 of 2)

2 Click Refresh to update the displayed information.

3 STOP. This procedure is complete.

Procedure 11 Home networking information retrieval

- 1
- Select Status > Home Networking from the top-level menu in the Ethernet Gateway window, as shown in Figure 15.

Figure 15 Home Networking information window




Table 16 describes the fields in the Home Networking window.

Table 16 Home Networking parameters

Field	Description
Local Interface	
Ethernet	Table displays the number of Ethernet connections and their settings
Wireless	Table displays the number of wireless connections and their settings
Wireless Settings	

(1 of 2)

Field	Description
Network Name	Name of the wireless network access point
Access Point	Hexadecimal address of the wireless access point
Local Devices	
Table entry	Each entry indicates the status (active or inactive), connection type, device name, IP address, hardware address, and IP address allocation of each connected local device.

(2 of 2)

2 Click Delete to delete a particular local device connection.

3 Click Refresh to update the displayed information.

4 STOP. This procedure is complete.


Procedure 12 Statistics retrieval

1 Select Status > Statistics from the top-level menu in the Ethernet Gateway window.

Statistics are available for LAN ports, WAN ports, and WLAN.

Figure 16 shows the statistics for the LAN ports.

Figure 16 Statistics window (LAN port statistics shown)



- 2 Click Refresh to update the displayed information.
- 3 STOP. This procedure is complete.

8.1.3 Network configuration

The A-020W-A CPE also supports network configuration, including:

- LAN
- LAN IPv6
- WAN
- WAN DHCP
- Wireless 2.4G
- Wireless 5G
- wireless schedule
- DNS

- TR-069
- QoS Configuration

Procedure 13 LAN configuration

- 1 Select Network > LAN from the top-level menu in the Ethernet Gateway window, as shown in Figure 17.

Figure 17 LAN settings window

NOKIA

Status

Network

LAN

LAN IPv6

WAN

WAN DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

DNS

TR-069

QoS Config

Security

Application

Maintenance

RG Troubleshooting

Ethernet Gateway

Logout

English | Español

Network>LAN

IPv4 Address

192.168.18.1

Subnet Mask

255.255.255.0

DHCP Enable

☒

DHCP Start IP Address

192.168.18.2

DHCP End IP Address

192.168.18.253

DHCP Lease Time

1440

(2~129600 mins, or 0 means 1 day)mins.

Primary DNS

Secondary DNS

Save

Refresh

Static DHCP Entry

MAC Address

IPv4 Address

Add

MAC Address

IPv4 Address

Delete

Table 17 describes the fields in the LAN window.

Table 17 LAN parameters

Field	Description
IPv4 Address	IP Address of the A-020W-A CPE
Subnet Mask	Subnet mask of the A-020W-A CPE
DHCP enable	Select this check box to enable DHCP
DHCP Start IP Address	Starting DHCP IP address

(1 of 2)

Field	Description
DHCP End IP Address	Ending DHCP IP address
DHCP Lease Time	DHCP lease time (in min)
Primary DNS	Primary domain name server address
Secondary DNS	Secondary domain name server address
Static DHCP MAC Address	Hexadecimal MAC address to associate to the LAN
Static DHCP IP Address	IP address to associate to the bound MAC address

(2 of 2)

2 Configure the LAN.

3 Click Save.

4 Bind a MAC address to the LAN by entering the MAC and IP addresses in the Static DHCP Entry fields and then clicking Add. Repeat for all MAC addresses to be bound.

5 STOP. This procedure is complete.

Procedure 14 LAN IPv6 networking configuration

- 1 Select Network > LAN_IPv6 from the top-level menu in the Ethernet Gateway window, as shown in Figure 18.

Figure 18 LAN IPv6 network window

NOKIA

Status

Network

LAN

LAN_IPv6

WAN

WAN DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

DNS

TR-069

QoS Config

Security

Application

Maintenance

RG Troubleshooting

Ethernet Gateway

Logout

English | Español

Network>LAN_IPv6

IPv6 LAN Host Configuration

DNS Server

HGWProxy

Prefix Config

WANConnection

Interface

DHCPv6 Server Pool

DHCP Start IP Address

0:0:0:2

DHCP End IP Address

0:0:0:255

Whether the address info through DHCP

Whether other info obtained through DHCP

Maximum interval for periodic RA messages

600

seconds

Minimum interval for periodic RA messages

200

seconds

Save/Apply

Table 18 describes the fields in the LAN IPv6 network window.

Table 18 LAN IPv6 network parameters

Field	Description
DNS Server	Choose a DNS server from the drop-down menu.
Prefix Config	Choose a prefix config option from the drop-down menu, either WANConnection (prefix will be obtained from the WAN) or Static (enables you to enter the prefix).
Prefix	This field appears if you selected the “Static” option for the “prefix config” field. Type a connection.
Interface	This field appears if you selected the Wan Connection option for the “prefix config” field. Choose a WAN connection interface from the drop-down menu.

(1 of 2)

Field	Description
DHCP Start IP Address	Enter the starting DHCP IP address.
DHCP End IP Address	Enter the ending DHCP IP address.
Whether the address info through DHCP	Select this check box to enable address information retrieval through DHCP.
Whether other info obtained through DHCP	Select this check box to enable retrieval of other information through DHCP.
Maximum interval for periodic RA messages	Enter the maximum interval (in seconds) for periodic Router Advertisement messages. The interval range is from 4 to 1800.
Minimum interval for periodic RA messages	Enter the minimum interval (in seconds) for periodic Router Advertisement messages. The interval range is from 4 to 1800.

(2 of 2)

2 Choose a DNS server, Prefix Config, and Interface.

3 Enter the DHCP configuration information.

4 Enter the maximum and minimum intervals for RA messages.

5 Click Save/Apply.

6 STOP. This procedure is complete.

Procedure 15 WAN networking configuration

- 1 Select Network > WAN from the top-level menu in the Ethernet Gateway window, as shown in Figure 19.

Figure 19 WAN window

NOKIA

Status

Network

LAN

LAN_IPv6

WAN

WAN DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

DNS

TR-069

QoS Config

Security

Application

Maintenance

RG Troubleshooting

Ethernet Gateway

Logout

English | Español

Network>WAN

WAN Connection List

Create One New Connection

Connection Type

☒IPoE ☐PPPoE

IP mode

IPv4

Enable/Disable

☐

NAT

☒

Service

☐TR-069 ☐INTERNET ☐PTV

Enable VLAN

☒

VLAN ID

VLAN PRI

WAN IP Mode

DHCP

Manual DNS

Save

Delete

Table 19 describes the fields in the WAN window.

Table 19 WAN parameters

Field	Description
WAN Connection List	Choose a WAN connection from the drop-down menu to set the connection parameters
Connection Type	Select a connection type: IPoE or PPPoE
IP Mode	Choose an IP mode from the drop-down menu: IPv4 or IPv6
Enable/Disable	Select this checkbox to enable the WAN connection
NAT	Select this checkbox to enable NAT
Service	Select the checkboxes to enable service types for this connection
Enable VLAN	Select this checkbox to enable VLAN
VLAN ID	Enter the VLAN ID

(1 of 2)

Field	Description
VLAN PRI	Enter the VLAN PRI
WAN IP Mode	Choose an IP mode from the drop-down menu
Manual DNS	Enter a DNS

(2 of 2)

2 Configure a specific WAN connection.

3 Click Save.

4 STOP. This procedure is complete.

Procedure 16 WAN DHCP configuration

- 1 Select Network > WAN DHCP from the top-level menu in the Ethernet Gateway window, as shown in Figure 20.

Figure 20 WAN DHCP window

The screenshot shows the 'Ethernet Gateway' interface with the 'Network' menu selected. The left sidebar contains a tree view with 'WAN DHCP' highlighted. The main content area is titled 'Network > WAN DHCP' and contains a 'WAN Connection List' dropdown menu. Below this, there are three checkboxes: 'DHCP Option 50 Persistent', 'Enable DHCP Option 60', and 'Enable DHCP Option 61'. At the bottom right, there are 'Save' and 'Refresh' buttons. The top right of the interface shows 'Logout' and language links 'English | Español'.

Table 20 describes the fields in the WAN DHCP window.

Table 20 **WAN DHCP parameters**

Field	Description
WAN Connection List	Choose a WAN connection from the drop-down menu
DHCP Option 50 persistent	Select this checkbox to enable DHCP Option 50
Enable DHCP Option 60	Select this checkbox to enable DHCP Option 60 (vendor class identifier)
Enable DHCP Option 61	Select this checkbox to enable DHCP Option 61 (client identifier)

2 Configure a WAN DHCP option.

3 Click Save.

4 STOP. This procedure is complete.

Procedure 17 **Wireless (2.4GHz) networking configuration**

- 1
- Select Network > Wireless (2.4GHz) from the top-level menu in the Ethernet Gateway window, as shown in Figure 21.

Figure 21 Wireless (2.4GHz) network window

NOKIA

Ethernet Gateway

Logout

English | Español

Network>Wireless (2.4GHz)

Status

Network

LAN

LAN_IPV6

WAN

WAN_DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

DNS

TR-069

QoS Config

Security

Application

Maintenance

RG Troubleshooting

Enable

Mode

Bandwidth

Channel

Transmitting Power

WMM

Total MAX Users

☒

auto(b/g/n)

20MHz

Auto

100%

Enable

32

SSID Configuration

SSID Select

SSID Name

Enable SSID

SSID Broadcast

MAX Users

Encryption Mode

WPA Version

WPA Encryption Mode

WPA Key

Enable WPS

WPS Mode

SSID1

NOKIA-1910

Enable

Enable

32

WPA/WPA2 Personal

WPA2

AES

Enable

PBC

WPS Connect

Save

Refresh

Table 21 describes the fields in the Wireless 2.4GHz network window.

Table 21 Wireless 2.4GHz network parameters

Field	Description
Enable	Select this check box to enable WiFi

(1 of 2)

Field	Description
Mode	Choose a WiFi mode from the drop-down menu: <ul style="list-style-type: none"> • auto (b/g/n) • b • g • n • b/g
Bandwidth	Choose 20 MHz or 40 MHz from the drop-down menu.
Channel	Choose a channel from the drop-down menu or choose Auto to have the channel automatically assigned
Transmitting Power	Choose the percentage transmitting power from the drop-down menu
WMM	Select this check box to enable or disable wireless multi media
Total MAX Users	Enter the total number of MAX users
SSID Select	Choose the SSID from the drop-down menu
SSID Name	Enter the SSID name
Enable SSID	Enable or disable SSID from this drop-down menu
SSID Broadcast	Enable or disable SSID broadcast from this drop-down menu
MAX Users	Enter the number of MAX users
Encryption Mode	Choose an encryption mode from the drop-down menu: <ul style="list-style-type: none"> • OPEN • WEP • WPA/WPA2 Personal • WPA/WPA2 Enterprise
WPA Version	Choose a WPA version from the drop-down menu: <ul style="list-style-type: none"> • WPA1 • WPA2 • WPA1/WPA2
WPA Encryption Mode	Choose a WPA encryption mode from the drop-down menu: <ul style="list-style-type: none"> • TKIP • AES • TKIP/AES
WPA Key	Enter the WPA key
Enable WPS	Enable or disable WPS from this drop-down menu
WPS Mode	Select a WPS mode from the drop-down menu: PBC (Push Button Connect) or PIN (Personal Identification Number)

(2 of 2)

2 Configure the WiFi connection.

3 If you have enabled and configured WPS, click WPS connect.

- 4 Click Save.
- 5 STOP. This procedure is complete.

Procedure 18 Wireless (5GHz) networking configuration

- 1 Select Network > Wireless (5GHz) from the top-level menu in the Ethernet Gateway window, as shown in Figure 22.

Figure 22 Wireless (5GHz) network window

NOKIA

Ethernet Gateway

Logout

[English](#) | [Español](#)

Status

Network

LAN

LAN IPv6

WAN

WAN DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

DNS

TR-069

QoS Config

Security

Application

Maintenance

RG Troubleshooting

Network>Wireless (2.4GHz)

Enable☒

Mode

auto(b/g/n)

Bandwidth

20MHz

Channel

Auto

Transmitting Power

100%

WMM

Enable

Total MAX Users

32

SSID Configuration

SSID Select

SSID1

SSID Name

NOKIA-1910

Enable SSID

Enable

SSID Broadcast

Enable

MAX Users

32

Encryption Mode

WPA/WPA2 Personal

WPA Version

WPA2

WPA Encryption Mode

AES

WPA Key

☐ Show password

Enable WPS

Enable

WPS Mode

PBC

WPS Connect

Save

Refresh

Table 22 describes the fields in the Wireless 5GHz network window.

Table 22 Wireless 5GHz network parameters

Field	Description
Enable	Select this check box to enable WiFi
Bandwidth	Choose from: <ul style="list-style-type: none"> 20 MHz 40 MHz 80 MHz
Channel	Choose a channel from the drop-down menu or choose Auto to have the channel automatically assigned
Transmitting Power	Choose a percentage for the transmitting power from the drop-down menu: <ul style="list-style-type: none"> Low (20%) Medium (40%) High (60%) Maximum (100%)
WMM	Select this check box to enable or disable wireless multi media
Enable MU-MIMO	Choose Enable or disable MU-MIMO from this drop-down menu The default is Enable, which enables users and wireless terminals to communicate with each other. MU-MIMO may decrease WiFi performance for clients who do not support it, in which case Nokia recommends that you choose Disable.
Total MAX Users	Enter the total number of MAX users
DFS re-entry	Select this check box to enable or disable DFS re-entry
SSID Select	Choose the SSID from the drop-down menu
SSID Name	Change the name of the selected SSID
Enable SSID	Choose Enable or disable SSID from this drop-down menu
SSID Broadcast	Choose Enable or disable SSID broadcast from this drop-down menu
MAX Users	Enter the number of MAX users
Encryption Mode	Choose an encryption mode from the drop-down menu: <ul style="list-style-type: none"> OPEN WEP WPA/WPA2 Personal WPA/WPA2 Enterprise ⁽¹⁾⁽²⁾
WPA Key	Enter the WPA key
Enable WPS	Choose Enable or disable WPS from this drop-down menu

Notes


- (1) When Encryption Mode is set to "WPA/WPA2 Enterprise", the following options are no longer available: WPA version, WPA encryption mode, WPA key, Enable WPS, WPS mode.
- (2) When Encryption Mode is set to "WPA/WPA2 Enterprise", the following options become available: Primary RADIUS server, port and password; Secondary RADIUS server, port, and password; RADIUS accounting port.

- 2 Configure the Wireless connection.
- 3 If you have enabled and configured WPS, click WPS connect.
- 4 Click Save.
- 5 STOP. This procedure is complete.

Procedure 19 Wireless scheduling

- 1 Select Network > Wireless Schedule from the top-level menu in the Ethernet Gateway window, as shown in Figure 23.

Figure 23 Wireless Schedule window



- 2 Select the Schedule Function check box to turn the wireless signal off for the configured period.
- 3 Click the plus sign (+) to add a scheduling rule.
A separate panel appears for configuring wireless schedule rules.
- 4 Enter a start time and end time for the period in which you want the wireless signal off.

- 5

Choose Everyday or Individual Days from the drop-down menu.
- 6

If you chose Individual Days, select the check boxes for the desired days.

The Recurrence Pattern shows the rules created to date.
- 7

If desired, click the plus sign (+) to add more rules.
- 8

Click Save Changes.
- 9

STOP. This procedure is complete.

Procedure 20 DNS configuration

- 1

Select Network > DNS from the top-level menu in the Ethernet Gateway window, as shown in Figure 24.

Figure 24 DNS network window

NOKIA

Status

Network

LAN

LAN_IPv6

WAN

WAN_DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

DNS

TR-069

QoS Config

Security

Application

Maintenance

RG Troubleshooting

Ethernet Gateway

Logout

English | Español

Network>DNS

DNS Proxy

☒Enabled

Save

Domain Name

IPv4 Address

Add

Origin Domain

New Domain

Add

Domain Name	New Domain	IPv4 Address	Delete
www.Nokia-wifi.com		192.168.18.1	Delete

Origin Domain

New Domain

Delete

Refresh

Table 23 describes the fields in the DNS network window.

Table 23 **DNS network parameters**

Field	Description
DNS Proxy	Select this check box to enable DNS proxy
Domain Name	Domain name
IPv4 Address	Domain IP address
Origin Domain	Origin domain name
New Domain	New domain name

2 Enter the domain name and IP address and click Add.

3 If required, associate an origin domain with a new domain, click Add.

4 STOP. This procedure is complete.

Procedure 21 TR-069 configuration

- 1 Select Network > TR-069 from the top-level menu in the Ethernet Gateway window, as shown in Figure 25.

Figure 25 TR-069 network window

The screenshot shows the Nokia Ethernet Gateway web interface. The top header includes the Nokia logo, 'Ethernet Gateway', a 'Logout' link, and language options 'English | Español'. The left sidebar menu has 'Status' selected, and 'Network' is highlighted in red. Under 'Network', 'TR-069' is selected. The main content area is titled 'Network > TR-069' and contains the following configuration fields:

- Periodic Inform Enable: ☒
- Periodic Inform Interval(s):
- URL:
- Username:
- Password:
- Connect Request Username:
- Connect Request Password:

At the bottom right of the configuration area are 'Save' and 'Refresh' buttons.

Table 24 describes the fields in the TR-069 network window.

Table 24 TR-069 network parameters

Field	Description
Periodic Inform Enable	Select this check box to enable periodic inform updates
Periodic Inform Interval(s)	Time between periodic inform updates, in seconds
URL	URL of the auto-configuration server
Username	Username used to log in to the A-020W-A CPE
Password	Password used to log in to the A-020W-A CPE
Connect Request Username	Username used to log in to the auto-configuration server
Connect Request Password	Password used to log in to the auto-configuration server

- 2 Configure TR-069 by entering the required information.

- 3 Click Save.
- 4 STOP. This procedure is complete.

Procedure 22 QoS configuration

- 1 Select Network > QoS Config from the top-level menu in the Ethernet Gateway window.
- Figure 26 shows the window for configuring QoS L2 (Layer 2 packet sizes).

Figure 26 QoS Config window (L2)

NOKIA

Ethernet Gateway

Logout

English | Español

Network>QoS Config

Status

Network

LAN

LAN_IPv6

WAN

WAN_DHCP

Wireless_2.4GHz

Wireless_5GHz

Wireless_Schedule

DNS

TR-069

QoS Config

Security

Application

Maintenance

RG_Troubleshooting

QoS Setting

ID	Source MAC	Source MAC Exclude	Protocol	Protocol Exclude	Source Port	Source Max	SExclude	Dest Port	Dest Max	DExclude
----	------------	--------------------	----------	------------------	-------------	------------	----------	-----------	----------	----------

< >

Type

L2 Criteria

Classification Criteria

Source MAC

Exclude

Interface

select an option

Classification Result

DSCP Remark:

(Range:0~63)

802.1p Remark:

(Range:0~7)

Forwarding Policy:

(Range:1~7)

Add

Figure 27 shows the window for configuring QoS L3 (Layer 3 packet sizes).

Figure 27 QoS Config window (L3)

QoS Setting

ID	Source MAC	Source MAC Exclude	Protocol	Protocol Exclude	Source Port	Source Max	SExclude	Dest Port	Dest Max	DExclude
----	------------	--------------------	----------	------------------	-------------	------------	----------	-----------	----------	----------

Type

L3 Criteria

Classification Criteria

Protocol

None

Exclude

Application

Source Ip

Source Ip Mask

Exclude

Dest Ip

Dest Ip Mask

Exclude

Source Port

Source Port Max

Exclude

Dest Port

Dest Port Max

Exclude

Source Ip

Source Ip Mask

Exclude

Dest Ip

Dest Ip Mask

Exclude

Source Port

Source Port Max

Exclude

Dest Port

Dest Port Max

Exclude

802.1p

(Range:0~7)

Interface

select an option

Classification Result

802.1p Remark:

(Range:0~7)

DSCP Remark:

(Range:0~63)

Forwarding Policy:

(Range:1~7)

Add

Table 25 describes the fields in the QoS Config window.

Table 25 QoS Config parameters

Field	Description
Type	Choose a QoS service layer type from the drop-down menu, either L2 or L3.
Source MAC	Enter the source MAC. Select the Exclude check box to exclude the source MAC
Interface	Choose an interface from the drop-down menu
DSCP Remark	Enter the value for the DSCP mark (range: 0-63); valid only for L3 Criteria
802.1p Mark	Enter the value for the 802.1p (range: 0-7)
Forwarding Policy	Enter the number for the forwarding policy (range: 1-7)
Additional fields for L3	
Protocol	Choose a protocol from the drop-down menu, or select the Exclude check box
Application	Choose an application from the drop-down menu
Source IP and Source IP Mask	Enter the values for the source IP and IP mask, or select the Exclude check box
Destination IP and Destination IP Mask	Enter the values for the destination IP and IP mask, or select the Exclude check box
Source Port and Source Port Max	Enter the values for the source port and port max (highest port number) or select the Exclude check box
Destination Port and Destination Port Max	Enter the values for the destination port and port max (highest port number), or select the Exclude check box

2 Choose a QoS type from the drop-down menu: L2 or L3.

3 Configure a QoS policy.

4 Click Add to add a QoS policy.

5 STOP. This procedure is complete.

8.1.4 Security configuration

The A-020W-A CPE also supports security configuration, including:


- firewall
- MAC filter
- IP filter
- URL filter

- parental control
- DMZ and ALG
- access control

Procedure 23 Firewall configuration

- 1 Select Security > Firewall from the top-level menu in the Ethernet Gateway window, as shown in Figure 28.

Figure 28 Firewall window



Firewall security applies only to services provided by the A-020W-A CPE. Internet access from the LAN side is not affected by this firewall.

Three security levels are available: Off, Low, and High.

At the Off level, no firewall security is in effect,

At the Low level, pre-routing is supported: port forwarding, DMZ, host application, and host drop. Also supported are application services: DDNS, DHCP, DNS, H248, IGMP, NTP client, SSH, Telnet, TFTP, TR-069, and VoIP. The following types of ICMP messages are permitted: echo request and reply, destination unreachable, and TTL exceeded. Other types of ICMP messages are blocked. DNS proxy is supported from LAN to WAN but not from WAN to LAN.

At the High level, pre-routing and application services are not supported. UDP Port 8000 can be used to access the services, for example FTP can use 8021 and Telnet can use 8023. Regular UDP cannot be used. RG access is permitted via the LAN side but not via the WAN side.

Table 26 describes the fields in the firewall window.

Table 26 Firewall parameters

Field	Description
Security level	Choose the security level from the drop-down menu: Off, Low, or High
Attack Protect (Protection against DoS or DDoS attacks)	Choose enable or disable attack protect from the drop-down menu The default is disable

-
- 2 Configure the firewall.
 - 3 Click Save.
 - 4 STOP. This procedure is complete.
-

Procedure 24 MAC filter configuration

- 1
- Select Security > MAC Filter from the top-level menu in the Ethernet Gateway window, as shown in Figure 29.

Figure 29 MAC filter window

NOKIA

Ethernet Gateway

Logout

English | Español

Security>MAC Filter

Status

Network

Security

Firewall

MAC Filter

IP Filter

URL Filter

Parental Control

DMZ and ALG

Access Control

Application

Maintenance

RG Troubleshooting

Ethernet Interface

MAC Filter Mode

Allowed

LAN Port

☐ LAN1 ☐ LAN2

MAC Address

Custom settings

e.g: D0:54:2D:00:00:00

Save

Mac Address

Delete

Refresh

Wi-Fi SSID

MAC Filter Mode

Allowed

SSID Select

SSID1

Enable

☐

MAC Address

Custom settings

e.g: D0:54:2D:00:00:00

Save

Mac Address

Delete

Refresh

Table 27 describes the fields in the MAC filter window.

Table 27 **MAC filter parameters**

Field	Description
Ethernet Interface MAC filter	
MAC Filter Mode	Choose the MAC filter mode from this drop-down menu: Blocked or Allowed
LAN Port	Select the check boxes for the LAN ports
MAC Address	Choose a MAC address from the drop-down menu or enter the address in the text field
WiFi SSID (WLAN) MAC filter	
MAC Filter Mode	Choose the MAC filter mode from this drop-down menu: Blocked or Allowed
SSID Select	Choose an SSID option from the drop-down menu
Enable	Select this check box to enable MAC filtering for WiFi SSID
MAC Address	Choose a MAC address from the drop-down menu or enter the address in the text field

2 Configure a MAC filter for the Ethernet interface.

3 Click Save.

4 If desired, select a MAC address and click the Delete column to delete a MAC address.

5 Click Refresh to update the information.

6 Configure a MAC filter for WiFi SSID (WLAN MAC filter).

7 Click Save.

8 STOP. This procedure is complete.

Procedure 25 IP filter configuration

- 1 Select Security > IP filter from the top-level menu in the Ethernet Gateway window, as shown in Figure 30.

Figure 30 IP filter window

Table 28 describes the fields in the IP filter window.

Table 28 IP filter parameters

Field	Description
Enable IP Filter	Select this check box to enable an IP filter
Mode	Choose an IP filter mode from the drop-down menu: <ul style="list-style-type: none">Drop for upstreamDrop for downstream
Internal Client	Choose an internal client from the drop-down menu: <ul style="list-style-type: none">Customer setting - uses the IP address input belowIP - uses the connecting devices' IP to the device
Local IP Address	Local IP address
Source Subnet Mask	Source subnet mask
Remote IP Address	Remote IP address
Destination Subnet Mask	Destination subnet mask
Protocol	Choose an application protocol or all from the drop-down menu

- 2
- Configure the IP filter.
- 3
- Click Add.
- 4
- STOP. This procedure is complete.

Procedure 26 URL filter configuration

- 1
- Select Security > URL Filter from the top-level menu in the Ethernet Gateway window, as shown in Figure 31.

Figure 31 URL Filter window

NOKIA

Status

Network

Security

Firewall

MAC Filter

IP Filter

URL Filter

Parental Control

DMZ and ALG

Access Control

Application

Maintenance

RG Troubleshooting

Ethernet Gateway

Logout

English | Español

Security>URL Filter

URL Filter-- please select the type of filter and then configure the URL. Support up to 100 URL filters.

Enable URL filter

URL filter type:

Block

Allow

URL List

URL Address	Port Number	Delete
URL Address		
Port – default to 80		
Add Filter		



Note — You cannot use URL filtering for HTTPS. The URL is encrypted when using HTTPS.

Table 29 describes the fields in the URL Filter window.

Table 29 URL Filter parameters

Field	Description
Enable URL filter	Select the check box to enable the URL filter
URL filter type	Select the radio button for Exclude URL or Include URL
URL Address	Enter the URL address
Port	Enter the port number; the default is 80

- 2 Configure the URL Filter.
- 3 Click Add Filter.
- 4 STOP. This procedure is complete.

Procedure 27 Parental control

- 1 Select Security > Parent Control from the top-level menu in the Ethernet Gateway window, as shown in Figure 32.


Figure 32 Parental Control window

Table 30 describes the fields in the Parental Control window.

Table 30 Parental control parameters

Field	Description
Policy Name	Enter a name for the parental control policy or choose a policy from the list
Device	The device for which the rule will apply
IP	Enter the IPv4 address for the device or choose an IPv4 address from the list
Days of the week	Choose Every Day, or Individual Days and select the check boxes for the days of the week for which the policy applies
From/To	Enter the times for the policy to be in effect

- 2

Select the Access Control check box.
- 3

Click the plus sign (+) to add a policy.

A separate panel appears for configuring the policy name, IP address of the device, and dates and times for the policy.
- 4

Configure the parental control policy.
- 5

Click Enable to activate the policy.
- 6

STOP. This procedure is complete.

Procedure 28 DMZ and ALG configuration

- 1
- Select Security > DMZ and ALG from the top-level menu in the Ethernet Gateway window, as shown in Figure 33.

Figure 33 DMZ and ALG window

NOKIA

Ethernet Gateway

Logout

English | Español

Security>DMZ and ALG

Status

Network

Security

Firewall

MAC Filter

IP Filter

URL Filter

Parental Control

DMZ and ALG

Access Control

Application

Maintenance

RG Troubleshooting

ALG Config

FTP ☒

TFTP ☒

SIP ☒

H323 ☒

RTSP ☒

L2TP ☒

IPSEC ☒

PPTP ☒

Save ALG

DMZ Config

WAN Connection List

Enable DMZ

DMZ IP Address

Custom settings

Save DMZ

Table 31 describes the fields in the DMZ and ALG window.

Table 31 DMZ and ALG parameters

Field	Description
ALG Config	Select the check boxes to enable the protocols to be supported by the ALG: FTP, TFTP, SIP, H323, RTSP, L2TP, IPSEC, PPTP
DMZ Config	
WAN Connection List	Choose a WAN connection from the drop-down menu
Enable DMZ	Select this check box to enable DMZ on the chosen WAN connection
DMZ IP Address	Choose Customer Setting and enter the DMZ IP address or choose the IP address of a connected device from the drop-down menu

- 2
- Configure ALG.

- 3
- Click Save ALG.

- 4
- Configure DMZ.

- 5

Click Save DMZ.
- 6

STOP. This procedure is complete.

Procedure 29 Access control configuration

This procedure describes how to configure the access control level (ACL).



- Note 1

— ACL takes precedence over the firewall policy.
- Note 2

— The trusted network object will be shared for all WAN connections; it is not applied individually to a WAN connection.

- 1

Select Security > Access Control from the top-level menu in the Ethernet Gateway window, as shown in Figure 34.

Figure 34 Access Control window

NOKIA

Ethernet Gateway

Logout

English | Español

Security>Access Control

WAN

LAN

Trusted Network Enable

ICMP

Allow

Deny

Telnet

Allow

Deny

SSH

Allow

Deny

HTTP

Allow

Allow

TR-069

Allow

Deny

HTTPS

Allow

Allow

SFTP

Allow

Deny

SFTP access can be set in Application -> USB

Save

Refresh

Trusted Network

Source IP Start

Source IP End

Add

Source IP Start

Source IP End

Delete

Table 32 describes the fields in the Access Control window.

Table 32 Access control parameters

Field	Description
WAN	Choose a connection from the drop-down menu
Trusted Network Enable	Click to enable or disable
ICMP, Telnet, SSH, HTTP, TR-069, HTTPS	Select an access control level for each protocol: WAN side: Allow, Deny, or Trusted Network Only LAN side: Allow or Deny
Source IP Start	Enter a start IP address for the new subnet trusted network
Source IP End	Enter an end IP address for the new subnet trusted network

2 Select a WAN connection from the drop-down menu.

3 Click to enable or disable Trusted Network.

4 Select an access control level for each of the six protocols: ICMP, Telnet, SSH, HTTP, TR-069, and HTTPS for both the WAN and the LAN side.

5 Click Save.

6 Optionally, add one or more subnet trusted networks.

The maximum number of entries is 32.

You can also use the Source IP fields to delete a previously created entry for a subnet trusted network.

7 STOP. This procedure is complete.

8.1.5 Application configuration

The A-020W-A CPE also supports application configuration, including:

- port forwarding
- port triggering
- DDNS
- NTP
- UPnP and DLNA

Procedure 30 Port forwarding configuration

- 1 Select Application > Port forwarding from the top-level menu in the Ethernet Gateway window, as shown in Figure 35.

Figure 35 Port forwarding window

NOKIA

Ethernet Gateway

Logout

English | Español

Status

Network

Security

Application

Port Forwarding

Port Triggering

DDNS

NTP

UPNP and DLNA

Maintenance

RG Troubleshooting

Application>Port Forwarding

Application Name

Custom settings

WAN Port

~

LAN Port

~

Internal Client

Custom settings

Protocol

TCP

Enable Mapping

☐

WAN Connection List

Add

Application Name	WAN Connection	WAN Port	LAN Port	Device Name	Internal Client	Protocol	Status	Delete
------------------	----------------	----------	----------	-------------	-----------------	----------	--------	--------

Table 33 describes the fields in the port forwarding window.

Table 33 Port forwarding parameters

Field	Description
Application Name	Choose an application name from the drop-down menu
WAN Port	WAN port range
LAN Port	LAN port range
Internal Client	Choose a connected device from the drop-down menu and enter the associated IP address
Protocol	Choose the port forwarding protocol from the drop-down menu: <ul style="list-style-type: none">TCPUDPTCP/UDP
Enable Mapping	Select this check box to enable mapping
WAN Connection List	Choose a WAN connection from the drop-down menu Note: only active devices are shown on this menu

- 2

Configure port forwarding.
- 3

Click Add.
- 4

STOP. This procedure is complete.

Procedure 31 Port triggering

- 1

Select Application > Port Triggering from the top-level menu in the Ethernet Gateway window, as shown in Figure 36.

Figure 36 Port Triggering window

NOKIA

Status

Network

Security

Application

Port Forwarding

Port Triggering

DDNS

NTP

UPNP and DLNA

Maintenance

RG Troubleshooting

Ethernet Gateway

Logout

English | Español

Application>Port Triggering

Application Name

Custom settings

Open Port

~

Triggering Port

~

Expire Time

600

(Range:1~999999)(seconds)

Open Protocol

TCP

Trigger Protocol

TCP

Enable Triggering

☐

WAN Connection List

Add

Application Name	WAN Connection	Open Port	Triggering Port	Expire Time	Open Protocol	Trigger Protocol	Status	Delete
------------------	----------------	-----------	-----------------	-------------	---------------	------------------	--------	--------

Table 33 describes the fields in the Port Triggering window.

Table 34 Port triggering parameters

Field	Description
Application Name	Choose an application name from the drop-down menu

(1 of 2)

Field	Description
Open Port	Enter the open port range
Triggering Port	Enter the triggering port range
Expire Time	Enter the expiration time in seconds
Open Protocol	Choose the open port protocol from the drop-down menu: <ul style="list-style-type: none">• TCP• UDP• TCP/UDP
Trigger Protocol	Choose the triggering port protocol from the drop-down menu: <ul style="list-style-type: none">• TCP• UDP• TCP/UDP
Enable Triggering	Select this check box to enable port triggering
WAN Connection List	Choose a WAN connection from the drop-down menu Note: only active devices are shown on this menu

(2 of 2)

2 Configure port triggering.

3 Click Add.

4 STOP. This procedure is complete.

Procedure 32 DDNS configuration

- 1 Select Application > DDNS from the top-level menu in the Ethernet Gateway window, as shown in Figure 37.

Figure 37 DDNS window

The screenshot shows the 'Ethernet Gateway' web interface. On the left is a sidebar menu with the Nokia logo at the top. The menu items are: Status, Network, Security, Application (highlighted in red), Port Forwarding, Port Triggering, DDNS (highlighted in red), NTP, UPNP and DLNA, Maintenance, and RG Troubleshooting. The main content area is titled 'Application>DDNS'. It contains the following fields: 'WAN Connection List' (a drop-down menu), 'Enable DDNS' (a checkbox), 'ISP' (a drop-down menu with 'DynDNS.org' selected), 'Domain Name' (a text input field), 'Username' (a text input field), and 'Password' (a text input field). At the bottom right of the form are 'Save' and 'Refresh' buttons. The top right of the interface has a 'Logout' link and language options 'English' and 'Español'.

Table 35 describes the fields in the DDNS window.

Table 35 DDNS parameters

Field	Description
WAN Connection List	Choose a WAN connection from the drop-down menu
Enable DDNS	Select this check box to enable DDNS on the chosen WAN connection
ISP	Choose an ISP from the drop-down menu.
Domain Name	Enter the domain name for the DDNS server
Username	Enter the DDNS username
Password	Enter the DDNS password


- 2 Configure DDNS.

-
- 3 Click Save.
 - 4 STOP. This procedure is complete.
-

Procedure 33 NTP configuration

-
- 1 Select Application > NTP from the top-level menu in the Ethernet Gateway window, as shown in Figure 38.

Figure 38 NTP window




-
- 2 Select the Enable NTP Service check box.
 - 3 Click Save.
 - 4 STOP. This procedure is complete.
-

Procedure 34 UPNP and DLNA configuration

- 1 Select Application > UPNP and DLNA from the top-level menu in the Ethernet Gateway window, as shown in Figure 39.

Figure 39 UPNP and DLNA window



- 2 Select the Enable UPnP check box to enable UPnP.
 - 3 Click Save/Apply.
 - 4 STOP. This procedure is complete.
-

8.1.6 Maintenance

The A-020W-A CPE supports maintenance tasks, including:

- password change
- device management
- backup and restore
- firmware upgrade
- device reboot

- restore factory defaults
- diagnostics
- log

Procedure 35 Password configuration

A password must adhere to the following password rules:

- the password may consist of uppercase letters, lowercase letters, digital numbers, and the following special characters `! # + , - / @ _ : =]`
- the password length must be from 8 to 24 characters
- the first character must be a digital number or a letter
- the password must contain at least two types of characters: numbers, letters, or special characters
- the same character must not appear more than 8 times in a row

When the password meets the password rules, the application displays the message “Your password has been changed successfully”.

When the password does not meet the password rules, the application displays a message to indicate which password rule has not been followed, for example:

- the password is too short
- the password is too long

- the first character cannot be a special character
- there are not enough character classes

-
- 1 Select Maintenance > Password from the top-level menu in the GPON Home Gateway window, as shown in Figure 40.

Figure 40 Password window

The screenshot displays the 'Maintenance > Password' configuration page of a Nokia Ethernet Gateway. The left sidebar lists various system management options, with 'Maintenance' and its sub-option 'Password' highlighted. The main content area features three text input fields for 'New Password', 'Re-enter Password', and 'Prompt Message'. 'Save' and 'Refresh' buttons are positioned at the bottom right of the form. The top navigation bar shows the 'Ethernet Gateway' title, a 'Logout' link, and language selection options for 'English' and 'Español'.

Table 36 describes the fields in the password window.

Table 36 Password parameters

Field	Description
New Password	New password (must adhere to the password rules described above)
Re-enter Password	Must match the new password entered above exactly
Prompt Message	Password prompt message

-
- 2 Configure the new password.
-
- 3 Click Save.
-
- 4 STOP. This procedure is complete.
-

Procedure 36 Device management

- 1
- Select Maintenance > Device Management from the top-level menu in the Ethernet Gateway window, as shown in Figure 41.

Figure 41 Device Management window




Table 37 describes the fields in the Device Management window.

Table 37 Device Management parameters


Field	Description
Host Name	Choose a host from the drop-down menu
Host Alias	Enter an alias for the chosen host

- 2
- Configure an alias for a specific host.
- 3
- Click Add.
- 4
- STOP. This procedure is complete.

Procedure 37 Backup and Restore

- 1 Select Maintenance > Backup and Restore from the top-level menu in the Ethernet Gateway window, as shown in Figure 42.

Figure 42 Backup and Restore window




- 2 Click Select File and choose the backup file.
 - 3 Click Import Config File to restore the A-020W-A CPE to the saved backup or click Export Config File to export the current configuration to the backup file.
 - 4 STOP. This procedure is complete.
-

Procedure 38 Upgrade firmware

- 1 Select Maintenance > Firmware Upgrade from the top-level menu in the Ethernet Gateway window, as shown in Figure 43.

Figure 43 Firmware Upgrade window




- 2 Click Select File and choose the new firmware file.
 - 3 Click Upgrade to upgrade the firmware.
 - 4 STOP. This procedure is complete.
-

Procedure 39 Reboot

- 1 Select Maintenance > Reboot Device from the top-level menu in the Ethernet Gateway window, as shown in Figure 44.

Figure 44 Reboot Device window




- 2 Click Reboot to reboot the A-020W-A CPE.
 - 3 STOP. This procedure is complete.
-

Procedure 40 Restore factory defaults

- 1 Select Maintenance > Factory Default from the top-level menu in the Ethernet Gateway window, as shown in Figure 45.

Figure 45 Factory Default window



- 2 Click Factory Default to reset the A-020W-A CPE to its factory default settings.
 - 3 STOP. This procedure is complete.
-

Procedure 41 Diagnose connections

- 1 Select Maintenance > Diagnostics from the top-level menu in the Ethernet Gateway window, as shown in Figure 46.

Figure 46 Diagnostics window


- 2 Choose a WAN connection to diagnose from the drop-down menu.
- 3 Enter the IP address or domain name.
- 4 Select the test type: ping, traceroute, or both.
- 5 Enter the number of ping attempts to perform (1 to 1000); the default is 4.
- 6 Enter a ping packet length (64 to 1500); the default is 64.
- 7 Enter the maximum number of trace hops (1 to 255); the default is 30.
- 8 Click Start Test. Results will be displayed at the bottom of the window.

- 9 Click Cancel to cancel the test.
- 10 STOP. This procedure is complete.

Procedure 42 View log files

- 1 Select Maintenance > Log from the top-level menu in the Ethernet Gateway window, as shown in Figure 47.

Figure 47 Log window



- 2 Choose a write level from the drop-down menu to determine which types of events are recorded in the log file:
 - Emergency
 - Alert
 - Critical
 - Error
 - Warning
 - Notice
 - Informational
 - Debug

-
- 3 Choose a reading level from the drop-down menu to determine which types of events to display from the log file:
 - Emergency
 - Alert
 - Critical
 - Error
 - Warning
 - Notice
 - Informational
 - Debug
-
- 4 The log file is displayed at the bottom of the window.
-
- 5 STOP. This procedure is complete.
-

8.1.7 RG troubleshooting counters

The Troubleshooting Counters feature enables service providers and end users to monitor the performance of their broadband connection.

Tests are run to retrieve upstream and downstream throughput, latency, and DNS response time. The Troubleshooting Counters window also displays upstream and downstream packet loss and Internet status.

Procedure 43 Retrieve Residential Gateway (RG) troubleshooting counters

-
- 1 Select RG Troubleshooting Counters from the left menu in the Ethernet Gateway window.
The RG Troubleshooting Counters window appears; see Figure 48.

Figure 48 RG Troubleshooting Counters window

NOKIA

Status

Network

Security

Application

Maintenance

RG Troubleshooting

RG Troubleshoot Counters

Ethernet GatewayLogoutEnglishEspañol

RG Troubleshooting>RG Troubleshoot Counters

WAN Connection List

US Throughput

US-SpeedTest

DS Throughput

DS-SpeedTest

US Packet Loss

DS Packet Loss

Internet Status

Latency

LatencyTest

DNS Response Time

DNSResponseTest

Port Mirror

Source Port

Destination Port

Direction

Status

WAN

LAN1

Downstream

Enable

Save

Source Port

Destination Port

Direction

Delete

Refresh

Table 38 describes the fields in the RG Troubleshooting Counters window.

Table 38 RG Troubleshooting Counters parameters

Field	Description
WAN Connection List	Select a WAN connection from the list
US Throughput	This test is used to determine the upstream throughput/speed Click US Speed Test to specify the time for the upstream test The default is weekly, performed at idle to a public server
DS Throughput	This test is used to determine the downstream throughput/speed Click DS Speed Test to specify the time for the downstream test The default is weekly, performed at idle to a public server
US Packet Loss	The number of upstream packages lost

(1 of 2)

Field	Description
DS Packet Loss	The number of downstream packages lost
Internet Status	Whether the broadband connections is active (UP) or not (DOWN)
Latency	This test is used to determine the lowest round-trip time in milliseconds by pinging the target server multiple times Click Latency Test to specify the time for the test The default is weekly, performed at idle to a public server
DNS Response Time	This test is used to determine the lowest round-trip time in milliseconds by sending a request to the target DNS server Click DNS Response Test to specify the time for the test The default is weekly, performed at idle to a public server
Port Mirror	Select Source Port, Destination Port, Direction (Up or Down) and Status (Enable or Disable)

(2 of 2)

2 Configure the test times if desired.

3 Click Refresh to update the data.

4 STOP. This procedure is complete.

Customer document and product support



Customer documentation

[Customer Documentation Welcome Page](#)



Technical Support

[Customer Documentation Technical Support](#)



Documentation feedback

[Customer Documentation Feedback](#)

