
NB-IOT Sensor RS485/UART to NB-IoT Converter

Model: RS485-NB

last modified by kai
on 2024/11/09 13:51

Table of Contents

1. Introduction	5
1.1 What is RS485 / UART to NB-IoT Converter	5
1.2 Features	6
1.3 Specification	7
1.4 Applications	7
1.5 Sleep mode and working mode	8
1.6 Button & LEDs	8
1.7 BLE connection	9
1.8 Pin Definitions , Switch & SIM Direction	9
1.8.1 Jumper JP2	9
1.8.2 BOOT MODE / SW1	9
1.8.3 Reset Button	10
1.8.4 SIM Card Direction	10
1.8.5 SW2 Jumper (Define UART level to external Sensor)	10
1.9 Mechanical	10
1.9.1 for NB version	10
1.9.2 for NS version	10
2. Use RS485-NB/NS to communicate with IoT Server	10
2.1 Send data to IoT server via NB-IoT network	10
2.2 Configure Device to Read RS485 Sensors	11
2.2.1 Method 1 -- via RS485 Configure Tool	11
2.2.2 Method 2 -- via AT Commands	12
2.2.3 Configure sensors	14
2.2.4 Configure read commands for each sampling	15
2.2.5 Uplink when the sensor is not responding	17
2.2.6 Uplink on Interrupt	18
2.3 Payload Types	18
2.3.1 General Json Format(Type=5)	19
2.3.2 HEX format Payload(Type=0)	20
2.4 Test Uplink and Change Update Interval	21
2.5 Fast command to handle MODBUS device	21
2.6 RS485 command timeout	22
2.7 Clear RS485 Command	22
2.8 Set Payload version	22
2.9 Control output power duration	22
2.10 Get sensor value	23
2.11 +3V3 Output	23
2.12 +5V Output	23
2.13 Switch Jumper	23
2.14 Clock logging (Since firmware version v1.0.7)	24
2.15 Example Query saved historical records	25
2.16 Uplink log query	26
2.17 Scheduled domain name resolution	27
2.18 Set the QoS level	27
3. Configure RS485-NB/NS	27
3.1 Configure Methods	27
3.2 Serial Access Password	27
3.3 AT Commands Set	29
4. Battery & Power Consumption	30
5. Firmware update	31
6. FAQ	31
6.1 How can I access t BC660K-GL AT Commands?	31
6.2 How many RS485-Slave can RS485-NB/NS connects?	31

User Manual for LoRaWAN /NB -IoT End Nodes - RS485-
NB/NS -- RS485/UART to NB-IoT Converter User Manual

6.3 How to configure the device through the MQTT subscription function?	31
6.4 How to Use RS485-NB/NS to connect to RS232 devices?	33
6.5 How to judge whether there is a problem with the set COMMAND	33
6.5.1 Introduce:	33
6.5.2 Set up PC to monitor RS485 network With Serial tool	34
6.5.3 With ModRSsim2:	35
6.5.4 Example – Test the CFGDEV command	37
6.5.5 Example – Test CMD command sets.	38
6.5.6 Test with PC	39
7. Order Info	41
8. Packing Info	41
9. Support	42

Table of Contents:

- [1. Introduction](#)
 - [1.1 What is RS485 / UART to NB-IoT Converter](#)
 - [1.2 Features](#)
 - [1.3 Specification](#)
 - [1.4 Applications](#)
 - [1.5 Sleep mode and working mode](#)
 - [1.6 Button & LEDs](#)
 - [1.7 BLE connection](#)
 - [1.8 Pin Definitions , Switch & SIM Direction](#)
 - [1.8.1 Jumper JP2](#)
 - [1.8.2 BOOT MODE / SW1](#)
 - [1.8.3 Reset Button](#)
 - [1.8.4 SIM Card Direction](#)
 - [1.8.5 SW2 Jumper \(Define UART level to external Sensor\)](#)
 - [1.9 Mechanical](#)
 - [1.9.1 for NB version](#)
 - [1.9.2 for NS version](#)

- [2. Use RS485-NB/NS to communicate with IoT Server](#)
 - [2.1 Send data to IoT server via NB-IoT network](#)
 - [2.2 Configure Device to Read RS485 Sensors](#)
 - [2.2.1 Method 1 -- via RS485 Configure Tool](#)
 - [2.2.2 Method 2 -- via AT Commands](#)
 - [2.2.2.1 Configure UART settings for RS485 or TTL communication](#)
 - [2.2.3 Configure sensors](#)
 - [2.2.4 Configure read commands for each sampling](#)
 - [2.2.5 Uplink when the sensor is not responding](#)
 - [2.2.6 Uplink on Interrupt](#)
 - [2.3 Payload Types](#)
 - [2.3.1 General Json Format\(Type=5\)](#)
 - [2.3.2 HEX format Payload\(Type=0\)](#)
 - [2.4 Test Uplink and Change Update Interval](#)
 - [2.5 Fast command to handle MODBUS device](#)
 - [2.6 RS485 command timeout](#)
 - [2.7 Clear RS485 Command](#)
 - [2.8 Set Payload version](#)
 - [2.9 Control output power duration](#)
 - [2.10 Get sensor value](#)
 - [2.11 +3V3 Output](#)
 - [2.12 +5V Output](#)
 - [2.13 Switch Jumper](#)
 - [2.14 Clock logging \(Since firmware version v1.0.7\)](#)
 - [2.15 Example Query saved historical records](#)
 - [2.16 Uplink log query](#)
 - [2.17 Scheduled domain name resolution](#)
 - [2.18 Set the QoS level](#)
- [3. Configure RS485-NB/NS](#)
 - [3.1 Configure Methods](#)
 - [3.2 Serial Access Password](#)
 - [3.3 AT Commands Set](#)
- [4. Battery & Power Consumption](#)
- [5. Firmware update](#)
- [6. FAQ](#)
 - [6.1 How can I access t BC660K-GL AT Commands?](#)
 - [6.2 How many RS485-Slave can RS485-NB/NS connects?](#)
 - [6.3 How to configure the device through the MQTT subscription function?](#)
 - [6.4 How to Use RS485-NB/NS to connect to RS232 devices?](#)
 - [6.5 How to judge whether there is a problem with the set COMMAND](#)
 - [6.5.1 Introduce:](#)
 - [6.5.2 Set up PC to monitor RS485 network With Serial tool](#)
 - [6.5.3 With ModRSsim2:](#)
 - [6.5.4 Example – Test the CFGDEV command](#)
 - [6.5.5 Example – Test CMD command sets.](#)
 - [6.5.6 Test with PC](#)
- [7. Order Info](#)
- [8. Packing Info](#)
- [9. Support](#)

1. Introduction

1.1 What is RS485 / UART to NB-IoT Converter

The Dragino RS485-NB/NS is a **RS485 / UART to NB-IoT Converter** for Internet of Things solutions. User can connect RS485 or UART sensor to RS485-NB/NS converter, and configure RS485-NB/NS to periodically read sensor data and upload via NB-IoT network to IoT server.

RS485-NB/NS can interface to RS485 sensor, 3.3v/5v UART sensor or interrupt sensor. RS485-NB/NS provides **a 3.3v output** and **a 5v output** to power external sensors. Both output voltages are controllable to minimize the total system power consumption.

RS485-NB/NS supports different uplink methods including **MQTT, MQTTs, UDP, TCP or CoAP** for different application requirement, and support uplinks to various IoT Servers.

RS485-NB/NS supports **BLE configure and wireless OTA update** which make user easy to use.

RS485-NB/NS is IP67 **waterproof** and powered by **8500mAh Li-SOCI2 battery or solar powered + Li-ion battery**, it is designed for long-term use up to several years.

RS485-NB/NS has optional built-in SIM card and default IoT server connection version. Which makes it works with simple configuration.

RS485-NB in a NB-IoT Network



1.2 Features

- NB-IoT Bands: B1/B2/B3/B4/B5/B8/B12/B13/B17/B18/B19/B20/B25/B28/B66/B70/B85 @H-FDD
- Ultra-low power consumption
- Support multiply RS485 devices by flexible rules
- Support Modbus protocol
- Support Interrupt uplink
- Supports connecting a UART sensors with 3.3V or 5V
- Multiply Sampling and one uplink
- Support Bluetooth v5.1 remote configure and update firmware
- Uplink via MQTT, MQTTs, TCP, UDP or CoAP
- Uplink on periodically
- Downlink to change configure
- 8500mAh Li/SOCI2 Battery (RS485-NB)
- Solar panel + 3000mAh Li-ion battery (RS485-NS)

1.3 Specification

Common DC Characteristics:

- Supply Voltage: 2.5v ~ 3.6v
- Operating Temperature: -40 ~ 85 °C

I/O Interface:

- Battery controllable output (2.6v ~ 3.6v depends on battery)
- +5v controllable output
- 1 x RS485 Interface
- 1 x UART Interface , 3.3v or 5v
- 1 x Interrupt or Digital IN/OUT pins
- 1 x I2C Interface
- 1 x one wire interface

NB-IoT Spec:

NB-IoT Module: BC660K-GL

Support Bands:

- B1 @H-FDD: 2100MHz
- B2 @H-FDD: 1900MHz
- B3 @H-FDD: 1800MHz
- B4 @H-FDD: 2100MHz
- B5 @H-FDD: 860MHz
- B8 @H-FDD: 900MHz
- B12 @H-FDD: 720MHz
- B13 @H-FDD: 740MHz
- B17 @H-FDD: 730MHz
- B18 @H-FDD: 870MHz
- B19 @H-FDD: 870MHz
- B20 @H-FDD: 790MHz
- B25 @H-FDD: 1900MHz
- B28 @H-FDD: 750MHz
- B66 @H-FDD: 2000MHz
- B70 @H-FDD: 2000MHz
- B85 @H-FDD: 700MHz

Battery:

- Li/SOCI2 un-chargeable battery
- Capacity: 8500mAh
- Self Discharge: <1% / Year @ 25 °C
- Max continuously current: 130mA
- Max boost current: 2A, 1 second

Power Consumption

- STOP Mode: 10uA @ 3.3v
- Max transmit power: 350mA@3.3v

1.4 Applications


- Smart Buildings & Home Automation
- Logistics and Supply Chain Management
- Smart Metering
- Smart Agriculture
- Smart Cities
- Smart Factory

1.5 Sleep mode and working mode

Deep Sleep Mode: Sensor doesn't have any NB-IoT activate. This mode is used for storage and shipping to save battery life.

Working Mode: In this mode, Sensor will work as NB-IoT Sensor to Join NB-IoT network and send out sensor data to server. Between each sampling/tx/rx periodically, sensor will be in IDLE mode), in IDLE mode, sensor has the same power consumption as Deep Sleep mode.

1.6 Button & LEDs



Behavior on ACT	Function	Action
Pressing ACT between 1s < time < 3s	Send an uplink	If sensor has already attached to NB-IoT network, sensor will send an uplink packet, blue led will blink once. Meanwhile, BLE module will be active and user can connect via BLE to configure device.
Pressing ACT for more than 3s	Active Device	Green led will fast blink 5 times, device will enter OTA mode for 3 seconds. And then start to attach NB-IoT network. Green led will solidly turn on for 5 seconds after joined in network. Once sensor is active, BLE module will be active and user can connect via BLE to configure device, no matter if device attach NB-IoT network or not.
Fast press ACT 5 times.	Deactivate Device	Red led will solid on for 5 seconds. Means device is in Deep Sleep Mode.

Note: When the device is executing a program, the buttons may become invalid. It is best to press the buttons after the device has completed the program execution.

1.7 BLE connection


RS485-NB/NS support BLE remote configure and firmware update.

BLE can be used to configure the parameter of sensor or see the console output from sensor. BLE will be only activate on below case:

- Press button to send an uplink
- Press button to active device.
- Device Power on or reset.

If there is no activity connection on BLE in 60 seconds, sensor will shut down BLE module to enter low power mode.

1.8 Pin Definitions , Switch & SIM Direction



1.8.1 Jumper JP2

Power on Device when put this jumper.

1.8.2 BOOT MODE / SW1

1) **ISP**: upgrade mode, device won't have any signal in this mode. but ready for upgrade firmware. LED won't work. Firmware won't run.

2) **Flash**: work mode, device starts to work and send out console output for further debug

1.8.3 Reset Button

Press to reboot the device.

1.8.4 SIM Card Direction

See this link. [How to insert SIM Card](#).

1.8.5 SW2 Jumper (Define UART level to external Sensor)

SW2 defines the voltage level of BOARD_RX and BOARD_TX pins. It should match the external sensor voltage level

1.9 Mechanical

1.9.1 for NB version

1.9.2 for NS version

2. Use RS485-NB/NS to communicate with IoT Server

2.1 Send data to IoT server via NB-IoT network

The RS485-NB/NS is equipped with a NB-IoT module, the pre-loaded firmware in RS485-NB/NS will get environment data from sensors and send the value to local NB-IoT network via the NB-IoT module. The NB-IoT network will forward this value to IoT server via the protocol defined by RS485-NB/NS.

Below shows the network structure:

There are two version: **-GE** and **-1T** version of RS485-NB/NS.

GE Version: This version doesn't include SIM card or point to any IoT server. User needs to use AT Commands to configure below two steps to set RS485-NB/NS send data to IoT server.

- Install NB-IoT SIM card and configure APN. See instruction of [Attach Network](#).
- Set up sensor to point to IoT Server. See instruction of [Configure to Connect Different Servers](#).

Below shows result of different server as a glance.

Servers	Dash Board	Comments
---------	------------	----------

[Node-Red](#)



[DataCake](#)



[General UDP](#)

Raw Payload. Need Developer to design Dash Board

[General MQTT](#)

Raw Payload. Need Developer to design Dash Board

1D Version: This version has 1NCE SIM card pre-installed and configure to send value to DataCake. User Just need to select the sensor type in DataCake and Activate RS485-NB/NS and user will be able to see data in DataCake. See here for [DataCake Config Instruction](#).

2.2 Configure Device to Read RS485 Sensors

There are plenty of RS485 and TTL level devices in the market and each device has different commands to read the valid data. To support these devices in most flexible, RS485-NB/NS supports flexible command set. User can use [Dragino RS485 Tool](#), [AT Commands](#) or [LoRaWAN Downlink](#) Command to configure how RS485-NB/NS should read the sensor and how to handle the return from RS485 or TTL sensors.

2.2.1 Method 1 -- via RS485 Configure Tool

Use the RS485 Configure tool is the recommend method. Please see the instruction of how to use the tool:

- [RS485 Configure Tool Instruction](#)

2.2.2 Method 2 -- via AT Commands

2.2.2.1 Configure UART settings for RS485 or TTL communication

RS485-NB/NS can connect to either RS485 sensors or TTL sensor. User need to specify what type of sensor need to connect.

1. RS485-MODBUS mode:

AT+MOD=1 // Support RS485-MODBUS type sensors. User can connect multiply RS485 , Modbus sensors to the A / B pins.

2. TTL mode:

AT+MOD=2 // Support TTL Level sensors, User can connect one TTL Sensor to the TXD/RXD/GND pins.

RS485-NB/NS default UART settings is **9600, no parity, stop bit 1,data bit 8**. If the sensor has a different settings, user can change the RS485-NB/NS setting to match.

AT Commands	Description	Example
AT+BAUDR	Set the baud rate. Default Value is: 9600.	AT+BAUDR=9600 Options: (1200,2400,4800,14400,19200,115200)
AT+PARITY	Set UART parity. Default Value is: no parity.	AT+PARITY=0 Option: 0: no parity, 1: odd parity, 2: even parity
AT+STOPBIT	Set serial stopbit Default Value is: 1bit.	AT+STOPBIT=0 for 1 bit AT+STOPBIT=1 for 1.5 bits AT+STOPBIT=2 for 2 bits
AT+DATABIT	Set serial databit.	AT+DATABIT=7 for 7 bits

Default Value is: 8bits.

AT+DATABIT=8 for 8 bits

Example(Soil three-parameter detector):

Wiring the UART sensor

GND <-----> GND
TX <-----> RX
RX <-----> TX
VCC <-----> 3.3/5V



Set the correct configuration:

AT+BAUDR=9600

AT+PARITY=0

AT+STOPBIT=1

AT+DATABIT=8

If the sensor needs 5v. Need to move the switch position to 5v and then use the command **AT+5VT=30000**

Configuration read command:

AT+CFGDEV=FE 03 00 00 00 03 11 C4,0

FE: Station address

03: Function code

00 00: Register start address

00 03: Number of registers

11 04: Check code

Use AT+COMMAND1 to set it as a command, and use AT+DATA CUT1 to intercept the bytes I need

```
AT+PAYVER=1
AT+MBFUN=0
AT+COMMAND1=fe 03 00 00 00 03 11 c4,0 AT+SEARCH1=0,0 AT+DATA CUT1=11,2,4~9 AT+CMDL1=0
AT+COMMAND2=0,0 AT+SEARCH2=0,0 AT+DATA CUT2=0,0,0 AT+CMDL2=0
AT+COMMAND3=0,0 AT+SEARCH3=0,0 AT+DATA CUT3=0,0,0 AT+CMDL3=0
AT+COMMAND4=0,0 AT+SEARCH4=0,0 AT+DATA CUT4=0,0,0 AT+CMDL4=0
AT+COMMAND5=0,0 AT+SEARCH5=0,0 AT+DATA CUT5=0,0,0 AT+CMDL5=0
AT+COMMAND6=0,0 AT+SEARCH6=0,0 AT+DATA CUT6=0,0,0 AT+CMDL6=0
AT+COMMAND7=0,0 AT+SEARCH7=0,0 AT+DATA CUT7=0,0,0 AT+CMDL7=0
AT+COMMAND8=0,0 AT+SEARCH8=0,0 AT+DATA CUT8=0,0,0 AT+CMDL8=0
AT+COMMAND9=0,0 AT+SEARCH9=0,0 AT+DATA CUT9=0,0,0 AT+CMDL9=0
AT+COMMANDA=0,0 AT+SEARCHA=0,0 AT+DATA CUTA=0,0,0 AT+CMDLA=0
AT+COMMANDB=0,0 AT+SEARCHB=0,0 AT+DATA CUTB=0,0,0 AT+CMDLB=0
AT+COMMANDC=0,0 AT+SEARCHC=0,0 AT+DATA CUTC=0,0,0 AT+CMDLC=0
AT+COMMANDD=0,0 AT+SEARCHD=0,0 AT+DATA CUTD=0,0,0 AT+CMDLD=0
AT+COMMANDE=0,0 AT+SEARCHE=0,0 AT+DATA CUTE=0,0,0 AT+CMDLE=0
AT+COMMANDF=0,0 AT+SEARCHF=0,0 AT+DATA CUTF=0,0,0 AT+CMDLF=0

OK
```

upload payload:

```
[41270]*****Upload start:0*****

CMD1    = fe 03 00 00 00 03 11 c4
RETURN1 = fe 03 06 00 00 09 49 00 00 b6 cb
Payload = 01 00 00 09 49 00 00

[41928]BAT:3.584 V
[45458]Open a Socket Service successfully
[52516]Datagram is sent by RF
[53550]Send complete
```

2.2.3 Configure sensors

Some sensors might need to configure before normal operation. User can configure such sensor via PC or through RS485-NB/NS AT Commands [AT+CFGDEV](#).

When user issue an [AT+CFGDEV](#) command, Each [AT+CFGDEV](#) equals to send a command to the RS485 or TTL sensors. This command will only run when user input it and won't run during each sampling.

AT Commands	Description	Example
-------------	-------------	---------

AT+CFGDEV	This command is used to configure the RS485/TTL devices; they won't be used during sampling. AT+CFGDEV=xx xx xx xx xx xx xx xx xx xx, mm: 0: no CRC, 1: add CRC-16/MODBUS in the end of this command	AT+CFGDEV=xx xx xx xx xx xx xx xx xx xx,m
-----------	--	---

2.2.4 Configure read commands for each sampling

Note: Please upgrade firmware to v1.0.3 or above. Otherwise, if a data error occurs in AT+COMMANDx check crc mode, the device will enter an inoperable state.

RS485-NB/NS is a battery powered device; it will sleep most of time. And wake up on each period and read RS485 / TTL sensor data and uplink.

During each sampling, we need to confirm what commands we need to send to the sensors to read data. After the RS485/TTL sensors send back the value, it normally includes some bytes and we only need a few from them for a shorten payload.

To save the LoRaWAN network bandwidth, we might need to read data from different sensors and combine their valid value into a short payload.

This section describes how to achieve above goals.

During each sampling, the RS485-NB/NS can support 15 commands to read sensors. And combine the return to one or several uplink payloads.

Command from RS485-NB/NS to Sensor:

RS485-NB/NS can send out pre-set max 15 strings via **AT+COMMAD1**, **ATCOMMAND2**,..., to **AT+COMMANDF** . All commands are of same grammar.

Handle return from sensors to RS485-NB/NS:

After RS485-NB send out a string to sensor, RS485-NB/NS will wait for the return from RS485 or TTL sensor. And user can specify how to handle the return, by **AT+DATA CUT** or **AT+SEARCH** commands

- **AT+DATA CUT**

When the return value from sensor have fix length and we know which position the valid value we should get, we can use AT+DATA CUT command.

- **AT+SEARCH**

When the return value from sensor is dynamic length and we are not sure which bytes the valid data is, instead, we know what value the valid value following. We can use AT+SEARCH to search the valid value in the return string.

Define wait timeout:

Some RS485 device might has longer delay on reply, so user can use AT+CMDDL to set the timeout for getting reply after the RS485 command is sent. For example, AT+CMDDL1=1000 to send the open time to 1000ms

Examples:

Below are examples for the how above AT Commands works.

AT+COMMANDx : This command will be sent to RS485/TTL devices during each sampling, Max command length is 14 bytes. The grammar is:

AT+COMMANDx=xx xx xx xx xx xx xx xx xx xx,m
--

xx xx xx xx xx xx xx xx xx xx xx: The RS485 command to be sent

m: 0: no CRC, 1: add CRC-16/MODBUS in the end of this command

For example, if we have a RS485 sensor. The command to get sensor value is: 01 03 0B B8 00 02 46 0A. Where 01 03 0B B8 00 02 is the Modbus command to read the register 0B B8 where stored the sensor value. The 46 0A is the CRC-16/MODBUS which calculate manually.

In the RS485-NB/NS, we should use this command AT+COMMAND1=01 03 0B B8 00 02,1 for the same.

If a single command exceeds 14 bytes, you can use the command splicing function.

When AT+CMDDLx=1, the commands of AT+COMMANDx and AT+COMMAND(x+1) will be merged.

Examples: To send 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F data it should be configured:

AT+COMMAND1=00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D,0

AT+COMMAND1=1

AT+COMMAND2=0E 0F,0

AT+SEARCHx: This command defines how to handle the return from AT+COMMANDx.

AT+SEARCHx=aa,xx xx xx xx xx

- aa: 1: prefix match mode; 2: prefix and suffix match mode
- xx xx xx xx xx: match string. Max 5 bytes for prefix and 5 bytes for suffix

Examples:

1) For a return string from AT+COMMAND1: 16 0c 1e 56 34 2e 30 58 5f 36 41 30 31 00 49

If we set AT+SEARCH1=1,1E 56 34. (max 5 bytes for prefix)

The valid data will be all bytes after 1E 56 34, so it is **2e 30 58 5f 36 41 30 31 00 49**

2) For a return string from AT+COMMAND1: 16 0c 1e 56 34 2e 30 58 5f 36 41 30 31 00 49

If we set AT+SEARCH1=2, 1E 56 34+31 00 49

Device will search the bytes between 1E 56 34 and 31 00 49. So it is **2e 30 58 5f 36 41 30**

AT+DATA CUTx : This command defines how to handle the return from AT+COMMANDx, max return length is 100 bytes.

AT+DATA CUTx=a,b,c

- a: length for the return of AT+COMMAND
- b:1: grab valid value by byte, max 6 bytes. 2: grab valid value by bytes section, max 3 sections.
- c: define the position for valid value.

Examples:

- **Grab bytes:**
- **Grab a section.**

- [Grab different sections.](#)

Note:

AT+SEARCHx and **AT+DATACUTx** can be used together, if both commands are set, RS485-NB/NS will first process AT+SEARCHx on the return string and get a temporary string, and then process AT+DATACUTx on this temporary string to get the final payload. In this case, AT+DATACUTx need to set to format **AT+DATACUTx=0,xx,xx** where the return bytes set to **0**.

Example:

AT+COMMAND1=11 01 1E D0,0

AT+SEARCH1=1,1E 56 34

AT+DATACUT1=0,2,1~5

Return string from AT+COMMAND1: 16 0c 1e 56 34 2e 30 58 5f 36 41 30 31 00 49

String after SEARCH command: 2e 30 58 5f 36 41 30 31 00 49

Valid payload after DataCUT command: 2e 30 58 5f 36

2.2.5 Uplink when the sensor is not responding

1) When **AT+MOD=1**, if the data intercepted by **AT+DATACUT** or **AT+MBFUN** is empty, it will display **NULL**, and the payload will be filled with **n FFs**.



```
[146157]Signal Strength:23
[149091]*****Upload start:4*****

CMD1  = 1e 03 00 00 00 03 11 c4
RETURN = NULL
Payload = 01 FF FF FF FF FF FF FF FF

[149645]BAT:3.594 V
[156683]Datagram is sent by RF
[157718]Send complete
[158743]*****End of upload*****
```

2) When **AT+MOD=2**, if the data intercepted by **AT+DATACUT** or **AT+MBFUN** is empty, it will display **NULL**, and the payload will be filled with **n 00s**.

```
[172119]Signal Strength:23
[175053]*****Upload start:5*****


CMD1   = fe 03 00 00 00 03 11 c4
RETURN1 = NULL

Payload = 01 00 00 00 00 00 00

[176587]BAT:3.591 V
[183623]Datagram is sent by RF
[184658]Send complete
[185683]*****End of upload*****
```

2.2.6 Uplink on Interrupt

Put the interrupt sensor between 3.3v_out and GPIO_EXTI.



AT+INTMOD=0 Disable Interrupt.(Default Value)

AT+INTMOD=1 Interrupt trigger by rising or falling edge.

AT+INTMOD=2 Interrupt trigger by falling edge.

AT+INTMOD=3 Interrupt trigger by rising edge.

2.3 Payload Types

To meet different server requirement, RS485-NB/NS supports different payload type.

Includes:

- [General JSON format payload](#). (Type=5)
- [HEX format Payload](#). (Type=0)

User can specify the payload type when choose the connection protocol. Example:

AT+PRO=2,0 // Use UDP Connection & hex Payload
AT+PRO=2,5 // Use UDP Connection & Json Payload
AT+PRO=3,0 // Use MQTT Connection & hex Payload
AT+PRO=3,5 // Use MQTT Connection & Json Payload
AT+PRO=4,0 // Use TCP Connection & hex Payload
AT+PRO=4,5 // Use TCP Connection & Json Payload

2.3.1 General Json Format(Type=5)


This is the General Json Format. As below:

```
{"IMEI":"866207053462705","Model":"RS485-  
NB","Payload":"01111122223333","battery":3.581,"signal":23}
```

Notice:The maximum number of bytes in the Payload is 1 payload version number plus 687 RS485 data.

AT+CLOCKLOG=1,65535,1,5:

```
{"IMEI":"863663062798815","Model":"RS485-NB/  
NS","Payload":"010da5","battery":3.295,"signal":23,"1":["010da9","2024/07/15 02:45:09"],"2":  
["010da4","2024/07/15 02:44:09"],"3":["010da6","2024/07/15 02:43:09"],"4":["010da4","2024/07/15  
02:42:09"],"5":["010da3","2024/07/15 02:41:18"]}
```



2.3.2 HEX format Payload(Type=0)

This is the HEX Format. As below:

f863663062798815 176e 0cdd 1a 00 00 66948e7b 01 0da4

HEX Format for RS485-NB	176e	0cdd	1a	00	00	66948e7b	01	0da4
IMEI	Model	BAT	Signal	1	2	Payload	Payload_reason	Signal_strength

Version:

These bytes include the hardware and software version.

Higher byte: Specify Sensor Model: 0x17 for RS485-NB/NS

Lower byte: Specify the software version: 0x6e=110, means firmware version 1.1.0

BAT (Battery Info):

Ex1: 0x0cdd = 3293mV

Signal Strength:

NB-IoT Network signal Strength.

Ex1: 0x1a = 26

- 0** -113dBm or less
- 1** -111dBm
- 2...30** -109dBm... -53dBm
- 31** -51dBm or greater
- 99** Not known or not detectable

GPIO_EXIT Level :

GPIO_EXTI is used as Interrupt Pin.

Example:

01 (H): GPIO_EXTI pin is high level.

00 (L): GPIO_EXTI pin is low level.

GPIO_EXIT Flag:

This data field shows if this packet is generated by **Interrupt Pin** or not.

Note: The Interrupt Pin is a separate pin in the screw terminal.

Example:

0x00: Normal uplink packet.

0x01: Interrupt Uplink Packet.

TimeStamp:

Unit TimeStamp Example: 66948E7B(H) = 1721011835(D)

Put the decimal value into this link(<https://www.epochconverter.com/>) to get the time.

Payload_version:

The payload version number is used to parse different decodes.

RS485_sensor_data:

The data returned by the RS485 sensor or UART sensor needs to be cut out the AT+DATA CUTx and AT+MBFUN or AT+SEARCHx commands.

2.4 Test Uplink and Change Update Interval

By default, Sensor will send uplinks **every 2 hours**

User can use below commands to change the **uplink interval**.

AT+TDC=7200 // Set Update Interval to 7200s

User can also push the button for more than 1 seconds to activate an uplink.

2.5 Fast command to handle MODBUS device

The command is for fast configure to read Modbus devices. It is only valid for the devices which follow the [MODBUS-RTU protocol](#).

AT+MBFUN has only two value:

- **AT+MBFUN=1:** Enable Modbus reading. And get response base on the MODBUS return

AT+MBFUN=1, device can auto read the Modbus function code: 01, 02, 03 or 04. AT+MBFUN has lower priority vs AT+DATACUT command. If AT+DATACUT command is configured, AT+MBFUN will be ignore.

- **AT+MBFUN=0:** Disable Modbus fast reading.

Example:

- AT+MBFUN=1 and AT+DATACUT1/AT+DATACUT2 are not configure (0,0,0).
- AT+COMMAND1= 01 03 00 10 00 08,1 --> read slave address 01 , function code 03, start address 00 01, quantity of registers 00 08.
- AT+COMMAND2= 01 02 00 40 00 10,1 --> read slave address 01 , function code 02, start address 00 40, quantity of inputs 00 10.

2.6 RS485 command timeout

Some Modbus device has slow action to send replies. This command is used to configure the RS485-NB/NS to use longer time to wait for their action.

Default value: 0, range: 0 ~ 10 seconds

- **AT Command:**

AT+CMDDLaa=hex(bb cc)

Example:

AT+CMDDL1=1000 to send the open time to 1000ms

2.7 Clear RS485 Command

The AT+COMMANDx and AT+DATACUTx AT+SEARCHx and AT+CMDDLx settings are stored in special location, user can use below command to clear them.

- **AT Command:**

AT+CMDEAR=mm,nn mm: start position of erase ,nn: stop position of erase Etc. AT+CMDEAR=1,10 means erase AT+COMMAND1/AT+DATACUT1/AT+SEARCH1/AT+CMDDL1 to AT+COMMANDA/AT+DATACUTA/AT+SEARCHA/AT+CMDDLA.

2.8 Set Payload version

This is the first byte of the uplink payload. RS485-NB/NS can connect to different sensors. User can set the PAYVER field to tell server how to decode the current payload.

- **AT Command:**

AT+PAYVER: Set PAYVER field = 1

2.9 Control output power duration

User can set the output power duration before each sampling.

- **AT Command:**

Example:

AT+3V3T=1000 // 3V3 output power will open 1s before each sampling.

AT+3V3T=0 // Normally open 3V3 power supply.

AT+3V3T=65535 // Normally closed 3V3 power supply.

AT+5VT=1000 // +5V output power will open 1s before each sampling.

AT+5VT=0 // Normally closed +5V power supply.

AT+5VT=65535 // Normally open +5V power supply.

2.10 Get sensor value

- **AT Command:**

AT+GETSENSORVALUE=0 // The serial port gets the reading of the current sensor

AT+GETSENSORVALUE=1 // The serial port gets the current sensor reading and uploads it.

2.11 +3V3 Output

RS485-NB/NS has a Controllable +3V3 output, user can use this output to power external sensor.

The +3V3 output will be valid for every sampling. RS485-NB/NS will enable +3V3 output before all sampling and disable the +3V3 after all sampling.

The +3V3 output time can be controlled by AT Command.

AT+3V3T=1000

Means set +3v3 valid time to have 1000ms. So, the real +3v3 output will actually have 1000ms + sampling time for other sensors.

By default, the AT+3V3T=0. This is a special case, means the +3V3 output is always on at any time

2.12 +5V Output

RS485-NB/NS has a Controllable +5V output, user can use this output to power external sensor.

The +5V output will be valid for every sampling. RS485-NB/NS will enable +5V output before all sampling and disable the +5v after all sampling.

The 5V output time can be controlled by AT Command.

AT+5VT=1000

Means set 5V valid time to have 1000ms. So, the real 5V output will actually have 1000ms + sampling time for other sensors.

By default, the AT+5VT=0. If the external sensor which require 5v and require more time to get stable state, user can use this command to increase the power ON duration for this sensor.

2.13 Switch Jumper

Switch Jumper	Feature
SW1	ISP position: Upgrade firmware via UART Flash position: Configure device, check running status.
SW2	5V position: set to compatible with 5v I/O. 3.3v position: set to compatible with 3.3v I/O.

+3.3V: is always ON

+5V: Only open before every sampling. The time is by default, it is **AT+5VT=0**.

Note: If SW2 is at +5V and AT+5VT=0, work mode 2 will not be able to send data.

2.14 Clock logging (Since firmware version v1.0.7)

Sometimes when we deploy lots of end nodes in field. We want all sensors sample data at the same time, and upload these data together for analyze. In such case, we can use clock logging feature.

We can use this command to set the start time of data recording and the time interval to meet the requirements of the specific collection time of data.

- AT Command: AT+CLOCKLOG=a,b,c,d**

a: 0: Disable Clock logging. 1: Enable Clock Logging

b: Specify First sampling start second: range (0 ~ 3599, 65535) // **Note:** If parameter b is set to 65535, the log period starts after the node accesses the network and sends packets.


c: Specify the sampling interval: range (0 ~ 255 minutes)

d: How many entries should be uplink on every TDC (max 32)

Note: To disable clock recording, set the following parameters: AT+CLOCKLOG=1,65535,0,0

Example: AT+CLOCKLOG=1,0,15,8


Device will log data to memory start from the 0th second (11:00 00th of first hour and then sampling and log every 15 minutes. Every TDC uplink, the uplink payload will consist: Battery info + last 8 memory record with timestamp + the latest sample at uplink time) . See below for the example.



Example:

AT+CLOCKLOG=1,65535,1,5

After the node sends the first packet, data is recorded to the memory at intervals of 1 minute. For each TDC uplink, the uplink load will include: battery information + the last 5 memory records (payload + timestamp).



Note: Users need to synchronize the server time before configuring this command. If the server time is not synchronized before this command is configured, the command takes effect only after the node is reset.

- **Downlink command: 0x0A**

Format: Command Code (0x0A) followed by 5 bytes.


- **Example 1:** Downlink Payload: **0A01FFFF0F08** // Set SHT record time: AT +CLOCKLOG=1,65535,15,8
- **Example 1:** Downlink Payload: **0A0104B00F08** // Set SHT record time: AT +CLOCKLOG=1,1200,15,8

Note: When entering the downlink payload, there must be no Spaces between bytes.

2.15 Example Query saved historical records

- **AT command: AT+CDP**

This command can be used to search the saved history, recording up to 32 groups of data, each group of historical data contains a maximum of 100 bytes.



2.16 Uplink log query

- **AT command:** `AT+GETLOG`

This command can be used to query upstream logs of data packets.

2.17 Scheduled domain name resolution

This command is used to set up scheduled domain name resolution.

AT command:

- **AT+DNSTIMER** // Unit: hour

After setting this command, domain name resolution will be performed regularly.

2.18 Set the QoS level

This command is used to set the QoS level of **MQTT**.

AT command:

- **AT+MQOS** // 0~2

Downlink command: 0x07

Format: Command Code (0x07) followed by 1 byte.

Ex1: Downlink payload: **0x0700** // AT+MQOS=0

Ex2: Downlink payload: **0x0701** // AT+MQOS=1

3. Configure RS485-NB/NS

3.1 Configure Methods


RS485-NB/NS supports below configure method:

- AT Command via Bluetooth Connection (**Recommended**): [BLE Configure Instruction](#).
- AT Command via UART Connection : See [UART Connection](#).


3.2 Serial Access Password

After the Bluetooth or UART connection is successful, use the Serial Access Password to enter the AT command window.

The label on the box of the node will print the initial password: AT+PIN=**xxxxxx**, and directly use the six-digit password to access the AT instruction window.



If you need to change the password, use **AT+PWORD=xxxxxx** (6 characters), NB nodes only support lowercase letters.



Note: After entering the command, you need to add a line break, and you can also set automatic line breaks in the Bluetooth tool or UART connection tool.

3.3 AT Commands Set

AT+<CMD>? : Help on <CMD>

AT+<CMD> : Run <CMD>

AT+<CMD>=<value> : Set the value

AT+<CMD>=? : Get the value

General Commands

AT : Attention

AT? : Short Help

ATZ : MCU Reset

AT+TDC : Application Data Transmission Interval

AT+CFG : Print all configurations

AT+CFGMOD : Working mode selection

AT+DEUI : Get or set the Device ID

AT+PRO : Choose agreement

AT+RXDL : Extend the sending and receiving time
AT+DNSCFG : Get or Set DNS Server
AT+GETSENSORVALUE : Returns the current sensor measurement
AT+SERVADDR : Server Address
AT+MOD: Get or Set work mode
AT+5VT : Get or Set extend the time of 5V power
AT+3V3T : Get or Set extend the time of 3V3 power
AT+INTMOD : Get or Set the trigger interrupt mode (0:input,1:falling or rising,2:falling,3:rising)
AT+BAUDR: Get or Set baudr of uart
AT+DATABIT: Get or Set databit(7:7 bit,8:8 bit) of uart
AT+PARITY: Get or Set parity(0:none,1:odd,2:even) of uart
AT+STOPBIT: Get or Set stopbit(0:1 bit,1:1.5 bit,2:2 bit) of uart
AT+CMDEAR: Erase command(number of begin to number of ending)
AT+PAYVER: Get or Set payload version
AT+MBFUN: Get or Set Modbus Funtion code(0:none,1:01 or 02,2:03 or 04)for automatic cut
AT+COMMAND: Send data of command1-15 to RS485 deceive for payload
AT+SEARCH: Retrieve the hexadecimal character that appears in command 1-15
AT+DATACUT: Cut receive data after use command1-15
AT+CMDDL: Set delay timeout after send rs485 command1-15
AT+CFGDEV: Send data to RS485 deceive
AT+DNSTIMER: Regularly resolve domain names

MQTT Management

AT+CLIENT : Get or Set MQTT client
AT+UNAME : Get or Set MQTT Username
AT+PWD : Get or Set MQTT password
AT+PUBTOPIC : Get or Set MQTT publish topic
AT+SUBTOPIC : Get or Set MQTT subscription topic

Information

AT+FDR : Factory Data Reset
AT+PASSWORD : Serial Access Password
AT+LDATA : Get the last upload data

4. Battery & Power Consumption

RS485-NB use ER26500 + SPC1520 battery pack and RS485-NS use 3000mAh Recharable Battery with Solar Panel. See below link for detail information about the battery info and how to replace.

[Battery Info & Power Consumption Analyze](#) .

5. Firmware update

User can change device firmware to::

- Update with new features.
- Fix bugs.

Firmware and changelog can be downloaded from : [Firmware download link](#)

Methods to Update Firmware:

- (Recommended way) OTA firmware update via BLE: [Instruction](#).
- Update through UART TTL interface : [Instruction](#).

6. FAQ

6.1 How can I access t BC660K-GL AT Commands?

User can access to BC660K-GL directly and send AT Commands.

[See BC660K-GL AT Command set](#)

6.2 How many RS485-Slave can RS485-NB/NS connects?

The RS485-NB/NS can support max 32 RS485 devices. Each uplink command of RS485-NB/NS can support max 16 different RS485 command. So RS485-NB/NS can support max 16 RS485 devices pre-program in the device for uplink. For other devices no pre-program, user can use the downlink message (type code 0xA8) to poll their info.

6.3 How to configure the device through the MQTT subscription function?

1) Subscription content: {AT COMMAND}

Example:

Setting AT+5VT=500 through Node-RED requires MQTT to send the content {AT+5VT=500}.



The serial port displays:

```
CMD1    = fe 03 00 00 00 03 11 c4
RETURN1 = fe 03 06 11 11 22 22 33 33 65 54
Payload  = 01 11 11 22 22 33 33

[42203]BAT:3.584 V
[47629]Opened the MQTT client network successfully
[51187]Successfully connected to the server
AT+PWRM2
[54905]Upload data successfully
[58443]Received downlink data:AT+5VT=500
[59330]Subscribe to topic successfully
[62877]Close the port successfully
[63916]Send complete
[64940]*****End of upload*****
```

2) Starting with v1.1.0 firmware,, multiple AT commands can be configured on the downlink.

The command format is as follows:

{AT COMMAND1;AT COMMAND2;..AT COMMANDn}

Each command is separated by a ";" symbol and the total length of the commands issued cannot exceed 150 characters.

Example:

a)Send downstream from the MQTT.fx platform.



b)You can see the downlink received on the serial port.


```
DRAGINO RS485-NB-GE SensorManual
Image Version: v1.1.0
NB-IoT Stack : D-BC660K-003
Protocol in Used: MQTT
[6010]NB module is initializing...
[15607]NB-IOT has responded.
[19928]Echo mode turned off successfully.
[21271]Disable the reporting of deep sleep event URC.
[22626]Model information:BC660K-GL.
[23963]The IMEI number is:863663062798971.
[25306]The IMSI number is:460083880200247.
[27349]Set the data format for sending and receiving.
Currently set frequency band: 8,20,28,2,4,12,13,66,85,5
[32754]Exit sleep mode
[39363]Signal Strength:23
[44383]PSM mode configured
[47008]DNS configuration is successful
[49047]No DNS resolution required
[50082]*****Upload start:0*****

Payload = 01

[50141]BAT:3.647 V
[55550]Opened the MQTT client network successfully
[59096]Successfully connected to the server
AT+PWRM2
[62841]Upload data successfully
[66371]Received downlink data:AT+COMMAND2=01 03 60 26 00 02,1;AT+DATA CUT2=9,1,4+5+6+7;AT
+COMMAND3=01 03 60 26 00 02,1;AT+DATA CUT3=9,1,4+5+6+7;AT+COMMAND4=01 03 60 26 00 02,1;AT
+DATA CUT4=9,1,4+5+6+7
[66667]Subscribe to topic successfully
[70203]Close the port successfully
[71238]Send complete
[72258]*****End of upload*****
```

The configuration is completed, as follows.

```
AT+STOPBIT=0
AT+PAYVER=1
AT+MBFUN=0
AT+COMMAND1=0,0 AT+SEARCH1=0,0 AT+DATA CUT1=0,0,0 AT+CMDDL1=0
AT+COMMAND2=01 03 60 26 00 02 ,1 AT+SEARCH2=0,0 AT+DATA CUT2=9,1,4+5+6+7 AT+CMDDL2=0
AT+COMMAND3=01 03 60 26 00 02 ,1 AT+SEARCH3=0,0 AT+DATA CUT3=9,1,4+5+6+7 AT+CMDDL3=0
AT+COMMAND4=01 03 60 26 00 02 ,1 AT+SEARCH4=0,0 AT+DATA CUT4=9,1,4+5+6+7 AT+CMDDL4=0
```

6.4 How to Use RS485-NB/NS to connect to RS232 devices?

[Use RS485-NB/NS to connect to RS232 devices. - DRAGINO](#)

6.5 How to judge whether there is a problem with the set COMMAND

6.5.1 Introduce:

Users can use below the structure to fast debug the communication between RS485-NB/NS. The principle is to put the PC in the RS485 network and sniff the packet between Modbus MTU and RS485-NB/NS. We can [use this way to:](#)

1. Test if Modbus-MTU works with PC commands.
2. Check if RS485-NB/NS sent the expected command to Modbus-MTU
3. Check if Modbus-MTU return back the expected result to RS485-NB/NS.

4. If both b) and c) has issue, we can compare PC's output and RS485-NB/NS output.



Example Connection:

6.5.2 Set up PC to monitor RS485 network With Serial tool

Note: Receive and send set to hex mode

7. Order Info

Part Number: **RS485-NB-XX** or **RS485-NS-XX**

XX:

- **GE:** General version (Exclude SIM card)
- **1T:** with 1NCE * 10 years 500MB SIM card and Pre-configure to ThingsEye server

YY: The grand connector hole size

- **M12:** M12 hole
- **M16:** M16 hole

8. Packing Info

Package Includes:

- 1 x RS485-NB or RS485-NS NB-IoT Sensor Node
- External antenna x 1

Dimension and weight:

- Device Size: 13.0 x 5 x 4.5 cm
- Device Weight: 150g
- Package Size / pcs : 14.0 x 8x 5 cm
- Weight / pcs : 180g

9. Support

- Support is provided Monday to Friday, from 09:00 to 18:00 GMT+8. Due to different timezones we cannot offer live support. However, your questions will be answered as soon as possible in the before-mentioned schedule.
- Provide as much information as possible regarding your enquiry (product models, accurately describe your problem and steps to replicate it etc) and send a mail to Support@dragino.cc.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.