



AirSpeed-1200 eNB Installation Guide

Part Number: DUG01285

System Release: 15.5

Revision: AFC

Published: August 2017

© Copyright by **Airspan Networks Inc.**, 2017 - 2017. All rights reserved worldwide.

Legal Notices

The information contained within this document is proprietary and is subject to all relevant copyright, patent and other laws protecting intellectual property, as well as any specific agreements protecting Airspan Networks Inc. rights in the aforesaid information. Neither this document nor the information contained herein may be published, reproduced or disclosed to third parties, in whole or in part, without the express, prior, written permission of Airspan Networks Inc. In addition, any use of this document or the information contained herein for the purposes other than those for which it is disclosed is strictly forbidden.

Airspan Networks Inc. reserves the right, without prior notice or liability, to make changes in equipment design or specifications.

Information supplied by Airspan Networks Inc. is believed to be accurate and reliable. However, no responsibility is assumed by Airspan Networks Inc. for the use thereof nor for the rights of third parties which may be effected in any way by the use of thereof.

Any representation(s) in this document concerning performance of Airspan Networks Inc. product(s) are for informational purposes only and are not warranties of future performance, either expressed or implied. Airspan Networks Inc. standard limited warranty, stated in its sales contract or order confirmation form, is the only warranty offered by Airspan Networks Inc. in relation thereto.

This document may contain flaws, omissions or typesetting errors; no warranty is granted nor liability assumed in relation thereto unless specifically undertaken in Airspan Networks Inc. sales contract or order confirmation. Information contained herein is periodically updated and changes will be incorporated into subsequent editions. If you have encountered an error, please notify Airspan Networks Inc. All specifications are subject to change without prior notice.

Product performance figures quoted within this document are indicative and for information purposes only.

Acknowledgements



© Intel Corporation <http://www.intel.com/>



© Microsoft Corporation <http://www.microsoft.com>

Table of Contents

Document Information.....	1
Abstract.....	1
Revision History	1
Warnings and Cautions.....	2
Human Exposure to Radio Frequencies	2
Avertissement et Precautions d'Utilisation	2
Radio Interference	2
Modifications	2
General	2
Général	2
⚠ Important Safety Instructions	3
Safety.....	3
Securite.....	4
Warning of Hazardous Voltages	4
Attention aux Voltages Hasardeux.....	5
Adherence to European Directive 1999/5/EC	5
Warning Symbols.....	5
Service Information	5
UL Information	6
Lightning Protection	6
Outdoor Ethernet Cabling	7
DECLARATION OF CONFORMITY.....	7
GPS Compliance	8
Maximum Output TX Total Power	9
Power Consumption.....	9
Antenna System.....	10
About This Document	11
Purpose.....	11
Intended Audience	11

Document Conventions.....	11
Related Reading	12
Customer Care Help Desk	13
Airspan Encourages Comments	13
1 Introduction	14
1.1 AirSpeed 1200	14
1.1.1 Deployment.....	14
1.1.2 Integrated Backhaul – LTE UE Relay	14
2 Getting Started	16
2.1 Workflow of Installation	16
2.2 AirSpeed 1200 Installation Checklist	16
3 Verifying Prerequisites	17
3.1 Verifying Site Requirements.....	17
3.2 Verify Installation Requirements.....	17
3.2.1 Verify the Tools	17
3.2.2 Verify the Parts and Kits.....	18
3.2.3 Power.....	19
3.2.4 Physical Dimensions	19
3.2.5 Environmental	20
4 Installation of AirSpeed 1200.....	21
4.1 Mounting	21
4.1.1 Mounting Bracket on a Non-Wooden Pole.....	21
4.1.2 Mounting Bracket on a Wooden Pole	22
4.1.3 Mounting Bracket on a Wall.....	23
4.2 Securing AirSpeed 1200 to the Mounting Bracket.....	24
5 Connecting and Managing Power Cable	25
5.1 Power Cable Connection.....	25
5.1.1 Power Cable Preparation	25
5.1.2 Wire Connection for the Power Cable Connector	25
A Job Sheet.....	28
B Abbreviations	30

Figures

Figure 1: AirSpeed 1200	10
Figure 2: AirSpeed 1200	15
Figure 3: Workflow	16
Figure 4: AirSpeed 1200 Unit.....	19
Figure 5: AirSpeed Bottom View	19
Figure 6: Positioning Overview	21
Figure 7: Mounting Bracket on Pole.....	22
Figure 8: Mounting Bracket on Wooden Pole	22
Figure 9: Mounting Bracket on Wall.....	23
Figure 10: Securing AirSpeed 1200 to Mounting Bracket.....	24
Figure 11: Cable Connector Exploded View	25
Figure 12: Cable Preparation	26
Figure 13: Secure Cable to Connector	26
Figure 14: Power Cable Assembled	26
Figure 15: Close AC Connector Clamps.....	27
Figure 16: AirSpeed 1200 on Wooden Pole	27
Figure 17: AirSpeed 1200 on Non-Wooden Pole	28
Figure 18: AirSpeed 1200 on Wall	28

Tables

Table 1: AirSpeed 1200 B41 FCC Maximum Output TX Total Power	9
Table 2: AirSpeed 1200 B41 ETSI Maximum Output TX Total Power	9
Table 3: Power Consumption.....	9
Table 4: Typographic Conventions	11
Table 5. Minimum Hardware Requirements	17
Table 6: AirSpeed 1200 Components.....	18
Table 7. AirSpeed 1200 Physical Dimensions	19
Table 8. AirSpeed 1200 Environment Compliance	20
Table 9: Wire Assignment	26

Document Information

Abstract

This document details procedures for installing the Airspan's AirSpeed 1200 Pico-class LTE eNodeB variant.

Revision History

Revision Details	Date	Summary of Changes
0.1	June 2017	Initial document & comments
A	July 2017	- Additions prior to publishing - Additional content from comments
AFC1	August 2017	Additions

Warnings and Cautions

Human Exposure to Radio Frequencies

The AirSpeed 1200 should be installed and operated from a minimum safe distance of 2.5m

Avertissement et Precautions d'Utilisation

Exposition des personnes aux fréquences radioélectriques

Les antennes d'AirSpeed 1200 doivent être installée et utilisée de façon à garantir la distance minimale de sécurité de 2.5m

Radio Interference

This AirSpeed 1200 generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the technician is encouraged to try to correct the interference by performing one or more of the following measures:

- Re-orientate or relocate the unit
- Increase separation between the units and/or End Device
- Connect the equipment to a circuit different from that to which the power source is connected

Modifications

Any changes and modifications to this device that are not expressly approved by Airspan Networks may void the user's authority to operate the equipment.

General

- Only qualified personnel should be allowed to install, replace, and service the equipment.
- The device cannot be sold retail, to the general public or by mail order. It must be sold to operators.
- Installation must be controlled.
- Installation must be performed by licensed professionals.
- Installation requires special training. The AirSpeed 1200 radio and antenna should be installed ONLY by experienced installation professionals who are familiar with local building and safety codes and, wherever applicable, are licensed by the appropriate government regulatory authorities. Failure to do so may void Airspan's product warranty and may expose the end user or the service provider to legal and financial liabilities. Airspan and its resellers or distributors are not liable for injury, damage or violation of regulations associated with the installation of outdoor units or antennas.
- The device is to be installed in a Restricted Access Location.
- Power provided by PoE output cannot be considered limited power source (LPS) per IEC/UL 60950-1 clause 2.5.
- Connection to the PoE port is permitted only by certified electrician according to NEC requirements.
- Connect PoE terminal only to equipment which does NOT require "LPS only" feeding.

Général

- Seul le personnel qualifié peut être autorisé pour installer ou remplacer l'équipement ainsi qu'effectuer les opérations de maintenance pour cet équipement.
- L'équipement ne peut pas être vendu en grande distribution ou par commande via email à destination du public. Il doit être vendu aux opérateurs de télécommunications.
- Son installation doit être contrôlée
- Son Installation doit être effectuée par des professionnels autorisés.
- Son installation requiert une formation spécifique du personnel. L'AirSpeed 1200, radio et antenne doit être installée UNIQUEMENT par des installateurs professionnels expérimentés et ayant une connaissance des constructions locales et règles de sécurité, ainsi que, dès que nécessaire, disposant d'un accord des autorités gouvernementales de régulation. Toute infraction à ces obligations peut annuler la garantie délivrée par Airspan pour ces produits et peut exposer l'utilisateur final ou le fournisseur de services à des dommages légaux et financiers.
- Airspan et ses revendeurs ou ses distributeurs ne sont pas responsables des blessures, dommages ou violations de la régulation en vigueur liés à l'installation du système extérieur ou des antennes.
- L'Équipement doit être installé dans une zone à accès réduit et contrôlé.
- L'alimentation fournie par la sortie PoE ne peut pas être considérée comme une Source d'Alimentation Limitée (ou LPS – limited power source) selon le standard IEC/UL 60950-1 clause 2.5
- La connexion au port PoE est autorisée par un électricien certifié selon les standards NEC.
- Connecter le port PoE uniquement aux équipements NE demandant PAS une source de type " LPS only

Important Safety Instructions

- Read and Save these instructions
- This Installation Guide contains instructions and warnings that should be followed during installation, and operation.
- Failure to follow these instructions could cause bodily injury and/or product failure.

Safety

1. Read this guide and follow all operating and safety instructions.
2. Supply cord is not shipped with the unit and is to be provided by user. Installation is to be performed by a qualified electrician according to local codes. Installation to be done in accordance with the National Electrical Code (NEC), ANSI/NFPA 70, the Canadian Electrical Code (CEC), Part I, CAN/CSA C22.1, and when applicable, the National Electrical Safety Code, IEEE C2.
3. Static sensitive components inside - do not remove the lid or base: No user serviceable parts inside.
4. The ground connection should be made before connecting to supply connections.
5. Position the power cord to avoid possible damage; do not overload circuits.
6. Do not place this product on or near a direct heat source, and avoid placing objects on the terminal.
7. To avoid electrical shock do not install this device during adverse conditions such as rain or inclement weather.
8. Use only a damp cloth for cleaning. Do not use liquid or aerosol cleaners. Disconnect the power before cleaning.
9. The units should not be located too near power lines or other electrical power circuits, where it can come into contact with such power lines or circuits.

10. The radio transceiver must be properly grounded to protect against power surges and accumulated static electricity. It is the user's responsibility to install this device in accordance with the local electrical codes.
11. Installation of the AirSpeed 1200 must be contracted to a professional installer.
12. The circuit breaker should be easily accessible in case you have to disconnect the device.
13. When installed in the final configuration, the product must comply with the applicable Safety Standards and regulatory requirements of the country in which it is installed. If necessary, consult with the appropriate regulatory agencies and inspection authorities to ensure compliance.

Securite

1. Lire attentivement ce guide et suivre les instructions d'utilisation et de sécurité.
2. Le cordon d'alimentation n'est pas livré avec l'appareil et doit être fourni par l'utilisateur. L'installation doit être effectuée par un électricien qualifié conformément aux règles et standards locaux. L'installation doit être effectuée en conformité avec le Code national de l'électricité (NEC), ANSI / NFPA 70, le Code canadien de l'électricité (CCE), Partie I, CAN / CSA C22.1, et le cas échéant, le Code national de sécurité électrique, IEEE C2.
3. Des composants sensibles a électricité statique sont utilisés à l'intérieur. Ne pas retirer le coffre ou la base. Aucune pièce a l'intérieur est d'utilité pour l'utilisateur.
4. La connexion "terre" doit être effectuée en priorité et avant d'effectuer les connexions à la source d'alimentation (phase et neutre).
5. Positionner le cordon d'alimentation de façon à éviter des dommages potentiels. Ne pas surcharger les circuits.
6. Ne pas placer ce produit sur ou à proximité d'une source directe de chaleur et éviter de placer des objets sur le terminal.
7. Afin d'éviter des problèmes électriques, ne pas installer cet équipement au cours d'évènements climatiques difficiles comme averses ou météo non clémente.
8. Utiliser uniquement chiffon de coton pour nettoyage. Ne pas utiliser de produits liquides ou d'aérosols. Déconnecter le produit de la source d'alimentation avant nettoyage.
9. L'unité ne doit pas être située trop près de lignes électriques ou autres circuits de puissance, avec lesquels il pourrait entrer en contact.
10. L'émetteur radio doit être correctement relié a la terre afin de le protéger contre les surtensions ou accumulation d'électricité statique. L'utilisateur est tenu responsable de l'installation du produit conformément aux règles électrique en vigueur localement.
11. L'installation de AirSpeed 1200 doit être contractualisée avec un installateur professionnel.
12. L'interrupteur de circuit électrique doit être facilement accessible afin de pouvoir déconnecter l'équipement.
13. Lors de l'installation de la configuration finale, le produit doit être conforme aux Standards de Sécurité en vigueur ainsi qu'aux exigences réglementaires du pays dans lequel il est installé. Si nécessaire, consulter les agences réglementaires appropriées, ainsi que les autorités chargées de l'inspection afin de garantir la conformité.

Warning of Hazardous Voltages

On AC installations, hazardous voltages exist. Use caution when verifying or working with AC power. Remove metal jewellery that could come into contact with AC power.

On DC sections, short-circuiting the low voltage, low impedance circuits can cause severe arcing that may result in burns or eye damage. Remove rings, watches etc. to avoid shorting DC circuits.

Note: Airspan products do not contain hazardous substances (as defined in UK Control of Substances Hazardous to Health Regulations 1989 and the Dangerous Substances Regulations 1990). At the end of any Airspan products life cycle, the customer should consult with Airspan to ensure that the product is disposed of in conformance with the relevant regulatory requirements.

Attention aux Voltages Hasardeux

Sur les installations de réseau électrique de type courant alternatif (CA) des voltages hasardeux peuvent survenir. Garder une Attention particulière lors d'une vérification ou de travaux sur réseau électrique CA. Retirer tous bijoux en métal qui pourraient entrer en contact avec l'alimentation ou le réseau CA.

Sur les portions de réseau électrique de type courant continu (CC), un circuit basse impédance peut causer de sérieux arcs électriques qui pourraient bruler ou endommager les yeux. Retirer bagues, anneaux, montres etc... afin d'éviter les court-circuit sur le réseau CC.

Adherence to European Directive 1999/5/EC

European Council Recommendation 1999/5/EC details basic restrictions and reference levels on human exposure to electromagnetic fields as advised by the ICNIRP. Adherence to these recommended restrictions and reference levels should provide a high level of protection as regards the established health effects that may result from exposure to electromagnetic fields.



Airspan equipment is compliant with CE and R&TTE regulations and can be operated in all EU (European Union) locations listed below:

Country Code			
BE	EL	LT	PT
BG	ES	LU	RO
CZ	FR	HU	SI
DK	HR	MT	SK
DE	IT	NL	FI
EE	CY	AT	SE
IE	LV	PL	UK

Warning Symbols

The following symbols may be encountered during installation or troubleshooting. These warning symbols mean danger. Bodily injury may result if you are not aware of the safety hazards involved in working with electrical equipment and radio transmitters. Familiarize yourself with standard safety practices before continuing.



Caution, hot surface



Caution



Electro-Magnetic
Radiation



High Voltage

Service Information

Refer all repairs to qualified service personnel. Do not modify any part of this device, as this will void the warranty.

Disconnect the power to this product and return it for service if the following conditions apply:

- a. The terminal does not function after following the operating instructions outlined in this manual.
- b. The product has been dropped or the housing is damaged.

Locate the serial number of the terminal and record this on your registration card for future reference. Also record the MAC address, located on the product sticker.

UL Information

- The equipment must be properly grounded according with NEC and other local safety code requirements.
- Reminder to all the BWA system installers: Attention to Section 820-40 of the NEC which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as is practical.
- AirSpeed 1200 is designed to operate in environmental conditions complying with IP66 and relevant standards.

Lightning Protection

WARNING: The following notes are general recommendations for the system. The wireless equipment should be installed by a qualified professional installer and must follow local and national codes for electrical grounding and safety. Failure to meet safety requirements and/or use of non-standard practices and procedures could result in personal injury and damage to equipment. A direct lightning strike may cause serious damage even if these guidelines are followed.

All outdoor wireless equipment is susceptible to lightning damage from a direct hit or induced current from a near strike. Lightning protection and grounding practices in local and national electrical codes serve to minimize equipment damage, service outages, and serious injury. The antennas are to be DC grounded, so surge protection is not required. Reasons for lightning damage are summarized as:

- Poorly grounded tower/antenna sites that can conduct high lightning strike energy into equipment.
- Lack of properly installed lightning protection equipment that can cause equipment failures from lightning induced currents.

A lightning protection system provides a means by which the energy may enter earth without passing through and damaging parts of a structure. A lightning protection system does not prevent lightning from striking; it provides a means for controlling it and preventing damage by providing a low resistance path for the discharge of energy to travel safely to ground. Improperly grounded connections are also a source of noise that can cause sensitive equipment to malfunction.

A good tower grounding system disperses most of the surge energy from a tower strike away from the building and equipment.

To limit the equipment damage due to a lightning strike, the following practices are recommended for the wireless system:

- Provide direct grounding from the antenna mounting bracket, the radio and antenna and the lightning/surge protectors to the same ground point at the base of the tower or a ground bus on the building. Use the grounding screws on the antenna bracket and the radio and antenna for terminating the ground wires.
- The circuit ground must be connected to the same grounding system as the eNodeB.

Outdoor Ethernet Cabling

- Ethernet cable connected to should be outdoor grade with UV protection.
- Use shielded out CAT6 cabled terminated with metallic RJ45 connectors.
- In order to protect the indoor unit, install surge protection circuits on all copper cables on their entrance to the building.
- Surge protection circuit must use a minimum 14AWG grounding cable.

DECLARATION OF CONFORMITY

European Community, Switzerland, Norway, Iceland, and Liechtenstein

Declaration of Conformity with Regard to the R&TTE Directive 1999/5/EC

English:

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Deutsch:

Dieses Gerät entspricht den grundlegenden Anforderungen und den weiteren entsprechenden Vorgaben der Richtlinie 1999/5/EU.

Dansk:

Dette udstyr er i overensstemmelse med de væsentlige krav og andre relevante bestemmelser i Directiv 1999/5/EF.

Español:

Este equipo cumple con los requisitos esenciales así como con otras disposiciones de la Directiva 1999/5/EC.

Greek:

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Airspan ΔΗΛΩΝΕΙ ΟΤΙ Ο ΕΞΟΠΛΙΣΜΟΣ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Français:

Cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la Directive 1999/5/EC.

Íslenska:

Þessi búnaður samrýmist lögboðnum kröfum og öðrum ákvæðum tilskipunar 1999/5/ESB.

Italiano:

Questo apparato é conforme ai requisiti essenziali ed agli altri principi sanciti dalla Direttiva 1999/5/EC.

Nederlands:

Deze apparatuur voldoet aan de belangrijkste eisen en andere voorzieningen van richtlijn 1999/5/EC.

Norsk:

Dette utstyret er i samsvar med de grunnleggende krav og andre relevante bestemmelser i EU-directiv 1999/5/EC.

Português:

Este equipamento satisfaz os requisitos essenciais e outras provisões da Directiva 1999/5/EC.

Suomalainen:

Tämä laite täyttää direktiivin 1999/5/EY oleelliset vaatimukset ja on siinä asetettujen muidenkin ehtojen mukainen.

Svenska:

Denna utrustning är i överensstämmelse med de väsentliga kraven och andra relevanta bestämmelser i Direktiv 1999/5/EC.

Român:

Acest echipament este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivei 1999/5/CE.

The Declaration of Conformity related to this product can be obtained from PLM@Airspan.com.

GPS Compliance

The GPS is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC."

The GPS complies with the following EMC Common Regulatory Testing standards:

- EN55022: Radiated and Conducted Emissions
- CISPR 22: Class B
- EN 50081-1: Generic Emissions Class B
- EN 50082-1: Generic Immunity Class B
- EN 61000-4-2: Electrostatic Discharge Immunity
- EN 61000-4-3: Radiated RF EM Field Immunity Test
- EN 61000-4-4: Electrical Fast Transient/Burst Test
- EN 61000-4-6: Conducted Immunity
- EN 61000-4-8: Magnetic Field Immunity

Note: A GPS is recommended for synchronizing between LTE sectors.

Note: An optional GPS Lightning/Surge protector is available from Airspan when installing the GPS antenna in a remote location for lightning prone deployments.

Maximum Output TX Total Power

Table 1: AirSpeed 1200 B41 FCC Maximum Output TX Total Power

Frequency Band (MHz)	FCC TX	EIRP	Antenna Gain
2496 – 2690	28.32 dBm	38.82 dBm	10.5 dBi

Table 2: AirSpeed 1200 B41 ETSI Maximum Output TX Total Power

Frequency Band (MHz)	ETSI TX	EIRP	Antenna Gain
2496 – 2690 MHz	28 dBm	38.5 dBm	10.5 dBi

Caution: Do not set maximum output TX power to higher than local regulations.

Power Consumption

AirSpeed 1200 has a Max nominal power consumption of 50W. AirSpeed 1200 power consumption is described in the following table:

Table 3: Power Consumption

Duplex	Tx Power at RF Port (dBm)	Nominal Power Consumption (W)
TDD	Sec1: 25 Sec2: 41	50

Antenna System

The AirSpeed 1200 provides the best SINR levels toward the donor MACRO eNodeB.

Figure 1: AirSpeed 1200



About This Document

Purpose

This guide provides the workflow and step-by-step procedures for Installing the AirSpeed 1200. These procedures include:

- Verify prerequisites
- Install the AirSpeed 1200
- Connect and manage cables

Intended Audience

This guide is intended for persons who are responsible for installing the AirSpeed 1200 equipment. These persons should have a working knowledge of the equipment.

Document Conventions

This document uses the following typographic conventions.

Table 4: Typographic Conventions

Convention	Element
<u>Blue</u> underlined text	Cross-reference links.
Bold text	Keyboard buttons and GUI elements.
Command	Command names or phrases.
Computer output	Text displayed by the computer.
Hyperlinks	Website and e-mail addresses.
Danger	Signifies a hazardous situation—if not avoided—will cause death or serious injury. Describes how to avoid it.
Warning	Signifies a hazardous situation—if not avoided—can cause death or serious personal injury. Describes how to avoid it.
Caution	Signifies a hazardous situation—if not avoided—can void the product warranty, and cause property damage. Describes how to avoid it.
Important	Provides necessary information to explain a task.
Note	Provides additional information.
Tip	Provides helpful hints.

Related Reading

The following documents contain related information:

- AirSpeed 1200 Product Datasheet
- Airspan LTE Commissioning Manual *Pending*

Customer Care Help Desk

Airspan's *Customer Care Help Desk* offers prompt and efficient customer support services.

Note: To avail Airspan's *Customer Care Help Desk* support, you must be a registered user and must have a valid support contract. To register, click [here](#) and fill the **Registration** form.

To create and update issue logs, send e-mails to [Customer Care Help Desk](#). Once you submit your issue, the system generates a new issue and sends an issue number for your reference. The system uses this issue number to categorize and store e-mails under the appropriate issue.

To help *Customer Care Help Desk* identify your issue, include the issue number and your *Customer Care Helpdesk* account details in all further communications.

Main Operations

Airspan Communications Ltd.
Capital Point
33 Bath Road
Slough, Berkshire
SL1 3UF, United Kingdom
Tel: +44-1895-467-100

Worldwide Headquarters

Airspan Networks Inc.
777, Yamato Road, Suite 105
Boca Raton, FL 3341-4408, USA
Tel: +1 561 893 8670

Airspan Encourages Comments

Airspan welcomes any feedback and suggestions that help to improve the quality of the documentation. Send your feedback to documentfeedback@airspan.com.

1 Introduction

This section provides a descriptive overview of the Airspan's AirSpeed 1200 Pico-class eNodeB variant and its place in the Airspan product suite.

1.1 AirSpeed 1200

AirSpeed 1200 is part of Airspan's carrier-class LTE advanced outdoor small cell eNodeB family. AirSpeed 1200 is a Pico-class LTE eNodeB product, providing high-speed data, mobility, Voice over LTE, and broadcast/multicast services.

AirSpeed 1200 is a super compact, easy to install Pico-class eNodeB. Allowing an operator to deploy LTE broadband services on any Street Furniture, rooftop or building front without the need for backhaul connectivity or infrastructure – It uses the already existing Macro layer for backhauling.

AirSpeed 1200 is a dual sector / carrier 2x2 MIMO product.

AirSpeed 1200 fully supports the standard LTE (Uu/S1/X2) interfaces.

All Airspan eNodeB products, including AirSpeed 1200, are interoperable with a rich portfolio of 3rd party end user devices, including many handsets, indoor UEs, outdoor UEs and USB dongles from several ODMs, using various chipsets. For an updated of interoperability list, please contact your nearest Airspan Sales Representative.

Note: For management please refer to the AirSpan LTE Commissioning Manual as well as the Netspan User Manual.

1.1.1 Deployment

AirSpeed 1200 perfectly fits the requirements of the hard zoning outdoor locations such as hotels, city centers, parks and universities all due to its super compact one box form factor.

AirSpeed 1200 creates a single install process for LTE Access and Backhaul, and enables “Just add Power” plug and play deployment method and along with the easy zoning of the product saving deployment related costs and time.

Note: The following is for illustration only; actual layout may differ as infrastructure is installation-specific.

Note: AirSpeed 1200 must be properly grounded according with NEC and other local safety code requirements.

1.1.2 Integrated Backhaul – LTE UE Relay

AirSpeed 1200 includes an integrated wireless backhaul using an innovative LTE UE Relay technology using the Macro layer for backhauling.

Figure 2: AirSpeed 1200




Note: The illustration above displays the AirSpeed 1200 unit.

2 Getting Started

2.1 Workflow of Installation

The Workflow to install the AirSpeed 1200 is shown in the following diagram:

Figure 3: Workflow



2.2 AirSpeed 1200 Installation Checklist

Plan the installation of the AirSpeed 1200 by using the Installation Checklist, which you can find as a removable job aid in [Appendix A](#) for this guide.

3 Verifying Prerequisites

Prior to installing the AirSpeed 1200, verify the required safety, power, tools, parts and components. This chapter includes the hardware, software, and client requirements for installation.

Important: Set up requirements for the installation is detailed in the **Job Sheet**, see [Appendix A](#).

3.1 Verifying Site Requirements

To set up the AirSpeed 1200, an IP connection to a Netspan server is required.

3.2 Verify Installation Requirements

3.2.1 Verify the Tools

Table 5. Minimum Hardware Requirements


Tool	Use
Large flat bladed screwdriver	securing the pole straps
10mm or 13/32 inch wrench	for securing flange nuts
Large pliers	Tightening cable glands - To fit 15mm
Small flat blade screw driver (insulated shaft recommended)	For AC power cable preparation
pliers	For AC power cable preparation
Knife	For AC cable preparation
Small side cutters	For AC power cable preparation
Wire strippers	For AC power cable preparation

3.2.2 Verify the Parts and Kits

The following figures display various AirSpeed 1200 components and accessory kits.

Note: Verify order and requirements to ensure the correct unit type is being installed.

Table 6: AirSpeed 1200 Components

Installation Kit / Part	Product Code	Airspan No.	Consisting of	Images
AirSpeed 1200 , 2.496 - 2.568 / 2.618 - 2.69 GHz (B41LH), AC	AS12-U41LH-B00A	998-73-410SP	AirSpeed 1200 , 2.496 - 2.568 / 2.618 - 2.69 GHz (B41LH) & Bracket, including 2 Pole clamp bands, AC Connector clamp & universal bracket (cradle)	
AirSpeed universal pole and wall Mounting KIT	AS12-U-PMK-1		AirSpeed universal pole and wall Mounting KIT	

Note: Bracket extensions for when a greater distance is required from the pole due to larger pole diameters and their intrinsic blockage, are available, consult your Airspan representative.

AirSpeed-1200 variants are shown below.

Figure 4: AirSpeed 1200 Unit





Figure 5: AirSpeed Bottom View



3.2.3 Power

AirSpeed 1200 supports direct connection to AC power source
Operational Voltage Range: 100~240 VAC, 50-60Hz, 2.5A

3.2.4 Physical Dimensions

AirSpeed 1200 is in an all outdoor enclosure.

Table 7. AirSpeed 1200 Physical Dimensions

Variant	Dimensions (H x D)	Comment
Total size	260 x 200 - 230 mm / 10.24 x 8-9 in.	The physical dimensions exclude connectors
Weight		
Main Unit	4.6 Kg / 10.14 Lbs.	
Universal mounting bracket (cradle)	1 Kg / 2.2 Lbs.	

3.2.5 Environmental

Note: AirSpeed 1200 is not meant to be used in a Marine environment.

AirSpeed 1200 meets the following environmental requirements:

- GR-63 Storage and Transportation
- ETSI EN 300-019-1-4 Operational (non-weather protected equipment)
- ETSI EN 300-019-1-1 Storage (weather protected, not temperature controlled locations)
- ETSI EN 300-019-1-2 Transportation

Table 8. AirSpeed 1200 Environment Compliance

Type	Details
Operating temperature	-40°C to 55°C / -40°F to 131°F
Operating humidity	5% - 100% non-condensing
Storage temperature	-40°C to 70° C / -40°F to 158°F
Storage humidity	5% - 100% non-condensing
Rain and dust ingress protection	IP66

4 Installation of AirSpeed 1200

4.1 Mounting

AirSpeed 1200 is installed on a pole or wall and comes fully assembled. Prior to installation of the AirSpeed unit the mounting bracket must first be affixed in place.


Caution: Proper local rigging and hoisting practices should be followed when installing the AirSpeed 1200.

Note: Bracket extensions for when a greater distance is required from the pole due to larger pole diameters and their intrinsic blockage, are available, consult your Airspan representative.

Note: Pole installation should be so the antenna(s) are positioned parallel to the street for maximum coverage.

Note: Sector and Antenna direction are indicated on the bottom panel of the AirSpeed 1200, see [AirSpeed Bottom View](#)


Figure 6: Positioning Overview



4.1.1 Mounting Bracket on a Non-Wooden Pole

The following images show the mounting bracket pole mount assembly for a non-wooden pole.

1. Select the location on the pole to mount the AirSpeed 1200 mounting bracket. You can attach the AirSpeed 1200 to any pole from 2 to 8 inch (48 to 210 mm) in diameter.
2. Position the mounting bracket with the engagement holes facing up.
3. Insert the clamp bands (supplied) by passing them through the upper notches and the lower slots in the bracket, in two (2) places.
4. Tighten the clamp bands with a large screw driver.


Figure 7: Mounting Bracket on Pole

5. Loosen the screws and open the AC connector clamps in preparation for later insertion of the AC connector.
6. The mounting bracket is installed and ready for AirSpeed 1200 installation.

4.1.2 Mounting Bracket on a Wooden Pole

The following images show the mounting bracket pole mount assembly for a wooden pole.

1. Select the location on the pole to mount the AirSpeed 1200 mounting bracket. You can attach the AirSpeed 1200 to any pole from 2 to 8 inch (48 to 210 mm) in diameter.
2. Position the mounting bracket with the engagement holes facing up.
3. Insert the clamp bands (supplied) by passing them through the upper notches and the lower slots in the bracket, in two (2) places.
4. You can optionally insert through bolts (not supplied) for additional fastening.
5. Tighten the clamp bands with a large screw driver.

Figure 8: Mounting Bracket on Wooden Pole

6. Loosen the screws and open the AC connector clamps in preparation for later insertion of the AC connector.
7. The mounting bracket is installed and ready for AirSpeed 1200 installation.


4.1.3 Mounting Bracket on a Wall

The following images show the bracket wall mount assembly.

1. Select the location on the wall to mount the AirSpeed 1200 mounting bracket.
2. Position the mounting bracket against the wall with the engagement holes facing up. Be sure to position the mounting bracket straight with **level mounting** to ensure the unit sits uniformly.
3. Mark the wall through the holes on the mounting bracket at the required height.
4. Attach the mounting bracket to the wall using wall plugs (x4) and appropriate screws rated for at least 8-10 Kg per fastener.

Note: Wall plugs (x4) and necessary hardware are **not** supplied by Airspan and are the responsibility of the installer. Recommended 3/8" dia. with appropriate wall plugs according to field conditions.

Figure 9: Mounting Bracket on Wall



5. Loosen the screws and open the AC connector clamps in preparation for later insertion of the AC connector.
6. The mounting bracket is installed and ready for AirSpeed 1200 installation.


4.2 Securing AirSpeed 1200 to the Mounting Bracket

The following procedure describes assembly of the AirSpeed 1200 on the mounting bracket (cradle).

This procedure is applicable to all mounting scenarios, pole or wall.

1. Lift the AirSpeed 1200 unit on to the mounting bracket and align the hangers with their respective slots on the top portion of the bracket.
2. Insert the hangers into the top slots of the mounting bracket.
3. With the hangers engaged in the top slots align the threaded (M8) studs (that protrude from the bottom of the unit) into the bottom holes of the mounting bracket and fasten the supplied M8 washer and flange nut.
4. Tighten the M8 flange nuts (2 places).

Figure 10: Securing AirSpeed 1200 to Mounting Bracket



The AirSpeed 1200 is installed and ready for power cable connection.

Assembly of the power cable and the power cable connector clamp are described in [Power Cable Preparation](#) below.

5 Connecting and Managing Power Cable

5.1 Power Cable Connection

Danger: Hazardous voltage! Before working, ensure that the power is removed from the power connection cables. When the system is powered on, **do not touch the power terminals**.

5.1.1 Power Cable Preparation

Tip: It is good practice to label both ends of the cable to identify which AirSpeed 1200 unit it is connected to.

Tip: It is good practice to leave a spare loop of cable (approximately 0.5m). This will allow for easier wiring and will allow the cable to be re-terminated if necessary in the future.

Warning: Required:

- Circuit breaker for AC power source -16A for EU installation and 20A for US installation. Minimum – 10A.

The power cable is connected to the AirSpeed 1200 connector on the back panel of the unit.

Figure 11: Cable Connector Exploded View



Note: When securing the cable make sure there is no tension on the cable so that it is easy to disconnect and re-connect for future maintenance actions.

5.1.2 Wire Connection for the Power Cable Connector

1. Unscrew the connector lower section of the connector which is attached to the cable on the AirSpeed 1200 unit.
2. Feed the unterminated end of the power cable to the location of the AC Power Connector suspended from the AirSpeed unit.
3. Strip back and remove the outer sheath to expose the inner blue / white and black insulated wires to a length of 3cm (1.18 in). Then strip back 6mm (0.24 in) of the inner core insulation.
4. Thread the prepared cable end through the gland, washer, sealing ring and body of the connector.

Figure 12: Cable Preparation



5. Secure the prepared ends of the cable into the inner part of the connector.

Figure 13: Secure Cable to Connector



6. Line up the attached cable in preparation for closing the connector housing sections. Do not tighten the tail nut yet.

Figure 14: Power Cable Assembled



7. Once assembled tighten the tail nuts.

Table 9: Wire Assignment

Wire Color	Description
White	Neutral
Black	Phase
Green	Ground


1. Insert into connector, and screw shut.
2. Tighten the tail nut on to the body forcing the seal to compress around the power cable ends.

Caution: Do not over tighten the connector or the tail nut. The connector nut should be tightened to a torque of **no** more than 3.3 Nm (2.43 lb-ft) max.

Note: When securing the cable verify there is no tension on the connector so that it is easy to disconnect and re-connect for future maintenance actions.

3. Gently re-position the AC Connector so the AC Connector Clamps close onto the power cable holding it in place.

Figure 15: Close AC Connector Clamps



4. Secure the AC clamp screws.
5. The AirSpeed 1200 is installed and ready for power cable connection.

AirSpeed 1200 mounted on a wooden pole.

Figure 16: AirSpeed 1200 on Wooden Pole



AirSpeed 1200 mounted on a non-wooden pole.

Figure 17: AirSpeed 1200 on Non-Wooden Pole



AirSpeed 1200 mounted on a wall.

Figure 18: AirSpeed 1200 on Wall



A Job Sheet

This job sheet enables the users to keep track of their installation. It covers all the prerequisites required for accomplishing the AirSpeed 1200 installation.

Site Requirements	
	○ Pole or Wall for installation identified ○ Position on pole or Wall identified ○ Access restrictions (highway regulations, other services on pole, power pole) ○ Method of reaching desired positions (ladders, Elevated work platform) ○ AC main fuse block available (where needed) ○ Configuration programming details known ○ All equipment items available at the installation site

○ Main AirSpeed 1200 unit ○ AC Connector Clamp
Tool Requirements (For further information, see Verify the Tools.)
○ Large flat screw driver for pole clamps ○ Small flat blade screw driver (insulated shaft recommended) ○ Medium Philips head screw driver ○ 8mm wrench for unit nuts ○ Knife ○ pliers ○ Small side cutters ○ Tweezers (or fine blade long nose pliers) ○ Wire strippers
Required Ancillary Equipment
○ Laptop PC for initial configuration ○ cable for temporary connection of the lap top

B Abbreviations

Term	Definition
3GPP	3rd Generation Partnership Project, responsible for LTE
ABS	Almost Blank Subframe
ACS	Adjacent Channel Selectivity is a measurement of a receiver's ability to process a desired signal while rejecting a strong signal in an adjacent frequency channel. ACS is defined as the ratio of the receiver filter attenuation on the assigned channel frequency to the receiver filter attenuation on the adjacent channel frequency.
AWGN	Additive White Gaussian Noise is a channel model in which the only impairment to communication is a linear addition of white noise with a constant spectral density and a Gaussian distribution of amplitude.
BER	Bit Error Rate
CN	Core Network
CP	Cyclic Prefix
CTC	Convolution Turbo Code is a high-performance forward error correction (FEC) code
dB	Decibel. A logarithmic unit used to describe a ratio (such as power ratio in radio telecommunications)
dBm	An abbreviation for the power ratio in decibels (dB) of the measured power referenced to one milliwatt (mW). It is used as a convenient measure of absolute power because of its capability to express both very large and very small values in a short form
eNodeB	Evolved Node B, is the element in E-UTRAN of LTE
ESP	Encapsulating Security Payloads (ESP) provide confidentiality, data-origin authentication, connectionless integrity, an anti-replay service (a form of partial sequence integrity), and limited traffic-flow confidentiality
E-UTRAN	Evolved UMTS Terrestrial Radio Access Network, is the air interface of 3GPP's Long Term Evolution
EVM/RCE	The Error Vector Magnitude or EVM (sometimes also called Receive Constellation Error or RCE) is a measure used to quantify the performance of a digital radio transmitter or receiver. It is measured in dB or percentage (%) – the lower the better
FDD	Frequency-Division Duplexing. A transceiver mode where the transmitter and receiver operate at different carrier frequencies
GNSS	Global Navigation Satellite System is a term used to describe a satellite navigation system with global coverage. There are currently two fully operational GNSSs – the US GPS and the Russian GLONASS.
GTP-U	GPRS Tunneling Protocol for User data is a relatively simple IP based tunneling protocol which permits many tunnels between each set of end points
HPBW	Half Power BandWidth is the angular separation in an antenna, in which the magnitude of the radiation pattern decreases by 50% (or -3 dB) from the peak of the main beam
ICS	In-channel selectivity is a measure of the receiver's ability to receive a wanted signal at its assigned Resource Block locations in the presence of an interfering signal
IPSec	Internet Protocol Security is a protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a communication session

LED	Light Emitting Diode
LTE	Long Term Evolution
MAC	Medium Access Controller – responsible for several functions such Error Correction, Packet (De)Multiplexing, etc...
MBSFN	Multicast-Broadcast Single Frequency Network is an LTE feature designed to deliver services such as Mobile TV using the LTE infrastructure, and is expected to be a competitor to DVB-H-based TV broadcast
MCS	Modulation and Coding Scheme
MME	Mobility Management Entity is the key control-node for the LTE access-network. It is responsible, among other things for idle mode UE tracking and paging procedure including retransmissions
MTBF	Mean Time Between Failures
OFDMA	Orthogonal Frequency-Division Multiple Access (OFDMA) is a multi-user version of OFDM digital modulation scheme, used for eNodeB transmissions to UEs
PDPC	Packet Data Convergence Protocol. A Sub-Layer in LTE responsible for IP Header (De)Compression, etc...
PDU	Protocol Data Unit
PTP	Precision Time Protocol is used to synchronize clocks throughout a network. In this document, PTP is referring to IEEE1588-2008 protocol
RB	Resource Block
RLC	Radio Link Control. A Sub-Layer in LTE responsible for Ack/Nack, error correction, packet reordering, etc...
ROHS	Restriction Of Hazardous Substances
RRM	Radio Resource Management is used to cover all functions that are related to the assignment and sharing of radio resources among UEs
S-GW	Serving Gateway. A Core entity in the LTE EPC architecture responsible for routing and forwarding user data packets, while also acting as the mobility anchor for the user plane during inter-eNodeB handovers and as the anchor for mobility between LTE and other 3GPP technologies
SC-FDMA	Single-Carrier FDMA is a frequency-division multiple access scheme, dealing with the assignment of multiple users to a shared communication resource. Used in LTE for UE
SCTP	Stream Control Transmission Protocol is a reliable transport layer protocol, ensuring in-sequence transport of messages with congestion control like TCP
SDR	Software Defined Radio
WEEE	Waste Electrical and Electronic Equipment