

## EF-6215

### Instruction manual

1. Frequency range: 88.1~107.9MHz。
2. Memory the latest frequency when press open button.
3. Memory store 10 (M1-M10) pcs optional selected frequency by user.
4. power source: 2 AAA batteries or DC5V car charge optional.
5. Memory frequency operate step:
  - a. Press frequency select button(+/-) select frequency you want to store.(i.e: 88.1MHz)
  - b. Press memory button around 2 seconds. M1 turn into glint state. With frequency select button(+/-) select memory spot you want store(i.e: M5).
  - c. Press memory button confirm. Frequency 88.1 MHz memory in M5 spot.
6. Cancel memory frequency operate step:
  - a. Press memory button rapidly. Press one time the frequency spot autoskip to next memory spot. Cycle between M1 to M10.

### FCC Warning

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- ☐ Consult the dealer or an experienced radio/TV technician for help.