



AirPrime WP7611

Hardware Integration Guide



SIERRA
WIRELESS®

41113538
Rev 1.0

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

Safety and Hazards

Do not operate the Sierra Wireless modem in areas where blasting is in progress, where explosive atmospheres may be present, near medical equipment, near life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the Sierra Wireless modem **MUST BE IN AIRPLANE MODE OR POWERED OFF**. The Sierra Wireless modem can transmit signals that could interfere with this equipment.

Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE IN AIRPLANE MODE OR POWERED OFF**. When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Patents

This product may contain technology developed by or for Sierra Wireless Inc. This product includes technology licensed from QUALCOMM®. This product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or more patents licensed from InterDigital Group and MMP Portfolio Licensing.

Copyright

©2019 Sierra Wireless. All rights reserved.

Trademarks

Sierra Wireless®, AirPrime®, AirLink®, AirVantage® and the Sierra Wireless logo are registered trademarks of Sierra Wireless, Inc.

Windows® and Windows Vista® are registered trademarks of Microsoft Corporation.

QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license.

Other trademarks are the property of their respective owners.

Contact Information

| | |
|---|--|
| Sales information and technical support, including warranty and returns | Web: sierrawireless.com/company/contact-us/ Global toll-free number: 1-877-687-7795 6:00 am to 5:00 pm PST |
| Corporate and product information | Web: sierrawireless.com |

Revision History

| Revision Number | Release Date | Changes |
|-----------------|-------------------|-------------------|
| 1.0 | November 04, 2019 | Document creation |

Contents

| | |
|---|-----------|
| Introduction | 5 |
| Accessories | 5 |
| Power | 6 |
| Power Supply | 6 |
| Module Power States | 6 |
| RF Specifications | 7 |
| Conducted Tx Power | 8 |
| Routing Constraints and Recommendations | 9 |
| General Rules and Recommendations | 9 |
| PCB Layout Recommendations | 9 |
| Power Supply | 9 |
| Antenna | 10 |
| PCB Specifications for the Application Board | 10 |
| Recommended PCB Land Pattern | 10 |
| Routing Constraints | 10 |
| Power Supply | 10 |
| UIM Interface | 11 |
| RF Circuit | 11 |
| USB Interface | 12 |
| Thermal Considerations | 12 |
| EMC and ESD Recommendations | 12 |
| Mechanical Integration | 13 |
| Signal Reference Schematics | 14 |
| Regulatory Compliance and Industry Certifications | 16 |
| Important Notice | 16 |
| Safety and Hazards | 16 |
| Important Compliance Information for North American Users | 17 |

>> | 1: Introduction

The AirPrime WP7611 is an industrial-grade LGA 239-pad module that provides voice and data connectivity on LTE and UMTS networks. The module also provides GNSS functionality as a SKU-configuration.

Accessories

A hardware development kit is available for AirPrime WP Series modules. The kit contains hardware components for evaluating and developing with the module, including:

- Development board
- Cables
- Antennas (additional antennas may be required to support all bands)
- Other accessories

>> 2: Power

Power Supply

The host provides power to the AirPrime WP7611 through multiple power and ground pins. The host must provide safe and continuous power at all times; the module does not have an independent power supply, or protection circuits to guard against electrical issues.

For detailed pinout and voltage/current requirements of this module, see the *AirPrime WP76XX Product Technical Specification*.

Module Power States

The module has four basic power states, as described in [Table 2-1](#).

Table 2-1: Supported Power States

| State | Description |
|-------------------------|---|
| Active | <p>Module is fully powered (Linux can be run in the Application Core; modem is on) and operating in one of the following modes:</p> <ul style="list-style-type: none"> Full function (WWAN radio active; GNSS radio can be turned on/off)—Highest power consumption. Idle mode (WWAN radio on; module is registered on network, but no active connection; GNSS radio can be turned on/off) Airplane mode (WWAN radio off; GNSS radio can be active if allowed by PRI) eDRX (Extended Discontinuous Reception)—eDRX mode provides a 'flexible sleep' for the modem, which significantly reduces energy consumption. |
| Sleep | <ul style="list-style-type: none"> Lower power consumption than Active state, but higher than PSM. Application Core is sleeping; modem is in DRX/eDRX. The processor monitors signals (triggers) that can 'wake' the module. Sleep state can be entered based on USB-SS (if USB is connected to the module), UART_DTR, wake_lock(), configured GPIOs, and QMI exchanges from the modem. <p>Note: On Windows systems, due to limitations of the Windows ECM driver, Sleep state is only supported if ECM is disabled or USB is disconnected.</p> |
| PSM (Power Saving Mode) | <p>3GPP Release 12 introduced network support of PSM. PSM allows the module to negotiate, with the network, an extended period during which registration context with the network is retained while the module is unreachable. During the negotiated period, the module enters a very low-power dormant state.</p> <p>After the specified period, the modem and application processors boot up and the modules sends a TAU (Tracking Area Update) to the network.</p> <p>After sending the TAU, the module remains active to allow any pending data to be exchanged with the network. Then, after a negotiated period of inactivity, the module automatically returns to PSM to repeat the cycle.</p> |
| OFF | <p>Module is OFF (no power to the system).</p> <p>Apply power for system to go to:</p> <ul style="list-style-type: none"> Active state (POWER_ON_N is asserted) <p>or</p> <ul style="list-style-type: none"> PSM (POWER_ON_N is de-asserted) |

>> 3: RF Specifications

The AirPrime WP7611 operates on the frequency bands listed below.

Table 3-1: LTE Frequency Band Support

| Band | Frequency (Tx) (MHz) | Frequency (Rx) (MHz) |
|------|----------------------|----------------------|
| B2 | 1850 – 1910 | 1930 – 1990 |
| B4 | 1710 – 1755 | 2110 – 2155 |
| B5 | 824 – 849 | 869 – 894 |
| B12 | 699 – 716 | 729 – 746 |
| B13 | 777 – 787 | 746 – 756 |
| B14 | 788 – 798 | 758 – 768 |
| B25 | 1850 – 1915 | 1930 – 1995 |
| B26 | 814 – 849 | 859 – 894 |
| B66 | 1710 – 1780 | 2110 – 2200 |
| B71 | 663 – 698 | 617 – 652 |

Table 3-2: WCDMA Frequency Band Support^a

| Band | Frequency (Tx) (MHz) | Frequency (Rx) (MHz) |
|------|----------------------|----------------------|
| B2 | 1850 – 1910 | 1930 – 1990 |
| B4 | 1710 – 1755 | 2110 – 2155 |
| B5 | 824 – 849 | 869 – 894 |

a. WCDMA channel spacing is 5 MHz, but this can be adjusted to optimize performance in a particular deployment scenario.

Table 3-3: GNSS Frequency Band Support

| Band | Frequencies (MHz) |
|---------|-------------------|
| GPS | 1575.42 ± 1.023 |
| GLONASS | 1597.52–1605.92 |
| Galileo | 1575.42 ± 2.046 |
| BeiDou | 1561.098 ± 2.046 |

Conducted Tx Power

Table 3-4: Conducted Tx Max Output Power Tolerances — LTE

| RF Band | Operating Condition | Min (dBm) | Typ (dBm) | Max (dBm) | Notes |
|---------|---------------------|-----------|-----------|-----------|---------------|
| B2 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B4 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B5 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B12 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B13 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B14 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B25 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B26 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B66 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |
| B71 | Normal (25°C) | 21 | 23 | 24 | Power class 3 |

Table 3-5: Conducted Tx Max Output Power Tolerances — WCDMA

| RF Band | Min (dBm) | Typ (dBm) | Max (dBm) | Notes |
|---------|-----------|-----------|-----------|-------------------|
| B2 | 21.5 | 23 | 24 | Power class 3 bis |
| B4 | 21.5 | 23 | 24 | Power class 3 bis |
| B5 | 21.5 | 23 | 24 | Power class 3 bis |

>> 4: Routing Constraints and Recommendations

This section describes general routing constraints and recommendations for the AirPrime WP7611.

Note: This is a non-exhaustive list of suggested design guidelines. The developer is responsible for deciding whether to implement these guidelines.

General Rules and Recommendations

Clock and other high-frequency digital signals (e.g. serial buses) should be routed as far as possible from the module's analog signals.

If the application design makes it possible, all analog signals should be separated from digital signals by a ground trace on the PCB.

Tip: Avoid routing any signals under the module on the application board.

PCB Layout Recommendations

Ground pads should be re-flowed on to the host PCB with < 30% voiding to allow effective heat dissipation.

Power Supply

When designing the power supply, make sure that VBAT_BB/VBAT_RF meet the requirements listed in the *AirPrime WP76XX Product Technical Specification*.

Careful attention should be paid to the following:

- Power supply quality—PFM, or PSM systems should be avoided; Low ripple, linear regulation or PWM converters are preferred for low noise.
- Capacity to deliver high current peaks in a short time (for pulsed radio emission)
- VBAT_BB/VBAT_RF must support peak currents with an acceptable voltage drop that guarantees the minimum required VBAT_BB/VBAT_RF value.
- VBAT_BB/VBAT_RF signal pads must never exceed the maximum required VBAT_BB/VBAT_RF value, otherwise the module's power amplifier and GPS chipset may be severely damaged.
- A weakly-designed (not robust) power supply could affect EMC performance, the emission spectrum, and the phase error and frequency error.

Antenna

Sierra Wireless strongly recommends working with an antenna manufacturer either to develop an antenna adapted to the application, or to adapt an existing solution to the application.

For information on routing constraints for the RF circuit, see [RF Circuit on page 11](#).

PCB Specifications for the Application Board

Sensitive signals (such as audio, UIM, and clocks) should be protected by ground planes/fills. Routing sensitive signals close to noisy signals could result in noise being coupled.

Recommended PCB Land Pattern

Refer to *AirPrime WPx5/WP76/WP77 Series Customer Process Guidelines*, available at <http://source.sierrawireless.com>.

Routing Constraints

Power Supply

If the following design recommendations are not followed, phase error (peak) and power loss could occur.

- Since the maximum peak current can reach 2.5 A, Sierra Wireless strongly recommends having a large width for the layout of the power supply signal (to avoid voltage loss between the external power supply and VBAT_BB/VBAT_RF).




Figure 4-1: Power Supply Routing Example

Note: Figure 4-1 shows separate traces for VBAT_BB and VBAT_RF. If VBAT_BB and VBAT_RF share a single power supply, these traces should be connected.

Note: For optimal decoupling, place the capacitors on the underside of the board, directly under the pins.

- Filtering capacitors (100 nF to 1500 μ F) are recommended near the module's power supply.
- Attention should be paid to the ground trace or the ground plane on the application board for the power supply that supplies the module. The ground trace or ground plane, as well as the VBAT trace, must be able to support current peaks.
- If the ground trace between the module and the power supply is a copper plane, make sure it is a solid plane.
- Design routing to make sure total line impedance does not exceed 10 m Ω @ 217 Hz.

Ground Plane Connection

The AirPrime WP7611 requires a solid, central ground plane (with solder mask defined pads) located directly under the module. This will:

- Ensure high current signal returns
- Provide heat dissipation under higher operating temperatures

The ground plane should be connected (with vias) to the reference ground layer of the application board.

UIM Interface

- The length of the tracks between the AirPrime WP7611 and the UIM socket should be as short as possible. Maximum recommended length is 10cm.
- ESD protection is mandatory on the UIM lines unless there is no physical access to the UIM.
- The decoupling capacitor(s) should be placed as close as possible to the UIM card connector for the UIM1_VCC signal.

RF Circuit

The RF signal must be routed on the application board using tracks with a 50 Ω characteristic impedance.

The characteristic impedance depends on the dielectric, the track width and the ground plane spacing.

It is recommended to use stripline design if the RF path is fairly long (more than 3 cm), since microstrip design is not shielded. Consequently, the RF (transmit) signal may interfere with neighboring electronic circuits. In the same way, the neighboring electronics (micro-controllers, etc.) may interfere with the RF (receive) signal and degrade the reception performance.

USB Interface

When the USB interface is externally accessible, ESD protection is required on the USB_VBUS, USB_D+, and USB_D- signals.

Thermal Considerations

When transmitting, the AirPrime WP7611 can generate significant amounts of heat (due to the internal Power Amplifier) that must be dissipated in the host device for safety and performance reasons.

The amount of thermal dissipation required depends on the following factors:

- Supply voltage—Maximum power dissipation for these modules can be up to 3 W at voltage supply limits.
- Usage—Typical power dissipation values depend on the location within the host, amount of data transferred, etc.

To enhance heat dissipation:

- Maximize airflow over / around the module
- Locate the module away from other components that generate heat
- Ensure the module is connected to a solid ground plane

EMC and ESD Recommendations

EMC tests must be performed on the application as soon as possible to detect any potential problems.

When designing, special attention should be paid to:

- Possible spurious emissions radiated by the application to the RF receiver in the receiver band
- ESD protection—Typically, ESD protection is mandatory for externally accessible signals, including:
 - VBAT_RF/VBAT_BB
 - UIM (if accessible from outside)
 - Serial link
 - USB
 - Antennas
- Length of the UIM interface lines (preferably <10 cm)
- Length of the HSIC interface lines (<10 cm, as required by the HSIC specification)
- EMC protection on audio input/output (filters against 900 MHz emissions)
- Ground plane: Sierra Wireless recommends a common ground plane for analog/digital/RF grounds

Note: The AirPrime WP7611 does not include any protection against over-voltage.

The host device must provide adequate ESD protection on digital circuits and antenna ports as detailed in the following table.

Note: The level of protection required depends on your application.

Table 4-1: ESD specifications ^{a,b}

| Category | Connection | Specification |
|-----------------|--|--|
| Operational | RF ports UIM connector USB connector UART connector | IEC-61000-4-2 - Level (Electrostatic Discharge Immunity Test) <ul style="list-style-type: none">• $\pm 6\text{kV}$ Contact• $\pm 8\text{kV}$ Air |
| Non-operational | Host connector interface | Unless otherwise specified: <ul style="list-style-type: none">• JESD22-A114 $\pm 1\text{kV}$ Human Body Model• JESD22-A115 $\pm 100\text{V}$ Machine Model• JESD22-C101C $\pm 500\text{V}$ Charged Device Model |

a. ESD specifications are preliminary, subject to change.

b. ESD protection is highly recommended at the point where the UIM contacts are exposed, and for any other signals that would be subjected to ESD by the user.

Mechanical Integration

Attention should be paid to:

- Antenna cable integration (bending, length, position, etc)
- Pads of the AirPrime WP7611 to be soldered to the ground plane
- Ensuring proper board layout
- Providing sufficient space around the module for heat dissipation

Signal Reference Schematics




Figure 4-2: UIM Interface

USB Interface




Figure 4-3: USB Interface




Figure 4-4: USB OTG Interface

>> 5: Regulatory Compliance and Industry Certifications

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

Safety and Hazards

Do not operate your AirPrime WP7611:

- In areas where blasting is in progress
- Where explosive atmospheres may be present including refueling points, fuel depots, and chemical plants
- Near medical equipment, life support equipment, or any equipment which may be susceptible to any form of radio interference.

In such areas, the AirPrime WP7611 **MUST BE POWERED OFF**. Otherwise, the module can transmit signals that could interfere with this equipment.

In an aircraft, the AirPrime WP7611 **MUST BE POWERED OFF**. Otherwise, the module can transmit signals that could interfere with various onboard systems and may be dangerous to the operation of the aircraft or disrupt the cellular network. Use of a cellular phone in an aircraft is illegal in some jurisdictions. Failure to observe this instruction may lead to suspension or denial of cellular telephone services to the offender, or legal action or both.

Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. The AirPrime WP7611 may be used normally at this time.

Important Compliance Information for North American Users

The AirPrime WP7611 has been granted modular approval for mobile applications. Integrators may use the AirPrime WP7611 in their end products without additional FCC/IC (Industry Canada) certification if they meet the following conditions. Otherwise, additional FCC/IC approvals must be obtained.

1. The end product must use the RF trace design approved with the AirPrime WP7611. The Gerber file of the trace design can be obtained from Sierra Wireless upon request.
2. At least 20 cm separation distance between the antenna and the user's body must be maintained at all times.
3. To comply with FCC/IC regulations limiting both maximum RF output power and human exposure to RF radiation, the maximum antenna gain including cable loss in a mobile-only exposure condition must not exceed the limits stipulated in [Table 5-1 on page 17](#).

Table 5-1: Antenna Gain Specifications

| Technology | Band | Frequency (MHz) | Maximum Antenna Gain (dBi) |
|------------|------|-----------------|----------------------------|
| LTE | 2 | 1850–1910 | 6 |
| | 4 | 1710–1755 | 6 |
| | 5 | 824–849 | 6 |
| | 12 | 699–716 | 6 |
| | 13 | 777–787 | 6 |
| | 14 | 788–798 | 6 |
| | 25 | 1850–1915 | 6 |
| | 26 | 814–849 | 6 |
| | 66 | 1710–1780 | 6 |
| | 71 | 663–698 | 6 |
| UMTS | 2 | 1850–1910 | 6 |
| | 4 | 1710–1755 | 6 |
| | 5 | 824–849 | 6 |

4. The AirPrime WP7611 may transmit simultaneously with other collocated radio transmitters within a host device, provided the following conditions are met:
 - Each collocated radio transmitter has been certified by FCC/IC for mobile application.
 - At least 20 cm separation distance between the antennas of the collocated transmitters and the user's body must be maintained at all times.
 - The radiated power of a collocated transmitter must not exceed the EIRP limit stipulated in [Table 5-2](#).

Table 5-2: Collocated Radio Transmitter Specifications

| Device | Technology | Frequency (MHz) | EIRP Limit (dBm) |
|--------------------------------------|------------|-----------------|------------------|
| Collocated transmitters ^a | WLAN | 2400–2500 | 25 |
| | | 5150–5850 | 27 |
| | WiMAX | 2300–2400 | 25 |
| | | 2500–2700 | 25 |
| | | 3300–3800 | 25 |
| | BT | 2400–2500 | 15 |

a. Valid collocated transmitter combinations: WLAN+BT; WiMAX+BT.
(WLAN+WiMAX+BT is not permitted.)

5. A label must be affixed to the outside of the end product into which the AirPrime WP7611 is incorporated, with a statement similar to the following:
This device contains FCC ID: N7NWP76B/IC:2417C-WP76B.
6. A user manual with the end product must clearly indicate the operating requirements and conditions that must be observed to ensure compliance with current FCC/IC RF exposure guidelines.

The end product with an embedded AirPrime WP7611 may also need to pass the FCC Part 15 unintentional emission testing requirements and be properly authorized per FCC Part 15.

Note: If this module is intended for use in a portable device, you are responsible for separate approval to satisfy the SAR requirements of FCC Part 2.1093 and IC RSS-102.
