PORTABLE LOCATOR DEVICE

USER GUIDE

Overview introduction

FINDER integrates with Apple's Find My network, providing a secure and user-friendly solution for tracking belongings. It effortlessly locates keys, wallets, and more using Apple Find My Network, prioritizing security.

Designed for user convenience, FINDER simplifies daily life. Say goodbye to lost items with FINDER and Apple's Find My network. experiencing a future of enhanced item tracking and peace of mind. Trust FINDER to redefine how you manage essentials effortlessly

Power On

Hold the button (approximately 2s) and release until a single beep heard, indicating the device is powering on.

Power Off

Hold the button until you hear a single beep followed by two consecutive beeps, and then three continuous beeps. Release the button after hearing the continuous three beeps (approximately 6 seconds), indicating the device is powering off.

HOW TO PAIR

Note: iOS or macOS with the latest version

Street Stry







(Figure 1)

(Figure 2)

(Figure 4)

(Figure 3) 1.1 Place the FINDER next to your Apple device like iPhone.

- 1.2 Turn on Bluetooth on iPhone and connect to Internet.
- 1.3 Press the finder side button, hear one beep to power on. 1.4 Open the 'Find My' app as shown in Figure 1
- 1.5 In 'Find My' app, click on Add Item Other Support Items. As shown in Figure 2
- 1.6 Click 'Continue'. As shown in Figure 3
- 1.7 Name your Finder and click 'Continue'. As shown in Figure 4
- 1.8 Select emoticons.

1.9 Click 'Continue', then click 'Finish' to complete.

Battery

FINDER Contains a coin shaped battery. During the product's lifespan, it may be necessary to replace the battery. By observing the correct negative and positive connections, only replace batteries of the same type (CR2032) and rating.

Battery replacement:

- 2.1Twist to open the back cover.
- 2.2Replace a new battery
- 2.3Twist to close the back cover.

ADDITIONAL TIPS

- 3.1 To switch from active mode to Disable mode (Airplane mode). simply remove the battery.
- 3.2 To switch from Disable mode (Airplane mode) to working mode, reinstall the battery. The FINDER will be successfully paired after this.
- 3.3 Press and hold the button until you hear 1 prompt tone, followed by 2 consecutive prompt tones, and then 3 consecutive indicator tones. Continue to press for 5 seconds. When you hear a long indicator tone, release the button to restore the device to its factory settings...
- 3.4 To remove the FINDER from your Apple devices, open the Find My app, select 'items,' find the device, and scroll down to click on 'Remove this device.
- 3.5 If the FINDER fails to connect to the Find My app, follow the instructions in section 3.3 to perform a factory reset, and then restart the pairing process.

Important matters

The FINDER contains delicate electronic parts, including a battery. To avoid damage, loss of function, or potential harm, please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.

AWARNING

- INGESTION HAZARD: This product contains a button cell or coin batter DEATH or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.
- KEEP new and used batteries OUT OF REACH of CHILDREN Seek immedilate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



Choking Hazard Warning

The FINDER, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children

Medical Device Interference

The FINDER contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and the FINDER. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you

defibrillator, or any other medical device, discontinue its use immediately.

Important Handling Guidelines

It's normal for the FINDER to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth. Avoid applying pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device.

suspect that the FINDER is interfering with your pacemaker.

Do not allow moisture to enter any openings or use aerosol sprays. solvents, or abrasive materials to clean the device.

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

便携式防丢器

概述介绍

FINDER与苹果的Find My网络集成,为追踪物品提供了一个安全 且对用户友好的解决方案。使用 Find My 网络轻松定位钥匙、钱 包等,并优先考虑安全性。FINDER专为方便用户而设计,简化了 日常生活。使用FINDER和苹果的Find Mv网络告别丢失物品,体 验增强物品防丢和安心的生活方式。相信FINDER可以重新定义您 轻松管理物品。

短按功能按键(约2秒),听见1声提示音,表示设备开机。

长按住功能按键,将依次听见1声提示音、连续的2声提示音、连续 的3声提示音,此时松开按键(约6秒)。

如何配对

注:iOS或macOS为14.6以上版本。



- 1.1将FINDER放在您的苹果设备(如iPhone)旁边;
- 1.2在您的苹果设备(如iPhone)上打开蓝牙并连接到互联网;
- 1.3轻按一下FINDER按钮, 听到一声蜂鸣声即可接诵电源:
- 1.4打开"查找"应用程序,如图1所示;
- 1.5在"查找"应用程序中,点击添加物品-其他支持物品。如图2所示;
- 1.6点击"继续"。如图3所示:
- 1.7命名您的FINDER, 然后点击"继续"。如图4所示:
- 1.8选择一个表情符号;
- 1.9点击"继续", 然后点击"完成", 即可完成配对。

FINDER包含一个硬币形状的电池。在产品使用寿命期间,可能需 要更换电池。通过观察正确的负极和正极连接,只能更换相同类型 (CR2032) 和额定值的电池。

电池更换:

- 2.1扭转以打开后盖
- 2.2更换新电池:
- 2.3扭转以关闭后盖

其他提示

- 3.1要从工作模式切换到禁用模式(飞行模式),只需卸下电池即可。 3.2要从禁用模式(飞行模式)切换到工作模式,请重新安装电 池。在此之后。FINDER将成功配对。
- 3.3按住按钮,直到听到1个提示音,然后是2个连续提示音,再是 3个连续提示音。继续按5秒钟。当您听到长提示音时,松开按钮设 备将恢复到出厂设置,
- 3.4要从您的苹果设备中删除FINDER, 请打开"查找"应用程序, 选择"物品",查找设备,然后向下滚动点击"移除此设备"。 3.5如果FINDER无法连接到Find Mv应用程序, 请按照第3.3中的 说明, 执行恢复出厂重置, 然后重新启动配对过程。

重要事项

FINDER包含精密的电子部件,包括电池。为避免损坏、功能丧失 或潜在伤害,请避免跌落、撞击、刺穿、压碎、拆卸、暴露在高温 或液体中, 或将其放置在工业化学品浓度高的区域。

A警告

- 摄入危害, 本产品包含一个纽扣电池或硬币电池。 如果摄入,可能会导致死亡或严重伤害。
- 吞下的纽扣由洲或硬币由洲可在2小时内造成内部化学烧伤
- 将新的和用过的电池放在儿童够不到的地方。 如怀疑电池被吞入或插入身体任何部位, 应立即就医



窒息危险警告

FINDER、电池舱门、电池本身和外壳可能会造成窒息危险或对幼 儿造成伤害。请把这些东西放在小孩子够不着的地方。

医疗器械干扰

FINDER包含发射电磁场的组件和无线电。这些元件可能潜在干扰 起搏器或其他医疗设备。为确保安全,请在您的医疗设备和 FINDER之间保持安全距离。我们强烈建议咨询您的医生和医疗设 备制造商,以获取针对您具体情况的信息。如果您怀疑FINDER干 扰了您的起搏器或任何其他医疗设备, 请立即停止使用。

FINDER在经常使用时出现变色是正常的。要清洁它,请使用柔 软、干燥、无绒布。避免用尖锐物体对设备内部的橡胶密封件或蓄 电池端子触点施加压力。

不要让湿气进入任何开口, 也不要使用气雾剂、溶剂或研磨材料清 洁设备。

使用Works with Apple Find My徽章意味着产品已被设计为专门

与徽章中确定的技术配合使用,并已通过产品制造商的认证,以满 足Apple Find My网络产品的规范和要求。苹果不对本产品的操 作、本产品的使用或其是否符合安全和监管标准负责。 Apple, Apple Find My, Apple Watch, iPhone, iPad, iPadOS、Mac、macOS和watchOS是苹果股份有限公司在美国 和其他国家注册的商标。IOS是思科在美国和其他国家/地区的商标 或注册商标, 经许可使用。



用户指南

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.