


About Notifications:

The icons that appear in the Notification bar at the bottom right corner of the screen alert you when new messages arrive or alarms or other application events occur.

View and respond to the notifications by opening the full Notifications panel.

- Touch the **Notification** bar to open the Notifications panel.



To respond to a Notification:

Touch a notification in the list; the Notifications panel will close and the application associated with the notification will launch.

To close the Notifications panel:

- Touch any other area of the screen except the Notifications panel or;
- Touch the **Back** icon.

■ Connecting to the Internet:

This tablet can utilize Wi-Fi data networks to connect to the Internet.

- ∞ Wireless Wi-Fi technology can provide Internet access at distances of over 300 feet; however, this distance can be affected by your surrounding environment and Wi-Fi router.

Requirements:

In order to connect to the Internet, you will need either of the following:

- **A wireless router or access point with a broadband Internet connection**

The wireless router must support Wi-Fi 802.11b/g/n connections. If the router supports 802.11n, make sure that it has been configured to accept 802.11b/g/n connections as well.



A minimum connection speed of 64 Kbps is recommended. Faster speeds will enable a better Internet experience.

You will need to know the name of your network (SSID), as well as the password or other credentials if your network is secured. These settings can usually be found on the administration webpage of your wireless router.


Please refer to your wireless router's documentation for help, or ask your network administrator for details.



You may encounter open Wi-Fi networks, or "hot spots." These networks are usually configured so that you can simply connect to them without needing to know its settings; the tablet will obtain all the information it needs from the router automatically.-

Connect to a Wi-fi network:

The Notification bar displays icons that indicate your tablet's Wi-Fi status.

	Connected to a Wi-Fi network (waves indicate connection strength).
[no icon]	There are no Wi-Fi networks in range, or the Wi-Fi radio is off.

1. Turn on the Wi-fi radio if it is not already on.

To turn on Wi-fi:

- Go to the Home screen:
Touch the **Home** icon.
- Open the Launcher screen:
Touch the **Launcher Tab**, then touch **Settings**.
- Open the Wireless & Networks menu:
Touch **WIRELESS & NETWORKS**.
- Open the Wi-Fi settings menu:
Touch **WiFi**.
- Make sure that the Wi-Fi option box is set to ON.
Touch and slide the block to the right to enable the **Wi-fi** connection.



When Wi-Fi is on, the tablet will look for and display a list of available Wi-Fi networks.



If a network that you have connected to previously is found, the tablet will connect to it.

*If you don't see your network in the list, you can force the tablet to re-scan. To scan for networks, tap the **SCAN** icon located on the top right corner of the screen.*

2. Select an available Wi-fi network to connect to:

In the same Wi-Fi settings menu above, touch a network in the list.

If the network is open, the tablet will prompt you to confirm connection to the network. Touch **Connect** to confirm.

If the network is secured (as indicated by a Lock icon), the tablet will prompt you to enter a password or other credentials. Touch the Wireless password box to show the on-screen keyboard and then use it to enter the password. Touch **Connect** to confirm.



When you have successfully connected to a Wi-Fi network, the Notifications bar at the bottom of the screen will show a Wi-Fi signal indicator.



■ Browsing the Web:

The Browser application lets you visit webpages and find information on the web. Keep up with the news, your friends, or enjoy video from YouTube™, the world's most popular video-sharing community.

To use Browser, the tablet must be connected to the Internet. Read the section “Connecting to the Internet” to learn how to connect to the Internet.


To open Browser, touch the Browser icon on the Home screen or in the Launcher.



Name		Description
1	New Window (+)	Creates a new browser window.
2	Address bar	Displays the address (URL) of the current page. Touch the bar to enter a new address or to search the web.
3	Add bookmark icon	Touch to add bookmarks.
4	Audio input	Touch the icon to input by voice.




Some common Browser actions are described below.

● **To go to a webpage:**

1. Touch the Address bar at the top of the Browser screen. The keyboard will open automatically. (If the address bar is not visible, drag the page down to return to the top of the Browser screen.)	
2. Use the keyboard to enter the address (URL) of the webpage (e.g., www.google™, com).	
3. Touch Enter key to open the webpage.	

● **To bookmark a webpage:**



Bookmark your favorite webpages in order to visit them quickly without entering a URL.

1. Go to the webpage that you want to bookmark	
2. Touch the Add Bookmark icon.	
3. If desired, you can modify the name of the bookmark or its location (URL address). Otherwise, touch Ok to finish adding the bookmark.	

● **To go to a bookmarked webpage:**

1. Touch the Goto Bookmark icon.	
2. Touch a bookmark tile to open it.	

● **To delete a bookmarked webpage:**

1. Touch the Goto Bookmark icon.	
2. Touch and hold a bookmark tile to open the option menu.	

3. Touch "Delete bookmark".	
4. Touch "OK" to confirm.	

Browser menu:

While viewing a webpage, touch the icon shown on the right to open the Browser menu, the icon is located on the top right corner of the screen. The options are:



- Refresh: Refresh the current webpage.
- Forward: Go to the next webpage.
- New tab: Open the webpage in a new window, under a new tab.
- New incognito tab: Open the webpage in a new window, under a new tab and the pages you view in the new window will not appear in your browser history or search history. See the on-screen explanation of going incognito.
- Share page: Use Email to send the webpage URL.
- Find on page: Search for content on the current page.

- Request desktop site:
- Save for offline reading: Save this page onto the internal memory, then you can read it when the internet connection is disabled.
- Page info: View information about the current page, including the URL.
- Settings: Customize the Browser.

■ Optional Connections:

Connecting to a Computer:

Connect the tablet to a computer to transfer files."

1. Connect your tablet to the computer:


With the included USB cable:

- Plug the small end of the cable into the USB 2.0 Hi-speed connector of the tablet.
- Plug the large end of the cable into an available USB 2.0 Hi-speed port on the computer.

When your tablet is connected, a USB icon will appear in the Notification bar.




- Touch the Notification bar to open the notifications panel.



The Tablet's "mass storage mode" is compatible with many operating systems including: Microsoft® Windows® XP, Vista, 7 or higher and Mac OS or Linux.

Using The USB Full-size Adapter:

The USB full-size adapter can be used to connect and use USB devices with the tablet. The adapter converts the Micro USB port on the tablet into a USB On-the-Go (OTG) connector.



Connecting a Keyboard:

For times when you want to type for an extended period of time, you may want to connect a full-size keyboard to the tablet.

Use the included USB full-size (Type A) adapter to connect a keyboard to the tablet.



You may also use this connection to add a mouse to the tablet.

The adapter supports one connection at a time. To use a keyboard and mouse simultaneously, you will need to add an external USB hub.

Connecting a Storage Device:

Use the included USB full-size (Type A) adapter to connect a storage device to the tablet (e.g., a USB flash memory drive).



This connection supports a maximum storage size of 32 GB. For additional storage capacity, a microSD card can be added to the tablet.

2. mount the storage drive.

- ④ Touch **USB connected** to mount the tablet's built-in storage, then touch "Turn on USB storage" and "OK" when prompted to confirm. When mounted, you can copy files to/from your computer.

Your tablet will be recognized by the computer as a Removable Storage drive. Drag and drop files between your tablet and the computer. To learn more about copying files, please refer to the documentation included with your computer or operating system.

Connecting headphones:

Connect a pair of headphones (or earphones) to the tablet to enjoy media in private.

Lower the volume level of the tablet before connecting headphones and then slowly raise the volume to a comfortable listening level.

- ④ The headphones must have a 3.5 mm (1/8 in) plug.
- ④ When headphones are connected, speaker output will be disabled automatically.



Hearing experts advise against the constant use of personal stereos played at high volume. Constant exposure to high volumes can lead to hearing loss. If you should experience ringing in the ears or hearing loss, discontinue use and seek medical advice.

■ Setting the System Options:

Open the system settings menu to adjust how the tablet looks and functions.



Many applications will have their own settings; refer to the documentation provided by the application developer to learn more.

To open the Settings menu:

1. From the Home screen, touch the **Launcher Tab**.
2. Touch **Settings** to open the Settings menu.

The settings are grouped by category. Touch a category to open and adjust its settings on the right.



Please refer to the manual for a description of the items in the Settings menu.



■ Specifications:

Processor	MTK8163
RAM	2GB
Storage	32GB flash built-in microSD card slot (max. 32GB supported)
Display	8"IPS 1280X800, capacitive touchscreen
Networking	Wi-Fi IEEE 802.11 b/g/n
Audio Output	3.5 mm headphone
UC Interface	USB 2.0 hi-speed
Additional Features	Front/Back facing camera Built-in microphone Mono speaker
Operating System	Android 7.0
Power	Rechargeable Li-poly battery power adapter
Playback Time (Hours)*	Up to 12 hours music, 3 hours video, 3 hours web browsing

** Music was tested with a 128 kbps MP3 file; video was tested with a 1920 x 1080 MPEG-4/AVC file; browsing was tested with the screen brightness set to default. Actual playback results may vary.*

FCC& ISDE Statement

This device complies with Part 15 of the FCC Rules and with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Cet appareil est conforme à la partie 15 des règles de la FCC et aux normes RSS exemptées de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes :

(1) cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. Cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du CNR - 102 et conformité avec RSS 102 de l'exposition aux RF, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs RF et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

Specific Absorption Rate (SAR) information:

TABLET PC meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC/ISED RF Exposure Information and Statement the SAR limit of FCC/ISED is 1.6 W/kg averaged over one gram of tissue. Device types: TABLET PC has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of TABLET PC kept 10 mm from the body. To maintain compliance with FCC/ISED RF exposure requirements, use accessories that maintain a 10 mm separation distance between the user's body and the back of TABLET PC. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC/ISED RF exposure requirements, and should be avoided.

Informations sur le débit d'absorption spécifique (DAS) :

Tablette PC répond aux exigences du gouvernement en matière d'exposition aux ondes radio. Les directives sont basées sur des normes élaborées par des organisations scientifiques indépendantes grâce à une évaluation périodique et approfondie d'études scientifiques. Les normes comprennent une marge de sécurité substantielle conçue pour assurer la sécurité de tous. Informations et déclaration FCC/ISED sur l'exposition aux RF la limite SAR de la FCC/ISED est de 1,6 W/kg en moyenne sur un gramme de tissu. Tablette PC a également été testé par rapport à cette limite SAR. Cet appareil a été testé pour des opérations typiques portées sur le corps avec l'arrière du système d'alarme mobile personnel maintenu à 10 mm du corps. Pour maintenir la conformité aux exigences d'exposition RF FCC/ISED, utilisez accessoires L'utilisation d'accessoires qui ne satisfont pas à ces exigences ne peut maintenir une distance de séparation de

10 mm entre le corps de l'utilisateur et Tablette PC. L'utilisation de clips de ceinture, d'étuis et d'accessoires similaires ne doit pas contenir de composants métalliques dans son sont conformes aux exigences d'exposition RF FCC / ISED et doivent être évitées.