

## The paper bin must be clean. Any debris will catch and damage the print head while printing. Use alcohol to clean the paper bin and print head.

- Do not disassemble the printer or attempt any self-repairs. Power off the printer if any malfunctions occur.
- expose the printer to high humidity or temperatures. Keep away from water.
- If any strange scents or smoke comes from the printer, poweroff and unplug immediately.
- Avoid dropping or shaking the printer to prevent damage. Do not open the cover while it is printing.
  Do not touch the print head immediately after printing as it
- will be HOT. • Use a soft clean cloth to clean the outside of the printer.
- results. Use of other label printers may result in poor print quality or damage to the printer.

High temperatures may result in poor print quality

- The longevity of the printed labels depends on the quality of the label paper.
- Choose high quality label paper if you need them to last.
   Keep away from children. • Store in a clean and dry environment.
- Printer does NOT come with an adapter. Use one with a
- rating of 5V 1A.

  This printer can only be used in non-tropical environments. The printer may cause radio interference. Take any necessary precautionary measures.

<1>

The contents of this manual may change without prior notice. The questions or concerns.

components, hardware, software, and technology may be upgraded for better functionality. Contact sales or customer support with any

Machine Parameters

Supported Paper Width

Supported Paper type

203 DPI

60 mm/s MAX

15mm (12mm available)

Manual Paper Cutting

1200 mAh

5V 1A DC

Type-C

50 km

79.5x30x130.6 mm

Gap Paper/ Continuous Paper

5~40°C,90%RH(no condensation)

5~40°C,90%RH(no condensation)

Print Technology

Resolution

Print Speed

Paper Cutting


Work Environment

Life expectancy

Product Size

Storage Environment

Charge




# For Android and Apple users, you can search "Nelko" in Google Play or APP store and install. The second method is scan the QR below code.



1.Slide the cover button to the other side to open the cover. 2.Load the paper roll in the paper bin. Refer to the image for the correct placement.

3.Unroll the paper enough so that it sticks out of the printer slightly.


4.Close the cover. Press the power/ feed button to calibrate the label Notes: Use label paper offered by printer manufacturer for best result



1.Search for and install app on Google Play or App Store.

2.Long press (hold) the power button to turn on the machine.

3. Slide cover button to the other side and open the over, place a roll









< 7 >









< 11 >

- Q: Why are the labels not aligned properly?
- A: Change the paper type on the app. Realign the printer by pressing the Power/ Feed button once.
- Q: Why are the labels not printing clearly?
- A: Check and adjust the printing density. If there is a line or blank area on the label, check if the print heed is clean. If not, clean it with alcohol. Low quality paper may also introduce problems. For best results, use label paper offered by printer manufacturer.

- This device complies with Part 15 of the FCC Rules.
- Operation is subject to the following two conditions: (1) this device may not cause harmful interference.
- including interference that may cause undesired operation This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.
- These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause 17 harmful interference to redio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to
- -Recrient or relo te the receiving antenna. - Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from

correct the interference by one or more of the following measures:

- that to which the receiver is connected

   Consult the dealer or an experienced radio/TV technician for help.

  The device has been evaluated to meet general RF exposure
- The device can be used in portable exposure condition without

< 12 >

- This device complies with Industry Canada licence-exempt
- RSS standard(s). Operation is subject to the following two conditions:
- (1) This device may not cause interference, and
- (2) This device must accept any interfer ence, including interference that may cause undesired operation of the device.

### Le présentappareilestconf orme aux CNR d' Industrie Canada

- applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes:
- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareilldoit accepter tout brouillageradioélectriquesubi, mêrriesi le brouillageest susceptible d'encomprometti el e fonctionnement.

- We offers an extensive warranty for all products that extends through 1 YEAR of the order data. This warranty covers quality related issues
- and product defects.

  If you are past the 30–day return period on Amazon, contact us directly via the "Contact seller" option on your Order Deteils. If the product is not working properly, we can send you a replacement
- product. This warranty does not apply in ceses of abuse, mishandling, or unauthorized repair of the product.

  If you have any question about this warranty or would like additional information, please contact us via the "Contact Seller" option or directly via e-mail (check the packing box). Please keep the original
- box, packing materials and all documentation in the event that service

材质: 128g铜版纸

单张尺寸: 74x124mm (七折页)



正面