

S P E C T R A®

1759MG

System Programming Guide

Software Version 2.0

Default Installer Code

0000 / 000000 (see section [281] on page 18)

Default System Master Code

1234 / 123456 (see section [301] on page 18)

How Do I Enter Programming Mode?

- 1) Press [ENTER].
- 2) Enter your [INSTALLER CODE].
- 3) Enter 3-digit [SECTION] you wish to program.
- 4) Enter required [DATA].

Decimal and Hexadecimal Programming Table

Value or Action	What Do I Press?	What Do I See?		
		10-Zone LED	16-Zone LED	LCD
Values 1 to 9	[1] to [9]	[1] to [9]	[1] to [9]	[1] to [9]
A (hex only)	[0]	[0 (10)]	[10]	0
B (hex only)	[STAY]	[STAY]	[11]	B
C (hex only)	[BYP]	[BYP]	[12]	C
D (hex only)	[MEM]	[MEM]	[13]	D
E (hex only)	[TBL] / [TRBL]	[TBL]	[14]	E
F (hex only)	[PG] / [FNC1]	[PG]	[15]	F
Exit Without Saving	[CLEAR]	[ENTER] flashes	[ARM1] & [STAY1] flash	"SECTION []"
Erase Current Digit	[FORCE]	Displays next digit or next section		
Save Data (hex only)	[ENTER]	Advances to the next section		

Trouble Display

Press the [TBL] or [TRBL] key to view the Trouble Display. Please note that the keypad can be programmed to emit a BEEP every 5 seconds whenever a new trouble condition has occurred. Press the [TBL] or [TRBL] key to stop the beeping.

[1] - No Battery or Low Battery

[2] - Wireless Transmitter Low Battery

[3] - Power Failure

[4] - Bell Output Disconnected

[5] - Maximum Bell Current

[6] - Maximum Auxiliary Current

[7] - Communicator Report Failure

[8] - Timer Loss**

[9] - Tamper or Zone Wiring Failure*

[10] - Telephone Line Monitoring Failure

[11]/[STAY] - Fire Loop Trouble*

[12]/[BYP] - Module Loss

[13]/[MEM] - Wireless Transmitter Supervision Loss*

[16]/[FORCE] and [TBL]/[TRBL] flashes - Keypad Fault

* Press the illuminated key ([9], [STAY] or [MEM]) to view which zones are causing the trouble. Enter the Installer Code to clear Tamper troubles.

** Press [8] to re-program the time.

Table of Contents


Default Installer Code	1
Default System Master Code	1
How Do I Enter Programming Mode?	1
Decimal and Hexadecimal Programming Table	1
Trouble Display	1
Data Display Mode (LED Keypads Only)	5
Configuring the 1686H, 1686V and 1689 Keypads (V2.0 or higher)	5
Zone Programming.....	6
System Timers	8
Programmable Outputs	9
System Options	12
Communication Settings	15
Report Codes	16
System Settings	18
User Code Options.....	18
Reprogram All Modules.....	19
Paradox Memory Key (PMC-3)	19
4-PGM Output Modules V2.0	20
PGM Programming.....	20
Printer Module V2.0	21
PGM Programming.....	22
Clock Programming.....	22
Voice-assisted Arm/Disarm Bus Module V2.0	23
Wireless Features.....	24
Zone Assignment	24
Serial Number Display.....	24
Signal Strength Display	24
Remote Control User Assignment.....	25
Button Options.....	25
Remote Control Assignment	26
Zone Expansion Bus Modules	27
PGM Programming (SPC-ZX8 and APR3-ZX8 Only)	27
User Operation	28
Partitioning	28
Programming Access Codes.....	28
Programming Chime Zones	29
Keypad Muting	29
Keypad Backlight (1686H and 1686V Only).....	29
Quick Function Keys	29
Appendix A - Ademco CID Report Code List (Prog.)	30
Appendix B - Ademco CID Report Code List (All Codes)	31
Bus Module Connections	32
Printer Module (APR3-PRT1).....	32
4-PGM Output Module (APR3-PGM4)	33
4-zone expansion Bus Module (SPC-ZX4 and APR3-ZX4)	33

Voice-assisted Arm/Disarm Bus Module (APR3-ADM2).....	34
8-Zone Expansion Bus Modules (SPC-ZX8 and APR3-ZX8)	35
Hardware Connections.....	36
Single Zone Inputs	36
Connecting Fire Circuits, Keyswitches and PGMs.....	36
Programming a Wireless Fire Zone	36
Alarm Relay and PGM Connections	37
Connecting More Than Two Keypads.....	37
AC Power & Backup Battery Connections	37
Spectra 1759MG PCB Layout.....	38

Data Display Mode (LED Keypads Only)

View the section's programming one digit at a time. Does not function with sections using Feature Select Programming.

To access the Data Display Mode, press the **[ENTER]** key after entering a section and before entering any data. The three LEDs as indicated below will begin to flash indicating that you are in the Data Display Mode.



1686H

1686V

1689

Each time the **[ENTER]** key is pressed, the keypad will display the next digit in the current section and will continue through all the following sections one digit at a time without changing the programmed values. Not available for sections using the Multiple Feature Select Method. Press the **[CLEAR]** key at any time to exit the Data Display Mode.

Configuring the 1686H, 1686V and 1689 Keypads (V2.0 or higher)

The keypad's zone number, EOL definition and anti-tamper switch are programmed through the keypad's programming mode. To do so:

How Do I Configure The Keypad?

- 1) Press **[ENTER]**
- 2) Enter your **[INSTALLER CODE]** (default: 0000 / 000000)
- 3) Press the **[PG]** (1686H/V) / **[FNC1]** (1689) key and hold it for 3 seconds.
- 4) Press the desired key (**[1]** to **[3]**). See below)
- 5) Press **[ENTER]** to exit programming mode



PLEASE NOTE: After two minutes, the keypad exits programming mode.

Key [1] - Keypad Zone Selection

Key **[1]** determines whether the keypad's zone is Keypad Zone 1 or Keypad Zone 2. When key **[1]** is OFF (not illuminated), the keypad's zone is Keypad Zone 1. When key **[1]** is ON (illuminated), the keypad's zone is Keypad Zone 2. Refer to the *Zone Recognition Table* on page 6 for more information.

Key **[1]** OFF - Keypad Zone 1 (default)

Key **[1]** ON - Keypad Zone 2

Key [2] - EOL Definition

Key **[2]** determines the keypad zone's EOL definition. When key **[2]** is OFF (not illuminated), EOL is disabled and the keypad zone uses the on-board EOL resistor. When key **[2]** is ON (illuminated), EOL is enabled and the keypad zone requires that an external EOL resistor be connected (refer to *Spectra 1759MG PCB Layout* on page 38 for more details).

Key **[2]** OFF - EOL disabled

Key **[2]** ON - EOL enabled (default)

Key [3] - On-Board Tamper

Key **[3]** enables or disables the keypad's on-board anti-tamper switch. When key **[3]** is OFF (not illuminated), the anti-tamper switch is disabled. When key **[3]** is ON (illuminated), the anti-tamper switch is enabled.

Key **[3]** OFF - On-board anti-tamper switch disabled

Key **[3]** ON - On-board anti-tamper switch enabled



PLEASE NOTE: The keypad can be ordered with or without an anti-tamper switch. If the keypad has no anti-tamper switch, key **[3]** will be OFF by default. If the keypad has an anti-tamper switch, key **[3]** will be ON by default.

Zone Programming

When programming zones, the zone assignments are dependent on where the detection devices are connected to in the system (see *Zone Recognition Table*). In installations that require using mostly the expansion inputs, refer to *Reassign Keypad Zone 2* (see section [126] option [7] on page 12) and *Reassign zones to expansion inputs* (see section [126] option [8] on page 12).



Do not assign inputs from different modules to the same expansion input.

Zone Recognition Table

	Option [7]: OFF Option [8]: OFF	Option [7]: ON Option [8]: OFF	Option [7]: OFF Option [8]: ON	Option [7]: ON Option [8]: ON
Control Panel				
Input 1 =	Zone 1	Zone 1	Zone 1	Zone 1
Input 2 =	Zone 2	Zone 2	Zone 2	Zone 2
Input 3 =	Zone 3	Zone 3	N/A	N/A
Input 4 =	Zone 4	Zone 4	N/A	N/A
Input 5 =	Zone 5	Zone 5	N/A	N/A
Keypad				
Zone 1 =	Zone 6	Zone 6	Zone 3	Zone 3
Zone 2 =	Zone 7	N/A	Zone 4	N/A
Expansion				
Input 1 =	Zone 8	Zone 7	Zone 5	Zone 4
Input 2 =	Zone 9	Zone 8	Zone 6	Zone 5
Input 3 =	Zone 10	Zone 9	Zone 7	Zone 6
Input 4 =	Zone 11	Zone 10	Zone 8	Zone 7
Input 5 =	Zone 12	Zone 11	Zone 9	Zone 8
Input 6 =	Zone 13	Zone 12	Zone 10	Zone 9
Input 7 =	Zone 14	Zone 13	Zone 11	Zone 10
Input 8 =	Zone 15	Zone 14	Zone 12	Zone 11

 = not displayed on 10-Zone LED Keypads

Option [7] = Reassign Keypad Zone 2

Option [8] = Reassign zones to expansion inputs

How Do I Program the Zones?

- 1) Press the [ENTER] key
- 2) Enter the [INSTALLER CODE] (Default: 0000 / 000000)
- 3) Enter 3-digit [SECTION]
- 4) Enter one digit from the **Zone Definition** table (see page 7)
- 5) Enter one digit from the **Partition Assignment** table (see page 7)
- 6) Select one or more options from the **Zone Options** table (see page 7)
- 7) Press the [ENTER] key

Zone Definition

Empty - Zone Disabled

- 1 - Entry Delay 1
- 2 - Entry Delay 2
- 3 - Follow
- 4 - Instant
- 5 - 24Hr Burglary
- 6 - 24Hr Buzzer

Additional definitions for on-board terminals:

- 7 - Keyswitch
- 8 - Fire 24Hr
- 9 - Delayed Fire 24Hr



[FORCE] key = empty

Partition Assignment

Empty - Zone Disabled

- 1 - Partition 1
- 2 - Partition 2
- 3 - Both Partitions

Zone Options

- 1 - Auto Zone Shutdown
- 2 - Bypass Enabled
- 3 - Stay Zone

4 - 5 - Zone Alarm Type

- off off Audible alarm (steady)
- off on Audible alarm (pulsed)
- on off Silent alarm
- on on Generates a report only

- 6 - Intellizone
- 7 - Delay alarm transmission
- 8 - Force Zone

Keyswitch Options

- 1 - off = Maintained
on = Momentary
- 2 - off = Regular Arm
on = Stay Arm

First Digit

Second Digit

Section	Description	Zone Definition	Partition Assignment	Zone Options
[001] = Zone 01:				1 2 3 4 5 6 7 8
[002] = Zone 02:				1 2 3 4 5 6 7 8
[003] = Zone 03:				1 2 3 4 5 6 7 8
[004] = Zone 04:				1 2 3 4 5 6 7 8
[005] = Zone 05:				1 2 3 4 5 6 7 8
[006] = Zone 06:				1 2 3 4 5 6 7 8
[007] = Zone 07:				1 2 3 4 5 6 7 8
[008] = Zone 08:				1 2 3 4 5 6 7 8
[009] = Zone 09:				1 2 3 4 5 6 7 8
[010] = Zone 10:				1 2 3 4 5 6 7 8
[011] = Zone 11:				1 2 3 4 5 6 7 8
[012] = Zone 12:				1 2 3 4 5 6 7 8
[013] = Zone 13:				1 2 3 4 5 6 7 8
[014] = Zone 14:				1 2 3 4 5 6 7 8
[015] = Zone 15:				1 2 3 4 5 6 7 8
Defaults =		Empty	Partition 1	1 and 2 ON

⚠ Only the control panel's on-board inputs can be defined as a Fire, Delayed Fire or a Keyswitch zone.

The on-board zones are zones 01 to 05. To program a wireless fire zone, refer to Programming a Wireless Fire Zone on page 36.

System Timers

Section #	Decimal Value (000 to 255)	Description	Default
[050]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 1)	600 msec.
[051]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 2)	600 msec.
[052]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 3)	600 msec.
[053]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 4)	600 msec.
[054]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 5)	600 msec.
[055]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 6)	600 msec.
[056]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 7)	600 msec.
[057]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 8)	600 msec.
[058]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 9)	600 msec.
[059]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 10)	600 msec.
[060]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 11)	600 msec.
[061]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 12)	600 msec.
[062]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 13)	600 msec.
[063]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 14)	600 msec.
[064]	___/___/___ x 10 msec.	ZONE SPEED (ZONE 15)	600 msec.
[065]		FUTURE USE	
[066]	___/___/___ seconds (000 = follow Deactivation Event)	PGM1 TIMER	5 sec.
[067]	___/___/___ seconds (000 = follow Deactivation Event)	PGM2 TIMER	5 sec.
[068]	___/___/___ seconds (000 = follow Deactivation Event)	GLOBAL PGM TIMER	5 sec.
[069]	___/___/___ seconds	ENTRY DELAY 1	45 sec.
[070]	___/___/___ seconds	ENTRY DELAY 2	45 sec.
[071]	___/___/___ seconds	EXIT DELAY 1	30 sec.
[072]	___/___/___ seconds	EXIT DELAY 2	30 sec.
[073]	___/___/___ minutes (000 = no bell on alarm)	BELL CUT-OFF TIMER (PARTITION 1)	4 min.
[074]	___/___/___ minutes (000 = no bell on alarm)	BELL CUT-OFF TIMER (PARTITION 2)	4 min.
[075]	___/___/___ x 15 minutes (000 = disabled)	NO MOVEMENT TIMER (PARTITION 1)	Disabled
[076]	___/___/___ x 15 minutes (000 = disabled)	NO MOVEMENT TIMER (PARTITION 2)	Disabled
[077]	___/___/___ seconds (minimum 10 sec.)	ANSWERING MACHINE OVERRIDE DELAY	Disabled
[078]	___/___/___ (000 = no answer, maximum = 15 rings)	NUMBER OF RINGS	8 rings
[079]	___/___/___ x 2 sec. (minimum 32 sec.)	TLM FAIL TIMER	32 sec.
[080]	___/___/___ seconds	DELAY ALARM TRANSMISSION	Disabled
[081]	___/___/___ (000 = 16, maximum = 16)	MAXIMUM DIALING ATTEMPTS	8 attempts
[082]	___/___/___ seconds	DELAY BETWEEN ATTEMPTS	20 sec.
[083]	___/___/___ seconds	PAGER DELAY	5 sec.
[084]	___/___/___ seconds (minimum 10 sec.)	INTELLIZONE DELAY	48 sec.
[085]	___/___/___ seconds	RECENT CLOSING DELAY	No delay
[086]	___/___/___ minutes	POWER FAILURE REPORT DELAY	15 min.
[087]	___/___/___ days (000 = disabled)	AUTO TEST REPORT	Disabled
[088]	___/___/___ 000 to 127 = +1 to +127 seconds 128 to 255 = -1 to -127 seconds	CLOCK ADJUST	Disabled
[089]	___/___/___ (000 = disabled, maximum = 15)	AUTO ZONE SHUTDOWN COUNTER	5
[090]	___/___/___ minutes (000 = disabled)	RECYCLE ALARM DELAY	Disabled
[091]	___/___/___ (000 = disabled)	RECYCLE ALARM COUNTER	Disabled
[092]	___/___/___ attempts before locking (000 = disabled)	KEYPAD LOCKOUT	Disabled
[093]	___/___/___ minutes (000 = disabled)	KEYPAD LOCKOUT DELAY	Disabled
[094]	___/___/___ seconds (000 = disabled)	PANIC LOCKOUT TIMER	Disabled
[095]	___/___/___ days (000 = disabled)	CLOSING DELINQUENCY TIMER (PARTITION 1)	Disabled
[110]	___/___ : ___/___ hours (00 to 23) : minutes (00 to 59)	AUTO TEST REPORT (TIME OF DAY)	Disabled
[111]	___/___ : ___/___ hours (00 to 23) : minutes (00 to 59)	AUTO-ARM TIME (PARTITION 1)	Disabled
[112]	___/___ : ___/___ hours (00 to 23) : minutes (00 to 59)	AUTO-ARM TIME (PARTITION 2)	Disabled

Programmable Outputs

Each PGM Deactivation event can be used as another start (activation) event if their respective PGM timer (see sections [066] to [068]) is programmed with a value other than 000.

Example: section [120] = 05 03 02: this means PGM1 will activate whenever partition 2 is Stay Armed.

Section #		Event Group #	Sub-Group #	Partition #	
[120]	PGM 1 PGM Activation Event	___/___	___/___	___/___	01 = Partition 1 02 = Partition 2 99 = Any Partition The Sub-Groups preceded by “(Partition 1)” cannot be assigned to activate Partition 2.
[121]	PGM 1 PGM Deactivation Event	___/___	___/___	___/___	
[122]	PGM 2 PGM Activation Event	___/___	___/___	___/___	
[123]	PGM 2 PGM Deactivation Event	___/___	___/___	___/___	
[124]	Global PGM Activation Event	___/___	___/___	___/___	
[125]	Global PGM Deactivation Event Used to activate PGMs on expansion modules & LCD keypads.	___/___	___/___	___/___	

Event Group #	Sub-Group #
00 = Zone OK	01 to 15 = Zones 1 to 15 99 = Any Zone
01 = Zone Open	01 to 15 = Zones 1 to 15 99 = Any Zone
02 = Partition Status	00 = System not ready (<i>Partition 1 only</i>) 01 = System ready (<i>Partition 1 only</i>) 02 = Steady Alarm in Partition 03 = Pulsed Alarm in Partition 04 = Pulsed or Steady Alarm in Partition 05 = Alarm in Partition Restored 06 = Bell Squawk Activated (<i>Partition 1 only</i>) 07 = Bell Squawk Deactivated (<i>Partition 1 only</i>) 08 = Ground start (<i>Partition 1 only</i>) 09 = Disarm Partition 10 = Arm Partition 11 = Entry Delay (breach when system is armed) 99 = Any Sub-Group
05 = Non-Reportable Events	00 = Telephone Line Trouble (<i>Partition 1 only</i>) 01 = [PG] or [FNC1] key was pressed (<i>Partition 1 only</i>). This option can also be used to reset smoke detectors. 02 = Instant Arming 03 = Stay Arming 04 = Force Arming 05 = Fast Exit (Force & Regular Only) 06 = PC Fail to Communicate (<i>Partition 1 only</i>) 07 = Midnight (<i>Partition 1 only</i>) 99 = Any Sub-Group (<i>Partition 1 only, except 02 to 05</i>)
06 = Arm/Disarm with Remote Control	01 to 08 = Remote Controls 1 to 8 99 = Any Remote Control
07 = Button Pressed on Remote (see button option “B” on page 25)	01 to 08 = Remote Controls 1 to 8 99 = Any Remote Control
08 = Button Pressed on Remote (see button option “C” on page 25)	01 to 08 = Remote Controls 1 to 8 99 = Any Remote Control

Event Group #	Sub-Group #
09 = Button Pressed on Remote (see button option "D" on page 25)	01 to 08 = Remote Controls 1 to 8 99 = Any Remote Control
10 = Bypass Programming	01 to 48 = User Code Numbers 001 to 048 99 = Any User Code
11 = User Activated PGM	01 to 48 = User Code Numbers 001 to 048 (<i>Partition 1 only</i>) 99 = Any User Code
12 = Zone with Delay Transmission Option Enabled is Breached	01 to 15 = Zones 1 to 15 99 = Any Zone
13 = Arm with User Code	01 to 48 = User Code Numbers 001 to 048 99 = Any User Code
14 = Special Arm	00 = Auto Arming (timed/no movement) 01 = Late to Close (Auto-Arming failed) 02 = No Movement Auto-Arming 03 = Partial Arming (Stay, Force, Instant, Bypass) 04 = One-Touch Arming 05 = Arm with WinLoad Software 07 = Closing Delinquency (<i>Partition 1 only</i>) 99 = Any Sub-Group
15 = Disarm with User Code	01 to 48 = User Code Numbers 001 to 048 99 = Any User Code
16 = Disarm After Alarm w/ User Code	01 to 48 = User Code Numbers 001 to 048 99 = Any User Code
17 = Cancel Alarm with User Code	01 to 48 = User Code Numbers 001 to 048 99 = Any User Code
18 = Special Disarm	00 = Cancel Auto Arm (timed/no movement) 01 = Disarm with WinLoad Software 02 = Disarm after alarm with WinLoad Software 03 = Cancel Alarm with WinLoad Software 99 = Any Sub-Group
19 = Zone Bypassed on Arming	01 to 15 = Zones 1 to 15 99 = Any Zone
20 = Zone in Alarm	01 to 15 = Zones 1 to 15 99 = Any Zone
21 = Fire Alarm	01 to 05 = Zones 1 to 5 (on-board inputs) 99 = Any Zone
22 = Zone Alarm Restore	01 to 15 = Zones 1 to 15 99 = Any Zone
23 = Fire Alarm Restore	01 to 05 = Zones 1 to 5 (on-board inputs) 99 = Any Zone
24 = Special Alarm	00 = Emergency Panic 01 = Auxiliary Panic 02 = Fire Panic 03 = Recent Closing 04 = Auto Zone Shutdown 05 = Duress Alarm 06 = Keypad Lockout 99 = Any Sub-Group
25 = Auto Zone Shutdown	01 to 15 = Zones 1 to 15 99 = Any Zone
26 = Zone Tamper	01 to 15 = Zones 1 to 15 99 = Any Zone
27 = Zone Tamper Restore	01 to 15 = Zones 1 to 15 99 = Any Zone

Event Group #	Sub-Group #
28 = System Trouble	01 = AC Loss: only after Power Failure Delay has elapsed (<i>Partition 1 only</i>) 02 = Battery Failure (<i>Partition 1 only</i>) 03 = Auxiliary current overload (<i>Partition 1 only</i>) 04 = Bell current overload (<i>Partition 1 only</i>) 05 = Bell disconnected (<i>Partition 1 only</i>) 06 = Timer Loss (<i>Partition 1 only</i>) 07 = Fire Loop Trouble (<i>Partition 1 only</i>) 08 = Future Use 09 = Module Fault (<i>Partition 1 only</i>) 10 = Printer Fault (<i>Partition 1 only</i>) 11 = Fail to Communicate (<i>Partition 1 only</i>) 99 = Any Sub-Group (<i>Partition 1 only</i>)
29 = System Trouble Restore	00 = TLM restore (<i>Partition 1 only</i>) 01 = AC Loss restore (<i>Partition 1 only</i>) 02 = Battery Failure restore (<i>Partition 1 only</i>) 03 = Auxiliary current overload restore (<i>Partition 1 only</i>) 04 = Bell current overload restore (<i>Partition 1 only</i>) 05 = Bell disconnected restore (<i>Partition 1 only</i>) 06 = Timer Programmed (<i>Partition 1 only</i>) 07 = Fire Loop Trouble restore (<i>Partition 1 only</i>) 08 = Future Use 09 = Module Fault restore (<i>Partition 1 only</i>) 10 = Printer Fault restore (<i>Partition 1 only</i>) 11 = Fail to Communicate restore (<i>Partition 1 only</i>) 99 = Any Trouble Restore (<i>Partition 1 only</i>)
30 = Special Reporting	00 = System Power Up (<i>Partition 1 only</i>) 01 = Test Report (<i>Partition 1 only</i>) 02 = WinLoad Software Access (<i>Partition 1 only</i>) 03 = WinLoad Software Access finished (<i>Partition 1 only</i>) 04 = Installer enters programming mode (<i>Partition 1 only</i>) 05 = Installer exits programming mode (<i>Partition 1 only</i>) 99 = Any Sub-Group (<i>Partition 1 only</i>)
31 = Wireless Transmitter Supervision Loss	01 to 15 = Zones 1 to 15 99 = Any Zone
32 = Wireless Transmitter Supervision Loss Restore	01 to 15 = Zones 1 to 15 99 = Any Zone
33 = Arming with a Keyswitch	01 to 05 = Zones 1 to 5 (on-board inputs) 99 = Any Zone
34 = Disarming with a Keyswitch	01 to 05 = Zones 1 to 5 (on-board inputs) 99 = Any Zone
35 = Disarm after Alarm with a Keyswitch	01 to 05 = Zones 1 to 5 (on-board inputs) 99 = Any Zone
36 = Cancel Alarm with a Keyswitch	01 to 05 = Zones 1 to 5 (on-board inputs) 99 = Any Zone
37 = Wireless Transmitter Low Battery	01 to 15 = Zones 1 to 15 99 = Any Zone
38 = Wireless Transmitter Low Battery Restore	01 to 15 = Zones 1 to 15 99 = Any Zone

Event Group #	Sub-Group #	Partition #
80 = PGM follows Clock (APR3-PGM4 only)	HH = hour according to 24hr. clock	MM = minutes according to 24hr. clock

System Options

Bold = Default Setting

Section [126]: General Options

Option	OFF	ON
[1] <i>Confidential Mode</i>	☐ Disabled	☐ Enabled
[2] <i>To exit Confidential Mode</i>	☐ Enter Access Code	☐ Press a Key
[3] <i>Confidential Mode timer</i>	☐ 2 minutes	☐ 5 seconds
[4] <i>PGM1 normal state</i>	☐ Normally Open (N.O.)	☐ Normally Closed (N.C.)
[5] <i>PGM2 normal state</i>	☐ Normally Open (N.O.)	☐ Normally Closed (N.C.)
[6] <i>Global PGM normal state</i>	☐ Normally Open (N.O.)	☐ Normally Closed (N.C.)
[7] <i>Reassign Keypad Zone 2*</i>	☐ Disabled	☐ Enabled
[8] <i>Reassign zones to expansion inputs*</i>	☐ Disabled	☐ Enabled

* *Reassign Keypad Zone 2* and *Reassign zones to expansion inputs* change the zone numbering to increase the number of expansion inputs that can be displayed on 10-Zone LED Keypads. Refer to the *Zone Recognition Table* on page 6 and the *Spectra 1759MG Reference & Installation Manual* for details.

Section [127]: General Options

Option	OFF	ON
[1] <i>Partitioning</i>	☐ Disabled	☐ Enabled
[2] <i>Access code length</i>	☐ 6-digits	☐ 4-digits
[3] <i>Keypad audible trouble warning</i>	☐ Disabled	☐ Enabled
[4] <i>Lock System Master Code</i>	☐ Disabled	☐ Enabled
[5] <i>Battery charge current</i>	☐ 350mA	☐ 700mA
[6] <i>User Code 048 is a Duress Code</i>	☐ Disabled	☐ Enabled
[7] <i>Alarm relay follows</i>	☐ Bell Output	☐ Global PGM
[8] <i>Future use</i>	☐ N/A	☐ N/A

Section [128]: General Options

Option	OFF	ON
[1] <i>Panic 1: keys [1] & [3]</i>	☐ Disabled	☐ Enabled
[2] <i>Panic 2: keys [4] & [6]</i>	☐ Disabled	☐ Enabled
[3] <i>Panic 3: keys [7] & [9]</i>	☐ Disabled	☐ Enabled
[4] <i>Panic 1: silent or audible</i>	☐ Silent	☐ Audible
[5] <i>Panic 2: silent or audible</i>	☐ Silent	☐ Audible
[6] <i>Panic 3: silent or fire</i>	☐ Silent	☐ Fire
[7] <i>Keypad 1 tamper supervision</i>	☐ Disabled	☐ Enabled
[8] <i>Keypad 2 tamper supervision</i>	☐ Disabled	☐ Enabled

Section [129]: General Options

Option	OFF	ON
[1] <i>PGM2 output activation option</i>	☐ Steady	☐ Pulse (flash)
[2] <i>PGM2 pulse once every 30 sec. if system armed</i>	☐ Disabled	☐ Enabled
[3] <i>PGM2 pulse on Arm, twice on Disarm</i>	☐ Disabled	☐ Enabled
[4] <i>ZX4 & ZX8 zone expansion module supervision</i>	☐ Disabled	☐ Enabled
[5] <i>Future use</i>	☐ N/A	☐ N/A
[6] <i>Wireless module low battery supervision</i>	☐ Disabled	☐ Enabled
[7] <i>4-PGM Output Module supervision (APR3-PGM4)</i>	☐ Disabled	☐ Enabled
[8] <i>Printer Module supervision (APR3-PRT1)</i>	☐ Disabled	☐ Enabled

Bold = Default Setting

Section [130]: Arming/Disarming Options

Option		OFF	ON
[1]	One-touch Regular Arming	☐ Disabled	☐ Enabled
[2]	One-touch Stay Arming	☐ Disabled	☐ Enabled
[3]	One-touch Force Arming	☐ Disabled	☐ Enabled
[4]	One-touch bypass programming	☐ Disabled	☐ Enabled
[5]	Restrict arming on battery failure	☐ Disabled	☐ Enabled
[6]	Restrict arming on Tamper failure	☐ Disabled	☐ Enabled
[7]	Bell Squawk on Arm/Disarm with keypad	☐ Disabled	☐ Enabled
[8]	Beep on exit delay	☐ Disabled	☐ Enabled

Section [131]: Arming/Disarming Options

Option		OFF	ON
[1]	Report Disarming	☐ Always	☐ Only after alarm
[2]	Regular Arming switches to Force Arming *	☐ Disabled	☐ Enabled
[3]	Bell Squawk on Arm/Disarm with remote control (must be enabled for UL installations)	☐ Disabled	☐ Enabled
[4]	No exit delay when Arming with a remote control	☐ Disabled	☐ Enabled
[5]	No exit delay beeps and no Bell Squawk when Stay Arming	☐ Disabled	☐ Enabled
[6]	Restrict arming on wireless transmitter supervision loss	☐ Disabled	☐ Enabled
[7]	Generate supervision loss if detected on bypassed wireless zone	☐ Yes	☐ No
[8]	Future Use	☐ N/A	☐ N/A

* This option cannot be done using a keyswitch. Force arming is not supported by keyswitches.

Section [132]: Zone Options

Option

[1]&[2]

Tamper Recognition Options		
[1]	[2]	
OFF	OFF	Disabled (default)
OFF	ON	When disarmed: GENERATES TROUBLE ONLY When armed: Follows <i>Zone Alarm Types</i>
ON	OFF	When disarmed: GENERATES SILENT ALARM When armed: Follows <i>Zone Alarm Types</i>
ON	ON	When disarmed: GENERATES AUDIBLE ALARM When armed: Follows <i>Zone Alarm Types</i>

[3]

Generate tamper if detected on bypassed zone

[4]

EOL (end-of-line) resistors

[5]

Future use

[6]

Report zone restore

[7]&[8]

Wireless Transmitter Supervision Options		
[7]	[8]	
OFF	OFF	Disabled (default)
OFF	ON	When disarmed: GENERATES TROUBLE ONLY When armed: Follows <i>Zone Alarm Types</i>
ON	OFF	When disarmed: GENERATES SILENT ALARM When armed: Follows <i>Zone Alarm Types</i>
ON	ON	When disarmed: GENERATES AUDIBLE ALARM When armed: Follows <i>Zone Alarm Types</i>

OFF

☐ see table

☐ see table

ON

☐ see table

☐ see table

☐ Yes

☐ No

☐ No EOL

☐ Use EOL Resistors

☐ N/A

☐ N/A

☐ On Bell Cut-off

☐ On Zone Closure

☐ see table

☐ see table

☐ see table

☐ see table

Bold = Default Setting

Section [133]: Partition 1 Options

Option	OFF	ON
[1] <i>Auto-arm on time</i>	☐ Disabled	☐ Enabled
[2] <i>Auto-arm on no movement</i>	☐ Disabled	☐ Enabled
[3] <i>Auto Arming = Regular or Stay</i>	☐ Regular Arming	☐ Stay Arming
[4] <i>Switch to Stay Arming if no entry delay is opened</i>	☐ Disabled	☐ Enabled
[5] <i>Stay Arming with Delay Partition 1 (Delay = [070])</i>	☐ Disabled	☐ Enabled
[6] to [8] <i>Future use</i>	☐ N/A	☐ N/A

Section [134]: Partition 2 Options

Option	OFF	ON
[1] <i>Auto-arm on time</i>	☐ Disabled	☐ Enabled
[2] <i>Auto-arm on no movement</i>	☐ Disabled	☐ Enabled
[3] <i>Auto Arming = Regular or Stay</i>	☐ Regular Arming	☐ Stay Arming
[4] <i>Switch to Stay Arming if no entry delay is opened</i>	☐ Disabled	☐ Enabled
[5] <i>Stay Arming with Delay Partition 2 (Delay = [070])</i>	☐ Disabled	☐ Enabled
[6] to [8] <i>Future use</i>	☐ N/A	☐ N/A

Section [135]: Dialer Options

Option	OFF	ON																		
[1] & [2]	☐ see table ☐ see table	☐ see table ☐ see table																		
<table border="1"><thead><tr><th colspan="3">Telephone Line Monitoring (TLM) Options</th></tr><tr><th>[1]</th><th>[2]</th><th></th></tr></thead><tbody><tr><td>OFF</td><td>OFF</td><td>TLM Disabled (default)</td></tr><tr><td>OFF</td><td>ON</td><td>TLM generates a trouble if armed</td></tr><tr><td>ON</td><td>OFF</td><td>TLM generates an audible alarm if armed</td></tr><tr><td>ON</td><td>ON</td><td>Silent alarms become audible</td></tr></tbody></table>			Telephone Line Monitoring (TLM) Options			[1]	[2]		OFF	OFF	TLM Disabled (default)	OFF	ON	TLM generates a trouble if armed	ON	OFF	TLM generates an audible alarm if armed	ON	ON	Silent alarms become audible
Telephone Line Monitoring (TLM) Options																				
[1]	[2]																			
OFF	OFF	TLM Disabled (default)																		
OFF	ON	TLM generates a trouble if armed																		
ON	OFF	TLM generates an audible alarm if armed																		
ON	ON	Silent alarms become audible																		
[3] <i>Reporting (Dialer)</i>	☐ Disabled	☐ Enabled																		
[4] <i>Dialing method</i>	☐ Pulse Dialing	☐ Tone (DTMF) Dialing																		
[5] <i>Pulse ratio</i>	☐ 1:2	☐ 1:1.5																		
[6] <i>If armed, activate bell output on Com. Failure</i>	☐ Disabled	☐ Enabled																		
[7] & [8] <i>Future use</i>	☐ N/A	☐ N/A																		

Section [136]: Dialer Options

Option	OFF	ON																		
[1] <i>Call back WinLoad</i>	☐ Disabled	☐ Enabled																		
[2] <i>Automatic event buffer transmission</i>	☐ Disabled	☐ Enabled																		
[3] <i>Contact I.D. report codes</i>	☐ Programmable	☐ All Codes (automatic)																		
[4] <i>Alternate dial</i>	☐ Disabled	☐ Enabled																		
[5] <i>If no dial tone is present</i>	☐ Continue after 4 sec.	☐ Hang-up after 16 sec.																		
[6] & [7]	☐ see table ☐ see table	☐ see table ☐ see table																		
<table border="1"><thead><tr><th colspan="3">Pager Reporting Format Dialer Options</th></tr><tr><th>[6]</th><th>[7]</th><th></th></tr></thead><tbody><tr><td>OFF</td><td>OFF</td><td>1 call to pager or cellular telephone (default)</td></tr><tr><td>OFF</td><td>ON</td><td>2 calls to pager or cellular telephone</td></tr><tr><td>ON</td><td>OFF</td><td>3 calls to pager or cellular telephone</td></tr><tr><td>ON</td><td>ON</td><td>4 calls to pager or cellular telephone</td></tr></tbody></table>			Pager Reporting Format Dialer Options			[6]	[7]		OFF	OFF	1 call to pager or cellular telephone (default)	OFF	ON	2 calls to pager or cellular telephone	ON	OFF	3 calls to pager or cellular telephone	ON	ON	4 calls to pager or cellular telephone
Pager Reporting Format Dialer Options																				
[6]	[7]																			
OFF	OFF	1 call to pager or cellular telephone (default)																		
OFF	ON	2 calls to pager or cellular telephone																		
ON	OFF	3 calls to pager or cellular telephone																		
ON	ON	4 calls to pager or cellular telephone																		
[8] <i>Pager Format Transmission Options</i>	☐ Transmit report code after Pager delay	☐ Transmit report code immediately																		

Section [137]: Event Call Direction

Section [138]: Event Call Direction

Communication Settings

[140] ____ / ____
 TEL1 TEL2

REPORTING FORMATS

- 1** = ADEMCO SLOW (1400HZ, 1900HZ, 10BPS)
- 2** = SILENT KNIGHT FAST (1400HZ, 1900HZ, 20BPS)
- 3** = SESCOA (2300HZ, 1800HZ, 20BPS)
- 4** = ADEMCO EXPRESS (DTMF 4+2)
- 5** = **ADEMCO CONTACT ID (DEFAULT)** see option **[3]** in section **[136]** on page 14
- 6** = PAGER FORMAT

[141]	___/___/___/___	PANEL IDENTIFIER (WINLOAD SOFTWARE)
[142]	___/___/___/___	PC PASSWORD (WINLOAD SOFTWARE)
[143]	___/___/___/___	PARTITION ACCOUNT NUMBER 1 (For less than 4 digits, use the [FORCE] key to enter blanks.)
[144]	___/___/___/___	PARTITION ACCOUNT NUMBER 2 (For less than 4 digits, use the [FORCE] key to enter blanks.)

[illegible]

Special Keys for Telephone Numbers		
[STAY] = *	[MEM] = Switch from pulse to tone dialing or vice versa	[FORCE] = Delete current digit
[BYP] = #	[TBL] or [TRBL] = 4-second pause	[PG] or [FNC1] = Inserts Blank Space

Report Codes

Ademco Slow, Silent Knight, SESCOA, Ademco Express and Pager Formats: Enter the desired 1- or 2-digit hex-value (0-F or 00-FF). **Ademco “Programmable” Format:** Enter the desired 2-digit hex values from the “Ademco Report Code List - Programmable” (see *Appendix A* on page 30). Also Note that entering FF will set the report code to the default Ademco Report Code. **Ademco “All Codes” Format:** The control panel automatically generates report codes from the “Ademco Report Code List - All Codes” (see *Appendix B* on page 31).

Arming Report Codes

[160] ___ / ___ Access Code 01
___ / ___ Access Code 02
___ / ___ Access Code 03
___ / ___ Access Code 04

[161] ___ / ___ Access Code 05
___ / ___ Access Code 06
___ / ___ Access Code 07
___ / ___ Access Code 08

[162] ___ / ___ Access Code 09
___ / ___ Access Code 10
___ / ___ Access Code 11
___ / ___ Access Code 12

[163] ___ / ___ Access Code 13
___ / ___ Access Code 14
___ / ___ Access Code 15
___ / ___ Access Code 16

[164] ___ / ___ Access Code 17
___ / ___ Access Code 18
___ / ___ Access Code 19
___ / ___ Access Code 20

[165] ___ / ___ Access Code 21
___ / ___ Access Code 22
___ / ___ Access Code 23
___ / ___ Access Code 24

[166] ___ / ___ Access Code 25
___ / ___ Access Code 26
___ / ___ Access Code 27
___ / ___ Access Code 28

[167] ___ / ___ Access Code 29
___ / ___ Access Code 30
___ / ___ Access Code 31
___ / ___ Access Code 32

[168] ___ / ___ Access Code 33
___ / ___ Access Code 34
___ / ___ Access Code 35
___ / ___ Access Code 36

[169] ___ / ___ Access Code 37
___ / ___ Access Code 38
___ / ___ Access Code 39
___ / ___ Access Code 40

[170] ___ / ___ Access Code 41
___ / ___ Access Code 42
___ / ___ Access Code 43
___ / ___ Access Code 44

[171] ___ / ___ Access Code 45
___ / ___ Access Code 46
___ / ___ Access Code 47
___ / ___ Access Code 48

Special Arming Codes

[172] ___ / ___ Auto-Arming
___ / ___ Late to Close
___ / ___ No Movement
___ / ___ Partial Arming

[173] ___ / ___ Quick Arming
___ / ___ Arming via PC
___ / ___ Keyswitch Arming
___ / ___ Closing Delinquency

Disarming Report Codes

[174] ___ / ___ Access Code 01
___ / ___ Access Code 02
___ / ___ Access Code 03
___ / ___ Access Code 04

[175] ___ / ___ Access Code 05
___ / ___ Access Code 06
___ / ___ Access Code 07
___ / ___ Access Code 08

[176] ___ / ___ Access Code 09
___ / ___ Access Code 10
___ / ___ Access Code 11
___ / ___ Access Code 12

[177] ___ / ___ Access Code 13
___ / ___ Access Code 14
___ / ___ Access Code 15
___ / ___ Access Code 16

[178] ___ / ___ Access Code 17
___ / ___ Access Code 18
___ / ___ Access Code 19
___ / ___ Access Code 20

[179] ___ / ___ Access Code 21
___ / ___ Access Code 22
___ / ___ Access Code 23
___ / ___ Access Code 24

[180] ___ / ___ Access Code 25
___ / ___ Access Code 26
___ / ___ Access Code 27
___ / ___ Access Code 28

[181] ___ / ___ Access Code 29
___ / ___ Access Code 30
___ / ___ Access Code 31
___ / ___ Access Code 32

[182] ___ / ___ Access Code 33
___ / ___ Access Code 34
___ / ___ Access Code 35
___ / ___ Access Code 36

[183] ___ / ___ Access Code 37
___ / ___ Access Code 38
___ / ___ Access Code 39
___ / ___ Access Code 40

[184] ___ / ___ Access Code 41
___ / ___ Access Code 42
___ / ___ Access Code 43
___ / ___ Access Code 44

[185] ___ / ___ Access Code 45
___ / ___ Access Code 46
___ / ___ Access Code 47
___ / ___ Access Code 48

Special Disarming Codes

[186] ___ / ___ Cancel Auto-Arm
___ / ___ Disarming via PC
___ / ___ Keyswitch Disarm
___ / ___ N/A

Alarm Report Codes

Alarm	Restore	Special
[187] ___/___ Zone 01 ___/___ Zone 02 ___/___ Zone 03 ___/___ Zone 04	[191] ___/___ Zone 01 ___/___ Zone 02 ___/___ Zone 03 ___/___ Zone 04	[195] ___/___ Emergency Panic ___/___ Auxiliary Panic ___/___ Fire Panic ___/___ Recent Closing
[188] ___/___ Zone 05 ___/___ Zone 06 ___/___ Zone 07 ___/___ Zone 08	[192] ___/___ Zone 05 ___/___ Zone 06 ___/___ Zone 07 ___/___ Zone 08	[196] ___/___ Zone Shutdown ___/___ Duress ___/___ Keypad Lockout ___/___ N/A
[189] ___/___ Zone 09 ___/___ Zone 10 ___/___ Zone 11 ___/___ Zone 12	[193] ___/___ Zone 09 ___/___ Zone 10 ___/___ Zone 11 ___/___ Zone 12	
[190] ___/___ Zone 13 ___/___ Zone 14 ___/___ Zone 15 ___/___ N/A	[194] ___/___ Zone 13 ___/___ Zone 14 ___/___ Zone 15 ___/___ N/A	

Tamper Report Codes

Trouble		
[197] ___/___ Zone 01 ___/___ Zone 02 ___/___ Zone 03 ___/___ Zone 04	[200] ___/___ Zone 13 ___/___ Zone 14 ___/___ Zone 15 ___/___ N/A	[203] ___/___ Zone 09 ___/___ Zone 10 ___/___ Zone 11 ___/___ Zone 12
[198] ___/___ Zone 05 ___/___ Zone 06 ___/___ Zone 07 ___/___ Zone 08	Restore [201] ___/___ Zone 01 ___/___ Zone 02 ___/___ Zone 03 ___/___ Zone 04	[204] ___/___ Zone 13 ___/___ Zone 14 ___/___ Zone 15 ___/___ N/A
[199] ___/___ Zone 09 ___/___ Zone 10 ___/___ Zone 11 ___/___ Zone 12	[202] ___/___ Zone 05 ___/___ Zone 06 ___/___ Zone 07 ___/___ Zone 08	

System Trouble Report Codes

System Trouble	Restore	Special
[205] ___/___ N/A ___/___ AC Failure ___/___ Battery Failure ___/___ Auxiliary Supply	[208] ___/___ TLM ___/___ AC Failure ___/___ Battery Failure ___/___ Auxiliary Supply	[211] ___/___ Cold Start (Shutdown) ___/___ Test Report ___/___ N/A ___/___ PC Exit
[206] ___/___ Bell Output Overload ___/___ Bell Output Disconnect ___/___ Timer Loss ___/___ Fire Loop Trouble	[209] ___/___ Bell Output Overload ___/___ Bell Output Disconnect ___/___ Timer Loss ___/___ Fire Loop Trouble	[212] ___/___ Installer In ___/___ Installer Out ___/___ N/A ___/___ N/A
[207] ___/___ Wireless Low Battery ___/___ Module Fault ___/___ Printer Fault ___/___ Fail to Communicate	[210] ___/___ Wireless Low Battery ___/___ Module Fault ___/___ Printer Fault ___/___ Fail to Communicate	[213] ___/___ TX Supervision Loss ___/___ TX Supervision Restore ___/___ N/A ___/___ N/A

System Settings

Section #	Description
[280] __/__/__:__/_	SYSTEM REAL TIME CLOCK (HH:MM)
[281] __/__/__/__/__/__	INSTALLER CODE, DEFAULT: 0000 / 000000
[282] __/__/__	INSTALLER CODE LOCK, DEFAULT: 000 (147 TO LOCK, 000 TO UNLOCK)
[301] __/__/__/__/__/__	SYSTEM MASTER CODE, DEFAULT: 1234 / 123456

User Code Options

System Master Code arms or disarm partitions using any arming method and can create, modify or delete any User Access Code. Only the System Master Code can modify or delete User Access Codes assigned to both partitions.

Master Code 1 is permanently assigned to partition 1 and can be used to create, modify or delete User Access Codes that are assigned to partition 1.

Master Code 2 is permanently assigned to partition 2 (except when partitioning is disabled, Master Code 2 will be assigned to partition 1) and can be used to create, modify or delete User Access Codes that are assigned to the same partition.

Default for all user codes is options [1], [3] and [4] ON.
ON = Option Enabled
OFF = Option Disabled

[1] ON = Partition 1 Access	[5] ON = Force Arming
[2] ON = Partition 2 Access	[6] ON = Arm Only
[3] ON = Bypass Programming	[7] ON = PGM Activation Only
[4] ON = Stay Arming	[8] ON = Future Use

Section #	User Code Options (ON/OFF)	Section	User Code Options (ON/OFF)
[302] Master Code 1	1 2 3 4 5 6 7 8	[325] User Code 025	1 2 3 4 5 6 7 8
[303] Master Code 2	1 2 3 4 5 6 7 8	[326] User Code 026	1 2 3 4 5 6 7 8
[304] User Code 004	1 2 3 4 5 6 7 8	[327] User Code 027	1 2 3 4 5 6 7 8
[305] User Code 005	1 2 3 4 5 6 7 8	[328] User Code 028	1 2 3 4 5 6 7 8
[306] User Code 006	1 2 3 4 5 6 7 8	[329] User Code 029	1 2 3 4 5 6 7 8
[307] User Code 007	1 2 3 4 5 6 7 8	[330] User Code 030	1 2 3 4 5 6 7 8
[308] User Code 008	1 2 3 4 5 6 7 8	[331] User Code 031	1 2 3 4 5 6 7 8
[309] User Code 009	1 2 3 4 5 6 7 8	[332] User Code 032	1 2 3 4 5 6 7 8
[310] User Code 010	1 2 3 4 5 6 7 8	[333] User Code 033	1 2 3 4 5 6 7 8
[311] User Code 011	1 2 3 4 5 6 7 8	[334] User Code 034	1 2 3 4 5 6 7 8
[312] User Code 012	1 2 3 4 5 6 7 8	[335] User Code 035	1 2 3 4 5 6 7 8
[313] User Code 013	1 2 3 4 5 6 7 8	[336] User Code 036	1 2 3 4 5 6 7 8
[314] User Code 014	1 2 3 4 5 6 7 8	[337] User Code 037	1 2 3 4 5 6 7 8
[315] User Code 015	1 2 3 4 5 6 7 8	[338] User Code 038	1 2 3 4 5 6 7 8
[316] User Code 016	1 2 3 4 5 6 7 8	[339] User Code 039	1 2 3 4 5 6 7 8
[317] User Code 017	1 2 3 4 5 6 7 8	[340] User Code 040	1 2 3 4 5 6 7 8
[318] User Code 018	1 2 3 4 5 6 7 8	[341] User Code 041	1 2 3 4 5 6 7 8
[319] User Code 019	1 2 3 4 5 6 7 8	[342] User Code 042	1 2 3 4 5 6 7 8
[320] User Code 020	1 2 3 4 5 6 7 8	[343] User Code 043	1 2 3 4 5 6 7 8
[321] User Code 021	1 2 3 4 5 6 7 8	[344] User Code 044	1 2 3 4 5 6 7 8
[322] User Code 022	1 2 3 4 5 6 7 8	[345] User Code 045	1 2 3 4 5 6 7 8
[323] User Code 023	1 2 3 4 5 6 7 8	[346] User Code 046	1 2 3 4 5 6 7 8
[324] User Code 024	1 2 3 4 5 6 7 8	[347] User Code 047	1 2 3 4 5 6 7 8
		[348] User Code 048	1 2 3 4 5 6 7 8

Reprogram All Modules

- [750] After removing an expansion module from the communication bus, the control panel keeps the module's programmed sections in memory. Therefore, if you add or replace a module you can re-program the module with the settings saved in the control panel. To do so, enter section [750] and press [ENTER]. The keypads will beep twice every second until the procedure is completed.


Paradox Memory Key (PMC-3)

[900] DOWNLOAD FROM PARADOX MEMORY KEY TO DESTINATION CONTROL PANEL.

[902] COPY TO MEMORY KEY FROM SOURCE CONTROL PANEL.



Download to DESTINATION Control Panel

- 1) Remove AC and battery power from the control panel.
- 2) Insert the Memory Key onto the serial connector labelled KEY on the Spectra control panel to which you wish to download the contents of the memory key to.
- 3) Re-apply AC and battery power.
- 4) Enter installer programming mode, enter section [900], then press [ENTER] to acknowledge.
- 5) When the keypad emits a "confirmation beep", remove the Memory Key.
- 6) Enter section [750] to reprogram the modules with the information downloaded from the Paradox Memory Key.



Copy to Memory Key from SOURCE Control Panel

- 1) Remove AC and battery power from the control panel.
- 2) Insert Memory Key onto the serial connector labelled KEY on the Spectra control panel that you want to copy. Make sure the write protect jumper of the Memory Key is on.
- 3) Re-apply AC and battery power.
- 4) Enter installer programming mode, enter section [902], then press [ENTER] to acknowledge.
- 5) When the keypad emits a Confirmation Beep, remove the Memory Key. Remove the Memory Key's jumper if you do not wish to accidentally overwrite its contents.



4-PGM Output Modules V2.0

Due to the APR3-PGM4's Auto-recognition feature, it can be used with either the Spectra (V2.0 or higher), DGP-848 or DGP-NE96 control panel. When connected to the bus, the APR3-PGM4 automatically detects which control panel it is connected to and adjusts its internal communication parameters to function accordingly. Only one APR3-PGM4 can be connected to each Spectra control panel.

 Modules with the APR- prefix are compatible with Spectra (versions 2.0 and higher) and DGP-848. Modules with the APR3- prefix are compatible with Spectra (versions 2.0 and higher), DGP-848 and DGP-NE96.

Bold = Default Setting

Section [500]: General Options

Option	OFF	ON
[1] PGM1 Time Base Selection	☐ Seconds	☐ Minutes
[2] PGM2 Time Base Selection	☐ Seconds	☐ Minutes
[3] PGM3 Time Base Selection	☐ Seconds	☐ Minutes
[4] PGM4 Time Base Selection	☐ Seconds	☐ Minutes
[5] to [8] Future use	☐ N/A	☐ N/A

PGM Programming

Each PGM Deactivation event can be used as another activation event if their respective PGM timer (see sections [501] to [504]) is programmed with a value other than 000. The APR3-PGM4 uses the same PGM events as the Spectra control panel, please refer to *Programmable Outputs* on page 9.

Section #	Decimal Value (000-255)	Description	Default Value
[501] ___/___/___	(000 = follow deactivation event)	PGM1 TIMER	5 sec.
[502] ___/___/___	(000 = follow deactivation event)	PGM2 TIMER	5 sec.
[503] ___/___/___	(000 = follow deactivation event)	PGM3 TIMER	5 sec.
[504] ___/___/___	(000 = follow deactivation event)	PGM4 TIMER	5 sec.

Section #	Event Group #	Sub-Group #	Partition #
[505] PGM1 Activation Event	___/___	___/___	___/___
[506] PGM1 Deactivation Event	___/___	___/___	___/___
[507] PGM2 Activation Event	___/___	___/___	___/___
[508] PGM2 Deactivation Event	___/___	___/___	___/___
[509] PGM3 Activation Event	___/___	___/___	___/___
[510] PGM3 Deactivation Event	___/___	___/___	___/___
[511] PGM4 Activation Event	___/___	___/___	___/___
[512] PGM4 Deactivation Event	___/___	___/___	___/___

Printer Module V2.0

Due to the APR3-PRT1's Auto-recognition feature, it can be used with either the Spectra (V2.0 or higher), DGP-848 or DGP-NE96 control panel. When connected to the bus, the APR3-PRT1 automatically detects which control panel it is connected to and adjusts its internal communication parameters to function accordingly. Only one APR3-PRT1 can be connected to each Spectra control panel.



Modules with the APR- prefix are compatible with Spectra (versions 2.0 and higher) and DGP-848. Modules with the APR3- prefix are compatible with Spectra (versions 2.0 and higher), DGP-848 and DGP-NE96.

Bold = Default Setting

Section [550]: General Options

Option	OFF	ON
[1] <i>Assigned to Partition 1</i>	☐ Disabled	☐ Enabled
[2] <i>Assigned to Partition 2</i>	☐ Disabled	☐ Enabled
[3] <i>PGM normal state</i>	☐ Normally Open (N.O.)	☐ Normally Closed (N.C.)
[4] <i>Print Arming and disarming events</i>	☐ Disabled	☐ Automatically
[5] <i>Print Alarm and Alarm Restore events</i>	☐ Disabled	☐ Automatically
[6] <i>Print Tamper and Tamper Restore events</i>	☐ Disabled	☐ Automatically
[7] <i>Print Trouble and Trouble Restore events</i>	☐ Disabled	☐ Automatically
[8] <i>Print Special events</i>	☐ Disabled	☐ Automatically

Section [551]: Automatic Zone Status Printing

Option	OFF	ON
[1] <i>Print status of Zone 1</i>	☐ Disabled	☐ Automatically
[2] <i>Print status of Zone 2</i>	☐ Disabled	☐ Automatically
[3] <i>Print status of Zone 3</i>	☐ Disabled	☐ Automatically
[4] <i>Print status of Zone 4</i>	☐ Disabled	☐ Automatically
[5] <i>Print status of Zone 5</i>	☐ Disabled	☐ Automatically
[6] <i>Print status of Zone 6</i>	☐ Disabled	☐ Automatically
[7] <i>Print status of Zone 7</i>	☐ Disabled	☐ Automatically
[8] <i>Print status of Zone 8</i>	☐ Disabled	☐ Automatically

Section [552]: Automatic Zone Status Printing

Option	OFF	ON
[1] <i>Print status of Zone 9</i>	☐ Disabled	☐ Automatically
[2] <i>Print status of Zone 10</i>	☐ Disabled	☐ Automatically
[3] <i>Print status of Zone 11</i>	☐ Disabled	☐ Automatically
[4] <i>Print status of Zone 12</i>	☐ Disabled	☐ Automatically
[5] <i>Print status of Zone 13</i>	☐ Disabled	☐ Automatically
[6] <i>Print status of Zone 14</i>	☐ Disabled	☐ Automatically
[7] <i>Print status of Zone 15</i>	☐ Disabled	☐ Automatically
[8] <i>N/A</i>	☐ N/A	☐ N/A

Bold = Default Setting

Section [553]: Serial and Parallel Port Setup Options

Option

OFF

ON

[1] *Serial port*

☐ **Disabled**

☐ Enabled

[2]&[3]

☐ see table

☐ see table

☐ see table

☐ see table

Baud Rate Settings			
[2]	[3]	APR-PRT1	APR3-PRT1
OFF	OFF	1200 baud (default)	2400 baud (default)
ON	OFF	2400 baud	9600 baud
OFF	ON	9600 baud	19200 baud
ON	ON	19200 baud	57600 baud

[4] *Parallel port*

☐ **Disabled**

☐ Enabled

[5] *Off-line status ignored (parallel port only)*

☐ **Disabled**

☐ Enabled

[6] *Paper empty status ignored (parallel port only)*

☐ **Disabled**

☐ Enabled

[7] *Printer fault status ignored (parallel port only)*

☐ **Disabled**

☐ Enabled

[8] *Printer busy status ignored (parallel port only)*

☐ **Disabled**

☐ Enabled

PGM Programming

The PGM Deactivation event can be used as another activation event if the PGM Timer (section [554]) is programmed with a value other than 000. The APR3-PRT1 module uses the same PGM events as the Spectra control panel, please refer to *Programmable Outputs* on page 9.

Section #	Decimal Value (000-255)	Description	Default Value
[554] ____/____/____	seconds (000 = follow deactivation event)	PGM1 TIMER	5s

Section #	Event Group #	Sub-Group #	Partition #
[555] PGM1 Activation Event	____/____	____/____	____/____
[556] PGM1 Deactivation Event	____/____	____/____	____/____

Clock Programming

For example, to enter the date March 26, 2004 you would enter 2004 (year), 03 (month), and 26 (day).

Section #	Value
[557]	Year ____/____/____ Month ____/____ Day ____/____



Voice-assisted Arm/Disarm Bus Module V2.0

Due to InTouch's Auto-recognition feature, it can be used with either the Spectra (V2.0 or higher), DGP-848 or DGP-NE96 control panels. When connected to the bus, InTouch automatically detects which control panel it is connected to and adjusts its internal communication parameters to function accordingly. Only one InTouch can be connected to each Spectra control panel.

APR3-ADM2 can also be programmed using the WinLoad Software. Refer to the *WinLoad Online Help* for more information.



Modules with the APR- prefix are compatible with Spectra (versions 2.0 and higher) and DGP-848. Modules with the APR3- prefix are compatible with Spectra (versions 2.0 and higher), DGP-848 and DGP-NE96.

Section #	Decimal Value (000-255)	Description	Default Value
[575] ___/___/___	rings (000 = disabled)	NUMBER OF RINGS	8 rings
[576] ___/___/___	seconds (010-255, 000 = disabled)	ANSWERING MACHINE OVERRIDE	000
[577] ___/___/___	seconds/minutes (000 = disabled)	PGM TIMER	005

Bold = Default Setting

Section [578]: General Options

Option	OFF	ON
[1] Stand-alone Code length	☐ 6-digits	☐ 4-digits
[2] Partitioned system	☐ Disabled	☐ Enabled
[3] PGM output	☐ Disabled	☐ Enabled
[4] PGM time in	☐ Seconds	☐ Minutes
[5] to [8] Future use	☐ N/A	☐ N/A

Wireless Features

 Do not cut, bend or alter 1759MG's antennae and ensure that electrical wires do not cross over the antennae, as this may affect signal reception.

Zone Assignment

The serial number can be located on the inside of the transmitter or you can use the Serial Number Display feature (see page 24). Also, refer to *Zone Recognition Table* on page 6.

Section # Serial #
[601] ___/___/___/___/___/___ = EXPANSION INPUT 1

[602] ___/___/___/___/___/___ = EXPANSION INPUT 2

[603] ___/___/___/___/___/___ = EXPANSION INPUT 3

[604] ___/___/___/___/___/___ = EXPANSION INPUT 4

[605] ___/___/___/___/___/___ = EXPANSION INPUT 5

[606] ___/___/___/___/___/___ = EXPANSION INPUT 6

[607] ___/___/___/___/___/___ = EXPANSION INPUT 7

[608] ___/___/___/___/___/___ = EXPANSION INPUT 8

Bold = Default Setting

Section [610]: General Options

Option	OFF	ON
[1] <i>Wireless transmitter check-in supervision</i>	☐ Disabled	☐ Enabled
[2] <i>Check-in supervision interval</i>	☐ 24h	☐ 80min
[3] to [7] <i>Future use</i>	☐ N/A	☐ N/A
[8] <i>Tamper Supervision</i>	☐ Disabled	☐ Enabled

Serial Number Display

Section #	Description
[630]	Press the anti-tamper switch of the Magellan Wireless Transmitter. The keypad will emit a confirmation beep. On LED keypads, press the [ENTER] key to view the digits one at a time. On LCD keypads, the first 3 digits of the serial number will appear. Press the [ENTER] key 3 times to view the next 3 digits. Continue activating the desired transmitters or press [CLEAR] to exit.

Signal Strength Display

Section #	Description
	After entering the desired section, activate the Magellan Wireless Transmitter by opening/closing the zone or by pressing the anti-tamper switch. Always ignore the first reading as it won't be accurate. An average reading of 3 or higher is acceptable.
[631]	Display Signal Strength of Expansion Input 1 - Section [601]
[632]	Display Signal Strength of Expansion Input 2 - Section [602]
[633]	Display Signal Strength of Expansion Input 3 - Section [603]
[634]	Display Signal Strength of Expansion Input 4 - Section [604]
[635]	Display Signal Strength of Expansion Input 5 - Section [605]
[636]	Display Signal Strength of Expansion Input 6 - Section [606]
[637]	Display Signal Strength of Expansion Input 7 - Section [607]
[638]	Display Signal Strength of Expansion Input 8 - Section [608]

Remote Control User Assignment

Section #	Decimal Value	Description	Default Value
[701]	___/___/___ (001-048 = user #)	remote control #1 - section [731]*	000
[702]	___/___/___ (001-048 = user #)	remote control #2 - section [732]*	000
[703]	___/___/___ (001-048 = user #)	remote control #3 - section [733]*	000
[704]	___/___/___ (001-048 = user #)	remote control #4 - section [734]*	000
[705]	___/___/___ (001-048 = user #)	remote control #5 - section [735]*	000
[706]	___/___/___ (001-048 = user #)	remote control #6 - section [736]*	000
[707]	___/___/___ (001-048 = user #)	remote control #7 - section [737]*	000
[708]	___/___/___ (001-048 = user #)	remote control #8 - section [738]*	000

* refer to *Remote Control Assignment* on page 26.

Button Options



MG-REM1

Button Options Table

Empty Slot [FORCE] - Button disabled

- 1 - Regular arming
- 2 - Stay arming
- 3 - Instant arming
- 4 - Force arming
- 5 - Disarm
- 6 - Disarm when no alarm
- 7 - Regular arm and disarm
- 8 - Panic 1
- 9 - Panic 2
- A - Panic 3
- B - PGM Activation (Event Group #7, see PGM Programming)
- C - PGM Activation (Event Group #8, see PGM Programming)
- D - PGM Activation (Event Group #9, see PGM Programming)

 Please note that the User Code assigned to the remote control (sections [701] to [708]) must have the same User Options and Button Options enabled. For example, if you enable the Force Arming button option you must enable the appropriate Force Arming user option. Also, if you enable any of the Panic button options, you must enable the Panic options in the control panel.

Remote Control Button Programming

RC#	Section	RC Buttons Default: (1 5 0 0 0 0 0 0)							
1	[711]	___/___/___/___/___/___/___/___							
2	[712]	___/___/___/___/___/___/___/___							
3	[713]	___/___/___/___/___/___/___/___							
4	[714]	___/___/___/___/___/___/___/___							
5	[715]	___/___/___/___/___/___/___/___							
6	[716]	___/___/___/___/___/___/___/___							
7	[717]	___/___/___/___/___/___/___/___							
8	[718]	___/___/___/___/___/___/___/___							

 = These button combinations are not available with the MG-REM1 or MG-RAC1 remote controls and cannot be programmed.

Remote Control Assignment

Enter the appropriate section and press any button on the remote control twice to assign the remote control. If you hear a rejection beep, an error has occurred or the remote control has already been assigned. To delete a remote control, enter the desired section and then press the **[FORCE]** button.

Section #	
[731]	REMOTE CONTROL #1
[732]	REMOTE CONTROL #2
[733]	REMOTE CONTROL #3
[734]	REMOTE CONTROL #4
[735]	REMOTE CONTROL #5
[736]	REMOTE CONTROL #6
[737]	REMOTE CONTROL #7
[738]	REMOTE CONTROL #8

 Modules with the APR- prefix are compatible with Spectra (versions 2.0 and higher) and DGP-848. Modules with the APR3- prefix are compatible with Spectra (versions 2.0 and higher), DGP-848 and DGP-NE96.

Section [650]: Options

Section [651]: Zone AssignmentSpectra 1759MG - 27 - Programming Guide

User Operation

Partitioning

The Spectra system is equipped with a partitioning feature which can divide the alarm system into two distinct areas identified as Partition 1 and Partition 2. Partitioning can be used in installations where shared security systems are more practical, such as an office/warehouse building. ***If the system is not partitioned, all User Codes and features will be recognized as belonging to Partition 1.***

How does a partitioned system work?

- Users can only arm or disarm their assigned partitions.
- Only zones assigned to Partition 1 will arm or disarm when Partition 1 is armed or disarmed.
- Only zones assigned to Partition 2 will arm or disarm when Partition 2 is armed or disarmed.
- Zones assigned to both partitions will arm when both partitions are armed and will disarm when at least one disarms.
- Some of the system's features can be programmed separately for each partition.

Programming Access Codes

User Access Codes are personal identification numbers that allow users to enter certain programming modes, arm or disarm the alarm system as well as activate or deactivate PGMs. Spectra security systems support the following:

System Master Code can arm or disarm any partition using any arming method and can create, modify or delete any User Access Code. Only the System Master Code can modify or delete User Access Codes assigned to both partitions.

Master Code 1 is permanently assigned to partition 1 and can be used to create, modify or delete User Access Codes that are assigned to partition 1.

Master Code 2 is permanently assigned to partition 2 (except when partitioning is disabled, Master Code 2 will be assigned to partition 1) and can be used to create, modify or delete User Access Codes that are assigned to the same partition.

45 User Access Codes (including 1 Duress code)

How Do I Program Access Codes?

- 1) Press [ENTER]
- 2) Key in the [SYSTEM MASTER CODE] or [MASTER CODE]
- 3) Key in 3-digit [SECTION] (see User Code Table)
- 4) Key in new 4- or 6-digit [ACCESS CODE]
[ENTER] flashes. Return to step 3

How Do I Delete Access Codes?

- 1) Repeat steps 1 to 3 (see above)
- 2) Press the [FORCE] key once for each digit in the access code (4 or 6 times) until the keypad emits a Confirmation Beep.

User Code Table

Section	User Codes
[001]	User Code 001 = System Master Code
[002]	User Code 002 = Master Code 1
[003]	User Code 003 = Master Code 2
[004] to [047]	User Code 004 to User Code 047
[048]	User Code 048 or Duress Code

Programming Chime Zones

This feature allows users to program which zones will be Chime Enabled. A Chime Enabled zone will cause the keypad to emit a rapid intermittent beep tone (BEEP-BEEP-BEEP-BEEP) advising the user every time it is opened. Each keypad must be Chime Programmed separately. Keypad chimes must be re-programmed if the system suffers a total power loss (16-zone LED and LCD Keypads only).

10-Zone LED Keypad

Press and hold any key from **[1]** to **[10]** for 3 seconds to activate or deactivate Chiming for zones 1 to 10. For example, press and hold the **[1]** key to enable chiming on zone 1. If, after pressing and holding a key, the keypad emits a confirmation beep, this means the chime feature has been enabled for that zone. If the keypad emits a Rejection Beep, this means the Chime feature has been disabled for the corresponding zone.

16-Zone LED Keypad

Press and hold the **[9]** key. Enter the 2-digit (**01 to 16**) zone number(s). When the corresponding LED is on, the zone is chimed. When the corresponding LED is off, the zone is unchimed. When the desired zones are chimed, press **[ENTER]**.

LCD Keypad

Press and hold the **[9]** key. Enter the 2-digit (**01 to 16**) zone number(s) or use the arrow keys to scroll through the zones. When the appropriate zone is displayed, press the **[FNC1]** key. When the desired zones are chimed, press **[ENTER]**.

Keypad Muting

Press and hold the **[CLEAR]** key for 3 seconds to enable or disable keypad muting. When muted, the keypad will only beep when a key is pressed or when the keypad emits a Rejection or Confirmation Beep. All other beep functions are disabled.

Keypad Backlight (1686H and 1686V Only)

The illumination level behind the keys can be modified to suit the user's needs. There are four backlight levels. The **[MEM]** key is used to set the desired level. Each consecutive push of the **[MEM]** key will increase the backlight level until the maximum level is reached. After reaching the maximum level, the backlight level will return to the lowest level and the whole process is repeated. To change the backlight level:

How do I Modify the Backlight?

- 1) Press and hold the **[MEM]** key for 3 seconds
- 2) The **[MEM]** key will illuminate
- 3) Press the **[MEM]** key to set the desired backlight level
- 4) Press **[CLEAR]** or **[ENTER]** to exit

Quick Function Keys

Installer Test Mode

[ENTER] + [INSTALLER CODE] + [TBL] or [TRBL]

The Installer Test Mode allows you to perform walk tests where the bell/siren will squawk once to indicate an open zone and twice to indicate a closed zone. To enter this mode, press **[ENTER] + [INSTALLER CODE] + [TBL] or [TRBL]**. The keypad will emit a Confirmation Beep. To disable this mode, press the **[TBL] or [TRBL]** key again. The keypad will emit a Rejection Beep.

Test Report

[ENTER] + [INSTALLER/MASTER CODE] + [MEM]

Sends the Test Report report code programmed in section [211] to the central station.

Call WinLoad Software

[ENTER] + [INSTALLER/MASTER CODE] + [BYP]

This feature is used to establish communication between the control panel and a computer using the WinLoad Software. After entering this mode, the control panel will dial the telephone number programmed in section **[150]**.

Cancel Communication

[ENTER] + [INSTALLER/MASTER CODE] + [STAY]

Cancels all communication until the next reportable event. If the Master Code was used, only communication with WinLoad would be cancelled.

Answer WinLoad Software

[ENTER] + [INSTALLER/MASTER CODE] + [FORCE]

Forces the control panel to pick-up an incoming telephone call.

Appendix A - Ademco CID Report Code List (Prog.)

If using the Ademco Contact ID Programmable code format, enter the 2-digit hexadecimal value from the table below (Prog. Value) into sections [160] to [213] to program the desired report codes. **To enter a 0 value press the [FORCE] key.**


CID#	Reporting Code	Prog. Value	CID#	Reporting Code	Prog. Value	CID#	Reporting Code	Prog. Value
MEDICAL ALARMS - 100			203	Gate Valve Sensor	2E	401	O/C by User	5B
100	Medical Alarm	01	204	Low Water Level	2F	402	Group O/C	5C
101	Pendant Transmitter	02	205	Pump Activated	30	403	Automatic O/C	5D
102	Fail to Report In	03	206	Pump Failure	31	404	Late to O/C	5E
FIRE ALARMS - 110			SYSTEM TROUBLES - 300 & 310			405	Deferred	5F
110	Fire Alarm	04	300	System Trouble	32	406	Cancel	60
111	Smoke	05	301	AC Loss	33	407	Remote Arm/Disarm	61
112	Combustion	06	302	Low System Battery	34	408	Quick Arm	62
113	Water Flow	07	303	RAM Checksum Bad	35	409	Keyswitch O/C	63
114	Heat	08	304	ROM Checksum Bad	36	REMOTE ACCESS - 410		
115	Pull Station	09	305	System Reset	37	411	Callback Request Made	64
116	Duct	0A	306	Panel Program Changed	38	412	Success - Download Access	65
117	Flame	0B	307	Self-Test Failure	39	413	Unsuccessful Access	66
118	Near Alarm	0C	308	System Shutdown	3A	414	System Shutdown	67
PANIC ALARMS - 120			309	Battery Test Failure	3B	415	Dialer Shutdown	68
120	Panic Alarm	0D	310	Ground Fault	3C	ACCESS CONTROL - 420		
121	Duress	0E	SOUNDER/RELAY TROUBLES - 320			421	Access Denied	69
122	Silent	0F	320	Sounder Relay	3D	422	Access Report By User	6A
123	Audible	10	321	Bell 1	3E	SOUNDER RELAY DISABLES - 520		
BURGLAR ALARMS - 130			322	Bell 2	3F	520	Sounder/Relay Disabled	6B
130	Burglary	11	323	Alarm Relay	40	521	Bell 1 Disable	6C
131	Perimeter	12	324	Trouble Relay	41	522	Bell 2 Disable	6D
132	Interior	13	325	Reversing	42	523	Alarm Relay Disable	6E
133	24-Hour	14	SYSTEM PERIPHERAL TROUBLES - 330 & 340			524	Trouble Relay Disable	6F
134	Entry/Exit	15	330	System Peripheral	43	525	Reversing Relay Disable	70
135	Day/Night	16	331	Polling Loop Open	44	COMMUNICATION DISABLES - 550 & 560		
136	Outdoor	17	332	Polling Loop Short	45	551	Dialer Disabled	71
137	Tamper	18	333	Exp. Module Failure	46	552	Radio xmitter Disabled	72
138	Near Alarm	19	334	Repeater Failure	47	BYPASSES - 570		
GENERAL ALARMS - 140			335	Local Printer Paper Out	48	570	Zone Bypass	73
140	General Alarm	1A	336	Local Printer Failure	49	571	Fire Bypass	74
141	Polling Loop Open	1B	COMMUNICATION TROUBLES - 350 & 360			572	24-Hour Zone Bypass	75
142	Polling Loop Short	1C	350	Communication	4A	573	Burg. Bypass	76
143	Expansion Module Failure	1D	351	Telco Fault 1	4B	574	Group Bypass	77
144	Sensor Tamper	1E	352	Telco Fault 2	4C	TEST/MISC. - 600		
145	Expansion Module Tamper	1F	353	Long Range Radio	4D	601	Manual Trigger Test	78
24-HOUR NON-BURGLARY - 150 & 160			354	Fail to Communicate	4E	602	Periodic Test Report	79
150	24-Hour Non-Burglary	20	355	Loss of Radio Supervision	4F	603	Periodic RF Xmission	7A
151	Gas Detected	21	356	Loss of Central Polling	50	604	Fire Test	7B
152	Refrigeration	22	PROTECTION LOOP TROUBLES - 370			605	Status Report to Follow	7C
153	Loss of Heat	23	370	Protection Loop	51	606	Listen-in to Follow	7D
154	Water Leakage	24	371	Protection Loop Open	52	607	Walk Test Mode	7E
155	Foil Break	25	372	Protection Loop short	53	621	Event Log Reset	7F
156	Day Trouble	26	373	Fire Trouble	54	622	Event Log 50% Full	80
157	Low Bottled Gas Level	27	SENSOR TROUBLES - 380			623	Event Log 90% Full	81
158	High Temp	28	380	Sensor Trouble	55	624	Event Log Overflow	82
159	Low Temp	29	381	Loss of Super. -RF	56	625	Time/Date Reset	83
161	Loss of Air Flow	2A	382	Loss of Super. - RPM	57	626	Time/Date Inaccurate	84
FIRE SUPERVISORY - 200 & 210			383	Sensor Tamper	58	627	Program Mode Entry	85
200	Fire Supervisory	2B	384	RF xmtr. Low Battery	59	628	Program Mode Exit	86
201	Low Water Pressure	2C	OPEN/CLOSE - 400			631	Exception Schedule Change	87
202	Low CO2	2D	400	Open/Close	5A	654	System Inactivity	88

Appendix B - Ademco CID Report Code List (All Codes)

System Event	Default Contact ID Report Code when option [3] is on in section [136]	System Event	Default Contact ID Report Code when option [3] is on in section [136]
Arming with Master Code (##)	3 4A1 - Close by user	Auxiliary supply trouble	1 3AA - System trouble
Arming with User Code (##)	3 4A1 - Close by user	Bell output current limit	1 321 - Bell 1
Arming with Keypad (##)	3 4A9 - Keypad Close	Bell absent	1 321 - Bell 1
Auto Arming	3 4A3 - Automatic Close	Clock lost	1 626 - Time/Date inaccurate
Arm with PC software	3 4A7 - Remote arm/disarm	Fire loop trouble	1 373 - Fire trouble
Late To Close	3 4A4 - Late to Close	Wireless Transmitter Low Battery	1 384 - RF xmtr. low battery
No Movement	3 4A4 - Late to Close	Wireless Transmitter Supervision Loss	1 381 - Loss of super. - RF
Partial arming	1 574 - Group bypass	Module fault	1 333 - Expansion module failure
Quick arming	3 408 - Quick arm	Printer fault	1 336 - Local printer failure
		Fail to communicate with central station	1 354 - Fail to communicate
Disarm with Master Code (##)	1 4A1 - Open by user	Wireless Transmitter Low Battery	1 384 - RF xmtr. low battery
Disarm with User Code (##)	1 4A1 - Open by user	TLM trouble restore	3 351 - Telco 1 fault restore
Disarm with Keypad (##)	1 4A9 - Keypad Open	AC Failure restore	3 3A1 - AC loss restore
Disarm after alarm with Master Code (##)	1 4A1 - Open by user	Battery Failure restore	3 3A9 - Battery test restore
Disarm after alarm with User Code (##)	1 4A1 - Open by user	Auxiliary supply trouble restore	3 3AA - System trouble restore
Disarm after alarm with Keypad (##)	1 4A9 - Keypad Open	Bell output current limit restore	3 321 - Bell 1 restore
		Bell absent restore	3 321 - Bell 1 restore
Auto Arming Cancellation	1 4A5 - Deferred Open/Close	Clock programmed	3 626 - Time/Date Reset
Disarm with PC software	1 4A7 - Remote arm/disarm	Fire loop trouble restore	3 373 - Fire trouble restore
Disarm after an alarm with PC software	1 4A7 - Remote arm/disarm	Wireless Transmitter Low Battery	3 384 - RF xmtr. low battery
		Wireless Transmitter Supervision Loss	3 381 - Loss of super. - RF
Zone Bypassed (##)	1 57A - Zone bypass	Module fault restore	3 333 - Expansion module failure restore
Zone alarm (##)	1 13A - Burglary Alarm	Printer fault restore	3 336 - Local printer failure restore
Fire alarm (##)	1 11A - Fire alarm	Fail to communicate with central station	3 354 - Fail to communicate restore
Zone alarm restore (##)	3 13A - Burglary Alarm Restore		
Fire alarm restore (##)	3 11A - Fire alarm Restore	Cold Start	1 3A8 - System shutdown
		Test Report engaged	1 6A2 - Periodic test report
Panic 1 - Emergency	1 12A - Panic alarm	PC software communication finished	1 412 - Successful - download access
Panic 2 - Medical	1 1AA - Medical alarm	Installer on site	1 627 - Program mode Entry
Panic 3 - Fire	1 115 - Pull Station	Installer programming finished	1 628 - Program mode Exit
		Delinquency	1 654 - Inactivity
Recent closing	3 4AA - Open/Close		
Global zone shutdown	1 574 - Group bypass		
Duress alarm	1 121 - Duress		
Zone shutdown (##)	1 57A - Zone bypass		
Zone tampered (##)	1 144 - Sensor tamper		
Zone tamper restore (##)	3 144 - Sensor tamper restore		
AC Failure	1 3A1 - AC loss		
Battery Failure	1 3A9 - Battery test failure		


Bus Module Connections

Printer Module (APR3-PRT1)




- A** Green "Locate" LED: Remains illuminated during power up
- B** Red "Watchdog" LED: Flashes to indicate proper operation. If there is a communication failure, the red LED will flash ON for one second and OFF for one second.
- C** Red "TX" LED: Flashes when the Printer Module is transmitting data through the serial port only.
- D** 25-pin Parallel Port: Connect the Printer Module's 25-pin parallel port to any dot matrix printer. **Note: The dot matrix printer must support a minimum of 80 columns.**
- E** 9-Pin Serial Port: Connect the Printer Module's 9-Pin serial port to a dot matrix printer. **Note: The dot matrix printer must support a minimum of 80 columns.**
- F** 9-Pin Serial Port: Connect the Printer Module's 9-Pin serial port to a computer's COM port to view the control panel's events on the computer's monitor. The events displayed on the monitor can then be printed through the printer connected to the computer.

Connecting the PGM Output




Remove AC power and battery before adding APR3-PRT1 to the system. Do not connect any modules more than 76m (250ft) from the control panel. Only one Printer Module can be connected per Spectra control panel.

4-PGM Output Module (APR3-PGM4)



⚠ Remove AC and battery from the control panel before adding the 4-PGM Output Module to the system. Do not connect the APR3-PGM4 more than 76m (250ft) from the control panel. Only one APR3-PGM4 can be connected per Spectra control panel.

4-zone expansion Bus Module (SPC-ZX4 and APR3-ZX4)




⚠ Remove AC and battery power from the control panel before connecting the module to the communication bus. Do not connect the APR3-ZX4 or SPC-ZX4 more than 76m (250ft) from the control panel. Only one APR3-ZX4 or one SPC-ZX4 can be connected per Spectra control panel.




Voice-assisted Arm/Disarm Bus Module (APR3-ADM2)




Remove AC and battery power from the control panel before adding the APR3-ADM2 module to the system. Do not connect the APR3-ADM2 more than 76m (250ft) from the control panel. Only one APR3-ADM2 can be connected per Spectra control panel.



Inset 1: Connecting the APR3-ADM2 PGM Output




8-Zone Expansion Bus Modules (SPC-ZX8 and APR3-ZX8)



Remove AC power and battery before adding a module to the system. Do not connect the APR3-ZX8 or SPC-ZX8 more than 76m (250ft) from the control panel. Only one SPC-ZX8 or APR3-ZX8 can be connected per Spectra control panel.

Hardware Connections

Single Zone Inputs



Connecting Fire Circuits, Keyswitches and PGMs



Program the PGM with the "[PG]/[FNC1] Key was pressed" Activation Event so that the smoke detectors can be reset by pressing the [PG] or [FNC1] key. See Event Group # 5 on page 9.




All 4-wire smoke detectors must be connected using the daisy chain configuration.

Programming a Wireless Fire Zone


Fire zones cannot be assigned to expansion zones. As a result, when installing a wireless smoke detector, the corresponding zone must be programmed as follows:

- 1) Enter [5] in the Zone Definition to define it as a 24Hr Burglary Alarm (see page 7).
- 2) Disable [4] and enable [5] in Zone Options to set the zone's alarm type to a pulsed Audible Alarm (see page 7).
- 3) Disable [1] and [2] in Zone Options to disable the zone's Auto Zone Shutdown and Bypass Enabled features (see page 7).
- 4) Change the zone's report code from a Burglary Report Code (Prog. Value 11) to a Fire Report Code (Prog. Value 04). See Appendix A on page 30. If using Ademco Contact I.D., set the Contact ID Options from All Codes to Programmable (section [136] option [3] = OFF) and then enter the report code manually (see page 14).


Fire Circuits 4-Wire Installation Control Panel Terminals



Keyswitch




PGM



Alarm Relay and PGM Connections

Alarm Relay (5A) can be programmed to follow the BELL output or the Global PGM




Connecting More Than Two Keypads

If there are more than 2 keypads connected to the control panel and at least one keypad zone is being used, connect as shown and program as described in the *Spectra 1759MG Reference & Installation Manual*.



When a 1641 LCD keypad is connected to Spectra, the Keypad Zone Sending option (Option [2] key [1]) determines whether the status of the keypad zone will be transmitted to the control panel. Refer to the *1641 Installer's Guide* for more information. The Keypad Zone Sending option of the 1641 keypad must be enabled during the following conditions:

- If you are using both keypad zones and at least one is from a 1641 keypad.
- If you are using the keypad zones of other types of keypads, such as a 1686H 10-zone LED keypad, and the keypad zone definition of the 1641 keypad (keypad zone 1 or keypad zone 2; Option [2] key [3]) matches that of another connected keypad.




AC Power & Backup Battery Connections

Transformer Requirements Table

Transformer:	Amseco XP-1620 16VAC 20VA *	Recommended: 16VAC 40VA UL: Basler BE156240CAA007
Spectra DC Power Supply rated at:	1.2A	1.5A
Auxiliary Supply can provide a maximum of:	typ: 600mA max: 700mA	typ: 600mA max: 700mA UL installations: typ. 200mA
Acceptable Battery Charge Currents (section [127] option [5])	350mA	350mA / 700mA

* Not verified by UL



Spectra 1759MG PCB Layout

"STATUS" LED:

Flash once every second = normal


Flashes ON 1 second and OFF 1 second = trouble

Always ON = panel is using phone line

Fast flash 4 seconds after power up = installer lock enabled

"RX" LED:

Flashes quickly when receiving signals from wireless devices.



⚠ For UL and C-UL warnings, refer to the UL and C-UL Warnings section at the back of the Spectra 1759MG Reference & Installation Manual.

Warranty

Paradox Security Systems Ltd. ("Seller") warrants its products to be free from defects in materials and workmanship under normal use for a period of one year. Except as specifically stated herein, all express or implied warranties whatsoever, statutory or otherwise, including without limitation, any implied warranty of merchantability and fitness for a particular purpose, are expressly excluded. Because Seller does not install or connect the products and because the products may be used in conjunction with products not manufactured by Seller, Seller cannot guarantee the performance of the security system and shall not be responsible for circumstances resulting from the product's inability to operate. Seller obligation and liability under this warranty is expressly limited to repairing or replacing, at Seller's option, any product not meeting the specifications. Returns must include proof of purchase and be within the warranty period. In no event shall the Seller be liable to the buyer or any other person for any loss or damages whether direct or indirect or consequential or incidental, including without limitation, any damages for lost profits stolen goods, or claims by any other party, caused by defective goods or otherwise arising from the improper, incorrect or otherwise faulty installation or use of the merchandise sold.

Notwithstanding the preceding paragraph, the Seller's maximum liability will be strictly limited to the purchase price of the defective product. Your use of this product signifies your acceptance of this warranty.

BEWARE: Dealers, installers and/or others selling the product are not authorized to modify this warranty or make additional warranties that are binding on the Seller.

© 2002-2005 Paradox Security Systems Ltd. All rights reserved. Specifications may change without prior notice. One or more of the following US patents may apply: 6215399, 6111256, 5751803, 5721542, 5287111, 5119069, 5077549, 5920259 and 5886632. Canadian and international patents may also apply.

Spectra, Digiplex and Magellan are trademarks or registered trademarks of Paradox Security Systems Ltd. or its affiliates in Canada, the United States and/or other countries.

For technical support in Canada or the U.S., call 1-800-791-1919 for English or 1-866-912-0600 for French, Monday to Friday from 8:00 a.m. to 8:00 p.m. EST. For technical support outside Canada and the U.S., call 00-1-450-491-7444, Monday to Friday from 8:00 a.m. to 8:00 p.m. EST. Please feel free to visit our website at www.paradox.ca.

P ▲ R ▲ D O X[®]
S E C U R I T Y S Y S T E M S
780 Industriel Blvd., Saint-Eustache (Quebec) J7R 5V3 CANADA
Tel.: (450) 491-7444 Fax: (450) 491-2313
www.paradox.ca
PRINTED IN CANADA - 01/2005 1759MG-EP05

