

App Functionality	ONE	AIR	PRO
<b>In-race gameplay continued</b>			
Top speed	✓	✓	✓
Proximity sound	✓	✓	✓
Practice	✓	✓	✓
Pit lane pit stop	✓	✓	✓
Fuel usage	✓	✓	✓
Tyre wear		✓	✓
In-race damage		✓	✓
Weather conditions		✓	✓
Kinetic Energy Recovery System (KERS)			✓
Lane Changing			✓
<b>Pre-race Configuration</b>			
Set selection	✓	✓	✓
Car selection	✓	✓	✓
Multi-device display	✓	✓	✓
Track Layout selector	✓	✓	✓

App Functionality	ONE	AIR	PRO
<b>Pre-race configuration continued</b>			
Maximum power limiter		✓	✓
Hand throttle mapping		✓	✓
<b>Social media</b>			
Twitter race statistics update	✓	✓	✓
Facebook race statistics update	✓	✓	✓
Post-race statistics	✓	✓	✓
Post-race statistics graph	✓	✓	✓

**Powerbase- Power/Bluetooth LED**

State	Off	Orange Flashing	Green Solid	Red Flashing
Meaning:	No power connected.	Power on, no bluetooth connection.	Power on, Bluetooth connected.	Power on, Bluetooth connected.

**Powerbase- Binding LED**

State	Off	Green Flashing	Green Solid
Meaning:	No controller connected	Channel is in binding mode.	Channel is connected to a Controller.

**Controller- Indicator LED**

State	Off	Green Flashing	Green Solid
Meaning:	Power off or controller in Sleep mode.	Controller is in binding mode.	Controller is connected to a channel on the Powerbase.

**Device****Sympton****Resolution**

Hand controller	The LED on my hand controller does not light up when i turn it on.	Check you have correctly installed the batteries, and try new ones.
Hand controller	My hand controller has gone to sleep.	To restart your hand controller you must turn it off and back on again.
Powerbase/App	The cars are not being sensed when passing through the powerbase straight.	Unplug the power to the powerbase and abort your race. Now power up the Powerbase and try again.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC ID: 2ACUF-C8433

IC: 12075A-C8433