Application for FCC / IC FCC ID: K6620755X40 / IC: 511B-20755X40





VHF/UHF DIGITAL/ANALOG TRANSCEIVER C4FM/FM

Contents

Safety Precautions (Be Sure to Read) 3				
FTM-7250DR Quick Reference Guide 5				
Introduction6				
Features of this radio6				
Accessories & Options7				
Supplied Accessories7				
Optional Accessories7				
Installation8				
Connecting the Microphone8				
Connecting the Antenna 8				
Mobile Installation				
Power connection				
Base Station Installation11				
AC Power Supplies11				
Front Panel Controls & Switches				
Front Panel				
Microphone Switches				
Microphone (MH-48A6JA)14				
[P1] button				
[P2] button				
[P3] button (Wires-X)				
[P4] button (TX PW/T.CALL)				
Rear Panel Connectors				
Rear Panel				
Basic Operation				
Turning the Transceiver ON and OFF				
Inputting the call sign				
Adjusting the Audio Volume Level				
Adjusting the Squelch Setting				
Frequency Navigation				
Using the Dial				
Using the MH-48A6JA Microphone				
Channel Step Selection				
Selecting the communication mode				
AMS function				
Transmission				
Adjusting the transmit power				
Lock Feature				
Advanced Operation				
Register the DG-ID number in the DG-ID memory 22				
Recall and use the DG-ID number registered				
in the DG-ID memory				
Restore the DG-ID number to "00" for both				
transmit and receive without using the				
DG-ID memory				
Use the GM (Group Monitor) with the				
DG-ID function				
Digital Personal ID (DP-ID) feature				
Registering the DP-ID to a DR-2X digital repeater 25				
Register the transceivers				
Deleting the registered DP-ID				
Advanced Operation				
Repeater Operation				
Checking the Repeater Uplink (Input) Frequency 27				
CTCSS Operation				

Tone Search	
DCS Operation	28
DCS Search	29
EPCS (Enhanced Paging &	
Code Squelch) Operation	29
Split Tone Operation	29
DTMF Operation	29
Memory Operation	30
Memory Storage	30
Split Memory	30
Memory Recall	31
Memory Recall from the Microphone Keypad	31
Moving Memory Data to the VFO	31
Memory Only Mode	31
Masking Memories	32
Unmasking Memories	32
HOME Channel Memory	32
Changing the frequency of the home channel	
Scanning	33
Basic Scanner Operation	33
Scan Resume Options	33
Memory Skip Scanning	33
Preferential Memory Scan	33
Programmable Memory Scan (PMS)	
Priority Channel Scanning (Dual Watch)	33
GM Function	
What is the GM (Group Monitor) Function?	
Displaying all the stations using the GM function	34
Reset Procedure/Clone	
Reset Procedure	35
Reset Procedure Microprocessor Resetting	35 35
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting	35 35 35
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone	35 35 35 35
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature	35 35 35 35 36
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X?	35 35 35 35 36
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital	35 35 35 35 36 36
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended)	35 35 35 36 36
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID	35 35 35 36 36 36
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room	35 35 35 36 36 36 36 39
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings	 35 35 35 36 36 36 36 39 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments	35 35 35 36 36 36 36 39 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper	35 35 35 36 36 36 36 39 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness	35 35 35 36 36 36 36 36 30 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT)	35 35 35 36 36 36 36 30 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO)	35 35 35 36 36 36 36 30 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO)	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level	35 35 35 36 36 36 36 36 30 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting Displaying the Supply Voltage	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting Displaying the Supply Voltage Displaying the Temperature	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting Displaying the Supply Voltage Displaying the Temperature Band Edge Beeper	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness. Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting Displaying the Supply Voltage Displaying the Temperature Band Edge Beeper	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting Displaying the Supply Voltage Displaying the Temperature Band Edge Beeper Setup (Menu) Mode Maintenance	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting Displaying the Supply Voltage Displaying the Temperature Band Edge Beeper Setup (Menu) Mode Maintenance Care and maintenance	35 35 35 36 36 36 36 30 40 40 40 40 40 40 40 40 40 40 40 40 40
Reset Procedure Microprocessor Resetting Setup (Menu) Mode Resetting Clone Connecting the WIRES-X feature What is WIRES-X? Connecting to a WIRES-X digital node (Recommended) Connecting to the other node ID or the other room ID Disconnecting from the node or room Miscellaneous Settings Programming the Key Assignments Keyboard Beeper Display Brightness Time-Out-Timer (TOT) Automatic Power Off (APO) Busy Channel Lock-Out (BCLO) TX Deviation Level MIC Gain Setting Displaying the Supply Voltage Displaying the Temperature Band Edge Beeper Setup (Menu) Mode Maintenance	35 35 35 36 36 36 30 40 40 40 40 40 40 40 40 40 40 40 40 40

Safety Precautions (Be Sure to Read)

Be sure to read these important precautions, and use this product safely.

Yaesu is not liable for any failures or problems caused by the use or misuse of this product by the purchaser or any third party. Also, Yaesu is not liable for damages caused through the use of this product by the purchaser or any third party, except in cases where ordered to pay damages under the laws.

Types and meanings of the marks

Types and meanings	Of the marks		
	This mark indicates an imminently hazardous situation, which, if not avoided, could result in death or serious injury.		
	This mark indicates a avoided, could result in	a potentially hazardous situation, which, if not death or serious injury.	
	This mark indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury or only property damage.		
Types and meanings	of symbols		
		which must not be done to use this product safely. t should not be disassembled.	
		which must be done to use this product safely. For g should be disconnected.	
	<u> </u>	NGER	
vehicles where its us hospitals and airpland This may exert an impa- devices.	act on electronic and medical	Do not transmit in crowded places in consider- ation of people who are fitted with medical devic- es such as heart pacemakers. Electromagnetic waves from the device may affect the medical device, resulting in accidents caused by malfunctions.	
Make sure to stop the before use if the device driver.	act while driving or riding a result in accidents. a car in a safe location first e is going to be used by the evice when flammable gas	When an alarm goes off with the external anten- na connected, cut off the power supply to this radio immediately and disconnect the external antenna from this radio. If not, this may result in fire, electric shock and equip- ment failure.	
Never touch the antenna during transmission. This may result in injury, electric shock and equipment failure.		Do not touch any liquid leaking from the liquid display with your bare hands. There is a risk of chemical burns occurring when the liquid comes into contact with the skin or gets into the eyes. In this case, seek medical treatment immediately.	
	<u>.</u>	RNING	
Do not use voltages power supply voltage Doing so may result in		When smoke or strange odors are emitted from the radio, turn off the power and disconnect the power cord from the socket. This may result in fire, liquid leak, overheating, dam age, ignition and equipment failure. Please contac our company amateur customer support or the reta store where you purchased the device.	
This may cause the te	ously for long periods of time. Emperature of the main body rns and failures due to over-		
Do not dismantle or n This may result in inju ment failure.	nodify the device. ry, electric shock and equip-	Keep the power plug pins and the surrounding areas clean at all times. This may result in fire, liquid leak, overheating, breakage, ignition etc.	
with wet hands. Also power plug with wet h	ver plug and connector etc. do not plug and unplug the nands. ry, liquid leak, electric shock	Disconnect the power cord and connection ca- bles before incorporating items sold separately and replacing the fuse. This may result in fire, electric shock and equipment failure.	

Do not pull the cable when plugging and unplugging the power cord and connection cables.

Please hold the plug or connector when unplugging. If not, this may result in fire, electric shock and equip-

Refrain from using headphones and earphones

Continuous exposure to loud volumes may result in

Do not use the device when the power cord and

connection cables are damaged, and when the

DC power connector cannot be plugged in tightly.

Please contact our company amateur customer

support or the retail store where you purchased the

device as this may result in fire, electric shock and

Follow the instructions given when installing

This may result in fire, electric shock and equipment

Do not use the device when the alarm goes off.

For safety reasons, please pull the power plug of the

DC power equipment connected to the product out

Never touch the antenna as well. This may result in fire, electric shock and equipment failure due to

items sold separately and replacing the fuse.

ment failure

at a loud volume.

hearing impairment.

equipment failure.

of the AC socket.

failure

thunder

be erased

Safety Precautions (Be Sure to Read)



Never cut off the fuse holder of the DC power cord. This may cause short-circuiting and result in ignition and fire.

Do not use fuses other than those specified. Doing so may result in fire and equipment failure.

Do not allow metallic objects such as wires and water to get inside the product.

This may result in fire, electric shock and equipment failure.

Do not place the device in areas that may get wet easily (e.g. near a humidifier).

This may result in fire, electric shock and equipment failure.



When connecting a DC power cord, pay due care not to mix up the positive and negative polarities. This may result in fire, electric shock and equipment failure.

Do not use DC power cords other than the one enclosed or specified.

This may result in fire, electric shock and equipment failure.

Do not bend, twist, pull, heat and modify the power cord and connection cables in an unreasonable manner.

This may cut or damage the cables and result in fire, electric shock and equipment failure.

Do not place this device near a heating instru-

ment or in a location exposed to direct sunlight.

Do not place this device in a location where there

This may result in deformation and discoloration.

Doing so may result in fire and equipment failure.

may have a negative effect on the human body.

Keep out of the reach of small children.

If not, this may result in injuries to children.

Do not wipe the case using thinner and benzene etc.

Please use a soft and dry piece of cloth to wipe away

Do not put heavy objects on top of the power

This may damage the power cord and connection cables, resulting in fire and electric shock.

For safety reasons, switch off the power and pull

out the DC power cord connected to the DC pow-

er connector when the device is not going to be

Do not transmit near the television and radio.

This may result in electromagnetic interference.

If not, this may result in fire and overheating

is a lot of dust and humidity.

during transmission.

the stains on the case.

cord and connection cables.

used for a long period of time.




Do not throw or subject the device to strong impact forces.



This may result in equipment failure.



Do not the put this device near magnetic cards and video tapes. The data in the cash card and video tape etc. may



Do not turn on the volume too high when using a headphone or earphone.

This may result in hearing impairment.




Do not use optional products other than those specified by our company.

If not, this may result in equipment failure.

Do not place the device on an unsteady or sloping surface, or in a location where there is a lot of vibration.

The device may fall over or drop, resulting in fire, injury and equipment failure.



place heavy objects on top or insert objects inside it. If not, this may result in equipment failure.



Do not use a microphone other than those specified when connecting a microphone to the device. If not, this may result in equipment failure.

Do not touch the heat radiating parts.



ment failure.

When used for a long period of time, the temperature of the heat radiating parts will get higher, resulting in burns when touched. Do not open the case of the product except when replac-

ing the fuse and when installing items sold separately.


This may result in injury, electric shock and equip-



When using the device in a hybrid car or fuel-saving car, make sure to check with the car manufacturer before using.

The device may not be able to receive transmissions normally due to the influence of noises from the electrical devices (inverters etc.) fitted in the car

FTM-7250DR Quick Reference Guide



Introduction

Features of this radio

- O 430 MHz mobile radio, equipped with a C4FM communication modem.
- O 50 Watts of power output, with selection of three power levels for every operating situation.
- O Clear audio and data communication is achieved using the C4FM modem functions.
- O Expanded receiver coverage: 420-470 MHz.
- With the GD-ID (Digital Group ID) feature, the Group Monitor (GM) feature enables automatically locating, and communicating with other stations that have the same DG-ID number within contact range, by utilizing a matching group ID number from 00 to 99.
- O The Digital Personal ID (DP-ID) feature supports communication specifically with transceivers registered with the individual ID information. The DP-ID is different for each transceiver and is included in each C4FM transmission.
- O Easily connect with the WIRES-X linking system.
- O Keyboard entry of operating frequencies from the microphone.
- O 220 memories (199 "basic" memory channels, 10 sets of band-edge memory channels, and one "Home" channel) which can store repeater shifts, odd repeater shifts, CTCSS/DCS tones, and 8-character Alpha-Numeric labels for easy channel recognition.
- O Built-in CTCSS and DCS Encoder/Decoder circuits.
- Extensive Menu system, which allows customization of a number of transceiver performance characteristics.
- Equipped with the GM (Group Monitor) function.

Additional features include a transmit Time-Out-Timer (TOT), Automatic Power-Off (APO), and Automatic Repeater Shift (ARS). Also included is an RF Squelch circuit that allows the owner to set the squelch to open at a programmed setting of the S-Meter, thus reducing guesswork in setting the squelch threshold.

Congratulations on your purchase of the FTM-7250DR! Whether this is your first rig, or if Yaesu equipment is already the backbone of your station, the Yaesu organization is committed to ensuring your enjoyment of this high-performance transceiver. It should provide you with many years of satisfying operation. Our dealer network and technical support personnel stand behind every product we sell, and we invite you to contact us should you require technical advice or assistance.


We recommend that you read this manual in its entirety prior to installing the FTM-7250DR, so that you fully understand the capabilities of your new transceiver.

Accessories & Options

Supplied Accessories



DTMF Microphone MH-48A6JA




Mobile Mounting Bracket (Attachment screw set)



DC power cable w/Fuse

Spare fuse (15 A)



USB cable

Operating Manual

Optional Accessories

MH-42C6JMicrophoneMH-48A6JADTMF MicrophoneMLS-100High-Power External SpeakerFP-1030AAC Power Supply (USA market only)


Installation

Connecting the Microphone

Connect the supplied MH-48A6JA microphone to the FTM-7250DR.

Plug the microphone connector into the MIC jack on the front panel until it clicks.


Note: When disconnecting the microphone, pull the cable while pressing the connector latch.



Connecting the Antenna

Connect the coaxial cable to the body.

Plug the coaxial cable jack into the ANT terminal on the rear panel of the body, then rotate and tighten it.



Installation

Mobile Installation

The FTM-7250DR must only be installed in vehicles having a 13.8 Volt negative ground electrical system. Mount the transceiver where the display, controls, and microphone are easily accessible, using the supplied mounting bracket.

The transceiver may be installed in almost any location, but should not be positioned near a heating vent nor anywhere where it might interfere with driving (either visually or mechanically).

Make sure to provide plenty of space on all sides of the transceiver so that air can flow freely around the radio's case. Refer to the diagrams showing proper installation procedures.

