

E-Class Saloon

Operator's Manual

Mercedes-Benz





Front passenger airbag warning





WARNING Risk of injury or death due to an enabled co-driver airbag

If the co-driver airbag is enabled, a child on the co-driver seat may be struck by the codriver airbag during an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENA-BLED FRONT AIRBAG. DEATH or SERI-OUS INJURY to the CHILD can occur.

Observe the chapter "Children in the vehicle".

Welcome to the world of Mercedes-Benz

Before your first drive, please read this Owner's Manual carefully and familiarise yourself with your vehicle. For your own safety and a longer service life of the vehicle, follow the instructions and warning notices in this Owner's Manual. Disregarding them may lead to damage to the vehicle or injury to people.

The standard equipment and product description of your vehicle may vary and depends on the following factors:

- Model
- Order
- National version
- Availability

Your vehicle may therefore differ from that shown in the descriptions and illustrations in individual cases.

The illustrations in this Owner's Manual show a left-hand drive vehicle. On right-hand drive vehicles, the layout of vehicle parts and controls differs accordingly.

Mercedes-Benz is constantly developing its vehicles further.

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- Design
- Equipment
- · Technical features

The following documents are components of the vehicle:

- Digital Owner's Manual
- · Printed Owner's Manual
- · Service Booklet
- Supplementary manuals relating to specific equipment
- Supplementary documents

Keep these documents in the vehicle at all times. Ensure that all documents are in the vehicle or passed on in the event of sale or rental.



Symbols	5	Mercedes me App Operating safety Notes on assembling the number plate on		Notes on pets in the vehicle			
Indicator and warning lamps (with driver camera)	8 8 10 12 14 16 18 20	Notes on assembling the number plate on the front licence plate holder		Opening and closing Key Digital Vehicle Key Doors Boot Side windows Sliding sunroof Roller sunblinds Anti-theft protection Seats and stowing Notes on the correct driver's seat position Notes on grab handles	70 . 80 . 85 . 90 100 100		
Digital Owner's Manual Calling up the Digital Owner's Manual	22 22	Occupant safety	39	, ,	12		
General notes Protection of the environment Take-back of end-of-life vehicles Mercedes-Benz GenuineParts Touch-sensitive controls	23 23 23 24 25	Restraint system		Memory function Stowage areas Cup holders Sockets Wireless charging of the mobile phone and connection with the exterior aerial	129 140 140		

Fitting and removing floor mats	146	Vehicle towing instructions	302	System settingsAMG TRACK PACE	36
Light and sight Exterior lighting Interior lighting Windscreen wipers and windscreen washer system Mirrors	147 159 162 164	Driver's display	304 304 305 306 312	Fit & Healthy	37 41 44 44 45 46 46
Climate control Overview of climate control systems Operating the climate control system	168	Overview of status displays on the driver's display		Maintenance and care	46
Driving and parking	181 194 196 203	MBUX voice assistant Notes on operating safety Operation Using MBUX voice assistant effectively Essential voice commands	316 316 318	Maintenance Management Telediagnostics Engine compartment Cleaning and care	46 47
Refuelling	209 215 294	MBUX multimedia system Overview and operation MBUX Interior Assistant Driver camera	323 345	Breakdown assistance Emergency Flat tyre Battery (vehicle) Tow-starting or towing away	48 48 49

4 Contents

Electrical fuses	505
Wheels and tyres Notes on noise or unusual handling characteristics Notes on regularly inspecting wheels and tyres Notes on snow chains Activating or deactivating snow chain mode Tyre pressure Wheel change Emergency spare wheel	509 509 509 510 510 515 524
Technical data Notes on technical data On-board electronics Regulatory radio information Vehicle identification plate, VIN and engine number overview Operating fluids Vehicle data Trailer hitch	526 526 526 528 630 632 640 641

Display messages and warning/indicator lamps	64
Index	74

In this Owner's Manual, you will find the following symbols:

WARNING Danger due to not observing the warning notices

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

Observe the warning notices.



ENVIRONMENTAL NOTE Environmental damage due to failure to observe environmental notes

Environmental notes include information on environmentally responsible behaviour or environmentally responsible disposal.

Observe environmental notes.

NOTE Damage to property due to failure to observe notes on material damage

Notes on material damage inform you of risks which may lead to your vehicle being damaged.

- Observe notes on material damage.
- These symbols indicate useful instructions or further information that could be helpful to you.

Instruction

 $(\longrightarrow page)$

Further information on a topic

Display

Display in the central display




Highest menu level, which is to be selected in the multimedia system




Relevant submenus, which are to be selected in the multimedia system

Indicates a cause




Left-hand-drive vehicles

Steering wheel gearshift paddles	\rightarrow	201	ტ Switches the MBUX multimedia system	\rightarrow	323
Combination switch	\rightarrow	149	on/off		
Driver's display	\rightarrow	305	図 Switches sound on/off	\rightarrow	342
DIRECT SELECT lever	\rightarrow	196	Adjusts the volume		
ENGINE START / STOP START / STO	\rightarrow	182	• Hazard warning light system	\rightarrow	150
(A) ECO start/stop function	\rightarrow	192	Control panel for the MBUX multimedia system	\rightarrow	332
Central display	\rightarrow	323	Adjusts the steering wheel	\rightarrow	124
Glove compartment	\rightarrow	131	Control panel:		
Stowage compartment	\rightarrow	131	Driver's display	\rightarrow	305
Switch panel for:			Cruise control or variable limiter	\rightarrow	225
DYNAMIC SELECT button	\rightarrow	195	Active Distance Assist DISTRONIC	\rightarrow	231
Rative Parking Assist	\rightarrow	277	Diagnostics connection	\rightarrow	32
Switches the stationary heater on/off	\rightarrow	177	(5) Opening the bonnet	\rightarrow	471
Quick vehicle access		177	(e) Electric parking brake	\rightarrow	211
Fingerprint sensor	\rightarrow	334	Light switch	\rightarrow	147




Left-hand-drive vehicles

Steering wheel gearshift paddles	\rightarrow	201	Quick vehicle access		
② Combination switch	\rightarrow	149	Fingerprint sensor	\rightarrow	334
3 Driver's display	\rightarrow	305	U Switches the MBUX multimedia system	\rightarrow	323
DIRECT SELECT lever	\rightarrow	196	on/off		
Start/stop button	\rightarrow	182	図 Switches sound on/off	\rightarrow	342
(A) ECO start/stop function	\rightarrow	192	Adjusts the volume		
Selfie and video camera			Mazard warning light system	\rightarrow	150
MBUX hyperscreen with:			Control panel for the MBUX multimedia system	\rightarrow	332
Central display			Adjusts the steering wheel	\rightarrow	124
Front passenger display			Control panel:		
Glove compartment	\rightarrow	131	Driver's display	\rightarrow	305
Stowage compartment	\rightarrow	131	Cruise control or variable limiter	\rightarrow	225
Switch panel for:			Active Distance Assist DISTRONIC	\rightarrow	231
DYNAMIC SELECT button	\rightarrow	195	Diagnostics connection	\rightarrow	32
Active Parking Assist	\rightarrow	277	Opens the bonnet	\rightarrow	471
Switches the stationary heater on/off	\rightarrow	177	Electric parking brake	\rightarrow	211
		.,,	Light switch	\rightarrow	147




Driver's display

🚺 🗘 🗘 Turn signal lights	\rightarrow	149	[₹] ESP®	\rightarrow	
2 🛂 Trailer hitch	\rightarrow	733	Diesel engine: preglow		
③ 📳 Suspension (red)	\rightarrow	741	Petrol engine: reduced power	\rightarrow	
Suspension (yellow)	\rightarrow	741	© Loolant temperature	\rightarrow	
Electrical fault	\rightarrow	735	Coolant temperature display	\rightarrow	
	\rightarrow	733	[[\rightarrow	
⊚ ! Power steering (yellow)	\rightarrow	733	Electric parking brake (red)	\rightarrow	
Rear-axle steering (red)	\rightarrow	733	Brakes (red)	\rightarrow	
Rear-axle steering (yellow)	\rightarrow	733	(D) Brakes (yellow)	\rightarrow	
Restraint system	\rightarrow	731	Reserve fuel with fuel filler flap location	\rightarrow	
Seat belt	\rightarrow	731	indicator		
Distance warning	\rightarrow	741	Fuel level	\rightarrow	
ABS	\rightarrow	741	⊕ High beam	\rightarrow	
Tyre pressure monitoring system	\rightarrow	747	Low beam	\rightarrow	
	\rightarrow	735	⊋oo⊊ Parking lights	\rightarrow	
Engine diagnostics				\rightarrow	
ESP® OFF	\rightarrow	741	Mercedes-Benz emergency call system	\rightarrow	




Driver's display with driver camera

	\rightarrow	149	Fuel level	\rightarrow	308
Seat belt	\rightarrow	731		\rightarrow	148
3 🛕 Distance warning	\rightarrow	741		\rightarrow	149
Restraint system	\rightarrow	731	Low beam	\rightarrow	147
Tyre pressure monitoring system	\rightarrow	747	∋oc Parking lights	\rightarrow	147
	\rightarrow	741	Mercedes-Benz emergency call system	\rightarrow	746
₽ ESP®	\rightarrow	741	Trailer hitch	\rightarrow	733
ABS	\rightarrow	741	Electrical fault	\rightarrow	735
Diesel engine: preglow			② Engine diagnostics	\rightarrow	735
Coolant temperature	\rightarrow	735	② Power steering (red)	\rightarrow	733
Coolant temperature display	\rightarrow	308	⊕ ! Power steering (yellow)	\rightarrow	733
(I) Electric parking brake (yellow)	\rightarrow	739	Rear-axle steering (red)	\rightarrow	733
② Electric parking brake (red)	\rightarrow	739	Rear-axle steering (yellow)	\rightarrow	733
Brakes (red)	\rightarrow	739	Suspension (red)	\rightarrow	741
(D) Brakes (yellow)	\rightarrow	739	Suspension (yellow)	\rightarrow	741
Reserve fuel with fuel filler flap location indicator	\rightarrow	735			




	Sun visors			9	Opens/close
2	Switches the front interior lighting on/off	\rightarrow	159		roof
3	Switches the rear interior lighting on/off	\rightarrow	159		Opens/close roof front roller su
4	me button	\rightarrow	429	10	Indicator lamps:
5	Opens/closes the panorama sliding sun- roof rear roller sunblind	\rightarrow	102		PASSENGER AIR B
6	Switches automatic interior lighting con-	\rightarrow	159		REAR SEAT AIR BA
•	trol on/off		139	1	Inside rear-view m
7	€SOS button	\rightarrow	429	12	Switches the left-h
8	Switches the right-hand reading lamp on/off	\rightarrow	159		

Opens/closes the panorama sliding sun- roof	\rightarrow	102
Opens/closes the panorama sliding sunroof front roller sunblind	\rightarrow	102
Indicator lamps:		
PASSENGER AIR BAG	\rightarrow	49
REAR SEAT AIR BAG		
Inside rear-view mirror	\rightarrow	165
Switches the left-hand reading lamp on/off	\rightarrow	159



 \rightarrow

① ਰੋ Locks/unlocks the vehicle	\rightarrow	86	Opens/closes the rear left side window
Opens the door	\rightarrow	86	Opens/closes the left side window
Adjusts the seats electrically	\rightarrow	114	Adjusting the head restraints
Switching the seat heating on/off	\rightarrow	121	Seat adjustment using the multimedia system
Switching the seat ventilation on/off	\rightarrow	123	Adjusts the seat fore-and-aft position
Operating the memory function	\rightarrow	128	Adjusting the 4-way lumbar support
o ত্র্যা Opens/closes the tailgate	\rightarrow	93	Adjusting the seat backrest inclination
Operating the outside mirrors	\rightarrow	164	Adjusting the seat height
Opens/closes the right side window	\rightarrow	99	Adjusts the seat cushion inclination
Opens/closes the rear right side window	\rightarrow	99	
Child safety lock for the rear side windows	\rightarrow	73	



B-pillar with:			Tow-starting or towing away	\rightarrow	499
QR code for accessing the rescue card	\rightarrow	35	Flat tyre	\rightarrow	487
Safety vests	\rightarrow	485	Fuel filler flap with:		
3 Fire extinguisher	\rightarrow	487	information label on fuel type	\rightarrow	203
	\rightarrow	429	information label on tyre pressure	\rightarrow	511
ু sos] SOS button	\rightarrow	429	QR code for accessing the rescue card	\rightarrow	35
[<u>A</u>] Hazard warning lights	\rightarrow	150	Tow-starting or towing away	\rightarrow	499
Stowage compartment for customer literature			TIREFIT kit	\rightarrow	488
7 To check and top up operating fluids	\rightarrow	632	First-aid kit (soft sided)	\rightarrow	486
Starting assistance	\rightarrow	496	Warning triangle	\rightarrow	486

Calling up the Digital Owner's Manual

Multimedia system:

- → 🔝 >> Settings >> Info
- >> Owner's Manual
- >> Open Digital Owner's Manual

The Digital Owner's Manual describes the functions and operation of the vehicle and the multimedia system.

- Select one of the following menu items in the Digital Owner's Manual:
- Quick start: find the first steps towards adjusting your seat (driver's side).
- Tips: find information that prepares you for certain everyday situations with your vehicle.
- Animations: watch animations of the vehicle functions.
- Messages: receive additional information about the messages in the driver's display.
- Language: select the language for the Digital Owner's Manual.

You can search for keywords using the search field Search, in order to find quick answers to questions about the operation of the vehicle.



- Menu
- Search
- Back
- Contents section

Some sections in the Digital Owner's Manual, suchas warning notes, can be expanded and collapsed.

Additional methods of calling up the Digital Owner's Manual:

Driver's display: call up brief information as display messages in the driver's display

MBUX Voice Assistant: call up via the voice control system

For safety reasons, the Digital Owner's Manual is deactivated while driving.

Protection of the environment



ENVIRONMENTAL NOTE Environmental damage due to operating conditions and personal driving style

The pollutant emission of the vehicle is directly related to the way you operate the vehicle.

Operate your vehicle in an environmentally responsible manner to help protect the environment. Please observe the following recommendations on operating conditions and personal driving style.

Operating conditions:

- Make sure that the tyre pressure is correct.
- Do not carry any unnecessary weight (e.g. roof luggage racks once you no longer need them).
- Adhere to the service intervals.
 A regularly serviced vehicle will contribute to environmental protection.

Always have maintenance work carried out at a qualified specialist workshop.

Personal driving style:

- ▶ Do not depress the accelerator pedal when starting the engine.
- Do not warm up the vehicle while stationary.
- Drive carefully and maintain a suitable distance from the vehicle in front.
- Avoid frequent, sudden acceleration and braking.
- Change gear in good time and use each gear only up to ¾ of its maximum engine speed.
- Switch off the vehicle in stationary traffic, e.g. by using the ECO start/stop function.
- Drive in a fuel-efficient manner. Observe the ECO display for an economical driving style.

Take-back of end-of-life vehicles

EU countries only:

Mercedes-Benz will take back your end-of-life vehicle for environment-friendly disposal in accordance with the European Union (EU) End-Of-Life Vehicles Directive.

A network of vehicle take-back points and dismantlers has been established for you to return your vehicle. You can leave it at any of these points free of charge. This makes an important contribution to closing the recycling circle and conserving resources.

For further information about the recycling and disposal of end-of-life vehicles, and the take-back conditions, please visit the national Mercedes-Benz website for your country.

Mercedes-Benz GenuineParts



ENVIRONMENTAL NOTE Environmental damage caused by not using recycled reconditioned components

Mercedes-Benz AG offers recycled reconditioned components and parts with the same quality as new parts. The same entitlement from the implied warranty is valid as for new parts.

- Recycled reconditioned components and parts from Mercedes-Benz AG.
- I NOTE Impairment of the operating efficiency of the restraint systems from installing accessory parts or from repairs or welding

Airbags and seat belt tensioners, as well as control units and sensors for the restraint systems, may be installed in the following areas of your vehicle:

doors

- door pillars
- Sill
- Seats
- Cockpit
- Driver's display
- · Centre console
- · lateral roof frame
- Do not install accessory parts such as audio systems in these areas.
- Do not carry out repairs or welding.
- Have accessories retrofitted at a qualified specialist workshop.

You could jeopardise the operating safety of your vehicle if you use parts, tyres and wheels as well as accessories relevant to safety that have not been approved by Mercedes-Benz. Safety-critical systems (e.g. the brake system) may malfunction. Use only Mercedes-Benz GenuineParts or parts of equal quality. Use only tyres, wheels and accessory parts that have been specifically approved for your vehicle model.

Mercedes-Benz tests original parts and conversion parts and accessory parts that have been specifically approved for your vehicle model for their reliability, safety and suitability. Despite ongoing market research, Mercedes-Benz is unable to assess other parts. Mercedes-Benz therefore accepts no responsibility for the use of such parts in Mercedes-Benz vehicles, even if they have been officially approved or independently approved by a testing centre.

Certain parts are officially approved for installation or modification only if they comply with legal requirements. All Mercedes-Benz GenuineParts meet the approval requirements. The use of nonapproved parts may invalidate the vehicle's general operating permit.

This is the case in the following situations:

- The vehicle type is different from that for which the vehicle's general operating permit was granted.
- Other road users could be endangered.
- The exhaust gas or noise level gets worse.

Always specify the vehicle identification number (VIN) (→ page 630) when ordering Mercedes-Benz GenuineParts.

Touch-sensitive controls

In addition to conventional switches and buttons. your vehicle is equipped with touch-sensitive controls.

These are located in the following areas of your vehicle:

- Roof and door control panel
- Climate control
- · Steering wheel
- MBUX multimedia system

The controls have touch-sensitive user interface surfaces. The surfaces are controlled by pressing or swiping to adjust settings or to trigger functions, forexample.

In the area of the touchscreen, you also receive haptic feedback in the form of a pulse or a vibration, or the surface structure changes on the

touch-sensitive user interface surface, forexample.

You receive haptic feedback in the following situations, forexample:

- When pressing a button on the user interface surface
- When scrolling in a list or table
- When reaching a new area on the user interface surface, e.g. a pop-up window

When handling touch-sensitive user interface surfaces, observe the following points to avoid problems operating:

- · Do not affix stickers or similar objects on the surfaces
- Keep the surfaces protected from moisture and wet conditions.
- · Keep the surfaces free of dust and dirt $(\rightarrow page 482)$.

Some touch-sensitive control elements have a symbol and integrated indicator lamps. When operating, make sure to press on the symbol of the control element.

Mercedes me App

Notes about the on-demand feature

You can also activate various functions (ondemand feature) subsequently via Mercedes me after purchasing your vehicle.

Information is available at any Mercedes-Benz Service Centre.

Activating on-demand feature using Mercedes me

Requirements:

- The vehicle has a wireless connection.
- The vehicle is linked to the Mercedes me user. account.

Ordering and activating on-demand feature

- Add the desired on-demand feature for the vehicle to the shopping basket in the Mercedes me Store.
- Complete the order. The on-demand feature is activated when operating the vehicle.

Speeding up activation

- Switch the vehicle off and lock it.
- Unlock the vehicle after about two minutes and switch on the vehicle.
 The on-demand feature has been activated.
 For some features, a notification also appears in the vehicle's multimedia system.

If the activation was not successful, repeat the process.

Operating safety

WARNING Risk of accident due to malfunctions or system failures

If you do not have the prescribed service/ maintenance work or any required repairs carried out, this could result in malfunctions or system failures.

Always have the prescribed service- and maintenance work or any required repairs carried out in a qualified workshop.

WARNING Risk of accident or injury due to improper modifications to electronic components

Modifications to electronic components, their software or wiring can impair their functionality and/or the functionality of other networked components or safety-relevant systems.

This can endanger the vehicle's operating safety.

- You must not tamper with wiring, electronic components, or their software.
- Always have work on electrical and electronic devices carried out at a qualified specialist workshop.

If you modify the on-board electronics, the general operating permit is rendered invalid.

Observe the "On-board electronics" section in "Technical data".

WARNING Risk of fire due to flammable material coming into contact with hot parts of the exhaust system

If combustible materials, e.g. leaves, grass or twigs, come into contact with hot parts of the exhaust system, they may ignite.

- When driving off-road or on unpaved surfaces, check the underside of the vehicle at regular intervals.
- In particular, remove any trapped parts of plants or other flammable material.
- If damage should occur, immediately inform a qualified specialist workshop.

NOTE Damage to the vehicle due to driving too fast and due to impacts to the vehicle underbody or suspension components

In the following situations, in particular, there is a risk of damage to the vehicle:

- the vehicle becomes grounded, e.g. on a high kerb or an unpaved road
- the vehicle is driven too fast over an obstacle, e.g. a kerb, speed bump or pothole
- a heavy object strikes the underbody or suspension components

In situations such as these, damage to the body, underbody, suspension components, wheels or tyres may not be visible. Components damaged in this way can unexpectedly fail or, in the case of an accident, may no longer absorb the resulting force as intended.

If the underbody panelling is damaged, flammable materials such as leaves, grass or twigs can collect between the underbody and the underbody panelling. These materials may ignite if they come into contact with hot parts of the exhaust system.

Have the vehicle checked and repaired immediately at a qualified specialist workshop.

or

If driving safety is impaired while continuing your journey, pull over and stop the vehicle immediately, while paying attention to road and traffic conditions, and contact a qualified specialist workshop.

Vehicles with a 48 V on-board electrical system

A

DANGER Risk of fatal injury by touching damaged high-voltage components


Vehicles with a 48 V on-board electrical system contain individual high-voltage components. These high-voltage components are under high voltage.

If you modify component parts of these highvoltage components or touch damaged component parts, you may be electrocuted.

High voltage components may be damaged in an accident, although the damage may not be visible.

- Never perform modifications to component parts of high-voltage components.
- Never touch damaged component parts of high-voltage components.
- Never touch component parts of highvoltage components after an accident.

Vehicles with a 48 V on-board electrical system contain high-voltage components. These components are marked with a high-voltage label:



All work on high voltage components must be carried out at a qualified specialist workshop.

Notes on assembling the number plate on the front licence plate holder

NOTE Malfunctions and system failures due to incorrect assembly of the licence plate on the front licence plate holder

If the licence plate is incorrectly assembled on the front licence plate holder, sensors, cameras or driving and safety systems may malfunction or fail. Observe the following points when assembling the licence plate on the front licence plate holder:

- Assemble the licence plate directly on the licence plate holder without advertising media or other holders.
- Assemble the licence plate so that it does not protrude above or to the side of the licence plate adapter.

Declarations of conformity and notes on driving in different countries

Electromagnetic compatibility

The electromagnetic compatibility of the vehicle components has been checked and certified according to the currently valid version of Regulation UN-R 10.

National information for components subject to radio regulations

Only for EU and EFTA countries and countries that recognise the EU manufacturer's declaration of conformity:



The following information applies to all wireless components of the vehicle and of the information systems and communication devices integrated in the vehicle:

The manufacturers of the wireless components ensure that all wireless components installed in the vehicle comply with Directive 2014/53/EU. The full texts of the EU declarations of conformity are available at the following web address:

https://moba.i.mercedes-benz.com/markets/ece-row/baix/cars/certificates-of-conformity/en_GB/index.html



You can obtain further information from a Mercedes-Benz service centre.

For Israel only:

It is prohibited to make any change to a vehicleinstalled radio component that could affect the wireless specifications of the device, including software changes, replacement of the original antenna, or adding the option to connect the device to an external antenna, without first obtaining approval from the Communica-tions Ministry, because of concern about wireless interference.

For the United Kingdom only:



The following information applies to all wireless components of the vehicle and of the information systems and communication devices integrated in the vehicle:

The manufacturers of the radio components declare that all radio equipment installed in the vehicle is in compliance with the relevant statutory requirements. The full texts of the declarations of conformity are available at the following web address:

https://moba.i.mercedes-benz.com/markets/ ece-row/baix/cars/certificates-of-conformity/ en GB/index.html



For Brazil only:



Note on two-way radio systems in the vehicle:

These systems are not protected against harmful interference and must not cause interference in properly approved systems.

For Jamaica only:

All wireless vehicle components have received type approval from the SMA.

For Nigeria only:

Connection and use of this communications equipment is permitted by the Nigerian Communications Commission

Connection and use of the radio communications equipment in this vehicle is permitted by the Nigerian Communications Commission

For Russia only:



The manufacturers of the wireless components installed in the vehicle hereby declare that all wireless components installed in the vehicle comply with the technical regulations for two-way radios. You can obtain further information from a Mercedes-Benz service centre.

For Ukraine only:



The manufacturers of the wireless components installed in the vehicle hereby declare that the wireless components installed in the vehicle comply with the technical regulations for two-way radios. You can obtain further information from a Mercedes-Benz service centre.

lack

Copy and translation of the original declaration of conformity:

EC declaration of conformity

The undersigned, representing

Manufacturer:

BRANO a s

747 41 Hradec nad Moravicí, Opavská 1000,

The Czech Republic

ID No.: 64-387-5933

VAT No.: CZ64-387-5933

herewith declares under our sole responsibility that the product:

2. a)

Name:

lack

Type, Number:

A) A 164 580 02 18, A 166 580 01 18

B) A 240 580 00 18

C) A 639 580 02 18

D) A 639 580 03 18

E) A 910 580 00 00

F) A 247 580 00 00, A 293 580 00 00

G) A 247 580 01 00, A 293 580 01 00

H) A 247 580 02 00, A 293 580 02 00

Year of manufacture: 2022

Complies with all relevant provisions

Directive No. 2006/42/EC

b)

Description and purpose of use:

Car jack is intended solely for lifting of the concrete car, in accordance with the instruction label on the car jack.

3.

References of harmonized and other standards or specifications

ISO 4063, EN ISO 14341-A, AS 2693, DBL 8230.10, DBL 7382.20, DBL 7392.10, DBL 8451.15, MBN 10435.

Technical documentation of the product is stored at the premise of the manufacturer. The person responsible for assembling the technical documentation of the product: Head of the Technical Department Brano a.s.

4.

Hradec nad Moravicí

Place

5.

14.03.2022

Date

Dipl. Engineer Michal Koberský

[Signature]

Director SBU-CJ

TIREFIT kit

Copy and translation of the original declaration of conformity:

EC declaration of conformity

In accordance with EC Directive 2006/42/EC

We hereby declare that the product

Product designation: Daimler electric air pump

Model designation: 0872, DT/UW 200077 - IBK-LK2P

MB part no.: A 000 583 9204

complies with the following relevant regulations:

2014/30/EU

Applied harmonised standards, in particular:

DIN EN 55014-1: 2017 DIN EN 55014-2: 2015

Manufacturer: Dunlop Tech GmbH

Address: Offenbacher Landstrasse. 8, 63456

Hanau

Authorised representative: IMS dept.

Date: March 2020

Signature: IMS-AE, IMS-AE-L

Diagnostics connection

The diagnostics connection is a technical interface in the vehicle. It is used, for example, during repair and maintenance work or for reading out vehicle data in a specialist workshop. Diagnostic devices should therefore only be connected in a qualified specialist workshop.

WARNING Risk of accident due to connecting devices to the diagnostics connection

If you connect devices to the diagnostics connection of the vehicle, the function of vehicle systems and operating safety may be impaired.

For safety reasons, we recommend that you only use and connect products approved by a Mercedes-Benz service centre. WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.


- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.
- NOTE Battery discharging from using devices connected to the diagnostics connection

Using devices at the diagnostics connection drains the battery.

Check the charge level of the battery.

If the charge level is low, charge the battery, e.g. by driving a considerable distance.

Please also note the information about the 12 V battery and short-distance trips in the "Driving and Parking" chapter (\rightarrow page 187).



33

Connecting and using another device with the diagnostics connection can have the following effects:

- Malfunctions in the vehicle system
- Permanent damage to vehicle components

Please refer to the warranty terms and conditions for this matter.

Moreover, connecting equipment to the diagnostics connection can lead to emissions monitoring information being reset, for example. This may lead to the vehicle failing to meet the requirements of the next emissions inspection during the main inspection.

Qualified specialist workshop

A qualified specialist workshop has the necessary special skills, tools and qualifications to correctly carry out any necessary work on your vehicle. This particularly applies to safety-relevant work.

Always have the following work carried out on your vehicle at a qualified specialist workshop:

Safety-relevant work

- Service and maintenance work
- Repair work
- Modifications as well as installations and conversions
- Work on electronic components
- Vehicles with 48 V on-board electrical system: work on the high-voltage component of the 48 V on-board electrical system

Mercedes-Benz recommends a Mercedes-Benz service centre.

Vehicle registration

Mercedes-Benz may ask its service centres to carry out technical inspections on certain vehicles. The quality or safety of the vehicle is improved as a result of the inspection.

Mercedes-Benz can only inform you about vehicle checks if Mercedes-Benz has your registration data.

It is possible that your vehicle has not yet been registered in your name in the following cases:

- if your vehicle was not purchased at an authorised specialist dealer.
- if your vehicle has not yet been examined at a Mercedes-Benz service centre.

It is advisable to register your vehicle with a Mercedes-Benz service centre.

Inform Mercedes-Benz as soon as possible about any change in address or vehicle ownership. You can do this at a Mercedes-Benz service centre. for example.

Correct use of the vehicle

If you remove any warning stickers, you or others could fail to recognise certain dangers. Leave warning stickers in position.

Observe the following information in particular when driving your vehicle:

• the safety notes in this Owner's Manual, vehicle-specific supplements and further supplementary documents

- technical data for the vehicle
- traffic rules and -regulations
- laws and safety standards pertaining to motor vehicles

Information on the REACH regulation

EU and EFTA countries only:

the REACH regulation (Regulation (EC) No. 1907/2006, Article 33) stipulates a duty to supply information about substances of very high concern (SVHCs).

Mercedes-Benz AG acts to the best of its knowledge to prevent these SVHCs from being used and to enable customers to safely handle these substances. There are SVHCs known to Mercedes-Benz AG, according to supplier information and internal product information, found in individual components of this vehicle in quantities of over 0.1 percent by weight.

Further information can be obtained at the following addresses:

https://reach.daimler.com/de/home/

https://reach.daimler.com/en/home/

Notes for persons with electronic medical aids

Mercedes-Benz AG cannot, despite carefully developing vehicle systems, completely rule out the interaction of vehicle systems with electronic medical aids such as cardiac pacemakers.

In addition, there are components installed in the vehicle that, regardless of the operating status of the vehicle, can generate magnetic fields on a par with permanent magnets. These fields can be found, for example, in the area around the multimedia and sound system or also in the area of the seats, depending on the vehicle equipment.

For this reason, the following can occur in isolated cases, depending on the aids used:

- · Medical aids malfunctioning
- · Adverse health effects

Observe the notes and warnings of the manufacturer of the medical aids; if in doubt, contact the device manufacturer and/or your doctor. If there is continuing uncertainty concerning the possibility of medical aids malfunctioning, Mercedes-

Benz AG recommends using only few electrical vehicle systems and/or maintaining a distance from the components.

Only have repairs and maintenance work in the area of the following components carried out at a qualified specialist workshop:

- · vehicle components carrying live voltage
- transmission aerials
- multimedia system and sound system

If you have any queries or suggestions, consult a qualified specialist workshop.

Implied warranty

!

NOTE Damage to the vehicle arising from violation of these operating instructions.

Damage to the vehicle can arise from violation of these operating instructions.

This damage is not covered either by the Mercedes-Benz implied warranty or by the New- or Used-Vehicle Warranty.

Follow the instructions in these operating instructions on proper operation of your vehicle as well as on possible vehicle damage.

QR code for rescue card

QR codes are attached in the fuel filler flap and on the opposite side on the B-pillar. In the event of an accident, rescue services can use the QR code to guickly find the appropriate rescue card for your vehicle. The current rescue card contains the most important information about your vehicle (e.g. the routing of the electric lines) in compact form.

Further information can be obtained at https:// www.mercedes-benz.de/gr-code

Data storage

Data processing in the vehicle

Electronic control units

Electronic control units are fitted in your vehicle. Control units process data which, for example,

they receive from vehicle sensors, generate themselves or exchange between themselves. Some control units are required for the safe operation of your vehicle, some assist you when driving, suchas driver assistance systems, while others enable convenience or infotainment functions.

The following provides you with general information regarding data processing in the vehicle. Additional information regarding exactly which data in your vehicle are collected, saved and transmitted to third parties, and for what purpose, can be found in the information directly related to the functional characteristics in question in their respective operating instructions. This information is also available online and, depending on the vehicle equipment, digitally.

Personal data

Every vehicle is identified by a unique vehicle identification number. Depending on the country, this vehicle identification number can be used by, forexample, governmental authorities to determine the identity of the owner. There are other possibilities to use data collected from the vehicle to identify the owner or driver, such as the licence plate number.

Therefore, data generated or processed by control units may be attributable to a person or, under certain conditions, become attributable to a person. Depending on which vehicle data are available, it may be possible to make inferences about, forexample, your driving behaviour, your location, your route or your use patterns.

Legal requirements regarding the disclosure of data

If legally required to do so, manufacturers are, in individual cases, legally obliged to provide governmental entities, upon request and to the extent required, data stored by the manufacturer. Forexample, this may be the case during the investigation of a criminal offence.

Governmental entities are themselves, in individual cases and within the applicable legal framework, authorised to read out data from the vehicle. In the case of an accident, information that can help with an investigation can, therefore, be taken from the airbag control unit, forexample.

Operational data in the vehicle

This is data regarding the operation of the vehicle, which have been processed by control units.

This includes the following data, forexample:

- vehicle status information suchas the speed, longitudinal acceleration, lateral acceleration, number of wheel revolutions or the fastened seat belts display
- ambient conditions, suchas temperature, rain sensor or distance sensor

Generally, the use of these data is temporary; they will not be stored beyond the period of operation and will only be processed within the vehicle itself. Control units often contain data memories for vehicle keys, forexample. Their use permits the temporary or permanent documentation of technical information about the vehicle's operating state, component loads, maintenance requirements and technical events or faults.

Depending on the vehicle equipment, the following data are stored:

- operating status of system components, suchas fill levels, tyre pressure or battery status
- malfunctions or faults in important system components, suchas lights or brakes

- system reactions in special driving situations, suchas airbag deployment or the intervention of stability control systems
- information on events leading to vehicle damage

In certain cases, it may be required to store data that would have otherwise been used only temporarily. This may be the case if the vehicle has detected a malfunction, forexample.

If you use services, suchas repair services and maintenance work, stored operational data as well as the vehicle identification number can be read out and used. They can be read out by service network employees, suchas workshops and manufacturers or third parties, suchas breakdown services. The same is true in the case of warranty claims and quality assurance measures.

In general, the readout is performed via the legally prescribed port for the diagnostics connection in the vehicle. The operational data that are read out document technical states of the vehicle or of individual components and assist in the diagnosis of malfunctions, compliance with warranty obligations and quality improvement. To that end, these

data, in particular information about component loads, technical events, malfunctions and other faults may be transmitted along with the vehicle identification number to the manufacturer. Furthermore, the manufacturer is subject to product liability. For this reason the manufacturer also uses operational data from the vehicle, forexample, for recalls. These data can also be used to examine the customer's warranty and guarantee claims.

Fault memories in the vehicle can be reset by a service outlet or at your request as part of repair or maintenance work.

Convenience and infotainment functions

You can store convenience settings and individual settings in the vehicle and change or reset them at any time.

Depending on the vehicle equipment, this includes the following settings, forexample:

- seat and steering wheel positions
- suspension and climate control settings
- · individual settings, such as interior lighting

Depending on the selected equipment, you can import data into vehicle infotainment functions yourself.

Depending on the vehicle equipment, this includes the following data, forexample:

- multimedia data, suchas music, films or photos for playback in an integrated multimedia system
- address book data for use in connection with an integrated hands-free system or an integrated navigation system
- · entered navigation destinations
- data about the use of Internet services

These data for convenience and infotainment functions may be saved locally in the vehicle or they may be located on a device which you have connected to the vehicle, suchas a smartphone, USB flash drive or MP3 player. If you have entered these data yourself, you can delete them at any time.

This data is transmitted from the vehicle to third parties only at your request. This applies, in par-

ticular, when you use online services in accordance with the settings that you have selected.

Smartphone integration (e.g. Android Auto or Apple CarPlay®)

If your vehicle is accordingly equipped, you can connect your smartphone or another mobile end device to the vehicle. You can then control them by means of the control elements integrated in the vehicle. Images and audio from the smartphone can be output via the multimedia system. Certain information is simultaneously transferred to your smartphone. Depending on the type and integration, thisincludes position data, day/night mode and other general vehicle statuses. For more information please consult the Owner's Manual of the vehicle/infotainment system.

This integration allows the use of selected smartphone apps, suchas navigation or music player apps. There is no further interaction between the smartphone and the vehicle; in particular, vehicle data is not directly accessible. The type of additional data processing is determined by the provider of the app being used. Which settings you can make, if any, depends on the specific app and the operating system of your smartphone.

Online services

Wireless network connection

If your vehicle has a wireless network connection, it enables data to be exchanged between your vehicle and additional systems. The wireless network connection is made possible by the vehicle's own transmitter and receiver or by a mobile end device that you have brought into the vehicle, forexample, a smartphone. Online functions can be used via the wireless network connection. This includes online services and applications/apps provided to you by the manufacturer or by other providers.

Manufacturer's services

Regarding the manufacturer's online services, the individual functions are described by the manufacturer in a suitable place, forexample, in the Owner's Manual or on the manufacturer's website, where the relevant data protection information is also given. Personal data may be used for the provision of online services. Data are exchanged via a secure connection, suchas the manufacturer's designated IT systems. Any personal data which are collected, processed and

used, other than for the provision of services, is done so exclusively on the basis of legal permission. This is the case, forexample, for a legally prescribed emergency call system, a contractual agreement or when consent has been given.

You can have services and functions, some of which are subject to a fee, activated or deactivated. This excludes legally prescribed functions and services, suchas an emergency call system.

Third party services

If you use online services from other providers (third parties), these services are the responsibility of the provider in question and subject to that provider's data protection conditions and terms of use. As a general rule, the manufacturer has no influence on the content exchanged.

For this reason, when services are provided by third parties, please ask the service provider in question for information about the type, extent and purpose of the collection and use of personal data.

Data protection rights

Depending on your country or the equipment and range of functions of your vehicle as well as the services you use and the services on offer, you are entitled to different data protection rights. Further information on data protection and your data protection rights can either be found on the manufacturer's website or you will receive this information as part of the various services and service offers. There you will also find the contact information for the manufacturer and its data protection officers.

At a workshop, forexample, with the support of a specialist and possibly for a fee, you can have data read out which is stored only locally in the vehicle.

Copyright

Information on licences for free and open-source software used in your vehicle can be found on the data carrier in your vehicle document wallet and with updates on the following website:

https://www.mercedes-benz.com/opensource

Restraint system

Protection provided by the restraint system

The restraint system includes the following components:

- Seat belt system
- Airbags
- · Child restraint system
- · Child seat anchors

The restraint system can help prevent the vehicle occupants from coming into contact with parts of the vehicle interior in the event of an accident. In the event of an accident, the restraint system can also reduce the forces to which the vehicle occupants are subjected.

A seat belt can only provide the best level of protection if it is worn correctly. Depending on the detected accident situation, seat belt tensioners and/or airbags supplement the protection offered by a correctly worn seat belt. Seat belt tensioners and/or airbags are not deployed in every accident.

In order for the restraint system to provide the intended level of protection, each vehicle occupant must observe the following information:

- · Fasten seat belts correctly.
- Sit in an almost upright seat position with their back against the seat backrest.
- Sit with their feet resting on the floor, if possible.
- Always secure persons under 1.50 m tall in an additional restraint system suitable for Mercedes-Benz vehicles.

However, no system available today can completely eliminate injuries and fatalities in every accident situation. In particular, the seat belt and airbag generally do not protect against objects penetrating the vehicle from the outside. It is also not possible to completely rule out the risk of injury caused by the airbag deploying.

Limitations of the protection provided by the restraint system



WARNING Risk of injury or death due to modifications to the restraint system

Vehicle occupants may no longer be protected as intended if alterations are made to the restraint system.

- Never alter the parts of the restraint system.
- Never tamper with the wiring or any electronic component parts or their software.

If it is necessary to modify the vehicle to accommodate a person with disabilities, contact a qualified specialist workshop.

Mercedes-Benz recommends that you use driving aids which have been approved for your vehicle by Mercedes-Benz.

Restraint system functionality

When the vehicle is switched on, a self-test is performed, during which the restraint system warning lamp lights up. It goes out no later than a few seconds after the vehicle is started. The components of the restraint system are then functional.

Malfunctioning restraint system

A malfunction has occurred in the restraint system if:

- the prestraint system warning lamp does not light up when the vehicle is switched on
- the prestraint system warning lamp lights up continuously or repeatedly during a journey

WARNING Risk of injury due to malfunctions in the restraint system

Components in the restraint system may be activated unintentionally or not deploy as intended in an accident.

Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Function of the restraint system in an accident

How the restraint system works depends on the severity of the impact detected and the apparent type of accident:

- Frontal impact
- Rear impact
- Side impact
- Rollover

The activation thresholds for the components of the restraint system are determined based on the evaluation of the sensor values measured at various points in the vehicle. This process is pre-emptive in nature. The triggering/deployment of the components of the restraint system must take place in good time at the start of the collision.

Factors which can only be seen and measured after a collision has occurred cannot play a decisive role in airbag deployment. Nor do they provide an indication of airbag deployment.

The vehicle may be deformed significantly without an airbag being deployed. This is the case if only parts which are relatively easily deformed are affected and the rate of vehicle deceleration is not high. Conversely, an airbag may be deployed even though the vehicle suffers only minor deformation. If very rigid vehicle parts such as longitudinal members are hit, this may result in sufficiently high levels of vehicle deceleration.

Depending on the detected deployment situation, the components of the restraint system can be activated or deployed independently of each other:

- Seat belt tensioner: frontal impact, rear impact, side impact, rollover
- Driver's airbag, front passenger airbag: frontal impact
- Knee airbag: frontal impact
- Side airbag: side impact
- Centre airbag: side impact

- Window airbag: side impact, rollover, frontal impact
- PRE-SAFE® Impulse Side: side impact

Only when the PASSENGER AIR BAG OFF indicator lamp is off can the front passenger airbag deploy in the event of an accident. If the front passenger seat is occupied, make sure, both before and during the journey, that the status of the front passenger airbag is correct $(\rightarrow page 49).$



WARNING Risk of burns from hot airbag components

The airbag parts are hot after an airbag has been deployed.

- Do not touch the airbag parts.
- Have a deployed airbag replaced at a qualified specialist workshop as soon as possible.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop after an accident. Take this into account, particularly if a seat belt tensioner is triggered or an airbag deployed.

If the seat belt tensioners are triggered or an airbag is deployed, you will hear a bang, and a small amount of powder may also be released:

- The bang will not generally affect your hearing.
- In general, the powder released is not hazardous to health but may cause short-term breathing difficulties to persons suffering from asthma or other pulmonary conditions.

Provided it is safe to do so, leave the vehicle immediately or open the window in order to prevent breathing difficulties.

Seat belts

Protection provided by the seat belt

Always fasten your seat belt correctly before starting a journey. A seat belt can only provide the best level of protection if it is worn correctly.

WARNING Risk of injury or death due to incorrectly fastened seat belt

If the seat belt is not worn correctly, it cannot perform its intended protective function.

In addition, an incorrectly fastened seat belt can also cause injuries, for example, in the event of an accident or when braking or changing direction suddenly.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly.

Always observe the instructions about the correct driver's seat position and adjusting the seat $(\rightarrow page 111).$

In order for the correctly worn seat belt to provide the intended level of protection, each vehicle occupant must observe the following information:

- The seat belt must not be twisted and must fit tightly and snugly across the body.
- The seat belt must be routed across the centre of the shoulder and as low down across the hips as possible.

- The shoulder section of the seat belt should not touch your neck nor be routed under your arm or behind your back.
- Avoid wearing bulky clothing, e.g. a winter coat.
- Push the lap belt down as far as possible across your hips and pull tight with the shoulder section of the belt. Never route the lap belt across your abdomen.

Pregnant women must also take particular care with this.

- Never route the seat belt across sharp, pointed, abrasive or fragile objects.
- Only one person should use each seat belt at any one time.
- Never secure objects with a seat belt if the seat belt is also being used by one of the vehicle's occupants.

Also ensure that no objects, e.g. a cushion, are ever placed between a person and the seat.

If children are travelling in the vehicle, be sure to observe the instructions and safety notes on "Children in the vehicle" (\rightarrow page 54).

Always observe the instructions for loading the vehicle when securing objects, luggage or loads (\rightarrow page 129).

Limitations of the protection provided by the seat belt

A

WARNING Risk of injury or death due to incorrect seat position

The seat belt will not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you may slip under the seatbelt and injure yourself.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is

routed across the centre of your shoulder.

A

WARNING Risk of injury or death when additional restraint systems are not used for persons with a smaller stature

Persons under 1.50 m tall cannot wear the seat belt correctly without a suitable additional restraint system.

Always secure persons under 1.50 m tall in a suitable restraint system.

A

WARNING Risk of injury or death due to damaged or modified seat belts

Seat belts cannot provide protection in the following situations:

- the seat belt is damaged, has been modified, is extremely dirty, bleached or dyed
- the seat belt buckle is damaged or extremely dirty

43

 modifications have been made to the seat belt tensioner, seat belt anchorage or seat belt retractor

Seat belts may sustain non-visible damage in an accident, e.g. due to glass splinters.

Modified or damaged seat belts could tear or fail in the event of an accident, for example.

Modified seat belt tensioners could accidentally trigger or fail to function as intended.

- Never modify the seat belt system, for example the seat belt, seat belt buckle, seat belt tensioner, seat belt anchorage and seat belt retractor.
- Make sure that the seat belts are undamaged, not worn and clean.
- Always have the seat belts checked immediately after an accident at a qualified specialist workshop.

Mercedes-Benz recommends that you use seat belts which have been approved for your vehicle by Mercedes-Benz.

WARNING Risk of injury or death from deployed pyrotechnic seat belt tensioners

Pyrotechnic seat belt tensioners that have been deployed are no longer operational and are unable to perform their intended protective function.

Therefore, have deployed pyrotechnic seat belt tensioners immediately replaced at a qualified specialist workshop.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop after an accident.

NOTE Damage caused by trapping the seat belt

If an unused seat belt is not fully retracted, it may become trapped in the door or in the seat mechanism.

Always ensure that an unused seat belt is fully retracted.

Fastening and adjusting seat belts

If the seat belt is pulled quickly or sharply, the seat belt retractor locks. The seat belt strap cannot be pulled out any further.



Always engage seat belt tongue 1 of the seat belt into seat belt buckle 2 of the corresponding seat.

44 Occupant safety

- To adjust the seat belt height: press button
 on the seat belt outlet and slide the seat belt outlet to the desired position.
- To engage the seat belt outlet: release button and ensure that the seat belt outlet engages.
- A seat belt can only provide the best level of protection if it is worn correctly. Observe the notes on fastening the seat belt (→ page 41).
- NOTE Deployment of components of the restraint system when the front passenger seat is unoccupied and a seat belt is buckled

When the front passenger seat is unoccupied and the seat belt tongue of the seat belt is engaged in the seat belt buckle, components of the restraint system may deploy unnecessarily on the front passenger side, e.g. the seat belt tensioner.

- Only buckle the seat belts as intended.
- Observe the notes on stowage areas (→ page 129).

Information on fitting a child restraint system and on children travelling in the vehicle can be found in the "Children in the vehicle" section (\rightarrow page 58).

Seat belt adjustment function

Vehicles with PRE-SAFE®: after a front seat belt has been fastened, the automatic seat belt adjustment may apply a certain tightening force. Do not hold the seat belt tightly while it is adjusting.

You can activate and deactivate the seat belt adjustment function using the multimedia system (\rightarrow page 44).

Activating/deactivating seat belt adjustment via the multimedia system

Multimedia system:

- Activate or deactivate Belt adju
- Activate or deactivate Belt adjustment.

Releasing seat belts

Press the release button in the seat belt buckle and guide the seat belt back with the seat belt tongue.

Seat belt warning function for the driver and front passenger

In addition, a warning tone may sound.

As soon as the driver and front passenger fasten their seat belts, the seat belt warning goes out.

Function of the rear seat belt status display

The rear seat belt status display is only available for certain countries.

The rear seat belt status display in the driver's display is a reminder that all vehicle occupants must wear their seat belts correctly.

In addition, a warning tone may sound.

45

If a person unfastens a seat belt in the rear passenger compartment while the vehicle is motion, the rear seat belt status display appears again.

Display in the driver's display



Depending on the vehicle equipment, you can determine the status of the rear seat belt by the colour of the seat symbol in the driver's display as follows:

· Vehicles with seat occupancy recognition in the rear passenger compartment (seat belt warning)

When the vehicle is switched on, if one of the rear seats is occupied and the seat belt tongue of the rear seat belt is not engaged in the seat belt buckle of the corresponding seat, the status display for the rear seat belt is displayed.

- Grey: the rear seat is unoccupied.
- Green: the seat belt tongue of a rear seat belt is engaged in the seat belt buckle of the displayed seat.
- Red: the seat belt of the person in the rear seat is not fastened.

The seat belt warning goes out as soon as the seat belt of the person in the rear seat is fastened.

 Vehicles without seat occupancy recognition in the rear passenger compartment


Every time the vehicle is switched on, the rear seat belt status display informs you for a certain amount of time which rear seat belt is not fastened.

Grey: the rear seat belt is not fastened.

- Green: the seat belt tongue of a rear seat belt is engaged in the seat belt buckle of the displayed seat.
- Red: the person in the rear seat has unfastened their seatbelt.

Airbags

Overview of airbags



- Front passenger knee airbag1
- Driver's knee airbag
- Driver's airbag
- Front passenger airbag

- Window airbag
- Side airbag
- Centre airbag¹

1) Only for certain countries.

The installation location of an airbag is identified by the AIRBAG symbol. An additional arrow symbol ▶ indicates the installation location for certain airbags.

When enabled, an airbag can provide additional protection for the respective vehicle occupant.

Potential protection provided by each airbag:

- . Knee airbag: thigh, knee and lower leg
- Driver's airbag, front passenger airbag: head and ribcage
- Window airbag: head
- Side airbag: ribcage, also pelvis for front seat occupants
- Centre airbag: head and ribcage

Information on child restraint systems on the front passenger seat

A

WARNING Risk of injury or death due to an enabled co-driver airbag

If the co-driver airbag is enabled, a child on the co-driver seat may be struck by the codriver airbag during an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENA-BLED FRONT AIRBAG. DEATH or SERI-OUS INJURY to the CHILD can occur.

When fitting a child restraint system to the front passenger seat, observe the vehicle-specific information (\rightarrow page 71). Also, always observe the notes on rearward-facing or forward-facing child restraint systems on the front passenger seat (\rightarrow page 70).

Information on the automatic front passenger airbag shutoff

Only when the PASSENGER AIR BAG OFF indicator lamp is off can the front passenger airbag deploy in the event of an accident. If the front

passenger seat is occupied, make sure, both before and during the journey, that the status of the front passenger airbag is correct $(\rightarrow$ page 49).

! NOTE Deployment of components of the restraint system when the front passenger seat is unoccupied

In an accident, the components of the restraint system may deploy unnecessarily on the front passenger side if:

- There are heavy objects on the front passenger seat.
- The seat belt tongue is engaged in the seat belt buckle of the front passenger seat and the front passenger seat is unoccupied.
- Stow objects in a suitable place.
- Only one person should use each seat belt at any one time.

Depending on the detected accident situation, the window airbag on the front passenger side may deploy. The airbag is deployed regardless of whether the front passenger seat is occupied.

Information on the centre airbag

When triggered, the centre airbag deploys between the front seats. Do not stow any objects in the deployment area of the centre airbag.

Protection provided by the airbags

Depending on the accident situation, an airbag may supplement the protection offered by a correctly fastened seat belt.



WARNING Risk of injury or death due to an incorrect seat position

If you deviate from the correct seat position, the airbag cannot perform its intended protective function.

Each vehicle occupant must make sure of the following:

• Fasten seat belts correctly. Pregnant women must take particular care to ensure that the lap belt never lies across the abdomen.

- Adopt the correct seat position and keep as far away as possible from the airbags.
- Observe the following information.
- Always make sure that there are no objects between the airbag and vehicle occupant.

To avoid the risks resulting from the deployment of an airbag, each vehicle occupant must observe the following information in particular:

- Before starting your journey, adjust your seat correctly; the driver's seat and front passenger seat should be moved as far back as possible.
 - When doing so, always observe the information on the correct driver's seat position $(\rightarrow page 111)$.
- · Only hold the steering wheel by the steering wheel rim. This allows the airbag to be fully deployed.
- Always lean against the seat backrest when the vehicle is in motion. Do not lean forwards or against the door or side window. You may

- otherwise be in the deployment area of the airbags.
- The occupants must always keep their feet on the floor. Do not put your feet on the cockpit, for example. Your feet may otherwise be in the deployment area of the airbag.
- If children are travelling in the vehicle, observe the additional notes (\rightarrow page 54).
- Always stow and secure objects correctly.

Objects in the vehicle interior may prevent an airbag from functioning correctly. Each vehicle occupant must always make sure of the following in particular:

- There are no people, animals or objects between the vehicle occupants and an airbag.
- There are no objects between the seat, door and door pillar (B-pillar).
- There are no hard objects, e.g. coat hangers, hanging on the grab handles or coat hooks.
- There are no accessories, such as mobile navigation devices, mobile phones or cup holders, within the deployment area of an airbag, e.g.

on the cockpit, on the door, on the side window or on the side trim.

In addition, no connecting cables, tensioning straps or retaining straps must be routed or attached to the vehicle within the deployment area of an airbag. Always comply with the accessory manufacturer's installation instructions and, in particular, the notes on suitable places for installation.

 There are no heavy, sharp-edged or fragile objects in the pockets of your clothing. Store such objects in a suitable place.

Limitations of the protection provided by airbags

WARNING Risk of injury due to modifications to the cover of an airbag

If you modify the cover of an airbag or affix objects such as stickers to it, the airbag can no longer function as intended.

- Never modify the cover of an airbag.
- ▶ Do not attach any objects to the cover.

The installation location of an airbag is identified by the AIRBAG symbol (\rightarrow page 45).

Objects in the deployment area of an airbag may prevent the airbag from functioning correctly.

A

WARNING Risk of injury from objects in the deployment area of an airbag

Objects in the deployment area of an airbag can hinder or prevent the correct deployment of the airbag.

The airbag may then deploy in an uncontrolled manner and may even cause additional injuries to the vehicle occupants by deploying. This may be the case in particular if the airbag is integrated into the seat.

- Always stow and secure objects correctly.
- Before commencing your journey, make sure that no objects are stowed in the deployment area of an airbag.

Observe the notes on loading the vehicle (\rightarrow page 129). When triggered, the centre airbag deploys between the front seats (\rightarrow page 45).

A

WARNING Risk of injury or death due to the use of unsuitable seat covers

If you use unsuitable seat covers, the airbags cannot protect vehicle occupants as they are designed to do.

In addition, the function of the automatic codriver airbag shutoff could be restricted.

You should only use seat covers that have been approved for the corresponding seats by Mercedes-Benz.

A

WARNING Risk of injury due to malfunctioning sensors in the door

The function of the airbags can be impaired due to modifications or incorrect work performed on the doors or door trim, or if the doors are damaged.

- Never modify the doors or parts of the doors.
- Always have work on the doors or door trim carried out at a qualified specialist workshop.

WARNING Risk of injury due to deployed airbag

A deployed airbag no longer offers any protection.

Have the vehicle towed to a qualified specialist workshop in order to have the deployed airbag replaced.

Have deployed airbags replaced immediately.

Status of the front passenger front airbag

Function of the PASSENGER AIR BAG indicator lamps



Vehicles without automatic front passenger airbag shutoff have a special sticker affixed to the side of the cockpit on the front passenger side $(\rightarrow page 69)$.

Self-test of the automatic front passenger airbag shutoff

When the vehicle is switched on, both the PASSENGER AIR BAG ON and OFF indicator lamps simultaneously light up during the self-test.

The status of the front passenger airbag is displayed after the self-test via the PASSENGER AIR BAG indicator lamps:

- ON is lit: the front passenger airbag may deploy during an accident.
 - The indicator lamp goes out after 60 seconds.
- ON and OFF are not lit: the front passenger airbag may deploy during an accident.
- OFF is lit: the front passenger airbag is disabled. It will then not be deployed in the event of an accident.

When the PASSENGER AIR BAG ON indicator lamp is off, only the PASSENGER AIR BAG OFF indicator lamp displays the status of the front passenger airbag. The PASSENGER AIR BAG OFF indicator light may be lit continuously or off.

If the PASSENGER AIR BAG OFF indicator lamp and the prestraint system warning lamp light up simultaneously, the front passenger seat may not be used. Also in this case, do not fit a child restraint system to the front passenger seat. Have the automatic front passenger airbag shutoff checked and repaired immediately at a qualified specialist workshop.

Status display

If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger airbag is correct for the current situation.

After fitting a rearward-facing child restraint system to the front passenger seat: PASSENGER AIR BAG OFF must be lit continuously.

A

WARNING Risk of injury or death when using a rearward-facing child restraint system while the front passenger airbag is enabled

If you secure a child in a rearward-facing child restraint system on the front passenger seat and the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger airbag can deploy in the event of an accident.

The child could be struck by the airbag.

- Always ensure that the front passenger airbag is disabled. The PASSENGER AIR BAG OFF indicator lamp must be lit.
- NEVER use a rearward-facing child restraint system on a seat with an ENA-BLED FRONT AIRBAG. This can result in the DEATH of or SERIOUS INJURY to the CHILD.

When fitting a child restraint system to the front passenger seat, observe the vehicle-specific information (\rightarrow page 70).

Depending on the child restraint system and the stature of the child, the PASSENGER AIR BAG OFF indicator lamp may be off. In this case, do not fit the rearward-facing child restraint system to the front passenger seat.

Instead, fit the rearward-facing child restraint system to a suitable rear seat.

After fitting a forward-facing child restraint system to the front passenger seat: depending on the child restraint system and the stature of the child, PASSENGER AIR BAG OFF may be lit continuously

or be off. Always observe the following information.



WARNING Risk of injury or death due to incorrect positioning of the child restraint system

If you secure a child in a forward-facing child restraint system on the co-driver seat and you position the co-driver seat too close to the dashboard, in the event of an accident, the child could:

- come into contact with the vehicle's interior if the PASSENGER AIR BAG OFF indicator lamp is lit, for example
- be struck by the airbag if the PASSENGER AIR BAG OFF indicator lamp is off
- Always move the co-driver seat as far back as possible. In doing so, always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards and downwards from the seat belt outlet.

- If necessary, adjust the seat belt outlet and the co-driver seat accordingly.
- Always comply with the child restraint system manufacturer's installation instructions.

When fitting a child restraint system to the front passenger seat, observe the vehicle-specific information (\rightarrow page 70).

If a person is sitting on the front passenger seat: PASSENGER AIR BAG OFF may be lit continuously or be off, depending on the person's stature.

A person on the front passenger seat must always observe the following information:

If the front passenger seat is occupied by an adult or a person with a stature corresponding to that of an adult, the PASSENGER AIR BAG OFF indicator lamp must be off. This indicates that the front passenger airbag is enabled.
 If the PASSENGER AIR BAG OFF indicator lamp is lit continuously, an adult or person with a build corresponding to that of an adult must not use the front passenger seat.
 Instead, they should use a rear seat.

- If the front passenger seat is occupied by a person of smaller stature (e.g. a teenager or small adult), the PASSENGER AIR BAG OFF indicator lamp is either lit continuously or remains off, depending on the classification.
 - If the PASSENGER AIR BAG OFF indicator lamp is off: move the front passenger seat as far back as possible, or the person of smaller stature should use a rear seat.
 - If the PASSENGER AIR BAG OFF indicator lamp is lit continuously: the person of smaller stature should not use the front passenger seat.

★ WARNING Risk of injury or death when the PASSENGER AIR BAG OFF indicator lamp is lit

If the PASSENGER AIR BAG OFF indicator lamp remains lit after the self-test, the front passenger airbag is disabled.

If the front passenger seat is occupied, always ensure that:

- The classification of the person in the front passenger seat is correct and the front passenger airbag is enabled or disabled in accordance with the person in the front passenger seat.
- The person is seated properly with a correctly fastened seat belt.
- The front passenger seat has been moved as far back as possible.

PRE-SAFE® system

Function of PRE-SAFE® (anticipatory occupant protection)

 $\mathsf{PRE}\text{-}\mathsf{SAFE}^{@}$ is able to detect certain critical driving situations and implement pre-emptive measures to protect the vehicle occupants.

PRE-SAFE® can implement the following measures independently of each other:

- Tightening the seat belts on the driver's seat and front passenger seat.
- · Closing the side windows.
- Vehicles with sliding sunroof: closing the sliding sunroof.
- Vehicles with memory function: moving the front passenger seat to a more favourable seat position.
- Vehicles with multicontour seat: increasing the air pressure in the seat side bolsters of the seat backrest.
- PRE-SAFE® Sound: provided that the multimedia system is switched on, generating a brief noise signal to stimulate the innate protective mechanism of a person's hearing.
- **NOTE** Damage caused by objects in the footwell or behind the seat

The automatic adjustment of the seat position may result in damage to the seat and/or the object.

Stow objects in a suitable place.

Reversing the PRE-SAFE® system measures

If an accident did not occur, the pre-emptive measures that were taken are reversed.

You will need to perform certain settings yourself.

If the seat belt pre-tensioning is not reduced, move the seat backrest back slightly. The locking mechanism releases.

Function of PRE-SAFE® PLUS (anticipatory occupant protection plus)

PRE-SAFE® PLUS can detect certain impacts, particularly an imminent rear impact, and take preemptive measures to protect the vehicle occupants. These measures cannot necessarily prevent an imminent impact.

PRE-SAFE® PLUS can implement the following measures independently of each other:

• Tightening the seat belts on the driver's seat and front passenger seat.

- Activating the rear hazard warning lights at a higher flashing frequency.
- Increasing brake pressure when the vehicle is stationary. This brake application is cancelled automatically when the vehicle pulls away.

If an accident did not occur, the pre-emptive measures that were taken are reversed.

System limits

The system will not initiate any action in the following situations:

- · when reversing or
- when the vehicle is towing a trailer and there is a risk of a rear impact

The system will not initiate any braking application in the following situations:

- whilst driving or
- when entering or exiting a parking space while using Active Parking Assist

You can watch an animation on this topic via the following link:

Function of PRE-SAFE® Impulse Side

If an imminent side impact is detected, PRE-SAFE® Impulse Side can pre-emptively move the front seat vehicle occupant's upper body towards the centre of the vehicle. It does this by rapidly inflating an air cushion in the outer seat side bolster of the seat backrest on the side on which the impact is anticipated. This increases the distance between the door and the vehicle occupant.

If PRE-SAFE® Impulse Side has been deployed or is faulty, the PRE-SAFE impulse side inoperative See Owner's Manual display message appears.

Automatic measures after an accident

Depending on the type and severity of the accident, and depending on the vehicle's equipment, the following measures can be implemented, for example:

automatic braking (post-collision brake)

- · activating the hazard warning lights
- triggering an automatic emergency call $(\rightarrow page 440)$
- switching off the engine

To start the vehicle again, switch the vehicle off and on once more (\rightarrow page 182). Depending on the type and severity of the accident, you may no longer be able to start the vehicle.

- switching off the fuel supply
- · unlocking the vehicle doors
- lowering the side windows
- displaying the emergency guide in the central display
- switching on the interior lighting

Function of the post-collision brake

Depending on the accident situation, the post-collision brake can minimise the severity of a further collision or even avoid it.

If an accident is detected, the post-collision brake can implement automatic braking. When the vehicle has come to a standstill, the electric parking brake is automatically applied.

The driver can cancel automatic braking by taking the following actions:

- braking more strongly than automatic braking
- fully depressing the accelerator pedal with force

Safely transporting children in the vehicle

Always observe when children are travelling in the vehicle

Also strictly observe the safety notes for the specific situation. In this way you can recognise potential risks and avoid dangers if children are travelling in the vehicle $(\rightarrow page 54)$.

Be diligent

Bear in mind that negligence when securing a child in the child restraint system may have serious consequences. Always be diligent in securing a child carefully before every journey.

Never allow babies and children to travel sitting on the lap of another vehicle occupant.

To improve protection for children younger than 12 years old or under 1.50 m in height, Mercedes-Benz recommends you observe the following information:

- Always secure the child in a child restraint system suitable for this Mercedes-Benz vehicle.
- The child restraint system must be appropriate to the age, weight and size of the child.
- . The vehicle seat must be suitable for fitting a child restraint system (\rightarrow page 58).

Accident statistics show that children secured on the rear seats are generally safer than children secured on the front seats. For this reason. Mercedes-Benz strongly advises that you fit a child restraint system to a rear seat.

The generic term child restraint system

The generic term child restraint system is used in this Owner's Manual. A child restraint system is, for example:

- · a baby car seat
- a rearward-facing child seat
- a forward-facing child seat

 a child booster seat with a backrest and seat belt guide

Mercedes-Benz recommends using a child booster seat with a backrest.

The child restraint system must be appropriate to the age, weight and size of the child.

Observe laws and legal requirements

Always observe the legal requirements when using a child restraint system in the vehicle.

Make sure that the child restraint system is approved in accordance with the valid test specifications and guidelines. Further information can be obtained at a qualified specialist workshop. Mercedes-Benz recommends that you use a Mercedes-Benz Service Centre for this purpose.

Only use approved child restraint systems

Only child restraint systems that meet the following UNECE standards are permitted for use in the vehicle:

- UN-R44
- UN-R129 (i-Size child restraint systems)

Information on child restraint system approval categories and details on the approval label on the child restraint system (\rightarrow page 59).

Detecting risks, avoiding danger

Securing systems for child restraint systems in the vehicle

Only use the following securing systems for child restraint systems:

- the ISOFIX or i-Size securing rings
- the vehicle's seat belt system
- the Top Tether anchorages

Fitting an ISOFIX or an i-Size child restraint system is preferred.

Simply attaching to the securing rings on the vehicle can reduce the risk of fitting the child restraint system incorrectly.

When securing a child with the integrated seat belt of the ISOFIX or i-Size child restraint system, always comply with the permissible gross weight for the child and child restraint system $(\rightarrow page 62)$.

Advantage of a rearward-facing child restraint system

It is preferable to transport a baby or a small child in a suitable rearward-facing child restraint system. In this case, the child sits in the opposite direction to the direction of travel and faces backwards.

Babies and small children have comparatively weak neck muscles in relation to the size and weight of their head. The risk of injury to the cervical spine during an accident can be reduced in a rearward-facing child restraint system.

Always secure a child restraint system correctly



WARNING Risk of injury or death due to incorrect installation of the child restraint system

The child can then not be protected or restrained as intended.

 Be sure to comply with the manufacturer's installation instructions for the child restraint system and its correct use.

- Make sure that the entire base of the child restraint system always rests on the sitting surface of the seat.
- Never place objects (e.g. cushions) under or behind the child restraint system.
- Use child restraint systems only with the original cover designed for them.
- Always replace damaged covers with genuine covers.



WARNING Risk of injury or death due to unsecured child restraint systems in the vehicle

If the child restraint system is incorrectly fitted or not secured, it can become detached.

The child cannot then be protected or restrained as intended.

The unused child restraint system can be become detached and strike vehicle occupants.

- Always comply with the manufacturer's installation instructions for the child restraint system and its correct use.
- Always fit child restraint systems correctly, even if they are transported unused in the vehicle.
- Always observe the child restraint system manufacturer's installation and operating instructions as well as the vehicle-specific information:
 - Fitting the ISOFIX or i-Size child restraint system to the rear seat (→ page 62).
 - Securing the child restraint system with the seat belt on the rear seat (→ page 68).
 - Securing the child restraint system with the seat belt on the front passenger seat (→ page 71). Observe the specific instructions for the rearward-facing and forward-facing child restraint systems (→ page 70).

If the front passenger seat is occupied, ensure, both before and during the jour-

ney, that the status of the front passenger airbag is correct for the current situation $(\rightarrow page 49)$.

- · Observe the warning labels in the vehicle interior and on the child restraint system.
- Also secure Top Tether if present.

Do not modify the child restraint system

WARNING Risk of injury due to modifications to the child restraint system

The child restraint system can no longer function properly. This poses an increased risk of injury.

- Never modify a child restraint system.
- Only affix accessories which have been specially approved for this child restraint system by the child restraint system's manufacturer.

Mercedes-Benz recommends Mercedes-Benz care products for cleaning child restraint systems recommended by Mercedes-Benz.

Only use child restraint systems which are in proper working condition

WARNING Risk of injury or death caused by the use of damaged child restraint systems

Child restraint systems or their retaining systems that have been subjected to stress in an accident may not be able to perform their intended protective function.

It may be the case that the child cannot be properly restrained.

- Always immediately replace child restraint systems that have been damaged or involved in an accident.
- Have the securing systems for the child restraint systems checked at a qualified specialist workshop before installing a child restraint system again.

Avoid direct sunlight

WARNING Risk of burns when the child seat is exposed to direct sunlight

If the child restraint system is exposed to direct sunlight or heat, parts could heat up.

Children could suffer burns from these parts, particularly on metallic parts of the child restraint system.

- Always make sure that the child restraint system is not exposed to direct sunlight.
- Protect the child restraint system with a blanket, for example,
- If the child restraint system has been exposed to direct sunlight, allow it to cool before securing a child into it.
- Never leave children unattended in the vehicle.

Observe when stopping or parking



WARNING Accident- and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for example by:

- releasing the parking brake.
- change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

Never leave persons, particularly children, unattended in the vehicle.

Overview of recommended child restraint systems

Further information on the correct child restraint system can be obtained at a qualified specialist workshop. Mercedes-Benz recommends that you use a Mercedes-Benz Service Centre for this purpose.

Securing with ISOFIX

Weight category 0+ (up to 13 kg and up to approximately 15 months)

Type ¹	BABY SAFE plus	
Size category	Е	
Approval	E1 04 301 146	

Type ¹	BABY SAFE plus	
Order number ²	B6 6 86 8224	
1 Manufacturer: Britax Römer.	2 With colour code 9H95.	

Weight category I (9 to 18 kg and from approximately 9 months to 4 years)

Type ¹	DUO plus
Size category	B1
Approval	E1 04 301 133
Order number ²	A 000 970 43 02
1 Manufacturer: Britax Römer.	2 With colour code 9H95.

Securing with the vehicle seat belt

Weight category 0 (up to 10 kg and approximately 6 months) and weight category 0+ (up to 13 kg and approximately 15 months)

Type ¹	BABY SAFE plus II	
Approval	E1 04 301 146	
Order number ²	A 000 970 38 02	
1 Manufacturer: Britax Römer.	2 With colour code 9H95.	

Weight category I (9 to 18 kg and from approximately 9 months to 4 years)

Type ¹	DUO plus
Approval	E1 04 301 133
Order number ²	A 000 970 43 02
1 Manufacturer: Britax Römer.	2 With colour code 9H95.

Weight category II/III (15 to 36 kg and from approximately 3 to 12 years)

Type ¹	KIDFIX XP
Approval	E1 04 301 304
Order number ²	A 000 970 49 02
1 Manufacturer: Britax Römer.	2 With colour code 9H95.

Weight category II/III (15 to 36 kg and from approximately 3 to 12 years)

Type ¹	AMG KIDFIX XP
Approval	E1 04 301 304
Order number ²	A 000 970 33 02
1 Manufacturer: Britax Römer.	2 With colour code 9H95.

Overview of suitable seats in the vehicle for fitting a child restraint system

Left/right rear seat

Preferred securing system:

 \bigcirc ISOFIX child seat anchor (\rightarrow page 60) or

i-Size child seat anchor (\rightarrow page 62)

Also secure Top Tether if present (→ page 64).

Alternative securing system:

 \checkmark Vehicle seat belt (\rightarrow page 66)

Front passenger seat

Securing system:

★ Vehicle seat belt (→ page 66)

Be sure to observe:

 If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger airbag is correct for the current situation (→ page 49). Notes on the automatic front passenger airbag shutoff

Centre rear seat

Securing system:



Vehicle seat belt (\rightarrow page 66)

Approval categories for child restraint systems

Only use approved child restraint systems

Only child restraint systems that meet the following UNECE standards are permitted for use in the vehicle:

- UN-R44
- UN-R129 (i-Size child restraint systems)

Identification on the child restraint system
Information about the approval category, weight
category and approval number, forexample, is on
the approval label on the child restraint system.

There may be further information suchas the ISO-FIX size categories, depending on the approval category of the child restraint system.

Approval categories in accordance with UN-R44



Example of an approval label

Universal: child restraint systems in the "Universal" category are approved for installation in vehicles. They can be used, in accordance with overviews of the suitability of seats for securing child restraint systems, on seats labelled U, UF or IUF.

The identification IUF refers to ISOFIX child restraint systems in the "Universal" category.

These child restraint systems must also be secured using Top Tether or support points.

- Semi-Universal: child restraint systems in the "Semi-Universal" category may only be used if the vehicle and vehicle seat are listed in the child restraint system manufacturer's vehicle model list.
- Vehicle-specific: child restraint systems in the "vehicle-specific" category may only be used if the vehicle and vehicle seat are listed in the child restraint system manufacturer's vehicle model list.

Approval categories in accordance with UN-R129



Example of an approval label

 i-Size: child restraint systems in the "i-Size" category are approved for installation in vehicles with i-Size mounting brackets. They can be used, in accordance with overviews of the suitability of seats for securing child restraint systems, on seats labelled i-U.

The identification i-U refers to i-Size child restraint systems in the "Universal" category.

These child restraint systems must also be secured using Top Tether or support points.

Observe the suitability of vehicle seats

Depending on the approval category, there are forward-facing and rearward-facing child restraint systems. Their use can be restricted for certain vehicle seats:

- Suitability of seats for attaching ISOFIX child restraint systems (→ page 60)
- Suitability of seats for securing i-Size child restraint systems (→ page 62).
- Suitability of seats for attaching belt-secured child restraint systems (→ page 66)

Fitting an ISOFIX or i-Size child restraint system on the left and right rear seats

Overview of suitability of the seats for attaching ISOFIX child restraint systems

ISOFIX is a standardised securing system for specially designed child restraint systems.

&

The symbol indicates seats suitable for attaching an ISOFIX child restraint system in accordance with UN R44 (→ page 59).

Attach only child restraint systems that are

Attach only child restraint systems that are approved in accordance with UN R44 as per the following ISOFIX tables.

Carry cot

Size class – Equipment	Left/right rear seat
F - ISO/L1	Χ
G - ISO/L2	Χ
X Not suitable for an ISOFIX child restraint system in this weight group and/or size class.	

Weight group 0 (up to 10 kg and up to approx. 6 months)

Size class – Equipment	Left/right rear seat
E - ISO/R1	IL
IL Suitable for ISOFIX child restraint systems according to the table in "Overview of the recommended child restraint systems", or if the vehicle and the seat are listed on the child restraint system manufacturer's vehicle model list.	

Weight group 0+ (up to 13 kg and up to approx. 15 months)

Size class – Equipment	Left/right rear seat
E - ISO/R1	IL
D - ISO/R2, ISO/R2X	IL

Size class - Equipment	Left/right rear seat
C - ISO/R3	IL (1)
IL Suitable for ISOFIX child restraint systems according to the table in "Overview of the recommended child restraint systems", or if the vehicle and the seat are listed on the child restraint system manufacturer's vehicle model list. (1) When using a child restraint system of size class (ISO/R3), move the front seat into the highest position. Make sure that the seat backrest of the front seat does not rest against the child restraint system.	

Weight group 1 (9–18 kg and approx. 9 months to 4 years)

Size class – Equipment	Left/right rear seat
D - ISO/R2, ISO/R2X	IL
C - ISO/R3	IL (1)
B - ISO/F2	IUF
B1 - ISO/F2X	IUF

Size class - Equipment	Left/right rear seat
A - ISO/F3	IUF
IL Suitable for ISOFIX child restraint systems according to the table in "Overview of the recommended child restraint systems", or if the vehicle and the seat are listed on the child restraint system manufacturer's vehicle model list.	
IUF Suitable for forward-facing ISOFIX child restraint systems of the "Universal" category in this weight group.	
(1) When using a child restraint system of size class (ISO/R3), move the front seat into the highest position. Make sure that the seat backrest of the front seat does not rest against the child restraint system.	

Overview of suitability of the seats for attaching i-Size child restraint systems

i-Size is a standardised securing system for specially designed child restraint systems.

The symbol indicates seats suitable for attaching an i-Size child restraint system in accordance with UN R129 (→ page 59).

Child restraint systems that are permitted in accordance with UN R44 as per the ISO-FIX tables (\rightarrow page 60) or UN R129 as per the following i-Size tables may be attached.

i-Size child restraint systems (ISO/R2, ISO/F2X, ISO/B2, ISO/B3)

Front passenger seat	Left/right rear seat
Χ	i-U
X Not suitable for an i- Size child restraint sys- tem in the "Universal" category.	i-U Suitable for forward-facing and rear- ward-facing i-Size child restraint systems in the "Universal" category.

Fitting the ISOFIX or i-Size child restraint system on the left and right rear seats

WARNING Risk of accident if the rear bench seat, rear seat and seat backrest are not engaged

The rear bench seat, rear seat and seat backrest may fold forwards, even while the vehicle is in motion.

- As a result, the vehicle occupant will be pressed into the seat belt with increased force. The seat belt will not be able to protect as intended and could cause additional injury.
- Objects or loads in the boot or load compartment cannot be restrained by the seat backrest.
- Make sure that the rear bench seat, the rear seat and the seat backrest are engaged before every trip.

If the rear seat backrest is not engaged and locked in place, the red lock verification indicator will be visible.

WARNING Risk of injury or death if the permissible gross mass of the child and child restraint system together is exceeded.

Too much load may be placed on the ISOFIX or i-Size child restraint systems and the child may not be restrained correctly in the event of an accident, for example.

If the child is secured in an ISOFIX or i-Size child restraint system with integrated seat belts, the total mass of the child and child restraint system must not exceed 33 kg.

Always comply with the information about the mass of the child:

- in the manufacturer's installation and operating instructions for the child restraint system used
- on a label on the child restraint system, if present

Regularly check that the permissible gross mass of the child and child restraint system is still complied with.

When fitting a child restraint system, observe the following:

Always observe the correct use of the seats and consider their suitability for attaching a child restraint system.

SOFIX child seat anchor (\rightarrow page 60) or

i-Size child seat anchor (→ page 62)

- Always comply with the manufacturer's installation and operating instructions for the child restraint system used.
- Make sure that the child's feet do not touch the front seat. If necessary, move the front seat slightly forwards.

When fitting an ISOFIX child restraint system, also observe the following:

When using a baby car seat in weight group 0/0+ and a rearward-facing child restraint system in weight group 1 on a rear seat: adjust the front seat so that the seat does not touch the child restraint system.

✓ When using a forward-facing child restraint system in weight group 1: remove the head restraint from the respective seat, if possible. In addition, the backrest of the child restraint system must lie as flat as possible against the backrest of the vehicle seat.

After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.


✓ If the head restraint of the child seat cannot be fully extended when it is installed in the vehicle, this will result in restrictions on the maximum size setting for child restraint systems in weight group 2 or 3.

Contact with the roof when the head restraint is fully extended and locked in place will not result in any restrictions on use.

The child restraint system must not be put under strain between the roof and the seat cushion and/or be fitted facing in the wrong direction. Where possible, adjust the seat cushion inclination accordingly.

- The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.
- When fitting an i-Size child restraint system, also observe the following:
- When using a rearward-facing child restraint system: adjust the front seat so that it does not touch the child restraint system.
- When using a forward-facing child restraint system: remove the head restraint from the respective seat, if possible. In addition, the backrest of the child restraint system must lie as flat as possible against the backrest of the vehicle seat.

After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.



- ISOFIX mounting bracket
- i-Size mounting bracket

Before every journey, make sure that the ISOFIX child restraint system or the i-Size child restraint system is engaged correctly in both mounting brackets in the vehicle.

- **NOTE** Damage to the seat belt for the centre seat during installation of the child restraint system
 - Make sure that the seat belt is not trapped.
- Fold the respective covers rearward.
- Attach the ISOFIX or i-Size child restraint system to both mounting brackets in the vehicle.

Fastening a Top Tether

WARNING Risk of injury or death if the rear seat backrests are not locked after Top Tether belts are fitted

The rear seat backrests may fold forwards when you are driving.


As a result, child restraint systems will no longer be able to perform their intended protective function. This may also cause additional injuries.

- Always lock rear seat backrests after fitting Top Tether belts.
- Observe the lock verification indicator.

If the rear seat backrest is not engaged and locked in place, the red lock verification indicator will be visible.

If the child restraint system is equipped with a Top Tether belt:

The risk of injury may be reduced by Top Tether. The Top Tether belt enables an additional connection between the child restraint system attached with ISOFIX or i-Size and the vehicle.



- If necessary, slide head restraint upwards (→ page 118).
- Fold up cover ② of Top Tether anchorage ③.
- Fit the ISOFIX or i-Size child restraint system with Top Tether. In doing so, comply with the child restraint system manufacturer's installation instructions.



- Guide Top Tether belt (a) under head restraint (b) between the two head restraint bars.
- Hook Top Tether hook (a) of Top Tether belt
 into Top Tether anchorage (a) without twisting.
- Tension Top Tether belt (a). In doing so, comply with the child restraint system manufacturer's installation instructions.
- Fold down cover ② of Top Tether anchorage ③.
- If necessary, slide head restraint ① downwards (→ page 118). Make sure that you do not interfere with the correct routing of Top Tether belt ②.

Securing the child restraint system with the seat belt

Notes on the suitability of seats for attaching belt-secured child restraint systems Suitability of seats for attaching belt-secured child restraint systems

Rear seats

Weight category 0: to 10 kg	
Left/right rear seat	U, L
Centre rear seat ¹	U, L
Weight category 0+: to 13 kg	
Left/right rear seat	U, L
Centre rear seat ¹	U, L
Weight category I: 9 to 18 kg	
Left/right rear seat	U, L

Centre rear seat ¹	U, L
Weight category II: 15 to 25 kg	
Left/right rear seat	U, L
Centre rear seat ¹	U, L
Weight category III: 22 to 36 kg	
Left/right rear seat	U, L
Centre rear seat ¹	U, L
UN-R129 child restraint systems	
Left/right rear seat	U, L, B2, B3
Centre rear seat ¹	U, L, B2, B3
1 Child restraint systems with a supporting bracket are not suitable for this seat.	

U Suitable for child restraint systems of the "Universal" category in this weight category.	
L Suitable for semi-universal child restraint systems according to the table in "Recommended child restraint systems", or if the vehicle and the seat are listed in the child restraint system manufacturer's vehicle model list.	
B2, B3 Suitable for the installa- tion of child restraint systems complying with ISO/B2 and ISO/B3 child seat cushion test equipment.	

Notes on child restraint systems on the front passenger seat

 If it is absolutely necessary for you to fit a child restraint system to the front passenger seat, be sure to observe the information on

- child restraint systems on the front passenger seat (\rightarrow page 71).
- Observe the specific instructions for the rearward-facing and forward-facing child restraint systems. If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger airbag is correct for the current situation (→ page 49).

Front passenger seat

Weight category 0: to 10 kg	
Front passenger air- bag enabled ¹	X
Front passenger airbag disabled ^{1, 2}	U, L
Weight category 0+: to 13 kg	
Front passenger air- bag enabled ¹	X

Front passenger airbag disabled ^{1, 2}	U, L
Weight category I: 9 to 18 kg	
Front passenger airbag enabled ¹	UF, L
Front passenger airbag disabled ^{1, 2}	U, L
Weight category II: 15 to 25 kg	
Front passenger air- bag enabled ¹	UF, L
Front passenger air- bag disabled ^{1, 2}	U, L
Weight category III: 22 to 36 kg	
Front passenger air- bag enabled ¹	UF, L

Front passenger airbag disabled ^{1, 2}	U, L
UN-R129 child restraint systems	
Front passenger air- bag enabled ¹	UF, L, B2, B3
Front passenger air- bag disabled ^{1, 2}	U, L, B2, B3
1 Adjust the seat cushion inclination so that the front edge of the seat cushion is in the highest position and the rear edge of the seat cushion is in the lowest position.	
2 The vehicle is equipped with automatic front passenger air- bag shutoff. The PASSENGER AIR BAG OFF indicator lamp must be lit.	

X Not suitable for children in this weight category.

U Suitable for child restraint systems of the "Universal" category in this weight category.

L Suitable for semi-universal child restraint systems according to the table in "Recommended child restraint systems", or if the vehicle and the seat are listed in the child restraint system manufacturer's vehicle model list.

UF Suitable for forward-facing child restraint systems of the "Universal" category in this weight category.

B2, B3 Suitable for the installation of child restraint systems complying with ISO/B2 and ISO/B3 child seat cushion test equipment.

Securing the child restraint system with the seat belt on the rear seat

A

WARNING Risk of accident if the rear bench seat, rear seat and seat backrest are not engaged

The rear bench seat, rear seat and seat backrest may fold forwards, even while the vehicle is in motion.

 As a result, the vehicle occupant will be pressed into the seat belt with increased

- force. The seat belt will not be able to protect as intended and could cause additional injury.
- Objects or loads in the boot or load compartment cannot be restrained by the seat backrest.
- Make sure that the rear bench seat, the rear seat and the seat backrest are engaged before every trip.

If the rear seat backrest is not engaged and locked in place, the red lock verification indicator will be visible.

When fitting a belt-secured child restraint system, observe the following:

- Always comply with the manufacturer's installation and operating instructions for the child restraint system used.
- ✓ For a child restraint system in the "Universal" or "Semi-Universal" category, make sure that the system has been approved for the vehicle seat.

Observe the notes under "Suitability of seats for attaching belt-secured child restraint systems" (\rightarrow page 66).

- When using a weight category 0/0+ baby car seat and a weight category I rearward-facing child restraint system on a rear seat: adjust the front seat so that the seat does not touch the child restraint system.
- When using a weight category I forwardfacing child restraint system: remove the head restraint from the respective seat, if possible.

After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.


- ✓ The backrest of the forward-facing child restraint system must, as far as possible, be resting on the seat backrest of the rear seat.
- If the head restraint of the child seat cannot be fully extended when it is installed in the vehicle, this will result in restrictions on the maximum size setting for child restraint systems in weight category II or III.

Contact with the roof when the head restraint is fully extended and locked in place will not result in any restrictions on use.

- The child restraint system must not be put under strain between the roof and the seat cushion and/or be fitted facing in the wrong direction. Where possible, adjust the seat cushion inclination accordingly.
- The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.
- Make sure that the child's feet do not touch the front seat. If necessary, move the front seat slightly forwards.
- Install the child restraint system. The entire base of the child restraint system must always rest on the seat surface of the rear seat.
- Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system.

The shoulder belt strap must be routed forward from the seat belt outlet.

Notes on vehicles without automatic front passenger airbag shutoff



Sticker visible when the front passenger door is open

Vehicles without automatic front passenger airbag shutoff have a special sticker affixed to the side of the cockpit on the front passenger side.

Make sure you observe the following information:

- Never fit a rearward-facing child restraint system to the front passenger seat
- Always fit a rearward-facing child restraint system to a suitable rear seat
 - Observe the overview on suitability of seats for attaching belt-secured child restraint systems (→ page 66).
 - Secure the child restraint system with the seat belt on the rear seat (→ page 68).
- Notes on rearward-facing and forward-facing child restraint systems on the front passenger seat (→ page 70)

Notes on rearward-facing and forward-facing child restraint systems on the front passenger seat


★ WARNING Risk of injury or death when using a rearward-facing child restraint system while the front passenger airbag is enabled

If you secure a child in a rearward-facing child restraint system on the front passenger seat and the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger airbag can deploy in the event of an accident.

The child could be struck by the airbag.

- Always ensure that the front passenger airbag is disabled. The PASSENGER AIR BAG OFF indicator lamp must be lit.
- NEVER use a rearward-facing child restraint system on a seat with an ENA-BLED FRONT AIRBAG. This can result in the DEATH of or SERIOUS INJURY to the CHILD.

Observe the specific instructions for the rearward-facing and forward-facing child restraint systems (\rightarrow page 71).



Warning notice on the front passenger sun visor

Always observe the status of the front passenger airbag on the PASSENGER AIR BAG OFF indicator lamp:

- If it is absolutely necessary to fit a child restraint system to the front passenger seat, always observe the information on automatic front passenger airbag shutoff.
- When using a rearward-facing child restraint system on the front passenger seat, the front

passenger airbag must always be disabled. This is only the case if the PASSENGER AIR BAG OFF indicator lamp is lit continuously $(\rightarrow page 49)$.

 If the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger airbag is enabled. The front passenger airbag may be deployed during an accident.

Securing the child restraint system with the seat belt on the front passenger seat

When fitting a belt-secured child restraint system on the front passenger seat, always observe the following:

- ✓ Observe the notes on rearward-facing and forward-facing child restraint systems on the front passenger seat (→ page 70).
- Observe the child restraint system manufacturer's installation and operating instructions.
- ✓ For a child restraint system in the "Universal" or "Semi-Universal" category, make sure that the system has been approved for the vehicle seat.

Observe the notes under "Suitability of seats for attaching belt-secured child restraint systems" (\rightarrow page 66).

- When using a forward-facing child restraint system in weight category I: remove the head restraint from the respective seat, if possible.

 After the child restraint system has been removed, replace the head restraint immediately and adjust all head restraints correctly.
- ▼ The backrest of the forward-facing child restraint system must, as far as possible, be resting on the seat backrest of the front passenger seat.
- If the head restraint of the child seat cannot be fully extended when it is installed in the vehicle; this will result in restrictions on the maximum size setting for child restraint systems in weight category II or III.

Contact with the roof when the head restraint is fully extended and locked in place will not result in any restrictions on use.

The child restraint system must not be put under strain between the roof and the seat

- cushion and/or be fitted facing in the wrong direction.
- ✓ The child restraint system must not be put under strain by the head restraint. Adjust the head restraints as appropriate.
- ✓ Never place objects (e.g. cushions) under or behind the child restraint system.

WARNING Risk of injury or death caused by objects between the seat surface and the child restraint system

Objects between the seat surface and the child restraint system could affect the function of the automatic co-driver airbag shutoff.

- Do not place any objects between the seat surface and the child restraint system.
- Always make sure that the child restraint system is installed correctly.
- Set the front passenger seat as far back as possible and move the seat into the highest position if possible.

- Fully retract the seat cushion length adjustment.
- Adjust the seat cushion inclination so that the front edge of the seat cushion is in the highest position and the rear edge of the seat cushion is in the lowest position.
- Set the seat backrest to the most vertical position possible.
- Install the child restraint system. The entire base of the child restraint system must always rest on the sitting surface of the front passenger seat.
- Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system.

The shoulder belt strap must be routed forwards and downwards from the seat belt outlet.

If necessary, adjust the seat belt outlet and the front passenger seat accordingly.

Child safety locks

Activating or deactivating the child safety lock for the rear doors

WARNING Accident- and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for example by:

- releasing the parking brake.
- change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

- Never leave persons, particularly children, unattended in the vehicle.
- WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are travelling in the vehicle, they could, in particular:


- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- · operate vehicle equipment and become trapped, for example.

- Always activate the installed child safety locks if children are travelling in the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.

Vehicles for the United Kingdom: observe the important safety notes in the "Notes on the additional door lock" section.

There are child safety locks for the rear doors and the rear side windows.

The child safety lock on the rear doors secures each door separately. The doors can no longer be opened from the inside.



- Press the lever in direction (activate) or (deactivate).
- Make sure that the child safety locks are working properly.

Activating and deactivating the child safety lock for the rear side windows

WARNING Accident – and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for exampleby:

- releasing the parking brake.
- change the gearbox setting.
- · start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

- ► Keep the key out of reach of children.
- **WARNING** Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If persons, particularly children, are subjected to prolonged exposure to intense heat or cold, there is a risk of severe injury or even death.

- Never leave persons, particularly children, unattended in the vehicle.
- **WARNING** Risk of accident and injury due to children left unattended in the vehicle


If children are travelling in the vehicle, they could, in particular:

- open doors, thereby endangering other persons or road users.
- get out and be struck by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

- Always activate the installed child safety locks if children are travelling in the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.

Vehicles for the United Kingdom: observe the important safety notes in the "Notes on the additional door lock" section.

There are child safety locks for the rear doors and the rear side windows.



- To activate/deactivate: press button ②.
 The rear side window can be opened or closed in the following cases:
 - indicator lamp ① is lit: via the switch on the driver's door
 - indicator lamp is off: via the switch on the corresponding rear door or driver's door

Occupant presence reminder

Function of the occupant presence reminder

The occupant presence reminder can help to remind you about a child who may have been forgotten in the rear compartment of the vehicle. It activates and deactivates automatically when the rear door is open for an extended period of time and a child, which the system presumes to be present, could enter or exit the vehicle.

When the vehicle is switched off, the Do not leave persons or animals in the vehicle message appears on the driver's display if the system was already automatically activated.

Activating or deactivating the occupant presence reminder in the multimedia system

Multimedia system:

→ Settings → Vehicle
→ Occupant protection

Activate or deactivate the function.

Notes on pets in the vehicle

A

WARNING Risk of accident and injury due to animals left unsecured or unattended in the vehicle

If you leave animals in the vehicle unattended or unsecured, they could press buttons or switches, for instance.

An animal may:

- activate vehicle equipment and become trapped, for example
- switch systems on or off and endanger other road users

Unsecured animals may be thrown about the vehicle in the event of an accident, or sudden steering and braking manoeuvres, and injure vehicle occupants.

- Never leave animals unattended in the vehicle.
- Always correctly secure animals while driving, e.g. using a suitable animal carrier.

Key

Overview of key functions

WARNING Accident– and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for exampleby:

- releasing the parking brake.
- change the gearbox setting.
- · start the vehicle.
- Never leave children unattended in the vehicle.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

This also applies to the Digital Vehicle Key.

- I NOTE Damage to the key caused by magnetic fields
- Keep the key away from strong magnetic fields.



- Vehicle key
- Indicator lamp
- To lock

- 3 Unlocks (with embossed surface)
- Opens/closes the boot lid
- i) If indicator lamp ① does not light up after pressing the ② or ② button, the battery is weak or possibly discharged. Replace the battery as soon as possible.

Replace the key battery (\rightarrow page 78).

The key locks and unlocks the following components:

- Doors
- Fuel filler flap
- Boot lid

If the vehicle is not opened within approximately 40 seconds after unlocking, it locks again. Antitheft protection is primed again.

Do not keep the key together with electronic devices or metal objects. This can affect the key's functionality.

Activating/deactivating the acoustic locking verification signal

Multimedia system:

- → Settings → Vehicle
- ➤ Open/close
- Activate or deactivate the Acoustic lock.
- (i) Please observe:

The selected setting for the acoustic locking verification signal must comply with the relevant national road and traffic regulations. In some countries, including Germany, using the acoustic locking verification signal is forbidden by traffic laws (in accordance with §16 Para. 1 and §30 Para. 1 of the German national road traffic regulations). The driver of the vehicle must comply with these regulations. In countries where the use of this function is forbidden, this function is not activated in the vehicle and must not be activated.

Changing the unlocking settings

Possible unlocking functions of the key:

· Central unlocking

- Unlocking the driver's door and fuel filler flap
- To switch between settings: press the and buttons simultaneously for approximately six seconds until the indicator lamp flashes twice.

Options if the unlocking function for the driver's door and fuel filler flap has been selected:

- To unlock the vehicle centrally: press the
 ☐ button twice.
- Vehicles with KEYLESS-GO: if you touch the inner surface of the door handle on the driver's door, only the driver's door and the fuel filler flap are unlocked.

Deactivating the function of the key

If you deactivate the key function, the KEYLESS-GO functions are also deactivated. Access or drive authorization by KEYLESS-GO is then no longer possible with that particular key. Activate the function of the key so that all its functions will again be available. You can also deactivate the function of the key to reduce the energy con-

sumption of the key if you do not use the vehicle or a key for an extended period of time.

If you do not use the vehicle or a key for an extended period of time, you can also deactivate the function of the key to reduce the energy consumption of the key.


- Press and hold the key <a> button.
- With the key button pressed, immediately press key button twice in quick succession.

The indicator light of the key lights up once briefly and once for a long time.

- (i) You have the following options to reactivate the key:
 - Press any key on the key.
 - Start the vehicle with the key in the centre console storage compartment (→ page 185).

Removing/inserting the emergency key

Removing the emergency key



- Press release button ①.
 Emergency key ② is pushed out slightly.
- Fully remove emergency key ②.

Inserting the emergency key



- Insert emergency key ② at marking ③ until it engages.
- (i) You can use emergency key (2) to attach the key to a key ring.

Replacing the key battery

DANGER Risk of fatal injuries due to swallowing batteries

Batteries contain toxic and corrosive substances. If batteries are swallowed or otherwise

enter the body, severe internal burns can occur within two hours.

There is a risk of fatal injury.

- Keep batteries out of the reach of children.
- If the battery compartment cover and/or lid do not close securely, stop using the key and keep it away from children.
- If batteries are swallowed or otherwise enter the body, seek immediate medical attention.

ENVIRONMENTAL NOTE Environmental damage due to improper disposal of batteries

Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.

Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

Requirements:

• You require a CR 2032 3 V cell battery.

Mercedes-Benz recommends that you have the battery replaced at a qualified specialist workshop.

Remove the emergency key (\rightarrow page 78).



Press emergency key (2) into the opening in the key in the direction of the arrow until cover (1) opens. When doing so, do not hold cover (1) closed.



- Insert emergency key ② into the opening and lift up covering ③ and remove it.
- Repeatedly tap the key against your palm until battery (a) falls out of the key.
- Insert the new battery with the positive pole facing upwards. Use a lint-free cloth to do so.
- Make sure that the surface of the battery is free of lint, grease and other impurities.
- Insert the front tabs of covering (3) into the housing and then press on both sides to close it.
- Make sure that covering (3) is completely closed.
- Insert the front tabs of cover (1) into the housing and then press until it is completely closed.
- ▶ Insert the emergency key again (\rightarrow page 78).

Problems with the key, troubleshooting

You can no longer lock or unlock the vehicle Possible causes:

- The key battery is weak or discharged.
- Check the battery using the indicator lamp (→ page 76).
- Replace the key battery, if necessary (→ page 78).
- Use the replacement key.
- Use the emergency key to lock or unlock (→ page 90).
- Have key checked at a qualified specialist workshop.

There is interference from a powerful radio signal source

Possible causes if the function of the key is impaired:

- · high voltage power lines
- · mobile phones
- electronic devices (notebooks, tablets)

- shielding due to metal objects or induction loops for electrical gate systems or automatic barriers
- Make sure that there is sufficient distance between the key and the potential source of interference.

You have lost a key

- Have the key deactivated at a qualified specialist workshop.
- If necessary, have the mechanical lock replaced as well.

Digital Vehicle Key Function of the Digital Vehicle Key

runction of the Digital Vehicle Rey

If you have activated a suitable terminal device, e.g. a smartphone, as a digital vehicle key, you can use it like a conventional vehicle key.

Information on setting up a user account and activating the "Digital Vehicle Key" service https://www.mercedes.me.

The Digital Vehicle Key can then be used for the following functions:

- Locking/unlocking the vehicle with KEYLESS-GO (→ page 87)
- Locking and unlocking the vehicle with the NFC function (→ page 84)
- HANDS-FREE ACCESS function (→ page 96)
- Convenience closing (closing the vehicle from outside) (→ page 101)
- Anti-theft protection (→ page 107)
- Starting the vehicle (→ page 182) or parking (→ page 209)
- Starting the vehicle with the digital vehicle key in the storage compartment (emergency mode) (→ page 183)

Set up and manage the digital vehicle key:

- Registering the digital vehicle key (→ page 81)
- Manage digital vehicle key (→ page 82)
- Remove digital vehicle key (→ page 83)

- Unlocking and locking the vehicle with the digital vehicle key (→ page 84)
- Changing the Unlocking Settings for the Digital Vehicle Key (→ page 85)
- Fixing Problems with the Digital Vehicle Key (→ page 85)

Setting up the digital vehicle key

Requirements

- Create a Mercedes me user account at: https://www.mercedes.me.
- The Mercedes me app is installed on the end device (optional).
- You have received an e-mail from Mercedes me connect.
 - If you have selected the "Digital Vehicle Key" equipment, you will receive an e-mail with information on how to set up the digital vehicle key.
- Bluetooth[®] is switched on at the end device and at the vehicle.
- The terminal is sufficiently charged.

You have the following options for setting up a terminal as a digital vehicle key:

- via Mercedes me app
- by e-mail
- · via MBUX multimedia system

Set up via the Mercedes me app

- Start the Mercedes me app.
- Select the "Digital vehicle key" menu.
- Follow the steps in the Mercedes me app.

When the message "Add key and pair with vehicle" appears:

- ▶ Place the terminal in the tray (\rightarrow page 183).
- Follow the action steps on the terminal.

 Your Digital Vehicle Key is now stored in the
 Wallet-App of your end device.

Set up by e-mail

- Open the e-mail from Mercedes me connect.
- Follow the displayed action steps as described in the email.

Your Digital Vehicle Key is now stored in the Wallet-App of your end device.

or

- Open the link in the e-mail with the end device that you want to use as a digital vehicle key.
- Follow the action steps on the terminal. When the message "Add key and pair with vehicle" appears:
- ▶ Place the terminal in the tray (\rightarrow page 183).
- Follow the action steps on the terminal. Your Digital Vehicle Key is now stored in the Wallet-App of your end device.

or

- Set up the terminal on the vehicle.
- Place the terminal in the tray (→ page 183). Mercedes-Benz Digital Vehicle Key" is displayed on the terminal device.
- Press "Enter code".The display for entering the code appears.
- Enter the 8-digit code displayed in the e-mail. When the message "Add key and pair with vehicle" appears:
- Follow the action steps on the terminal. Your Digital Vehicle Key is now stored in the Wallet-App of your end device.

Set up via MBUX multimedia system

- Select the menus in the multimedia system Settings, Vehicle, Open/close.
- Select Digital Vehicle Key menu.
- Follow the action steps in the multimedia system.

Your Digital Vehicle Key is now stored in the Wallet-App of your end device.

- (i) You can now use the digital vehicle key like the conventional vehicle key (→ page 84).
- i Set up and manage the digital vehicle key:
 - Function (→ page 80)
 - Managing (→ page 82)
 - Remove (→ page 83)
 - Changing the Unlocking Settings for the Digital Vehicle Key (→ page 85)

Manage digital vehicle key

Requirements

 A suitable end device is activated as a Digital Vehicle Key.

- Bluetooth[®] is switched on at the end device (with the activated digital vehicle key) and at the vehicle.
- The terminal is sufficiently charged.

You have the following options for managing a digital vehicle key:

- Switch express mode (comfort mode) off or on
- Set up other devices of family members or friends as digital vehicle keys.
- Setting up permissions for the digital vehicle keys

Switch express mode off or on

- Open the Wallet-App on the end device.
- Switch express mode off or on
- Express mode is switched on by default. This setting allows you to make the best possible use of the Digital Vehicle Key.

If the express mode is switched off and the battery of the end device is empty, you can no longer unlock the vehicle via the NFC function.

Only switch off the express mode if you do not want to use the digital vehicle key function.

Setting up other terminals as digital vehicle keys

- Open the Wallet-App on the end device.
- Select the menu "Invite people to use your Mercedes-Benz key".
- Follow the action steps on the terminal.

Setting up permissions for the digital vehicle keys

You can assign the following authorisations to the Digital Vehicle Keys:

- Vehicle access and driving authorisation
- · Vehicle access authorisation
- Open the Wallet-App on the end device.
- Select the menu "Invite people to use your Mercedes-Benz key".
- Select the "Configure car key access" menu.
- Follow the action steps on the terminal.
- i Further information on the digital vehicle key:
 - Function (→ page 80)

- Setting up (→ page 81)
- Remove (→ page 83)
- Changing the Unlocking Settings for the Digital Vehicle Key (→ page 85)

Remove digital vehicle key

Requirements

- A suitable end device is activated as a Digital Vehicle Key.
- Bluetooth[®] is switched on at the end device (with the activated digital vehicle key) and at the vehicle.
- The terminal is sufficiently charged.

You have the following options for removing a digital vehicle key:

- via the Wallet-App
- · via iCloud
- · via Mercedes me user account
- via MBUX multimedia system
- i You can remove individual users or remove your own digital vehicle key from the terminal.

Remove via Wallet-App

- Open the Wallet-App on the end device.
- Select the user whose Digital Vehicle Key is to be removed.
- Follow the action steps on the terminal. The selected Digital Vehicle Key is removed and can no longer be used.

Remove via iCloud

- Log in to iCloud.
- Follow the action steps.
 The selected Digital Vehicle Key is removed and can no longer be used.

Remove via Mercedes me user account

The following options are available:

- · Remove the linked vehicle
- object to the terms of use and consents
- · Delete the user account
- Log in to the Mercedes me user account.
- Select one of the above options.

The selected Digital Vehicle Key is removed and can no longer be used.

Remove via MBUX multimedia system

The following options are available:

- Disconnect all digital vehicle keys
- Change the Digital Vehicle Key of the main owner
- Disconnect the owner's Digital Vehicle Key
- Remove a digital vehicle key
- Select the menus in the multimedia system Settings, Vehicle, Open/close.
- Select Digital Vehicle Key menu.
- Select one of the above options.
- Follow the action steps in the multimedia system.

The selected Digital Vehicle Key is removed and can no longer be used.

- i Further information on the digital vehicle key:
 - Function (→ page 80)
 - Setting up (→ page 81)
 - Managing (→ page 82)
 - Changing the Unlocking Settings for the Digital Vehicle Key (→ page 85)

Unlocking and locking the vehicle with the digital vehicle key


Requirements

- The "Digital Vehicle Key" function is activated via Mercedes me: https:// www.mercedes.me.
- A suitable end device is activated as a Digital Vehicle Key.
- Bluetooth[®] is switched on at the end device and at the vehicle.
- The terminal is sufficiently charged.
- If the connection via Bluetooth[®] is faulty or the battery of the digital vehicle key is empty, you can also lock, unlock or start the vehicle via the NFC function. (→ page 183).

The Digital Vehicle Key can be used for the following functions:

- Locking and unlocking the vehicle with the NFC function
- Locking/unlocking the vehicle with KEYLESS-GO (→ page 87)
- HANDS-FREE ACCESS function (→ page 96)

- Convenience closing (closing the vehicle from outside) (→ page 101)
- Anti-theft protection (→ page 107)
- Starting the vehicle (→ page 182) or parking (→ page 209)
- Starting the vehicle with the digital vehicle key in the storage compartment (emergency mode) (→ page 183)
- Mercedes-Benz recommends that you carry the emergency key in case of function restrictions(→ page 78).



 Lock and unlock the vehicle with the NFC function: Hold the digital vehicle key against
 the door handle in the area of the NFC antenna.

Changing the Unlocking Settings for the Digital Vehicle Key

Multimedia system:

Set selective or global unlocking

Switch on driver's door unlocking only. Selective unlocking is activated. If this function is deactivated, the owner key unlocks the entire vehicle.

Fixing Problems with the Digital Vehicle Key

You can no longer lock and unlock the vehicle with the Digital Vehicle Key.

Possible causes:

- Bluetooth[®] is switched off on the Digital Vehicle Key or on the vehicle.
- The battery of the Digital Vehicle Key is low or empty.
- Switch on Bluetooth® on the digital vehicle key or on the vehicle.

- Check the charge level of the Digital Vehicle Key battery.
- If necessary, charge the battery of the Digital Vehicle Key.
- Use the NFC function of the digital vehicle key to lock or unlock the vehicle. (→ page 84).
- Use the vehicle key.
- Use the emergency key to lock or unlock (→ page 90).
- Have the vehicle and the Digital Vehicle Key checked at a qualified specialist workshop.

There is interference from a powerful radio signal source

Possible causes of Digital Vehicle Key impairment:

- high voltage power lines
- mobile phones
- · electronic devices (notebooks, tablets)
- shielding due to metal objects or induction loops for electrical gate systems or automatic barriers

Ensure sufficient distance between the Digital Vehicle Key and a potential source of interference.

You have lost a Digital Vehicle Key.

Remove the Digital Vehicle Key (→ page 83).

Doors

Notes on the additional door lock

The additional door lock is only available for vehicles for the United Kingdom.



WARNING Risk of injury to persons inside the vehicle when the additional door lock is activated

If the additional door lock is activated, the doors can no longer be opened from the inside.

- Never leave persons, in particular children, unattended in the vehicle.
- If there are persons in the vehicle, do not activate the additional door lock.

The additional door lock is automatically activated in the following situations:

- The vehicle is locked using the key.
- The vehicle is locked using KEYLESS-GO.

If the vehicle has been locked via Mercedes me connect, the additional door lock is not activated $(\rightarrow page 433)$.


If the additional door lock is activated, the doors cannot be opened from the inside.

After locking you can issue a signal with the horn.

You can prevent the additional door lock from being activated by deactivating interior protection before locking the vehicle (\rightarrow page 110).


Unlocking/opening the doors from the inside

United Kingdom only: observe the notes on the additional door lock (\rightarrow page 85).



Pull the door 1 handle.

Centrally locking and unlocking the vehicle from the inside



- To unlock: press 1 button.
- To lock: press button 2. The red indicator lamp on button 2 lights up once the vehicle is locked.

This does not lock or unlock the fuel filler flap.

The vehicle is not unlocked:

- if you have locked the vehicle using the key
- if you have locked the vehicle using KEYLESS-GO


Recessed door handles extend or retract

The door handles extend automatically:

- when you unlock the vehicle with the key
- when you touch the outer sensor surface of the door handle (when the vehicle is unlocked)

The door handles retract automatically:

- when you lock the vehicle with the key
- when pulling away
- · after waiting for a time



Extend the door handle: Touch the outer osensor surface.

Locking/unlocking the vehicle with KEYLESS-GO

Requirements

- The key is outside the vehicle.
- The distance between the key and the vehicle does not exceed 1 m.

- The driver's door and the door on which the door handle is used are closed.
- Vehicles with Digital Vehicle Key: You can use the Digital Vehicle Key like the conventional vehicle key.

The door handles extend automatically:

- when a vehicle key is detected (the vehicle is then not yet unlocked)
- when you unlock the vehicle with the key
- when you touch the outer sensor surface of the door handle to unlock it

The door handles retract automatically:

- when you lock the vehicle with the key
- when you touch the recessed sensor surface of the door handle to lock it
- after comfort locking (→ page 101)
- when pulling away
- after waiting for a time

- **NOTE** Damage to the vehicle caused by unintentionally opening the boot lid or a door
- when using an automatic car wash
- when using a high pressure cleaner
- Deactivate the function of the key in these situations.

or

Make sure that the key is at a minimum distance of 3 m (high-pressure cleaner) or 6 m (automatic car wash) away from the vehicle.

Vehicles with digital vehicle key:


- NOTE Vehicle damage due to unintentional opening of the boot lid or a door
- when using an automatic car wash
- when using a high pressure cleaner
- In these situations, switch off the Digital Vehicle Key.

or

Make sure the key is at least 3 m (pressure washer) or 6 m (car wash) away from the vehicle.


Observe the notes:

- on washing the vehicle in a car wash $(\rightarrow page 477)$
- on using a high pressure cleaner $(\rightarrow page 478)$




Unlocking the vehicle: With the door handle extended, touch the inside surface (1) of the door handle.

If the door handle is not extended, e.g. after a waiting period:



► Touch the sensor surface ② to unlock.



- To lock the vehicle: touch recessed sensor surface (3).
- Convenience closing: touch recessed sensor surface (3) for an extended period.
- Further information on convenience closing
 (→ page 101).

You can watch an animation on this topic via the following link:

Problems with KEYLESS-GO, troubleshooting

You can no longer lock or unlock the vehicle using KEYLESS-GO

Possible causes:

- The function of the key has been deactivated.
- The key battery is weak or discharged.
- \blacktriangleright Activate the function of the key (\rightarrow page 77).
- Check the battery using the indicator lamp (→ page 76).
- Replace the key battery, if necessary (→ page 78).
- Use the replacement key.
- Use the emergency key to lock or unlock $(\rightarrow page 90)$.
- Have the vehicle and key checked at a qualified specialist workshop.

There is interference from a powerful radio signal source

Possible causes if the function of KEYLESS-GO is impaired:

· high voltage power lines

- mobile phones
- electronic devices (notebooks, tablets)
- shielding due to metal objects or induction loops for electrical gate systems or automatic barriers
- Make sure that there is sufficient distance between the key and the potential source of interference.

Activating or deactivating the automatic locking feature

Multimedia system:

- → Settings → Vehicle
- >> Open/close
- (i) The vehicle is locked automatically when the vehicle is switched on and the wheels are turning faster than walking pace.
- Activate or deactivate Automatic locking. In the following situations, there is a danger of being locked out when the function is activated:
- The vehicle is being towed or pushed.

If the vehicle is being tested on a roller dynamometer.

Power closing function

A

WARNING Risk of becoming trapped when the doors close automatically

Body parts or objects can become trapped, causing injuries.

- Ensure that no body parts or objects are in the closing area.
- Automatic closing of the doors can be cancelled by pulling the outer or inner door handle.

If you push the door into the lock to the first detent position, the power closing function will automatically pull the door into the lock.

(i) If the vehicle is locked from the outside, or while pulling away, an automatic closing of the doors can be triggered.


Locking/unlocking the vehicle with the emergency key

Unlocking a left-hand vehicle door with the emergency key element


- i If you unlock and open the driver's door with the emergency key, this triggers the burglar alarm system.
- i If you unlock the driver's door with the emergency key, the boot lid will not be unlocked.

Vehicles without KEYLESS-GO

Remove the emergency key (\rightarrow page 78).




Pull 1 and hold the door handle.



- Insert emergency key 2 into the lock cylinder as shown.
- Turn the emergency key 2 anti-clockwise to position 1.
- Turn the emergency key 2 back to its starting position.
- Remove emergency key 2 and release door handle 10.

Vehicles with KEYLESS-GO

 \triangleright Remove the emergency key (\rightarrow page 78).




If the door handle is retracted:

Insert a flat, non-metallic object behind door handle 1 from above and pry it slightly outward.

92 Opening and closing

Reach behind door handle from below, pull it outward to the pressure point and hold it there.




If the door handle is extended:

- Pull door handle o outward to the pressure point and hold it there.
- Insert the emergency key into the lock cylinder.

- Turn the emergency key anti-clockwise to position 1.
- Forcefully pull door handle ① outward past the pressure point.
- Turn the emergency key back to its starting position.
- Remove the emergency key and release the door handle.

You can watch an animation on this topic via the following link:

Locking the doors



- Insert a suitable object, e.g. the emergency key, into opening 1 on the door lock.
- To lock the left-hand side of the vehicle: turn the emergency key clockwise as far as it will go.

To lock the right-hand side of the vehicle: turn the emergency key anti-clockwise as far as it will go.

If the locked door is then closed, it can no longer be opened from the outside.

Boot

Opening the boot lid

▲ DANGER Risk of exhaust gas poisoning

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the boot lid is open when the engine is running, especially if the vehicle is in motion.


- Always switch off the engine before opening the boot lid.
- Never drive with the boot lid open.

NOTE Damage to the boot lid by obstacles above the vehicle

The boot lid swings upwards when it is opened.

- Therefore, make sure that there is sufficient clearance above the boot lid.
- Pull the boot lid handle.
- Vehicles with HANDS-FREE ACCESS: make a kicking movement with your foot below the bumper (→ page 96).

Vehicles with boot lid convenience closing



Pull remote operating switch ① until the boot lid opens.

10

- Press and hold the substitution on the key.
 - If the boot lid is stopped in an intermediate position, pull it upwards. Release it as soon as it begins to open.

With the boot lid opening limiter activated, manually pull the stopped boot lid upwards.

If an obstacle obstructs the boot lid during the automatic opening process, blockage detection will stop the boot lid. The automatic blockage detection function is only an aid and is not a substitute for your attentiveness.

Closing the boot lid

WARNING Risk of injury from unsecured items in the vehicle

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be thrown around and thereby hit vehicle occupants.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Always stow objects in such a way that they cannot be thrown around.

Before the journey, secure objects, luggage or loads against slipping or tipping over.

Observe the notes on loading the vehicle. Notes on closing the boot lid: your vehicle is equipped with automatic key recognition. If a key belonging to the vehicle is detected in the vehicle, the boot lid will not be locked and will pop open again.

Note that the boot lid will not be locked if the following situation occurs:

- · You have locked the vehicle and close the boot lid while a key belonging to the vehicle is inside the vehicle. and
- A second key belonging to the vehicle is not detected outside the vehicle.

Automatic key recognition is only an aid and is not a substitute for your attentiveness.

Before locking, ensure that at least one key belonging to the vehicle is outside the vehicle.

- To close the boot lid: pull the boot lid downwards using the handle recess and push it closed.
- Vehicles with boot lid convenience closing: if you lightly push the boot lid closed, the power closing function will automatically pull the boot lid into the lock.

Vehicles with boot lid convenience closing

WARNING Risk of becoming trapped during automatic closing of the boot lid


Parts of the body could become trapped. There may be people in the closing area.

- Make sure that nobody is in the vicinity of the closing area.
- Use one of the following options to stop the closing process:
 - Press the 🐒 button on the key.
 - Press or pull the remote operating switch on the driver's door.
 - Press the closing or locking button on the boot lid.


Pull the boot lid handle.

Vehicles with HANDS-FREE ACCESS: it is also possible to stop the closing process by making a kicking movement below the rear bumper.

- Pull the boot lid handle. Release it as soon as it begins to close.
- If the boot lid is stopped in an intermediate position, push it downwards. The boot lid will continue to close.



► Push remote operating switch ● until the boot lid is fully closed.



Press closing button
on the boot lid.

Vehicles with KEYLESS-GO

Press locking button ② on the boot lid. If a key is detected outside the vehicle, the boot lid will close and the vehicle will be locked.

- (i) Vehicles with Digital Vehicle Key: this also applies to the Digital Vehicle Key if the function is activated and the Digital Vehicle Key is connected to the vehicle.
- With the boot lid completely open, press and hold the ্ৰিচা button on the key. The key must be in the vicinity of the vehicle.

Vehicles with HANDS-FREE ACCESS

With the boot lid completely open, make a kicking movement with your foot below the bumper (→ page 96).

Boot lid automatic reversing function

The boot lid is equipped with automatic blockage detection with a reversing function. If an obstacle obstructs the boot lid during the automatic closing process, it will automatically open again. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

During the closing process, make sure that no body parts are in the closing area.

WARNING Risk of becoming trapped despite reversing function

The reversing function will not react:

- to soft, light and thin objects, e.g. fingers
- towards the end of the closing procedure

In these situations in particular, the reversing function cannot prevent someone being trapped.

- Ensure that no body parts are in the closing area.
- If someone is trapped, use one of the following options:
 - Press the [5] button on the key.
 - Press the remote operating switch on the driver's door.
 - Press the closing or locking button on the boot lid.
 - · Pull the boot lid handle.

HANDS-FREE ACCESS function



With HANDS-FREE ACCESS you can open, close or interrupt boot lid movement by performing a kicking movement under the rear bumper.

The kicking movement triggers the opening or closing process alternately.

Observe the notes when opening (\rightarrow page 93) and closing (\rightarrow page 94) the boot lid.

i) A warning tone sounds while the boot lid is opening or closing.

A

WARNING Risk of burns caused by a hot exhaust system

The vehicle exhaust system can become very hot. If you use HANDS-FREE ACCESS, you could burn yourself by touching the exhaust system.

- Always ensure that you only make a kicking movement within the detection range of the sensors.
- NOTE Damage to the vehicle caused by unintentionally opening the boot lid or a door
- when using an automatic car wash
- when using a high pressure cleaner
- Deactivate the function of the key in these situations.

or

Make sure that the key is at a minimum distance of 3 m (high-pressure cleaner) or 6 m (automatic car wash) away from the vehicle.

Vehicles with digital vehicle key:

- ! NOTE Vehicle damage due to unintentional opening of the boot lid or a door
- when using an automatic car wash
- when using a high pressure cleaner
- In these situations, switch off the Digital Vehicle Key.

or


Make sure the key is at least 3 m (pressure washer) or 6 m (car wash) away from the vehicle.

When making the kicking movement, make sure that you are standing firmly on the ground. You could otherwise lose your balance, e.g. on ice.

Observe the following notes:

- The key is behind the vehicle.
- Vehicles with digital vehicle key: The Digital Vehicle Key is behind the vehicle.
- Stand at least 30 cm away from the vehicle while performing the kicking movement.

- Do not come into contact with the bumper while making the kicking movement.
- Do not carry out the kicking movement too slowly.
- The kicking movement must be towards the vehicle and back again.



Detection range of the sensors

If several consecutive kicking movements are not successful, wait ten seconds.

System limits

The system may be impaired or may not function in the following cases:

- The sensors are dirty, e.g. due to road salt or snow.
- The kicking movement is made using a prosthetic leg.

The boot lid could be opened or closed unintentionally, in the following situations:

- A person's arms or legs are moving in the sensor detection range, e.g. when polishing the vehicle or picking up objects.
- Objects are moved or placed behind the vehicle, e.g. the hose of a fuel dispenser, a charging cable or luggage
- Clamping straps, tarpaulins or other coverings are pulled over the bumper.
- A protective mat with a length reaching over the boot sill down into the detection range of the sensors is used.
- The protective mat is not secured correctly.

• Work is being done on the trailer hitch, trailers or rear bicycle racks.

Deactivate the function of the key (\rightarrow page 77) or do not carry the key about your person in such situations.

You can watch an animation on this topic via the following link:

Switching separate boot locking on and off

Multimedia system:

→ Settings → Vehicle → Locking function

Switching separate boot locking on

- Select Block boot.
- Create a PIN.
- Confirm the PIN with OK.
- Enter the PIN again and confirm it. The boot will remain locked if you unlock the vehicle centrally.

i If an accident has been detected, the boot will unlock even if separate locking is switched on.

Switching separate boot locking off

- Select Block boot.
- Enter the PIN.

If the PIN is correct, separate boot locking will be switched off and the PIN deleted.

Activating/deactivating the boot lid opening limiter

Multimedia system:

- → Settings → Vehicle
- Other functions
- Activate or deactivate Opening height limiter.

This function prevents the boot lid from hitting a low garage ceiling, for example.

Side windows

Opening and closing the side windows



WARNING Risk of becoming trapped when opening a side window

When you open a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- When opening, make sure that nobody is touching the side window.
- If someone is trapped, release the button immediately or pull it in order to close the side window again.

WARNING Risk of becoming trapped when closing a side window

When closing a side window, body parts could be trapped in the closing area in the process.

When closing, make sure that no body parts are in the closing area.

▶ If someone is trapped, release the button immediately or press the button in order to reopen the side window.


WARNING Risk of becoming trapped when children operate the side windows

Children could become trapped if they operate the side windows, particularly when unattended.

- Activate the child safety lock for the rear side windows.
- ► When leaving the vehicle, always take the key with you and lock the vehicle.
- Never leave children unattended in the vehicle.

Requirements

The power supply or the vehicle has been switched on.



- Closing
- Opening

The buttons on the driver's door take precedence.

- To start automatic operation: press the <a>[E] button beyond the point of resistance or pull and release it.
- To interrupt automatic operation: press or pull the 📋 button again.

When the vehicle is switched off, you can continue to operate the side windows.

The function is also available until the doors are closed again.

Automatic reversing function of the side windows If an obstacle impedes a side window during the closing process, the side window will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

- During the closing process, make sure that no body parts are in the closing area.
 - ★ WARNING Risk of becoming trapped despite there being reversing protection on the side window

The reversing function does not react:

- to soft, light and thin objects, e.g. fingers.
- · during resetting.

The reversing function cannot prevent someone from becoming trapped in these situations.

- During the closing process, make sure that no body parts are in the closing area.
- If someone becomes trapped, press the <a> button to open the side window again.

Automatic function of the side windows

In the following cases, the side windows will be closed automatically when the vehicle is switched off:

- if it starts to rain
 Rain is detected by a rain sensor on the wind-screen.
- · in extreme temperatures
- after a certain time (depending on the onboard electrical system voltage)
- if there is a malfunction in the power supply

The side windows will be closed as far as the ventilation position.

Vehicles with a panorama sliding sunroof: the side windows will be closed completely if the sliding sunroof is open.

If the side windows are obstructed during automatic closing, the side window concerned will open again slightly. After another automatic closing process, the automatic function may be deactivated. The automatic function will be active again the next time the vehicle is started.

Convenience opening (ventilating the vehicle before starting a journey)

A

WARNING Risk of entrapment when opening a side window

When opening a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- When opening, make sure that nobody is touching the side window.
- Release the button immediately if some-body becomes trapped.

Requirements

- The key is in the immediate vicinity of the vehicle.
- Press and hold the button on the key. The following functions are performed:
 - The vehicle is unlocked.
 - The side windows are opened.
 - The panoramic sliding roof is opened.
 - The seat ventilation of the driver's seat is switched on.
- If the roller sunblind of the panoramic sliding sunroof is closed, the roller sunblind is opened first.
- To interrupt convenience opening: release ∃ the button.
- To continue convenience opening: press and hold the 글 button again.

Convenience closing (closing the vehicle from outside)

WARNING Risk of entrapment due to not paying attention during convenience closing

When the convenience closing feature is operating, parts of the body could become trapped in the closing area of the side window and the sliding sunroof.

When the convenience closing feature is operating, monitor the entire closing process and make sure that no body parts are in the closing area.

Requirements

- The key is in the immediate vicinity of the vehicle.
- Press and hold the button on the key. The following functions are performed:
 - The vehicle is locked.
 - The side windows are closed.
 - · The panoramic sliding roof is closed.

- To interrupt convenience closing: release the \Delta button.
- To continue convenience closing: press and hold the \(\bigota \) button again.
- Convenience closing also functions with KEY-LESS-GO (\rightarrow page 87).

Resolving problems with the side windows

WARNING Risk of becoming trapped or fatally injured if reversing protection is not activated

If you close a side window again immediately after it has been blocked, the side window will close with increased or maximum force. The reversing function is then not active and body parts may become trapped.

- Make sure that no parts of the body are in the closing area.
- To stop the closing process, release the button or press the button again to reopen the side window.

A side window cannot be closed and you cannot see the cause.

- Check to see whether any objects are in the window guide.
- Adjust the side windows.

Adjusting the side windows

If a side window is obstructed during closing and reopens again immediately:

Immediately after this, pull and hold the corresponding button again until the side window has closed and hold the button for at least one more second (re-adjustment).
The side window will be closed without the

The side window will be closed without the automatic reversing function.

If the side window is obstructed again and reopens again immediately:

Immediately after this, pull and hold the corresponding button again until the side window has closed and hold the button for at least one more second (follow-up adjustment).
The side window will be closed without the automatic reversing function.

The side windows cannot be opened or closed using the convenience opening feature.

Possible causes:

- · The key battery is weak or discharged.
- Check the battery using the indicator lamp (\rightarrow) page 76).
- Replace the key battery, if necessary (→ page 78).

Sliding sunroof

Opening and closing the sliding sunroof

- i The term "sliding sunroof" refers to the panorama sliding sunroof.
- WARNING Risk of becoming trapped when the sliding sunroof is being opened and closed

Body parts may become trapped in the range of movement.

- During the opening and closing process, make sure that no body parts are in the sweep of the sliding sunroof.
- If someone is trapped, release the control panel immediately.

or

 Touch the control panel during automatic operation.
 The opening/closing process will be stopped.

WARNING Risk of entrapment if the sliding sunroof is operated by children

Children operating the sliding sunroof could get caught in the moving parts, particularly if unattended.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.

WARNING Risk of becoming trapped when the roller sunblind is being opened and closed

Body parts may become trapped between the roller sunblind and frame or sliding roof.

- During the opening or closing process, make sure that no body parts are in the roller sunblind's range of movement.
- If someone is trapped, release the control panel immediately.

or

Touch the control panel during automatic operation.

The opening/closing process will be stopped.

NOTE Malfunction due to snow and ice

Snow and ice may cause the sliding sunroof to malfunction.

Open the sliding sunroof only if it is free of snow and ice.

NOTE Damage caused by protruding objects

Objects that protrude from the sliding sunroof may damage the seals.

- Do not allow anything to protrude from the sliding sunroof.
- NOTE Damage to panorama sliding sunroof caused by roof luggage rack

If the panorama sliding sunroof is opened when a roof luggage rack is fitted, the panorama sliding sunroof may be damaged by the roof luggage rack.

Do not open the panorama sliding sunroof if a roof luggage rack is fitted.



The sliding sunroof and the roller sunblind are operated using control panel 1.

The panorama sliding sunroof can be operated only when the roller sunblind is open.

- To open: swipe backwards across control panel (1) and hold.
- To close: swipe forwards across control panel and hold.

104 Opening and closing

- ➤ To raise or lower: press control panel triefly.
- ➤ To start automatic operation: swipe forwards or backwards across control panel ①.
- ➤ To cancel automatic operation: press control panel again.

 The opening/closing process will be stopped.

Automatic reversing function of the sliding sunroof

If an obstacle obstructs the sliding sunroof during the closing process, the sliding sunroof will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

During the closing process, make sure that no body parts are in the closing area.

WARNING Risk of becoming trapped despite reversing function

The reversing function will not react:

- to soft, light and thin objects, e.g. fingers.
- towards the end of the closing procedure.

- · during resetting.
- During the closing process, make sure that no body parts are in the closing area.
- If someone is trapped, release the control panel immediately.

or

attentiveness.

Touch the control panel during automatic closing.

The closing process will be stopped.

Automatic reversing function of the roller sunblind If an obstacle obstructs the roller sunblind during the closing process, the roller sunblind will open again automatically. The automatic reversing function is only an aid and is not a substitute for your

When closing the roller sunblind, make sure that no body parts are in the range of movement.

WARNING Risk of becoming trapped despite reversing function

In particular, the reversing function does not react to soft, light and thin objects, e.g. fingers.

- When closing the roller sunblind, make sure that no body parts are in the range of movement.
- If someone is trapped, release the control panel immediately.

or

▶ Touch the control panel during automatic closing.

The closing process will be stopped.

Automatic functions of the sliding sunroof

i The term "sliding sunroof" refers to the panorama sliding sunroof.

The sliding sunroof will be closed automatically when the vehicle has been switched off in the following situations:

if it starts to rain

Rain is detected by a rain sensor on the windscreen.

- in extreme temperatures
- after a certain time (depending on the onboard electrical system voltage)
- if there is a malfunction in the power supply

The sliding sunroof will rise at the rear in order to continue ventilating the vehicle interior.

If the sliding sunroof is obstructed during an automatic closing procedure, the roof will be opened again slightly. The automatic function for the sliding sunroof and the side windows will then be deactivated.

Rain closing function when driving Vehicles with a panorama sliding sunroof: if it starts to rain, the raised sliding sunroof will automatically be lowered while the vehicle is in motion.

Automatic lowering function Vehicles with a panorama sliding sunroof: if the sliding sunroof is raised at the rear, it will automatically be lowered slightly at higher speeds. At low speeds, it will be raised again automatically.

WARNING Risk of becoming trapped by automatic lowering of the sliding sunroof

At higher speeds, the raised sliding sunroof will automatically be lowered slightly at the rear.

- Make sure that nobody reaches into the sliding sunroof's range of movement while the vehicle is in motion.
- If someone becomes trapped, touch the control panel.

Rectifying problems with the sliding sunroof

WARNING Risk of becoming trapped or fatal injuries when the sliding sunroof is closed again

If you close the sliding sunroof again immediately after it has been blocked or reset, the sliding sunroof will close with increased or maximum force.

There is a risk of becoming trapped or even of fatal injuries!

- Make sure that no parts of the body are in the closing area.
- If someone is trapped, release the control panel immediately.

or

Touch the control panel during automatic closing.

The closing process will be stopped.

The sliding sunroof cannot be closed and you cannot see the cause.

(i) The term "sliding sunroof" refers to the panorama sliding sunroof.

If the sliding sunroof is obstructed during closing and reopens again slightly:

Immediately after automatic reversing, swipe forwards across the control panel (→ page 102) and hold until the sliding sunroof is closed.

The sliding sunroof will be closed with increased force.

If the sliding sunroof is obstructed again and opens again slightly:

106 Opening and closing

Repeat the previous step. The sliding sunroof will be closed again with increased force.

The sliding sunroof or the roller sunblind is not operating smoothly.

Reset the sliding sunroof and the roller sunblind.

Resetting the sliding sunroof and the roller sunblind

- Swipe forwards across the control panel (→ page 102) and hold repeatedly until the sliding sunroof is completely closed.
- Press and hold the control panel for another second.
- Press and hold the control panel until the front roller sunblind is completely closed.
- Press and hold the control panel for another second.
- Use automatic operation to fully open and then close the sliding sunroof.


Roller sunblinds

Extending the rear side window roller sunblinds

I NOTE Damage to the inertia reel due to it snapping back

If suddenly snapped back, the inertia reel may be damaged.

- Always move the roller sun blind by hand.
- Do not drive with the roller sun blind hooked in and rear side windows opened at the same time.



Pull the roller sunblind out by tab
and hook it onto brackets
at the top of the window.

Extending or retracting the rear-window roller sunblind


WARNING Risk of becoming trapped when extending or retracting the roller sunblind

Body parts may become trapped in the roller sunblind's range of movement.

- Ensure there are no body parts in the range of movement.
- If someone becomes trapped, briefly press the button again. The opening or closing process will briefly be stopped. The roller sunblind will then return to its starting position.
- **NOTE** Damage caused by objects

Objects can cause the roller sunblind to malfunction.

- Do not place any objects on the rear shelf.
- Ensure that the roller sunblind can move freely.



To extend or retract: press button ①.

Anti-theft protection Function of the immobiliser

The immobiliser prevents your vehicle from being started without the correct key.

This also applies to the Digital Vehicle Key.

The immobiliser is automatically activated when the vehicle is switched off, and deactivated when the vehicle is switched on.

ATA (Anti-Theft Alarm system)


Function of the ATA system

If the ATA system is primed, a visual and audible alarm is triggered in the following situations:

- when a door is opened
- when the boot lid is opened
- when the bonnet is opened
- when interior protection is triggered $(\rightarrow page 109)$
- when tow-away protection is triggered $(\rightarrow page 108)$
- Vehicles with Digital Vehicle Key: The EDW works with the Digital Vehicle Key in the same way as with the conventional vehicle key.

The ATA system is primed automatically after approximately ten seconds in the following situations:

- · after locking the vehicle with the key
- after locking the vehicle using KEYLESS-GO
- After locking with the NFC function (vehicles with digital vehicle key:)



Indicator lamp

flashes when the ATA system is primed.

The ATA system is deactivated automatically in the following situations:

- after unlocking the vehicle with the key
- after unlocking the vehicle using KEYLESS-GO
- after unlocking with the NFC function (vehicles with digital vehicle key)
- after pressing the start/stop button with the key in the stowage compartment (→ page 185)

Deactivating the ATA

Press the ট্রি, 🕲 or 🐒 button on the key.

or

- Press the start/stop button with the key in the stowage compartment (→ page 185)
- Vehicles with digital vehicle key: Press the start/stop button with the digital vehicle key in the storage compartment (→ page 183).

Deactivating the alarm using KEYLESS-GO

 With the key outside the vehicle, touch the inner surface of the door handle.
 This also applies to the Digital Vehicle Key.

Function of tow-away protection

An audible and visual alarm is triggered if an alteration to your vehicle's angle of inclination is detected while tow-away protection is primed.

Tow-away protection is automatically primed after approximately 60 seconds:

- after locking the vehicle with the key
- after locking the vehicle using KEYLESS-GO
 This also applies to the Digital Vehicle Key.
- After locking with the NFC function (vehicles with digital vehicle key:)

Tow-away protection is only primed when the following components are closed:

- Doors
- Boot lid

Tow-away protection is automatically deactivated:

- after pressing the ∂ or ₺ button on the key
- after pressing the start/stop button with the key in the stowage compartment $(\rightarrow page 185)$
- after pressing the start-stop button with the digital vehicle key in the storage compartment (Vehicles with digital vehicle key) $(\rightarrow page 183)$
- after unlocking the vehicle using KEYLESS-GO This also applies to the Digital Vehicle Key.
- after unlocking with the NFC function (vehicles with digital vehicle key)
- when using HANDS-FREE ACCESS

Information on collision detection on a parked vehicle (\rightarrow page 214).

Priming/deactivating tow-away protection

Multimedia system:

- → Settings >> Vehicle ▶ Opening/closing ▶ Vehicle protection
- Prime or deactivate Tow-away protection.

Tow-away protection is primed again in the following cases:

- The vehicle is unlocked again.
- A door is opened.
- The vehicle is locked again.

Function of interior protection

When interior protection is primed, a visual and audible alarm is triggered if movement is detected in the vehicle interior.

Interior protection is primed automatically after approximately ten seconds:

- after locking the vehicle with the key
- after locking the vehicle using KEYLESS-GO This also applies to the Digital Vehicle Key.

After locking with the NFC function (vehicles with digital vehicle key:)

Interior protection is only primed when the following components are closed:

- Doors
- Boot lid

Interior protection is automatically deactivated:

- after pressing the 🔒 or 🐒 button on the key
- after pressing the start/stop button with the key in the stowage compartment $(\rightarrow page 185)$
- after pressing the start-stop button with the digital vehicle key in the storage compartment (Vehicles with digital vehicle key) $(\rightarrow page 183)$
- after unlocking the vehicle using KEYLESS-GO This also applies to the Digital Vehicle Key.
- after unlocking with the NFC function (vehicles with digital vehicle key)
- when using HANDS-FREE ACCESS

110 Opening and closing

The following situations can lead to a false alarm:

- when there are moving objects suchas mascots in the vehicle interior
- if a side window is open
- if the panoramic sunroof is open

Priming/deactivating interior protection

Multimedia system:

▶ Opening/closing ▶ Vehicle protection

► Prime or deactivate Interior motion sensor.

Interior protection is primed again in the following cases:

- The vehicle is unlocked again.
- A door is opened.
- The vehicle is locked again.

Notes on the correct driver's seat position



WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.




Ensure the following when adjusting steering wheel 1, seat belt 2 and driver's seat 3:

- · You are sitting as far away from the driver's airbag as possible, taking the following points into consideration:
- You are sitting in an upright position
- Your thighs are slightly supported by the seat cushion

- Your legs are not fully extended and you can depress the pedals properly
- The back of your head is supported at eye level by the centre of the head restraint
- You can hold the steering wheel with your arms slightly bent
- You can move your legs freely
- You can see all the displays on the driver's display clearly
- You have a good overview of the traffic conditions
- Observe the notes on correctly fastening the seat belt (\rightarrow page 41).

Notes on grab handles



If you apply your full body weight to the grab handle or pull it abruptly, the grab handle may be damaged or come loose from its anchorage. This may result in injuries.

Use the grab handles only to stabilise the seating position or to assist in getting in and out of the seat.

Seats

Adjusting the front seat manually and electrically (with Seat Comfort Package)

WARNING Risk of becoming trapped if the seats are adjusted by children

Children could become trapped if they adjust the seats, particularly when unattended.

- ► When leaving the vehicle, always take the key with you and lock the vehicle.
- Never leave children unattended in the vehicle.

You can adjust the seats when the vehicle is switched off.

WARNING Risk of becoming trapped during seat adjustment

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

Make sure when adjusting a seat that no one has any body parts in the sweep of the seat.

This also applies to the Digital Vehicle Key. Observe the safety notes on "Airbags" and "Children in the vehicle".

WARNING Risk of accident due to the driver's seat not being engaged

The driver's seat may move unexpectedly while driving.

This could cause you to lose control of the vehicle.

Always make sure that the driver's seat is engaged before starting the vehicle.

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

WARNING Risk of injury due to head restraints not being fitted or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- ► Always drive with the head restraints fitted.
- Before driving off, make sure for every vehicle occupant that the centre of the head restraint supports the back of the head at about eye level.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

WARNING Risk of injury or death due to incorrect seat position

The seat belt will not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you may slip under the seatbelt and injure vourself.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the centre of your shoulder.

WARNING Risk of potentially fatal injuries due to objects trapped under the front passenger seat

Objects trapped under the front passenger seat may interfere with the function of the automatic front passenger airbag shutoff or damage the system.

- Do not stow any objects under the front passenger seat.
- When the front passenger seat is occupied, ensure that no objects have become trapped beneath the front passenger seat.
- NOTE Damage to the seats when adjusting


The seats may be damaged by objects when adjusting the seats.

When adjusting the seats, make sure that there are no objects in the footwell, under or behind the seats.

NOTE Damage to the roof lining during adjustment

The roof lining may be damaged when you adjust the front seats.

Adjust the head restraints first before adjusting each seat height.



- Seat backrest inclination
- Seat height
- Seat cushion inclination
- Seat cushion length
- Seat fore-and-aft position
- To adjust the seat fore-and-aft position: lift lever
 and slide the seat into the desired position.

Make sure that the seat is engaged.

Adjusting the front seat fully electrically

lack

WARNING Risk of becoming trapped if the seats are adjusted by children

Children could become trapped if they adjust the seats, particularly when unattended.

- When leaving the vehicle, always take the key with you and lock the vehicle.
- Never leave children unattended in the vehicle.

This also applies to the Digital Vehicle Key. You can adjust the seats when the vehicle is switched off.



WARNING Risk of becoming trapped during seat adjustment

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

Make sure when adjusting a seat that no one has any body parts in the sweep of the seat.

Observe the safety notes on "Airbags" and "Children in the vehicle".

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- · if you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

WARNING Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

WARNING Risk of injury due to head restraints not being fitted or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints fitted.
- Before driving off, make sure for every vehicle occupant that the centre of the head restraint supports the back of the head at about eye level.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

WARNING Risk of injury or death due to incorrect seat position

The seat belt will not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

In particular, you may slip under the seatbelt and injure yourself.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is

routed across the centre of your shoulder.

WARNING Risk of potentially fatal injuries due to objects trapped under the front passenger seat

Objects trapped under the front passenger seat may interfere with the function of the automatic front passenger airbag shutoff or damage the system.


- Do not stow any objects under the front passenger seat.
- When the front passenger seat is occupied, ensure that no objects have become trapped beneath the front passenger seat.

! NOTE Damage to the seats when adjusting

The seats may be damaged by objects when adjusting the seats.


When adjusting the seats, make sure that there are no objects in the footwell, under or behind the seats.

The switches for adjusting the seats do not move. You will therefore receive no direct feedback on the switch while pressing the switch. Feedback is provided only by the movement of the seat.



- Head restraint height
- Seat height
- Seat cushion inclination
- Seat cushion length
- Seat fore-and-aft position
- Seat backrest inclination
- Save the settings with the memory function $(\rightarrow \text{ page } 128)$.

Adjusting the 4-way lumbar support



- Higher
- Softer

- 1 ower
- Firmer
- Use buttons (1) to (3) to adjust the contour of the backrest.

Head restraints

Adjusting the head restraints on the front seats

★ WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint,

steering wheel and mirror, and fasten your seat belt.

WARNING Risk of injury due to incorrectly adjusted head restraints

If head restraints have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or sudden braking.

Before driving off, make sure for every vehicle occupant that the centre of the head restraint supports the back of the head at about eye level.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

Seats with manual and electric seat adjustment



- Take hold of the head restraint on both sides and press release knob ①.
- To move forwards or backwards: pull the head restraint forwards or push it backwards.
- ➤ To move upwards or downwards: push the head restraint upwards or downwards.
- Let go of release knob ①.

Seats with electric seat adjustment



- Take hold of the head restraint on both sides and press release knob
 .
- To move forwards or backwards: pull the head restraint forwards or push it backwards.
- Let go of release knob ①.
- To move upwards or downwards: adjust the head restraint using the buttons on the door operating unit (→ page 114).

Adjusting the head restraints of the rear seats manually


WARNING Risk of injury due to head restraints not being fitted or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints fitted.
- Before driving off, make sure for every vehicle occupant that the centre of the head restraint supports the back of the head at about eye level.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

(i) Move all head restraints up at least to the first detent. If a head restraint is in the lowest. non-locked position, the respective seat must not be used.



To raise: push release knob (1) in the direction of the arrow and pull the head restraint up until it engages.

To lower: press release knob (1) in the direction of the arrow and push the head restraint down until it engages.

Fitting/removing the rear seat head restraints


WARNING Risk of injury due to head restraints not being fitted or being adjusted incorrectly

If head restraints have not been installed or have not been adjusted correctly, there is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints fitted.
- Before driving off, make sure for every vehicle occupant that the centre of the head restraint supports the back of the head at about eye level.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

Removing



- Release the rear seat backrest and fold it forwards slightly (\rightarrow page 133).
- Press release knob 2 and pull the head restraint upwards as far as it will go. Release knob (1) will extend.

120 Seats and stowing

- Push both release knobs (1) and (2) at the same time in the direction of the arrow and pull out the head restraint.
- Fold the rear seat backrest back until it engages.

Fitting

- Release the rear seat backrest and fold it forwards slightly (→ page 133).
- Insert the head restraint such that the notches on the bar are on the left when viewed in the direction of travel.
- Push the head restraint down until it engages.
- Fold the rear seat backrest back until it engages.

Configuring the seat settings

Multimedia system:



Adjusting the air cushions

In the corresponding menu, adjust the air cushions for Lumbar or Side bolsters.

Setting the seat heating balance

- Select Heating settings.
- Select Seat heating balance.
- Adjust the heat distribution for the desired seat.

Setting automatic seat adjustment

WARNING Risk of becoming trapped during adjustment of the driver's seat after calling up a driver profile

Selecting a user profile may trigger an adjustment of the driver's seat to the position saved under the user profile. You or other vehicle occupants could be injured in the process.

Make sure that when the position of driver's seat is being adjusted using the multimedia system, no people or body parts are in the seat's range of movement.

If there is a risk of someone becoming trapped, immediately stop the adjustment process by:

a) Pressing the warning message on the central display.

or

 b) Pressing a position button of the memory function or a seat adjustment switch in the driver's door.
 The adjustment process is stopped.

Multimedia system:

Manually adjusting driver's seat and steering wheel position to body size

The vehicle calculates a suitable driver's seat and steering wheel position on the basis of the driver's body size and sets this directly.

- To set the unit of measurement: select cm or ft/in.
- Set the size using the scale.
- Select Start positioning.
 The driver's seat and steering wheel position is adjusted to the body size that has been set.

- You can also configure these settings via the Mercedes me user account for your user profile. By synchronising the profiles in the vehicle and the Mercedes me connect profiles, you can carry over these settings for your vehicle. Further information about synchronising user profiles (\rightarrow page 339).
- If the driver's seat and steering wheel position calculated by the vehicle is not practical or comfortable, it can be manually adapted at any time via the control buttons. The outside mirrors are not set via this function. Instead, they have to be set manually via the operating switches.

Overview of relaxation programmes

- Depending on the vehicle equipment, different massage programmes are available:
- Classic Massage Calming back relaxation programme.
- Relaxing MassageRelaxing back massage with increasing wave motions and then soothing movements.

- Wave Massage Regenerating relaxation programme via soothing waves across the back and in the seat cushion.
- Deep Wave Massage: Wave-like movements in the cushion can promote blood flow and metabolic processes in the legs.
- Hot Stone Massage: Massage combined with heat. A back massage is started. In addition, warm pressure points become noticeable, starting in the pelvic area.
- Activating Massage: This massage is designed to aid your health and attention on long journeys. The activating stimulation including deliberately chosen pauses to keep you attentive and awake in monotonous driving conditions.

Selecting a relaxation programme for the front seats

Multimedia system:

- ¬→ 🙀 >> Comfort >> Massage
- Select a massage programme (\rightarrow page 121).

- Start the programme for the desired seat 🕨
- To set the relaxation intensity: switch High intensity on or off.
- The availability of this function is dependent on the vehicle's equipment.

Resetting seat settings

Multimedia system:

¬→ 🔝 >> Comfort >> Seat

- Select Reset.
- Select for the desired seat.

Switching the seat heating on/off

WARNING Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

In particular, the health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.

Do not repeatedly switch on the seat heating.

To protect against overheating, the seat heating may be temporarily deactivated after it has been switched on repeatedly.


NOTE Damage to the seats caused by objects or documents when the seat heater is switched on

When the seat heater is switched on, overheating may occur due to objects or documents placed on the seats e.g. seat cushions or child seats. This could cause damage to the seat surface.

Make sure that no objects or documents are on the seats when the seat heater is switched on.

Requirements

The power supply is switched on.



Press button for the respective seat repeatedly until the desired heating level is reached.
 Depending on the heating level, up to three indicator lamps will light up. If all indicator lamps are off, the seat heating is switched off.

- The seat heating will automatically switch down from the three heating levels after 8, 10 and 20 minutes until the seat heating switches off.
- i) If you switch the power supply off and on again within 20 minutes, the previous setting of the seat heating for the driver's seat will remain active.
- You can set the heat distribution of the heated sections among the seat cushions and seat backrests of the front seats in the multimedia system (→ page 120).

Setting the panel heating

Multimedia system:

- → Comfort → Seat
- ➤ Heating settings ➤ Panel heating


The armrests can be heated when the seat heating is switched on.

Switch the function for the desired seats on or off.

Switching the seat ventilation on/off

Requirements:

• The power supply is switched on.



Press button (1) for the respective seat repeatedly until the desired blower setting is reached. Depending on the blower setting, up to three indicator lamps will light up. If all indicator

lamps are off, the seat ventilation is switched off.

If you switch the power supply off and on again within 20 minutes, the previous seat ventilation setting for the driver's seat will remain active.

Steering wheel

Adjusting the steering wheel manually

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint,

steering wheel and mirror, and fasten your seat belt.

WARNING Risk of entrapment for children when adjusting the steering wheel

Children could injure themselves if they adjust the steering wheel.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.


This also applies to the Digital Vehicle Key.

Unlocking



- Fold release lever 1 down as far as it will go.
- Adjust height 2 and distance 3 to the steering wheel.

Locking



- Fold release lever 1 up as far as it will go.
- Check and make sure that the steering column is locked by moving the steering wheel.

Adjusting the steering wheel electrically

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:


- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion.
- if you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten vour seat belt.

WARNING Risk of entrapment for children when adjusting the steering wheel

Children could injure themselves if they adjust the steering wheel.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.

This also applies to the Digital Vehicle Key. The steering wheel can be adjusted when the power supply is disconnected.



- To move up
- To move back
- To move down
- To move forward
- Save the settings with the memory function $(\rightarrow page 128)$.

Linking the steering wheel heater to the seat heating

Requirements

• The power supply or the vehicle has been switched on.

Multimedia system:

- → Comfort >> Seat
- ➤ Heating settings
- Tap on Additional steering wheel heater. The steering wheel heater will be linked to the seat heating.

When the function has been activated, the steering wheel heater will automatically be activated and deactivated when you switch the seat heating on and off.

Easy entry and exit feature

Using the easy entry and exit feature



WARNING Risk of accident when pulling away during the adjustment process of the easy entry and exit feature

You could lose control of the vehicle.

Always wait until the adjustment process is complete before driving off.

This also applies to the Digital Vehicle Key. **Vehicles with memory function:** you can stop the adjustment process by pressing one of the memory function position switches.



WARNING Risk of becoming trapped if children activate the easy entry and exit feature

Children could become trapped if they activate the easy entry and exit feature, particularly when unattended.

Never leave children unattended in the vehicle.

When leaving the vehicle, always take the key with you and lock the vehicle.

This also applies to the Digital Vehicle Key. In order to use the easy entry and exit feature, the automatic seat adjustment function must have been switched on (\rightarrow) page 120).

When the easy entry and exit feature is active, the steering wheel and driver's seat will move as follows:

- The steering wheel will move upwards.
- The driver's seat will move forward or backward to a seat position suitable for getting out of the vehicle.

This will occur in the following situations:

- You switch off the vehicle when the driver's door is open.
- You open the driver's door when the vehicle is switched off.
- The steering wheel will then move upwards only if it is not already as high as it will go. The driver's seat will then move backwards

only if it is not already at the rear of the seat adjustment range.

The steering wheel and the driver's seat will move back to the last driving position in the following cases:

- You switch the power supply or the vehicle on when the driver's door is closed.
- You close the driver's door when the vehicle is switched on.

The last drive position will be saved when:

- · You switch off the vehicle.
- Vehicles with memory function: you call up the seat settings via the memory function.

Vehicles with memory function: press one of the memory function position switches to stop the adjustment process.

Setting the easy entry and exit feature

Requirements

The automatic seat adjustment has been activated (→ page 120).

Multimedia system:

- → 🔝 >> Settings >> Vehicle
- >> Easy entry and exit feature
- Select Steering wheel and seat, Steering wheel only or Off.
- If you are using an individual user profile, this information is used for the easy entry and exit feature. This will cause the driver's seat and steering wheel to move into the correct position automatically (\rightarrow page 336).

Memory function

Function of the memory function

WARNING Risk of an accident if the memory function is used while driving

If you use the memory function on the driver's side while driving, you could lose control of the vehicle as a result of the adjustments being made.

Only use the memory function on the driver's side when the vehicle is stationary.

WARNING Risk of entrapment when adjusting the seat with the memory function

When the memory function adjusts the seat, you and other vehicle occupants - particularly children - could become trapped.

- During the adjusting process of the memory function, ensure that no body parts are in the area of movement of the seat or the steering wheel.
- If someone becomes trapped, press a preset position button or seat adjustment switch immediately. The adjustment process is stopped.

WARNING Danger of entrapment when memory function is activated by children

When children activate the memory function. they can get trapped, especially if they are unsupervised.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.

This also applies to the Digital Vehicle Key.

You can use the memory function when the vehicle is switched off.

Seat adjustments for up to three people can be stored and called up using the memory function.

You can save the following settings for the front seat:

- · Seat, backrest, head restraint position and contour of the seat backrest in the lumbar region
- Seat heating: distribution of the heated sections of the seat cushion and seat backrest

128 Seats and stowing

- Driver's side: steering wheel position and position of the outside mirrors on the driver's and front passenger sides
- Head-up display

Operating the memory function

WARNING Risk of an accident if the memory function is used while driving

If you use the memory function on the driver's side while driving, you could lose control of the vehicle as a result of the adjustments being made.


- Only use the memory function on the driver's side when the vehicle is stationary.
- **WARNING** Danger of entrapment when memory function is activated by children

When children activate the memory function, they can get trapped, especially if they are unsupervised.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.


This also applies to the Digital Vehicle Key. You can use the memory function when the vehicle is switched off.

Storing



- Set the seat, the steering wheel, the head-up display and the outside mirror to the desired position.
- Press the M button and then release it.

Press one of the preset position buttons **1**, 2 or 3 within three seconds. An acoustic signal sounds. The settings are stored.



To call up: press the preset position button 2 or 3 The seat is moved to the stored position. After releasing the button, the front seat, outside

mirror, head-up display and steering column

continue to move into the stored position automatically.

Stowage areas

Notes on loading the vehicle

DANGER Risk of exhaust gas poisoning

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the boot lid is open when the engine is running, especially if the vehicle is in motion.

- Always switch off the engine before opening the boot lid.
- Never drive with the boot lid open.

Objects in the deployment area of an airbag may prevent the airbag from functioning correctly. Observe the notes on protection provided by the airbag (\rightarrow page 47).

WARNING Risk of injury from unsecured items in the vehicle

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be thrown around and thereby hit vehicle occupants.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around.
- Before the journey, secure objects, luggage or loads against slipping or tipping over.

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.
- ▲ WARNING Risk of accident from objects in the driver's footwell and front-passenger footwell

Objects in the driver's footwell and frontpassenger footwell may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell or front-passenger footwell.
- Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient clearance for the pedals.
- Do not use loose floor mats and do not lay multiple floor mats on top of one another.

Vehicles with automatic front-passenger airbag shutoff: Objects trapped under the front-passenger seat may interfere with the operation of the automatic front-passenger airbag shutoff or damage the system. Please observe the notes on the operation of the automatic front-passenger airbag shutoff.

A

WARNING Risk of burns from the tailpipe and tailpipe trims

The exhaust tailpipe and tailpipe trims can become very hot. If you come into contact

with these parts of the vehicle, you could burn yourself.

- Always be particularly careful around the tailpipe and the tailpipe trims and supervise children especially closely in this area.
- Allow vehicle parts to cool down before touching them.
- Leather is a natural product. It exhibits natural surface properties such as, e. g. differences in structure, marks caused by growth and injury or subtle colour differences. These surface properties are characteristics of leather and not material faults. Leather is also subject to a natural ageing process during which the surface properties change.

The handling characteristics of your vehicle are dependent on the distribution of the load within the vehicle. You should bear the following in mind when loading the vehicle:

 Do not exceed the permissible total mass or the permissible axle loads of the vehicle (including load and occupants). information can be found on the vehicle identification plate (\rightarrow page 630).

- The load must not protrude above the upper edge of the seat backrests.
- · Always place the load behind unoccupied seats if possible.
- · Secure the load using the lashing eyelets and distribute the load evenly.

Notes on driving with a roof load

- Distribute the roof load and the load inside the vehicle evenly, placing heavy objects at the bottom. Also comply with the notes on loading the vehicle (\rightarrow page 129).
- Drive attentively, avoiding abrupt starts, braking and steering as well as rapid cornering.
- When transporting roof loads and when the vehicle is fully loaded or fully occupied, select one of the driving modes **E** or **C**. These are designed to focus on stability $(\rightarrow page 194)$.

Stowage spaces in the vehicle interior

Overview of the front stowage compartments

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.

Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.

Observe the notes on loading the vehicle.



- Stowage spaces in the doors
- Stowage and telephone compartment beneath the armrest with USB ports
- Stowage compartment in the front centre console with cup holders, USB ports and charging module for wireless charging of mobile phones
- Glove compartment

- The compartment under armrest ② and the stowage compartment in centre console ③ are connected via a channel so that cables can be routed through them. This allows, for example, USB cables for connecting devices to be stowed in both compartments.
- The rubber mat in the stowage compartment in front centre console and be removed for cleaning with clean, lukewarm water. Please comply with the notes on caring for the interior (→ page 482).
- Opening and closing the stowage compartment in the front centre console

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.

Observe the notes on loading the vehicle.



- ➤ To open: slide the cover of the stowage compartment in the front centre console all the way forwards in the direction of the arrow using handle ①.
- To close: briefly push handle of the open cover of the stowage compartment in the front centre console forwards.
 The cover will automatically close the stowage

compartment in the front centre console.

Locking/unlocking the glove compartment

WARNING Risk of injury due to objects being stowed incorrectly


If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.

Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.

Observe the notes on loading the vehicle.



Turn the emergency key a quarter turn clockwise 2 (to lock) or anti-clockwise 1 (to unlock).

Through-loading feature in the rear bench seat (EASY-PACK Quickfold)

Folding the rear seat backrests forward

WARNING Risk of becoming trapped when adjusting the seats

When you adjust a seat, you may trap yourself or a vehicle occupant.

When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.

WARNING Risk of an accident because the seat backrest is not engaged

The seat backrest may fold forwards.

There is a risk of the following, in particular:

The vehicle occupant may be pressed against the seat belt. The seat belt cannot protect as intended and could cause additional injury.

134 Seats and stowing

- A child restraint system is no longer properly supported or properly positioned and may no longer fulfil its function as intended.
- The seat backrest cannot restrain objects or goods in the boot or load compartment.

Always ensure that the seat backrest is engaged, especially:

- After the seat has been adjusted.
- After the load compartment enlargement has been folded forwards

Make sure that the red marking of the lock verification indicator is no longer visible. Otherwise, the seat backrest is not locked.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly. Particular attention must be paid to children.

Requirements:

The rear seat backrest head restraints are fully inserted.


• The rear armrest has been folded up.

Folding the rear outer seat backrests forward You can fold the centre and right seat backrests forwards separately.


The left seat backrest can be folded forwards only together with the centre seat backrest.

If you no longer require the folded-down rear seat backrest as a load area, fold the backrest back into place.

Ensure that the centre seat backrest is in an upright position and locked to the left seat backrest (→ page 137).



- Press the seat belt tongue of seat belt 1 into marked position 2.
- Move the driver's or front passenger seat forwards, if necessary.



To fold the left seat backrest forward: briefly press left button 1.

The left seat backrest folds forward together with the centre seat backrest.

If the left seat backrest is not locked with the centre seat backrest, this will be shown on the central display.

To fold the right seat backrest forward: briefly press right button 1. The right seat backrest will fold forwards.


(i) If you wish to fold only one of the outer seat backrests forwards, fold the right seat backrest forwards.

Folding the centre rear seat backrest forwards separately

If you no longer require the folded-down seat backrest as a load area, fold the backrest back into place.



- Press release catch 3.
- Fold seat backrest 2 forwards.
- Folding back the rear seat backrest



When you adjust a seat, you may trap yourself or a vehicle occupant.

- When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.
- **WARNING** Risk of an accident because the seat backrest is not engaged

The seat backrest may fold forwards.

There is a risk of the following, in particular:

- The vehicle occupant may be pressed against the seat belt. The seat belt cannot protect as intended and could cause additional injury.
- A child restraint system is no longer properly supported or properly positioned and may no longer fulfil its function as intended.
- The seat backrest cannot restrain objects or goods in the boot or load compartment.

Always ensure that the seat backrest is engaged, especially:

After the seat has been adjusted.

• After the load compartment enlargement has been folded forwards

Make sure that the red marking of the lock verification indicator is no longer visible. Otherwise, the seat backrest is not locked.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly. Particular attention must be paid to children.

NOTE Damage caused by trapping the seat belt when folding back the seat backrest

The seat belt could become trapped and thus be damaged when the seat backrest is folded back.

Make sure that the seat belt is not trapped when folding back the seat backrest.



- Move the driver's or front passenger seat forwards, if necessary.

Locking and releasing the release catch of the centre rear seat backrest

WARNING Risk of becoming trapped when adjusting the seats

When you adjust a seat, you may trap yourself or a vehicle occupant.

When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.

WARNING Risk of an accident because the seat backrest is not engaged

The seat backrest may fold forwards.

There is a risk of the following, in particular:

- The vehicle occupant may be pressed against the seat belt. The seat belt cannot protect as intended and could cause additional injury.
- · A child restraint system is no longer properly supported or properly positioned and

may no longer fulfil its function as intended.

• The seat backrest cannot restrain objects or goods in the boot or load compartment.

Always ensure that the seat backrest is engaged, especially:

- · After the seat has been adjusted.
- After the load compartment enlargement has been folded forwards

If the seat backrests are not engaged and locked in place, the red lock verification indicators will be visible.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly. Particular attention must be paid to children.


You can lock the centre seat backrest release catch if you want to secure the boot against unauthorised access. The centre seat backrest can then be folded forwards only together with the left seat backrest.



To lock or unlock: slide catch 1 upwards or downwards.

Overview of the tie-down eyes

Observe the notes on loading the vehicle $(\rightarrow page 129)$.




1 Tie-down eyes

Objects or items of luggage may be flung around and hit vehicle occupants.

- Only hang light objects on the bag hooks.
- Never hang hard, sharp-edged or fragile objects on the bag hooks.


Observe the notes on loading the vehicle (\rightarrow page 129).

Subject the bag hooks to a maximum load of 3 kg and do not attach any goods to them. $\,$



Bag hooks

Overview of bag hooks



The bag hooks cannot restrain heavy objects or items of luggage.

Attaching a roof luggage rack

WARNING Risk of accident due to exceeding the maximum roof load

The vehicle centre of gravity and the usual driving characteristics as well as the steering and braking characteristics alter.

If you exceed the maximum roof load, the driving characteristics, as well as steering and braking, will be greatly impaired.

Never exceed the maximum roof load and adjust your driving style.

You will find information on the maximum roof load in the "Technical data" section in the printed Owner's Manual.

NOTE Damage to the vehicle due to not observing the maximum permitted headroom clearance


If the vehicle height is greater than the maximum permitted headroom clearance, the roof and other parts of the vehicle may be damaged.

- Observe the signposted headroom clearance.
- If the vehicle height is greater than the permitted headroom clearance, do not enter.
- Observe the changed vehicle height with add-on roof equipment.
- NOTE Damage to the panorama sliding sunroof due to non-approved roof luggage racks

The panorama sliding sunroof may be damaged by the roof luggage rack if you attempt to open it when using a roof luggage rack not tested and approved for Mercedes-Benz.

When a roof luggage rack is fitted, open the panorama sliding sunroof only if this has been tested and approved for Mercedes-Benz

The panorama sliding sunroof may be raised to allow ventilation of the vehicle interior.



NOTE Damage to the covers

The covers may be damaged and scratched when being opened.


- ▶ Do not use metallic or hard objects.
- Carefully fold covers 1 upwards in the direction of the arrow.

140 Seats and stowing

- Secure the roof luggage rack to the fastening points beneath covers ①.
- Comply with the installation instructions of the roof luggage rack manufacturer.
- Secure the load on the roof luggage rack.

Cup holders

Fitting or removing the cup holder in the centre console



The cup holder cannot hold a container secure while the vehicle is in motion.

If you use a cup holder while the vehicle is in motion, the container may be flung around and liquids could be spilled. The vehicle occupants may come into contact with the liquid and if it is hot, they could be scalded. You could be distracted from traffic conditions and you may lose control of the vehicle.

- Only use the cup holder when the vehicle is stationary.
- Only use the cup holder for containers of the right size.
- Always close the container, particularly if the liquid is hot.

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.


There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Always stow objects in such a way that they cannot be thrown around in such situations.

- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
 - Close the lockable stowage spaces before starting a journey.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.


The cup holder can be removed for cleaning. Observe the notes on loading the vehicle $(\rightarrow$ page 129).

Inserting a cup holder




- Starting with corner (3), insert the cup holder and rotate it into place in the recess in the trim using both tabs 2.
- Rotate the cup holder into the compartment and push housing (1) down until it engages.

Removing the cup holder



- Push the side wall of rear beverage compartment 4 to the left until the cup holder releases.
- Using corner (5), swing out the cup holder to the front left.
- Reinsert the cup holder after cleaning.

Removing/fitting mats




Insert mats 6 in the cup holder beverage compartments can be removed for cleaning.

- To remove: use a suitable tool to push the insert mats out of their mounting from the rear of the removed cup holder.
- To install: press mats into the cup holder housing until they engage.

Using the cup holder

(i) Check whether the beverage container is held firmly by the cup holder. Some beverage containers will not be secured adequately in the cup holder due to their shape or size.

The side wall of the front beverage compartment can be retracted and extended manually.



Gently push a beverage container into the bottom ② of the beverage compartment.
 The side panel will automatically extend to the left to secure the beverage container.

Alternatively, you can extend the side wall of the beverage compartment by pressing lightly on grooved surface ①.

Retracting the side wall

When the front beverage compartment is not in use, the side panel can be retracted manually. The cup holder's holding function will then no longer be available.



Push the side panel back in the direction of the arrow until it engages in correct position


3.

Sockets

Using the 12 V socket in the front passenger footwell

Requirements

· Only connect devices up to a maximum of 180 W (15 A).



12 V socket in the front passenger footwell

- Fold up the cap on socket 1.
- Insert the plug of the device.
- Make sure that no cables are running through or secured in the airbag deployment area when using the socket. Also observe the notes on airbag protection (\rightarrow page 47).

Using USB ports

Depending on its equipment, the vehicle has the following USB ports:

- two USB ports in the stowage compartment in the front centre console
- one or two USB ports in the stowage compartment under the front armrest
- two USB ports in the rear centre console

You can charge a USB device, such as a mobile phone, at the USB ports using a suitable charging cable. Depending on the vehicle equipment, the devices can be charged with up to 20 V (5 A) when the vehicle is switched on.

Wireless charging of the mobile phone and connection with the exterior aerial

Notes on wirelessly charging a mobile phone

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone receptacles cannot always retain all objects within.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects so that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.

Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot/load compartment.

Observe the notes on loading the vehicle.

WARNING Risk of fire from placing objects in the mobile phone stowage compartment

Placing other objects in the mobile phone stowage compartment could constitute a fire hazard.

- Apart from a mobile phone, do not place any other objects in the mobile phone stowage compartment, especially those made of metal.
- NOTE Damage to objects caused by placing them in the mobile phone stowage compartment

If objects are placed in the mobile phone stowage compartment, these may be damaged by electromagnetic fields.

- Do not place credit cards, storage media, ski passes or other objects sensitive to electromagnetic fields in the mobile phone stowage compartment.
- NOTE Damage to the mobile phone stowage compartment caused by liquids

If liquids enter the mobile phone stowage compartment, the compartment may be damaged.

Ensure that no liquids enter the mobile phone stowage compartment.

Always observe the notes for persons with electronic medical aids (\rightarrow page 34).

- Depending on the vehicle equipment, the mobile phone is connected to the vehicle's exterior aerial via the charging module.
- The charging function and wireless connection of the mobile phone to the vehicle's exterior aerial are only available if the vehicle is switched on.

- Small mobile phones may not be able to be charged in every position of the mobile phone stowage compartment.
- Large mobile phones which do not rest flat in the mobile phone stowage compartment may not be able to be charged or connected with the vehicle's exterior aerial.
- The mobile phone may heat up during the charging process. This may also depend on the applications (apps) currently open in the background.
- To ensure more efficient charging and connection with the vehicle's exterior aerial, remove the protective cover from the mobile phone.
 Protective covers which are necessary for wireless charging are an exception.

Wirelessly charging a mobile phone in the front

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around

and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always retain all objects they contain.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around in such situations
- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot.


Observe the notes on loading the vehicle.

Requirements:

The mobile phone is suitable for wireless charging.

A list of compatible mobile phones can be found at: https://www.mercedes-benzmobile.com/

It is possible to wirelessly charge a mobile phone in the front stowage compartment of the vehicle's centre console.



Wirelessly charging a mobile phone in the front stowage compartment

Place the mobile phone as close to the centre of mat 1 as possible with the display facing upwards.

When the charging symbol is shown in the multimedia system, the mobile phone is being charged. In addition, malfunctions during the mobile phone's charging process are shown in the multimedia system display.

(i) The mat can be removed for cleaning, e.g. using clean, lukewarm water.

Radio equipment approval numbers for Brazil

This device operates on a secondary basis, that is to say it has no protection against harmful interference, not even from the same type of stations, and must not cause interference with systems operating on a primary basis.

This product is permitted in accordance with the procedure defined in Directive 242/2000 by the Brazilian telecommunications agency ANATEL and meets the applicable technical requirements.

Further information is available on the ANATEL website, www.anatel.gov.br

Further information on the declaration of conformity for vehicle components which receive and/or transmit radio waves.

Fitting and removing floor mats


WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.

Fitting floor mats



- Slide the corresponding seat backwards and lay the floor mat in the footwell such that it fits.
- Press studs ① onto holders ②.
- Adjust the corresponding seat.

Removing floor mats

- Slide the corresponding seat backwards and pull the floor mat off holders 2.
- Adjust the corresponding seat.

Exterior lighting

Notes on adjusting the lights when driving abroad

As a convenience function, the headlamps automatically adjust when you cross the border into countries where traffic drives on the other side of the road. If necessary, the headlamps can also be adjusted manually in the Low beam menu $(\rightarrow page 158)$.

The automatic light adjustment function is available:

- If Automatic is activated in the Low beam menu
- If the navigation and the navigation position are available

In the following cases, check the headlamp setting and change it manually if necessary:

- If the Low beam setting (left/right-side traffic) Manual adjustment only display message is displayed.
- If the Check low beam setting (left/rightside traffic) display message is displayed.

Following manual adjustment:


- Oncoming traffic will not be dazzled.
- The edge of the road will not be illuminated as far or as high.
- The "motorway mode" and "enhanced fog light" functions will not be available.

Information about lighting systems and your responsibility

The various lighting systems of the vehicle are only aids. The driver of the vehicle is responsible for correct vehicle illumination in accordance with the prevailing light and visibility conditions, legal requirements and traffic situation.

Light switch

Operating the light switch



- **←P** Left-hand parking lights
- **P** ∈ → Right-hand parking lights
- Standing lights and licence plate light-
- **AUTO** Automatic driving lights (preferred light switch position)

5 D Low beam/high beam

O\$ Switches the rear fog light on/off.

When low beam is activated, the [305] indicator lamp for the standing lights will be deactivated and replaced by the [30] low-beam indicator lamp.

- Always park your vehicle safely using sufficient lighting, in accordance with the relevant legal stipulations.
- ! NOTE Battery discharging by operating the standing lights

Do not have the standing lights switched on over a period of several hours.

For vehicles that are wider than 2 m or longer than 6 m, single-sided parking lighting is not permitted in some countries. In this case, the standing lights are also switched on in the parking lights position.

If the battery is insufficiently charged, the standing lights or parking lights will be switched off automatically to facilitate the next engine start.

The exterior lighting (except standing and parking lights) will switch off automatically when the driver's door is opened.

 Observe the notes on locator lighting (→ page 159).

Switching on accident scene lighting

- Switch off the vehicle.
- Switch on the hazard warning lights (\rightarrow) page 150).
- ➤ Turn the light switch from the AUTO position to the ☑D position. The low beam will be switched on despite the vehicle being switched off.

The accident scene lighting will be switched off if:

- vou switch off the hazard warning lights.
- you turn the light switch back to AUTO.
- the battery is insufficiently charged.

Automatic driving lights function

When the vehicle is switched on, the standing lights, low beam and daytime running lights will be switched on automatically depending on the light conditions.

A

WARNING Risk of accident when the dipped beam is switched off in poor visibility

When the light switch is set to AUTO, the dipped beam may not be switched on automatically if there is fog, snow or other causes of poor visibility such as spray.

In such cases, turn the light switch to

The automatic driving lights are only an aid. You are responsible for the vehicle lighting.


Switching the rear fog light on/off

Requirements:

- The light switch is in the D or AUTO position.
- ► Press button 0 .

Please observe the country-specific laws on the use of rear fog lamps.

Operating the combination switch for the lights



- High beam
- Turn signal light, right
- Headlamp flashing
- Turn signal light, left
- Use the combination switch to select the desired function.

Switching on high beam

- Turn the light switch to the or auto position.
- Push the combination switch in the direction of arrow 1. When high beam is activated, the indicator lamp for low beam will be deactivated and replaced by the indicator lamp for high beam **≣**□.

Switching off high beam

Push the combination switch in the direction of arrow or pull it in the direction of arrow

Headlamp flashing

Pull the combination switch in the direction of arrow 3.

Turn signal light


To indicate briefly: push the combination switch briefly to the point of resistance in the direction of arrow 2 or 4. The corresponding turn signal light will flash three times.

To indicate permanently: push the combination switch beyond the point of resistance in the direction of arrow 2 or 4.

Vehicles with Active Lane Change Assist:

- · A turn signal indicator activated by the driver may continue to operate for the duration of the lane change.
- · If the driver indicated directly beforehand but a lane change was not immediately possible, the turn signal indicator may activate automatically.

Activating/deactivating the hazard warning lights



Press button 1.

The hazard warning lights will switch on automatically if:

- · the airbag has been deployed.
- · the vehicle is braked heavily from a speed of more than 70 km/h to a standstill.

When you pull away again, the hazard warning light system will switch off automatically at approximately 10 km/h. You can also switch off the hazard warning light system using the warning lamp button.

DIGITAL LIGHT adaptive functions

Intelligent Light System function

You can watch an animation on this topic via the following link:

With this system, the headlamps adapt to the driving and weather situation. It also provides extended functions for improved illumination of the road.

The system comprises the following functions:

- Active headlamps (→ page 150)
- Cornering light (→ page 151)
- Motorway mode (→ page 151)
- Enhanced fog light function (\rightarrow page 151)
- Bad weather light (\rightarrow page 152)
- City lighting (\rightarrow page 152)
- Topographical compensation (\rightarrow page 152)

The system is active only when it is dark.

Active headlamps function




- The headlamps follow the steering movements.
- Relevant areas are better illuminated during a journey.

The functions are active when the low beam is switched on.

Depending on the vehicle's equipment, the course of the lane in which you are driving will also be evaluated and the active headlamps function will adjust the light in advance.

Cornering light function



The cornering light improves the illumination of the carriageway over a wide angle in the turning direction, enabling better visibility on tight bends, for example. The cornering light will be activated only when low beam is switched on.


The function will be active in the following cases:

- At speeds below 40 km/h when the turn signal light is switched on or the steering wheel is turned
- At speeds between 40 km/h and 70 km/h and when the steering wheel is turned

Roundabout and junction function: the cornering light will be activated on both sides based on an evaluation of the vehicle's current navigation position. It will remain active until after the vehicle has left the roundabout or junction.

Motorway mode function

Motorway mode increases the range and brightness of the cone of light, enabling better visibility.



The function will be active if a motorway journey is detected by means of:

- the vehicle's speed
- the multifunction camera
- the navigation system

The function is not active in the following cases:

at speeds below 80 km/h

Enhanced fog light function

The enhanced fog light function reduces self-dazzling and improves the illumination of the edge of the carriageway.



The function is automatically activated under the following conditions:

 At speeds below 70 km/h and when the rear fog light is switched on.

The function is automatically deactivated under the following conditions:

- When speeds greater than 100 km/h are reached.
- When the rear fog light is switched off.

Function of the bad weather light

The bad weather light reduces reflections in rainy conditions by dimming individual areas of the headlamps. The driver and other road users are dazzled less as a result.

The city lighting function

City lighting improves the illumination of roadsides in urban areas using a broad distribution of light.

The function will be active in the following cases:

- At low speeds
- In illuminated parts of urban areas

Function of the topographical compensation

Based on available map data, the lighting system responds pre-emptively to different road heights. This means that the headlamp range remains virtually constant when you are driving on uphill or downhill gradients.

(i) Only vehicles with a multimedia system with navigation have this function.

Assistance functions of DIGITAL LIGHT

DIGITAL LIGHT visually expands on the driver assistance systems by projecting the assistant displays in front of the vehicle while it is in motion. DIGITAL LIGHT can therefore help the driver in critical situations.

- (i) The availability of the functions is dependent on the country.
- (i) The assistance functions of DIGITAL LIGHT may be an on-demand feature (\rightarrow page 25).

The system will be active in the following cases:

- The light switch is in the AUTO position.
- High beam is switched on.
- Depending on the country in which you are currently driving, certain functions may be disabled due to different legal requirements, even if they are enabled in the multimedia system. When you cross a border, the vehicle will automatically adapt to the applicable requirements.

Spotlight




The spotlight function runs in the background and flashes the headlamps in four short bursts at persons detected within the lane markings. You will also be made aware of the position of the person by a projected symbol.

The function will be active in the following circumstances:

- You are driving outside illuminated areas.
- The system detects a lane marking.

Warnings



If Traffic Sign Assist detects a corresponding situation, a triangle will be projected onto the road in the following cases at speeds of at least 30 km/h:

- You are driving in the opposite direction to the permissible direction of travel, e.g. on a motorway slip road.
- You are driving towards a stop sign without reducing your speed.
- · You are driving towards a red traffic light without reducing your speed.


Observe the system limitations of Traffic Sign Assist (\rightarrow page 250).

Notes




If Traffic Sign Assist detects a roadworks zone, the system will provide support as follows:

- A corresponding symbol will be projected onto the road when you enter a roadworks zone.
- When you drive through a roadworks zone, guide lines that roughly match the width of the vehicle will be projected onto the road. The guide lines will be switched off temporarily on tight bends.



Observe the system limitations of Traffic Sign Assist (\rightarrow page 250).


Collision warning



If you fall below the safe distance at speeds of at least 30 km/h, a collision warning symbol will be projected onto the road.

Observe the system limitations of Active Brake Assist (\rightarrow page 243).

Lane change warning



During assisted lane changes at speeds of at least 30 km/h, the course of the lane change as displayed will be brighter. This enables you to identify possible dangers in the new lane at an early stage.

Observe the system limitations of Active Lane Change Assist (\rightarrow page 241).

Lane keeping and blind spot warning



At speeds of at least 30 km/h, a triangle that indicates a lane correction and its direction will be projected onto the road in the following cases:

- You leave the lane unintentionally.
 Observe the system limitations of Active Lane Keeping Assist (→ page 258).
- You switch on the turn signal light while an object or obstacle is in your blind spot.
 Observe the system limitations of Active Blind Spot Assist (→ page 255).

Switching the Intelligent Light System on/off

Requirements

· The vehicle is switched on.

Multimedia system:

→ 🔝 ➤ Settings ➤ Lights

- >> DIGITAL LIGHT
- Activate or deactivate Dynamic low beam.

Activating or deactivating enhanced assistance functions

- i The availability of the functions is dependent on the country.
- This function is an on-demand feature (→ page 25).
- Select Supporting projections.
- Activate or deactivate the desired projections.
- Switch Projection for greeting/farewell on or off.

If the locator lighting or the exterior switch-off delay time is activated, a high-resolution greeting or farewell scene will be played back for a short period of time when the vehicle is

opened or switched off. You can choose between the Digital Rain and Star Wave sequences.

More information on locator lighting $(\rightarrow page 159)$ More information on the exterior switch-off delay time (\rightarrow page 159)

Adaptive Highbeam Assist

Adaptive Highbeam Assist function

WARNING Risk of accident despite Adaptive Highbeam Assist

Adaptive Highbeam Assist does not react to:

- road users without lights, e.g. pedestrians
- road users with poor lighting, e.g. cyclists
- · road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist may fail to recognise other road users with their own lighting, or may recognise them too late.

In these, or in similar situations, the automatic high beam will not be deactivated or will be activated despite the presence of other road users.


Always observe the road and traffic conditions carefully and switch off the high beam in good time.

Adaptive Highbeam Assist cannot take into account road, weather or traffic conditions.

Detection may be restricted in the following cases:

- In poor visibility, e.g. fog, heavy rain or snow
- if there is dirt on the sensors or the sensors are obscured

Adaptive Highbeam Assist is only an aid. You are responsible for adjusting the vehicle's lighting to the prevailing light, visibility and traffic conditions.



Adaptive Highbeam Assist automatically switches between the following types of light:

- Low beam
- High beam

At speeds greater than 30 km/h:

• If no other road users are detected, high beam will switch on automatically.

The high beam will switch off automatically in the following cases:

- At speeds below 25 km/h
- If other road users are detected
- If street lighting is sufficient
- (i) The system's optical sensor is located behind the windscreen near the overhead control panel.
- Switching Adaptive Highbeam Assist on/off

WARNING Risk of accident despite Adaptive Highbeam Assist

Adaptive Highbeam Assist does not react to:

- road users without lights, e.g. pedestrians
- road users with poor lighting, e.g. cyclists
- road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist may fail to recognise other road users with their own lighting, or may recognise them too late.

In these, or in similar situations, the automatic high beam will not be deactivated or will be activated despite the presence of other road users.

Always observe the road and traffic conditions carefully and switch off the high beam in good time.

Switching on

- Turn the light switch to the AUTO position.
- Switch on high beam using the combination switch.

If Adaptive Highbeam Assist is activated, the higher indicator lamp will light up on the driver's display.

Switching off

Switch off high beam using the combination switch.

Adaptive Highbeam Assist Plus

Adaptive Highbeam Assist Plus function

WARNING Risk of accident despite Adaptive Highbeam Assist Plus

Adaptive Highbeam Assist Plus does not react to:

- road users without lights, e.g. pedestrians
- road users with poor lighting, e.g. cyclists
- road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist Plus may fail to recognise other road users with their own lighting, or may recognise them too late.

In these, or in similar situations, the automatic high beam will not be deactivated or will be activated despite the presence of other road users.


Always observe the road and traffic conditions carefully and switch off the high beam in good time.

Adaptive Highbeam Assist Plus cannot take into account road, weather or traffic conditions.

Detection may be restricted in the following cases:

- In poor visibility, e.g. fog, heavy rain or snow
- if there is dirt on the sensors or the sensors are obscured

Adaptive Highbeam Assist Plus is only an aid. You are responsible for adjusting the vehicle's lighting to the prevailing light, visibility and traffic conditions.



Adaptive Highbeam Assist Plus automatically switches between the following types of light:

- Low beam
- Partial high beam
- High beam
- ULTRA RANGE Highbeam

ULTRA RANGE Highbeam increases the brightness of the cone of light to the legally permitted maximum.

Partial high beam does not include other road users in the high beam area. It does not dazzle them but enables full high-beam illumination for the driver apart from the excluded vehicles. Highly reflective signs are also illuminated with reduced brightness.

At speeds below 25 km/h or when there is sufficient street lighting:

· Partial high beam and high beam will be switched off automatically.

At speeds greater than 30 km/h:

- If no other road users are detected, high beam will switch on automatically.
- If other road users are detected, partial high beam will switch on automatically.

at speeds below 40 km/h:

The ULTRA RANGE Highbeam will switch off automatically.

At speeds above 50 km/h:

- If no other road users are detected, the road is straight and it is not raining heavily, the ULTRA RANGE Highbeam will be switched on automatically.
- If other road users are detected, the ULTRA RANGE Highbeam will automatically switch off and the partial high beam will switch on.
- If highly reflective signs are detected, ULTRA RANGE Highbeam will be switched off automatically.
- (i) The system's optical sensor is located behind the windscreen near the overhead control panel.

Switching Adaptive Highbeam Assist Plus on/off

WARNING Risk of accident despite Adaptive Highbeam Assist Plus

Adaptive Highbeam Assist Plus does not react to:

- · road users without lights, e.g. pedestrians
- road users with poor lighting, e.g. cyclists
- · road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist Plus may fail to recognise other road users with their own lighting, or may recognise them too late.

In these, or in similar situations, the automatic high beam will not be deactivated or will be activated despite the presence of other road users.

Always observe the road and traffic conditions carefully and switch off the high beam in good time.

Switching on

- Turn the light switch to the **AUTO** position.
- Switch on high beam using the combination switch.

If Adaptive Highbeam Assist Plus is activated. the indicator lamp will light up on the driver's display. When partial high beam or high beam is active, the corresponding blue indicator lamp will also light up.

Switching off

Switch off high beam using the combination switch.

Setting low beam

Multimedia system:

- → 🔝 >> Settings >> Lights
- ▶ DIGITAL LIGHT ▶ Low beam
- Select Right-side traffic, Left-side traffic or Automatic.

Setting the exterior lighting switch-off delay time

Multimedia system:

- → Settings → Lights
- >> Interior/exterior lighting
- >> Exterior lighting delayed switch off
- Set the switch-off delay time. When the vehicle's engine is switched off, the exterior lighting will be activated for the set time.

Activating/deactivating the locator lighting


Multimedia system:

- → Settings → Lights
- >> Interior/exterior lighting
- Activate or deactivate Locator lighting.

When the function is activated, the exterior lighting will light up for 40 seconds after the vehicle is unlocked or the driver's door is opened when the vehicle is parked and not locked. When you start the vehicle, the locator lighting will be deactivated and the automatic driving lights activated.


Interior lighting

Adjusting the interior lighting



- Switches the front interior lighting on/ off.
- Switches the rear interior lighting on/ off.
- Switches automatic interior lighting control on / off.
- To switch reading lamps on/off: hold your hand under the respective reading lamp 4 or

Operating unit inside the grab handle (rear)



- Reading lamp on the respective side of the vehicle
- Rear interior lighting
- To switch reading lamps on: press button ①. The reading lamp, the interior lighting in the grab handle and the dome lamp on the respective side of the vehicle will light up.
- To switch reading lamps off: press button (1) once or twice.

When you press it once, the interior lighting in the grab handle and the dome lamp on the respective side of the vehicle will go out.

When you press it twice, the reading lamp on the respective side of the vehicle will go out.

To switch the rear interior lighting on/off: press button ②.
The reading lamps, the interior lighting in the grab handle and the dome lamps on both sides of the vehicle will light up or go out.

Adjusting the ambient lighting

Multimedia system:

→ Comfort → Ambient light

Setting the colour

- Select Colour.
- ► Select Monochrome or Multi-colour.
- Set the desired colour or colour scheme.

Sound2Light

 In combination with the selected light colour, the Sound2Light function visually accentuates the sound content.

Adjusting the brightness

Select Brightness.

- Adjust the brightness.
- Depending on the ambient light conditions, the ambient lighting will automatically switch between day and night modes.

Activating the brightness for zones

- Select Brightness.
- Switch off Link zones.
 The Direct, Indirect and Accents zones can be set separately.
- i The Light strip zone can also be set in vehicles with active ambient lighting.

Activating effects

WARNING Risk of accident despite ambient lighting and active ambient lighting effects switched on.

The warning assistance effects are fully active only if the respective driving or driving safety systems are switched on in the Driving Assistance menu.

Ensure that the respective driving or driving safety systems are switched on.

- (i) Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (→ page 215).
- Select Effects.
- Activate the desired effect.
- i Depending on the vehicle equipment, different effects are available.

Night shut-off

 The lines of light on the head-up display can be dimmed while you are driving. This only takes place at night.

Operating feedback effects

- Climate: If changes are made to the temperature setting in the vehicle, the colour of the ambient lighting will change briefly.
- Voice assistant: For vehicles with active ambient lighting, the voice assistant is visually animated.
- Greeting: When you get into the vehicle, a special colour animation will play.

Warning assistance effects

· Warning when exiting: If an object is detected in the blind spot while you are getting out of the vehicle, the ambient lighting in the affected door will flash red.

Further information on the exit warning $(\rightarrow page 255)$.

· Active Lane Keeping Assist: If there is a warning from Active Lane Keeping Assist, the active ambient lighting will flash red. Further information on Active Lane Keeping Assist (\rightarrow page 258).

- Active Brake Assist: If there is an Active Brake Assist warning, the active ambient lighting in the centre of the cockpit will flash bright red. Further information on the Active Brake Assist $(\rightarrow page 243).$
- Active Blind Spot Assist: In vehicles with active ambient lighting, the ambient lighting on the affected side will flash red if there is a warning from Active Blind Spot Assist. Further information on Active Blind Spot Assist (\rightarrow page 255).

• Parking Assist PARKTRONIC: The information from the parking sensors during parking manoeuvres is displayed in colour.

Further information on Parking Assist PARKTRONIC: (\rightarrow) page 271)

Multi-colour animation

- The chosen colour combination will change at predefined intervals.
- In vehicles with active ambient lighting, an animation will be played.
- The desired operating feedback and warning assistance can be activated or deactivated via the symbol. Depending on the equipment, different operating feedback and warning assistance effects are available.
- If the brightness is set to a low level, warning animations will be displayed at a higher basic brightness.

You can watch an animation on this topic via the following link:

Switching the interior lighting switch-off delay time on/off


Multimedia system:

- → 🔝 >> Settings >> Lights
- >> Interior/exterior lighting
- >> Interior lighting delayed switch off
- Activate or deactivate Interior lighting delayed switch off. If this function is active, the interior lighting

will be switched on for a short time after the end of the journey.

Windscreen wipers and windscreen washer system

Switching the windscreen wipers on/off



- Windscreen wipers off
- 2 Automatic wiping, normal
- Automatic wiping, frequent

- Continuous wiping, slow
- Continuous wiping, fast
- Turn the combination switch to the corresponding position 1 - 5.
- Single wipe/washing: push the button on the combination switch in the direction of arrow
 - Single wipe
 - Wipes with washer fluid
- Observe the notes on washing the vehicle in a car wash (\rightarrow page 477).

Replacing the windscreen wiper blades

WARNING Risk of becoming trapped if the windscreen wipers are switched on while wiper blades are being replaced

If the windscreen wipers begin to move while you are changing the wiper blades, you can be trapped by the wiper arm.


Always switch off the windscreen wipers and vehicle before changing the wiper blades.

Moving the wiper arms into the replacement position

- Switch the vehicle on and then off again immediately.
- Within around 15 seconds, press and hold the button on the combination switch for approximately three seconds (\rightarrow page 162). The wiper arms will move into the replacement position.


Removing the wiper blades

Fold the wiper arms away from the windscreen.



- Hold the wiper arm with one hand. With the other hand, turn the wiper blade away from the wiper arm in the direction of arrow (1) as far as it will go.
- Press release button 2.
- Remove the wiper blade from the wiper arm in the direction of arrow 3.

Fitting the wiper blades




- Push the new wiper blade into the wiper arm in the direction of arrow 1 until release knob 2 engages.
- Make sure that the wiper blade is seated correctly.
- Fold the wiper arms back onto the windscreen.

- Switch on the vehicle.
- Press the button on the combination switch.
 - The wiper arms will return to their original positions.
- Switch off the vehicle.
- Check the condition of the wiper blades regularly and replace them in the event of visible damage or ongoing smearing.

Maintenance display

There is a maintenance display at the tip of the newly mounted wiper blade.



Remove protective film (1) from the maintenance display.

When the colour of the maintenance display changes from black to yellow, the wiper blades should be replaced.

Mirrors

Operating the outside mirrors

WARNING Risk of accident due to adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations in particular:


- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- · if you fasten your seat belt while the vehicle is in motion
- Before starting the vehicle: in particular, adjust the driver's seat, head restraint, steering wheel and mirror, and fasten your seat belt.

WARNING Risk of accident due to misjudgement of distance when using the outside mirror

The outside mirrors reflect objects on a smaller scale. The objects in view are in fact closer than they appear.

► Therefore, always look over your shoulder in order to ensure that you are aware of the actual distance between you and the road users driving behind you.

Adjusting the outside mirrors



- Use button 2 or 4 to select the desired mirror.
- In vehicles with MBUX Interior Assistant and driver camera, the required outside mirror can also be preselected automatically via a natural head movement to the left or right(\rightarrow page 350).

Use button 1 to adjust the position of the selected mirror.

Folding the outside mirrors in/out (vehicles with electrically folding outside mirrors)

- Briefly press button 3.
- If the battery has been disconnected or has discharged, the outside mirrors must be moved briefly using button 3. Only then will the automatic mirror folding function work properly.

Engaging the outside mirrors

If an outside mirror has been forcibly disengaged, proceed as follows.

- Vehicles without electrically folding outside mirrors: manually move the outside mirror into the correct position.
- Vehicles with electrically folding outside mirrors: press and hold button 3. You will hear a click and the mirror will audibly engage. The outside mirror will now be set to the correct position.

Automatic anti-dazzle mirrors function

WARNING Risk of acid burns and poisoning due to the anti-dazzle mirror electro-

Electrolyte may escape if the glass in an automatic anti-dazzle mirror breaks.

The electrolyte is hazardous to health and causes irritation. It must not come into contact with your skin, eyes, respiratory organs or clothing or be swallowed.

- If you come into contact with electrolyte, observe the following:
 - · Immediately rinse the electrolyte from your skin with water and seek medical attention.
 - If electrolyte comes into contact with your eyes, immediately rinse them thoroughly with clean water and seek medical attention.
 - If the electrolyte is swallowed, immediately rinse your mouth out thoroughly. Do not induce vomiting. Seek medical attention immediately.

166 Light and sight

- Immediately change out of clothing which has been contaminated with electrolyte.
- If an allergic reaction occurs, seek medical attention immediately.

The inside rearview mirror and the outside mirror on the driver's side will automatically go into anti-dazzle mode if light from a headlamp hits the sensor on the inside rearview mirror.

System limits

The system will not go into anti-dazzle mode if:

- · The vehicle is switched off.
- Reverse gear is engaged.
- The interior lighting is switched on.

Front-passenger outside mirror parking position function

The parking position makes parking easier.

The front-passenger outside mirror will swivel downwards in the direction of the rear wheel on the front passenger's side when:


- the parking position is stored (\rightarrow page 166).
- the front-passenger mirror is selected.
- · reverse gear is engaged.

The front-passenger outside mirror will move back to its original position when:

- you shift the transmission to another transmission position.
- you are travelling at a speed greater than 15 km/h.
- you press the button for the outside mirror on the driver's side.


Storing the parking position of the frontpassenger outside mirror using reverse gear

Storing



- Select the front-passenger outside mirror using button 2.
- Engage reverse gear.
- Move the front-passenger outside mirror into the desired parking position using button ①.

Calling up



- Adjusts the outside mirrors.
- Selects the front-passenger outside mirror.
- Select the front-passenger outside mirror using button 2.
- Engage reverse gear. The front-passenger outside mirror will move into the stored parking position.

Activating/deactivating the automatic mirror folding function

Multimedia system:

→ 📊 >> Settings >> Vehicle

- ▶ Opening/closing
- Activate or deactivate Automatic mirror foldin.


Overview of climate control systems

Notes on climate control

An interior filter in combination with the prefilter in the engine compartment must always be used so that the air conditioning system, pollution level monitoring and the air filtration work correctly. Use filters recommended and approved by Mercedes-Benz. Always have maintenance work carried out at a qualified specialist workshop.

Overview of the climate bar

The indicator lamps indicate that the corresponding functions are activated.




Front climate bar on the central display (example)

- Sets the air distribution on the left
- \$\ Increases or reduces the airflow on the left or switches on climate control $(\rightarrow page 169)$
- Increases/reduces the temperature on the left
- Calls up the fine particulate status display (\rightarrow page 171) or
- EMENU Calls up the air conditioning menu $(\rightarrow page 171)$
- Demists the windscreen

- Example: witches the rear window heater on / off.
 - The function of this button can be assigned via the climate menu
- Increases/reduces the temperature on the right
- \$\ Increases or reduces the airflow on the right or switches on climate control $(\rightarrow page 169)$
- Sets the air distribution on the right
- The climate bar will remain visible even when the vehicle is parked or the air conditioning is switched off (\rightarrow page 169).
- The airflow is automatically reduced in the event of an incoming call. The airflow can still be adjusted manually via 2 and 9.
- The availability of individual functions depends on the country and equipment.

Overview of the rear operating unit

The rear operating unit is available only for vehicles with the THERMOTRONIC air conditioning control panel.



- Sets air distribution to the centre and side air vents in the rear passenger compartment, left
- Sets the temperature in the rear passenger compartment, left

- Sets the airflow in the rear passenger compartment, left, or switches climate control on/off (\rightarrow page 170)
- Switches climate control on /off $(\rightarrow page 170)$
- Sets the airflow in the rear passenger compartment, right, or switches climate control on/off (\rightarrow page 170)
- Sets the temperature in the rear passenger compartment, right
- Sets air distribution to the centre and side air. vents in the rear passenger compartment, right
- Sets rear climate control to automatic mode. right (\rightarrow page 172)
- Sets the air distribution to the right rear footwell vents
- Synchronisation is activated (\rightarrow page 174)
- Sets the air distribution to the rear left footwell vents
- Sets rear climate control to automatic mode. left (\rightarrow page 172)

The settings for the second row of seats can be configured via the rear operating unit or the multimedia system (→ page 174) depending on the vehicle's equipment.

Operating the climate control system

Switching climate control on/off

Switching on climate control

Set the airflow to level 1 or higher via \$\ \\$ on the climate bar on the central display

Press AUTO OF FMENU.

Switching off climate control

Set the airflow to level 0 via # on the climate bar on the central display

or

Press Ca

If climate control is switched off, the windows may mist up more quickly. Switch climate control off only briefly.

(i) If climate control is switched off via (c), **OFF** will be shown on the climate bar.

Switching climate control on/off via the rear operating unit

Switching on



- Press the button.
- Set the airflow to level 1 or higher using buttons (3) and (5).

or

Press buttons 2, 6, 8 or 2.

Switching off

- Press the **(4)** button.

or

- Set the airflow to level 0 using buttons (3) and **(5)**
- rear climate control is switched off via button (4), OFF will be shown on the display.

Configuring the climate bar

Multimedia system:

→ Climate menu ➤ First row of seats

In the climate menu, you can choose between the different assignments for the freely configurable button on the climate bar.

The following assignments are available on the climate menu:

- PM2.5 Air quality
- Recirculated air
- A/C function

- **SYNC** Synchronisation function
- Rear window heater
- (i) Functions that are not permanently set on the climate bar are available in the climate menu.
- Select 🔼.
- Select the desired function for the button in the window. The function will be applied to the button.
- The window for assigning the button can also be accessed directly by pressing and holding the button once.

Setting the temperature and airflow

Calling up the controller for the temperature and airflow

To call up the controller: press the temperature displayed or \$\ \\$ on the climate bar of the central display

press and hold the temperature displayed or s on the climate bar of the central display

or

swipe on the displayed temperature or \$\\\\$ on the climate bar of the central display.

Setting the temperature

- To increase the temperature: press + or move the controller. Press and hold + to set the temperature to the maximum.
- To lower the temperature: press or move the controller. To switch off climate control, press and hold -.
- The temperature for the driver's and front passenger side can only be operated one after the other.

Setting the airflow

- display.
- To increase the airflow: press + or move the controller. Press and hold + to set the airflow to the maximum.
- To reduce the airflow: press or move the controller. To switch off the airflow, press and hold -.

The airflow will remain active if the AUTO function is activated.

Activating/deactivating the A/C function via the climate bar

The A/C function heats, cools and dehumidifies the vehicle's interior air.

- Press A/c on the climate bar on the central display.
- The A/c button on the climate bar of the central display can also be assigned other functions. If the button on the climate bar is not available, the A/C function can be switched on and off via the climate menu.
- Switch off the A/C function only briefly; otherwise, the windows may mist up more auickly.

Condensation may drip from the underside of the vehicle when cooling mode is active. This is not indicative of a fault.

Calling up the air conditioning menu using the climate bar

The air conditioning menu can be called up via the climate bar. The climate bar is always shown on the lower edge of the central display.

Select the Menu entry in the climate bar. The First row of seats menu is opened.

Jumping directly to the Air quality menu

- Select the [PM2.5] fine particle prefilter status display in the air conditioning bar. The Air quality menu is opened. An animation of the automatic air cleaning taking place is shown.
- The fine particle prefilter status display is on the home screen next to the temperature display on the right and it informs you of the current particulate levels inside and outside of the vehicle.

The measurement values are shown with the ug/m³ units (microgrammes per cubic metre).

Strong acceleration after longer parking periods will lead to a detachment of the dust covering the vehicle. This dust measured by the PM2.5 sensor might lead to a short rise of outside values.

Defrosting the windscreen via the climate bar

Switching on

Press on the climate bar on the central display.

Switching off

Press , auto or c on the climate bar on the central display

or

- set the airflow to 0.
- When the defrost function is activated, some functions (e.g. the temperature setting or the air distribution) will automatically be deactivated.

Activating/deactivating the A/C function via the air conditioning menu

Multimedia system:

→ Climate menu → First row of seats

Depending on the external conditions, support for improved cooling and dehumidification of the interior air will be provided when the A/C function is activated. If it is not possible to operate the A/C function on the climate bar on the central display, switch the function on or off in the climate menu of the central display.

Select A/C (A/C).

Condensation may drip from the underside of the vehicle when cooling mode is active. This is not indicative of a fault.


Setting climate control to automatic mode

In automatic mode, the set vehicle interior temperature is controlled automatically and maintained at a constant level by the air supply.

- Press son the climate bar on the central display and then select AUTO.
- You can increase or reduce the airflow via a controller by pressing on the climate bar of the multimedia system. In the event of an incoming call, the airflow is automatically reduced. The airflow can still be adjusted manually by pressing . In automatic mode, five levels can be set via the controller and seven levels can be set without automatic mode.

Setting climate control to automatic mode via the rear operating unit

In automatic mode, the temperature is automatically regulated by the temperature of the dispensed air and the airflow.



Press the (a) or (12) button.

Overview of the air distribution settings

The symbols on the central display indicate the vents through which the airflow is being directed:

Demister vents

Centre and side air vents

Footwell vents

Setting air distribution and air vents via the air conditioning menu

Multimedia system:

Climate menu

Setting the air distribution

- Select First row of seats or Second row of seats.
- Select an air distribution option using the
- When the air conditioning system is switched on, at least one zone is always active. However, several air distribution options can be selected at the same time, for example to set the climate control for the interior and the footwells simultaneously. In doing so, the climate control for the windscreen can only be selected for the first seat row. When automatic mode is active, the buttons for setting the air distribution are automatically deactivated. When the air conditioning system

is switched off, the buttons remain operable and the last setting is saved.

Setting air distribution for the air vents

Air distribution for the first seat row can also be set automatically in the air conditioning menu using the hybrid operating concept of the air vents.

- Select First row of seats.
- Select 😼
- Select from the various settings Towards the body, Head, Chest, Evenly or Away from the body.
- The air vents automatically move into the set position.
- The air vents can also be set manually using the corresponding controller (\rightarrow page 178).
- The hybrid air vents are equipped with an automatic blockage detection feature. If the air vents are moved using the multimedia system but prevented from doing so by manual intervention or objects, the air vents will return to their previous starting position after two attempts.

Setting rear climate control using the air conditioning menu

Multimedia system:

¬→ Climate menu

Setting the temperature

- Select Second row of seats.
- ► Set the temperature.

Setting the airflow

- Select Second row of seats.
- ➤ Set the air flow with 🛕 or 🔻.

Controlling the rear climate control automatically

- Select AUTO.
 - i) When the defrost function is activated, some functions (e.g. the temperature setting) will automatically be deactivated. To deactivate the defrost function, press either □ Auto or □ set the air flow to level 0 (→ page 172).

Deactivating rear climate control

Select REAR OFF.

Switching the synchronisation function on/off via the air conditioning menu

Multimedia system:

→ Climate menu ➤ First row of seats

The synchronisation function controls the climate control centrally. The driver's settings for temperature, airflow and air distribution are automatically adopted for each climate zone.

Select SYNC (SYNC).

Demisting the windows

Windows misted up on the inside

- Press AUTO on the climate bar on the central display.
- If the windows remain misted up: press make on the climate bar on the central display.

Windows misted up on the outside

- Switch on the windscreen wipers.
- Press **AUTO** on the climate bar on the central display.

Switching air-recirculation mode on/off

Press on the climate bar on the central display.
The interior air will be recirculated.

Air-recirculation mode will automatically switch to fresh air mode after a while.

i If air-recirculation mode is switched on, the windows may mist up more quickly. Switch on air-recirculation mode only briefly.

Switching the air-recirculation mode on/off via the air conditioning menu

Requirements

 A fine particle prefilter is installed in the vehicle.

Multimedia system:

→ Climate menu → Air quality

Press in the upper display area of the climate bar.

The interior air will be recirculated.

Air-recirculation mode will automatically switch to fresh air mode after a while.

- (i) If air-recirculation mode is switched on, the windows may mist up more quickly. Switch on air-recirculation mode only briefly.
- i By selecting the fine particle status display on the climate bar, you can jump directly to the air quality menu.

Switching residual heat mode on/off via the climate bar

Requirements

- The residual heat function is available.
- The vehicle is parked.
- The coolant temperature is sufficiently high.

It is possible to make use of the residual heat from the engine to continue heating or ventilating the front compartment of the vehicle for approximately 30 minutes, depending on the temperature set.

To switch on or off: select Residual heat on the climate bar of the central display.

The residual heat function will automatically switch off after some time.

(i) If residual engine heat utilisation is activated, the two buttons for setting the temperature and air distribution will automatically be deactivated.

Activating/deactivating ionisation

Multimedia system:

→ Climate menu → Air quality

When ionization is activated, the indoor air is enriched with negatively charged oxygen ions. These can promote the well-being of the occupants.

- Select lonisation.
- The function can only be performed if the AUTO mode is activated or the air distribution is set to the side air vent. The function is restricted if the side air vents on the driver's side are closed.

Fragrance system

Activating/deactivating the fragrance system using the multimedia system

Requirements

- · Automatic climate control is activated.
- The glove compartment will close.
- · A flacon is inserted.

Multimedia system:

→ Climate menu → Air quality

The fragrance system distributes a pleasant fragrance throughout the vehicle interior from a flacon located in the glove box.

- Navigate down until the climate control bar is active.
- Select Air freshener.
- Activate or deactivate fragrancing.

Setting the fragrance system

Requirements

- The climate control system is switched on.
- The glove compartment will close.

· A flacon is inserted.

Multimedia system:

→ Climate menu → Air quality

The fragrance system distributes a pleasant fragrance throughout the vehicle interior from a flacon located in the glove box.

- Select Air freshener.
- Keep pressing until the desired intensity is reached.
- Inserting or removing the flacon of the fragrance system
- **WARNING** Risk of injury from liquid perfume


If children open the flacon, they could drink the liquid perfume or it could come into contact with their eyes.

- Do not leave children unattended in the vehicle.
- Consult a doctor immediately if liquid perfume has been drunk.

- If liquid perfume comes into contact with your eyes or skin, rinse your eyes with clean water.
- If symptoms continue, consult a doctor.
- ENVIRONMENTAL NOTE Environmental damage due to improper disposal of full flacons



Full flacons must be taken to a harmful substance collection point.



- Cap
- Placon
- To insert: slide the flacon into the holder as far as it will go.
- To remove: after opening the glove box, wait for approximately seven seconds and pull out the flacon.

If you do not use genuine Mercedes-Benz interior perfumes, observe the manufacturers' safety notices on the perfume packaging.

Dispose of the genuine Mercedes-Benz interior perfume flacon when it is empty and do not refill

Refillable flacon

- Unscrew the cap of the empty flacon.
- Fill the flacon with a maximum of 15 ml.
- Screw the cap back onto the flacon.

Always refill the empty refillable flacon with the same perfume. Observe the separate information sheet with the flacon.

Stationary heater/ventilation

Stationary heater/ventilation function

- The following function is equipment-dependent.
- The air inside the vehicle is heated or ventilated to the set temperature.

- The air inside the vehicle cannot be cooled down to temperatures below the outside temperature.
- If the outside temperature changes, ventilation mode will automatically switch to heating mode or heating mode will automatically switch to ventilation mode.

The stationary heater and the exhaust gas outlet are situated behind the right front wheel.

Switching the stationary heater/ventilation on/off

DANGER Risk of fatal injury due to poisonous exhaust gases

If the tailpipe is blocked or sufficient ventilation is not possible, poisonous exhaust gases such as carbon monoxide may enter the vehicle. This is the case in enclosed spaces or if the vehicle gets stuck in snow, for example.

Always switch the stationary heater off in enclosed spaces without an air extraction system, e.g. in garages.

- Keep the tailpipe and the area around the vehicle free from snow when the vehicle or the auxiliary heating is running.
- Open a door or a roof hatch on the windward side of the vehicle to ensure an adequate supply of fresh air.

WARNING Risk of fire due to hot stationary heater components and exhaust gases

Flammable materials such as leaves, grass or twigs may ignite.

- When the stationary heater is switched on, make sure that:
 - · hot vehicle parts do not come into contact with flammable materials.
 - · the exhaust gas can flow out of the stationary heater exhaust pipe unhindered.
 - the exhaust gas does not come into contact with flammable materials.

NOTE Battery discharge caused by stationary heater or stationary ventilation operation

Operating the stationary heater or stationary ventilation drains the battery.

After heating or ventilating the vehicle twice, drive for a longer period of time.

Requirements

- The vehicle has a stationary heater.
- The outside temperature is below 15°C.
- The fuel tank is sufficiently full.
- (i) If the fill level of the fuel tank is too low, auxiliary heating mode may be restricted.
- ➤ Set the temperature using the ▲ and ▼ arrows on the climate bar on the central display.
- Press the button on the climate bar on the central display.

The red or blue indicator lamp below the button will light up or go out.

The colours of the indicator lamp have the following meanings:

- Blue: stationary ventilation is switched on.
- Red: the stationary heater is switched on.
- Yellow: the departure time is preselected.

The stationary heater/ventilation will switch off automatically after 50 minutes.

Setting the stationary heater/ventilation via the multimedia system

Requirements

The vehicle is fitted with the stationary heater equipment.

Multimedia system:

→ Climate menu >> Stationary heater

Selecting the departure time

Select Time A, Time B or Time C.

Setting the departure time

- ▶ Select Time A, Time B or Time C.
- Select the pen beside the time.
- Set a time.

Air vents

Adjusting the front air vents




WARNING Risk of burns or frostbite due to being too close to the air vents

Very hot or very cold air can flow from the air vents.

- Make sure that all vehicle occupants always maintain a sufficient distance from the air vents.
- If necessary, direct the airflow to another area of the vehicle interior.

To guarantee the flow of fresh air through the air vents into the vehicle interior, note the following:

- Always keep the vents and ventilation grilles in the vehicle interior clear.
- Keep the air inlet free of residue build-up (→ page 477).



- To set the airflow direction of the side air vents: hold controller (1) and move it up or down or to the left or right.
- To set the airflow direction of the centre air vents: hold controller 1 and move it up or down or to the left or right.
- To open or close the side air vents: turn respective controller 2 up or down as far as it will go.
- To open or close the centre air vents: turn respective controller 2 to the left or right as far as it will go.

The air distribution for the first row of seats can also be adjusted electrically via the multimedia system (\rightarrow page 173).

Adjusting the rear air vents

WARNING Risk of burns or frostbite due to being too close to the air vents

Very hot or very cold air can flow from the air vents.

- Make sure that all vehicle occupants always maintain a sufficient distance from the air vents.
- If necessary, direct the airflow to another area of the vehicle interior.



- To open or close: turn controller 2 up or down as far as it will go.
- To set the airflow direction: hold the centre of controller 1 and move it up or down or to the left or right.

Adjusting the rear side air vents



- ➤ To open or close the side air vents in the rear passenger compartment: hold the controller of side air vent and move it up or down as far as it will go.
- To set the airflow direction of the side air vents: hold controller and move it up or down or to the left or right.

Driving

Switching on the power supply or the vehicle



WARNING Accident - and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for example by:


- releasing the parking brake.
- change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

This also applies to the Digital Vehicle Key.

Requirements

- The key is in the vehicle and is recognised.
- Vehicles with Digital Vehicle Key: a Digital Vehicle Key with drive authorisation is detec-
- The brake pedal is not depressed.



To switch on the power supply: press button once.

You can, for example, switch on the windscreen wipers.

The power supply will be switched off again if the following conditions are met:

- You open the driver's door.
- You press button 1 twice more.

To switch on the vehicle: press button twice. Indicator and warning lamps will light up on the driver's display.

The vehicle will be switched off again if one of the following conditions is met:

- You do not start the vehicle within 15 minutes and the transmission is in position P or the electric parking brake is applied.
- You press button ① once.

Starting the vehicle

Starting the vehicle with the start/stop button

DANGER Risk of fatal injuries due to exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Breathing in these exhaust gases is hazardous to health and results in poisoning.

Never leave the engine and, if present, the stationary heater, running in an

enclosed space without sufficient ventilation.

WARNING Risk of fire due to flammable materials in the engine compartment or on the exhaust system

Flammable materials may ignite.

Therefore, regularly check that there are no flammable foreign materials in the engine compartment or on the exhaust system.

WARNING Accident – and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.


In addition, the children could also set the vehicle in motion, for example by:

- releasing the parking brake.
- · change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

This also applies to the Digital Vehicle Key.

Requirements

- The key is in the vehicle and is recognised.
- Vehicles with Digital Vehicle Key: a Digital Vehicle Key with drive authorisation is detected.



- Shift the transmission to position [P] or [N].
- Depress the brake pedal and press button (1) once.
- If the vehicle does not start; switch off nonessential consumer equipment and press button
 once.
- If the vehicle still does not start and the Place the key in the marked space See Owner's

Manual display message appears on the driver's display: start the vehicle with the key in the marked space (emergency operation mode) (\rightarrow page 185).

You can switch off the vehicle while driving. To do this, press and hold button (1) for about three seconds or press button (1) three times within three seconds. Be sure to observe the safety notes concerning this under "Driving tips" (\rightarrow page 187).

Observe any information regarding display messages that may be shown on the driver's display.

Start the vehicle with the Digital Vehicle Key in the marked space (emergency operation mode)

DANGER Risk of fatal injuries due to exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Breathing in these exhaust gases is hazardous to health and results in poisoning.

Never leave the engine and, if present, the stationary heater, running in an

enclosed space without sufficient ventilation.

WARNING Risk of fire due to flammable materials in the engine compartment or on the exhaust system

Flammable materials may ignite.

Therefore, regularly check that there are no flammable foreign materials in the engine compartment or on the exhaust system.

WARNING Accident- and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for example by:


- releasing the parking brake.
- change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

This also applies to the Digital Vehicle Key.

Requirements

- The vehicle is equipped with the "Digital Vehicle Key" pre-installation.
- A suitable end device is activated as a Digital Vehicle Key.
- (i) Mercedes-Benz recommends that you carry the emergency key in case of function restrictions.

If the vehicle does not start and the Please place key in the cup holder or Digital Vehicle Key in inductive charging bracket See Owner's Manual display message appears on the driver's display, you can start the vehicle in emergency operation mode.



Place key 1 in stowage compartment 2.



- Place the Digital Vehicle Key in stowage space 3.
- Depress the brake pedal and start the vehicle using the start/stop button. It may take a few seconds until the vehicle starts.
- When the Key not detected display message appears on the driver display, press the Start/ Stop button again.

Starting the vehicle with the key in the marked space (emergency operation mode)

DANGER Risk of fatal injuries due to exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Breathing in these exhaust gases is hazardous to health and results in poisoning.

Never leave the engine and, if present, the stationary heater, running in an enclosed space without sufficient ventilation.

WARNING Risk of fire due to flammable materials in the engine compartment or on the exhaust system

Flammable materials may ignite.

Therefore, regularly check that there are no flammable foreign materials in the engine compartment or on the exhaust system.

WARNING Accident- and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- · Open doors and thereby endanger other persons or road users.
- · get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for exampleby:

- · releasing the parking brake.
- · change the gearbox setting.
- · start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

This also applies to the Digital Vehicle Key.

If the vehicle does not start and the Place the key in the marked space See Owner's Manual display message appears on the driver's display, you can start the vehicle in emergency operation mode.

Vehicles with Digital Vehicle Key: If the vehicle does not start and the Please place key in the cup holder or Digital Vehicle Key in inductive charging bracket See Owner's Manual display message appears on the driver's display, you can start the vehicle in emergency operation mode.



- Make sure that marked space (2) is empty.
- Remove key 1 from the key ring.

- Place key ① on the symbol in marked space ②.

 The vehicle will start after a short time.

 If you remove key ① from marked space ②, the vehicle can still be driven. For further engine starts, however, key ① must be located on the symbol in marked space ② during the entire journey.
- Have key ① checked at a qualified specialist workshop.

If the vehicle does not start:

- ▶ Place key in marked space and leave it there.
- Depress the brake pedal and start the vehicle using the start/stop button.
- (i) You can switch on the power supply or the vehicle with the start/stop button.

Observe any information regarding display messages that may be shown on the driver's display.

Running-in notes

To preserve the engine during the first 1500 km:

- Drive at varying road speeds and engine speeds.
- No faster than 140 km/h.
- Shift to the next higher gear at the very latest when the needle reaches the last third before the red area in the rev counter.
- Do not shift down manually in order to brake.
- Avoid overstraining the vehicle, e.g. driving at full throttle.
- Do not depress the accelerator pedal past the pressure point (kickdown).
- Only increase the engine speed gradually and accelerate the vehicle to full speed after 1500 km.

This also applies when the engine or parts of the drivetrain have been replaced.

Please also observe the following running-in notes:

- In certain handling and driving safety systems, the sensors adjust automatically while a certain distance is being driven after the vehicle has been delivered or after repairs. Full system effectiveness is only reached when this teaching-in process has concluded.
- Brake pads, brake disks and tyres that are either new or have been replaced only achieve optimum braking effect and grip after driving several hundred kilometres. Compensate the reduced braking effect by applying greater force to the brake pedal.

Notes on optimised acceleration

If all necessary requirements and activation conditions are fulfilled, the best possible acceleration can be achieved from a standstill.

Do not use optimised acceleration on public roads. Individual wheels could spin and you could lose control of the vehicle. There is an increased risk of skidding and/or accident.

Be sure to observe the safety notes and information on ESP[®] (\rightarrow page 218).

Pulling away with optimised acceleration

WARNING Risk of skidding and accidents due to wheelspin

If you pull away with optimised acceleration, individual wheels could spin and you could lose control of the vehicle

There is a higher risk of skidding and accidents when ESP® is deactivated in particular.

Make sure that there are no persons or obstacles in the vicinity of the vehicle.

Requirements

- the vehicle is run in (\rightarrow page 186).
- the vehicle and tyres are in good condition.
- the road surface is high-grip.
- the engine and transmission are at normal operating temperature.

NOTE Increased wear due to optimised acceleration

When pulling away with optimised acceleration, all components of the drivetrain are subjected to a very high load.

This can lead to increased component wear.

- Do not always pull away with optimised acceleration.
- Engage drive position $\boxed{\mathbf{D}}$ (\rightarrow page 200).
- Move the steering wheel to the straight-ahead position.
- Select drive program \bigcirc (\rightarrow page 195).
- Deactivate ESP[®] (\rightarrow page 220).
- Depress and hold the brake pedal firmly with your left foot.
- With your right foot, fully depress the accelerator pedal.

- After no more than five seconds, take your left foot quickly off the brake, but keep the accelerator pedal depressed.
- The vehicle will pull away at maximum acceleration.
- Switch on ESP® once the acceleration procedure is complete.

Ending optimised acceleration

- Remove your foot from the accelerator pedal.
- Reactivate ESP®.
- After you pull away with optimised acceleration, components of the drivetrain can become very hot, which means that optimised acceleration values may be reached again only after a few minutes.

Notes on driving

WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Always fit the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.

WARNING Risk of accident due to incorrect footwear

Incorrect footwear includes, for example:

- shoes with platform soles
- shoes with high heels
- slippers

There is a risk of an accident.

Always wear suitable footwear so that you can operate the pedals safely.

MARNING Risk of accident if the vehicle is switched off while driving

If you switch off the vehicle while driving, safety functions are restricted or no longer available.

This may affect the power steering system and the brake force boosting, for example.

You will need to use considerably more force to steer and brake, for example.

Do not switch off the vehicle while driving.

DANGER Risk of fatal injuries due to exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Breathing in these exhaust gases is hazardous to health and results in poisoning.

Never leave the engine and, if present, the stationary heater, running in an enclosed space without sufficient ventilation.

WARNING Risk of skidding and of an accident due to shifting down on slippery road surfaces

If you shift down on slippery road surfaces to increase the engine braking effect, the drive wheels may lose traction.

Do not shift down on slippery road surfaces to increase the engine braking effect.

DANGER Risk of fatal injury due to poisonous exhaust gases

If the tailpipe is blocked or sufficient ventilation is not possible, poisonous exhaust gases such as carbon monoxide may enter the vehicle. This is the case, for example, if the vehicle gets stuck in the snow.

Keep the tailpipe and the area around the vehicle free from snow when the engine or the stationary heater is running.

- Open a window on the side of the vehicle facing away from the wind to ensure an adequate supply of fresh air.
- WARNING Risk of accident due to the brake system overheating

If you leave your foot on the brake pedal when driving, the brake system may overheat.

This increases the braking distance and the brake system can even fail.

- Never use the brake pedal as a footrest.
- Do not depress the brake pedal and the accelerator pedal at the same time while driving.
- **NOTE** Engine damage due to excessively high engine speeds

The engine will be damaged if you drive with the engine in the overrevving range.

▶ Do not drive with the engine in the overrevving range.

- **NOTE** Causing wear to the brake linings by permanently depressing the brake pedal
- Do not permanently depress the brake pedal while driving.
- To use braking effect of the engine, shift to a lower gear in good time.
- **NOTE** Damage to the drivetrain and engine when pulling away
- Do not warm up the engine while the vehicle is stationary. Pull away immediately.
- Avoid high engine speeds and driving at full throttle until the engine has reached its operating temperature.
- **NOTE** Damage to the catalytic converter due to non-combusted fuel

The engine is not running smoothly and is misfiring.

Non-combusted fuel may get into the catalytic converter.

- Only depress the accelerator pedal slightly.
- Have the cause rectified immediately at a qualified specialist workshop.
- **NOTE** Reduced battery life due to frequent short-distance trips

The 12 V battery may not be sufficiently charged when the vehicle is used only for short-distance trips. This reduces the life of the battery.

- Drive longer distances regularly to charge the battery.
- **NOTE** Damage to the vehicle due to not observing the maximum permitted headroom clearance

If the vehicle height is greater than the maximum permitted headroom clearance, the roof and other parts of the vehicle may be damaged.

- Observe the signposted headroom clearance.
- If the vehicle height is greater than the permitted headroom clearance, do not enter.
- Observe the changed vehicle height with add-on roof equipment.
- i Please bear in mind that all the speed values stated in this Operator's Manual are approximate and are subject to a certain tolerance.

Notes on driving with a roof load, trailer or fully laden vehicle

When driving with a loaded roof luggage rack or trailer as well as with a fully laden or fully occupied vehicle, the vehicle's driving and steering characteristics change.

You should bear the following in mind:

- Do not exceed the permissible roof load and towing capacity. Also observe the information in the Technical Data.
- Distribute the roof load and the load inside the vehicle evenly, placing heavy objects at the

- bottom. Also comply with the notes on loading the vehicle (\rightarrow page 129).
- Drive attentively, and avoid abrupt starts, braking and steering as well as rapid cornering.

Advice on driving on salt-strewn roads

The braking effect is limited on salt-strewn road surfaces.

Therefore, observe the following notes:

- Due to salt build-up on the brake disks and brake pads, the braking distance can increase considerably or result in one-sided braking.
- Maintain a much greater safety distance to the vehicle travelling ahead.

Remove salt build-up as follows:

- Brake occasionally, paying attention to the traffic conditions
- Carefully depress the brake pedal at the end of the journey and when starting the next journey

Notes on aquaplaning

Aquaplaning can take place if a certain depth of water has built up on the road surface.

Observe the following notes during heavy precipitation or in conditions in which aquaplaning may occur:

- Reduce speed
- Avoid tyre ruts
- · Avoid sudden steering movements
- Brake carefully
- (i) Also observe the notes on regularly checking wheels and tyres (→ page 509).

Notes on driving through water on the road

Water ingress can damage the engine, electrics and transmission.

Water can also enter the air intake of the engine and cause engine damage.

Observe the following if you have to drive through water:

- The water, when calm, may reach no higher than the lower edge of the vehicle body.
- Drive at walking speed at most; water can otherwise enter the vehicle interior or the engine compartment.

· Vehicles travelling ahead, or oncoming vehicles, can create waves which may exceed the maximum permissible depth of the water.

The braking effect of the brakes is reduced after fording. Brake carefully, paying attention to the traffic conditions until braking power has been fully restored.

Function of rear axle steering

The rear axle steering is an electromechanical auxiliary steering on the rear axle which adjusts the steering of the rear wheels according to the position of the front wheels, depending on the speed. This results in greater manoeuvrability and improved driving stability, e.g. when cornering. Rear axle steering has the following characteristics:

- reduced steering effort and turning circle resulting in reduced parking effort
- · improved driving stability, e.g. when cornering
- more direct steering resulting in improved handling of the vehicle

Observe the notes on snow chains and snow chain mode (\rightarrow page 510).

ECO start/stop function

ECO start/stop function

Depending on the engine, the ECO start/stop function is not available in all drive programs. Observe the status display on the driver's display concerning this.

The engine will be switched off automatically in the following situations if all vehicle conditions for an automatic engine stop are met:

- You brake the vehicle to a standstill in transmission position \mathbf{D} or \mathbf{N} .
- You depress the brake pedal when travelling at a low speed.

If the system has detected one of the following situations, the engine will not stop:

- You stop at a stop sign and there is no vehicle in front of you.
- The vehicle that stopped in front of you starts up again.

- You manoeuvre, turn the steering wheel sharply or engage reverse gear.
- If the system detects an intelligent stop inhibitor, e.g. a stop sign, the engine will not stop. If you activate the HOLD function or engage the park position **P**, the engine can be switched off in spite of an intelligent stop inhibitor.

The engine will restart automatically in the following cases:

- You engage transmission position **D** or **R**.
- · You depress the accelerator pedal.
- The vehicle requires an automatic engine start.
- You release the brake pedal.
- You release the brake pedal on a downhill gradient and the vehicle does not roll.
- The vehicle rolls on a downhill gradient and does not automatically enter glide mode at 20 km/h.

ECO start/stop function symbols on the driver's display:

- The symbol (green) appears when the vehicle is at a standstill: the engine was switched off by the ECO start/stop function.
- The symbol (yellow) appears when the vehicle is at a standstill: not all vehicle conditions for an engine stop have been met.
- Neither the symbol nor the symbol appears when the vehicle is at a standstill: an intelligent stop inhibitor, e.g. a stop sign, has been detected.
- The symbol appears: the ECO start/stop function is deactivated or there is a malfunction.

If the engine was switched off by the ECO start/ stop function and you leave the vehicle, a warning tone will sound and the engine will not be restarted. In addition, the following display message will appear on the driver's display:

Vehicle is operational Switch off vehicle before exiting

If you do not switch off the vehicle, it will automatically be switched off after three minutes.

Switching the ECO start/stop function on/off

- Press the button.
 A display will appear on the driver's display when you switch the ECO start/stop function on/off.
- (i) (A) will be continuously shown on the driver's display while the ECO start/stop function is deactivated.

ECO display function



The ECO display shows an evaluation of your driving style on the driver's display depending on the situation. This enables you to check the efficiency of your driving style and adjust it if necessary. The ECO display menu shows a ball ② that will roll forwards or backwards on a stylised road in the direction of travel according to the driving characteristics.

Above and below the road, lines mark the area for an efficient driving style ③. Ball ② will light up in green if it is rolling within these lines. Outside the lines, the ball will light up in orange.

The ECO display assesses the following criteria for an economical driving style:

- coasting at the right times
- consistent speed
- moderate acceleration

The overall assessment of your driving style "from start" is indicated using stars ①. It starts with five empty stars, which you can fill one after the other if you drive efficiently. When all five stars are filled, a glow will appear in the background.

You can call up the ECO display function via the Classic menu (\rightarrow page 306).

ECO Assist function (vehicles with 48 V on-board electrical system)

ECO Assist analyses data for the vehicle's expected route. This allows the system to optimally adjust the driving style for the route ahead, save fuel and recuperate. If the system detects an event ahead and the vehicle nears the event. ECO Assist will calculate the optimum speed for maximum fuel economy and recuperative energy based on the distance, speed and downhill gradient.

If the deceleration provided by ECO Assist is not sufficient, you must also brake with the service brake. This is especially the case if, for example, you pull away again in slow-moving traffic and the distance to the vehicle in front is very short.



- "Foot off the accelerator" recommendation
- Route event ahead

If a route event or vehicle that requires an adjustment of your driving style for more efficiency is detected ahead, corresponding symbol 2 and the symbol (grey) will be displayed.

If you release the accelerator pedal, the 🔼 symbol will turn green and recuperation in overrun mode will be initiated. If the deceleration is not sufficient, also apply the service brake. If ECO Assist intervenes for a route event ahead (not for a vehicle in front) and you then press the accelerator pedal again, you end ECO Assist's control.

The ECO Assist display is hidden again in the following cases:

- You do not react to the ECO Assist recommendation for a long time.
- You press the accelerator pedal while ECO Assist is intervening for a route event ahead (not for a vehicle in front).
- · ECO Assist cannot identify any further recommendations from the route ahead.

In addition to a vehicle in front . ECO Assist can detect the following route events (2) depending on the vehicle's equipment:

Roundabout

S-bend

Sharp bend

T-junction

% Downhill gradient

Speed limit

System limits

If the calculated route is adhered to when route guidance is active. ECO Assist will operate with

greater accuracy. The basic function is also available without active route guidance. Not all information and traffic situations can be foreseen. The quality depends on the map data.

ECO Assist is only an aid. The driver is responsible for keeping a safe distance from the vehicle in front, for vehicle speed and for braking in good time.

The system may be impaired or may not function in the following situations:

- If there is poor visibility, e.g. due to insufficient illumination of the road, highly variable shade conditions, rain, snow, fog or heavy spray.
- If there is glare, e.g. from oncoming traffic, direct sunlight or reflections.
- If the windscreen is dirty in the vicinity of the multifunction camera.
- If the multifunction camera is misted up, damaged or obscured.
- If road signs are hard to detect, e.g. due to dirt, snow or insufficient lighting, or because they are obscured.

- If the information in the navigation system's digital map is incorrect or out of date.
- If signs are ambiguous, e.g. road signs in roadworks or in adjacent lanes.
- If the radar sensors are dirty or obscured.
- When you drive on roads with steep uphill or downhill gradients.
- If there are narrow vehicles in front, such as bicycles or motorcycles.

DYNAMIC SELECT button

Function of the DYNAMIC SELECT button

i Depending on the engine and equipment, the vehicle has different drive programs.

Use the DYNAMIC SELECT button to change between the following drive programs:

The drive program selected will appear on the driver's display.

Individual

Individual settings (→ page 195)

s Sport

- Maximum output is available
- Sporty driving
- Sporty, but with an emphasis on stability
- Enables a sporty driver to adopt a more active driving style
- Suitable only for good road conditions, a dry surface and a clear stretch of road
- Vehicles with AIRMATIC: lowers the vehicle to low level -1

C Comfort

- Comfortable and economical driving
- Balance between traction and stability
- Recommended for all road conditions
- Vehicles with AIRMATIC:
 - Adjusts the vehicle to normal level
 - From 120 km/h: lowers the vehicle to low level -1
 - Below 80 km/h: raises the vehicle to normal level

E Eco


- · Particularly economical driving
- Balance between traction and stability
- Recommended for all road conditions
- Vehicles with AIRMATIC: lowers the vehicle to low level -1
- (i) The ESP® settings in the drive programs [E] and are designed for stability. Therefore, choose one of these drive programs especially when transporting roof loads, in trailer operation and when the vehicle is fully loaded or fully occupied.

Depending on the drive program, the following systems will change their characteristics:

- Drive
 - Engine and transmission management
 - Active Distance Assist DISTRONIC
 - Availability of Glide mode
- FSP®
- Vehicles with AIRMATIC: suspension
 - Suspension and damping

- Vehicle level
- Steering
- Sound characteristics of the engine in the vehicle interior

Selecting the drive program



- Press the DYNAMIC SELECT button
 on the left or right.
- The drive program selected will appear on the driver's display.

Configuring DYNAMIC SELECT (multimedia system)

Multimedia system:

→ 🔝 >> Settings >> Vehicle DYNAMIC SELECT

Setting drive program I

- Select I Individual.
- Select and set a category.

Displaying vehicle data

Multimedia system:

→ 🔝 🕪 Info

Select Vehicle.

The vehicle data is displayed.

Displaying engine data

Multimedia system:



- ► Select Engine.
 - The engine data is displayed.
- (i) The actual (maximum) values that can be achieved for engine output and engine torque may deviate from the certified values within the country-specific guidelines for permissible tolerances (basis: UN-ECE No. 85 or country-specific guidelines).

Influencing variables that can influence this are, for example:

- Sea level
- Fuel quality
- · Outside temperature
- Operating temperature of the engine

Adjust your driving style accordingly.

The warning lamp in the driver's display is on until the engine has reached operating temperature.

- The values displayed serve only as orientation. The values for engine output and engine torque shown on the central display may deviate from the actual values.
- i The warning lamp to show the power output limitation after starting the vehicle is not available in all vehicle models.

Automatic transmission

DIRECT SELECT lever

Function of the DIRECT SELECT lever

WARNING Risk of accident due to incorrect gearshifting

If the engine speed is higher than the idle speed and you engage the transmission position $\boxed{\mathbf{D}}$ or $\boxed{\mathbf{R}}$, the vehicle may accelerate sharply.

If you engage the transmission position

D or N when the vehicle is at a standstill, always depress the brake pedal

firmly and do not accelerate at the same time.

WARNING Accident- and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular


- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for exampleby:

- · releasing the parking brake.
- · change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

Use the DIRECT SELECT lever to switch the transmission position. The current transmission position will be shown on the driver's display.




- Park position
- Reverse gear
- N Neutral
- Drive position

Engaging reverse gear R

WARNING Risk of accident due to incorrect gearshifting

If the engine speed is higher than the idle speed and you engage the transmission position **D** or **R**, the vehicle may accelerate sharply.

If you engage the transmission position **D** or **R** when the vehicle is at a standstill, always depress the brake pedal firmly and do not accelerate at the same time.




Depress the brake pedal and push the DIRECT SELECT lever upwards past the first point of resistance.

Engaging neutral N

WARNING Risk of accident due to incorrect gearshifting

If the engine speed is higher than the idle speed and you engage the transmission position **D** or **R**, the vehicle may accelerate sharply.

If you engage the transmission position **D** or **R** when the vehicle is at a standstill, always depress the brake pedal firmly and do not accelerate at the same time.



- Depress the brake pedal and push the DIRECT SELECT lever up or down to the first point of resistance.
- (i) To shift into neutral N with the vehicle switched on, push the selector lever up or down for several seconds to the first point of resistance.

Subsequently releasing the brake pedal will allow you to move the vehicle freely, e.g. to push it or tow it away.

Proceed as follows if you want the automatic transmission to remain in neutral N, even if the vehicle is switched off or the driver's door is opened:

- Depress the brake pedal and engage neutral N when the vehicle is at a standstill.
- Release the brake pedal.
- Switch off the vehicle.

The Risk of vehicle rolling away N activated manually No automatic switch to P message appears in the driver's display.

(i) If you then exit the vehicle leaving the key in the vehicle, the automatic transmission remains in neutral N.

The park position **P** is automatically re-engaged as soon as one of the following conditions is met:

- You switch to transmission position **D** or **R**.
- You press the button P.

Engaging park position P

WARNING Accident- and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle. they can in particular

- Open doors and thereby endanger other persons or road users.
- · get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.


In addition, the children could also set the vehicle in motion, for example by:

- · releasing the parking brake.
- change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

NOTE Damage due to engaging park position P while the vehicle is rolling

If you shift the transmission into park position **P** while the vehicle is rolling, the transmission may be damaged.

- If the vehicle is rolling, do not open a door.
- Only engage the park position **P** when the vehicle is stationary.



- Observe the notes on parking the vehicle (→ page 209).
- Depress the brake pedal until the vehicle comes to a standstill.
- When the vehicle is stationary, press button
 When the transmission position display show

When the transmission position display shows \boxed{P} , the park position is engaged. If the transmission position display \boxed{P} does not appear,

- apply the parking brake and secure the vehicle to prevent it from rolling away.
- (i) Depending on the situation, it may take a short time until [P] is engaged. Therefore, always pay attention to the transmission position display.

Park position P will be engaged automatically if one of the following conditions is met:

- You switch the stationary vehicle off in transmission position D or R.
- You open the driver's door when the vehicle is stationary in transmission position $\boxed{\mathbf{D}}$ or $\boxed{\mathbf{R}}$.
- When the vehicle is rolling, you switch if off in transmission position D or R and bring it to a standstill.
- When the vehicle is rolling, you shift to transmission position N, bring the vehicle to a standstill and open the driver's door when the vehicle is stationary.
- Engaging park position **P** automatically is required by the vehicle.
- (i) To manoeuvre with an open driver's door, open the driver's door while the vehicle is sta-

tionary and engage transmission position $\boxed{\textbf{D}}$ or $\boxed{\textbf{R}}$ again.


Engaging drive position D

A

WARNING Risk of accident due to incorrect gearshifting

If the engine speed is higher than the idle speed and you engage the transmission position $\boxed{\mathbf{D}}$ or $\boxed{\mathbf{R}}$, the vehicle may accelerate sharply.

If you engage the transmission position
D or R when the vehicle is at a stand-still, always depress the brake pedal firmly and do not accelerate at the same time.



Depress the brake pedal and push the DIRECT SELECT lever down past the first point of resistance.

When the automatic transmission is in transmission position **D**, it will shift gears automatically. This depends, among other things, on the following factors:

- The selected drive program
- The position of the accelerator pedal

The driving speed

Manual gearshifting



When the automatic transmission is shifted to position **D**, you can manually shift it with the steering wheel gearshift paddle. If permitted, the automatic transmission will shift to a higher or lower gear depending on the steering wheel gearshift paddle being pulled.

You have two options for manually shifting the automatic transmission:

- Temporary setting
- Permanent setting

The gears will shift automatically when manual shifting is deactivated.

Temporary setting:

To activate: pull steering wheel gearshift paddle 1 or 2.

Manual shifting will be activated for a short time. The transmission position display will show **M** and the current gear.

How long manual shifting stays activated depends on various factors.

Manual shifting can be deactivated automatically in the following cases:

- When the drive program is changed
- When the vehicle is restarted
- When transmission position D is engaged again
- Driving style
- To shift up: pull steering wheel gearshift paddle (2)
- To shift down: pull steering wheel gearshift paddle 1.

202 Driving and parking

D.

- ➤ To deactivate: pull and hold steering wheel gearshift paddle ②. The transmission position display will show
- (i) You can also activate or deactivate manual shifting permanently in the multimedia system.

Gearshift recommendation

The gearshift recommendation assists you in adopting an economical driving style.



When gearshift recommendation ① appears on the driver's display, shift to the recommended gear.

Using kickdown

Maximum acceleration: depress the accelerator pedal beyond the point of resistance.

To protect against engine overrev, the automatic transmission will shift up to the next gear when maximum engine speed has been reached.

Glide mode function

With an anticipatory driving style, Glide mode helps you to reduce fuel consumption.

Glide mode is characterised by the following:

- The combustion engine is disconnected from the drivetrain and continues to run in neutral.
- The transmission position display D is shown in green.
- The combustion engine can be switched off.
 All of the vehicle functions remain active.

Glide mode will be activated if the following conditions are met:

- Drive program is selected.
- · The speed is within a suitable range.
- The road's course is suitable, e.g. no steep uphill or downhill gradients or tight bends.
- There is no trailer hitched up to the trailer hitch, and no bicycle rack fitted.
- You do not depress the accelerator or brake pedal (except for light brake applications).
- i Glide mode can also be activated if you have selected the "Eco" setting for the drive in the drive program .

Glide mode will be deactivated again if one of the conditions is no longer met.

Glide mode can also be prevented by the following parameters:

- Incline
- Downhill gradient
- Temperature
- Height

- speed
- Operating status of the engine
- Traffic situation

Function of 4MATIC

4MATIC ensures that all four wheels are driven. Together with ESP® and 4ETS, 4MATIC improves the traction of your vehicle whenever a driven wheel spins due to insufficient traction.

If you fail to adapt your driving style, 4MATIC can neither reduce the risk of an accident nor override the laws of physics. 4MATIC cannot take account of road, weather or traffic conditions, 4MATIC is only an aid. You are responsible especially for maintaining a safe distance from the vehicle in front, for vehicle speed, for braking in good time and for staying in lane.

In wintry road conditions, the maximum effect of 4MATIC can be achieved only if you use winter tyres (M+S tyres), with snow chains if necessary.

Refuelling

Refuelling the vehicle



WARNING Risk of fire or explosion from fuel

Fuels are highly flammable.

- Fire, naked flames, smoking and creating sparks must be avoided.
- Before refuelling, switch off the vehicle and, if fitted, the stationary heater and keep switched off during filling.

WARNING Risk of injury from fuels

Fuels are poisonous and hazardous to your health.

- Do not swallow fuel or let it come into contact with skin, eyes or clothing.
- Do not inhale fuel vapour.
- Keep children away from fuel.
- Keep doors and windows closed during the refuelling process.

If you or other people come into contact with fuel, observe the following:

- Immediately rinse fuel off your skin with soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical attention immediately.
- If you swallow fuel, seek medical attention immediately. Do not induce vomiting.
- Change immediately out of clothing that has come into contact with fuel.

WARNING Risk of fire and explosion due to electrostatic charge

Electrostatic charge can ignite fuel vapour.

Before you open the fuel filler cap or take hold of the pump nozzle, touch the metallic vehicle body.

To avoid creating another electrostatic charge, do not get into the vehicle again during the refuelling process.

MARNING Risk of fire from fuel mixture

Vehicles with a diesel engine:

If you mix diesel fuel with petrol, the flash point of the fuel mixture is lower than that of pure diesel fuel.

While the vehicle is running, component parts in the exhaust system may overheat without warning.

- Never refuel using petrol.
- Never mix petrol with diesel fuel.

! NOTE Damage caused by the wrong fuel

Vehicles with a petrol engine:

Even small amounts of the wrong fuel could result in damage to the fuel system, the engine and the emission control system.

Only refuel using unleaded, sulphur-free spark-ignition engine fuel that conforms

to European EN 228, or an equivalent specification.

Fuel of this specification may contain up to 10% ethanol. Your vehicle is suitable for use with E10 fuel.

Never refuel with one of the following fuels:

- Diesel
- Regular petrol with an octane number lower than 91 RON
- Petrol with more than 10% ethanol by volume, e.g. E15, E20, E85, E100
- Petrol with more than 3% methanol by volume, e.g. M15, M30
- Petrol with additives containing metal

If you have accidentally refuelled with the wrong fuel:

- Do not switch on the vehicle.
- Consult a qualified specialist workshop.

NOTE Damage caused by the wrong fuel

Vehicles with a diesel engine:

Even small amounts of the wrong fuel could result in damage to the fuel system, the engine and the emission control system.

Only refuel using sulphur-free diesel fuel that conforms to European standard EN 590, or an equivalent specification. In countries without sulphur-free diesel fuel, refuel using only low-sulphur diesel fuel with a sulphur content less than 50 ppm.

Never refuel with one of the following fuels:

- Petrol
- Marine diesel
- · Heating oil
- · Pure bio-diesel or vegetable oil
- · Paraffin or kerosene

If you have accidentally refuelled with the wrong fuel:

- Do not switch on the vehicle.
- Consult a qualified specialist workshop.
- **NOTE** Do not use diesel to refuel vehicles with a petrol engine

If you have accidentally refuelled with the wrong fuel:

 Do not switch on the vehicle. Otherwise fuel can enter the engine. Even small amounts of the wrong fuel could result in damage to the fuel system

and the engine. The repair costs are high.

- Consult a qualified specialist workshop.
- Have the fuel tank and fuel lines drained completely.

NOTE Do not use petrol to refuel vehicles with a diesel engine

If you have accidentally refuelled with the wrong fuel:

- Do not switch on the vehicle. Otherwise. fuel can enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high.
- Consult a qualified specialist workshop.
- Have the fuel tank and fuel lines drained completely.
- NOTE Damage to the fuel system due to overfilling the fuel tank
- Only fill the fuel tank until the pump nozzle switches off.

If too much fuel has been added due, for example, to a faulty filling pump:

Do not switch on the vehicle.


- Consult a qualified specialist workshop.
- NOTE Fuel may spray out when you remove the fuel pump nozzle
- Only fill the fuel tank until the pump nozzle switches off.

Requirements

The vehicle must be unlocked.

Observe the notes on service products and fuel.

The recommended octane number for your vehicle can be found on the information label in the fuel filler flap.



- Fuel filler flap
- Bracket for fuel filler cap
- Tyre pressure table
- QR code for rescue card
- Fuel type
- Press on the rear part of fuel filler flap ①.
- Turn the fuel filler cap anti-clockwise and remove it.

- Insert fuel filler cap from above into bracket 2.
- Completely insert the pump nozzle into the tank filler neck, hook in place and refuel.
- Only fill the fuel tank until the pump nozzle switches off.
- Vehicles with a diesel engine: The tank filler neck is designed for refuelling at diesel filling pumps.
 - Your vehicle is equipped with a system that prevents filling up with the wrong fuel. This function may be deactivated in some countries due to local circumstances. For more information, consult a Mercedes-Benz service centre.
- Vehicles with a diesel engine: Refuel with at least 5 litres of diesel if the fuel tank has been run dry completely.
- Vehicles with a diesel engine: Use a filler neck with a large diameter for vehicles with a diesel engine when topping up fuel from a fuel can. Otherwise, the filler neck cannot be pushed into the tank shaft.

- Replace the cap on the filler neck and turn clockwise until it engages audibly.
- Close fuel filler flap 1.

AdBlue® (vehicles with a diesel engine only)

Notes on topping up AdBlue®

AdBlue[®] is a water-soluble fluid for the NOx exhaust gas aftertreatment of diesel engines. In order for the exhaust gas aftertreatment to function properly, only use AdBlue[®] in accordance with ISO 22241.

AdBlue[®] is characterised by the following:

- non-toxic
- · colourless and odourless
- · non-flammable

If you open the AdBlue® tank, small amounts of ammonia vapour may be released. Only fill the AdBlue® tank in well-ventilated areas.

Do not let AdBlue[®] come into contact with skin, eyes or clothes. Keep AdBlue[®] away from children.

Do not ingest AdBlue[®]. If AdBlue[®] is swallowed, immediately rinse your mouth out thoroughly. Drink plenty of water. Seek medical attention at once.

Observe the notes on operating fluids $(\rightarrow page 632)$.

AdBlue® is available here:

- AdBlue[®] can be topped up by fast service at a qualified specialist workshop, e.g. a Mercedes-Benz Service Centre.
- AdBlue[®] is available at many filling stations from AdBlue® filling pumps.
- Alternatively, AdBlue® is available at qualified specialist workshops, e.g. Mercedes-Benz Service Centres, and at many filling stations in AdBlue® refill canisters or AdBlue® refill bottles.
- Ensure the connection between the refill container and vehicle filler neck does not drip.

■ Topping up AdBlue[®]

- **NOTE** Engine damage due to AdBlue[®] being in the fuel
- AdBlue® must not be used to fill the fuel tank.
- Only use AdBlue® to fill the AdBlue® tank.
- Do not overfill the AdBlue® tank.
- NOTE Contamination of the vehicle interior due to AdBlue® leakage
- After topping up, carefully close the AdBlue® refill container.
- Avoid carrying AdBlue® refill containers permanently in the vehicle.

Requirements

The vehicle is unlocked.


The following messages appear in order in the driver's display when the AdBlue® tank requires refilling:

- Refill AdBlue See Owner's Manual. The AdBlue® level has fallen into the reserve range. Refill AdBlue® immediately.
- Top up AdBlue Emergency op. in XXX km See Owner's Manual. The low AdBlue® level will lead to limited performance after the remaining distance displayed has been covered. Refill AdBlue® immediately.
- Top up AdBlue XX,X I Emerg. op.: max. XXX km/h Start not poss. in XXX km. The low AdBlue® level will lead to an output restriction from the speed displayed. After the remaining distance displayed has been covered, it will no longer be possible to start the vehicle. Refill at least the indicated amount of AdBlue®.
- Top up AdBlue XX,X I Switch vehicle on, wait 60 sec. or engine start not poss.. The AdBlue® tank is empty. You can no longer start the vehicle. Refill at least the indicated amount of AdBlue®. Switch on the vehicle and

You can see the AdBlue® range and level in the Service menu in the driver's display.

(i) The AdBlue® range shown depends strongly on the driving style and operating conditions. The actual range can therefore differ from the calculated range.


Opening the AdBlue® filler cap



- Press on the rear part of fuel filler flap ①.
- Turn AdBlue® filler cap ② anti-clockwise and remove it.
- You can also place the AdBlue[®] filler cap in the fuel filler cap holder in the fuel filler flap hinge arm.

Topping up AdBlue®

Mercedes-Benz recommends refilling AdBlue® at a filling pump. If no AdBlue® filling pump is available, you can also top up AdBlue® using a canister.



Screw on the fastener of AdBlue[®] refill canister **(a)**.

- Screw the disposable hose 3 onto the opening of AdBlue® refill canister 4 until handtight.
- Screw the disposable hose (3) onto the filler neck of the vehicle until hand-tight.
- Lift up and tip AdBlue[®] refill canister (4). The filling process stops when the AdBlue® tank is completely full.

The AdBlue® refill canister (4) can be removed even if it has been only partially emptied.

- Unscrew and close the disposable hose 3 and AdBlue® refill canister (4) in reverse order.
- Replace AdBlue® filler cap 2 and turn it clockwise until it audibly engages.
- Close fuel filler flap 1.
- Switch on the vehicle for at least 60 seconds.
- If the vehicle could not be started because the AdBlue® tank was empty, it can take up to 60 seconds for the refill to be detected.
- Start the vehicle.

Avoid storing AdBlue® refill containers permanently in the vehicle.

Parking

Parking the vehicle

WARNING Risk of accident and injury caused by an insufficiently secured vehicle rolling away

If the vehicle is not securely parked sufficiently, it can roll away in an uncontrolled way even at a slight downhill gradient.

- On uphill or downhill gradients, turn the front wheels so that the vehicle rolls towards the kerb if it starts moving.
- apply the parking brake.
- Switch the transmission to position \mathbf{P} .

WARNING Risk of fire caused by hot exhaust system parts

Flammable materials such as leaves, grass or twigs may ignite.

- Park the vehicle so that no flammable material can come into contact with hot vehicle components.
- In particular, do not park on dry grassland or harvested grain fields.

WARNING Accident- and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for exampleby:

- releasing the parking brake.
- change the gearbox setting.
- start the vehicle.

210 Driving and parking


- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

This also applies to the Digital Vehicle Key.

- I NOTE Damage to the vehicle due to it rolling away
- Always secure the vehicle against rolling away.
- ! NOTE Damage caused by vehicle being lowered

Vehicles AIRMATIC: The vehicle can be lowered due to differences in temperature or extended non-operational times. This can cause damage to parts of the body.

When stopping the vehicle and when driving off, make sure that there are no obstacles such as kerbs under or in the immediate vicinity of the body.



- Bring the vehicle to a standstill by depressing the brake pedal.
- On uphill or downhill gradients, turn the front wheels so that the vehicle rolls towards the kerb if it starts moving.
- Apply the electric parking brake.

- Engage transmission position P in a stationary vehicle with the brake pedal depressed (→ page 199).
- Switch off the vehicle by pressing button ①.
- Release the service brake slowly.
- Get out of the vehicle and lock it.
- (i) When you park the vehicle, you can still operate the side windows and the panoramic sliding sunroof for approximately four minutes if the driver's door is closed.

Automatic shut-off function of the vehicle

If you leave the engine running and leave the vehicle, the driver's display will show the Vehicle is ready to drive Shutdown occurs when locked or automatically in XX minsdisplay message.

The vehicle will then switch off automatically after 20 minutes.

If you leave the engine running and remain in the vehicle while it is in park position $\boxed{\textbf{P}}$, the Vehicle is ready to drive Shutdown occurs when locked or automatically in XX minsdisplay message will appear on the driver's display after ten minutes.

The vehicle will be switched off automatically after a further ten minutes.

To avoid automatic switch-off, acknowledge the message on the central display of the multimedia system.

Electric parking brake

Function of the electric parking brake (applying) automatically)

WARNING Accident - and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- · Operate vehicle equipment and become trapped, forexample.

In addition, the children could also set the vehicle in motion, for example by:

- releasing the parking brake.
- · change the gearbox setting.
- start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.

This also applies to the Digital Vehicle Key.

The electric parking brake is applied if the transmission is in position P and one of the following conditions is fulfilled:

- The vehicle is switched off.
- The seat belt tongue is not inserted in the seat belt buckle of the driver's seat and the driver's door is opened.
- To prevent application: pull the handle of the electric parking brake (\rightarrow page 212).

In the following situations, the electric parking brake is also applied:

- The HOLD function is keeping the vehicle stationary.
- Active Parking Assist is keeping the vehicle stationary.
- Active Distance Assist DISTRONIC is bringing the vehicle to a standstill
- In addition, one of the following conditions must be fulfilled:
 - The vehicle is switched off.
 - The seat belt tongue is not inserted in the seat belt buckle of the driver's seat and the driver's door is opened.
 - There is a system malfunction.
 - The power supply is insufficient.
 - The vehicle is stationary for a lengthy period.

When the electric parking brake is applied, the red nindicator lamp lights up in the driver's display.

212 Driving and parking

 The electric parking brake is not automatically applied if the vehicle is switched off by the ECO start/stop function.

■ Function of the electric parking brake (releasing automatically)

The electric parking brake is released when the following conditions are fulfilled:

- · The driver's door is closed.
- · The vehicle has been started.
- If the transmission is in position **R**, the boot lid must be closed.
- The seat belt tongue is inserted into the seat belt buckle of the driver's seat.
 - If the seat belt tongue is not inserted into the seat belt buckle of the driver's seat, one of the following conditions must be fulfilled:
 - You shift from transmission position P.

- You have previously driven at speeds greater than 3 km/h.

When the electric parking brake is released, the red ((a)) indicator lamp in the driver's display goes out.

Applying/releasing the electric parking brake manually

WARNING Accident – and risk of injury with unsupervised children in the vehicle

If you leave children unattended in the vehicle, they can in particular

- Open doors and thereby endanger other persons or road users.
- get out of the car and are hit by traffic.
- Operate vehicle equipment and become trapped, forexample.


In addition, the children could also set the vehicle in motion, for example by:

• releasing the parking brake.

- change the gearbox setting.
- · start the vehicle.
- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the key out of reach of children.


This also applies to the Digital Vehicle Key.

Applying




- Push handle 1. The red (n) indicator lamp lights up in the driver's display.
- The electric parking brake is only securely applied if the red indicator lamp is lit continuously.

Releasing



- Switch on the vehicle.
- Pull handle 1. The red indicator lamp in the driver's display goes out.

Emergency braking



Press and hold handle ①. As long as the vehicle is in motion, the Release parking brake message is displayed and the red (indicator lamp flashes.

When the vehicle has been braked to a standstill, the electric parking brake is applied. The

red (n) indicator lamp lights up in the driver's display.

Information on collision detection on a parked vehicle

If a collision is detected on the locked vehicle when towing protection is switched on and collision detection is switched on, you will receive a message in the multimedia system when the vehicle is switched on.

You will receive information about the following points:

- The area of the vehicle that may have been damaged.
- The force of the impact.

The following situation can lead to inadvertent activation:

- The parked vehicle is moved, forexample, in a two-storey garage.
- i Deactivate tow-away protection in order to prevent inadvertent activation. If you deacti-

vate tow-away protection, collision detection will also be deactivated.

You can permanently deactivate collision detection via the multimedia system (\rightarrow page 214).

System limits

Detection may be restricted in the following situations:

- the vehicle is damaged without impact, forexample, if an outside mirror is torn off or the paint is damaged by a key
- an impact occurs at low speed
- the electric parking brake is not applied
- You are responsible for your vehicle. Convince yourself that your vehicle is free of damage and roadworthy.

Setting collision detection on a parked vehicle

Multimedia system:

- → Settings → Vehicle

 → Open/close → Vehicle protection
- Activate or deactivate the function via Collision notification.
- (i) A maximum of three incidents can be registered. Up to 15 photos are taken for every incident. In the event of another incident, the photos of the first incident will be overwritten if they have not been deleted already.

Activating or deactivating the collision photos function

Note possible legal restrictions in some countries regarding automatic recording of the vehicle surroundings.

Activate or deactivate Collision photos.

Transferring the collision photos with the Mercedes me App

- Select Upload collision photos.
- Select Upload automatically.

- Scan the generated QR code on the central display with the Mercedes me App. The encrypted collision photos will then be uploaded to Mercedes me.
- (i) Any device that can scan QR codes can be used to view the collision photos in the Mercedes me App.

Copying the collision photos to a USB flash drive

- Connect a USB flash drive (\rightarrow page 456).
- Select Manage collision photos.
- Select Copy (USB). All collision photos are copied to the USB flash drive.
- To ensure secure operation, only use with FAT32 or exFAT formatted USB storage devices.

Deleting collision photos

- Select Manage collision photos.
- Select Delete.
 - All collision photos will be deleted.

Notes on parking up the vehicle

If you leave the vehicle parked up for longer than six weeks, it may suffer damage through disuse.

The 12 V battery may also be impaired or damaged by heavy discharging.

Further information can be obtained at a qualified specialist workshop.

Driving and driving safety systems

Driving systems and your responsibility

Your vehicle is equipped with driving systems which assist you in driving, parking and manoeuvring the vehicle. The driving systems are only aids. They are not a substitute for you paying attention to your surroundings and do not relieve you of your responsibility pertaining to road traffic law. The driver is always responsible for maintaining a safe distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in lane. Pay attention to the traffic conditions at all times and intervene when necessary. Be aware of the limitations regarding the safe use of these systems.

Driving systems can neither reduce the risk of accident if you fail to adapt your driving style nor override the laws of physics. They cannot always take into account road, weather or traffic conditions.


Some driving systems can regulate or limit the speed to a previously set value. Draw attention to the stored speed when changing drivers.

Information on vehicle sensors and cameras

Some driving and driving safety systems use cameras as well as radar or ultrasonic sensors to monitor the area in front of, behind or next to the vehicle.

216 Driving and parking





- Multifunction camera
- Cameras in the outside mirrors
- Front radar
- Front camera

- Corner radars
- Output
 Ultrasonic sensors
- Reversing camera

▲ WARNING Risk of accident due to restricted detection performance of vehicle sensors and cameras

If the area around vehicle sensors or cameras is covered, damaged or dirty, certain driving and safety systems cannot function correctly. There is a risk of an accident.

- Keep the area around vehicle sensors or cameras clear of any obstructions and clean.
- Have damage to the bumper, radiator grille or stone chipping in the area of the front and rear windows repaired at a qualified specialist workshop.

Particularly, keep the areas around the sensors and cameras free of dirt, ice or slush (\rightarrow page 481). The sensors and cameras must not be covered and the detection ranges around them must be kept free. Do not attach additional

licence plate brackets, advertisements, stickers, foils or foils to protect against stone chippings in the detection range of the sensors and cameras. Make sure that there are no overhanging loads protruding into the detection range.

If there is damage to a bumper or the radiator grille, or after an impact, have the function of the sensors checked at a qualified specialist workshop. Have damage or stone chipping in the area of the cameras on the front and rear windows repaired at a qualified specialist workshop.

 The reversing camera can extend and retract automatically for the purpose of calibration, even though there is no camera image in the display.

Overview of driving systems and driving safety systems

- ABS (→ page 217)
- BAS (→ page 218)
- ESP[®] (→ page 218)
- ESP[®] Crosswind Assist (→ page 219)

- ESP® trailer stabilisation (\rightarrow page 219)
- EBD (→ page 220)
- STEER CONTROL (→ page 220)
- HOLD function (→ page 220)
- Hill Start Assist (→ page 221)
- Adaptive Brake Lights (→ page 222)
- ATTENTION ASSIST (→ page 222)
- Cruise control (→ page 224)
- Limiter (\rightarrow page 225)
- Speed Limit Assist (country-dependent) $(\rightarrow page 248)$
- Traffic Sign Assist (→ page 250)
- Traffic light view (→ page 255)

Driving Assistance Package

The availability of some functions or sub-functions of the Driving Assistance Package is equipment- or country-specific. The functions of your Driving Assistance Package may differ from the functions listed here. Active Distance Assist DISTRONIC, Active Blind Spot Assist, Active Brake Assist, Active

Lane Keeping Assist and Active Emergency Stop Assist are also available without the Driving Assistance Package, albeit with restricted functionality.

- Active Distance Assist DISTRONIC $(\rightarrow page 228)$
- Active Speed Limit Assist (→ page 234)
- Route-based speed adaptation (→ page 235)
- Active Brake Assist (→ page 243)
- Active Steering Assist (→ page 237)
- Active Emergency Stop Assist (→ page 239)
- Active Lane Change Assist (→ page 241)
- Active Stop-and-Go Assist (→ page 236)
- Active Blind Spot Assist with exit warning $(\rightarrow page 255)$
- Active Lane Keeping Assist (→ page 258)
- PRE-SAFE[®] Impulse Side (→ page 53)

Parking Package

- (i) The availability of individual functions depends on the country and equipment.
- Reversing camera (→ page 263)

- 360° Camera (→ page 265)
- Parking Assist PARKTRONIC (→ page 271)
- Active Parking Assist (→ page 275)
- Remote Parking Assist (→ page 281)
- Memory Parking Assist (country-dependent) $(\rightarrow page 288)$

Functions of ABS

The Anti-lock Brake System (ABS) regulates the brake pressure in critical driving situations:

- During braking, for instance, at maximum fullstop braking or if there is insufficient tyre traction, the wheels are prevented from locking.
- Vehicle steerability while braking is ensured.

If ABS intervenes when braking, you will feel a pulsing in the brake pedal. The pulsating brake pedal can be an indication of hazardous road conditions and can serve as a reminder to take extra care while driving.


System limits

• ABS is active from speeds of approx. 5 km/h.

218 Driving and parking

 ABS may be impaired or may not function if a malfunction has occurred and the yellow
 ABS warning lamp lights up continuously after the vehicle is started.

Function of BAS



If BAS is malfunctioning, the braking distance in an emergency braking situation is increased.

Depress the brake pedal with full force in emergency braking situations. ABS prevents the wheels from locking.

The Brake Assist System (BAS) supports your emergency braking situation with additional brake force.

If you depress the brake pedal quickly, BAS is activated:

- BAS automatically boosts the brake pressure.
- BAS can shorten the braking distance.

· ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

Function of ESP®

A

WARNING Risk of skidding if ESP® is deactivated

If you deactivate ESP®, ESP® cannot carry out vehicle stabilisation.

ESP® should only be deactivated in the following situations.

The Electronic Stability Program (ESP®) can monitor and improve driving stability and traction in the following situations within physical limits:

- When pulling away on wet or slippery carriageways.
- · When braking.

If the vehicle deviates from the direction desired by the driver, ESP® can stabilise the vehicle by intervening in the following ways:

- · One or more wheels are braked.
- The engine output is adapted according to the situation.

When $\mathrm{ESP}^{\$}$ is deactivated, the $\begin{tabular}{l} \P_{\$} \end{tabular}$ warning lamp lights up continuously:

- Driving stability will no longer be improved.
- The drive wheels could spin.
- ETS/4ETS traction control is still active.
- (i) When ESP® is deactivated, you are still assisted by ESP® when braking.

When the 📳 warning lamp flashes, one or several wheels has reached its grip limit:

- Adapt your driving style to suit the current road and weather conditions.
- Do not deactivate ESP[®].
- Only depress the accelerator pedal as far as is necessary when pulling away.

Deactivate ESP® in the following situations to improve traction:

- When using snow chains.
- In deep snow.
- On sand or gravel.
- (i) Spinning the wheels results in a cutting action, which enhances traction.

If the SP® warning lamp lights up continuously, ESP® is not available due to a malfunction. Observe the following information:

- Indicator and warning lamps (→ page 729)
- Display messages (→ page 644)

ETS/4ETS (Electronic Traction System)

ETS/4ETS traction control is part of ESP® and makes it possible to pull away and accelerate on a slippery carriageway.

ETS/4ETS can improve the vehicle's traction by intervening in the following ways:

• The drive wheels are braked individually if they spin.

• More drive torque is transferred to the wheel or wheels with traction.

Influence of drive programs on ESP®

The drive programs enable ESP® to adapt to different weather and road conditions as well as the driver's preferred driving style. Depending on the selected drive program, the appropriate ESP® mode will be activated. You can select the drive programs using the DYNAMIC SELECT switch $(\rightarrow page 195)$.

Function of ESP® Crosswind Assist

ESP® Crosswind Assist detects sudden gusts of side wind and helps the driver to keep the vehicle in the lane:

- ESP® Crosswind Assist is active at vehicle speeds between approx. 80 km/h and 200 km/h when driving straight ahead or cornering slightly.
- The vehicle is stabilised by means of individual brake application on one side.

Function of ESP® trailer stabilisation



WARNING Risk of accident in poor road and weather conditions

In poor road and weather conditions, the trailer stabilisation cannot prevent lurching of the vehicle/trailer combination. Trailers with a high centre of gravity may tip over before FSP® detects this.

Always adapt your driving style to suit the current road and weather conditions.

When driving with a trailer, ESP® can stabilise your vehicle if the trailer begins to swerve from side to side:

- ESP® trailer stabilisation is active above speeds of 65 km/h.
- Slight swerving is reduced by means of a targeted, individual brake application on one side.
- In the event of severe swerving, the operating energy output is also reduced and all wheels are braked.

ESP® trailer stabilisation may be impaired or may not function if:

 The trailer is not connected correctly or is not detected properly by the vehicle.

Activating/deactivating ESP® (Electronic Stability Program)

Multimedia system:



Select ESP.

Select On or 👼 Off.

 ESP^{\otimes} is deactivated if the $\begin{tabular}{l} \mathsf{ESP}^{\otimes} \mathsf{OFF} \mathsf{ warning lamp lights up continuously in the driver's display.} \end{tabular}$

Observe any information on warning lamps and display messages which may be shown in the driver's display.

Function of EBD

Electronic Brakeforce Distribution (EBD) is characterised by the following:

- Monitoring and regulating the brake pressure on the rear wheels.
- Improved driving stability when braking, especially on bends.

Function of STEER CONTROL

STEER CONTROL assists you by transmitting a noticeable steering force to the steering wheel in the direction required for vehicle stabilisation.

This steering recommendation is given in the following situations:

- both right wheels or both left wheels are on a wet or slippery road surface when you brake
- the vehicle starts to skid

System limits

STEER CONTROL may be impaired or may not function in the following situations:

ESP[®] is deactivated.

- ESP[®] is malfunctioning.
- · The steering is malfunctioning.

If $\ensuremath{\mathsf{ESP}}^{\ensuremath{\$}}$ is malfunctioning, you will be assisted further by the electric power steering.

HOLD function

HOLD function

The HOLD function holds the vehicle at a standstill without requiring you to depress the brake pedal, e.g. while waiting in traffic.

The HOLD function is only an aid. The responsibility for the vehicle safely standing still remains with the driver.

System limits

The HOLD function is only intended to provide assistance when driving and is not a sufficient means of safeguarding the vehicle against rolling away when stationary.

• The incline must not be greater than 30%.

Activating/deactivating the HOLD function

WARNING Risk of an accident due to the HOLD function being active when you leave the vehicle

If the vehicle is only braked with the HOLD function it could, in the following situations, roll away:

- If there is a malfunction in the system or in the power supply.
- If the HOLD function is deactivated by depressing the accelerator pedal or brake pedal, e.g. by a vehicle occupant.
- Always secure the vehicle against rolling away before you leave it.

Requirements

- The vehicle is stationary.
- The driver's door is closed or the seat belt on the driver's side is fastened.
- The vehicle has been started or has been automatically switched off by the ECO start/ stop function.

- The electric parking brake is released.
- Active Distance Assist DISTRONIC is deactivated.
- The transmission is in position **D**, **R** or **N**.

Activating the HOLD function

- Depress the brake pedal, and after a short time quickly depress further until the HOLD display appears in the driver's display.
- Release the brake pedal.

Deactivating the HOLD function

- Depress the accelerator pedal to pull away. or
- Depress the brake pedal until the HOLD display disappears from the driver's display.

The HOLD function is deactivated in the following situations:

- Active Distance Assist DISTRONIC is activated.
- The transmission is shifted to position **P**.
- The vehicle is secured with the electric parking brake.

In the following situations, the vehicle is held by transmission position P and/or by the electric parking brake:

- The seat belt is unfastened and the driver's door is opened.
- The vehicle is switched off.
- · There is a system malfunction.
- The power supply is insufficient.

In addition, the Brake immediately message may appear in the driver's display and a horn tone may sound at regular intervals.

- Immediately depress the brake pedal firmly until the warning message disappears. The HOLD function is deactivated.
- Additionally secure the vehicle against rolling awav.

Function of Hill Start Assist

Hill Start Assist holds the vehicle for a short time when pulling away on a hill under the following conditions:

• The transmission is in position **D** or **R**.

· The electric parking brake is released.

This gives you enough time to move your foot from the brake pedal to the accelerator pedal and depress it before the vehicle begins to roll away.



WARNING Risk of accident and injury due to the vehicle rolling away

After a short time, Hill Start Assist no longer holds the vehicle.

Swiftly move your foot from the brake pedal to the accelerator pedal. Do not leave the vehicle when it is being held by Hill Start Assist.

Function of Adaptive Brake Lights

Adaptive Brake Lights warn following traffic in an emergency braking situation with the following actions:

- flashing the brake lamps
- activating the hazard warning lights (→ page 150)

If the vehicle is braked sharply from speeds above 50 km/h, the brake lamps flash rapidly. This provides traffic travelling behind you with an even more noticeable warning.

ATTENTION ASSIST

■ Function of ATTENTION ASSIST

 Depending on the country and equipment, ATTENTION ASSIST has the sub-functions microsleep detection and distraction detection. These functions are only available in conjunction with the driver camera in the driver display (→ page 352).

ATTENTION ASSIST assists you on long, monotonous journeys, e.g. on motorways and trunk roads. If indicators of fatigue or increasing lapses in concentration on the part of the driver are detected, the system suggests taking a break.

ATTENTION ASSIST is only an aid. It cannot always detect fatigue or lapses in concentration in time. The system is not a substitute for a well-rested and attentive driver. On long journeys, take regular breaks in good time that allow for adequate recuperation.

You can choose between two settings:

- Standard: normal system sensitivity.
- Sensitive: higher system sensitivity. The driver is warned earlier and the attention level detected by ATTENTION ASSIST is adapted accordingly.

If fatigue or increasing inattention is detected, the warning appears in the driver display: ATTEN-TION ASSIST: Take a break!. you can acknowledge the message and take a break if necessary. If you do not take a break and ATTENTION ASSIST continues to detect increasing lapses in concentration, you will be warned again after a minimum of 15 minutes.

If ATTENTION ASSIST is unable to calculate the attention level and cannot issue a warning, the System suspended message appears.

If the driver display shows a warning, a service area search is offered in the multimedia system. You can select a rest area and start navigation to this rest area.

When you restart the vehicle, ATTENTION ASSIST is automatically switched on. The last selected sensitivity level remains stored.



The following information is displayed in the driver's display:

- The length of the journey since the last break
- The attention level determined by ATTENTION ASSIST:
 - The more segments 2 of the circle displayed, the higher the detected attention level.
 - Fewer segments 2 are displayed in the circle as the attention level decreases.

- · The status of microsleep and distraction detection (1):
 - Deactivated: display 1 is hidden.
 - Activated but not operational: display 1 is grey.
 - Activated and operational: display 1 is green.

Microsleep detection

If the system, which uses the driver camera, detects indicators of microsleep, the ATTENTION ASSIST Microsleep Take a break! warning message appears in the driver's display and a warning tone sounds simultaneously. This warning message must be confirmed by Touch Control. It is recommended that you take a break immediately. If the driver does not react to the microsleep

warning, an emergency stop can be initiated by the system (\rightarrow page 239).

Distraction detection

Attention Assist can use the driver's camera to detect when the driver is distracted by averting his or her gaze from the road ahead.

If the system detects driver distraction, after a few seconds the white message ATTENTION ASSIST Remain alert! appears and a warning tone sounds. If the driver does not turn his gaze back to the traffic scene, the message is displayed in yellow and a continuous warning tone sounds. If the driver still does not react to the warning, an emergency stop can be initiated by the system $(\rightarrow page 239)$.

System limits

ATTENTION ASSIST is active in the 60 km/h to 200 km/h speed range.

The microsleep detection function is available at a speed of 20 km/h and above.

If the system is not available due to an error, the ATTENTION ASSIST warning light for lights up continuously in the driver display.

Particularly in the following situations, ATTENTION ASSIST only functions in a restricted manner and warnings may be delayed or not occur:

• If you have been driving for less than approximately 30 minutes.

224 Driving and parking

- If the road condition is poor (uneven road surface or potholes).
- . If there is a strong side wind.
- If you adopt a sporty driving style (high cornering speeds or high rates of acceleration).
- If the Steering Assist function of Active Distance Assist DISTRONIC is active.
- If the clock is set to the incorrect time.
- If you change lanes and vary your speed frequently in active driving situations.

In addition, microsleep and distraction detection does not function when the driver camera cannot detect the driver's eyes, forexample as a result of the following factors:

- The driver's eyes are covered due to the steering column position, forexample.
- Poor lighting conditions.
- Some types of spectacles or sunglasses.
- The driver's line of vision is outside the driver camera's field of vision.

Also observe any information regarding display messages that can be displayed in the driver's display.

The ATTENTION ASSIST drowsiness or alertness assessment is reset and restarted when continuing the journey in the following situations:

- · You switch off the vehicle.
- If you unfasten your seat belt and open the driver's door (e.g. to change drivers or take a break).

Setting ATTENTION ASSIST

Multimedia system:

→ Settings → Assistance → ATTENTION ASSIST

Setting the sensitivity

- Select next to ATTENTION ASSIST.
- Select Standard or Sensitive.

Activating/deactivating the microsleep warning

Activate or deactivate Microsleep warning.

Cruise control and limiter

Function of cruise control

Cruise control regulates the speed to the value selected by the driver.

If you accelerate to overtake, forexample, the stored speed is not deleted. If you remove your foot from the accelerator pedal after overtaking, cruise control will resume speed regulation back to the stored speed.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

Displays in the driver's display

- (grey): cruise control is selected but not yet active, or temporarily passive.
- (green): cruise control is active.

System limits

Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out.

Change into a lower gear in good time on long and steep downhill gradients. Take particular note of this when driving a laden vehicle. By doing so, you will make use of the engine's braking effect. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Do not use cruise control in the following situations:

- in traffic situations which require frequent changes of speed, e.g. in heavy traffic, on winding roads
- on slippery roads. Accelerating can cause the drive wheels to lose traction and the vehicle could then skid.
- when visibility is poor

Function of the limiter

The limiter restricts the speed of the vehicle. To reduce the speed to the set speed, the limiter applies the brakes automatically.

You can limit the speed as follows:

• Variable: for a short-term speed restriction, e.g. in built-up areas

Permanent: for a longer-term speed restriction, e.g. in winter tyre mode

You can store any speed above 20 km/h up to the maximum design speed or up to the set winter tyre limit. You can also perform settings while the vehicle is stationary if the vehicle has been started.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

Displays in the driver's display

- LIM (grey): variable limiter is selected but not vet activated.
- LIM (flashes grey): variable limiter is temporarily passive.
- LIM (green): variable limiter is activated.

A stored speed appears under the **LIM** display and is indicated in the speedometer.

If you depress the accelerator pedal beyond the pressure point (kickdown), the variable limiter switches to passive mode. The message LIM

passive appears in the driver's display and the display **LIM** flashes.

The variable limiter is reactivated in the following situations:

- If the vehicle speed drops below the stored speed.
- If the stored speed is called up.
- If you store a new speed.

Operating cruise control or the variable limiter

WARNING Risk of accident due to stored speed

If you call up the stored speed and this is lower than your current speed, the vehicle decelerates.

Take into account the traffic situation before calling up the stored speed.

Requirements

Cruise control


- Cruise control is selected.
 - ESP® must be activated, but not intervening.

226 Driving and parking

- The vehicle speed is at least 20 km/h.
- The transmission is in position **D**.

Variable limiter

· The variable limiter is selected.



Steering wheel control panel for cruise control and variable limiter

RES/P Adopts the stored/detected speed

Deactivates cruise control/the variable limiter

Selects cruise control

LIM Selects the variable limiter

Control panel to increase/decrease speed

Operating cruise control and the variable limiter

Press the corresponding button with only one finger or swipe on the control panel.

Switching between cruise control and the variable limiter

- To select cruise control: press 📆 .
- To select the variable limiter: press LIM.
- Vehicles with Active Distance Assist DISTRONIC: the variable limiter is selected by a different button (→ page 231).

Activating cruise control or the variable limiter

Press <u>SET/+</u> or <u>SET/-</u> on control panel .

The current vehicle speed is stored and the vehicle maintains this speed (cruise control) or does not exceed it (variable limiter).

or

► Press RES/

Press RES/

• .

The last stored speed is called up and the vehicle maintains this speed (cruise control) or does not exceed it (variable limiter).

If the last stored speed has previously been deleted, the current vehicle speed is stored.

When you switch off the vehicle, the last speed stored is deleted. When you activate cruise control or Active Distance Assist DISTRONIC, the last speed stored for the variable limiter is deleted.

Increasing/decreasing the stored speed

- To increase the stored speed: swipe upwards from the bottom of control panel 1.
 - The stored speed is increased by 1 km/h.
- To decrease the stored speed: swipe downwards from the top of control panel ①.
 - The stored speed is decreased by 1 km/h.

Briefly press **SET/+** or **SET/-** on control panel

The stored speed is increased or decreased to the next increment of ten (e.g. to 50 km/h or 60 km/h).

Press and hold **SET/+** or **SET/-** on control panel The stored speed is increased or decreased to the next increment of ten and afterwards by increments of 10 km/h.

- Accelerate the vehicle to the desired speed.
- Press **SET/+** on control panel **①**.
- When the variable limiter is switched to passive mode, you cannot increase or decrease its stored speed in increments of 1 km/h.

Adopting a detected speed

If cruise control/variable limiter is activated and Traffic Sign Assist has detected a speed restriction sign with a maximum permissible speed and this is displayed in the driver's display:

Press RES/9. The maximum permissible speed shown by the traffic sign is stored and the vehicle maintains or does not exceed this speed.

Deactivating cruise control or the variable limiter

Press CANCEL.

- i) If you brake, deactivate ESP® or if ESP® intervenes, cruise control is deactivated. The variable limiter is not deactivated.
- When you switch off the vehicle, the last speed stored is deleted. When you select cruise control or Active Distance Assist DISTRONIC, the last speed stored for the variable limiter is cleared.

Information on the permanent limiter

If the vehicle should never exceed a specific speed (e.g. for driving in winter tyre mode), you can set this speed with the permanent limiter.

You do this by limiting the speed between 160 km/h and 240 km/h in the multimedia system (\rightarrow page 228).

Shortly before the set speed is reached, it appears in the driver's display. When you confirm the message, display messages no longer appear until you switch off the vehicle. The speed will only be displayed again once the vehicle has been restarted or if the set speed is changed.

The permanent limiter does not switch to passive mode even during kickdown and the driven speed remains below the set speed.

Setting the speed limit for winter tyres

Multimedia system:

- → Settings → Vehicle
- >> Winter tyre limit
- Activate or deactivate Winter tyre limit.

Setting a speed

- Select Winter tyre limit.
- Select a speed.

Active Distance Assist DISTRONIC

Function of Active Distance Assist DISTRONIC

The Active Distance Assist DISTRONIC described for vehicles without the Driving Assistance package is an on-demand feature $(\rightarrow page 25).$

DISTRONIC Active Distance Assist maintains the set speed when driving freely. If vehicles are detected ahead, the set distance is maintained, if necessary until the vehicle comes to a standstill. The vehicle accelerates or brakes depending on the distance to the vehicle in front and the set

speed. The speed and distance to the vehicle in front are set and saved using the steering wheel. Available speed range:

- · Vehicles without Driving Assistance Package: 20 km/h - 160 km/h
- Vehicles with Driving Assistance Package: 20 km/h - 210 km/h
- The adjustable set speed may differ if a limit speed (e.g. winter tyre limit) (\rightarrow page 227) is stored.

Other features of Active Distance Assist DISTRONIC:

- Adjusts the driving style depending on the selected drive program (energy-saving, comfortable or dynamic) (\rightarrow page 194)
- Initiates acceleration to the stored speed if the turn signal indicator is switched on to change to the overtaking lane
- Vehicles with Driving Assistance Package:
 - Reacts to stationary vehicles detected in urban speed ranges (except bicycles and motorcycles)

- Takes one-sided overtaking restrictions into account on motorways or on multilane roads with separate carriageways (country-dependent)
- (i) In the DYNAMIC SELECT menu, it is possible to set the driving mode of the Active Distance Assist DISTRONIC. Depending on which drive program is selected, the driving characteristics can be geared towards energy economy, comfort or dynamic performance. In the Active Distance Assist menu, the driving style can be permanently set to Comfort or Dynamic (\rightarrow page 236).

Vehicles with Active Parking Assist and Driving **Assistance Package:** if Active Distance Assist DISTRONIC has braked the vehicle to a standstill. it can automatically follow the vehicle in front when driving off again within 30 seconds. If a critical situation is detected in the surrounding area when driving off, such as a person in the vehicle path, a visual and acoustic warning is given indicating that the driver must now take control of the vehicle. The vehicle is not accelerated any further.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

Display in the driver's display in the Assistance menu



- Vehicle in front
- Distance indicator
- Set specified distance

Vehicle detected in front (1) is highlighted in green. It may also be in the lane to the left of your vehicle in situations where it is not permitted to overtake on the right, for example on motorways.

Permanent status display

- (grey): Active Distance Assist DISTRONIC selected but not yet active
- (green speedometer, grey vehicle): Active Distance Assist DISTRONIC active. speed set
- (green): Active Distance Assist DISTRONIC active and vehicle detected

The stored speed is shown under the permanent status display and highlighted on the speedometer. When Active Distance Assist DISTRONIC is passive, the status display is greyed out.

If the speed of the vehicle in front or the speed adjustment is less than the stored speed due to the route event ahead, the segments in the speedometer light up.

If you increase or decrease the set specified distance, the display briefly shows [3].

- On motorways or high-speed major roads, the green removed cyclically when the vehicle is ready to pull away.
- (i) If you depress the accelerator pedal beyond the setting of the Active Distance Assist

DISTRONIC, the system is switched to passive mode. The following message appears briefly in the driver's display suspended.

System limits

The system may be impaired or may not function in the following situations, for example:

- In snow, rain, fog, heavy spray, if there is glare, in direct sunlight or in greatly varying light conditions.
- The windscreen in the area of the camera is dirty, misted up, damaged or covered.
- If the radar sensors are dirty or covered.
- In multi-storey car parks or on roads with steep uphill or downhill gradients.
- If there are narrow vehicles in front, such as bicycles or motorcycles.

In addition, on slippery roads, braking or accelerating can cause one or several wheels to lose traction and the vehicle could then skid.

Do not use Active Distance Assist DISTRONIC in these situations.

WARNING Risk of accident from acceleration or braking by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC may accelerate or brake in the following cases, for example:

- If the vehicle pulls away using Active Distance Assist DISTRONIC.
- If the stored speed is called up and is considerably faster or slower than the currently driven speed.
- If Active Distance Assist DISTRONIC no. longer detects a vehicle in front or does not react to relevant objects.
- Always carefully observe the traffic conditions and be ready to brake at all times.
- Take into account the traffic situation. before calling up the stored speed.

WARNING Risk of accident due to insufficient deceleration by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC brakes your vehicle with up to 50% of the possible deceleration. If this deceleration is not sufficient. Active Distance Assist DISTRONIC alerts you with a visual and acoustic warning.

- Adjust your speed and maintain a suitable distance from the vehicle in front
- Brake the vehicle yourself and/or take evasive action.

WARNING Risk of accident if detection function of Active Distance Assist DISTRONIC is impaired

Active Distance Assist DISTRONIC does not react or has a limited reaction:

• when driving on a different lane or when changing lanes

- · to pedestrians, animals, bicycles or stationary vehicles, or unexpected obstacles
- to complex traffic conditions
- to oncoming vehicles and crossing traffic

As a result, Active Distance Assist DISTRONIC may neither give warnings nor intervene in such situations.

Always observe the traffic conditions carefully and react accordingly.

You can watch an animation on this topic via the following link:

Operating Active Distance Assist DISTRONIC and the variable limiter

WARNING Risk of accident if detection function of Active Distance Assist DISTRONIC is impaired

Active Distance Assist DISTRONIC does not react or has a limited reaction:

- when driving on a different lane or when changing lanes
- to pedestrians, animals, bicycles or stationary vehicles, or unexpected obstacles
- to complex traffic conditions
- to oncoming vehicles and crossing traffic

As a result, Active Distance Assist DISTRONIC may neither give warnings nor intervene in such situations.

Always observe the traffic conditions carefully and react accordingly.

WARNING Risk of accident from acceleration or braking by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC may accelerate or brake in the following cases, for example:

- If the vehicle pulls away using Active Distance Assist DISTRONIC.
- If the stored speed is called up and is considerably faster or slower than the currently driven speed.
- If Active Distance Assist DISTRONIC no. longer detects a vehicle in front or does not react to relevant objects.
- Always carefully observe the traffic conditions and be ready to brake at all times.
- Take into account the traffic situation before calling up the stored speed.

WARNING Risk of accident due to insufficient deceleration by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC brakes your vehicle with up to 50% of the possible deceleration. If this deceleration is not sufficient, Active Distance Assist DISTRONIC alerts you with a visual and acoustic warning.

- Adjust your speed and maintain a suitable distance from the vehicle in front
- Brake the vehicle yourself and/or take evasive action.

WARNING Risk of accident due to Active Speed Limit Assist adapting the vehicle's speed

The speed adopted by Active Speed Limit Assist may be too high or incorrect in some individual cases, such as:

- at speed limits below 20 km/h
- in wet conditions or in fog

- when towing a trailer
- Ensure that the driven speed complies with traffic regulations.
- Adjust the driving speed to suit current traffic and weather conditions.

Requirements

Active Distance Assist DISTRONIC:

- · The electric parking brake is released.
- ESP® is activated and is not intervening.
- The transmission is in position **D**.
- All the doors are closed.
- · Check of the radar sensor system has been successfully completed.
- Snow chain mode is not active (\rightarrow page 510).

Variable limiter:

The variable limiter is selected.



Adopts the stored/detected speed Deactivates Active Distance Assist DISTRONIC / the variable limiter

Increases/decreases the speed

Increases/decreases the specified distance

Switches between the variable limiter and Active Distance Assist DISTRONIC

To operate Active Distance Assist DISTRONIC or the variable limiter: press the respective button with only one finger or swipe on the control panel.

Switches between the variable limiter and Active Distance Assist DISTRONIC

▶ Press 📆.

Activating the variable limiter or Active Distance Assist DISTRONIC

To activate without a stored speed: press SET/+, SET/- or RES/

RES/

Active Distance **Assist DISTRONIC:** remove your foot from the accelerator pedal.

The current vehicle speed is stored and maintained (Active Distance Assist DISTRONIC) or limited (variable limiter) by the vehicle.

To activate with a stored speed: press RES/9. Active Distance Assist DISTRONIC: remove your foot from the accelerator pedal. The last stored speed is called up and the vehicle maintains this speed (Active Distance Assist DISTRONIC) or does not exceed it (variable limiter).

If the stored speed has been deleted, the current vehicle speed is stored.

When you switch off the vehicle, the stored speed is deleted. When you activate Active Distance Assist DISTRONIC, the last speed stored for the variable limiter is deleted.

Increasing or reducing the speed

- To increase the stored speed: swipe upwards from the bottom of control panel 1.
 - The stored speed is increased by 1 km/h.
- To decrease the stored speed: swipe downwards from the top of control panel 1.
 - The stored speed is decreased by 1 km/h.

Briefly press **SET/+** on the upper section or **SET/**- on the lower section of control panel

The stored speed is increased or reduced by 10 km/h.

Press and hold **SET/+** on the upper section or SET/- on the lower section of control panel

The stored speed is increased or reduced in increments of 10 km/h.

- Accelerate the vehicle to the desired speed.
- Press **SET/+** on the upper section of control panel 1.

Adopting the limit speed shown in the driver's display

- Activate Active Distance Assist DISTRONIC or the variable limiter: press SET/+, SET/- or RES/9.
- Accept the displayed speed limit: press RESI®. The limit speed displayed in the driver's display is adopted as the stored speed. The vehicle adapts its speed to that of the vehicle in front, but only up to the stored speed, or limits its speed accordingly.
- A speed limit shown in the driver display is only adopted while driving, not when stationary.

Pulling away with Active Distance Assist DISTRONIC

- Activate Active Distance Assist DISTRONIC and remove your foot from the brake pedal.
- Press RES/9.

Depress the accelerator pedal briefly and firmly.

The functions of Active Distance Assist DISTRONIC continue to be carried out.

Reducing or increasing the specified distance from the vehicle in front

Press 5.

The display appears. The specified distance is reduced by one level.

If the lowest level is already selected, the selection jumps to the highest level.

Deactivating Active Distance Assist DISTRONIC or the variable limiter



WARNING Risk of an accident due to Active Distance Assist DISTRONIC being active when you leave the driver's seat

If you leave the driver's seat while the vehicle is being braked by Active Distance Assist DISTRONIC only, the vehicle can roll away.

Always deactivate Active Distance Assist DISTRONIC and secure the vehicle to prevent it from rolling away before you leave the driver's seat.



If you brake, deactivate ESP® or if ESP® intervenes, Active Distance Assist DISTRONIC is deactivated. The variable limiter is not deactivated.

■ Function of Active Speed Limit Assist

If a changed speed limit is detected and the automatic adoption of speed limits is switched on, this is automatically adopted as the stored speed

 $(\rightarrow$ page 236). Speed limits below 20 km/h are not accepted.

The driven speed is adjusted when the vehicle is level with the traffic sign at the latest. In the case of signs indicating entry into an urban area, the speed is adapted according to the speed permitted within the urban area. The speed limit display in the driver's display is always updated when the vehicle is level with the traffic sign.

If you are driving on German motorways and there is no speed limit, the system uses the speed stored for a stretch of road with no speed limit as the set speed. If you do not alter the stored speed on a stretch of road with no speed limit, the recommended speed of 130 km/h is adopted.

If Active Distance Assist DISTRONIC has been put into passive mode by pressing the accelerator pedal, only speed limits which are higher than the set speed are adopted.

The maximum permissible speed does not take the road condition and current weather and traffic conditions into account. Adjust your speed accordingly, when necessary.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

System limits

The system limits of Traffic Sign Assist apply to the detection of traffic signs (\rightarrow page 250).

Speed limits below 20 km/h are not automatically adopted by the system as the stored speed. Temporary speed restrictions (e.g. for a certain time or due to weather conditions) cannot be properly detected by the system.

The maximum permissible speed applying to a vehicle with a trailer is not detected by the system.

Adjust the speed in these situations.



WARNING Risk of accident due to Active Speed Limit Assist adapting the vehicle's speed

The speed adopted by Active Speed Limit Assist may be too high or incorrect in some individual cases, such as:

- at speed limits below 20 km/h
- in wet conditions or in fog
- when towing a trailer
- Ensure that the driven speed complies with traffic regulations.
- Adjust the driving speed to suit current traffic and weather conditions.

Function of route-based speed adaptation

When Active Distance Assist DISTRONIC is activated, the vehicle speed will be adapted accordingly to the route events ahead. Depending on the drive program selected, the vehicle negotiates a route event ahead in an energy-saving, comfortable or dynamic manner. When the route event has been passed, the vehicle accelerates again to the stored speed. The set distance to the vehicle in front, vehicles detected ahead and speed restrictions ahead are taken into account.

Route-based speed adaptation can be activated in the multimedia system (\rightarrow page 236).

The following route events are taken into account:

Bends

- Roundabouts
- T-junctions
- Turns and exits
- Traffic jams ahead (only with Live Traffic $(\rightarrow page 396))$

Also, the speed is reduced if the turn signal indicator is switched on and one of the following situations is detected:

- Turning at junctions
- · Driving on slowing-down lanes
- Driving on lanes adjacent to slowing-down lanes

The driver is responsible for choosing the right speed and observing other road users. This applies in particular to junctions, roundabouts and traffic lights, as route-based speed adaptation does not brake the vehicle to a standstill.

Speed adaptation is cancelled in the following cases:

 If the turn signal indicator is switched off before the route event and it is therefore

- assumed that the route event is not relevant to the driver.
- If the driver depresses the accelerator or brake pedal during the process.

System limits

Route-based speed adaptation does not take right of way regulations into account. The driver is responsible for complying with road traffic regulations and driving at a suitable speed.

In difficult conditions, the speed selection made by the system may not always be suitable. This applies to the following situations, forexample:

- the road's course not clearly visible
- Road narrowing
- varying maximum permissible speeds in individual lanes, forexample at toll stations
- · wet road surfaces, snow or ice
- If transport equipment, forexample a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

In these situations the driver must intervene accordingly.

WARNING Risk of accident in spite of route-based speed adaptation

Route-based speed adaptation can malfunction or be temporarily unavailable in the following situations:

- If the driver does not follow the calculated route
- If map data is not up-to-date or available
- In the event of roadworks
- In bad weather or road conditions
- If the accelerator pedal is depressed
- In the event of electronically displayed speed limitations
- Adapt the speed to the traffic situation.

Setting Active Distance Assist DISTRONIC driving styles

Requirements:

Active Distance Assist DISTRONIC is activated.

Multimedia system:

→ Settings → Assistance → Driving → Active Distance Assist

Selecting a driving style

- Select Based on DYNAMIC SELECT, Dynamic or Comfortable.
- i Further information about Active Distance Assist DISTRONIC (→ page 231).

Setting speed adaptation

Select Route based or Speed limit. When these functions are active, the vehicle speed is adjusted depending on the route events ahead.

- (i) When one of the following systems is active, the detected speed can be manually adopted as the speed limit:
 - Active Distance Assist DISTRONIC
 - Cruise control
 - · Variable limiter
- Further information on speed adaptation
 (→ page 235).

Function of Active Stop-and-Go Assist

Active Stop-and-Go Assist helps you when in traffic jams on multi-lane roads with separate carriageways by automatically pulling away within up to 60 seconds and with moderate steering manoeuvres. It orients itself using the vehicle in front and lane markings. Active Stop-and-Go Assist automatically maintains a safe distance from the vehicle in front and vehicles cutting in.

Active Stop-and-Go Assist requires you, as the driver, to keep your hands on the steering wheel at all times so that you are able to intervene at any time to correct the course of the vehicle and keep it in lane.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

Active Stop-and-Go Assist activates automatically when all of the following conditions are met:

- · You are in a traffic jam on a motorway or highspeed major road.
- Active Distance Assist DISTRONIC is activated and active (\rightarrow page 231).
- Active Steering Assist is activated and active $(\rightarrow page 239).$
- You are travelling no faster than 60 km/h.

When Active Stop-and-Go Assist is active the status display appears in the driver's display.

System limits

The system limitations of Active Distance Assist DISTRONIC and Active Steering Assist apply to Active Stop-and-Go Assist (\rightarrow page 237).

Active Steering Assist

■ Function of Active Steering Assist

Active Steering Assist is only available up to a speed of 210 km/h. The system helps you to stay in the centre of the lane by means of moderate steering interventions. Depending on the speed driven, Active Steering Assist uses the vehicles ahead and lane markings as a reference.

Depending on the country, in the lower speed range Active Steering Assist can use the surrounding traffic as a reference. If necessary, Active Steering Assist can then also provide assistance when driving outside the centre of the lane.

If the detection of lane markings and vehicles ahead is impaired, Active Steering Assist switches to passive mode. The system provides no support in this case.

Permanent status display in the driver's display

Grey: activated and passive



Green: activated and active



Red, flashing: prompt to the driver to actively confirm or transition from active to passive status, system limit detected

During the transition from active to passive status, the symbol is shown as enlarged and flashing. Once the system is passive, the symbol is shown as grey in the driver's display.

Contact detection

The driver is required to keep their hands on the steering wheel at all times and be able to intervene at any time to correct the course of the vehicle and keep it in lane. The driver must expect a change from active to passive mode or vice versa at any time.



If the system detects that the driver has not steered the vehicle for a considerable period of time or has removed their hands from the steering wheel, an optical warning is given first. Display appears in the driver's display. If the driver still does not steer the vehicle, or gives no confirmation to the system, a warning tone sounds in addition to the visual warning message.

If the driver does not react to this warning for a considerable period, an emergency stop is initiated (\rightarrow page 239).

The warning is not issued or is stopped as soon as the system detects that the driver has touched the steering wheel. The touch detection may be limited or without function if there is no direct contact between the hand and the steering wheel, e.g. when wearing gloves or if there is a steering wheel cover on the steering wheel.

If Active Steering Assist detects that a system limit has been reached, a visual warning is issued and a warning tone sounds.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

System limits

Active Steering Assist has a limited steering torque for lateral guidance. In some cases, the steering intervention is not sufficient to keep the vehicle in the lane.

The system may be impaired or may not function in the following instances:

- There is poor visibility, e.g. due to snow, rain, fog, heavy spray, greatly varying light conditions or strong shadows on the carriageway.
- There is glare, e.g. from oncoming traffic, direct sunlight or reflections.

- Insufficient road illumination.
- The windscreen is dirty, misted up, damaged or covered in the vicinity of the camera, e.g. by a sticker.
- No, or several, unclear lane markings are present for one lane, or the markings change quickly, forexample, in a construction area or junctions.
- The lane markings are worn away, dark or covered up, e.g. by dirt or snow.
- If the distance to the vehicle in front is too short and thus the lane markings cannot be detected.
- · The road is narrow and winding.
- There are obstacles on the lane or projecting out into the lane, such as object markers.
- If transport equipment, forexample a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

The system does not provide assistance in the following conditions:

On very tight bends and when turning.

- When crossing junctions.
- At roundabouts or toll stations.
- When actively changing lane without switching on the turn signal indicator.
- When the tyre pressure is too low.

WARNING Risk of accident if Active Steering Assist unexpectedly stops functioning

If the system limits of Active Steering Assist are reached there is no guarantee that the system will remain active or will keep the vehicle in lane.

- Always keep your hands on the steering wheel and observe the traffic carefully.
- Always steer the vehicle paying attention to traffic conditions.

WARNING Risk of accident if Active Steering Assist unexpectedly intervenes

The detection of lane markings and objects may malfunction and cause unexpected steering interventions.

Steer according to traffic conditions.

You can watch an animation on this topic via the following link:

Activating/deactivating Active Steering Assist

Requirements

- ESP[®] is activated, but is not intervening.
- Active Distance Assist DISTRONIC is activated.

Multimedia system:

→ Settings → Assistance Driving

Activate or deactivate Active Steering Assist.

Function of Active Emergency Stop Assist

Active Emergency Stop Assist monitors the steering wheel and the accelerator and brake pedals. If the system detects a lack of driver activity and the vehicle threatens to leave the lane, a warning can be issued and an emergency stop initiated.

Vehicles without Driving Assistance Package: The system is available from a speed of approx. 60 km/h.

Vehicles with Driving Assistance package: If Active Steering Assist is switched off, the system is available from a speed of approx. 60 km/h.

If the system detects that the vehicle is threatening to leave the lane, a warning can be issued and an emergency stop initiated.

- The driver does not touch the steering wheel for a longer period of time or no steering movement can be measured for a longer period of time (depending on the vehicle equipment).
- Neither the accelerator nor the brake pedal is depressed.
- Vehicles with Driving Assistance package: if Active Steering Assist is switched on and active, only the steering wheel is monitored by the system. If the driver does not touch the steering wheel for a longer period of time, a warning may be given despite pedal actuation.

Also observe the instructions on the contact detection of Active Steering Assist $(\rightarrow \text{page } 237)$.



Active Emergency Stop Assist issues the following warnings in order:

- Display message

 appears in the driver's display.
- The message Beginning emergency stop will appear in the driver's display, a continuous warning tone will sound, the vehicle will no longer accelerate and, if necessary, slight belt tensioning will be produced.

- The vehicle speed is reduced in increments until it is at a standstill. Sharp brake impulses are also produced.
- (i) Vehicles with Driving Assistance Package: If Active Distance Assist DISTRONIC is active and the driver unfastens the seat belt and driver's door, an emergency stop can be initiated immediately.

Vehicles with Driving Assistance Package:

Depending on the country, a lane change to the adjacent lane is carried out, if possible. It is only possible to change across one lane and only into the outer lane, not onto the hard shoulder.

When automatic braking is initiated, Active Distance Assist DISTRONIC is deactivated. Depending on the country, the hazard warning light system is switched on.

When the vehicle is stationary, the following actions are carried out:

- The vehicle is secured with the electric parking brake.
- · The vehicle is unlocked.

 If possible, an emergency call is placed to the Mercedes-Benz emergency call centre.

Before automatic braking is initiated, you can cancel Active Emergency Stop Assist by steering.
You can cancel the intervention by Active Emergency Stop Assist after automatic braking is initiated by one of the following actions:

- Accelerating or braking: the emergency stop is cancelled, but the warning message, warning tone and power steering remain active
- Steering: power-assisted steering is cancelled, the warning message and warning tone remain active and the vehicle continues to be braked
- (i) Active Emergency Stop Assist can initiate an emergency stop a maximum of three times within a driving cycle. After that, Active Steering Assist and Active Emergency Stop Assist are disabled until the vehicle has been restarted.

System limits

For the detection of vehicles and other obstacles, observe the system limits of the following functions:

- Active Distance Assist DISTRONIC $(\rightarrow page 228)$
- Active Steering Assist (→ page 237)
- Active Lane Change Assist (→ page 241)
- Active Brake Assist (→ page 243)

Active Lane Change Assist

Function of Active Lane Change Assist

Active Lane Change Assist supports the driver when changing lanes and is activated by indicating briefly.

For this, the following conditions must be fulfilled:

- You are on a motorway or high-speed major road.
- The vehicle speed is between approximately 80 km/h and 180 km/h.
- The neighbouring lane is separated by a broken lane marking.

- No vehicle or obstacle is detected in the adiacent lane.
- Since the last time the vehicle was started, the sensors have detected a vehicle at a suitable distance behind your vehicle.
- Active Lane Change Assist is selected in the multimedia system.
- Active Distance Assist DISTRONIC and Active Steering Assist are activated on motorways.

The system is not available and must be reactivated in the following situations:

- Active Distance Assist DISTRONIC and Active Steering Assist were already activated before entering the motorway.
- · The system briefly does not detect the road you are on as a motorway or a motorway-like road, e.g. on a motorway junction.

As soon as Active Lane Change Assist detects a suitable road, you can reactivate it with RESI®, SET/+ or SET/-.

Display in the driver's display in the Assistance menu



- Green arrow: lane change initiated
- Red arrow: lane change cancelled

When Active Lane Change Assist is available, the display appears along with green arrows in the driver's display. If the system has been activated but is not currently available, the display appears along with grey arrows in the driver's display.

If no vehicle or obstacle is detected in the adjacent lane and a lane change is permitted, the lane change begins after the driver has indicated briefly. The lane change is shown to the driver with a flashing green arrow next to the with a flashing green arrow next to the steering wheel symbol. Green arrow Assistance is displayed in the appropriate adjacent lane in the menu in the driver's display. Themessage, for Lane change to the left example, also appears.

Active Lane Change Assist can be cancelled in various situations, including the following:

- Change in the surrounding conditions (e.g. detected obstacle).
- The driver removes their hands from the steering wheel.
- The driver steers with too much force or in the opposite direction.
- The driver moves the turn signal indicator in the opposite direction.
- Active Distance Assist DISTRONIC or Active Steering Assist is deactivated.

The vehicle cannot make the lane change as planned.

Cancellation of Active Lane Change Assist is displayed as follows:

- The arrow in the selected direction of travel turns red.
- A corresponding message will also appear in the driver's display.
- In certain circumstances a warning tone sounds.

WARNING Risk of accident when changing lane to an occupied adjacent lane

Lane Change Assist cannot always clearly detect if the adjacent lane is free.

The lane change might be initiated although the adjacent lane is not free.

- Before changing lanes, make sure that the neighbouring lane is free and there is no danger to other road users.
- Monitor the lane change.

WARNING Risk of accident if Lane Change Assist unexpectedly stops functioning

If the system limitations for Lane Change Assist have been reached, there is no guarantee that the system will remain active.

Lane Change Assist cannot then assist you by applying steering torque.

Always monitor the lane change and keep your hands on the steering wheel. Observe the traffic conditions and steer and/or brake if necessary.

System limits

The system limitations of Active Steering Assist apply to Active Lane Change Assist $(\rightarrow$ page 237).

The system may also be impaired or may not function in the following situations:

- The sensors are damaged, covered or dirty (→ page 215).
- The exterior lighting shows a defect.

- The system does not detect a suitable road, forexample, in tight bends or shortly after a slip road.
- The vehicle is on a construction site.
- The Active Lane Change Assist sensors adjust automatically while a certain distance is being driven after the vehicle has been delivered. Active Lane Change Assist is unavailable or only partially available during this teach-in process, and no arrows are displayed next to the Active Steering Assist symbol.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

Setting Active Lane Change Assist Multimedia system:

→ Settings → Assistance Driving

- Select Active Lane Change Assist.
- Select between the On, Also automatic or Off setting options.

Active Brake Assist

■ Function of Active Brake Assist

Active Brake Assist consists of the following functions:

- · Distance warning function
- Collision warning
- Autonomous braking function
- Situation-dependent brake force boosting
- Cornering Assist
- Vehicles with Driving Assistance Package: Evasive Steering Assist and intersection start-off function

Active Brake Assist can help you to minimise the risk of a collision with vehicles, cyclists or pedestrians or to reduce the effects of such a collision. If Active Brake Assist has detected a risk of colli-

sion, a warning tone sounds and the A distance warning lamp lights up.



In the Assistance menu, an insufficient distance 1 to the vehicle in front is displayed in red. If you further reduce the distance, the vehicle in front is also highlighted in red. When the system detects a risk of collision, red radar waves 2 appear in front of the vehicle.

- Vehicles with PRE-SAFE®: depending on the country, an additional haptic warning occurs in the form of slight, repeated tensioning of the seat belt.
- Vehicles with active ambient lighting: if Warning assistance is activated, the Active Brake Assist warning is also accompanied by ambient lighting (\rightarrow page 160).

If you do not react to the warning, autonomous braking can be initiated in critical situations.

In particularly critical situations, Active Brake Assist can also initiate autonomous braking directly. In this case, the warning tone is sounded and the distance warning lamp lights up simultaneously with the brake application.

If you apply the brake yourself in a critical situation or apply the brake during autonomous braking, situation-dependent brake force boosting occurs. The brake pressure increases up to maximum full-stop braking if necessary.



If autonomous braking or situation-dependent brake force boosting has occurred, pop up 1 appears in the driver's display and then automatically goes out after a short time.

If the autonomous braking function or situationdependent brake force boosting is triggered, additional preventive measures for occupant protection (PRE-SAFE®) may also be initiated.

WARNING Risk of an accident caused by limited detection performance of Active Brake Assist

Active Brake Assist cannot always clearly identify objects and complex traffic situations.

In such cases, Active Brake Assist might:

- Give a warning or brake without reason
- Not give a warning or not brake

Active Brake Assist is only an aid. The driver is responsible for maintaining a sufficiently safe distance to the vehicle in front, vehicle speed and for braking in good time.

Always pay careful attention to the traffic situation; do not rely on Active Brake Assist alone.



▶ Be prepared to brake or swerve if necessary.

If Active Brake Assist is deactivated or the functions are restricted, e.g. due to activation of another driving system, the Active Brake Assist warning lamp appears in the driver's displav.

If the system is unavailable due to dirty or damaged sensors or due to a fault, or if the functions are restricted, the Active Brake Assist warning lamp appears in the driver's display.

Also observe the system limits of Active Brake Assist.

The individual subfunctions are available in the following speed ranges:

Distance warning function

You are warned by the distance warning function from approximately 30 km/h if, over several seconds, the distance maintained to the vehicle travelling in front is insufficient for the driven speed. In this case, the distance warning lamp in the driver's display lights up. If the distance to the vehicle in front continues to decrease at higher

speeds, the A distance warning lamp begins to flash.

Collision warning

Collision warning can assist you in the following situations from approximately 7 km/h with an intermittent warning tone and the A distance warning lamp.

Vehicles without Driving Assistance Package:

- at speeds up to approximately 250 km/h when approaching vehicles ahead
- at speeds up to approximately 80 km/h when approaching stationary vehicles, pedestrians walking in the direction of travel and cyclists ahead
- at speeds up to approximately 70 km/h when approaching crossing pedestrians and cyclists
- at speeds up to approximately 60 km/h when approaching stationary pedestrians and cvclists

Vehicles with Driving Assistance Package:

• at speeds up to approximately 250 km/h when approaching vehicles ahead

- at speeds up to approximately 120 km/h when approaching crossing vehicles, pedestrians and cyclists
- at speeds up to approximately 100 km/h when approaching stationary vehicles
- at speeds up to approximately 80 km/h when approaching cyclists ahead
- at speeds up to approximately 70 km/h when approaching stationary pedestrians and cyclists

Autonomous braking function

If the vehicle is travelling at speeds above approximately 7 km/h, the autonomous braking function may intervene in the following situations:

Vehicles without Driving Assistance Package:

- at speeds up to approximately 250 km/h when approaching vehicles ahead
- at speeds up to approximately 80 km/h when approaching cyclists ahead, pedestrians walking in the direction of travel and stationary vehicles
- at speeds up to approximately 70 km/h when approaching crossing pedestrians and cyclists

Vehicles with Driving Assistance Package:

- at speeds up to approximately 250 km/h when approaching vehicles ahead
- at speeds up to approximately 120 km/h when approaching crossing vehicles, pedestrians and cyclists
- at speeds up to approximately 100 km/h when approaching stationary vehicles
- at speeds up to approximately 80 km/h when approaching cyclists ahead
- at speeds up to approximately 70 km/h when approaching stationary pedestrians and cvclists

Situation-dependent brake force boosting

If the vehicle is travelling at speeds above approximately 7 km/h, situation-dependent brake force boosting may intervene in the following situations.

Vehicles without Driving Assistance Package:

- at speeds up to approximately 250 km/h when approaching vehicles ahead
- at speeds up to approximately 80 km/h when approaching cyclists ahead, pedestrians walk-

ing in the direction of travel and stationary vehicles

- at speeds up to approximately 70 km/h when approaching crossing pedestrians and cyclists
- at speeds up to approximately 60 km/h when approaching stationary pedestrians and cyclists

Vehicles with Driving Assistance Package:

- at speeds up to approximately 250 km/h when approaching vehicles ahead
- at speeds up to approximately 120 km/h when approaching crossing vehicles, pedestrians and cyclists
- at speeds up to approximately 100 km/h when approaching stationary vehicles
- at speeds up to approximately 80 km/h when approaching cyclists ahead
- at speeds up to approximately 70 km/h when approaching stationary pedestrians and cyclists

Cancelling a brake application of Active Brake Assist

You can cancel a brake application of Active Brake Assist at any time by:

- Fully depressing the accelerator pedal or with kickdown.
- · Releasing the brake pedal.

Active Brake Assist may cancel the brake application when one of the following conditions is fulfilled:

- · you manoeuvre to avoid the obstacle
- there is no longer a risk of collision
- an obstacle is no longer detected in front of your vehicle

Reaction to oncoming road users (only vehicles with Driving Assistance Package)

Active Brake Assist can also react to detected oncoming road users:

 Reaction up to speeds of approximately 100 km/h

- Warning for oncoming road users through acoustic warning and distance warning lamp
- Autonomous braking application in order to reduce the severity of an accident

Cornering function

If the system detects a danger of collision from oncoming road users when turning across an oncoming lane, autonomous braking can be initiated at speeds of up to approx. 20 km/h.

Intersection start-off function (only vehicles with Driving Assistance Package)



If, when pulling away or driving at a walking pace, the risk of collision with other crossing vehicles is detected, three red arrows pointing in the direction of the crossing road user light up one by one along with the A distance warning lamp in the driver's display. If the situation is particularly critical, the arrows flash. A warning tone will also sound. If you do not react to the warning in critical situations, acceleration may be restricted or autonomous braking may be initiated. Autonomous braking can also prevent the vehicle from pulling away and hold it at a standstill. In particularly critical situations, Active Brake Assist can also initiate autonomous braking directly. In this case, the distance warning lamp lights up and the warning tone is sounded simultaneously with the brake application.

If autonomous braking or situation-dependent brake force boosting has occurred, a pop up appears in the driver's display and then automatically goes out after a short time.

In the Late setting of Active Brake Assist, the purely visual warning level and the limitation of possible acceleration is deactivated. If the situation is particularly critical, a visual warning may

continue to be displayed, a warning tone may sound and autonomous braking may be initiated.

Evasive Steering Assist

WARNING Risk of accident despite Evasive Steering Assist

Evasive Steering Assist cannot always recognise objects or complex traffic situations clearly.

Moreover, the steering support provided by Evasive Steering Assist is not sufficient to avoid a collision.

- Always pay careful attention to the traffic situation; do not rely on Evasive Steering Assist alone.
- Be prepared to brake or swerve if necessary.
- End the support by actively steering in non-critical situations.
- Drive at an appropriate speed if there are pedestrians close to the path of your vehicle.

Evasive Steering Assist has the following characteristics:

- · Detection of pedestrians, cyclists and vehicles.
- Assistance through power-assisted steering if it detects a swerving manoeuvre.
- Activation by an abrupt steering movement during a swerving manoeuvre.
- Assistance during swerving and straightening of the vehicle.
- Reaction from a speed of approximately 20 km/h up to a speed of approximately 110 km/h.

The steering support of Evasive Steering Assist can be cancelled at any time by counter steering.

System limits

Full system performance is not available for a short time after switching on the vehicle or after driving off. As long as the functions are restricted, the Active Brake Assist warning lamp can also be shown in the driver's display. Depending on the environmental conditions, it may take a

few minutes before full system performance is available.

The system may be impaired or may not function, particularly in the following situations:

- In snow, rain, fog, heavy spray, if there is glare, in direct sunlight or in greatly varying light conditions.
- If the sensors are dirty, misted up, damaged or covered. (→ page 215)
- If the sensors are impaired due to interference from other radar sources, e.g. strong radar reflections in multi-storey car parks.
- If a loss of tyre pressure or a defective tyre has been detected and displayed.
- In complex traffic situations where objects cannot always be clearly identified.
- If pedestrians, cyclists or vehicles move quickly into the sensor detection range.
- If road users are hidden by other objects or are located close to other objects.
- If the typical outline of a pedestrian or cyclist cannot be distinguished from the background.

- If a pedestrian or cyclist is not detected as such, e.g. due to special clothing or other objects.
- · If the driver's seat belt is not fastened.
- On bends with a tight radius.

You can watch an animation on this topic via the following link:

Setting Active Brake Assist

Requirements:

• The vehicle is switched on.

Multimedia system:

- → Settings → Assistance
- >> Collision avoidance
- Activate or deactivate the function.
- i It is recommended that you always leave Active Brake Assist activated.

When Active Brake Assist is deactivated, the distance warning function, the collision warning, the autonomous braking function and Evasive Steering Assist are deactivated.

i If Active Brake Assist is deactivated, the symbol appears in the status bar of the driver's display, and the system is reactivated the next time the vehicle is started.

Setting the time of the warnings

- Select next to Active Brake Assist.
- Select Early, Medium or Late.
- i) If ATTENTION ASSIST has detected indications of fatigue or a microsleep, the system can issue a warning earlier than the set time (country-dependent). Further information about ATTENTION ASSIST (→ page 222).

Speed Limit Assist

Function of Speed Limit Assist

(i) Speed Limit Assist uses OpenStreetMap data, which is made available under the conditions of the Open Database License (OBbL). For more information, see: https://www.osmfoundation.org/wiki/licence.

Speed Limit Assist detects speed limits with a multifunction camera and shows them in the driv-

er's display and optionally in the head-up display. The camera also detects speed limits with a restriction indicated by an additional sign (e.g. when wet).

Observe the notes on driving systems and your responsibility to ensure that you can recognise any dangers (\rightarrow page 215).

Warning when the permissible maximum speed is exceeded

The system can warn you if you unintentionally exceed the permissible maximum speed. Depending on the country, you can set in the multimedia system by how much the permissible maximum speed may be exceeded before a warning is given. You can set whether the warning should be visual (by flashing the traffic sign in the driver display) or visual and acoustic. The selection of the type of warning is confirmed country-specifically by an indication in the driver display.



- Visual warning only
- Warning off
- The type, duration and activation threshold of the speed warning, as well as the option of setting the activation threshold above which the warning is to be triggered, are subject to the legislation that is specific to the country in which the vehicle is delivered.

Display in the driver's display



- Permissible speed
- Permissible speed when there is a restriction
- Additional sign with restriction
- Traffic signs which have an impact on the permissible maximum speed, e.g. signs indicating the beginning or end of dual carriageways, can also be detected.

The system can show a maximum of two traffic signs in the driver's display simultaneously. The system always prioritises the display of speed limits. Up to one traffic sign with a permissible maximum speed can be shown in the head-up display.

If Speed Limit Assist cannot determine the current permissible maximum speed (e.g. if there is inadequate signage), the following display appears in the driver's display:



This is displayed continuously if the vehicle is in a country where Speed Limit Assist is not supported. Speed Limit Assist is not available in all countries.

If the system is temporarily or permanently unavailable due to a technical fault or dirt on the windscreen, a corresponding display message appears in the driver display. Depending on the country, the warning light on the driver's display also lights up.

(i) Please also note the information on the display messages (→ page 644).

System limits

The system may be impaired or inoperative particularly in the following situations:

- If visibility is poor, e.g. due to insufficient illumination of the road, highly variable shade conditions, rain, snow, fog, swirling dust or heavy spray.
- If there is glare, e.g. from oncoming traffic, direct sunlight or reflections.
- If there is dirt on the windscreen in the vicinity of the multifunction camera or if the camera is misted up, damaged or obscured.
- If the traffic signs are difficult to see because, forexample, they are dirty, obscured, faded, iced over, damaged, inconveniently positioned, insufficiently illuminated or distorted.
- Digital LED traffic signs may not be detected correctly or at all due to technical factors suchas transmission frequency.
- If the signs, road markings or road layout are ambiguous, e.g. in the case of traffic signs in

- construction sites, at exits and driveways, in the case of adjacent lanes or parallel roads, in the case of pedestrian crossing markings at traffic lights
- If the signage or road markings do not comply with the standard
- If the signage, road markings or road guidance is country-specific and deviates from the route guidance of the navigation system, e.g. in or after road works
- After sharp turns and tight bends, when traffic signs are outside the camera's field of vision.
- If you overtake vehicles with traffic signs which are affixed or attached to them.
- If you are using transport equipment secured with a trailer coupling, suchas a bicycle rack, the system may react to restrictions for car/ trailer combinations.

Traffic Sign Assist

Function of Traffic Sign Assist

 This function is an on-demand feature (→ page 25). The traffic sign assistant detects the traffic signs with the multifunction camera and compares them with the information on the digital road map of the navigation system. It assists you by displaying detected speed limits and overtaking restrictions in the driver's display and in the head-up display. The system can issue a warning when you exceed the maximum permissible speed.

The camera also detects and analyses traffic signs with a restriction indicated by an additional sign (e.g. when wet).

Traffic Sign Assist portrays only selected signs in the driver's display. Actual traffic signs and speed limits have priority over traffic signs and speed limits shown in the driver's display.

Also observe the following information:

- · select a speed adapted to the traffic, surroundings and weather conditions
- · observe actual traffic signs
- observe applicable traffic rules and regulations

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

Displays in the driver's display



- Permissible speed
- Permissible speed when there is a restriction
- Additional sign with restriction



Examples of traffic signs which can be displayed

Traffic Sign Assist can detect and display following traffic signs 1:

- speed limits
- end of the speed limit
- overtaking restrictions
- play streets
- depending on the country: signs showing the start or end of motorways and dual carriagewavs

Traffic Sign Assist can detect following additional signs (3) and, if necessary, analyse the relevance of the restrictions using other vehicle sensors:

- · when wet
- slippery road surfaces
- in fog
- temporary restrictions
- exits
- restrictions for car/trailer combinations

Traffic Sign Assist also uses data from the digital street map in the navigation system. When you leave or enter a municipality or change roads, on a motorway exit or slip road forexample, or after you turn at a junction, the display in the driver's display can thus be updated without a traffic sign having been detected.

(i) Regularly update the digital road map of the navigation system so that the traffic sign assistant can work optimally (\rightarrow page 404).

If Traffic Sign Assist cannot determine the currently applicable maximum permissible speed (e.g. due to missing signs), the following display appears in the driver's display:



Traffic Sign Assist is not available in all countries. If the vehicle is in a country where Traffic Sign Assist is not supported, this is displayed continuously.


If the Traffic Sign Assist is temporarily or permanently unavailable due to a technical malfunction or soiling of the windscreen, the Traffic Sign Assist warning light appears in the driver's display.

(i) Please also note the information on the display messages of the traffic sign assistant $(\rightarrow page 644)$.

Warning when the maximum permissible speed is exceeded

The system can warn you if you unintentionally exceed the maximum permissible speed. Depending on the country, you can set in the multimedia system by how much the maximum permitted speed may be exceeded before a warning is given. You can switch off the warning or set whether the

warning should be visual (by flashing the traffic sign in the driver display) or visual and audible. The selected setting is confirmed by an indication in the driver's display.



- Warning only visual
- WARNING off
- The type, duration and trigger levels of the speed warning, as well as the possibility of setting the trigger levels beyond which the warning is to be triggered, are subject to the country-specific legislation of the country in which the vehicle is delivered...

Additional functions of Traffic Sign Assist (country-specific)

Warning for no-entry signs: Traffic Sign Assist can warn you if you drive the wrong way down a section of road, forexample on motorway slip roads or one-way streets.

Warning at pedestrian crossings: if you approach pedestrian crossings, provided that pedestrians are in the danger zone or are moving towards it, Traffic Sign Assist can warn you up to a speed of approximately 70 km/h.

Warning at stop signs: Traffic Sign Assist can warn you up to a speed of approximately 70 km/h if you are about to drive past a stop sign unintentionally. For this to be possible, the signs must be clear, forexample if the system detects more than one stop sign, or a stop sign can be confirmed using the digital navigation map. No warning can be issued if several different signs are detected.

Warning at red lights: Traffic Sign Assist can warn you up to a speed of approximately 70 km/h if you are about to drive through a red light unintentionally.

The following conditions must be fulfilled:

- Several traffic lights have been detected.
- · All traffic lights detected are red.
- At least one of the red traffic lights detected is on the front passenger side beside the vehicle's own lane.
- The traffic lights are in the following sequence (from top to bottom): red, yellow, green.
- (i) If the function is available, you can activate or deactivate the warnings at pedestrian crossings, stop signs and red lights in the Traffic Sign Assist menu under Further warnings $(\rightarrow page 254)$.

System limits

The system may be impaired or may not function particularly in the following situations:

- · If visibility is poor, e.g. due to insufficient illumination of the road, highly variable shade conditions, rain, snow, fog, swirling dust or heavy spray.
- If there is glare, e.g. from oncoming traffic, direct sunlight or reflections.

- If there is dirt on the windscreen in the vicinity of the multifunction camera or if the camera is misted up, damaged or obscured.
- if the traffic signs are difficult to see because. forexample, they are dirty, obscured, faded, iced over, damaged, inconveniently positioned, insufficiently illuminated or distorted.
- Active traffic signs with LED displays may not be detected correctly or at all due to technical factors, such as transmission frequency.
- If the information on the navigation system's digital map is incorrect, incomplete or out of date.
- if the signs, road markings or road layout are ambiguous, e.g. in the case of traffic signs in construction sites, at exits and driveways, in the case of adjacent lanes or parallel roads, in the case of pedestrian crossing markings at traffic lights
- · if the road marking or road markings do not comply with the standard
- if the road marking, road markings or road guidance is country-specific and deviates from

- the route guidance of the navigation system, e.g. in or after road works
- After sharp turns and tight bends, when traffic signs are outside the camera's field of vision.
- If you overtake vehicles with traffic signs which are affixed or attached to them.
- If you are using transport equipment secured to the vehicle with a trailer coupling, suchas a bicycle rack, restrictions for car/trailer combinations may be considered valid if applicable.

Setting Traffic Sign Assist

Multimedia system:

- → Settings → Assistance
- ➤ Assistance ➤ Traffic Sign Assist

Activating or deactivating the speed warning

- (i) The speed warning is switched on by default (depending on the country).
- Switch off Speed limit warning.
 The speed warning remains off according to country-specific legislation until the next time the vehicle is switched on or off and the driver's door is opened.

The audible speed warning can also be switched off and on by quick access, by pressing and holding the mute button on the steering wheel, by pressing the speed icon in the status line of the central display or via a voice control command (functions are available depending on the country).

Change the type of speed warning

Change the warning to Visual only or Visual and acoustic.

Setting the warning threshold

This value determines the speed at which a warning is issued when exceeded.

- Set the desired speed under Warning Threshold.
- (i) The availability of the function is subject to country-specific legislation.

Switching the advisory tone for a new speed limit on or off

(i) The advisory tone for a new speed limit is switched off at the factory.

The function determines whether each change of the displayed speed in the driver's display is supported with a subtle, non-intrusive sound.

- Activate or deactivate the function.
- i The availability of the function is dependent on the country.

Activating or deactivating further functions of Traffic Sign Assist

Switch further warning contents on or off. The available functions are switched on or off.

Set the type of warning for other functions

Select Visual only or Visual and acoustic.

Traffic light view

Information about the traffic light view

The traffic light view supports the driver when waiting in front of a red light by displaying the camera image on the central display. The camera image is displayed when the driver is the first vehicle in front of the red light and faded out when the vehicle drives off.

Displaying traffic light view

Requirements

- The Traffic light view option is switched on.
- · A traffic light view is available.

Multimedia system:



This function is not available in all countries.

If the vehicle is in first position at a traffic light, the camera image with traffic light view is shown on the central display.

When the vehicle pulls away, the camera image is faded out.

Activate or deactivate Traffic light view.

Using other available functions

- Select 🔼 .
- Select On request or Automatic. If On request is set and a traffic light view is available, the Please tap here for traffic light

view. message is displayed. The camera image is shown after confirmation of the message.

When Automatic is set, the camera image is automatically displayed when the traffic light view is available.


Blind Spot Assist and Active Blind Spot Assist


Function of Blind Spot Assist and Active Blind Spot Assist with exit warning

Blind Spot Assist and Active Blind Spot Assist use radar sensors to monitor the area up to 40 m behind and 3 m next to your vehicle.

The system can detect vehicles travelling from speeds of approximately 12 km/h and issue a warning if they move into the monitoring range.

Status display in the driver's display







Display in the driver's display in the Assistance menu

If a vehicle is detected at speeds above approximately 12 km/h and this vehicle enters the warning range immediately afterwards, the warning lamp in the corresponding outside mirror lights up red. In the Assistance menu, the lamp in outside mirror 1 also lights up red, and the lane in which the vehicle is detected is hatched out.

If a vehicle is detected in the warning range and you switch on the turn signal indicator in the corresponding direction, a double warning tone sounds once, and the warning lamp flashes red in the corresponding outside mirror. Red radar

waves 2 are displayed next to your vehicle in the assistance graphic.

If the turn signal indicator remains on, the display in the outside mirror flashes for all other detected vehicles, but no further warning tone sounds. If you overtake a vehicle quickly, no warning is given.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).



WARNING Risk of accident despite Blind Spot Assist

Blind Spot Assist does not react to vehicles approaching and overtaking you at a greatly different speed.

Blind Spot Assist cannot warn drivers in this situation.

Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.

Exit warning

The exit warning is an additional function of Blind Spot Assist and Active Blind Spot Assist and can warn vehicle occupants attempting to leave a stationary vehicle about approaching vehicles.



WARNING Risk of accident despite exit warning

The exit warning neither reacts to stationary objects nor to persons or road users approaching you at a greatly differing speed.

The exit warning cannot warn drivers in these situations.

Always pay particular attention to the traffic situation when opening the doors and make sure there is sufficient clearance.

If a vehicle is detected in the monitoring range, the red warning lamp lights up in the corresponding outside mirror.

If a vehicle occupant pulls the door handle on the side of the warning, a warning tone sounds twice and the ambient lighting in the respective door

and the warning lamps in the corresponding outside mirror flash red.

Vehicles with MBUX Interior Assistant: the visual warning begins as soon as the hand of a vehicle occupant moves into the area of the door.

- Vehicles with ambient lighting: the Warning assistance of the ambient lighting can be activated and deactivated (\rightarrow page 160).
- i The warning assistance can differ depending on the equipment and may vary according to the setting.

This exit warning is only available when Blind Spot Assist is active.

After the vehicle is switched off, the exit warning continues to function for a few minutes. When the outside mirror warning lamp flashes three times, the exit warning is no longer available.

The exit warning is only an aid and not a substitute for the attention of vehicle occupants. The responsibility for opening and closing the doors and for leaving the vehicle remains with the vehicle occupants.

System limits

Blind Spot Assist and Active Blind Spot Assist may be limited in the following situations, in particular:

- if there is dirt on the sensors or the sensors are obscured
- in poor visibility, e.g. due to fog, heavy rain or snow
- if there are narrow vehicles, e.g. bicycles or motorbikes
- if the road has very wide or narrow lanes
- if vehicles are not driving in the middle of their lane

Warnings may be issued in error when driving close to crash barriers or similar continuous lane borders. Always make sure that there is sufficient distance to the side for other traffic or obstacles.

Warnings may be interrupted when driving alongside long vehicles, for example lorries, for a prolonged time.

Blind Spot Assist and Active Blind Spot Assist are not operational when reverse gear is engaged.

Blind Spot Assist and Active Blind Spot Assist are not operational if transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

Additionally, the exit warning may be limited in the following situations:

- when the sensors are covered by adjacent vehicles in narrow parking spaces
- when people approach the vehicle
- in the event of stationary or slowly moving objects

You can watch an animation on this topic via the following link:

Function of the brake application of Active Blind Spot Assist

(i) The brake application function is only available for vehicles with a Driving Assistance Package.

If Active Blind Spot Assist detects a risk of a side impact in the monitoring range, a course-correcting brake application is carried out. This is designed to help you avoid a collision.

The course-correcting brake application is available in the speed range between approximately 30 km/h and approximately 200 km/h.

WARNING Risk of accident despite brake application of Active Blind Spot Assist

A course-correcting brake application cannot always prevent a collision.

- Always steer, brake or accelerate yourself, especially if Active Blind Spot Assist warns you or makes a course-correcting brake application.
- Always maintain a safe distance at the sides.

WARNING Risk of accident despite Active Blind Spot Assist

Active Blind Spot Assist does not react in the following situations:

- If you overtake vehicles at a high speed.
- If vehicles approach and overtake you at a greatly different speed.

Active Blind Spot Assist may not give warnings or intervene in such situations.

Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.



If a course-correcting brake application occurs, the red warning lamp flashes in the outside mirror and a warning tone sounds. In addition, a display (1) indicating the danger of a side collision

appears in the driver's display.

In rare cases, the system may make

In rare cases, the system may make an inappropriate brake application. This brake application

may be interrupted at any time if you steer slightly in the opposite direction or accelerate.

System limits

Either a course-correcting brake application appropriate to the driving situation, or none at all, may occur especially in the following situations:

- Vehicles or obstacles, e.g. crash barriers, are located on both sides of your vehicle.
- A vehicle approaches too closely on the side.
- You have adopted a sporty driving style with high cornering speeds.
- · You brake or accelerate significantly.
- A driving safety system intervenes, e.g. ESP[®] or Active Brake Assist.
- ESP[®] is deactivated.
- A loss of tyre pressure or a defective tyre is detected.
- Transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

Activating/deactivating Blind Spot Assist or Active Blind Spot Assist Multimedia system:

- → ☐ → Settings → Assistan

 Collision avoidance
- Activate or deactivate Active Blind Spot Assist.

Active Lane Keeping Assist

Function of Active Lane Keeping Assist

Active Lane Keeping Assist monitors the area in front of your vehicle by means of the multifunction camera (→ page 215) and can warn you before you leave your lane unintentionally. The system can guide you back into your lane through a course-correcting steering intervention and additionally warns you with vibration pulses in the steering wheel. Active Lane Keeping Assist is available in the speed range between 60 km/h and 200 km/h.

The system can intervene in the following situations:

- Active Lane Keeping Assist detects a lane marking.
- One of your front wheels goes over a lane marking.

If you activate the turn signal indicator, a steering intervention does not occur on the corresponding side.

If you leave the lane without activating the turn signal indicator, but danger of a collision with a moving obstacle is detected in your lane, a steering intervention does not occur.

Vehicles with Blind Spot Assist or Driving Assistance Package: if the system detects an obstacle, such as another vehicle in the adjacent lane, a steering intervention will occur regardless of the turn signal indicator.

In the following situations (country-dependent), Active Lane Keeping Assist may already react from a speed of approximately 45 km/h:

• If your own vehicle is overtaken by another road user and the danger of a collision is

- detected, a lane-correcting steering intervention occurs.
- If you drive over a detected lane marking, the system warns you with vibration pulses in the steering wheel.



Display 1 will appear in the driver's display and a warning tone will sound in the following situations:

- A steering intervention by Active Lane Keeping Assist lasts longer than approximately ten seconds.
- The system carries out two or more steering interventions within approximately three minutes without any steering intervention from the driver.

In the Active Lane Keeping Assist settings, you can set the sensitivity of the system and set the level of support. Additionally, you can set whether the system should react to discontinuous lane markings or only continuous lane markings $(\rightarrow page 261)$.

If ATTENTION ASSIST has detected indications of fatigue or a microsleep, the most sensitive setting is automatically selected (\rightarrow page 222).

Status displays for Active Lane Keeping Assist

White: Active Lane Keeping Assist is deactivated.

> If ESP® is deactivated or a tyre pressure loss warning is displayed, Active Lane Keeping Assist is automatically deactiva-



Yellow: there is a malfunction. Please also observe the display messages.



Grev: Active Lane Keeping Assist is activated, but not operating.



Green: Active Lane Keeping Assist is activated and operating. If the system is operational on only one side, the lane marking is shown in green on the corresponding side.



Red: Active Lane Keeping Assist has guided you back into your lane with a coursecorrecting steering intervention. The status display will flash if there is also a haptic warning in the steering wheel. The lane marking is shown in red only on the side for which there is a warning.

> Vehicles without Driving Assistance Package: if both lane markings are simultaneously shown in red in the status display, Active Lane Keeping Assist has initiated an emergency stop (\rightarrow page 239).

Active Lane Change Assist display in the "Assistance" menu



If the front wheel of the vehicle drives over a detected lane marking, this will be highlighted red in the Assistance menu in the driver's display.

(i) Vehicles with active ambient lighting: if Warning assistance is activated, the Active Lane Keeping Assist warning is also accompanied by ambient lighting (\rightarrow page 160).

System limits

In the following situations, a lane-correcting steering intervention may not occur but rather a warning may be given on the steering wheel, depending on the situation:

- You clearly and actively steer, brake or accelerate.
- If a driving safety system intervenes, such as ESP®, Active Brake Assist or Active Blind Spot Assist.
- You have adopted a sporty driving style with high cornering speeds or high rates of acceleration.
- If transport equipment, for example a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

The system may be impaired or may not function particularly in the following situations:

· If there is poor visibility, e.g. due to insufficient illumination of the road, highly variable shade conditions, rain, snow, fog or heavy spray.

- If there is glare, e.g. from oncoming traffic, the sun or reflections.
- If there is dirt on the windscreen in the vicinity of the multifunction camera or if the camera is misted up, damaged or obscured.
- If there is dirt on the bumper in the area of the radar sensors, or if they are damaged or covered.
- If there are no lane markings, or several unclear lane markings are present for one lane, e.g. around roadworks.
- · If the lane markings are worn, dark or covered.
- If the distance to the vehicle in front is too short and thus the lane markings cannot be detected.
- If the lane markings change quickly, e.g. lanes branch off, cross one another or merge.
- If the carriageway is very narrow and winding.

Observe the notes on driving systems and your responsibility; you may otherwise fail to recognise dangers (\rightarrow page 215).

Activating/deactivating Active Lane Keeping Assist

Multimedia system:

→ 🔝 >> Settings >> Assistance

- >> Collision avoidance
- ➤ Active Lane Keeping Assist
- Activate or deactivate the function.

Alternatively, Active Lane Keeping Assist can be activated and deactivated via quick-access.

- (i) After starting the vehicle, the settings are country-specific.
- Setting Active Lane Keeping Assist Multimedia system:

→ 🔝 >> Settings >> Assistance

- >> Collision avoidance
- ➤ Active Lane Keeping Assist

Setting the sensitivity

- Select 🔼 .
- Select Early, Med. or Late.

The last selected setting will be adopted the next time the vehicle is started.

(i) The standard setting for this function is dependent on the country.

Activating or deactivating assistance on discontinuous lane markings

Select Advanced support.

The last selected setting will be adopted the next time the vehicle is started.

- (i) The standard setting for this function is dependent on the country.
- This function must be activated in vehicles without Driving Assistance Package, so that Emergency Stop Assist is fully available. Further information on Emergency Stop Assist $(\rightarrow page 239)$

AIRMATIC

■ Function of AIRMATIC

AIRMATIC is an air suspension system with variable damping for improved driving comfort. The allround level control system ensures the best possible suspension and constant ground clearance, even with a laden vehicle. When driving at speed,

the vehicle is lowered automatically to improve driving safety and to reduce energy consumption. You also have the option of manually adjusting the vehicle level.

AIRMATIC includes the following components and functions:

- air suspension with automatic all-round level control
- ADS PLUS (Adaptive Damping System with constant adjustment of damping characteristics)
- speed-dependent lowering of the vehicle level
- increased vehicle level for greater ground clearance, selected via the multimedia system

Suspension setting and vehicle level per drive program

Drive program **C**:

- comfortable suspension setting
- adjusting the vehicle to normal level
- lowering the vehicle at speeds above approx.
 120 km/h to low level -1

 raising the vehicle at speeds below approx. 80 km/h

Drive program **E**:

- · comfortable suspension setting
- adjusting the vehicle to low level -1

Drive program **s**:

- · firmer suspension setting
- · adjusting the vehicle to low level -1

Individual suspension settings can be called up in drive program (\longrightarrow) page 195).

Operation with a trailer or bicycle rack: if transport equipment, such as a trailer or a bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established, the vehicle remains at normal level irrespective of speed or the drive program selected.

Setting the vehicle level

A

WARNING Risk of accident because vehicle level is too high

Driving characteristics may be impaired.

The vehicle can drift outwards, for example, when steering or cornering.

Choose a vehicle level which is suited to the driving style and the road surface conditions.

WARNING Risk of entrapment from vehicle lowering

When lowering the vehicle, other people could become trapped if their limbs are between the vehicle body and the tyres or underneath the vehicle.

Make sure no one is underneath the vehicle or in the immediate vicinity of the wheel arches when the vehicle is being lowered.

WARNING Risk of becoming trapped due to the vehicle lowering

Vehicles with AIRMATIC or level control: when you unload luggage or leave the vehicle, the vehicle first rises slightly and then returns to the set level shortly afterwards.

You or anyone else in the vicinity of the wheel arches or the underbody could thus become trapped.

The vehicle can also be lowered after being locked.

- When leaving the vehicle, make sure that nobody is in the vicinity of the wheel arches or the underbody.
- **NOTE** Damage due to vehicle lowering

Parts of the body could be damaged when the vehicle is lowered.

Make sure that there are no obstacles such as kerbs underneath or in the immediate vicinity of the body when the vehicle is being lowered.

Requirements

- The vehicle has been started.
- The vehicle is not moving faster than 60 km/h.
- When the trailer socket is contacted (trailer/ bicycle rack): the vehicle is not moving faster than 30 km/h.

Multimedia system:



Raising the vehicle

Select .

The indicator lamp lights up continuously. The vehicle is raised to off-road level +1.

Your selection is saved. Off-road level+1 set remains stored even after the vehicle has been switched off.

The vehicle is lowered again in the following situations:

When driving faster than 80 km/h.

 When the trailer socket is contacted (trailer/ bicycle rack): the vehicle is moving faster than 30 km/h.

Lowering the vehicle

Select The indicator lamp goes out.

The vehicle is lowered to normal level.


In the Sport and Eco drive programs, only normal vehicle level is possible when the trailer socket is contacted (trailer/bicycle rack).

Reversing camera

Function of the reversing camera

The reversing camera is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that there are no persons, animals or objects etc., in the manoeuvring area while manoeuvring and parking.

The area behind the vehicle is displayed as a mirror image, as in the inside rear view mirror.



- Camera views menu (top view)
- Menu Parking Assistance
- Reversing camera with top view
- Wide-angle view
- Trailer view
- Activating/deactivating Parking Assist PARKTRONIC (→ page 274)

- Warning display of Parking Assist PARKTRONIC (→ page 271, 292)
- Guide lines at a distance of approximately 0.5 m, 1.0 m, 1.5 m and 3.0 m from the rear area
- Lane marking the course the tyres will take with the current steering angle (dynamic)
- Driven surface depending on the current steering angle (dynamic)
- Guide line at a distance of approximately 0.3 m from the rear area
- i When Active Parking Assist is active, lanes (8) are displayed in green (\rightarrow page 275).



Wide-angle view



Trailer view

- Yellow guide line, locating aid
- Red guide line at a distance of approximately 0.3 m from the ball head of the trailer hitch
- Ball head of the trailer hitch

System limits

If the system is not ready for operation, the System inoperative message appears in the central display.

The reversing camera will not function or will only partially function in the following situations:

- You are driving forwards at a speed greater than approximately 16 km/h.
- The boot lid is open.
- The weather conditions are poor, e.g. heavy rain, snow, fog, storm or spray.
- The light conditions are poor, e.g. at night or if light is shining into the camera.
- The camera lens is obstructed, dirty or misted up. Observe the notes on cleaning the reversing camera (\rightarrow page 481).
- The camera or rear of your vehicle is damaged. In this case, have the camera and its position and setting checked at a qualified specialist workshop.
- The detection range is limited by additional vehicle attachments at the rear, suchas a licence plate bracket or bicycle rack.

Also observe the information on vehicle sensors and cameras (\rightarrow page 215).

- (i) Do not use the reversing camera in these types of situations. You could otherwise injure others or collide with objects when parking the vehicle.
- The contrast of the display may be impaired by direct sunlight or by other light sources, e.g. when driving out of a garage. In this case, pay particular attention.
- Have the display repaired or replaced if, forexample, pixel errors considerably restrict its use.

360° Camera

Function of the 360° Camera


The 360° Camera is a system that consists of four cameras which cover the immediate surroundings of the vehicle. The cameras assist you when you are parking, forexample, or at exits with reduced visibility.

The 360° Camera includes the following cameras and evaluates their images:

- Reversing camera
- Front camera
- · Two side cameras in the outside mirrors

The cameras are only an aid and may show a distorted view of obstacles, show them incorrectly or not show them at all. They are not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that there are no persons, animals or objects etc., in the manoeuvring area while manoeuvring and parking.

Menu overview Camera views



- Menu Parking Assistance
- Top view with image from the front camera
- Top view with image from the reversing camera
- 4 3D view, left-hand side of the vehicle
- 3D view, right-hand side of the vehicle
- 3D auto view


- Activating/deactivating Parking Assist PARKTRONIC (→ page 274)
- To set the GPS activation point
- To switch between standard and wide-angle view
- To switch between standard and trailer view
- i In all views, the Parking Assist PARKTRONIC warning display is shown (→ page 271).

Function of the guide lines



- Guide lines at a distance of approximately 0.5 m, 1.0 m, 1.5 m and 3.0 m Distance from the rear area
- Lane marking the course the tyres will take with the current steering angle (dynamic)
- Driven surface depending on the current steering angle (dynamic)
- Guide line at a distance of approximately 0.3 m from the rear area
- (i) When Active Parking Assist is active, lanes and guide lines are displayed in green instead of yellow (\rightarrow page 275).

Top view with image from the front or reversing camera



- Warning display of Parking Assist PARKTRONIC (\rightarrow page 271)
- Your vehicle from above
- Lane indicating the route the vehicle will take at the current steering angle

3D view, left/right-hand side of the vehicle

NOTE Risk of accident due to objects being severely distorted in the display or not displayed at all

Due to the projection of the cameras, objects in the 3D views may be severely distorted when displayed or not displayed at all.

Make sure that there are no persons, animals or objects etc. in the manoeuvring area while manoeuvring and parking.



Display of Parking Assist PARKTRONIC (→ page 271)

In the 3D view, left-/right-hand side of the vehicle, the virtual camera moves to the respective side of the vehicle. When you change the transmission position, the view is automatically adapted.

3D auto view

(i) The area behind the vehicle is **not** displayed as a mirror image as is usual in the 3D views.



- Display of Parking Assist PARKTRONIC (→ page 271)
- Quide lines

In the 3D auto view, the virtual camera moves to the standard perspective, facing forward from the rear above the roof. The view changes automatically when approaching obstacles.

If you touch the touchscreen, the view changes to 3D view with free rotation. You can turn, tilt and zoom the views by touch.

Wide-angle view




- Display of Parking Assist PARKTRONIC (→ page 271)
- To switch between standard and wide-angle view

Trailer view

i In trailer mode, the guide lines are shown at the level of the trailer hitch.

If you select trailer view and no trailer is coupled to the vehicle, the following display appears:



Trailer view: locating aid

- To switch between standard and trailer view
- Yellow locating aid
- Ball head of the trailer hitch
- Red guide line at a distance of approximately 0.3 m from the ball head of the trailer hitch

When the electrical connection is established between the vehicle and the trailer, the display changes to the side camera view.



Trailer view: side view of the mirror cameras

To switch between standard and trailer view

System limits

If the system is not ready for operation, the System inoperative message appears in the central display.

The 360° Camera will not function or will only partially function in the following situations:

- You are driving forwards at a speed greater than approximately 16 km/h.
- The doors are open.
- An outside mirror is not completely folded out.
- The boot lid is open.

- The weather conditions are poor, e.g. heavy rain, snow, fog, storm or spray.
- The light conditions are poor, e.g. at night or if light is shining into the camera.
- The camera lens is obstructed, dirty or misted up.
- If cameras or vehicle components in which the cameras are fitted are damaged. In this event, have the cameras, their positions and their setting checked at a qualified specialist workshop.
- Do not use the 360° Camera under such circumstances. You could otherwise injure others or collide with objects when parking the vehicle.


For technical reasons, the standard height of the vehicle may be altered if the vehicle is carrying a heavy load and can result in inaccuracies in the guide lines and in the display of the generated images.

The field of vision and other functions of the camera system may be restricted due to additional attachments on the vehicle (e.g. licence plate bracket, bicycle rack).

- The contrast of the display may be impaired by abrupt, direct sunlight or by other light sources, e.g. when driving out of a garage. In this case, pay particular attention.
- Have the display repaired or replaced if, forexample, pixel errors considerably restrict its use.

See the notes on cleaning the 360° Camera (\rightarrow page 481).

Calling up the 360° Camera views using the button



- Press button ①.
- Select Camera views menu.
- Select the desired view in the multimedia system (→ page 265).

Selecting a view for the 360° Camera (reverse gear)

Requirements:

- The Activation in R setting is activated in the multimedia system (→ page 270).
- Engage reverse gear.
- Select the desired view in the multimedia system (→ page 265).
- Setting the reversing camera or 360° Camera Multimedia system:
- → Settings → Assistance
- Camera
- Activate or deactivate Activation in R.
- i The settings for deactivating the reversing camera are not available in every country.
- Opening the camera cover Multimedia system:
- → 🔝 ➤ Settings ➤ Assistance
- Camera
- Select Open camera cover.

The camera cover closes automatically after some time or after the vehicle is switched on or off.

Parking Assist PARKTRONIC

Function of Parking Assist PARKTRONIC

Parking Assist PARKTRONIC is an electronic parking assistance system which monitors the area surrounding your vehicle and shows you the distance between the vehicle and a detected obstacle visually and audibly.

The passive side impact protection also warns you of obstacles to the side. These must be detected beforehand by the sensors in the front or rear bumper while driving by them. If you steer in the direction of a detected obstacle and there is a risk of a lateral collision, a warning is issued. The passive side impact protection can be activated and deactivated via the multimedia system.

In order for front or rear obstacles to the side to be displayed, the vehicle must first travel a distance of at least half a vehicle length. Once the vehicle has travelled one vehicle length, obstacles on all sides can be shown.

Parking Assist PARKTRONIC is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that there are no persons, animals or objects in the manoeuvring area while manoeuvring and parking in/exiting parking spaces.

Displays in the central display



Vehicles with 360° Camera



Vehicles with reversing camera

As soon as Parking Assist PARKTRONIC is ready for display, the respective areas of the display are shown in blue.

- Front and rear display ready
- All-round display ready
- All around display ready and obstacles detected

The colour of the display changes depending on the distance to the detected obstacle:

- Blue: > 1 m (no obstacles detected)
- Yellow: approx. 1 m 0.7 m

272 Driving and parking

• Orange: approx. 0.7 m - 0.4 m

• Red: <0.4 m

Vehicles with 360° Camera: the boundary line shifts dynamically depending on the position and distance of the obstacles detected.

Depending on the distance to the obstacle detected, an intermittent warning tone also sounds. You can set the timing of the warnings in the multimedia system. In the Warn early setting, the system warns you from a distance of 1 m, in the standard setting only from 0.4 m.



Vehicles with 360° Camera



Vehicles with reversing camera

If you are not in the Camera & parking menu and an obstacle in the vehicle path is detected, popup window ① appears in the central display if the following requirements are met:

• Vehicles without Active Parking Assist: when driving no faster than 12 km/h.

Vehicles with Active Parking Assist: when driving no faster than 18 km/h.



Optionally, obstacles detected by Parking Assist PARKTRONIC from a distance of approximately 1.0 m in front 2 and 0.7 m on sides 3 can also be displayed in the head-up display.

Vehicles with active ambient lighting and Parking Package with remote parking functions

When Warning assistance is activated, the Parking Assist PARKTRONIC display is also accompanied by ambient lighting. If an obstacle is detected, the ambient lighting lights up in the same colour as the display in the central display.

The ambient lighting which accompanies the Parking Assist PARKTRONIC display is only intended to accentuate the display in the central display and does not replace it.

More information on ambient lighting: $(\rightarrow page 160)$

- (i) A display message for the ambient lighting does not occur in the area of the driver's display or in the rear compartment.
- Depending on the selected setting, other functions may supersede the ambient lighting effects of Parking Assist PARKTRONIC. In this case, the ambient lighting effects of Parking Assist PARKTRONIC do not occur.

System limits

Parking Assist PARKTRONIC does not necessarily take into account the following obstacles:

- · Obstacles below the detection range, e.g. persons, animals or objects.
- Obstacles above the detection range, e.g. overhanging loads, overhangs or loading ramps of lorries.

- Pedestrians or animals approaching the vehicle from the side.
- Objects placed next to the vehicle

Obstacles on the sides are not shown in the following situations, for example:

- You park the vehicle and switch it off.
- You open the doors.

After the engine is restarted, obstacles must be detected again by driving past them before a new warning can be issued.

Also observe the system limits of the following systems:

- Reversing camera (→ page 263)
- 360° Camera (→ page 265)

Observe the information on vehicle sensors and cameras; otherwise, the system cannot function properly (\rightarrow page 215).

Vehicles with towbar: If a transport device, e.g. trailer or bicycle carrier, is attached to the towbar and the electrical connection is correctly established, Parking Assist PARKTRONIC is deactivated for the rear zone.

Problems with Parking Assist PARKTRONIC

If the Parking Assist PARKTRONIC display lights up red for approximately three seconds then goes out, and the profit symbol appears in the driver's display, the system may have been deactivated due to signal interference. Start the vehicle again and check if Parking Assist PARKTRONIC is working at a different location.

If a warning tone also sounds, it may be due to one of the following causes:

- The sensors are dirty: clean the sensors and observe the notes on care of vehicle parts (→ page 481).
- Parking Assist PARKTRONIC has been deactivated due to a malfunction: restart the vehicle. If the problem persists, consult a qualified specialist workshop.

Activating/deactivating Parking Assist PARKTRONIC

! NOTE Risk of an accident from objects at close range

Parking Assist PARKTRONIC may not detect certain objects at close range.

When parking or manoeuvring the vehicle, pay particular attention to any objects which are above or below the sensors, e.g. flowerpots or drawbars. The vehicle or other objects could otherwise be damaged.

Requirements:

- The camera menu is open.
- Or: Active Parking Assist is active.
- Or: the PARKTRONIC pop-up window appears.
- Press Pm in the central display.

If the indicator lamp is lit, Parking Assist PARKTRONIC is active. If the indicator lamp does not light up or the symbol pri is displayed, PARKTRONIC Parking Assist is not active.

(i) Parking Assist PARKTRONIC is automatically activated when the vehicle is started.

Alternatively, Parking Assist PARKTRONIC can be activated or deactivated in the quick access menu.

Setting the warning tones of Parking Assist PARKTRONIC

Multimedia system:

Adjusting warning tones

- Select Set warning tones.
- Set the desired level under Volume or Tone pitch.

Activating/deactivating audio fadeout

 Audio fadeout select and Audio fade for warnings switch on or off.
 The volume of the currently playing media source is reduced during a Parking Assist PARKTRONIC warning tone.

or

Audio fadeout select and Audio fadeout in trans. position R switch on or off. The volume of the currently playing media source is reduced when reverse gear is engaged.

Setting the time of the warnings

- Select Time of warning
- Activate or deactivate Side warning.
- Set the desired warning time for Front or Rear.

Active Parking Assist

■ Function of Active Parking Assist

Active Parking Assist is an electronic parking assistance system, which uses ultrasound with the assistance of the reversing camera and 360° Camera. When you are driving forwards up to approximately 35 km/h, the system automatically measures parking spaces on both sides of the vehicle.

Active Parking Assist offers the following functions:

Vehicles with reversing camera

- Parking in parking spaces parallel to the road
- Reversing into parking spaces perpendicular to the road

Vehicles with 360° Camera

- Parking in parking spaces parallel to the road
- Parking in parking spaces perpendicular to the road (optionally either forwards or reverse)
- Parking in parking spaces that can only be detected as such due to markings (forexample at the roadside)
- Exiting a parking space parallel to the road
- Exiting a parking space perpendicular to the road (optionally either left or right)

Active Parking Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.

If Active Parking Assist is available, the message appears in the driver's display. When the

system detects parking spaces, (P) appears. The arrows show on which side of the road free parking spaces are located. These are then shown in the central display.

When Active Parking Assist is activated, the turn signal indicators are activated based on the calculated path of your vehicle. When you are entering or exiting a parking space, the procedure is assisted by acceleration, braking, steering and gear changes.

To start the parking procedure, press the [Page 1] button (\rightarrow page 277).

Active Parking Assist will be cancelled in the following situations:

- You deactivate Parking Assist PARKTRONIC.
- You press the button again.
- You begin steering.
- You engage park position P.
- FSP® intervenes.
- You open the driver's door.

System limits

If the exterior lighting is malfunctioning, Active Parking Assist is not available.

Also observe the system limits of the following systems:

- Reversing camera (→ page 263)
- 360° Camera (→ page 265)

Objects that are above or below the detection range of Active Parking Assist, e.g. protruding loads, overhangs or loading ramps of trucks or boundaries of parking spaces, are not detected when measuring the parking space. These are also then not taken into account when calculating the parking procedure. In some circumstances, Active Parking Assist may therefore guide you into the parking space prematurely or brake too late.

Certain environmental conditions, suchas snowfall or heavy rain, may lead to a parking space being measured inaccurately. Parking spaces that are partially occupied by trailer drawbars might not be identified as such or be measured incorrectly. Only use Active Parking Assist on level, high-grip ground.

A

WARNING Risk of accident due to objects located above or below the detection range of Active Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Active Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

There is a danger of collision!

In these situations, do not use Active Parking Assist.

Active Parking Assist can also display unsuitable parking spaces, e.g. parking spaces in which parking is not permitted or parking spaces on unsuitable surfaces.

Do not use Active Parking Assist in the following situations:

- In extreme weather conditions such as ice, packed snow or in heavy rain.
- When transporting a load that protrudes beyond the vehicle.

- If the parking space is on a steep downhill or uphill gradient.
 - When snow chains are fitted.
- When a trailer or bicycle rack is attached.
- Directly after a tyre change or when spare tyres are fitted.
- If the tyre pressure is too low or too high.
- If the suspension is out of alignment, e.g. after bottoming out on a kerb.
- On steep inclines of more than approximately 15 %.

You can watch an animation on this topic via the following link:

Parking with Active Parking Assist


WARNING Risk of accident due to objects located above or below the detection range of Active Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Active Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

There is a danger of collision!

In these situations, do not use Active Parking Assist.



Press ① button.



Select Parking Assistance menu.

Parking spaces 3 detected by the system are shown in the central display.



When the vehicle is stationary, indicated vehicle path (a) into currently selected parking space (s) also appears.

- If a parking space is displayed: stop the vehicle.
- If necessary, select another parking space.

- Vehicles with 360° Camera: to change the parking direction, tap the selected parking space again.
- To start the parking procedure: press button again.

The vehicle drives into the selected parking space.

The turn signal indicator is switched on automatically when the parking procedure begins. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions. If necessary, select the turn signal indicator accordingly.

▲ WARNING Risk of accident due to vehicle swinging out while parking or pulling out of a parking space

While parking or exiting a parking space, the vehicle swings out and can drive onto areas of the oncoming lane.

This could cause you to collide with objects or other road users.

Pay attention to objects and other road users.

Where necessary, stop the vehicle or cancel the parking procedure with Active Parking Assist.

On completion of the parking procedure, the Active Parking Assist finished display message appears.

- Secure the vehicle against rolling away. When required by legal requirements or local conditions: turn the wheels towards the kerb.
- (i) You can stop the vehicle and change the transmission position during the parking procedure. The system then calculates a new vehicle path. If no new vehicle path is available, the transmission position can be changed again, or the process can be cancelled.

Immediate parking via the Camera views menu



- Select the Camera views menu.
- When the vehicle is stationary and in transmission position **R**, and symbol **6** appears in the camera image: press button (1) again. The parking procedure is initiated for the detected parking space.
- The parking space and parking direction cannot be changed in immediate parking.

Exiting a parking space with Active Parking Assist

WARNING Risk of accident due to objects located above or below the detection range of Active Parking Assist

If there are objects above or below the detection range, the following situations may arise:


- Active Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

There is a danger of collision!

In these situations, do not use Active Parking Assist.

Requirements

- The vehicle is equipped with a 360° Camera.
- The vehicle has been parked with Active Parking Assist.
- Start the vehicle.



Press button 1.



- Select Parking Assistance 2 menu.
- If necessary, change direction of exit 3.
- To start exiting the parking space: press button (1) again.
- If necessary, change the gearbox setting. Observe any messages displayed in the driver's display and central display. The vehicle moves out of the parking space.

The turn signal indicator is automatically switched on when exiting a parking space begins and switched off when it is completed. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions. If necessary, select the turn signal indicator accordingly.

WARNING Risk of accident due to vehicle swinging out while parking or pulling out of a parking space

While parking or exiting a parking space, the vehicle swings out and can drive onto areas of the oncoming lane.

This could cause you to collide with objects or other road users.

- Pay attention to objects and other road users.
- Where necessary, stop the vehicle or cancel the parking procedure with Active Parking Assist.

After the parking space has been exited, a warning tone and the Active Parking Assist finished, take control of vehicle message prompt

vou to take control of the vehicle. You have to accelerate, brake, steer and change gear yourself again.

If you do not react to the prompt to take control of the vehicle, the system will brake the vehicle to a standstill.

Pausing Active Parking Assist

WARNING Risk of accident due to objects located above or below the detection range of Active Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Active Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

There is a danger of collision!

In these situations, do not use Active Parking Assist.

You can interrupt the parking or exiting procedure of Active Parking Assist by performing one of the following actions, forexample:

- Depress the brake pedal.
- Open the front passenger door, a rear door, the boot or the bonnet.
- Apply the electric parking brake or activating the HOLD function.
- To resume the parking or exiting procedure: gently depress the accelerator pedal.
- (i) If the electric parking brake was applied before Active Parking Assist was activated, depress the accelerator pedal lightly to start the parking or exiting procedure.

Check the area around your vehicle again before resuming a paused parking procedure. Make sure that persons, animals or objects are no longer in the manoeuvring range. Also observe the system limitations of Active Parking Assist.

Automatic braking function of Active Parking Assist

WARNING Risk of accident due to objects located above or below the detection range of Active Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Active Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

There is a danger of collision!

In these situations, do not use Active Parking Assist.

Persons or objects detected in the manoeuvring range could cause the vehicle to brake sharply and interrupt the parking or exiting procedure. The vehicle will then be held at a standstill. If you depress the accelerator pedal, the parking or exiting procedure is resumed.

Check the area around your vehicle again before resuming the parking or exiting procedure. Make sure that persons, animals or objects are no longer in the manoeuvring range. Also observe the system limitations of Active Parking Assist.

Remote Parking Assist

Function of Remote Parking Assist

Remote Parking Assist is an additional function of Active Parking Assist. Comply with local traffic laws and regulations when using Remote Parking Assist on public roads. If it is required to turn the wheels toward the kerb, you cannot use Remote Parking Assist. Please note that you can only use Remote Parking Assist if you have a valid driving licence and are in a fit state to drive.

Remote Parking Assist parks your vehicle or exits the parking space while you are outside of your vehicle. You can monitor the manoeuvring and parking procedure on your mobile phone.

With Remote Parking Assist, you can carry out all the parking procedures of Active Parking Assist. You can also position the vehicle directly in front of a garage or a driveway entrance and then use

Remote Parking Assist to enter or exit a parking space.

Remote Parking Assist manages pulling away, braking and steering. While Remote Parking Assist is active, the vehicle is locked.

Remote Parking Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Interrupt or terminate the parking procedure if necessary. Make sure that no persons, animals or objects etc. are in the manoeuvring range. Make sure to also pay attention to other vehicles.

System limits

If the system detects a malfunction or a system limit during the manoeuvring or parking procedure, the procedure will be cancelled:

- · The vehicle is brought to a standstill.
- Transmission position P is selected and the electric parking brake is applied automatically.
- · The vehicle is switched off.
- · The vehicle remains locked.

If the parking manoeuvre is cancelled, a corresponding message is displayed on the mobile phone.

Depending on the situation, you can then take control of the procedure, manoeuvre the vehicle back to the starting position or manually take control of the vehicle.

The system limits of Active Parking Assist apply $(\rightarrow page 275)$.

Certain environmental conditions, suchas snowfall or heavy rain, may lead to a parking space being measured inaccurately or to connection problems with the mobile phone. Only use Remote Parking Assist on level, high-grip ground.

During the parking procedure, you should not stand more than approx. 3.0 m away from the vehicle. At greater distances, the procedure will be interrupted and a corresponding message will be displayed on the mobile phone. If you move closer to the vehicle, you will be able to continue the procedure.

You can watch an animation on this topic via the following link:

Operating Remote Parking Assist


Requirements

For the Remote Park Assist function you need:

- a Mercedes me user account
- the current Remote Park Assist app for your vehicle type
- · a mobile phone
- (i) A list of compatible phones can be found at: https://www.mercedes-benz-mobile.com/

The following operating systems are supported:

- Android[™]
- Apple[®] iOS



If there are objects above or below the detection range, the following situations may arise:

- Active Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

There is a danger of collision!

In these situations, do not use Active Parking Assist.

Objects located above the detection range of Active Parking Assist will not be detected when the parking space is measured. These are not taken into account when the parking procedure is calculated, e.g. overhanging loads, overhangs or loading ramps of goods vehicles. In some circumstances, Active Parking Assist may therefore guide you into the parking space prematurely.

WARNING Danger due to insufficient view of the vehicle surroundings

If you manoeuvre, park or exit a parking space with the vehicle using Remote Parking Assist, observe the following:

- Make sure that you have the best view possible of the vehicle and the vehicle's surroundings.
- Make sure that no persons, animals or objects are in the path of your vehicle.


- Make sure that you maintain a suitable distance to the vehicle and that neither you nor other road users could be endangered.
- Be aware of the vehicle's surroundings at all times and identify possible dangers.
- If necessary, cancel the parking procedure.

No persons or pets are permitted to remain in the vehicle during the parking procedure. Observe the system limits at all times. If necessary, cancel the parking procedure. Always ensure that vehicle access by other road users is maintained.

- Activate the "Remote Parking Assist" service e.g. via the Mercedes me homepage.
- Authorise the mobile phone using the Remote Parking Assist App in the vehicle $(\rightarrow page 285)$.

Selecting the parking manoeuvre in advance while inside the vehicle

Stop the vehicle and select transmission position P.



Press button 1.



- Select Parking Assistance menu.
- For further information on Remote Parking Assist: select 3.
- If necessary, select another parking space 4 or select (5) to drive straight ahead into a garage, forexample.
- lf necessary, change parking direction 🜀.

- Alternatively, you can begin parking with Active Parking Assist (→ page 277) and continue with the Remote Parking Assist from any vehicle position. To do this, stop the parking process and adjust the gearbox setting **P**.
- Switch off the vehicle and exit it with the key.

Starting the parking procedure without selecting in advance

- Stop the vehicle and select transmission position **P**.
- Switch off the vehicle and exit it with the key.

Starting the parking procedure while outside the vehicle

Unlock the vehicle.

Carrying out a parking procedure with Remote Parking Assist

- Keep the vehicle key with you during the parking procedure. You can cancel the parking procedure and bring the vehicle to a standstill by pressing a button on the key.
- On completion of the parking procedure, the vehicle is locked.

If you have started the parking procedure as described above, the vehicle is ready to connect to your mobile phone for a limited time.

- Start the Remote Parking Assist App on the mobile phone and connect to the vehicle.
- Follow the instructions of the Remote Parking Assist App.
- The turn signal indicator is automatically switched on when starting parking and switched off when it is completed.
- If the connection between the vehicle and the mobile phone is interrupted while a parking manoeuvre is being performed, the manoeuvre can be continued if the connection is reestablished within a short time.
- WARNING Risk of accident due to vehicle swinging out while parking or pulling out of a parking space

While parking or pulling out of a parking space, the vehicle swings out and can drive onto areas of the oncoming lane.

This could cause you to collide with objects or other road users.

- Pay attention to objects and other road users.
- Where necessary, stop the vehicle or cancel the parking procedure with Remote Parking Assist.
- After ending the parking procedure, ensure that all vehicle doors, windows and the boot are closed. Secure the vehicle against rolling away.

Cancelling the parking procedure

You can cancel the parking procedure of Remote Parking Assist at any time and bring the vehicle to a standstill.

Cancel the parking procedure in the Remote Parking Assist App.

Or

Press a button on the vehicle key.

Pull a door handle.

Authorising/de-authorising a mobile phone for Remote Parking Assist

Multimedia system:

→ Settings → Assistance Parking

Authorising a new mobile phone

In order to be able to use the Remote Parking Assist function, you must authorise your mobile phone. You can authorise up to ten mobile phones.

- Select Remote Parking Assist.
- Select Authorise a new device. Remote Parking Assist is ready to connect.
- Start the Remote Parking Assist App and additionally start the authorisation process. A connection prompt is displayed.
- Scan the QR code on the central display. The mobile phone is authorised.

De-authorising mobile phones

- Select Remote Parking Assist.
- Select Deauthorise devices.

- To de-authorise a mobile phone: select a mobile phone.
- The mobile phone is deleted from the device list.
- To de-authorise all mobile phones: selectDeauthorise all devices. All mobile phones are deleted from the device list.

Manoeuvring assistant

■ Function of Drive Away Assist

Drive Away Assist can reduce the severity of an impact when pulling away. If the system detects an obstacle in the direction of travel, the vehicle's speed is briefly reduced to approximately 2 km/h.

A risk of collision may occur in the following situations, forexample:

- If the driver mixes up the accelerator and brake pedals.
- If the driver engages an incorrect gear.
- If the driver depresses the accelerator pedal with too much force.

Drive Away Assist is active under the following conditions:

- If the vehicle was stationary and the transmission position was changed to R or D.
- If the vehicle has rolled less than approximately 1.0 m since being at a standstill.
- If the detected obstacle is less than approx. 1.0 m away.

The Drive-away Assist can be deactivated or activated in the Manoeuvring assistance menu (→ page 288).

If a critical situation is detected, the _____ symbol appears in red in the selected view in the Camera & parkingmenu.

(i) If Drive Away Assist is not available, the same symbol appears in grey. If the Camera & parking menu is not opened in the central display, the symbol and pop-up of Parking Assist PARKTRONIC both appear.

Drive Away Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, ani-

mals or objects etc. are in the manoeuvring range.



WARNING Risk of accident caused by limited detection performance of Drive Away Assist

Drive Away Assist cannot always clearly identify objects and traffic situations.

- Always pay careful attention to the traffic situation; do not rely on Drive Away Assist alone.
- Be prepared to brake or swerve as necessary, provided the traffic situation permits and that it is safe to take evasive action.

System limits

The system limits of Active Parking Assist apply $(\rightarrow page 275)$.

On uphill gradients, the performance of Drive Away Assist is restricted.

If a transport device, e.g. trailer or bicycle carrier, is attached to the hitch and the electrical connec-

tion is correctly established, the drive-away assistance is not available when reversing.

Function of cross traffic warning

The cross traffic warning can warn you of crossing traffic when you are exiting a parking space. The radar sensors in the bumper also monitor the area adjacent to the vehicle.

The cross traffic warning is active under the following conditions:

- Warning for crossing traffic behind: the vehicle is driving in reverse at a speed slower than approx. 10 km/h.
- Warning for crossing traffic ahead: the vehicle is driving forwards at a speed slower than approx. 10 km/h and the camera image is shown in the central display (→ page 270).

The Warning for crossing traffic ahead can be deactivated or activated in the Manoeuvring assistance menu.

Depending on the country, the Warning for crossing traffic behind can also be deactivated or activated (\rightarrow page 288).

If a critical situation is detected, the 🛕 symbol appears in red in the selected view in the Camera & parkingmenu.

Warning for crossing traffic behind

- The vehicle can be braked automatically when crossing traffic is detected.
- If the Camera & parking menu is not opened and a critical situation is detected, a warning appears in the central display together with the PARKTRONIC Parking Assist pop-up.

Warning for crossing traffic ahead

- If Active Parking Assist is active, the vehicle can be braked automatically when crossing traffic is detected.
- If Active Parking Assist is not active but the Camera & parking menu is opened, a warning appears.
- If the Camera & parking menu is not opened, the system cannot react to crossing traffic.

The cross traffic warning is only an aid and not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.



WARNING Risk of accident caused by limited detection performance of the cross traffic warning

The cross traffic warning cannot always clearly identify objects and traffic situations.

- Always pay careful attention to the traffic situation; do not rely on the cross traffic warning alone.
- Be prepared to brake or swerve as necessary, provided the traffic situation permits and that it is safe to take evasive action.

System limits

(i) If the cross traffic warning is not available, the symbol appears in grey.

The system limits of Active Parking Assist apply $(\rightarrow page 275)$.

If the radar sensors are obstructed by vehicles or other objects, detection is not possible.

In the following situations, the cross traffic warning is not available:

- on inclines
- Warning for crossing traffic behind: if a transport device, e.g. trailer or bicycle carrier, is attached to the hitch and the electrical connection is correctly established.

Manoeuvring brake function

The manoeuvring brake function can prevent collisions with pedestrians when the vehicle is reversing at slow speeds. If the reversing camera detects a person in the vehicle path, the vehicle can be braked to a standstill.

The manoeuvring brake function can intervene under the following conditions:

- The vehicle is reversing at a speed slower than 10 km/h.
- The camera image is shown in the central display (\rightarrow page 270).

If the manoeuvring brake function is triggered, the symbol appears in red in the selected view in the menuCamera & parking.

(i) If the manoeuvring brake function is not available, the same symbol appears in grey.

The manoeuvring brake function is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.



WARNING Risk of accident caused by limited detection by the manoeuvring brake function

The manoeuvring brake function cannot always clearly detect people. Other obstacles are not detected by the function.

In these cases, the function may brake unnecessarily or not brake at all.

- Always pay careful attention to the traffic situation; do not rely on the manoeuvring brake function alone.
- Be ready to brake.

System limits

Observe the system limits of the following functions:

- Active Parking Assist (→ page 275)
- 360° Camera (→ page 265)

The manoeuvring brake function is not available in the following situations:

- on inclines
- If transport equipment, forexample a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection has been correctly established.

Activating/deactivating manoeuvring assistance

Multimedia system:

- → Settings → Assistance Parking
- This function is an on-demand feature $(\rightarrow page 25).$
- Select Manoeuvring assistance.

Activate or deactivate the desired manoeuvring assistance.

Memory Parking Assist

Function of Memory Parking Assist

Memory Parking Assist can park your vehicle using a previously stored parking space. You can store parking procedures with a total distance of up to 500 m (100 m per parking or exiting procedure).

During parking or exiting, the system can travel a previously stored path of up to approximately 100 m to or out of the desired parking space, for example, from the driveway entrance into the garage.

Within a radius of approx. 150 m, only one parking or exiting procedure can be recorded.

Only use Memory Parking Assist on private property. Use on public roads, e. g. in public parking spaces, is not permitted.

Memory Parking Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that no persons, animals or objects etc. are in the manoeuvring range.

System limits

Observe the system limitations of Active Parking Assist (\rightarrow page 275).



WARNING Risk of accident due to objects located above or below the detection range of Memory Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Memory Parking Assist may steer too early.
- The vehicle may not stop in front of these objects.

This result in a collision

In these situations, do not use Memory Parking Assist.

Objects located above or below the detection range of Memory Parking Assist may not be detected during the parking procedure.

Drawbars of parked trailers, among other objects, that protrude into the parking space may not be detected.

Do not use Memory Parking Assist in the following situations, for example:

- In extreme weather conditions such as ice. packed snow or in heavy rain.
- When transporting a load that protrudes beyond the vehicle.
- If the parking space is on a steep downhill or uphill gradient.
- · When snow chains are fitted.


You can watch an animation on this topic via the following link:

Recording a parking procedure using Memory Parking Assist

Requirements

- The entire route is, forexample, within your own property and not on public roads.
- The system needs reference points in the surroundings to orient itself, suchas fences, walls or trees. Therefore, after starting the vehicle, a

certain distance must first be driven. If not enough reference points are detected in the surrounding area, no new route can be recorded.



Press button 1. The Camera & parking view opens in the central display.




- Select Memory Parking Assist menu.
- Brake the vehicle to a standstill at the desired starting point of the assisted parking procedure, e.g. a driveway entrance.
- Start recording: Tap 3.
- If not all conditions for a recording are met, symbol (3) is greyed out.

- Park the vehicle in the desired parking space. Do not exceed 8 km/h.
- **End recording:** Stop the vehicle and tap (3) again. The recording is stored.
- In the Memory Parking Assist settings you can delete and rename stored parking procedures.
- Parking with Memory Parking Assist

Requirements:

A parking procedure has been recorded.



Press button 1. The Camera & parking view opens in the central display.




- Select Memory Parking Assist 2 menu.
- Brake the vehicle to a standstill at the starting point of the stored parking procedure.
- To start the parking procedure: press .
- Select the stored parking procedure from the list.

- Follow the instructions on the central display. The vehicle drives into the selected parking space.
- The turn signal indicator is not switched on automatically. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions.
- After completion of the parking procedure, safeguard the vehicle against rolling away.
- Exiting a parking space with Memory Parking Assist

Requirements:

- The exiting procedure was recorded together with the respective parking procedure and stored separately within one driving cycle.
- The vehicle was parked using Memory Parking Assist.



Press button 1. The Camera & parking view opens in the central display.



Select Memory Parking Assist 2 menu.

Starting the exiting procedure

- Press D.
- Confirm the saved exiting procedure.
- Follow the instructions on the central display. The vehicle drives the recorded route.

- The turn signal indicator is not switched on automatically. You are responsible for selecting the turn signal indicator in accordance with the traffic conditions.
- Take control of the vehicle after the exiting procedure has been completed.

Setting Memory Parking Assist Multimedia system:

→ Settings → Assistance

▶ Parking ▶ Memory Parking Assist

Renaming a recording

- Select Manage lanes.
- Select next to the desired recording.
- Enter a name and confirm with OK.

Deleting a recording

- Select Manage lanes.
- Select next to the desired recording.
- Select Delete entry.

Deleting all recordings

Select Manage lanes.

- button next to one of the desired recordings.
- Select Delete all.
- Alternatively, you can delete all data in Memory Parking Assist by resetting the multimedia system (\rightarrow page 362).

Trailer Manoeuvring Assist

Function of Trailer Manoeuvring Assist

This function is an on-demand feature $(\rightarrow page 25).$



WARNING Risk of accident due to unsuitable trailers

Trailers with a steered axle or a fifth wheel cannot be used with Trailer Manoeuvring Assist.

Due to this, the trailer cannot be manoeuvred in the desired direction and you can cause a collision or the trailer can overturn.

Only use Trailer Manoeuvring Assist with trailers with fixed drawbars and axles.

NOTE Damage due to overhanging loads in front or drawbar installations

The vehicle and the trailer may be damaged during manoeuvring due to overhanging loads at the front of the trailer or drawbar installations.

Pay attention to overhanging loads or drawbar installations while manoeuvring.

Trailer Manoeuvring Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe manoeuvring and parking remains with you. Make sure that there are no persons, animals or objects in the manoeuvring area while manoeuvring and parking in/exiting parking spaces.

Observe the notes on towing a trailer $(\rightarrow page 294)$.

System limits

Observe the system limits of the following functions:

- Active Parking Assist (→ page 275)
- 360° Camera (\rightarrow page 265)

Reversing camera (→ page 263)


The system may be impaired or may not function in the following situations:

- The gradient is greater than approximately 15 %.
- Using Trailer Manoeuvring Assist

Requirements


- The vehicle has been started and is stationary.
- A trailer has been detected.
- The gradient is less than approximately 15 %.
- The boot lid is closed.
- The electric parking brake is not applied.
- The driver's seat belt is fastened.

Using Trailer Manoeuvring Assist



- Engage reverse **R** gear.
- Press button 1.

The camera image is shown in the central display.



(i) The picture is exemplary and shown without trailer.

You can select various manoeuvres in the Trailer Manoeuvring Assist menu. The manoeuvres available depend on the current articulation angle and length of the trailer.

To adjust the articulation angle: select 3. In the central display, swipe the entire area of the camera image to the left or right to change the bend angle.

To activate the straightening manoeuvre: select 1

The system calculates the articulation angle in such a way that the direction of the trailer at the time of activation is maintained. There is a short countersteering movement of the trailer while the vehicle is reversed, which then guides it back to the desired line. In this way, the vehicle is aligned straight with the trailer and, at the same time, the direction of the trailer is maintained.

or

- To activate the 90° manoeuvre:
 - · Align the vehicle in the same direction (line) as the trailer.
 - Select (left or right) ②.

The system calculates the articulation angle so that the trailer can be manoeuvred into a space perpendicular to the vehicle using the smallest possible angle. After the manoeuvre, the vehicle is aligned again in the direction of the trailer.

Accelerate and brake as required.

- The maximum articulation angle depends on the length of the trailer. This is calculated by the system by driving the vehicle forwards, including cornering. Before the length of the trailer has been calculated, the maximum articulation angle is approximately 23°. The longer the trailer is, the higher the maximum articulation angle (max. approximately 60°).
- Pay attention to your surroundings and be ready to brake at all times.

Trailer hitch

Notes on trailer operation

NOTE The operating permit may be invalidated due to the illegal installation of trailer hitches

The installation – including retrofitting – of a non-folding or non-removable trailer hitch that even partially conceals the license plate or the lighting system is prohibited.

Observe the applicable legal regulations for the installation of trailer hitches.

WARNING Risk of accident due to car/ trailer combination swerving

If you drive too fast in trailer operation, the car/trailer combination may start to swerve.

This could cause you to lose control of the car/trailer combination. The car/trailer combination may even overturn.

- ► Under no circumstances should you try to straighten the car/trailer combination by increasing your speed.
- Reduce the speed and do not countersteer.
- Brake if necessary.
- **NOTE** Damage to the engine due to overheating
- If you have a trailer hitch retrofitted, modifications to the engine cooling system may be necessary depending on the vehicle type.

If you have a trailer tow hitch retrofitted, observe the fastening points on the vehicle frame.

Retrofitting a trailer hitch is permissible only if a trailer load is specified in your vehicle documents. If this is not the case, the vehicle is not approved for trailer operation.

Further information can be obtained at a qualified specialist workshop.

Observe the following notes on the tongue weight:

- Do not use a tongue weight that exceeds or falls below the permissible tongue weight
- Use a tongue weight as close as possible to the maximum tongue weight

Do not exceed the following values:

- Permissible towing capacity
- Permissible rear axle load of the towing vehicle
- Permissible gross weight of the towing vehicle
- Permissible gross weight of the trailer
- Maximum permissible speed of the trailer

Ensure the following before starting a journey:

- The tyre pressure on the rear axle of the towing vehicle is set for a maximum load
- The lighting of the connected trailer is operational

In the event of increased rear axle load, the car/ trailer combination must not exceed a maximum speed of 100 km/h for reasons concerning the operating permit. This also applies in countries in which the permissible maximum speed for car/ trailer combinations is above 100 km/h.

(i) When you are reversing with a trailer, remember to use the Trailer Manoeuvring Assist function (\rightarrow page 292).

Extending and retracting the ball neck fully electrically



WARNING Risk of accident due to the ball neck not being engaged

If the ball neck is not engaged, the trailer may come loose.

- Make sure that the ball neck securely engages and locks into place.
- ! NOTE Damage to the all-electric trailer hitch due to additional pressure

The all-electric trailer hitch could be mechanically damaged by applying additional pressure when the ball neck is being extended or retracted.


- Do not make the ball neck extend/ retract faster by applying additional pressure.
- ! NOTE Increased risk of damage to property due to folded-out ball neck
- When the trailer is not coupled or the bicycle rack is attached, fold in the ball neck or, in the case of a fully electric trailer hitch, retract the ball neck.

NOTE Damage to the vehicle due to incorrect use of the trailer hitch

If a trailer hitch is used to recover the vehicle, the vehicle or the trailer hitch itself may be damaged in the process.

- Use the trailer hitch only for pulling a trailer or attaching approved carrier systems (e.g. a bicycle rack).
 Exception: Since vehicles with a trailer hitch do not have a fixture for a towing eye at the rear, towing or tow-starting is permitted.
- When towing or tow-starting with the trailer hitch, observe the information in the section "Fitting and removing the towing eye."

Extending the ball neck fully electrically



- Secure the vehicle against rolling away.
- Keep the swivel range clear.
- Pull button ②. Indicator lamp ③ will flash and a message reading Trailer coupling in motionwill appear on the driver's display.

The ball neck will extend fully electrically.

Wait until the ball neck has reached the swung-out position with a clear locking noise. When indicator lamp (1) is continuously lit, the ball neck is securely locked in place. If the ball neck is not securely locked in place, indicator lamp (1) will flash and a message reading Trailer coupling Check lockwill appear on the driver's display.



Retracting the ball neck fully electrically

on the driver's display.

- Remove the trailer cable or adapter plug.
- Pull button 2. Indicator lamp (1) will flash and a message reading Trailer coupling in motionwill appear

The ball neck will retract fully electrically.

Wait until the ball neck has reached the swung-in locked position. When indicator lamp (1) goes out, the ball neck is securely locked in place. If the ball neck is not securely locked in place, indicator lamp (1) will flash and a message reading Trailer coupling Check lockwill appear on the driver's display.

Observe the information about the displays on the driver's display:

- Indicator and warning lamps (→ page 729)
- Display messages (→ page 644)

Coupling up/uncoupling a trailer

WARNING Risk of injury due to a change in vehicle level

Vehicles with AIRMATIC: the vehicle level may be changed unintentionally, e.g. by other persons. If you couple or uncouple the trailer during this time, you may become trapped. In addition, other people could become trapped if their limbs are between the vehicle body and the tyres or underneath the vehicle.

Observe the following when coupling or uncoupling:

- Do not open or close any doors or the boot lid.
- Do not initiate the level control system and do not operate the DYNAMIC SELECT switch.
- Do not lock or unlock the vehicle.

The trailer will be correctly detected by the vehicle only if the following conditions are met:

. The ball neck is extended and engaged in a securely locked position.

298 Driving and parking

- Vehicles with AIRMATIC: ensure the vehicle is at the normal level (→ page 262).
 Use the normal level in trailer operation. Offroad-level driving is not permitted in trailer operation on public roads.
- A trailer is selected in the Vehicle menu (→ page 300).

Trailers with a 7-pin plug can be connected to the vehicle with the following adapters:

- Adapter plug
- Adapter cable

The trailer will be correctly detected by the vehicle only if the following conditions are met:

- The trailer is connected correctly.
- The trailer lighting system is in working order.

A correctly connected trailer influences, among other things, the functions of the following systems:

- ESP[®] trailer stabilisation
- Trailer Manoeuvring Assist
- Active Lane Keeping Assist

- Parking Assist PARKTRONIC
- Active Parking Assist
- Blind Spot Assist or Active Blind Spot Assist
- Drive Away Assist
- Cross traffic warning
- Manoeuvring brake function
- · Reversing camera
- 360° camera
- AIRMATIC

Coupling up a trailer

! NOTE Damage to the starter battery due to full discharge

Charging the trailer battery using the power supply of the trailer can damage the starter battery.

- Do not use the vehicle's power supply to charge the trailer battery.
- Secure the vehicle against rolling away.

- Remove the cover cap from the ball head and store it in a safe place.
- Position the trailer on a level surface behind the vehicle and couple it up to the vehicle.



- Open the socket cap.
- Insert the plug with lug into groove on the socket.
- Turn bayonet coupling ② to the right as far as it will go.
- Let the cap engage.
- Secure the cable to the trailer with cable ties (only if you are using an adapter cable).

Make sure that the cable is always slack for ease of movement during cornering.

In the following circumstances, a message may appear on the driver's display even if the trailer has been connected correctly:

- LEDs have been installed in the trailer lighting system.
- The current has fallen below the trailer lighting system's minimum current (50 mA).
- Accessories can be connected to the permanent power supply up to 180 W and to the power supply that is switched on via the ignition lock.

Uncoupling a trailer

WARNING Risk of being crushed and becoming trapped when uncoupling a trailer

When uncoupling a trailer with an engaged inertia-activated brake, your hand may become trapped between the vehicle and the trailer drawbar.

- Do not uncouple trailers with an engaged overrun brake.
- **NOTE** Damage during uncoupling with an engaged overrun brake

The vehicle may be damaged if you uncouple with an engaged overrun brake.

Do not uncouple trailers with an engaged overrun brake.

WARNING Risk of becoming trapped when disconnecting the trailer cable

Vehicles with AIRMATIC: the vehicle may lower when you disconnect the trailer cable.

This could result in other people becoming trapped if their limbs are between the vehicle body and the tyres or underneath the vehicle.

Make sure nobody is underneath the vehicle or in the immediate vicinity of the wheel arches when you disconnect the trailer cable.

NOTE Damage to the rear bumper from installing adapter cables or adapter plugs

The following parts could be damaged when swiveling the ball neck fully electrically:

- Bumper
- Adapter cable
- Adapter plug
- Always remove the adapter cable or adapter plug before swiveling the ball neck fully electrically.
- Secure the trailer against rolling away.
- Disconnect the electrical connection between the vehicle and the trailer.
- Uncouple the trailer.
- Place the cover cap on the ball head.
- Trailers with LED lighting: after uncoupling the trailer, switch the vehicle on and then off again.

Adjusting settings for trailer operation

Multimedia system:

→ 🚡 >> Settings >> Vehicle >> Driving >> Trailer settings

Making settings for a trailer

The settings in this menu enable the calculation of a route suitable for the selected trailer and optimise the calculated arrival time.

- Select the desired trailer type.
- Enter the maximum permissible speed of the selected trailer.
- To save changes: select Confirm.

Bicycle rack function

WARNING Risk of an accident if the bicycle rack is used incorrectly

The bicycle rack may become detached from the vehicle in the following cases:

- the permissible load capacity of the trailer hitch is exceeded.
- the bicycle rack is used incorrectly.
- the bicycle rack is secured to the ball neck beneath the ball head.

Observe the following for your own safety and that of other road users:


- always adhere to the permissible load capacity of the trailer hitch.
- always observe the permissible rear axle load of the towing vehicle.
- use the bicycle rack only to transport bicycles.

- always mount the bicycle rack properly by attaching to the ball head and the ball neck guide pin, if possible.
- when transporting four bicycles, always use bicycle racks that have additional support on the ball neck guide pin.
- use only bicycle racks approved by Mercedes-Benz.
- always observe the bicycle rack operating instructions.
- **NOTE** Damage to or breakage of the trailer hitch due to unsuitable or improperly used bicycle rack.
- Only use bicycle racks approved by Mercedes-Benz properly as described below.
- NOTE Increased risk of damage to property due to folded-out ball neck
- ▶ When the trailer is not coupled or the bicycle rack is attached, fold in the ball

- neck or, in the case of a fully electric trailer hitch, retract the ball neck.
- **NOTE** The operating permit may be invalidated due to the illegal installation of trailer hitches

The installation – including retrofitting – of a non-folding or non-removable trailer hitch that even partially conceals the license plate or the lighting system is prohibited.

Observe the applicable legal regulations for the installation of trailer hitches.



Trailer hitch with additional guide pin

Depending on the bicycle rack's design, different numbers of bicycles can be transported.

The following bicycle rack designs are possible:

• When mounted by attaching to ball head ①, the maximum load capacity is 75 kg. You can transport up to three bicycles.

• When mounted on ball head (1) and guide pin 2, the maximum load capacity is 100 kg. You can transport up to four bicycles.

The maximum load capacity is calculated from the weight of the bicycle rack and the bicycle rack load.

Observe the notes on driving with a roof load, trailer or fully laden vehicle (\rightarrow) page 187).

When using a bicycle rack, set the tyre pressure for increased load on the rear axle of the vehicle. Further information on the tyre pressure can be found in the tyre pressure table (\rightarrow page 511).

Notes on loading

The larger the distance between the load's centre of gravity and the ball head, the greater the load on the trailer hitch.


Observe the following notes:

- · mount heavy bicycles as close to the vehicle as possible
- always distribute the load on the bicycle rack as evenly as possible across the vehicle's longitudinal axis

Mercedes-Benz recommends removing all detachable parts from bicycles (e.g. baskets, child seats, rechargeable batteries) before loading them onto the bicycle rack. This will improve the aerodynamic resistance and centre of gravity of the bicycle rack.

Always secure the bicycles to prevent them from moving around and check them at regular intervals to ensure that they are secure.

Do not use tarpaulins or other covers. The driving characteristics and rear view may be impaired. In addition, aerodynamic resistance and the load on the trailer hitch will increase.



Load distribution on the bicycle rack

- Vertical distance between centre of gravity and ball head
- O Horizontal distance between centre of gravity and ball head
- The centre of gravity is on the vehicle's centre axis.

Observe the following information when loading the bicycle rack:

Loading the bicycle rack

	3 bicycles	4 bicycles
Total weight of bicycle rack and load	Up to 75 kg	Up to 100 kg
Max. distance	420 mm	420 mm
Max. distance	300 mm	400 mm

When transporting four bicycles or a total weight between 75 kg and 100 kg, always use bicycle racks with additional support on both trailer hitch guide pins.

Vehicle towing instructions

The vehicle is not suitable for the use of tow bar systems that are used for flat towing or dinghy towing, for example. Attaching and using tow bar systems may result in damage to the vehicle. When you are towing a vehicle with tow bar systems, safe driving characteristics cannot be guaranteed for the towing vehicle or the towed vehicle.

The vehicle-trailer combination may swerve from side to side.

Observe the following information:

- Permitted towing methods (→ page 498)
- The notes on towing the vehicle with both axles on the ground (\rightarrow page 499)

Notes on the driver's display



WARNING Risk of accident if the driver display fails

If the driver display has failed or is malfunctioning, function restrictions in systems relevant to safety cannot be detected.

The operating safety of your vehicle may be impaired.

- Drive on carefully.
- Have the vehicle checked immediately at a qualified specialist workshop.

If the operating safety of your vehicle is impaired, park the vehicle immediately and safely. Contact a qualified specialist workshop.

The driver's display shows basic information such as speed, engine speed, fuel level, coolant temperature as well as indicator and warning lamps.

The driver's display shows the following basic information:

Speed and power meter level

- Range according to average consumption, personal driving style or high-consumption driving style
- State of charge of the high-voltage battery
- Indicator and warning lamps

Additional functions available include the following:

- Different menus, e.g. for assistance and navigation
- Status displays for the driving systems
- Display messages
- Information on speed, Consumption and range

Some menu content and settings can be customised (\rightarrow page 307).

Notes on the 3D driver display



WARNING Risk of accident if the driver display fails

If the driver display has failed or is malfunctioning, function restrictions in systems relevant to safety cannot be detected.

The operating safety of your vehicle may be impaired.

- Drive on carefully.
- Have the vehicle checked immediately at a qualified specialist workshop.

If the operating safety of your vehicle is impaired, park the vehicle immediately and safely. Contact a qualified specialist workshop.

The 3D driver's display enables a three-dimensional representation of the content of the driver's display. This requires the driver to be recorded by the driver camera.


The system may be impaired or may not function in the following situations:

- The driver camera is deactivated or is not working.
- The driver is outside the detection range of the driver camera.
- The operating conditions are not in place, e.g. if the outside temperature is too low or too high.

If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

Observe the legal requirements for the country in which you are currently driving when operating the driver's display.

cannot be sure of this, stop the



- Back button
- Main menu button
- Touch Control

The content on the driver's display is controlled using the control elements on the left side of the steering wheel. You can use Touch Control (a) to navigate vertically and horizontally by swiping with

Operating the driver's display

WARNING Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

Only operate this equipment when the traffic situation permits. one finger. Confirm your selection by pressing the Touch Control.

- To operate Touch Control (a) in the most effective way, use the tip of your thumb if possible. You can also set the sensitivity of the Touch Control on the central display (→ page 333).
- Briefly press main menu button 2.
- Select a menu by swiping to the left or right on Touch Control 3.
- ► To confirm: press Touch Control ③.

You can watch an animation on this topic via the following link:

Driver display menus

Notes on menus on the driver's display



WARNING Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

Observe the legal requirements for the country in which you are currently driving when operating the driver's display.

The following menus can be called up via the menu bar on the driver's display:

- Classic
- Exclusive
- Sport
- Navigation
- Assistance
- Service


On some of these menus, you can choose between different display content on the centre display area.

On most of the menus, you can use Options to configure further settings for the menu-specific display content.

You can watch an animation on this topic via the following link:

Calling up and operating menus on the driver's display

Calling up a menu via the driver's display menu bar



- Back button
- Main menu button
- Touch Control

Press main menu button 2 on the steering wheel. The driver's display menu bar will open.



- Swipe to the left or right on left-hand Touch Control (3) and select a menu (e.g. the Classic menu) on the menu bar.
- To confirm: press left-hand Touch Control 3.

Calling up or exiting the Options submenu

- To call up: press left-hand Touch Control 3.
- To exit: press back button 1.

Browsing through display content or lists

- Swipe up, down, left or right on left-hand Touch Control 3.
- Within different menus, icons will also appear at the right edge of the centre display section to indicate the current position on a list.

Setting display content as the standard display You can set custom-configured menu display content as the standard display.

- Press and hold left-hand Touch Control (3) until the bar display that appears is completely filled.
- The Set direct entry? prompt will appear.
- Swipe left on left-hand Touch Control (3) and select Yes.
- To confirm: press left-hand Touch Control 3.
- To call up standard displays: press back button 1 on the upper level of a menu.
- Pressing back button (1) on the standard display will call up the previous menu.

Resetting values

- To call up the Options submenu: press left-hand Touch Control 3.
- Select Yes.
- To confirm: press left-hand Touch Control 3.

Configuring settings on the Classic or Exclusive menus

Driver's display:

¬→ Classic

Selecting display content in the centre display area of the Classic and Exclusive menus

- Call up the Classic or Exclusive menu via the driver's display menu bar.
- To select display content: swipe upwards or downwards on the left-hand Touch Control and select the desired display content.



Vehicles with combustion engines

- Speedometer
- Rev counter
- Transmission position
- Coolant temperature display
- Outside temperature
- Display content, centre on the Classic menu (example: trip distance)

- 7 Time
- Fuel level and fuel filler flap location indicator

The following content can be shown in centre display area (a) of the Classic and Exclusive menus:

- Trip and total distance
- Trip computer From start and From reset
- ECO display
- Consumption
- ATTENTION ASSIST
- Audio
- Navigation
- If navigation is selected as the display content in the centre display area, navigation instructions that vary depending on the driving situation will appear.
- i If you have selected display content in the centre display area of the Classic or Exclusive menus and switch to the other menu, the selected display content will also be transferred.

Changing the radio station or track on the station or track list

You can select radio stations or tracks on the station or track list in the audio display content of the Classic and Exclusive menus.

The following adjustments can be made in the MBUX multimedia system:

- Configuring the station or track list
- Switching between media sources
- Setting the frequency band



Track list for the audio display content in the centre display area (example)

To change radio stations or tracks: swipe left or right on the left-hand Touch Control and select a radio station or track on station or track list .

i) The radio station or track displayed when the vehicle is restarted depends on the user profile used for the previous trip.

The following functions may be available on the **Options** submenu, for example:

- Navigation: selecting and adjusting zoom, route guidance and map settings
- Resetting the trip odometer
- Resetting the trip computer From start
- Resetting the trip computer From reset
- Resetting the ECO display values

Calling up the Service menu

Driver's display:

¬→ Service

The current status of the vehicle is shown on the Service menu.

To call up the menu: press the left-hand Touch Control.

The following display content is available on the Service menu (equipment-dependent):

- Information about how many messages are in the message memory
- AdBlue: AdBlue® range and fill level
- Tyre pressure:
 - Restarting the tyre pressure loss warning system (→ page 514)
 - Checking the tyre pressure with the tyre pressure monitoring system (\rightarrow page 512)
 - Restarting the tyre pressure monitoring system (→ page 513)
- ASSYST PLUS: calling up the service due date (→ page 468)
- Engine oil level: checking the engine oil level (→ page 473)
- · Coolant indicator

The following functions are available on the Options submenu:

- Tyre pressure (→ page 512)
- Message memory (→ page 644)

Calling up the assistant display on the Assistance menu

Driver's display:

→ Assistance

Various driver assistance systems and navigation instructions are displayed on the Assistance menu.

To call up the menu: press the left-hand Touch Control.



Active Distance Assist DISTRONIC display on the assistant display (example)

In vehicles with the Driving Assistance Plus Package, the following displays may vary depending on the driving situation:

- The navigation instructions in the left-hand display section
- The traffic light view in the right-hand display section
- The display of the driver assistance systems
- The level of detail on the assistant display

In vehicles without the Driving Assistance Plus Package, your lane and the vehicle in front will be displayed.

The following status displays are available on the assistant display:

- Green: pedestrian detection active
- Grey: pedestrian detection enabled
- Green radar waves next to vehicle: Blind Spot Assist or Active Blind Spot Assist enabled and ready for operation
- Grey radar waves next to vehicle: Blind Spot Assist or Active Blind Spot Assist enabled but not ready for operation

The content on the assistant display will adapt to the following situations:

- Number of lanes detected
- Change of direction, e.g. lane change
- Current road conditions
- Road users detected
- The assistant display does not display other detected obstacles with the exception of road users.

The following functions are available on the Options submenu:

- · Starting route guidance
- · With active route guidance: end route guidance
- Call up previous destinations and favourites
- Start new route guidance to a recent destination
- Start new route guidance to a favourite

Calling up displays on the Sport menu

Driver's display:

¬→ Sport

The Sport menu provides information about the engine data of the vehicle.

- When you call up the Sport menu on the menu bar of the driver's display, the menu colour setting will automatically be applied to the MBUX multimedia system.
- To call up the menu: press the left-hand Touch Control.



- Current torque
- G-meter

- Current power output
- Boost pressure
- Engine oil temperature
- Engine speed


Calling up navigation instructions on the driver's display

Driver's display:

¬→ Navigation

To call up the menu: press the left-hand Touch Control.

Changing the scale of the selected map view



- Distance to the change of direction
- Road to which the change of direction leads
- Display of traffic incident
- Currently selected route

- Indicator showing vehicle's current position
- 6 Change-of-direction symbol
- Recommended lane (white)
- ① Lane not recommended (grey)
- Ourrent lane
- (i) The level of detail in the navigation instructions in the left-hand display section may vary.
- To zoom in and out on the map directly: swipe upwards or downwards on the left-hand Touch Control.
- If no operation is performed within a short time of the autozoom being activated, the set map scale of the map view already selected will appear.

You can set the permanent map scale display in the MBUX multimedia system (\rightarrow page 402).

The following functions are available on the Options submenu:

- With active route guidance: end route guidance
- · Select route guidance

- Map settings
- (i) If the current route guidance is ended on the Navigation menu of the driver's display, it will also be ended in the MBUX multimedia system.

On the Options submenu, you can use other functions in the Destinations and Map settings categories.

You can use the following functions in the Destinations category:

- Call up previous destinations and favourites
- Start new route guidance to a favourite
- The two options Work and Home will be displayed in Favourites even if no address is stored.

You can use the following functions in the Map settings category:

- · Activate auto zoom
- Set the map view, satellite view and route overview.

The following map views are available on the Navigation menu:

- Entire route
- 2D direction of travel
- 2D north-up
- 3D map
- (i) There is an additional navigation view on the front passenger display. The front passenger can thus assist the driver with route guidance (→ page 390).

Head-up display

Function of the head-up display


The head-up display projects various content into the driver's field of vision, for example.

You can use the head-up display menu bar to select various contexts, e.g.:

- Minimal
- Sport
- Standard
- ECO display (→ page 192)

- Settings
- Head-up display on/off

Head-up display content with navigation (9x3°)



- Navigation instructions
- Navigation instructions (distance to the next route event)
- Steer Assist status
- Current speed
- Set speed in the driving system (e.g. cruise control)
- Detected traffic signs (Traffic Sign Assist)

When you receive a call, the Call waiting message will appear on the head-up display and the driver's display.

System limits

Visibility is particularly influenced by the following conditions:

- Seat position
- Image position setting
- Light conditions
- Wet road surfaces
- Objects on the display cover
- · Polarisation in sunglasses

Operating the head-up display

Selecting display content of the head-up display via the menu bar of the driver's display

- Press the main menu button on the left.
- To select the menu bar of the head-up display: swipe upwards on the left-hand Touch Control.



Switching between display content on the headup display

Swipe to the left or right on the left-hand Touch Control

A preview of the selected display content will appear on the head-up display.

To confirm: press the OK button.

Switching back to the driver's display

▶ Press the or button.

Setting the position and brightness

- Swipe to the left or right on the left-hand Touch Control and select Settings on the menu bar of the head-up display.
- Press the left-hand Touch Control. The current position and brightness settings will be displayed as graphics on the head-up display as well as on the driver's display.
- To adjust the position: swipe upwards or downwards on the left-hand Touch Control.
- To adjust the brightness: swipe to the left or right on the left-hand Touch Control. The settings configured for position and brightness will be saved automatically.
- Press the or ok button to exit the settings.

Switching the head-up display on/off

Driver's display:





Switching on

- Swipe upwards on the left-hand Touch Control.
- Press **OK** on the left-hand Touch Control.

Switching off

- Swipe upwards on the left-hand Touch Control.
- Swipe on the left-hand Touch Control and select Head-up display.
- Press OK on the left-hand Touch Control.


Vehicles with a 48 V on-board electrical system



- Electric drive support
- Recuperation behaviour of the electric motor
- Due to various system limits, the values displayed may temporarily differ slightly from the actual value.

Overview of status displays on the driver's display

The status displays for the driving and driving safety systems can be found in display sections 🕜 to 🙆



- Pedestrian detection (only on assistant display)
- Active Parking Assist is available $(\rightarrow page 277)$
- Active Parking Assist has recognised a parking space (\rightarrow page 277)
- Parking Assist PARKTRONIC deactivated P∭■ $(\rightarrow page 274)$

Cruise control (\rightarrow page 224)

LIM Limiter (\rightarrow page 225)

Active Distance Assist DISTRONIC **=**(S) $(\rightarrow page 228)$

Specified distance for Active Distance Assist DISTRONIC (→ page 228)

Active Brake Assist switched off ૐ<u>!</u>ૄ $(\rightarrow page 248)$

Active Brake Assist impaired or not func-એ!લ્ tioning (\rightarrow page 248)

₽ Active Steering Assist (\rightarrow page 237)

4/€/\ Active Lane Change Assist (\rightarrow page 241)

7:5 Active Lane Keeping Assist (→ page 258)

4 Active Blind Spot Assist (only on assistant display) (\rightarrow page 257)

ECO start/stop function (\rightarrow page 191) (A)

HOLD function (\rightarrow page 220) HOLD

■ Adaptive Highbeam Assist (\rightarrow page 155) Adaptive Highbeam Assist Plus $(\rightarrow page 156)$

Maximum permissible speed exceeded (for certain countries only)

Active Stop-and-Go Assist (\rightarrow page 236)

Slippery road surface warning

Vehicles with Speed Limit Assist: detected instructions and traffic signs (→ page 248)

Vehicles with Traffic Sign Assist: detected instructions and traffic signs (\rightarrow page 250)

Notes on operating safety

For your own safety, always observe the following points when operating mobile communications equipment and especially your Voice Assistant:

- Observe the legal requirements for the country in which you are driving.
- If you use the Voice Assistant in an emergency your voice can change and your telephone call, e.g. an emergency call, can thereby be delayed.
- Familiarise yourself with the Voice Assistant functions before starting the journey.

i The Voice Assistant does not replace the Owner's Manual.

The answers from the Voice Assistant do not provide the complete scope of information contained in the Owner's Manual. The Voice Assistant also does not give detailed warning or damage information. You can get the full scope of information about the function and safe operation of the systems and components in the vehicle in the Owner's Manual.

Operation

Function of the MBUX voice assistant

You can watch an animation on this topic via the following link:

Using the MBUX voice assistant, vehicle functions and various areas of the MBUX multimedia system can be operated by voice input, e.g. Navigation or Telephone. The MBUX voice assistant is operational about half a minute after switching on the vehicle and can be operated from all seats (depending on the special equipment).

Conducting a dialogue

Requirements

- Voice activation must be switched on in the multimedia system (→ page 317).
- For corrections during output, the Voice barge-in option must be activated in the multimedia system (→ page 317).

Starting a dialogue

Say Hey Mercedes to activate the MBUX voice assistant. or

Press the button on the multifunction steering wheel.

A blue wave appears in the MBUX multimedia system. The dialogue can be started.

For the dialogue with the MBUX voice assistant, you can use complete sentences of colloquial language as voice commands. Voice activation can also be combined directly with a voice command, e.g. Hey Mercedes, how warm is it outside?

Interrupting the dialogue

- During the dialogue say Pause. The dialogue is interrupted.
- Say Hey Mercedes to continue the dialogue.

Changing dialogue level

During the dialogue, say Back.
 The MBUX voice assistant jumps back to the previous dialogue step.

Navigating in the selection list

If a voice command does not achieve a clear result, a selection list is shown.

- Say the line number or the content to select an entry or to have further details shown.
- Say Next page or Previous page to browse the selection list.

Calling up help

- Current application: say Help. You will receive suggestions and information about operation of the MBUX voice assistant for the current application.
- Specific function: call up the voice command for the required function, for example with Hey Mercedes, I need help with Radio.

Overview of the operable functions of the MBUX voice assistant

You can use the MBUX voice assistant to operate the following functions depending on the vehicle equipment:

- Telephone
- Text message and e-mail
- Navigation
- Radio and media

- Vehicle functions
- Online functions

Full functionality of the Voice Assistant is only available for you with activation of online voice control (\rightarrow page 317).

Information on the language setting

You can change the language of the MBUX voice assistant via the system language settings (\rightarrow) page 358). If the set system language is not supported by the MBUX voice assistant, English will be selected.

Setting functions of MBUX voice assistant using the multimedia system

Multimedia system:

→ 🔝 >> Settings >> System >> Voice assistant

Switching voice activation of MBUX voice assistant on or off

- (i) For vehicles with driver camera or MBUX Interior Assistant, the MBUX voice assistant can be switched on or off in the Intelligent Assistants menu.
- Select Hey Mercedes. When the function is active, the Hev Mercedes voice command can activate the dialogue.

Switching direct commands on or off

- Select 🔯 .
- Activate or deactivate the function. If the function is active, some commands can be used without Hey Mercedes, for example Next track.

Switching voice activation for individual seats on or off

- ➤ Select 🔯 .
- Switch the function for the desired seats on or off.

Switching voice interruption on or off

- Select Further settings.
- Select Voice barge-in. If the function is active, a command can be interjected during voice output of the system.

Switching proactivity on or off

- Select Further settings.
- Select the desired situation, e.g. Activate your profile or Don't forget your phone. When the function is active, the voice assistant proactively provides information in specific situations.

Activating or deactivating online voice control

- Online voice control is activated at the factory.
- Select Online recognition.

Activate or deactivate the function.

If the function is activated and a Mercedes me user account is linked to the vehicle, additional results are available through the provision of external information, e.g. information on POIs. By clicking the symbol in the blue wave, more information about the online voice control can be displayed.

Activating or deactivating contacts for online use

Select Contact upload for online recognition. When the function is active, contacts will be found more easily and accurately using voice input.

Using MBUX voice assistant effectively Notes on optimum use of MBUX voice assistant

 The MBUX voice assistant is operational half a minute after switching on the vehicle and can be operated from all seats, depending on the equipment installed. The system recognises from which seat the command was spoken and performs actions according to the seat position.

- If a dialogue has been ended, the MBUX voice assistant continues to be active, as long as the blue wave is shown in the multimedia system. You can say another voice command without saying Hey Mercedes.
- Using the direct command Change language to English, the system language can be changed to English without Hey Mercedes.
 Direct commands must be activated for this.
- With the MBUX voice assistant, incoming calls can be accepted or rejected without the keyword Hey Mercedes.

Information on the MBUX online voice assistant

The online voice control facilitates recognition and thanks to external information makes additional results available.

Therefore, Mercedes-Benz recommends that you activate online voice control (\rightarrow page 317).

You will need a Mercedes me user account for this. If you do not yet have a user account you have to create one and connect it with your vehicle (\rightarrow page 435).

Then call up your Mercedes me user account. The Mercedes me services are shown and can be activated (\rightarrow page 435).

By clicking on the symbols displayed in the blue wave, further information on the online status is displayed.

When online voice control is active, additional functions are available such as:

- Weather
- General knowledge
- · Public holidays and school holidays
- Smarthome
- Messages
- Time, date and time zones
- Pocket and currency calculator
- · Football results and fixture lists
- Share prices
- Calendar
- ChitChat
- Horoscope
- Geo Quiz

- The availability of these functions is country and equipment-dependent.
- Text content is taken from Wikipedia in accordance with the CC BY-SA 3.0 licence.

Essential voice commands

Notes on voice commands

It is not necessary to use exact voice commands to call up a specific function. The MBUX voice assistant also understands you when you use your colloquial speech. Some examples are listed below. For some languages however these examples are only available to a limited extent.

Examples of voice commands:

- Navigation (→ page 319)
- Telephone (→ page 320)
- Radio and TV (→ page 320)
- Media player (→ page 320)
- Messages (→ page 320)
- Vehicle functions (→ page 321)
- Online functions (→ page 321)

Examples of navigation voice commands

You can operate the navigation system using the MBUX voice assistant. The following list offers just a small selection of the possible navigation commands. You will receive additional suggestions if you say Help for navigation.

- Drive me home.
- Where is the nearest service station?
- Is there a service area along the route?
- Set Central Park as intermediate destination.
- Cancel the route guidance.
- Show my last destination.
- I want to buy juice.
- Search for a French restaurant in South London.
- Search for a filling station near the Mercedes-Benz Museum in Stuttgart.
- Navigate me to Warsaw and avoid toll roads.
- How is the traffic on the way to work?

Examples of telephone voice commands

You can operate phones connected with MBUX multimedia system the using the MBUX voice assistant. The following list offers just a small selection of the possible telephone commands. You will receive additional suggestions if you say Help for phone.

- Call Peter Miller on the mobile phone.
- Dial 0711 17 0.
- · Call my father.
- Write a text message to Jane Smith.
- Search for the contact Peter Miller.
- Tell Peter Müller: "I'll be there five minutes later".
- Read me my new text messages.
- Show me the missed calls.
- Switch to address book

For an incoming call:

- Reject call
- Accept call

Examples of radio and TV voice commands

Depending on the vehicle equipment, you can operate the radio and TV using the MBUX voice assistant. The following list offers just a small selection of the possible radio or TV voice commands. You will receive additional suggestions if you say Help for radio or Help for TV.

- Play the radio station Heart FM.
- Next station.
- · Previous station.
- Show me the list of radio stations
- Save the station
- What am I listening to?

Examples of media voice commands

You can operate connected media sources and online music using the MBUX voice assistant. The following list offers just a small selection of the possible media voice commands. You will receive additional suggestions if you say Help for media or Help for player.

Play Michael Jackson.

- Play Michael Jackson on Spotify.
- Play "Yellow Submarine' by the Beatles.
- Next track.
- Previous track.
- Play similar track.
- Repeat this track.
- Please skip five seconds.
- Please go back five seconds.
- Switch on random playback.
- Set the music volume to level six.
- Mute the music.
- Switch to USB.

Examples of message voice commands

Messages can be created, edited and listened to using the MBUX voice assistant. The following list offers just a small selection of the possible message commands. You will receive additional suggestions if you say Help for messaging.

• Write a text message to Jane Smith: When will the next meeting take place?

- Show me my new e-mails.
- Write an e-mail to Jane Smith.
- Read me my new text messages.
- · Show all new text messages.
- Write an e-mail to John Smith in English

Examples of vehicle voice commands

You can operate vehicle settings and vehicle functions using the MBUX voice assistant. The following list offers just a small selection of the possible vehicle voice commands.

- (i) If no seat is mentioned for commands, the action is carried out automatically for the seat from which the command was spoken or for the function which is closest to that seat.
- Switch the seat heating to level 2.
- · My feet are cold.
- Start the Refresh programme.
- Switch the massage function on.
- I would like to set the ambient light to blue
- Switch on the reading lamp.

- Turn off the rear light.
- Open all the windows.
- Switch the driver's display to 3D.
- How fast can I drive here?
- Tell me my next service appointment
- How warm is it outside?

Information about the vehicle can also be requested:

- Information about individual items of the vehicle equipment
 - Hey Mercedes, which massage programs do you have?
 - Hey Mercedes, do I have Blind Spot Assist?
 - Hey Mercedes, where is the warning triangle?
- Information about functioning of the systems and components installed in the vehicle
 - Hey Mercedes, what is DISTRONIC?
 - Hey Mercedes, what do I need ESP for?
 - Hey Mercedes, what is MBUX?

- Information about operating the systems and components installed in the vehicle
 - Hey Mercedes, how do I connect my smartphone?
 - Hey Mercedes, how can I turn on the high-beam headlamps?
 - Hey Mercedes, how do I stop the ionisation function?

Examples of online functions

Depending on the country, language and vehicle equipment, additional functions are available when online voice control is active. The system accesses external information and can, among other things, answer questions about general knowledge, provide information about weather or locations, perform calculations, etc.

- Is the sun shining in Manchester?
- Is it raining at my location?
- What are the skiing conditions on the Zugspitze?
- What's the time in Sydney now?

- In which country do you pay with dollars?How many Swiss franks make 25 euros?
- How long now until the holidays?
- What day is it tomorrow?
- What is 20% of 29?
- VVIIde 18 20% 01 27.
- What does my horoscope say?
- What is the price of Mercedes-Benz Group shares?
- Let's play Geo Quiz.I'm bored.
- I'm bored
- Who is the current prime minister?
- What do you know about the Globe Theatre in London?
- Who painted the picture "The Scream"?
- What's the status in the Premier League?
- Create a calendar entry tomorrow at 9 am.
- What's my next task?Tell me a joke.
- How many languages do you speak?
- How many languages do you speak What is your favourite animal?

Are there any updates?

Overview and operation

Overview of the MBUX multimedia system

WARNING Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.


You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

NOTE Increased surface temperature due to direct sunlight on the central display/ front passenger display

The surface of the display is very dark.

If the display is exposed to direct sunlight, the surface may heat up considerably.

If the display has been exposed to direct sunlight, allow it to cool down before touching it for a longer period of time.



Vehicles with MBUX Hyperscreen

Touch Control and control panel for the MBUX multimedia system

- Operates Touch Control (→ page 332)
- Central display with touch functionality for the driver
 - Overview of the zero layer (→ page 326)
 - · Calls up and operates the zero layer $(\rightarrow page 328)$
 - Home screen overview (→ page 330)
 - Operates the touchscreen (→ page 333)
- Sets haptic operation for the touchscreen $(\rightarrow page 334)$
- Front passenger display with touch functionality
- Switch panel with:
 - Fingerprint sensor

(b) Switches the MBUX multimedia system on or off, switches the driver's and front passenger displays on or off

Switches sound on or off

→ Adjusts the volume

Various MBUX multimedia system apps offer the option of linking with a QR code. Scan this QR code with your mobile phone before starting the journey.

- Alternatively, the MBUX voice assistant allows voice dialogue. Operation with natural speech starts after the wake-up call "Hey Mercedes" (→ page 316). You can start a voice navigation, for example, with the input of a threeword address from what3words.
- (i) If the vehicle is equipped with the MBUX Interior Assistant, vehicle and infotainment functions can be used contact-free. The interaction then follows intelligently, reactively or with hand or head movements.

Numerous application, online services, services and apps are available for you. These can be called up via the home screen.

In the zero layer, entertainment sources as well as telephone, active applications and suggestions are directly available to you. You can conveniently call up and add your favourite destinations using the \lineth button on the steering wheel.

Quick-access in the home screen and in the applications serve to select functions more quickly.

If you use the learning function of the multimedia system, during operation phone numbers dialled, active massage programmes or vehicle functions

are suggested to you, for example. Suggestions are displayed on the zero layer based on context and your user behaviour. The configuration of the suggestions is completed in the system settings. Furthermore, the multimedia system learns routines. Routines are actions that run automatically under certain conditions. You can compile your user profile from various vehicle settings and settings of the multimedia system. Some functions and services are protected by a PIN. If you teach in biometric procedures, you can identify yourself with these instead of the four-digit Mercedes me PIN.

The Notifications Centre collects incoming notifications, e.g. about an available software update. Depending on the type of notification it offers various actions. The call is made via the Control Center.

Overview of the front passenger display (only vehicles with MBUX Hyperscreen)

A

WARNING Risk of accident and injury due to distraction when the driver is looking at the front passenger display

If you look at the front passenger display while driving, you may be distracted from the traffic. This could also cause you to lose control of the vehicle. The front passenger display is intended exclusively for the front passenger.

- Keep the actual traffic situation constantly in view.
- Avoid looking at the front passenger display while driving.

The front passenger display is an additional touchscreen specifically for the front passenger.

Requirements for displaying content on the front passenger display while driving:

- The passenger is sitting on the passenger seat.
- The driver camera is switched on (→ page 353).

In the status line of the central display is shown as a white symbol.

The driver camera detects the driver's head and line of sight.

It displays content from the MBUX multimedia system independently of the central display. Depending on the application, operation is independent of the driver. Depending on the market, extended content, e.g. playback of media content, is also available while driving.

For the playback of certain content on the front passenger display, e.g. moving images, it is necessary to connect Bluetooth® headphones.

- When the vehicle is parked, the front passenger can use the front passenger display under the following conditions:
 - The passenger is sitting on the passenger seat.
 - There is interaction with the MBUX multimedia system.

If the driver has left the vehicle briefly, e.g. to go shopping, the front passenger display can also be operated.

If no front passenger is present, a digital decorative image can be shown on the front passenger display (\rightarrow page 354).

Visual shield function for front passenger display The visual shield function helps to avoid the driver viewing the front passenger display while driving.

Certain content on the front passenger display is dimmed for the driver.

Requirements for activating the visual shield function:

- The content shown on the front passenger display is blocked for the driver while driving, e.g. playback of videos.
- Content is blocked automatically via the MBUX multimedia system.
- The driver camera is switched on. In the status line of the central display is shown as a white symbol.
- The driver camera detects the driver's head and line of sight directed to the front passenger display. If the driver looks at the front passenger display for too long while driving, content subject to blocking is also dim-

med for the front passenger. A message appears on the front passenger display.

The front passenger display shows the contents again in the usual way under the following conditions:

- The driver looks forward again.
- No blocked content is shown on the front passenger display.

Anti-theft protection

This device is equipped with technical provisions to protect it against theft. More detailed information about anti-theft protection can be obtained at a qualified specialist workshop.

Zero layer

Function of the zero layer

Your software can be upgraded to a more current version at a later date.

The zero layer provides you with dynamic content from the MBUX multimedia system and is used to quickly access and control the applications you use. When you select on the central display, the digital map with the applications appears in the lower display area. Compared to the home screen with a classic menu, the steps required to call up the applications are reduced. You can switch between the zero layer and the home screen with a classic menu.

The applications can be hidden from the display area and shown again.

The zero layer provides the following modules and applications:

- Navigation module
 In the expanded view you can, for example, display the route overview, switch on the display of traffic information and make settings for View (map), Messages & tones, Route.
- Entertainment (media, radio) and telephone
 When the lower display area is shown, the
 entertainment sources are always displayed.
 A mobile phone must be connected to the
 MBUX multimedia system for the phone to be
 displayed.
- Active applications

The lower display area shows an active massage programme, for example.

Suggestions

Suggestions are displayed on the lower display area based on context and your user behaviour. Here are a few examples:

- Latest calls
- Active massage programs
- Vehicle functions
- Online voice applications
- Personalised routines

The learning function of the system recognises your typical operating sequences and offers to perform these automatically for you as a routine.

Modules and applications are first shown in a reduced view. By tapping on them, you can operate them or open the associated menu (expanded view).

A long press on a suggestion opens a context menu in which further functions are available.

The learning function can be switched on and off for the options (\rightarrow page 359).

Overview zero layer

Digital map and user-specific applications (example)



- Navigation module (reduced view)
- ② Enters a destination (→ page 375) Searching for parking
- 3 Calls up the Control Centre: pull the bar down
- Status line
- 6 Calls up user profile settings
- Suggestion

Requirement: suggestions are activated $(\rightarrow page 359)$.

- Active application
- Telephone Requirement for phone: the mobile phone is connected to the MBUX multimedia system.
- Press briefly: shows all applications

 $(\rightarrow page 328)$ Press and hold: calls up the home screen with classic menu (\rightarrow page 330)

- Entertainment sources (media, radio)
- Route monitor e.g. route list, lane recommendations, 3D image of the upcoming driving manoeuvre

The zero layer shows the digital map and the userspecific applications.

The following user-specific applications are displayed in the lower display area:

 Suggestions Requirement: suggestions are activated $(\rightarrow page 359)$.

- Active applications e.g. a massage programme
- Entertainment sources (8)
- Online voice applications

The lower display area can be hidden and shown $(\rightarrow page 328)$.

Information about entertainment sources

You can operate the applications in the reduced view or in the menu (expanded view) $(\rightarrow page 328)$.

Examples:

- Control a media source, e.g. pause/play, next track, set a station
- Select tracks from the current playlist or stations from the station list
- Select a media source The media source must be connected to the MBUX multimedia system.

Information about the telephone

To use the functions, the mobile phones must be connected to the MBUX multimedia system.

Requirement for suggestions: the Calls & messages option is activated in the suggestions.

Examples:

- Answer a call and call a missed call The missed calls are displayed for the mobile phones connected to the MBUX multimedia system.
- Display contacts and call list and call a contact
- Use voice functions
- Suggest contacts

The contacts are suggested for the mobile phones connected to the MBUX multimedia system. No contacts are suggested for the mobile phones that are linked to another user profile.

- Write messages to contacts (suggestion)
- Connect a device via the device manager (suggestion)

Information about active applications

The following functions are available:

- Operating the massage programme
- Operating an ENERGIZING COMFORT programme

Suggestions for comfort and vehicle functions as well as navigation

Requirement: the Comfort, Vehicle and Navigation options are activated in the suggestions.

- Operating the massage programme
 For example, the multimedia system suggests a programme at a certain time.
- Opening the boot lid
 Requirement: the vehicle is equipped with
 boot lid convenience closing.
- Operating an ENERGIZING COMFORT programme
- Making heating settings
- Activating/deactivating Parking Assist PARKTRONIC
- Selecting previous destinations and destinations from favourites

Suggestions for online voice applications

Requirement: the Online voice services option is activated in the suggestions.

The suggested voice applications are made available online and are based on your previous voice inputs.

Examples:

- What will the weather be like tomorrow?
- · Play the messages.
- · Start geoquiz.
- Open the garage door.

Suggestions for activating recognised routines Requirement: the Learning & suggestions option is activated in the suggestions.

Routines are actions that run automatically under certain conditions. An example of a routine: Whenever you drive to work in the morning (condition), the MBUX multimedia system should set a certain massage programme (action). Routines can also perform different actions.

Calling up and operating the zero layer

Calling up the zero layer

When the vehicle has been switched on, the zero layer is displayed with the digital map. Navigation is active.

From another application: press the http://doi.or.in.

or

► Tap on 🞧.

Operating applications in the reduced view (examples)

- Media: to play the previous or next track, tap

 ☑ or ☑.
- To answer a call or call a missed call: tap on the contact.

After the connection has been established, the call functions are available.

- To end a call: tap on the contact again.
- To reply to message: tap on a message and dictate the message via the MBUX Voice Assistant.

- To start a massage programme: tap on the application and start the massage programme.
- To select a previous destination: tap on the application and select one of the previous destinations.
- To select a destination from the favourites: tap on the application and select the destination.

Hiding and showing the display area with applications

- To hide: pull the applications down.
- To show: pull the bar above number upwards.

Select 🔝.

Press the button on the steering wheel on the right.

Navigation module (expanded view)



- Example: route guidance is active
- Traffic event on the route Distance from current vehicle position and remaining driving time
- Destination
- Searches for a filling station
- Switches traffic information display on or off

- Tap on the navigation module (\rightarrow page 326).
- Select Route in the lower menu bar.

Operating a menu in the lower display area (example: active massage programme)



- Selects a massage programme
- Starts/stops a programme for the driver
- Starts/stops a programme for the front passenger
- Sets the massage programme intensity for the driver's or front passenger seat

- Tap on the application. The expanded view of the application is displayed.
- ► To close the menu: select ►.

Opening and closing the context menu for a suggestion

- Press and hold on a suggestion. The context menu opens and shows the Do not suggest option, for example.
- ► To close: swipe downwards.

Removing a suggestion from the display area

Swipe the suggestion upwards.

Showing all applications

- Press briefly.

 Available applications are displayed.
- ► To hide applications: briefly press 🛕 again.

Switching between zero layer and home screen with classic menu

Long press on .
The home screen with classic menu is shown.

To return to the zero layer: press and hold on

Home screen overview



- Status line
- Calls up the Control Centre
- 3 Displays in the status line
- Calls up user profile settings and switches user
- 6 Calls up an application
- Quick-access to application
- Global menu

Calls up previous menu

- Press and hold: switches between home screen and zero layer
- Previous track or previous radio station

 Next track or next radio station
- i During a telephone call, the call duration is displayed in global menu 7.

Alternatively, to switch between the home screen and the zero layer, press and hold the button on the steering wheel on the right.

When bar ② is pulled down, the Control Centre appears.

The following functions are called up in the Control Centre:

- Notifications Centre
- Quick vehicle access

Personalised routines

Overview of personalised routines

The MBUX multimedia system supports you with daily routine tasks and can run them automatically. The system's learning function recognises

your typical operating sequences and suggests them as a routine in recurring situations.

When the system recognises a routine, it is proposed to you on the zero layer for activation.

Routines are actions that run automatically under certain conditions. An example of a routine: Whenever you drive to work in the morning (condition), the MBUX multimedia system should set a certain massage programme (action). Routines can also perform different actions.

Routines are available to you via three options:

- The MBUX multimedia system learns and suggests routines.
- You create your own routines.
- You select predefined routines (templates).

If the learning function Learning & suggestions is switched on and enough data is available, the system suggests a routine on the zero layer. You can activate or reject these. In the future, when the conditions for the routine are met, you will receive a notification with a timer. After confirmation or expiry of the timer, the actions of the routine are executed. If you tap in the notification, the

routine is cancelled. No actions are performed. However, the routine is still activated. If the conditions for the routine are met again, you will receive a notification again.

You can create your own routines or select predefined routines via the Routines app.

Conditions for routines are, for example:

- · When should a routine start?
 - Weekdays at 8 a.m.
- · Where should a routine start?
 - Start at home, start at work, tunnel passage
- At what temperature should a routine start?
 - From 0 °C
- At which event should a routine start?
 - Incoming or outgoing call
 - Strong sunlight

You can select the following actions, for example, from categories:

- Comfort
 - Selecting a massage programme

- Setting the seat heating
- Selecting the ENERGIZING COMFORT programme
- Climate control
 - Set temperature (front, rear)
 - Activate or deactivate the AC function
 - Adjusting the air vents
- Entertainment and navigation
 - Selecting a radio station
 - Select a media source
 - Switch off navigation announcements

Activating and starting suggested routines Multimedia system:



Activating routines

When a new routine is detected, it is suggested for automation on the zero layer.

Select Yes.

In the future, when the conditions for the routine are met, a notification will be displayed to prepare you to execute the routine.

or

To reject the routine this time: select Decide later.

You can find the routine in the Routines app and can activate or delete it there at any time.

Starting routines

A notification is displayed with a timer. When the timer has expired, the routine starts automatically.

- To start the routine immediately: tap the notification text.

Creating your own routines

Multimedia system:



Configuring conditions

- Select +.
- Select the condition, e.g. Weekdays.
- Select further conditions if required.

Configuring actions

- Select +.
- Select the category, e.g. Comfort.
- Select the action, e.g. Classic Massage.
- If required, select further actions also from other categories.
- Select Next.
- Select a symbol and enter a name, e.g. My first routine.
- Select Create skill.


The routine appears in the overview. When the conditions for the routine are met, a notification is displayed. The routine can be started.

- i You can edit a created routine at any time.
- Selecting predefined routines
 Multimedia system:
 - → 🔝 ➤ Routines ➤ Templates
 - Activate the desired routine.
 When the conditions for the routine are met, a notification is displayed. The routine can be started.

Templates can be edited like your own routines.

Touch Control

Operating Touch Control (MBUX multimedia system)



- Shows zero layer/home screen
- Touch Control

✓ Swipe in the direction of the arrow (navigate)

- OK Press (confirm)
- Returns to the previous display

- Makes or accepts a call
- Rejects or ends a call
- To increase volume: swipe upwards To reduce volume: swipe down
 - To switch off the sound: press
- ★ Calls up favourite destinations (press briefly) or adds a destination to favourites (press and hold)
- Starts the MBUX voice assistant
- To operate Touch Control (2) in the most effective way, use the tip of your thumb if possible.

You can navigate through menus and lists via the touch-sensitive surface of Touch Control 2 using a single-finger swipe, for example:

- To enter a character: select a character using the keyboard and press on Touch Control 2.
- To select a menu option: scroll in a list and press Touch Control 2.
- To move the digital map: swipe in any direction.

Setting the sensitivity for Touch Control

Multimedia system:

→ Settings → System

- >> Control elements
- >> Touch Control sensitivity
- Select Fast, Medium or Slow.

Setting acoustic operational feedback for all control elements

Multimedia system:

→ Settings → System

> Control elements > Acoustic feedback

The function is supported by the selection in a list.

Set Off, Unleaded or Loud. If the function is activated you will hear a clicking sound when selecting control elements or when scrolling in a list. When the beginning or end of the list is reached you will hear another clicking sound.

Touchscreen

Operating the touchscreen

Tapping

- To select a menu item or entry: tap on a symbol or an entry.
- To increase the map scale: tap twice quickly with one finger.
- To reduce the map scale: tap with two fingers.
- To enter characters with the keypad: tap on a button.

Single-finger swipe

- To navigate in menus: swipe up, down, left or right.
- To move the digital map: swipe in any direction.
- To use handwriting to enter characters: write the character with one finger on the touchscreen.

Two-finger swipe

To zoom in and out of the map: move two fingers together or apart.

- To enlarge or reduce the size of a section of a website: move two fingers together or apart.
- ➤ To turn the map: turn anti-clockwise or clockwise using two fingers.

Three-finger swipe

To call up the home screen: swipe up with three fingers in an application.

Touching, holding and moving

- To move the map: touch the touchscreen and move your finger in any direction.
- ➤ To set the volume on a scale: touch the touchscreen and move the finger to the left or right.

Touching and holding

- To save the destination in the map: touch the touchscreen and hold until a message is shown.
- To call up a global menu in the applications: touch the touchscreen and hold until the Options menu appears.

Switching haptic operation for the touchscreen on and off

Multimedia system:


- → 🙀 >> Settings >> System
- ➤ Control elements ➤ Touch & feel disp.
- Activate or deactivate the function.

 If the function is switched off, all you need to do is tap or swipe on the display to make an entry.

If the function is switched on, the system supports you with discreet tactile aids when you tap or swipe on the display.

You can operate the function on the central display.

Overview of the fingerprint sensor



Equipment with MBUX Hyperscreen

Fingerprint sensor allows you to conveniently access protected MBUX multimedia system functions and services. Compared to protection provided by the Mercedes me PIN, the entry of a four-digit number is not required to activate services and functions with personal content.

The fingerprint sensor must be set up before use $(\rightarrow page 337)$.

If equipped with a front passenger display, one fingerprint can be scanned in for the driver's seat and one for the front passenger seat. These fingerprints are then assigned to the respective seat. They can be used for authentication or to activate your own user profile on the assigned display.

The fingerprint sensor stores only a data model and no image of the fingerprint. The data model is only processed in the vehicle and is not transmitted from the vehicle.

User

Notes on user profiles



WARNING Risk of becoming trapped during adjustment of the driver's seat after calling up a driver profile

Selecting a user profile may trigger an adjustment of the driver's seat to the position saved under the user profile. You or other vehicle occupants could be injured in the process.

Make sure that when the position of driver's seat is being adjusted using the multimedia system, no people or body parts are in the seat's range of movement.

If there is a risk of someone becoming trapped, immediately stop the adjustment process by:

a) Pressing the warning message on the central display.

or

b) Pressing a position button of the memory function or a seat adjustment switch in the driver's door. The adjustment process is stopped.

The driver's seat is equipped with an anti-entrapment feature.

If the driver's door is open, the driver's seat will **not** be set after calling up the driver's profile.

Overview of user profiles

Requirements for use

· You have a Mercedes me user account.

- You have a Mercedes me PIN.
- You have agreed to the terms of use.
- The vehicle is linked to a Mercedes me user account.
- If one of the pre-requisites listed is missing or if no user profile has been selected, the data described in the following section will be saved in the vehicle as the standard setting. Standard settings can be changed by all vehicle users.

User profiles save personal settings. If the vehicle is used by several people, a person can change their profile settings without changing the settings of other users.

Some settings apply to the entire vehicle and are displayed in all user profiles, e.g. ambient lighting and the current navigation settings. These initially belong to the driver, but can also be changed by the other vehicle occupants in their user profile.

You can individualise a user profile in the vehicle using the set-up assistant or using the settings in your user profile. Some settings, e.g. the Mercedes me PIN and a profile photo are made in the Mercedes me App or in the Mercedes me Portal.

i If the user profile is downloaded while travelling, user profiles are not set up using the setup assistant.

User-specific content and applications with personal data are protected by different levels of security (\rightarrow page 337).

To access protected content, the Mercedes me PIN and, depending on the vehicle equipment, biometric sensors are used.

- (i) The security level is set by the multimedia system and calculated from the combination of all sensor inputs. Some security levels cannot be turned off.
- When a user profile is activated, the following personalised comfort systems, for example, can be adjusted or their settings loaded:
 - Seat
 - Ambient light
 - Outside mirrors
 - Roller blinds
 - · Climate control settings

· Head-up display

If the user profile is activated when driving, the driver's seat position will not be adjusted.

User-specific content

Depending on the vehicle equipment you can, as a user, save the following settings, for example:

- Driver's seat, steering wheel and mirror settings
- · Climate control
- Ambient light
- Radio (including station list)
- Suggestions

This function is an on-demand feature (→ page 25): If the vehicle key is linked to the user profile, the user profile is pre-activated when unlocking the vehicle or approaching a vehicle with KEYLESS-GO. Light, mirror and seat adjustments are made during this process. To use a user profile or an application, the vehicle key also serves as a sensor input for authorisation.

You can watch an animation on this topic via the following link:

Adding a user

Requirements

The vehicle is stationary.

Multimedia system:

→ 🔝 » Lhange user

- Select + Add user.
 A QR code is loaded.
- Scan the displayed QR code with the Mercedes me App or any QR code scanner on a mobile device. If the Mercedes me App is not yet installed on your mobile device, you will be directed to the store of your mobile device.
- Follow the steps in the Mercedes me App. The vehicle is connected with your Mercedes me user account. This automatically creates your user profile in the vehicle.

If only your user profile is available, it will be loaded automatically.

If more than one user profile is available, you will be directed to the user selection.

When the vehicle is stationary, the set-up assistant starts automatically after user selection.

When the user has been added, they can be selected (\rightarrow page 339).

Selecting user options

Multimedia system:





Protecting user-specific content and applications If you add a new user, access protection is already activated for the user profile. The Mercedes me PIN and, depending on the vehicle equipment, biometric sensors are available for access. Biometric sensors in the vehicle must be taught in. The authentication process then takes all taught-in and available sensors into account.

The following user-specific content and applications are protected, for example:

- User selection and user profile settings
- Biometric sensors The teaching-in of biometric sensors

For teaching in and editing biometric recognition see the following section.

Suggestions

The data and determination of the most probable navigation destinations, media sources, radio stations, contacts and messages.

ENERGIZING COACH

The recorded health data and its evaluation.

- In-Car Calendar The calendar
- Parking service The payment transactions.
- · Mercedes me Store The purchase of services.
- System activations of paid vehicle functions

In the following cases you will be prompted for authentication or re-authentication using a sensor or the Mercedes me PIN:

- When selecting a protected user profile
- When calling a function requiring special protection

- If biometric sensors provide insufficient or contradictory information
- If the multimedia system no longer trusts a sensor
- If the seat belt buckle and the door are opened at the same seat and a function requiring special protection is called up
- Facial recognition for re-authentication in the driver's seat is only possible once the door has been closed or the seat belt buckle has been fastened again.
- Select Protect content.
- Switch Access protection on or off.
- When access protection is switched off, your user profile can be viewed from any seat and changes can be made.
- Access protection is switched on or off on a vehicle-specific basis.
- Please note that authentication is necessary for several functions such as In-Car Calendar and cannot therefore be completely switched

Setting up and editing biometric recognition

The biometric data models are saved in the sensors in the vehicle. If recognition has been set up, this sensor serves as a contributory factor for authentication on the multimedia system.

- Select Protect content.
- Select Facial recognition or Fingerprint recognition.
- i If necessary, authenticate yourself on the multimedia system.

Setting up facial recognition

- Close the driver's door or fasten the driver's seat belt.
- ➤ Follow the system's instructions.
 Your face is scanned. A message in the driver's display or central display shows whether facial recognition was successful or not. You can unlock your user profile and protected applications with the facial scan.

Setting up fingerprint recognition

 Place and lift your finger several times on the fingerprint sensor under the touchscreen (→ page 334).

The finger is scanned. If the scanning procedure is successful, a message appears on the central display. You can unlock your user profile and protected applications with your finger print.

Deleting biometric data

- Tap on , for example, behind Fingerprint recognition.
- Select Yes.

Calling up the set-up assistant

- Select Profile.
- Select Set-up assistant.
- Follow the directions from the set-up assistant.

Changing a user name or profile photo

- Select Profile.
- Select Change user name.

or

- Select Profile picture.
- Enter the user name or select a user image.
- Select Finished.
- You can store your photo in the Mercedes me user account using the app or in the portal.
 The photo will then be shown in the vehicle. In the vehicle itself, you can select other sample images instead of the photo.

Deleting a user profile

- Select Profile.
- Select Remove.
- Select Remove user profile.
- Your Mercedes me user account and your personal data will remain within the Mercedes me ecosystem.

Resetting the user profile to factory settings

- Select Profile.
- Select Reset.
- Select Yes.

This resets the contents of the user profile to factory settings, but not the vehicle.

You can watch an animation on this topic via the following link:

Selecting a user

Multimedia system:



When you call up your driver profile, the driver's seat and the steering wheel can be set.

You can cancel the setting process with the following actions:

- Press Tap here to cancel. message on the central display.
- Press one of the seat operating buttons in the driver's door.
- Select Change user.
- Select a user.
- When requested to do so, authenticate with the Mercedes me PIN or a taught-in biometric characteristic.

The user profile is loaded and activated.

(i) If you select Continue without selecting user, no specific settings for the user profile are loaded.

Synchronising user profiles

Requirements

- You have a Mercedes me user account.
- The vehicle is connected with your Mercedes me user account.

Multimedia system:



Allow synchronisation.

When the vehicle is switched on or off, the data stored in the vehicle is automatically synchronised with the Mercedes me user accounts. This synchronization is done for all user profiles and is not profile-specific.

Select Synchronise now.

After selecting this option, the data stored in the vehicle is synchronised with the Mercedes me user accounts.

- (i) Not all user profile functions are available during synchronization.
- If the personalisation service in the vehicle is deactivated, only the following user profile master data is synchronised:
 - Profile name
 - Profile image
 - Mercedes me PIN

Notifications Centre

Overview of the Notifications Centre

The following communications are collected in the Notifications Centre:

- · Communications which are generated by the vehicle or from the multimedia system.
- Communications which are received through the use of services.

The following notification types are available for vou:

- Navigable destinations and routes
- Messages (text messages)

 Calendar entries and reminders, e.g. from In-Car Calendar

This function is not available in all countries.

- System information, e.g. Important software update available. Confirm to start the update.
- Other notifications, e.g. from additional online services that can be subscribed to or emergency reports (e.g. tornado)

The Notifications Centre is in the Control Center.

Depending on the style set, newly received notifications are shown using a coloured dot.

Notifications are normally briefly shown as they are received. If you take no action, these are stored for future access in the Notifications Centre.

The notifications are sorted chronologically. The most recent notifications are at the top.



Example of a message

- Calls up the Notifications Centre
- Symbol for a pinned notification
- Time message received
- Calls up the settings
- Motification
- Description of the notification and the issuing service

- Symbol for notifications
- Date of the received notifications

Depending on the type of notification, up to four different actions are available. If available these are shown as symbols.

Examples of actions include:

- Reading aloud
- · Placing a call
- Replying
- Calling up a web page
- Navigation

Some notifications, e.g. a navigation destination, are stored longer. Therefore, it is not necessary to carry out available actions directly upon receipt of the notifications. A route guidance can be started at a later time.

You can pin a notification so that this is not deleted automatically after a certain time. The notification is then denoted by symbol ②.

Calling up notifications

Opening the Notifications Centre

In the zero layer pull down bar (3) in the centre of the status line (\rightarrow page 326).

or

- In the home screen pull down bar (4) in the centre of the status line (\rightarrow page 330). The Control Centre opens.
- Select in the Control Center.

Selecting a notification

- If several messages are available swipe up or down.
- Select an action.

Closing the Notifications Centre

Select 5.

Selecting actions for a notification

The following options are available:

 Select the action directly after a notification is received and shown.

- Select the action later after calling up in the Notifications Centre.
- Up to two actions available: select the action.
- More than two actions available: select <.
- Select the action. The notification is still available.
- Close the actions with \supset .

Editing notifications

Call up the Notifications Centre $(\rightarrow page 341)$.

Configuring settings

- Select Settings.
- Select the service.
- Switch the options on or off.

The following options are available depending on the service:

- Allow notifications
- Display in notification centre
- Show notifications
- Switch Acoustic signals on or off

External access

The option allows an external service access to specific data, e.g. the current vehicle position. The detailed, approved information is shown with (1).

If Allow notifications is switched off, the options cannot be selected with the exception of External access.

Pinning a notification

- Drag a notification to the right on the touchscreen.
 - A pin appears.
- Tap on the pin. The notification is marked with a pin.

Deleting notifications


Drag a notification to the left on the touchscreen.

- Select 🔳 .
- Select Yes.
 - All messages are deleted.

Switching the sound for the MBUX multimedia system on or off



On the steering wheel



On the control panel when equipped with MBUX Hyperscreen

To switch off: press button 1. The current audio source is muted. The symbol appears in the status line of the central display.

If you are listening to a radio station, for example, and switch off the sound then all media sources will be muted.

Traffic and navigation announcements can still be heard in this case. The MBUX voice assistant and telephony are also not affected.

Switching on

Press button (1) again.

Set the volume.

or

The media source changes.

Entering characters

Using the character input function

Requirements

- · For the handwriting recognition read-aloud function: the MBUX multimedia system is equipped with the MBUX voice assistant.
- The read-aloud function is available for the selected system language.

The handwriting recognition read-aloud function is activated.

Enter the characters on the Touch Control or on the touchscreen. Character input can be started with a control element and resumed with another.

When the keypad is shown, enter the characters by swiping and pressing on the Touch Control or by tapping on the touchscreen.

If handwriting recognition has been selected, write the characters on the touchscreen.

Examples for character entry include for example, the entry of a navigation destination or a message.


The touchscreen supports character input with the following functions:

- Handwriting recognition offers character suggestions.
- If the read aloud function is activated for handwriting recognition then the entered characters are read aloud.

Entering characters on the touchscreen

Requirements

- If you wish to have the character input read aloud: the read aloud function of the handwriting recognition is switched on (\rightarrow page 344).
- An online connection is required for some functions.



Example: character input with the keypad

- Input line with current entry
- Search result
- Selects destination input, displays further destination inputs with double arrow
- Deletes an entry
- Adopts the search result in the input line and continues the search

344 MBUX multimedia system

- O Deletes the last character entered
- Hides the keypad
- Switches to handwriting recognition
- Starts the MBUX voice assistant (→ page 316)
- Sets the written language
- Switches to digits and special characters
- Switches to upper-case or lower-case letters
- Example: call up the navigation and enter a destination address (→ page 375).
- Briefly press on a character.
 The character is entered in input line ①.
- Resume character input.
- The available editing functions depend on the editing task, the language set and the character level.

Entering alternative characters

- Press and hold on a character.
- Select the character.

Ending character input

Hide keypad ②.



Example: entering characters with handwriting recognition

- Input line
- Shows suggestions during input
- Oeletes an entry
- Last character entered Pressing and holding deletes the entry
- Switches to input using the keyboard

- 6 Enters a space
- Accepts an entry
- Writing area

If available, the symbol allows you to change to voice input.

- ▶ When the keyboard is displayed, select 🦙.
- Write the character with one finger on the touchscreen. The letters can be written next to each other or above each other. The character is entered in input line ①. Suggestions are shown in ②.
- Select one of the suggestions.
- If available, display additional suggestions with or .
- To end character entry: press briefly on 5.

Setting the keyboard and handwriting recognition for character entry

Requirements

• The read-aloud function is available for the selected system language.

Multimedia system:

- → 🔝 >> Settings >> System
- >> Keyboards and handwriting

Setting the keyboard language

- Select Keyboard languages.
- Select one or more keyboard languages.

Setting the writing speed

- Select Handwriting recognition.
- Select an option, e.g. Medium.

Activating the read-aloud function

- Select Handwriting recognition.
- Switch on Read out . The letter that your write on the touchscreen is read aloud.

Activating handwriting recognition on the keyboard

- Select Handwriting recognition.
- Switch on Handwriting recognition . You can write characters directly on the keyboard.

Deleting the user dictionary

The user dictionary learns from your inputs and offers suggestions during character input. You can reset the user dictionary.

- Select Reset my dictionary.
- Select Yes.

MBUX Interior Assistant

Notes on lasers and laser classification

WARNING Risk of injury from the camera's laser radiation

This product uses a classification 1 laser system. If the housing is opened or damaged, laser radiation may damage your retina.

- Do not open the housing.
- Always have maintenance work and repairs carried out by a qualified specialist workshop.

This device is a class 1 laser product in accordance with IFC 60825-1:2014 and DIN FN 60825-1:2014.

The camera records image data for the applications, for example body, head and hand detection.

The camera converts the image data directly into meta data. No image data is saved in the process. The data is processed in the vehicle and is not transmitted from the vehicle. When you start the vehicle, the MBUX Interior Assistant is activated automatically. You can switch the Interior Assistant on or off $(\rightarrow page 352)$.


Overview of the MBUX Interior Assistant

The MBUX Interior Assistant detects the front vehicle occupants via 3D laser cameras in the overhead control panel. The Assistant interprets natural hand, head and body movements contextually or upon the explicit request of the driver or front passenger. The Assistant can thus automatically trigger vehicle interior functions and assist appropriately to the situation.

The Assistant recognises driver and front passenger interactions.

The applications are available under the following conditions:

- The MBUX Interior Assistant is activated (→ page 352).
- The MBUX multimedia system is activated.



Cameras
 are located in the overhead control panel.

The Assistant supports vehicle and infotainment functions at three interaction levels:

INTELLIGENT

The Assistant recognises vehicle occupants and objects automatically and activates functions.

REACTIVE

The Assistant recognises the natural body language of a vehicle occupant and carries out functions automatically, appropriate to the situation.

CONTACTLESS

The vehicle occupant actively requests a function using a hand movement.

The Assistant offers functions for the following:

SAFETY

The Assistant supports vehicle occupants with the use of restraint systems.

COMFORT

The Assistant enhances comfort by automating functions inside the vehicle and supporting natural interaction with the vehicle.

INFOTAINMENT

The Assistant facilitates operation of the Infotainment functions.

System limits, display messages and notes for rectification

(i) System limits that only apply to one application are described in the corresponding section.

The error messages are shown on the central display, for example.

The system may be impaired or may not function in the following situations:

 The camera in the overhead control panel may heat up due to operating conditions. As a result the camera may switch off temporarily, particularly during longer periods of operation and at high outside temperatures.

Do not touch or cover the camera. Wait until the camera has cooled down and is available again.

The Interior assistant unavailable. Notification to follow. message appears.

You receive a message when the camera is available again.

The camera is covered, dirty, misted up or scratched.

Wait until the camera has cooled down before cleaning the camera cover.

The Currently unavailable, see Owner's Manual. message appears.

Clean the outside of the camera cover with a dry or damp cotton cloth. Do not use microfibre cloths. Do not remove the cover when cleaning.

 A vehicle occupant is very large. Clothing being worn (gloves, hat, scarf, colour of clothing) or objects carried on a person, for example a watch with a large display, can affect the camera view. Or the detection range of the camera is restricted.

The Interior assist. only available to driver to limited extent, see Owner's Manual message appears.

Keep the camera's field of vision clear.

Objects in the detection range of the camera can restrict the camera view. Please make

sure that no objects hang on the inside rearview mirror, for example.

The MBUX Interior Assistant is faulty.

The Interior assistant is unavailable. Please contact a Mercedes-Benz workshop, message appears.

Consult a Mercedes-Benz service centre.

The three types of interaction:

Type of interaction	Description and example of application
INTELLIGENT	The Assistant detects the presence of vehicle occupants and objects. Depending on the situation, functions are carried out automatically. Example of application: prompt about fastening the child seat (safety)
REACTIVE	The natural body language of a vehicle occupant, e.g. a hand or head movement, is recognised and triggers a function implicitly. Example of application: switching the search light on or off (comfort)
CONTACTLESS	The vehicle occupant triggers a function by actively demanding this with a hand movement. Example of application: opening and closing the sliding sunroof and roller sunblind (Comfort)

You can watch an animation on this topic via the following link:

Anticipatory exit warning (SAFETY/reactive)

Requirements

• The vehicle is equipped with Active Blind Spot Assist with exit warning.

- Active Blind Spot Assist is activated (→ page 258).
- The vehicle is equipped with active ambient lighting or ambient lighting.
- Observe the information on the system limits of Active Blind Spot Assist with exit warning (→ page 255).

The function can warn vehicle occupants about a possible collision with an approaching vehicle or bicycle when they exit the vehicle.

As soon as the driver or front passenger moves their hand towards the door handle, depending on the vehicle equipment, the following warnings are issued:

 The active ambient lighting or ambient lighting flashes red.

- The warning lamp in the outside mirror also flashes red for one of the front doors.
- When the door is opened, a warning tone sounds.
- The visual warning is thus already given **before** the door is opened.
- (i) Further information on Active Blind Spot Assist with exit warning (\rightarrow page 255) and on ambient lighting (\rightarrow page 160).

Notes on fastening the child seat (SAFETY/intelligent)

The MRUX Interior Assistant detects child restraint systems on the front passenger seat. If a child restraint system is not fastened, e.g. a rearward-facing child seat, a message appears on the central display.

The function assists you in making sure that a child restraint system is secured with the seat belt on the front passenger seat.

 For further information on securing a child restraint system with the seat belt on the front passenger seat (\rightarrow page 71).

The MBUX Interior Assistant cannot check whether the child is correctly restrained in the child restraint system.

Switching the reading light on or off (COMFORT/ contactless)

Requirements:

• The driver's and front passenger's hand movement takes place under the inside rearview mirror.

A brief movement of the hand up and down, switches the reading light on or off.



Carrying out operation of the reading light for the driver and front passenger

- Move your hand up and down under the inside rearview mirror. The reading light is switched on or off.
- Further information on switching the reading lamps on and off (\rightarrow page 159).

Switching the search light on or off (COMFORT/ reactive)

Requirements:

 The function is available in the vehicle when it is dark.

- The front passenger seat is not occupied or a child is sitting in a child restraint system.
- The hand movement is made by the driver in the interaction area above the front passenger seat.

The function enhances the comfort in the vehicle interior.

Stretching out a hand over the front passenger seat switches a search light on automatically for the driver when it is dark. Pulling the hand back switches the search light off again.



Interaction area for activation of the search light

Automatic preselection of the outside mirrors (COMFORT/reactive)

Until now, to set the outside mirrors the desired mirror had to be selected using a preselection button in the driver's door.

With the MBUX Interior Assistant, the mirror to be set is preselected automatically by the natural movement of your head to the left or right. When the hand touches the button for adjusting the outside mirror, the LED under the button of the preselected mirror side lights up.

Use the button to set the position of the active outside mirror.

- Preselection of the outside mirrors using buttons is still possible. Further information on adjusting the outside mirrors (→ page 164).
- The driver camera is also used for this application.
 Further information on the driver camera (→ page 352).
- i This function is not supported if the MBUX Interior Assistant is not available.

Opening or closing the roller sunblind on the rear window (COMFORT/reactive)

Requirements

- The vehicle is equipped with a roller sunblind for the rear window.
- · Reverse gear is engaged.

If the driver glances back over their shoulder in the direction of the rear window, the roller sunblind opens automatically.

If the roller sunblind was closed before reversing, it will be closed automatically in the following situations:

- Park position P is selected.
- The vehicle exceeds a minimum speed when moving forward.

The function facilitates a good view when reversing, e.g. when parking, and reduces the number of operating steps.

 i) Further information on opening and closing the roller sunblind on the rear window (→ page 107). This function is not supported if the MBUX Interior Assistant is not available.

Opening and closing the sliding sunroof and roller sunblind (COMFORT/contactless)

Requirements

- The vehicle is equipped with a panoramic sliding sunroof.
- · Always operate directly under the overhead control panel.
- The doors are closed.
- The vehicle is switched on.

Opening the roller sunblind and sliding sunroof The MBUX Interior Assistant allows contactless operation of the roller sunblind and the sliding sunroof. The functions are available to the driver and front passenger.



Possible hand position at the beginning of the opening of the roller sunblind and sliding sunroof

Extend your hand upwards and hold it in front of the inside rearview mirror. The palm of the hand can face forward or backward.



Hand movement to operate the roller sunblind and sliding sunroof

- Move your hand away from the inside rearview mirror directly under the overhead control panel to the rear and out of the area again. The roller sunblind opens.
- When the roller sunblind is open, repeat the hand movement. The sliding sunroof opens.

Closing the roller sunblind and sliding sunroof

Extend your hand upwards and move it forward to the inside rearview mirror directly under the overhead control panel and out of

the area again. The palm of the hand can face forward or backward.

The sliding sunroof closes.

- When the sliding sunroof is closed, repeat the hand movement.
 The roller sunblind closes.
- To cancel opening or closing: move your hand under the overhead control panel. The opening/closing process will be stopped.
- (i) Further information on opening and closing the sliding sunroof and the roller sunblind (→ page 102).
- i This function is not supported if the MBUX Interior Assistant is not available.

Selecting settings for the MBUX Interior Assistant

Multimedia system:

- Switching the MBUX Interior Assistant on or off

Activate or deactivate the Assistant.

If the Assistant is activated, full functionality is used.

Driver camera

Overview of the driver camera

WARNING Risk of injury from infrared radiation from the camera

This product uses an infrared lighting system of risk group 0 (RG0). If the housing is opened or damaged, infrared radiation may damage your retina.

Do not open the housing.

Always have maintenance work and repairs carried out by a qualified specialist workshop.

This device is a product of risk group 0 (RG0) according to IEC 62471: 2006 (First Edition) & DIN FN 62471: 2008.

Depending on the equipment, the driver camera is located either in the driver's display or in the nozzle strip.

The driver camera is available either as a mono or a stereo camera.

The driver camera detects the following characteristics:

- Head position
- Viewing direction
- Eyelid closure characteristics
- Driver's face
- i) The driver camera is automatically activated each time the vehicle is opened with the key. The current status of the driver camera is shown in the status line of the central display.

The driver camera records image data for applications such as ATTENTION ASSIST and facial recognition, for example. The driver camera converts the image data directly into meta data. No image data is saved in the process. The data is only pro-

The driver camera must be set up for facial recognition before use (\rightarrow page 337).

cessed in the vehicle and is not transmitted

System limits

from the vehicle.

The system may be impaired or may not function in the following situations:

- · The driver camera is covered or dirty, misted up or scratched.
- The driver's face and/or eyes are covered.
- The driver is wearing glasses that block infrared.

Display messages

In the following situations display messages may be shown:

• If the driver camera is not functioning.

The driver camera is malfunctioning.

The Driver camera inoperative See Owner's Manual message appears.

 If the driver camera cannot capture the position of your head.

The Change steering wheel/ seat position until 6 dots are visible on the upper edge of the screen message appears.

 If the view of the driver camera is reduced or restricted.

The The camera's view of the driver is currently impeded Affected functions: see Owner's Manual message appears.

The message can appear, for example, in the following cases:

- The camera's view is obstructed, e.g. due to a scarf or hat being worn.
- The driver is wearing glasses that block infrared.
- If hair partially obstructs the eyes, e.g. as with a long fringe.

- In the event of strong direct sunlight. The driver camera cannot detect the driver's eyes if the light-dark contrast is too strong.
- When one hand or both hands are on top of the steering wheel (twelve o'clock position).

Notes on care

Please comply with the notes on caring for the interior (\rightarrow page 482).

Switching the driver camera on or off

Multimedia system:

→ Settings → System

>> Intelligent assistants

The driver camera is automatically activated each time the vehicle is switched on.

Select On or Off.

When the driver camera is switched off or the The camera's view of the driver is currently impeded Affected functions: see Owner's Manual message appears, the following functions are not available or limited:

- The 3D driver display (only for stereo camera)
 (→ page 304)
- The microsleep and distraction detection function of ATTENTION ASSIST (→ page 222)
- The facial recognition

This function serves as sensor input for authentication and unlocking of the user profile and protected applications (\rightarrow page 337).

The mirror preselection
 This function allows the natural movement of the head to the left or right to automatically preselect the outside mirror to be adjusted.
 (→ page 164)

System settings

Display

- Configuring display settings
 Multimedia system:
- → Settings → System → Display

Adjusting the brightness

- Select Display brightness.
- Vehicles with a driver's display and central display: Adjust the display brightness of the driver's display or central display.
- Vehicles with the MBUX Hyperscreen: Adjust the display brightness of the driver's display, central display or the front passenger display.

Switching the head-up display on/off

Switch the head-up display on or off.

Setting the decorative image for the front passenger display (vehicles with MBUX Hyperscreen)

i The function is country-dependent.

- Select Screensaver, passenger display.
 A selection of decorative images is displayed.
- Select the desired decorative image.
- i) The number of available decorative images is variable.
- i If no user is logged in to the front passenger display and the front passenger display is switched on, the decorative image is visible.

Time and date

Setting the time zone

Multimedia system:

- → 🔝 **>>** Settings **>>** System
- >> Time and date
- Select Time zone.
 The list of countries is displayed.
- (i) If there are several time zones available in a country, these will be shown after the country is selected.
- Select a country and, if required, a time zone. The time zone set is displayed after Time zone.

or

- Select the Automatic time zone entry from the country list.
 - The time zone will be set automatically according to the vehicle location.
- (i) The Automatic time zone option is available for vehicles with satellite reception.
- Setting the time and date format Multimedia system:
- → Settings → System
- >> Time and date >> Set format
- Select a time and date format.
- Setting the time and date manually Requirements:
- The vehicle does not have satellite reception.

Multimedia system:

- → Settings → System
- >> Time and date

Setting the time

Select Set time.

- Set a time.
- Press OK to confirm.

Setting the date

- Select Set date.
- Select a date.
- Press OK to confirm.
- On vehicles with satellite reception, the time and date settings are determined automatically based on the vehicle location and cannot be set manually.

Adjusting the time

- Select Adjust time.
- Set a value.
- Press OK to confirm.
- The function is only available in vehicles with satellite reception.

Vehicle position

Switching transmission of the vehicle position on or off

Requirements

- A Mercedes me user account is available.
- · At least one service is activated in the Mercedes me user account which has access to the transmitted position data.
- The function is country-dependent. For more information, consult a Mercedes-Benz service centre.

Multimedia system:

- → Settings → System
- >> Data protection
- Activate or deactivate the Transmit veh. position function.
- Alternatively, you can also switch the function on or off in the status line via \mathfrak{S}_{\bullet} .

Setting permissions

Multimedia system:

→ Settings → System ▶ Data protection ▶ Permissions

In the Permissions menu, you can set access permissions for various data points (such as microphone, camera) used in an application. You can change permissions that have already been granted here. You can set permissions either for individual data points or for certain applications or websites.

- Select Requests or Apps/websites.
- Make the required settings for the permissions.

Bluetooth®

■ Information about Bluetooth®

Bluetooth® technology is a standard for shortrange wireless data transfer up to approximately 10 m.

You can use Bluetooth® to connect your mobile phone to the multimedia system and use the following functions, for example:

- · Hands-free system with access to the following options:
 - Contacts (→ page 418)
 - Call lists (\rightarrow page 420)
 - Text messages (\rightarrow page 421)

Bluetooth® is a registered trademark of Bluetooth Special Interest Group (SIG) Inc.

Activating/deactivating Bluetooth® Multimedia system:

→ Settings → System > Internet and Bluetooth

Switch Bluetooth on or off.

Wi-Fi

■ Wi-Fi connection overview

You can use Wi-Fi to set up a connection to the Internet or to external network devices.

(i) The availability of the function is dependent on the country.

Generally, two types of Wi-Fi connection are available:

 Using the multimedia system as a Wi-Fi hot**spot** (\rightarrow page 357)

The vehicle's multimedia system serves as Wi-Fi hotspot for mobile communication devices, such as smartphone or tablet PC, for example.

Using a mobile communication device as a Wi-Fi hotspot (tethering) (\rightarrow page 447)

An external Wi-Fi hotspot is accessed for the Internet connection of the vehicle's multimedia system.

Switching Wi-Fi on or off Multimedia system:

→ Settings → System

> Internet and Bluetooth

Select Wi-Fi.

The controller is to the right: Wi-Fi is switched on.

When Wi-Fi is switched on, you can connect the multimedia system with external hotspots or make it available as a hotspot for external devices.

When Wi-Fi is switched off, it is not possible to establish a hotspot connection.

- The availability of the function is dependent on the country.
- Using the multimedia system as a Wi-Fi hotspot

Requirements:

- The device to be connected supports at least one of the types of connection described. The connection types shown depend on the device to be connected. The function must be supported by the multimedia system and by the device to be connected. The type of connection established must be selected on the multimedia system and on the device to be connected.
- The data volume of the vehicle or an already connected tethering device is used for the data connection. Vehicle data volumes: Depending on the vehicle equipment, you can purchase a data pack-

age directly from a mobile phone network provider via the Mercedes me Store. To be able to use the data package, you conclude a separate contract with a mobile phone network provider via the Mercedes me Store, which can be terminated at any time and for which there are no costs. This contract is a prereguisite for using the services from the previously purchased package. The availability of this option is dependent on the country. If the data package option is not available or can be upgraded, you can purchase data volume directly from the mobile phone network provider for a fee.

- (i) Some functions may first need to be activated on the device being connected. More detailed information can be found in the manufacturer's operating instructions.
- (i) The use of the vehicle data tariff by external devices is not available in all countries.

Multimedia system:

- ¬→ 📊 >> Settings >> System >> Internet and Bluetooth
- Select MBUX hotspot.

Select one of the following connection options.

Connecting using a QR code

Requirement: an app for scanning the QR code is installed on the device being connected.

Alternatively: the device being connected has an integrated QR code scanner (see manufacturer's operating instructions).

Scan the QR code shown. The Wi-Fi connection is established.

Connecting using a security key

- Select the vehicle from the device to be connected. The vehicle is displayed with the MBUX XXXXX network name.
- Enter the security key which is shown in the central display on the device to be connected.
- Confirm the entry.

Generating a new security key

- Select the Generate new security key option in the MBUX hotspot menu.
- Confirm the prompt with Yes. A new security key is generated.

A connection will be established with the newly created security key.

 When a new security key is generated, all existing Wi-Fi connections are then disconnected. If the Wi-Fi connections are being reestablished, the new security key must be entered.

System language

Notes on the system language

This function allows you to determine the language for the menu displays and the navigation announcements. The selected language affects the characters available for entry. The navigation announcements are not available in all languages. If a language is not available, the navigation announcements will be in English.

Setting the language

Multimedia system:

→ Settings → System → Language

Setting the system language

A list of the available system languages is shown.

Select a language.

The system language is switched to the selected language.

Setting the distance unit

Multimedia system:

- → Settings → System → Display
- i This function is not available in all countries.
- Select Units.
- Select a unit for the distance.
- For an additional display in the driver display of the instrument cluster, switch Additional speedometer on.

Activating/deactivating system PIN protection

Multimedia system:

→ 🔝 ➤ Settings ➤ System

▶ Data protection ▶ PIN protection

Setting the system PIN

Select Set PIN.

- Enter a four-digit system PIN.
- Enter the four-digit system PIN again.
 If both system PINs match, then the system PIN protection is active.

Changing the system PIN

- Select Change settings.
- Enter the current system PIN.
- Select Change PIN.
- Set a new system PIN.

Activating system PIN protection for software updates

- Select Protect software updates.
- Activate or deactivate the function.

Configuring suggestions

Multimedia system:

→ Settings → System

Suggestions

Activate or deactivate Learning & suggestions.

If the user profile is active and the function is switched on, personalised suggestions can be derived for activated applications.

- Select 🔼.
- Switch the options on or off individually. If an option is switched on and sufficient data has been gathered, personalised suggestions based on your user behaviour will be offered to you. These are, for example, navigation destinations visited, phone numbers dialled as well as suggestions based on your music preferences.

Navigation

When Allow destination suggestions is switched on, the vehicle makes suggestions based on your visited navigation destinations. If Activate commuter route is switched on, the navigation automatically detects that the vehicle is on a commuter route.

Calls & messages

Suggestions are offered for numbers dialled and messages sent.

Comfort

The vehicle makes suggestions based on the use of your comfort functions, e.g. which massage programme should be started at what time.

Entertainment

Suggestions are offered for the currently played media source. Suggestions are also made for online digital services, e.g. Spotify, TuneIn Radio and streaming services, and for categories, e.g. genre, artist and mood.

Climate control

The suggestions for quick temperature adjustment in the vehicle are displayed.

Vehicle

The suggestions for vehicle functions are displayed, e.g. for Parking Assist PARKTRONIC and for opening the boot.

In-Car Calendar

The suggestions for the calendar are displayed in the zero layer.

Online voice services

The suggestions are made available online based on your voice input and are offered on the zero layer.

The suggestions offered depend on the equipment.

Deleting collected suggestions

Multimedia system:

- ¬→ 🔝 >> Settings >> System
- Suggestions
- Select 3.
- Select Yes.
 - The suggestions are reset.

Software update

Information on software updates

ted systems up-to-date and prevent security flaws. Software updates are available for vehicle components such as control units, convenience systems, locking and safety systems, driver assistance systems, suspension and drive systems as well as for the MBUX multimedia system. Software updates are available via the communication module or a

Software updates keep your vehicle and the rela-

The navigation maps are also updated via updates from external storage media (e.g. USB flash drive). Install available software updates regularly. Otherwise the security of your MBUX multimedia system and individual vehicle components cannot be ensured.

Wi-Fi connection to an external hotspot.

(i) Software updates can be protected with a system PIN. Further information about the system PIN (\rightarrow page 358).

Further information about software updates can be found at https://me.secure.mercedesbenz.com.

Carrying out software updates

Requirements

For software updates via the communication module and Wi-Fi:

- Your vehicle is linked to a Mercedes me user. account (\rightarrow page 435).
- Software updates without Mercedes me user account: The Allow software updates option is activated in the Software update menu.
- For software updates via the communication module: an Internet connection exists via the communication module (\rightarrow page 446).
- For software updates via Wi-Fi: a connection to an external Wi-Fi hotspot exists $(\rightarrow page 447)$.
- Depending on the software update, this is started via the communication module, Wi-Fi or external storage medium.
- Online software updates cannot be performed via external Wi-Fi hotspots that are encrypted via TKIP.

If the Wi-Fi hotspot requires logging in via the browser, once the connection is successfully established the browser will open in order to start the update. Follow the instructions in the browser in order to start the download.

Multimedia system:

→ Settings → System

▶ Software update ▶ □

Starting a map update from an external storage medium

- Connect the storage medium with the vehicle via a media interface. A message about an available map update appears on the central display.
- Select the message.
- Select Start. The map update is started.

Starting the software update via the communication module

If the Automatic online update option is active, available software updates are downloaded and installed automatically. Activate the option in

order to always keep your vehicle up-to-date and avoid security flaws.

Select Automatic online update. The software update is downloaded and installed automatically.

If the option is deactivated, you will be informed of new software updates once. The updates are available for downloading for a limited period of time.

- Select an update from the list of available updates.
- Start the update. The software update is downloaded and installed automatically.

Starting a software update via Wi-Fi

Some software updates require an additional connection to a Wi-Fi hotspot. The connection to an external hotspot can be established when the software update is started.

- Select an update from the list of available updates.
- Start the update.

Establish the connection to a Wi-Fi hotspot. The update is downloaded and installed automatically.

For software updates requiring a safe vehicle status: when the last installation step is reached, a message appears on the central display after the vehicle is switched off. Follow the step-by-step instructions on the central display to complete the installation.

There are software updates that can only be installed when the vehicle is safely parked, there are no more people in the vehicle and the vehicle is locked.

Installing software updates

Software updates are installed automatically after they are downloaded. As soon as the software update has been completed, a message appears in the central display. It may be necessary to restart the MBUX multimedia system.

Some software updates require a safe vehicle status for the installation to be completed. They can only be carried out in a safely parked vehicle with the vehicle switched off. If this is necessary, a

message appears on the central display after the vehicle is switched off.

Follow the instructions on the central display.

For some software updates, you can set a time for installation. The installation is carried out automatically at the scheduled time. You do not need to be in the vehicle during installation. Note that the planned installation is cancelled as soon as the vehicle door is opened.

If an installation is available where you can set the time, a message appears on the central display after the vehicle is switched off.

Follow the instructions on the central display.

The vehicle cannot be used while these software updates are being installed. Make sure that no persons or animals are in the path of your vehicle. Events stored in the vehicle's control units can be overwritten.

Availability of the driver's and central display

During the installation of software updates, it is not possible to use the vehicle, driver's display and central display. You may receive the following display messages when an installation is running:



The display message does not appear every time a software update is installed.

In rare cases, an error can occur during the installation. The multimedia system automatically attempts to restore the previous version.

If it is not possible to restore the previous version, the display message shown above appears every time the vehicle is started.

Failure of the driver's display:

If the driver's display fails or there is a malfunction, you may not recognise limitations in the functions of systems relevant to safety or the speed display, for example. The operating safety of the vehicle may be impaired. Drive on carefully and have the vehicle checked at a qualified specialist workshop immediately (\rightarrow page 668).

Further information about software updates can be found at https://me.secure.mercedesbenz.com

Failure of the central display:

If the central display fails or the display message shown above is shown continuously, several systems such as the reversing camera, PARKTRONIC or climate control are no longer available. Drive on carefully and consult a specialist workshop as soon as possible.

Front passenger display failure (only vehicles with MBUX Hyperscreen):

If the front passenger display has failed or a display message appears permanently, functions and systems are no longer available via the front passenger display. Visit a qualified specialist workshop.

Resetting the multimedia system (reset function)



WARNING Risk of accident due to failure of central display functions

While the multimedia system is reset, its functions, such as the reversing camera, are not available.

Only reset the multimedia system when the vehicle is stationary.

Requirements

- The vehicle is switched on.
- Some settings can only be reset when the vehicle is stationary.

Multimedia system:









When resetting the system, personal data and settings are deleted, for example:

- Connected devices
- Individual user profiles
- Biometric data

- Vehicles with rear telephony: handset connection
- The data used and saved in the multimedia. system by the driver assistance systems is deleted.
- Vehicles with rear telephony: The handset must be in the cradle while the system is reset.
- Select Reset.

A query appears asking if the system should really be reset.

Select Yes.

The multimedia system is reset to the factory settings. The multimedia system is restarted after the system reset.

Due to data protection, as well as the function of individual driving systems and driving safety systems, it is a requirement to carry out a complete system reset before selling the vehicle or transferring it to a third party, or after use as a hire car.

AMG TRACK PACE

Function of AMG TRACK PACE

This function is an on-demand feature $(\rightarrow page 25)$.

With AMG TRACK PACE, the driving characteristics on race tracks can be analysed and optimised. You can drive previously saved race tracks (e.g. Hockenheimring), or record and save new tracks. The driven lap times are stored for every track. These can be analysed and compared to other lap times to achieve the best possible race results. Additionally, acceleration and braking manneuvres can be measured and stored

Note: Use AMG TRACK PACE only on closed-off routes outside the public traffic area. Adapt your driving style to your personal performance and environmental conditions. As the driver, you alone are responsible for driving your vehicle. Park your vehicle safely before operating the application.

Setting Track Race

Multimedia system:

TRACK PACE ► Track Race

Recording a new track

- Select New track.
- Select Start Record. at the desired starting point. The track recording starts at this point.

During track recording, sectors can be set to divide up the track.

- Select Set Sector.
- Select Stop Recording to end track recording or cross the starting line again.
- Confirm the prompt with Yes.
- Select the weather.
- The temperature is determined automatically.
- Enter a name.
- Press **OK** to confirm. The track is saved under the name entered.

Searching by track name

- ► Select Search.
- Enter the desired track name.
 Tracks with the searched name are displayed.

Measuring time on a saved track

- ► Select All tracks.
- Select the desired track.
- Select Start timing if you are already at the starting line.

or

Select Navigate to for navigation to the starting line.

Timing begins automatically when the starting line has been crossed.

- Select Stop timekeeping to end timekeeping.

- Confirm the prompt with OK.
- Select the weather.
- Select Yes to save the times driven for this track.

Showing readings during Track Race

The following readings can be shown:

- Tyre temperature
- Miniature map
- · Sector overview
- G-force display
- Lap overview
- Select Start timing.
- ➤ Select ■■■.
- Drag the desired display from the grid on the left or right edge of the central display.
 The readings are shown during the Track Race.

By selecting $\stackrel{\times}{}$ on the active display, you can deactivate this.

Displaying the analysis

- ➤ Select All tracks.
 An overview of all the driven tracks appears.
- Select a track.
- Select a session.

The following data are displayed:

- · Lap and sector times
- Average and top speed
- Driver
- Vehicle
- Date
- Weather
- Select Add recording to use a different session as a reference value.
- Select Diagram.
- Set the desired parameters.
 - The analysis is displayed.



- Lap overview
- Parameter overview
- Editing parameters
- Deleting parameters
- Adding new parameters
- The following values can be set for the parameters, for example:
 - Speed

- Longitudinal/lateral acceleration
- Steering angle
- Engine speed
- Engine oil/tyre temperature

Based on the analysis, you can check and optimise the driving behaviour for any position on the track.

Exporting tracks (USB)

- Select 2 Tracks. An overview of all stored tracks appears.
- Select the desired track.
- Select options of the desired track.
- Select Export track to.... The selected track can be exported to a USB storage device connected to the vehicle.

Editing tracks and recordings

- Select Tracks.
- Select the desired track.
- Select options for the desired track.
- Select Rename or Delete.

- Select a track.
- Highlight the desired recording.
- Select options.
- Select Exporting to... or Delete.

Setting Drag Race

Multimedia system:

→ TRACK PACE → Drag Race

Measuring acceleration

- Select Drag race options.
- Select Acceleration.
- Set a starting speed or select Automatic. Measurement begins as soon as the specified starting speed has been reached.
- Set a target speed. Measurement stops as soon as the specified target speed has been reached.
- Start off and begin the measurement. Measurement begins when the vehicle accelerates.

Measurement can be stopped early by interrupting the acceleration manoeuvre.

Quarter mile race

- ▶ Select Drag race options.
- Select Quarter-mile.
- Set a target distance.
 Measurement stops as soon as the specified target distance has been reached.
- Start off and begin the measurement. Measurement begins when the vehicle accelerates. Timing runs until the target distance or a maximum of one mile has been covered.

Measurement can be stopped early by interrupting the acceleration manoeuvre.

Measuring braking

- Drag Race options
- Select Braking.
- Set a starting speed or select Automatic.
- Start off and begin the measurement.

Brake to a stop.

Measurement is carried out in increments of 10 km/h to a stop. If the braking manoeuvre is started e.g. at a speed of 157 km/h, measurement starts as soon as 150 km/h has been reached

Storing and calling up measured values

If measurement is completed or cancelled, a prompt appears asking whether the measurement should be saved.

Confirm the prompt with OK to save.

Calling up saved measurements

- Select History.
- Select Acceleration, Quarter-mile or Braking.
- Select a measurement.
 The desired measurement is displayed in detail.

or

Delete a measurement.

Calling up the telemetry display

Multimedia system:

→ TRACK PACE → Telemetry

The telemetry display shows current vehicle data as a digital value and as a diagram. Up to four parameters can be selected to be shown on the display.

For example:

- Engine speed
- Wheel angle
- Speed
- Steering angle
- Set the parameters.
- Set the time.

The set parameters are evaluated in the diagram for the selected time.

Configuring AMG TRACK PACE

Requirements

To connect a mobile device to the TRACK PACE app:

- The TRACK PACE app must be installed on the mobile end device.
- The mobile end device must be connected to the multimedia system via Wi-Fi $(\rightarrow page 356)$.

Multimedia system:



Connect mobile device via the TRACK PACE app The TRACK PACE app makes it possible to record videos and to synchronise them with stored tracks.

- Select TRACK PACE App.
- Select Authorise new device.
- Start the TRACK PACE app on the device to be connected.
- Select Continue and confirm the authorisation prompt.
 - A four-digit code is shown on the central display.
- Enter the code on the smartphone. The device is authorised.

De-authorising the mobile device

- Select TRACK PACE App.
- Select a device.
- Confirm the message prompt with Yes. The device is de-authorised.

Setting the TRACK PACE display on the head-up display and driver's display

- Select IC and HUD contents.
- Activate or deactivate the desired contents. The contents on the head-up display and the driver's display are adapted.
- For further information on the Head-up Display (\rightarrow page 312).
- Further information about the driver's display $(\rightarrow page 304)$.

Setting acoustic feedback

- Select Acoustic feedback. A scale with values from 0 to 10 is shown.
- Select a setting.

Displaying statistics

Select TRACK PACE statistics. Statistics on the current user profile are displayed.

The following data are displayed:

- Driving time
- Track driven
- Recorded tracks
- Recorded Track Races
- Laps recorded
- Recorded Drag Races
- Maximum design speed

Activating the ambient light

If this function is active, the vehicle interior is lit in red or green depending on delta time.

- Select Ambient light.
- Activate or deactivate the function.

Adjusting the dashcam

If the vehicle is equipped with a dashcam, it can be used in AMG TRACK PACE.

- Select Dashcam.
- Select Track Race or Drag Race and activate Activate recording.
- You can set which overlay is to be used in the recorded video under Video overlay contents.

Fit & Healthy

Setting ENERGIZING seat kinetics

Requirements

These functions are available only for fully electric seats with a memory function.

Multimedia system:

- → 😭 >> Comfort >> Seat
- Select Seat kinetics.

ENERGIZING seat kinetics can support back health by changing the seat position during a journey. This involves repeatedly stressing and relieving the muscles and joints by means of minor movements of the cushion and backrest.

Starting seat kinetics

Select for the desired seat.

The programme will run for the set duration.

Configuring seat kinetics

- Select of for the desired seat.
- Select Backrest, Backrest & seat surface or Seat surface.
- Select the desired duration for the selected seat.

Vehicles with a multicontour seat:

In addition to the seat backrest and seat cushion, the lumbar region can be activated for the function.

Activate or deactivate Including lumbar.

ENERGIZING COMFORT

- Overview of ENERGIZING COMFORT programs
 You can watch an animation on this topic via the following link:
- (i) Note that the available programs and the associated functions depend on your vehicle

equipment. Depending on your equipment, fewer functions may be available.

Program overview

- Refresh: Can have a refreshing effect with short, cool puffs of air. The seat is ventilated, the vehicle interior is illuminated with cool colours and the program is completed with appropriate sound. In addition, the vitalising movement in the cushions can loosen the muscles.
- Warmth: Can increase the comfort level for the vehicle occupants. Seat, surface and steering wheel heating provide soothing warmth. The program is completed with unobtrusive sound and warm colours.
- Vitality: Can counteract diminishing attentiveness in monotonous driving situations. The activating stimulation of the vehicle occupants is carried out with invigorating sound, activating light and a vitalising movement.
- Joy: Can promote a positive mood in the vehicle occupants as well as mental regeneration.
 This results from the activation of a massage

program, friendly sound and illumination with suitable colours.

- Well-being: Can help relax the vehicle occupants. This results from a relaxing hot-stone massage program, friendly sound and illumination with suitable colours.
- Forest Glade: Can have a calming and soothing effect on the vehicle occupants thanks to the acoustics of the forest. The ambience is supported by a suitable animation, colours and sound.
- Sounds of the Sea: Can contribute to calming the vehicle occupants. The acoustics of the sound of waves and seagulls in combination with other vehicle functions create a relaxing seashore atmosphere.
- Summer Rain: Can help relax the vehicle occupants. The relaxing effect of a rain shower can be experienced via acoustics and other vehicle functions inside the vehicle.
- Anti-travel sickness (only front passenger): Can help to prevent, mitigate or delay symptoms of travel sickness. The light, sound and animation are adapted accordingly. The air-

conditioning system and the seat cushion are actively targeted. The effect can be enhanced by manually tilting the backrest back slightly. At the end of the program, the seat cushion and the backrest are automatically returned to their original position.

- Power Nap: The program consists of three phases.
- Falling asleep phase: here relaxing music is played.
- Sleep phase: the active functions are deactivated or restricted as much as possible.
- Waking phase: here slightly stimulating music is played. Additionally, functions such as seat ventilation and massage are activated.
- **Training:** Can counteract the onset of muscle tension, limbs falling asleep or stress with targeted relaxation or stimulation exercises. The exercises are demonstrated in short videos. The training consists of audio content and a

brief animation. The audio content is conceived so that it can also be played back when you are driving. Animations are only shown when the vehicle is stationary. Always observe the traffic conditions if you are training when driving.

• Tips: The system gives auditory tips for possible exercises or measures for improving the comfort level of the vehicle occupants. By selecting the desired area of the body you can receive targeted tips for the comfort level of this area.

Most programs that have been started for one seat can also be transferred simultaneously to another seat.

Starting the ENERGIZING COMFORT programme

WARNING Increased risk of accidents when using the ENERGIZING COMFORT programmes Tips and Training

The Tips and Training ENERGIZING COMFORT programmes can distract you when driving.

Only carry out exercises if the traffic situation permits.

- When listening to the tips, make sure you are aware of the traffic around you at all times.
- ▲ WARNING Risk of entrapment when using the ENERGIZING COMFORT programme Power Nap

With the Power Nap ENERGIZING COMFORT programme the following systems are moved automatically if required:

- Seats
- Side windows
- Sliding sunroof
- Roller sunblinds

This can cause you or another vehicle occupant to be trapped.

- Make sure that there is sufficient space behind the front seats.
- Make sure that no body parts are in the areas of movement.

WARNING Increased risk of accidents due to an incorrect seat position when using the Motion sickness prevention ENERGIZ-ING COMFORT programme for the front passenger

The Motion sickness prevention programme is only available for the front passenger. Improper adjustment of the seat position increases the risk of injury in the event of an accident.

- When adjusting the seat backrest to a slightly flatter position, always maintain a basically upright sitting posture. Never adopt a reclining sitting posture while driving. Further information on occupant safety.
- Always ensure correct belt routing, especially in the shoulder and hip area. Observe the information on the protective potential of the restraint systems and the correct belt installation in this Owner's Manual.
- If necessary, correct the seat adjustment (fore-and-aft adjustment, backrest incli-

- nation). If in doubt, do not use a flatter backrest position.
- The responsibility for seat position and belt routing always lies with the vehicle occupant.
- WARNING Increased risk of accidents when using the Motion sickness prevention ENERGIZING COMFORT programme for the front passenger with a child restraint system

The Motion sickness prevention programme is only available for the front passenger. If the programme is used improperly in conjunction with child seats and booster seats there is an increased risk of injury in the event of an accident.

- Make sure that no child seats or booster seats are installed in the vehicle.
- The programme may not be used as long as child seats and booster seats are in use.

Requirements

The vehicle is switched on.

For the start of Power Nap:

- Only the power supply is on.
- The doors are closed.
- The vehicle is secured against rolling away.
- The state of charge of the high-voltage battery is sufficient for the use of the auxiliary climate control.

Multimedia system:

→ Comfort

>> ENERGIZING COMFORT

Starting and stopping a programme

- Select a programme.
- Select for the desired seat.
- Select to stop the program.
- If, during an active programme, a function requirement is no longer met, a corresponding message appears. The active programme is cancelled.

Starting a Power Nap

- Select Power Nap.
- Select for the desired seat.

When the vehicle is stationary, the following actions are carried out when Power Nap is started:

- The roller sunblinds are extended.
- The doors are locked.
- The windows and sliding sunroof are closed.
- · The seats are moved into the fully reclined position.
- The parking brake is applied.
- Select to stop the program.

Starting the training programme

- Select Training.
- Select a programme .
- Select **t** o stop the training programme.
- The animations demonstrating the exercises are faded out when the vehicle is in motion and you only hear the instructions.

Starting tips

- Select Tips.
- Select a region of the body.
- Select **t** o stop playback of the tip.

ENERGIZING apps

Functions of the ENERGIZING app

Function of the ENERGIZING COACH

Requirements for use of the ENERGIZING COACH

- The ENERGIZING COACH service is activated in the Mercedes me portal or the Mercedes me App.
- The Mercedes me ENERGIZING app is installed on the mobile phone to use the service.

With ENERGIZING COACH you can evaluate the driving and driver situation. Depending on the situation, it offers recommendations for the start of an appropriate ENERGIZING COMFORT programme.

The following programmes could be suggested:

Vitality

As an activating programme in monotonous driving situations or for long journey times, for example

Information on the vitality program see $(\rightarrow page 368)$.

Joy

As a balancing programme in demanding driving situations

Information on the Joy program see $(\rightarrow page 368)$.

Refresh

As a refreshing programme when temperatures rise

Information on the Refresh programme; see $(\rightarrow page 368)$.

Warmth

As a warming programme when temperatures drop

Information on the Warmth programme; see $(\rightarrow page 368)$.

By connecting a Garmin fitness tracker, for example the Garmin vívoactive[®] 3, additional informa-

tion can be entered into the evaluation for the recommendation of an ENERGIZING COMFORT programme. The additional information includes the stress level, that is calculated by the fitness tracker. The stress level is based primarily on the pulse rate.

Requirements for the integration of additional information via a Garmin fitness tracker:

- Your fitness tracker is connected with your Garmin account.
- Your Garmin account is connected with your Mercedes me user account.

If you wear your Garmin fitness tracker at night also, the sleep data is included in the evaluation of the ENERGIZING COACH.

Requirement for the integration of the sleep data:

- The Garmin fitness tracker is synchronised with the Garmin account before the beginning of the journey.
- (i) If ATTENTION ASSIST determines an excessive lack of attention, ENERGIZING COACH makes no further suggestions. Further infor-

mation about ATTENTION ASSIST (\rightarrow page 224).

Function of the ENERGIZING Biofeedback

Requirements for use of the ENERGIZING Biofeedback

- The vehicle is switched on.
- (i) For full use, a connection with a fitness tracker must be established and the Mercedes me ENERGIZING app must also be installed on the mobile phone to use the service.

The ENERGIZING Biofeedback programme is designed to help reduce stress and increase concentration. It can be used with or without a connected mobile device or fitness tracker.

By connecting a mobile device, additional information about the user's vital signs can be accessed and it is indicated whether the exercise is having the desired effect. A stress-reduced state is indicated by a green display of the ENER-GIZING biofeedback, a red display indicates a deterioration of the state.

- When the mobile device is not connected, the programme is displayed in a neutral colour and no feedback can be given on the impact.
- Calling up the ENERGIZING COACH display

Requirements:

- The fitness tracker is connected with your Garmin account
- Your Garmin account is connected with your Mercedes me user account in the Mercedes me ENERGIZING app.
- The mobile phone is connected to the multimedia system (\rightarrow page 414).
- · You are logged in with your Mercedes me profile both in the vehicle and in the Mercedes me ENERGIZING app.

Multimedia system:

- → Apps → ENERGIZING COACH
- Your current pulse as well as an evaluation of your pulse for the last 30 minutes driving time are shown.
 - A corresponding fault message is shown if there is no mobile phone connected or no

- pulse can be sent to the system for an extended period.
- Only pulse values in the range of 30 140 (possibly 150) bpm are shown on the central display. The pulse values have no medical validity but are only informative in nature and are therefore also not required to be accurate.
- Calling up ENERGIZING Biofeedback

Requirements:

The vehicle is switched on.

Multimedia system:

¬→ | 🎧 | **>>** Apps

>> FNFRGIZING Biofeedback

Starting and stopping ENERGIZING Biofeedback

- Operate to start the program. A video is played giving a calming breathing frequency with opening and closing circles, supported by an audio with wave sounds.
- The circles are only shown when the vehicle is stationary, or only to the front passenger when the vehicle is moving, so as not to endanger the driver's attention.

Select ■ to stop the program.

Connecting a new device

- Select 🔼 .
- Select Device selection. The desired device can be chosen from the list of connected mobile devices.

Selecting a program

- Select Program settings.
- Switch the supporting functions from ENER-GIZING COMFORT via massage, ambient lighting and suggested programs on or off.

Setting the duration of the program

- Select Program settings.
- Under Duration of programme set the desired duration. You can choose between three, five or seven minutes.

Navigation and traffic

Switching navigation on

Multimedia system:



Alternatively, press the button on the steering wheel on the right (→ page 332). The zero layer with the digital map is displayed.

Calling up the navigation module in the expanded view

Multimedia system:



(i) Navigation means: tap on navigation module (i) on the zero layer (→ page 374).

The navigation module is called up in the expanded view and shows the route overview with additional functions. Select one of the functions (\rightarrow page 385).

The following functions are available, for example:

- Switch the traffic information display on or off.
- · Select Previous dest...
- Search for Filling stations.
- Search for Parking spaces.
- Select Other routes.
- Enter a destination with .
- Make settings for View, Messages & tones and Route with .

Navigation overview

Digital map



Navigation module (reduced view) Route guidance active:

The navigation module shows the information relevant to the route in the zoomed-out view, e.g. the arrival time at the destination or a traffic delay

⊗ Ends the current route guidance
 Tapping opens the navigation module in the expanded view with the Route (→ page 385)

- ② Destination entry
- Searches for a parking space

- Map orientation and set map type
- Current vehicle position (vehicle symbol or arrow)
- Display area with entertainment sources, phone, active applications and suggestions
- Navigation window shows the next driving manoeuvre in the reduced view when guidance is active or an enlarged view with a detailed display of the upcoming driving manoeuvre when approaching a driving manoeuvre, e.g. a map section, 3D images or lane recommendations

When route guidance is active, tapping on the navigation window opens the route monitor, which shows information for the entire route, e.g. upcoming driving manoeuvres, destinations, motorway exits or rest areas with points of interest

Switches off navigation announcements Switches on navigation announcements

Pressing 4 several times changes the map orientation in this order:

2D and to the north

- 2D and direction of travel
- 3D and direction of travel
- Map with complete route
- If the map is moved, the map switches between 3D direction of travel and 2D north orientation.
- If you notice a problem with the digital map you can report this under https:// mapfeedback.here.com/#/report. The digital map is not provided by the HERE map service in all countries.

Destination entry

Notes on destination entry

WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you could be distracted from the traffic situation. This

could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Entering a POI or address

Requirements


- For the online search:
 - There is an Internet connection.
 - Mercedes me connect is available.
 - You have set up a user account in the Mercedes me Portal.
 - The vehicle is connected with the user account and you have accepted the terms of use.

376 MBUX multimedia system

- Further information can be found at: https://www.mercedes.me
- The service is available and has been activated.
- if Online Search is not available, the search is performed using the data of the digital map.

Multimedia system:





Example: entering a POI or address

- Input line with current entry
- Search result
- Selects destination search, displays further destination searches with double arrow
- Deletes an entry

- Adopts the search result in the input line and continues the search
- Objective to the last character entered
- Hides the keypad
- Switches to handwriting recognition(→ page 343)
- Starts the MBUX voice assistant (→ page 316)
- Sets the written language
- Switches to digits and special characters
- Switches to upper-case or lower-case letters
- Enter a destination. The entries can be made in any order.
 The search results are displayed in a list.
- (i) Online search results for POIs may contain additional information, for example opening times and ratings. The information is provided by an online map service.

This online function is not available in all countries.

The following entries can be made, for example in

- Town, street, house number or street, town
- Postcode
- POI name or POI category, e.g. Restaurants
- Town, POI name
- Contact name
- Junctions in the following entry format: "road A" and "road B"
- Geo-coordinates (\rightarrow page 379)
- Three-word addresses from what3words $(\rightarrow page 379)$

Entering three-word addresses is possible in the online search.

- Hide the keyboard with OK.
- Select the destination in the list.

The following menu shows the selected destination with the address information and a corresponding map section.

The menu enables the route to be calculated.

Selecting a destination suggestion

Requirements:

- The Allow destination suggestions option is switched on (\rightarrow page 359).
- The multimedia system has gathered sufficient data in order to show destination suggestions.

Multimedia system:



Select Suggestions and accept a destination suggestion.

or

- Select a destination suggestion directly on the Zero Layer (\rightarrow page 325).
 - The route is calculated in the following menu.
- If Suggestions has been selected, a menu is available via •••. The menu offers settings for the suggestions and memory functions.
- Managing destination suggestions $(\rightarrow page 395)$.

Selecting previous destinations

Multimedia system:



- Select Previous destinations.
- Select a destination. The following menu enables the route to be calculated.
- You can save a destination as a favourite $(\rightarrow page 395)$.

Selecting a POI

Requirements

- For use of personal POIs: a USB device is connected with the multimedia system.
- · Personal POIs with the GPS Exchange format (.gpx) have been saved in the PersonalPOI folder on the USB device.

Multimedia system:



- Select POIs.
 - Select one of the displayed quick-access categories, e.g. P.

Select the POI.

The following menu enables the route to be calculated.

or

- Select All categories or Personal POIs (see requirements).
- Select the category.
- ► Select the POI.

The following menu enables the route to be calculated.

Setting a search filter after selecting a POI category

The preset search position depends on the status of the route guidance:

- If route guidance is not active, In the vicinity is searched.
- If route guidance is active, Along the route is searched.
- When the search results are displayed, select Filter.
- Select the search position, e.g. In the vicinity.

If a route with intermediate destinations already exists and Near destination has been selected in the search filters, the destination is selected for the search.

or

- Select the desired travelling time to the point of interest.
- Select Search results.

Configuring categories for quick access

The categories are displayed:

- As symbols after calling up the destination entry via
- As a list after calling up All categories
- In the POI menu, select All categories.
- ➤ Select ☆ or ★ for a category.

 Tapping on ☆ adds the category.

 Tapping on ★ removes the category.
- Use to change back. The new categories are shown after the destination entry is called up the next time.

i) If all available quick-access positions are full, select the category to be replaced.

Changing the order of quick-access categories

- In the POI menu, press and hold a category for quick access.
- Tap on the arrows next to the selected category.
 The arrows for the other categories are greyed out.
- Drag the category up or down.
- ➤ Select ②.

Deleting quick-access categories

- ▶ Select ★ for the chosen category.
- Select Delete.
- ➤ Select ②.

Changing categories for personal POIs

- Select Personal POIs.
- Press on a category as long as is necessary until a menu appears.
- Select Change name and enter a name.

- Select Change icon and select a symbol.
- Select Delete and confirm the prompt with Yes.

Selecting a contact for destination entry

Requirements:

- A mobile phone is connected to the multimedia system (\rightarrow page 414).
- The contacts from the mobile phone have been downloaded.
- The contact has a navigable address.
- The address data can be located on the digital map.

Multimedia system:



- Enter a contact in the entry line.
- Select the address.

The following menu allows you to calculate the route.

Alternatively, after calling up the destination entry, you can enter the name of a contact in the search field.

Entering geo-coordinates

Multimedia system:



Enter the geo-coordinates as latitude and longitude.

Examples of input formats:

- 47°58'11"N 7°57'25"E (degrees, minutes and seconds)
- 47.969722 7.956944 (decimal degrees)
- Confirm the entry. The following menu enables the route to be calculated.

Entering the destination as a three-word address

Requirements

- An active Internet connection is indicated in the status line on the central display with the symbol.
- The online search is active.

Multimedia system:



- Enter the destination as a three-word address from what3words. The entry can be made with spaces between the words instead of dots. The search results are displayed.
- Select the destination in the list. The following menu enables the route to be calculated.

The Brandenburg Gate has this language dependent three-word address:

- German: tapfer.gebäude.verliehen
- English: that.lands.winning
- French: posteaux.bobineur.ombrant
- Searching for a destination using three-word addresses is not possible in all countries and in all languages.

Alternatively, use the following entry options:

Voice navigation (→ page 316)

Example: during a telephone call you are given a 3 word address. After activating the MBUX

- Navigate to tapfer gebäude verliehen
- Navigate to tapfer Punkt gebäude Punkt verliehen



Three-word addresses from what3words are an alternative addressing system for multilingual georeferencing of global locations with a resolution of three metres. Using this grid, locations on the Earth's surface are included which do not have a building address such as a street and house number, for example.

(i) Three-word addresses are unique, easy to remember and suffice for most routine applications.

You can convert addresses to three-word addresses and back again:

- At the website https://what3words.com
- In the what3words apps
- Selecting a destination on the map Multimedia system:
- **→**
- If necessary, move the map (\rightarrow page 401).
- Press and hold on the map. Available destinations are displayed.

or

- Briefly press on a POI symbol. The POI is selected. If there are several POIs at this map position, a list appears.
- Select the destination in the Selected objects list.

The following menu allows the route to be calculated.

Selecting a destination from favourites

Requirements:

Destinations are saved as favourites.
 Save a previous destination or a destination suggestion as a favourite (→ page 395).

Multimedia system:



- Select Favourites.
- Select a favourite.
 The following menu allows you to calculate the route.

Addresses for home and work are already set

Select Home or Work.

The route is calculated in the following menu.

Addresses for home and work are not yet set

- Select Home or Work.
 The prompt No "Home" address available.
 Set address now? appears, for example.
- Select Yes.
- Search for or select the address.

Select Save.

Deleting favourites

- Select ••• for a favourite.
- Select Delete.

or

- Select Delete all.
- Confirm the prompt. When all the favourites have been deleted, Add favourite is available, for example.

Selecting received destinations

Requirements

- · There is an Internet connection for receiving external destinations.
- A destination has been sent to the vehicle.
- Destinations have been shared from another seat in the vehicle.

Multimedia system:







The vehicle can receive destinations from services or apps. You will be informed when a destination is received.

- Select Received destinations.
- Select a destination. The route is calculated in the following menu.
- You can save a received destination in the favourites (\rightarrow page 395).

Deleting received destinations

- Select ••• for a destination.
- Select Delete or Delete all. The destination or all destinations are deleted.

Route

Calculating a route



Example: detailed display

- Calls up alternative routes
- Adds the chosen destination to the existing destination as the next intermediate and recalculates the route
- Calculates a new route to the chosen destination

- Selects a point of interest in the vicinity of the destination
- Oetailed display with destination address, three-word address from what3words and online content

After selection of ② or ③, the route is recalculated.

Select one of the options.

Calling up alternative routes

- Select Routes.
- Select an alternative route.

Starting route guidance

► Select ▲ Let's go!.

Calling up the detailed display with destination address

Pull the bar above the Let's go! symbol upwards.
Depending on the destination selection and availability, online content, for example ratings and weather information, is shown.

- To share a destination: select Share.

 This option allows you to scan the displayed QR code.
- To save a destination as a favourite: select

 ★ Favourite and then an option.
- To call up an Internet address: if a web address is available, select www.
- To call the destination: if a telephone number is available, select Call.

Searching for POIs in the vicinity of the destination shown

- Select In the vicinity.
- Search using categories, enter a search entry or search for a personal POI (\rightarrow page 377).

Adding an intermediate destination to the existing route or starting a new route guidance

- Select Add.
 The selected destination address is set as the next intermediate destination. Route guidance begins.
- There are already four intermediate destinations: confirm the prompt with Yes and select

an intermediate destinations in the route overview (→ page 385), that should be overwritten with the new intermediate destination.

or

➤ Select
Replace.
The selected destination address is set as a new destination. Route guidance begins.

Switching low-emission zones for the route on or off

Requirements

- · Mercedes me connect is available.
- You have a Mercedes me connect user account and the vehicle is connected with the account.
- The "Traffic Restriction Zones" service is available and activated in the Mercedes me Portal.
 After registration the service is free of charge for the term offered.

Multimedia system:

overview.

- Switch on Low emission zones. The low emission zones along the route are shown on the digital map and in the route

Before you enter a low emission zone, you will be shown a notification in the central display.

Selecting a route type

Multimedia system:



Using trailer mode and online routes

The route is calculated as a fast route with a short journey time.

Trailer mode is available if a trailer has been coupled with the vehicle. If available, you can select online routes.

- Trailer mode and online routes are not available in all countries and for all vehicles.
- Select Trailer mode. A prompt is shown in the multimedia system.

Confirm the prompt.

The arrival time at the destination takes into account a reduced driving speed with trailer.

To use online routes: switch on the option.

Taking traffic information for the route into account

Select one of the options.

Explanation of the options:

Automatic

Traffic reports via Live Traffic Information are taken into account (\rightarrow page 396).

If a new route with a shorter journey time is determined based on traffic reports, the current route is shown in blue and the new route in grey on the map. You can accept the new route by tapping on the grey line or keep the current route.

Live Traffic Information is not available in all countries.

Off

No traffic reports are taken into account for the route.

Calculating alternative routes

Multimedia system:

- → Navigation → View
- Activate Overview of route after start. Alternative routes are calculated for every route.

Selecting route options

Multimedia system:

¬→ 🛕 ≫ Navigation ≫ 🐞 ≫ Route

Avoiding or using route sections, e.g. motorways or ferries

Activate or deactivate the avoid option. Avoid: the option is activated. The route avoids motorways, for example.

Use: the option is deactivated. The route takes motorways into consideration, for example.

The selected route options cannot always be taken into account. Therefore, a route may include a ferry, for instance, even though the Avoid ferries avoid option is enabled. A message then appears and you will hear a corresponding message.

Avoiding or using toll roads

The use of toll roads requires a usage fee (toll).

- ► Select Toll roads >.
- Activate or deactivate Avoid all.

 If the option is activated, the route avoids toll roads.

If the option is deactivated, the route takes toll roads into account.

or

Select an option for Payment by cash or card or Electronic billing.

Avoid: the route avoids toll roads with the selected method of payment.

Use: the route takes into account roads that require a toll corresponding with the payment type selected.

Avoiding or using roads requiring a special toll sticker

A vignette allows for the use of a route network for a limited time period.

- Select Avoid vignette roads \(\sumsets \).
- Activate or deactivate Avoid all.

Switch individual countries on or off in the list. Avoid: the option is activated. The route avoids roads requiring a special toll sticker in the selected countries.

Use: the option is deactivated. The route takes into account roads in the selected country which require you to pay a time-based fee (vignette).

i These route options are not available in every country.

Avoiding or using areas with low emission zones

- The function is available when there is an active internet connection.
- Activate or deactivate Area with low emission zones.

Avoid: the option is activated. The route avoids all low emission zones restricted for the vehicle. These are displayed in red on the map.

Use: the option is deactivated. The restricted low emission zones for the vehicle are passed through on the route. A warning is displayed before you drive into a low emission zone.

Avoiding areas

- ► Select Avoid areas \bigcirc (\rightarrow page 403).
- Selecting notifications for the route

Requirements:

- For an audible indication when approaching a personal POI: the USB device contains personal POIs.
- The USB device is connected with the multimedia system.
- The category in which the personal POI belongs is activated.

Multimedia system:

→ 🔝 **>>** Navigation **>>** 💍

➤ Messages & tones

Switching navigation announcements on or off

Activate Reduced messages.

If a driving instruction is available for a simple change in direction, you hear a brief announcement, e.g. "turn right in 200 m". The number of driving instructions along the route is minimised.

Activate Detailed messages.

If a driving instruction is available and there is a complex driving situation, you hear supplementary information, e.g. "In 200 m turn right and continue to follow the major road". Additional driving instructions are issued for the route, for example on turning major roads.

- Activate Announce street names. The name of the street into which the vehicle should turn is announced.
- This option is not available in all countries and languages.

Switching traffic announcements on or off

Activate or deactivate Announce traffic warnings.

If available, traffic warnings are announced, e.g. before the end of traffic jams that pose a risk.

Audible indication when approaching a personal POI

Select Personal POIs.

Activate a category. When approaching a personal POI in the selected category an audible indication will be issued.

Displaying a route overview

Requirements

A destination is entered.

Multimedia system:

Navigation



Example: route guidance is active

- Traffic event on the route Distance from current vehicle position and remaining driving time
- Destination

- Searches for a filling station
- Switches traffic information display on or off

When route guidance is active, the destination and entered intermediate destinations are shown.

Depending on the route, traffic situation and available data, further information can be displayed.

The route can include up to four intermediate destinations.

- If route guidance is not active, select Previous destinations in addition to (3), for example.
- Select the destination and calculate the route.
- i The following options are available for route planning in the route overview:
 - Changing the order of the destinations (→ page 386).
 - Deleting a destination.
 - Substituting an intermediate destination along the route.

Planning routes

Multimedia system:

- ► Navigation ► ✓
- (→ page 375).

 After entering the destination and new calculation of the route, the map is shown again.

 The route contains a new intermediate destination.
- If there are already four intermediate destinations, delete an intermediate destination
 (→ page 386).
- Editing a route with intermediate destinations

Requirements

• The destination and at least one intermediate destination have been entered.

Multimedia system:

→ 🔝 **>>** Navigation

Changing the order of the destinations

In the route overview, press and hold on a destination.

- ► Tap on Finished ... The editing mode is ended.

Deleting a destination

In the route overview tap on of for a destination.

Substituting an intermediate destination along the route

If an intermediate destination is entered and there are already four intermediate destinations, you will be asked to substitute one of intermediate destination. A prompt appears.

- Select Yes.
- In the route overview, tap on or the intermediate destination to be substituted. The new intermediate destination is added to the route.

Displaying the route list

Multimedia system:



Tap on the navigation window 🕖 $(\rightarrow page 374)$.



Example: route list

Upcoming manoeuvre with turning arrow, distance to manoeuvre, street number, street name

Switches off navigation announcements

Switches on navigation announcements

Including the following route sections on the route to the destination

Current vehicle position

The route sections are displayed in the navigation window. The route list is updated during the journey.

- (i) Motorway information shows the available service facilities. After selecting symbols, e.g. for car parks, service areas or motorway exits, the POI is adopted as an intermediate destination or destination.
- Press the arrow at the bottom of the navigation window briefly.
- Swipe up or down.
- Select a route section. The map section is displayed.
- Selecting an alternative route

Requirements

· A route has already been created.

Multimedia system:



The original route is shown in the navigation window and is highlighted on the map.

Alternative routes are shown on the map together with the difference in travelling time.

(i) A faster route may be shown as an alternative route that is considerably longer.

The following route information is displayed:

- Driving time
- Time of arrival
- Distance to the destination
- Avoid options based on the set route options
- Driving time saved or lost compared with the original route
- When the alternative routes have been calculated, display the route in the navigation window by swiping to the right or left.

Changing route type

- Select Filter.
- Switching the route type on or off.

Avoiding or using route options

- Select Filter.
- Switch the route options on or off (→ page 383).
- Confirm the settings with Finished.
- To start route guidance to the alternative route: select Start.
- To select an alternative route on the map: touch any point on the alternative route. The alternative route is highlighted.

Activating a commuter route

Requirements

- You have created a profile (→ page 336).
- The Allow destination suggestions option is switched on (→ page 337).
- The Activate commuter route option is switched on .
- The multimedia system has gathered sufficient data in order to show destination suggestions.
- Routes have been learned for these destination suggestions.

- Route guidance is not active.
- i This commuter route is not available in all countries.

Multimedia system:

- → 🔝 ➤ Navigation ➤ 🐞 ➤ Route
- Activate Activate commuter route.
 The navigation system automatically detects that the vehicle is on a commuter route.

For the daily commuter route, traffic events on the route are also reported when driving without active route guidance.

- To select commuter route: select Start. Route guidance begins without spoken driving instructions.
- (i) A commuter route is suggested even with delays on the route.
- ► To delete a commuter route: select x.
- Adjusting the route on the map

Requirements:

A route has already been created.

You can change the course of the original route on the map. A new intermediate destination is set in the process.

- (i) If the maximum number of intermediate destinations is reached, the function is not supported. Press the OK button to confirm the message.
- Press lightly on the route with one finger and hold the finger in place.
- A symbol appears. The route can be changed.
- Drag and hold the route with your finger to a desired map position.

The new route is displayed. The route is recalculated.

When the route is calculated, the journey time and distance are compared with the original route.

When the finger is pulled away from the display, the intermediate destination is shown on the map.

 Accept the route with Confirm or reject it with Cancel and return to the original route.

Switching the automatic filling station search on or off

Multimedia system:

- → Settings → Vehicle
- Select Other functions.
- Activate or deactivate Automatic filling station search.

If Automatic filling station search is switched on, a notification appears in which the search for filling stations is started.

Starting an automatic filling station search

Requirements

· The automatic filling station search is activated (\rightarrow page 389).

Driving situation

The fuel level in the fuel tank reaches the reserve fuel level.

The central display shows the following notification: Reserve fuelTap here to search for filling stations.

- Confirm the notification.
 - The automatic filling station search begins. The available filling stations along the route or in the vicinity of the vehicle's current position are displayed.
- Select a filling station.
- Calculate the route with the filling station as an intermediate destination or as a destination (\rightarrow page 381).
- If there are already four intermediate destinations: select Yes in the prompt. The selected filling station is entered in the route overview at position 1. Intermediate destination 4 is deleted. Route guidance begins.

Starting the automatic service station search

Requirements:

- ATTENTION ASSIST is activated $(\rightarrow page 224)$.
- You are driving on a motorway.
- There are service stations along the route section ahead.

Driving situation

The following notification is shown on the central display ATTENTION ASSIST Tap here to search for rest areas...

- Confirm the notification. The service station search starts. The available service stations along the route or in the vicinity of the vehicle's current position are displayed.
- Select a service station.
 - Calculate the route with the service station as an pintermediate destination or as a \land destination (\rightarrow page 381).
- If there are already four intermediate destinations: select Yes in the prompt.

The selected service station is entered in the route overview at position 1. Intermediate destination 4 is deleted. Route guidance begins.

Starting and editing a stored route

Requirements:

 A USB device with stored routes is connected with the multimedia system (\rightarrow page 456).

• The route is stored in the "Routes" folder with the GPS Exchange format (.gpx).

Multimedia system:



- Press the double arrow in the destination input line until Stored routes is displayed.
- Select Stored routes.

Starting a saved route

- Select a route.
- Select Start: route guidance at start or Start: current location.
 Route guidance begins.

Renaming a route

- Press on a route until a menu is shown.
- Select Rename.
- Enter the name.
- Select OK.

Recording and storing a route

Requirements:

A USB device is connected with the multimedia system (→ page 456).

Multimedia system:



- Press the double arrow in the destination input line until Stored routes is displayed.
- Select Stored routes.

Starting recording

Select Start recording.
 A white rectangle is displayed.
 The route is stored on the USB device.

Stopping recording

- Press the white rectangle.
- Select End recording.

Route guidance

Notes on route guidance



WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Route guidance begins once a route has been calculated. The road and traffic rules and regulations always have priority over multimedia system driving instructions. Driving instructions are, for example navigation announcements, changes in direction and lane recommendations.

Changes in direction and lane recommendations are shown in the navigation window.

The following displays and functions are also available in the navigation window, for example:

- Route list
- Destination information
- Traffic information, e.g. length of traffic jam, delav
- Motorway facilities
- Car park search
- Emergency lanes

If you do not follow the driving instructions or if you leave the calculated route, a new route is calculated automatically.

If, for example, the route is diverted or the direction of a one-way road has been reversed, driving instructions may deviate from the actual traffic situation.

Alternatives may be offered during route guidance, e.g. before passing a motorway exit road. The additional driving time for the journey along the motorway exit is shown.

For this reason, you must always observe road and traffic rules and regulations during your journey as well as the prevailing traffic conditions.

The route can differ from the ideal route, for example in the event of roadworks or incomplete digital map data.

Notes on satellite reception

The correct function of the navigation system depends amongst other things on reception of the satellite system used. In certain situations satellite reception can be impaired, malfunction or even not possible, e.g. in tunnels or in multi-storey car parks.

Changing direction overview

Changes of direction are shown in the following displays:

 Detailed image of the junction The display appears when you drive into a iunction.

• 3D image

The display appears when driving on junctionfree, multi-lane roads, for example at motorway exits and motorway interchanges.



Example: detailed image of the crossing with upcoming changes of direction

- Name of the street to turn into
 - Blue highlighted route (also on the map)
- Current distance to the change of direction



Example: 3D image of the upcoming change of direction

- Manoeuvre point
- Blue highlighted route (also on the map) Larger map scales show change of direction points instead of change of direction arrows.
- Current vehicle position
- Current distance to the change of direction

There are three phases when changing direction:

· Preparation phase If there is enough time between the changes of direction, the multimedia system prepares you for the upcoming change of direction. A

navigation announcement is issued, e.g. "Prepare to turn right".

The navigation window shows: the direction information or the name of the road which is to be turned into as well as the distance to the change of direction.

Announcement phase

The multimedia system announces the upcoming change of direction, e.g. by announcing "Turn right in 300 m".

When the Auto zoom map orientation is switched off (→ page 405), a detailed representation of the junction or a 3D image of the upcoming change in direction appears in the navigation window.

Change-of-direction phase

The multimedia system announces the imminent change of direction, e.g. by announcing "Now turn right".

Example 3D image: when the distance to the driving manoeuvre (1) is displayed with 0 m the driving manoeuvre is performed.

- (i) Changes in direction are also displayed on the driver's display and head-up display.
- Lane recommendations overview



Example: lane recommendations

- Lane not recommended (grey arrow)
- Possible lane (white arrow)
- Recommended lane (white arrow, blue background)

This display appears for multi-lane roads.

If the digital map contains the relevant data, lane recommendations are displayed in the navigation window.

Explanation of the displayed lanes:

- Recommended lane
 - In this lane, you will be able to complete both the next change of direction and the one after that.
- Possible lane In this lane, you will only be able to complete the next change of direction.
- Non-recommended lane In this lane, you will not be able to complete the next change of direction without changing lane.

During the change of direction, new lanes may be added. Bus lanes are also shown.

Lane recommendations are also displayed on the driver's display and head-up display.

Using motorway information

When driving on the motorway, upcoming motorway facilities and available service facilities are shown in the route list. These include car parks, service stations or motorway exits with service POIs, for example.

The entries are sorted according to increasing distance from the current vehicle position.

- Select an entry.
- If several service facilities are available, select a service facility from the list. The destination address and the map position are shown.
- Calculate the route (\rightarrow page 381).

or

Search for a POI in the vicinity.

Use other functions, e.g. store the destination address of the service facility.

Destination reached

Once the destination is reached, you will see the chequered flag. Route guidance will now be complete. The navigation menu is shown.

When an intermediate destination has been reached, you will see the intermediate destination flag with the number of your intermediate destination. Route guidance is continued.

Switching navigation announcements on or off

Switching off

Press the button on the steering wheel or on the MBUX multimedia system during a navigation announcement (\rightarrow page 342). The Spoken driving recommendations have been deactivated. message appears.

- Show the navigation menu (\rightarrow page 374).
- Select **■**)). The symbol changes to <a> .

Switching on

In the navigation window, select 💉 upcoming driving manoeuvre. The current navigation announcement is played.

Switching navigation announcements on or off during a phone call

Press the button on the steering wheel on the right.

or

- ▶ Press 🔝 in the central display.
- Select Settings.
- Select System.
- Select Audio.
- Select Voice output.
- Activate or deactivate Driving recommendations during call.
- ► To leave the menu: select .

Adjusting the volume of navigation announcements

Multimedia system:

- → Settings → System → Audio

 Voice output
- Select Driving recommendation vol..
- Set the volume.
- To leave the menu: select 5.

Route guidance is active

Set the volume during a navigation announcement on the steering wheel or under the touchscreen.

Switching audio fadeout on or off during navigation announcements

Press the button on the steering wheel on the right.

or

- Press in the central display.
- Select Settings.
- Select System.
- Select Audio.
- Select Voice output.
- Activate or deactivate Lower audio for driving recomm..
- To leave the menu: select .

Repeating navigation announcements

Requirements

- A route has already been created.
- Route guidance is active.

Multimedia system:

- **→**
- In the navigation window, select for an upcoming driving manoeuvre.
- Select M.
 The current navigation announcement is repeated.

Cancelling route guidance

Requirements

- A route has already been created.
- Route guidance is active.
- ➤ Select in the navigation module (→ page 374).

Overview of off-road status during route guidance

Due to roadworks, for example, there may be differences between the data on the digital map and the actual course of the road. In such cases, the multimedia system will temporarily be unable to locate the vehicle's current position on the digital map. The vehicle is off-road.

You can see the Please follow the arrow display and hear the corresponding navigation announcement. Route guidance may be restricted.

When the vehicle is back on a road known to the multimedia system, route guidance continues as normal.

Destination

Saving the current vehicle position Multimedia system:

- **→** 🔝
- When the map is shown, tap on the \(\bigcap \) current vehicle position.
- Select Store position.
- To save as a favourite: select Save as favourite.
- To save as "Home" address: select Home...
- To save as "Work" address: select Work.

Managing previous destinations

Multimedia system:



Select Previous destinations.

Saving the last destination as a favourite

- For a last destination, select A menu appears.
- To save as a favourite: select Save as favourite .
- To save as "Home" address: select Home.
- To save as "Work" address: select Work.

Deleting a previous destination

- For a last destination, select •••.
- Select Delete.

or

- Select Delete all.
- Confirm the prompt.

Editing destination suggestions

Requirements:

- The Allow destination suggestions option is switched on (\rightarrow page 359).
- For the display of destination suggestions: the multimedia system has gathered sufficient data.

Multimedia system:



- Press and hold on a destination suggestion. A menu appears.
- To cancel a destination suggestion: select Do not suggest now or Do not suggest.
- To save a destination suggestion: select Save as favourite. Home or Work.
- Delete a destination suggestion from the favourites (\rightarrow page 380).

Route guidance with current traffic reports

Traffic information overview

Current traffic reports are received with the Live Traffic Information subscription service.

i Live Traffic Information is not available in all countries.

The service must be registered in the Mercedes me user account (\rightarrow page 396). This ensures the free usage period.

The service updates the traffic situation via the Internet connection at short, regular intervals.

Information on the vehicle's position is regularly sent to Mercedes-Benz AG. The data is immediately rendered anonymous by Mercedes-Benz AG and forwarded to the traffic data provider. Using this data, traffic reports relevant to the vehicle's position are sent to the vehicle. The vehicle acts as a sensor for the flow of traffic and helps to improve the quality of the traffic reports.

There may be differences between the traffic reports received and the actual road and traffic conditions.

If you do not want to transmit the vehicle position, you have the following options:

- You deactivate the service in the Mercedes me user account.
- You have the service deactivated at a Mercedes-Benz service centre.
- (i) Hazard warnings can be received using the Car-to-X service (\rightarrow page 398).
- Showing information from the service provider for Live Traffic Information

Requirements:

• The vehicle is equipped with Live Traffic Information.

Multimedia system:

- → Apps → Mercedes me >> My services
- Select Live Traffic Information.
- Registering Live Traffic Information

Requirements

You have a Mercedes me user account.

- The vehicle is equipped with Live Traffic Information.
- Create a Mercedes me user account at: https://www.mercedes.me. A valid email address is required for this.
- Register the vehicle using the vehicle identification number (VIN).
- Connect the vehicle with your Mercedes me user account. A code is sent to the multimedia system.
- Enter the code into the multimedia system.
- Accept the general and specific terms of use.
- Alternatively, you can have the connection completed at a Mercedes-Benz service centre.

Extending a Live Traffic Information subscription

Requirements:

- You have a Mercedes me user account.
- The vehicle is equipped with Live Traffic Information.

- Call up the Mercedes me website.
- Call up the Mercedes me user account.
- Switch to the Mercedes me Store via the linked vehicle.
- Select the Live Traffic Information service.
- Select the renewal period.
- Add the product to the shopping basket.
- Accept the general and specific terms of use. Live Traffic Information remains activated for the selected extension period. Activation begins on the date of extension.

Displaying traffic information on the map

Requirements:

Traffic incidents and Free-flowing traffic are switched on (\rightarrow page 398).

Multimedia system:

▶ If necessary, move the map (\rightarrow page 401).

The map shows the following traffic information depending on the activated settings:

Traffic incidents

These are roadworks, road blocks and warning messages, for example.

When route guidance is active, the symbols for traffic incidents will be shown in colour on the route. Off the route they are grey.

Warning messages 1 Traffic safety information can be shown, e.g. if there are people on the carriageway. If the vehicle approaches a danger area, for example the end of a traffic jam in a dangerous position, the A symbol is shown on the map. If Announce traffic warnings is switched on and a message has been issued, an additional announcement is made.

- Traffic flow information:
 - Traffic jam (red line)
 - Slow-moving traffic (orange line)
 - Heavy traffic (yellow line)
 - Free-flowing traffic (green line)
- Display for traffic delays on the current route

The smallest value for the display for traffic delays is a minute.

Showing traffic events on the route

Requirements:

• The Traffic incidents display is switched on $(\rightarrow page 398)$.

Multimedia system:



If there are traffic events on the route, these are shown on the map and in the route overview.

The display is along the entire route.

- i) The display is for route lengths up to approx. 2000 km.
- With the MBUX Voice Assistant you can inform yourself about traffic events on your route. Ask, for example How is the traffic on my route? or How is the traffic at home?. A voice output is given.



Example: traffic events on the map

- Total delay
- Traffic event symbol, e.g. road works
- Colour display of traffic flow information, delay and length, road name and/or road number
- Switches traffic information display on or off

- If a message about forming an emergency corridor has been issued, Allow rescue lane is shown in the navigation window.
- To see all of the traffic events on the route. swipe to the right or left in the route overview. The route section is highlighted on the map.

Displaying detailed information

- Tap on a traffic event symbol or traffic flow information in the route overview (when route guidance is active) or on the map.
 - The detailed information is shown, for example the road section, the direction and the delay.
 - If a traffic jam symbol is selected, the trend can be displayed as decreasing or increasing.
- Several pieces of traffic flow information are available in the immediate vicinity on the map: tap on the upper line and select the traffic flow information in the list.
- Several traffic events are on the map in the immediate vicinity: tap on the top traffic event symbol and select from the list of traffic events.

Switching the traffic information display on Multimedia system:

- → 🔝 >> Navigation >> 💍
- Select View.
- Traffic.
- Activate Traffic incidents and Free-flowing traffic.

Traffic incidents, for example roadworks, local area reports (e.g. fog) and warning messages, are shown on the route.

Car-to-X-Communication

Car-to-X-Communication overview

The following requirements apply for the Car-to-X-Communication service:

- · The vehicle is equipped with an MBUX multimedia system with navigation function.
- There is a subscription for the Live Traffic Information service.
- The Car-to-X-Communication service is activated in your Mercedes me user account.

Car-to-X communication is not available in all countries.

The communication module automatically establishes an Internet connection once the vehicle is switched on. If there are any hazard warnings, they will be provided shortly thereafter. Depending on the mobile phone connection, the provision takes place from within a second up to about a minute.

Benefits of Car-to-X-Communication:

- Dangers are automatically detected by the vehicle or can be reported by the driver. These are then sent to vehicles with Car-to-X-Communication in the immediate vicinity.
- · If available, current details relating to hazard spots near the vehicle's current position are received.

This gives you sufficient time to adapt your driving style to the traffic conditions.

The use of Car-to-X-Communication requires the regular transmission of vehicle data to Mercedes-Benz AG. The data is then immediately pseudonymised by Mercedes-Benz AG. The vehicle data is deleted after an appropriate amount of time has

elapsed (several weeks) and is not stored permanently.

Data which serves as identification is replaced during the pseudonymisation process. In this way, your identity is protected against access by unauthorised third parties.

Displaying hazard warnings

Multimedia system:



If hazard warnings are available these can be shown as symbols on the map. The display depends on the settings for the Traffic incidents option.

Set the option via \bigcirc (\rightarrow page 398). If the option is activated, all of the symbols are shown.

If the option is deactivated, the symbols are only shown when there is a hazard warning.

The following hazards may be shown on the map:

- Accidents and breakdowns
- Slippery roads, fog, crosswinds and heavy rain
- Hazards reported manually

- Vehicle with active hazard warning light
- Roadworks
- Additional hazards (if available)
- If Announce traffic warnings is switched off (→ page 384), voice output can indicate a danger area.

Sending hazard warnings

Reporting hazards manually

- Automatically detected hazard warnings are sent by the vehicle.
- When the map is shown, tap on the \(\bigcap \) current vehicle position. The Position menu is shown.
- Select Report traffic incident. The Thank you for supporting accident prevention! message appears.

Overview of route guidance with augmented reality

- This function is an on-demand feature (→ page 25).
- ★ WARNING Risk of accident and injury as a result of distraction, incorrect depiction or wrong interpretation of the display

The camera image of the augmented reality display is not suitable as a guide for driving.

- Always keep an eye on the actual traffic situation.
- Avoid extended observation of the camera image.

During route guidance with augmented reality a camera image with the real traffic scene is shown on the central display before a turning manoeuvre. The camera image includes additional information, for example arrows indicating a change of direction.

If the options are switched on and this additional information is available, road names and house numbers are displayed (\rightarrow page 401).



- House number
- Street name
- Ohange of direction arrow

Route guidance with augmented reality will not be available in some situations, e.g. in the event of poor satellite reception or roads that have not been digitised.

Route guidance with augmented reality is not available in all countries.

You can watch an animation on this topic via the following link:

Activating route guidance with augmented reality

WARNING Risk of accident and injury due to imprecise positioning of additional information

The additional information from the augmented reality display may be inaccurate and is not a substitute for observing and assessing the actual driving situation.

 Always keep an eye on the actual traffic situation when carrying out all driving manoeuvres.

Multimedia system:



- Select View.
- Select Augmented reality video.

Activate or deactivate Augmented reality video.

If the function is activated, the following are shown before a turning manoeuvre in the central display:

- The camera's video image The video image includes additional information.
- The AR switch

The video image can be shown or hidden.

- To show or hide the video image: tap on AR
- Showing property information for route guidance with augmented reality

Requirements

Augmented reality is activated (→ page 400).

Multimedia system:

- ¬→ 🞧 ▶ Navigation ▶ 💍
- Select View.
- Select Augmented reality video.

Activate Street names and House numbers. During route guidance, the activated options are shown as additional information in the camera image.

Map and compass

Setting the map scale Multimedia system:



Zooming in

When the map is shown, tap twice quickly with one finger on the central display.

or

Move two fingers apart on the central display.

Zooming out

Tap with two fingers on the central display.

or

- Move two fingers together on the central display.
- You can set the unit of measurement of the map scale (\rightarrow page 358).

Moving the map

Multimedia system:



When the map is displayed, swipe in any direction with one finger on the central display.

The following functions are available:

- Select a destination on the map $(\rightarrow page 380)$.
- Select a POI (→ page 377).
- Show traffic incidents on the map $(\rightarrow page 397)$.
- To reset the map to the current vehicle position: select ② Centre.
- Switching the route overview after start on or off

Multimedia system:



Select View.

Activate or deactivate Overview of route after start.

If the option is enabled, the map shows the full route after route guidance is started and, if available, all alternative routes.

Selecting POI symbols for the map display Multimedia system:



POIs include restaurants and hotels, for example. These are displayed as symbols on the map. Not all POIs are available in all countries.

Personal POIs are destinations which you have saved on a USB device, for example.

- (i) The display of POI symbols on the map can be activated or deactivated as a favourite.
- Select View.
- ➤ Select POI symbols on map ∑.
- Activate or deactivate Hide all points of interest.

When the option is switched on, all POIs are hidden on the map. The settings in the POI categories are kept.

When the option is switched off, the POIs are shown on the map according to the settings in the POI categories.

i) If the conditions are fulfilled, the POI symbols are shown with current online information (→ page 406).

Switching display of categories for quick-access on or off

Switch a category on or off in the menu.

Selecting categories

- In the menu, select Other categories \(\).
- Activate or deactivate Show all.
 When the option is switched on, the POI symbols for all categories are shown on the map.

or

- Select the categories.
- Activate or deactivate the categories.

 The POI symbols for the selected categories are shown on the map.

Selecting personal POI categories

In the menu, select Personal POIs .

- ➤ Select > a category.
- Activate or deactivate Display on the map.
- To issue a signal when approaching: activate Visual warning and Acoustic notification.

Resetting the POI symbol display

- In the menu, select Reset POIs. The settings are reset to the standard settings.
- Selecting the display of additional information on the map

Multimedia system:

- → 🔝 → Navigation → 💆
- Select View.
- Select Show additional information.
- Switch the options on or off.

The following options are available:

Current street

If the option is enabled, it will be displayed in the navigation window.

Scale

If the option is enabled, the map scale is permanently displayed on the map.

The option also influences the display on the driver's display.

- Altitude
- Next junction

If the option is switched on and the journey continues without route guidance, the name of the next intersecting street will be displayed in the navigation window.

Displaying the map version

Multimedia system:

- → 🔝 >> Navigation >> 💍
- Select View.
- Select Map data version. The detail information is displayed.
- The online map update service from Mercedes me connect can be used to update the map data (\rightarrow page 404).

- You can obtain information about new versions of the digital map via the following options:
 - Depending on the setting as a message in the Mercedes inbox or as an e-mail
 - At any Mercedes-Benz service centre
- Overview of area avoidance on the route You can define areas along a route that you would like to avoid.
- Avoiding a new area for the route Multimedia system:
- → 🔝 → Navigation → 🐧 → Route >> Avoid areas
- Select Avoid new area.

Starting using the map

- Select Using map. A red rectangle appears. This designates the area that should be avoided.
- Move the map (\rightarrow page 401).
- Set the map scale (\rightarrow page 401).

- Select OK.
 - The area is entered into the list.

Starting using destination search

- Select Via address entry.
- Enter the address (\rightarrow page 375).
- Select the destination in the list. The map appears. The area is saved.

Changing an area to be avoided Multimedia system:

- → Navigation → Route >> Avoid areas
- Select an area in the list.
- Select Edit.
- To move an area on the map: swipe in any direction on the central display.

Changing the size of the area

- Move two fingers apart or together on the central display.
- Select OK. The area is entered into the list.

Taking the area for the route into account

- Select the area in the list.
- Activate Avoid area.

 If route guidance is active, a new route is cal-

If there is no route yet, the setting is carried over to the next route guidance.

The route can include an area that is to be avoided in the following cases:

- The destination is located in an area that is to be avoided.
- There is no practical alternative route.

Deleting an area to be avoided

Multimedia system:

culated.

Deleting an area to be avoided

- Select an area in the list.
- Select Delete.
- Confirm the prompt with Yes.

Deleting all areas to be avoided

- If at least two areas to be avoided are set, select Delete all.
- Confirm the prompt with Yes.

Map data update overview

As the content of a digital road map has a short life, outdated data may have a negative effect on all navigation functions. For the best MBUX navigation experience, you should install all of the map updates offered by Mercedes-Benz.

The following options are available for the update of map data:

- Online map update
- Updates from the Mercedes me Portal
- Update at a Mercedes-Benz service centre Additional costs can be incurred in this process.

Online map update

Requirements:

- · Mercedes me connect is available.
- You have a Mercedes me user account.

- The Online Map Update service is available for your region.
- The service has been activated.
- i The Online Map Update service is only available in certain countries.

Installation takes place in the background as an automatic map update.

The MBUX multimedia system installs all of the available map updates for the European, North American, Korean and Japanese regions in which the vehicle is located or is moved.

The online map update is activated at the latest after the next time the vehicle is switched on.

Updates from the Mercedes me Portal

The map data for several regions can also be updated manually. Log in with your Mercedes me user account at: https://www.mercedesbenz.de/

Follow the menu path My Mercedes me account > Dashboard > Manage vehicle > Manage services > Online Map Update. Select the regions to be downloaded to a storage medium.

After the map data has been copied, connect the storage medium with your vehicle. Select the notification with information about a new version of the map data and start the installation. After the MBUX multimedia system has been restarted, the updated map data is used.

Overview of map data

If map data is reinstalled in a vehicle, no activation code needs to be entered.

For map data purchased as data media, the enclosed activation code must be entered after starting the installation.

Activation codes are only ever valid for one vehicle.

In the event of the following problems, please contact a Mercedes-Benz service centre:

- The multimedia system does not accept the activation code.
- You have lost the activation code.

Displaying the compass

Multimedia system:



- When the map is shown, tap on the ____ current vehicle position until the Position menu is shown.
- Select Compass.

The compass display shows the following information:

- The current direction of travel with bearing (360° format) and compass direction
- Longitude and latitude coordinates in degrees, minutes and seconds
- Number of satellites from which a signal can be received

The information is not available in every country.

Displaying Qibla

Multimedia system:



- When the map is shown, tap on the current vehicle position until the Position menu is shown.
- Select Alerts.

The arrow on the compass shows the direction to Mecca in relation to the current direction of travel.

The number of satellites received is shown.

- i This function is not available in all countries.
- Setting the map scale automatically Multimedia system:



- Select View.
 - Activate Auto zoom.

 When the option is switched on, the map scale is set automatically depending on your driving speed and the type of road.

The automatically selected map scale can be changed manually. After a few seconds, this is automatically reset.

When the option is activated, no detailed display of the junction or a 3D image is shown in the navigation window during an upcoming driving manoeuvre.

Displaying the satellite map

Requirements:

- There is an Internet connection.
- Mercedes me connect is available.
- You have a Mercedes me user account.
- The vehicle is connected with the user account and you have accepted the Mercedes me connect terms of use.

Further information can be found at: https://www.mercedes.me

• Satellite maps are available.

Multimedia system:



Select View.

Activate or deactivate Satellite map.

When Satellite map is selected, they are displayed at the following map scales:

- On-board maps
 The satellite maps are displayed in map scales from 2 km.
- Online maps
 The satellite maps are displayed in highresolution map scales from 10 m.

When Satellite map is not selected, no satellite maps are displayed.

i The display of satellite maps is not available in all countries.

Displaying the range

Requirements:

- There is an Internet connection.
- · Mercedes me connect is available.
- You have a Mercedes me user account.
- The vehicle is connected with the user account and you have accepted the Mercedes me connect terms of use.

Further information can be found at: https://www.mercedes.me

The service is available and has been activated.

Multimedia system:



- Select View.
- Range.

The range is shown on the map with the following displays:

For petrol and diesel vehicles: green display

When the lower reserve capacity is reached then the range display on the map is switched off.

i The range display on the map is not available in all countries.

Displaying online map contents

Requirements:

- · There is an Internet connection.
- · Mercedes me connect is available.
- · You have a Mercedes me user account.

- The vehicle is connected with the user account and you have accepted the Mercedes me connect terms of use.
- Further information can be found at: https:// www mercedes me
- The service is available and has been activated.

Multimedia system:

- Select View.
- Switch on an online service, e.g. Weather. Current weather information is displayed on the navigation map, e.g. temperature or cloud cover.

The service information is not shown in all map scales, e.g. weather symbols.

The display of online map content is not available in all countries.

Parking service

Notes on the parking service

NOTE Damage to the vehicle due to not observing the maximum permitted headroom clearance

If the vehicle height is greater than the maximum permitted headroom clearance, the roof and other parts of the vehicle may be damaged.

- Observe the signposted headroom clearance.
- If the vehicle height is greater than the permitted headroom clearance, do not enter.
- Observe the changed vehicle height with add-on roof equipment.
- This service is not available in all countries.

Selecting parking options

NOTE Vehicle damage due to failure to observe local information and parking conditions

The data is based on the information provided by the respective service providers.

Always observe the local information and conditions.

Requirements:

- Navigation Services is activated in your Mercedes me user account.
- The parking service is part of the scope of the Navigation Services.
- Parking is activated (→ page 408).

Multimedia system:

Tap on **P** the map.

or

In the route overview, select P Parking spaces (\rightarrow page 385).

 Select the search position and search filter, e.g. Near destination and Multi-storey car parks.

The map shows car parks suited to the selected settings.

Select a parking option.

The following information is displayed (if available):

- Destination address, distance from current vehicle position and arrival time
- Information on the multi-storey car park/car park, for example:
 - Opening times
 - Parking charges
 - Current occupancy
 - Maximum parking time
 - Maximum access height

The maximum access height shown by the parking service does not replace the need for observation of the actual circumstances.

- Available payment options (Mercedes pay, coins, bank notes, cards)
- · Details on parking tariffs
- Number of available parking spaces
- Payment method (e.g. at the machine)
- Services/facilities at the parking option
- Telephone number
- Calculate the route (\rightarrow page 381).

The following functions can be used (if available):

- Searching for POIs in the vicinity.
- Saving the destination.
- Placing a call at the destination.
- Sharing the destination via the QR code.
- Calling up the web address.
- Showing the destination on the map.

Displaying parking options on the map

Requirements:

 Navigation Services is activated in your Mercedes me user account. The parking service is part of the scope of the Navigation Services.

Multimedia system:

→ 🔝 **>>** Navigation **>>** 🔘

Activate Parking.

The parking options within the vicinity of the current vehicle position are shown.

Prior booking of a parking space

Requirements:

- Navigation Services is activated in your Mercedes me user account.
- The parking service is part of the scope of the Navigation Services.
- You have registered with your payment details for the payment of parking in the Mercedes me Portal with Mercedes pay and the respective contract partner.
- Parking is activated (→ page 408).
- i This option is not available in all countries.

Multimedia system:

- Select a parking option on the map.
- If a parking space available to book has been selected, select Book parking space.
- Select the desired booking period. Take note of the cancellation conditions. If the parking space is available for the selected period, the price will be shown.
- Press **OK** to confirm.
- In the booking overview, confirm with Book.
- If required, enter the Mercedes me PIN. The parking space will be booked in the background.
 - A booking confirmation including a car park ticket will be sent to your registered e-mail address.

Making use of or cancelling the booking

- Start the Mercedes me App on your smartphone.
- Open Menu.

- Select My transactions.
- Select Parking transactions.
- Select the desired booking.
- To make use of the booking: select Show car park ticket.

or

- To cancel the booking: select Cancel booking.
- If possible, a parking space booking can be cancelled up to the stated time. If a booking cannot be cancelled, this will already be shown to you during the booking procedure.

Paying parking charges

Requirements:

- Navigation Services is activated in your Mercedes me user account.
- The parking service is part of the scope of the Navigation Services.
- You have registered with your payment details for the payment of parking in the Mercedes me Portal with Mercedes pay and the respective contract partner.
- Parking is activated (\rightarrow page 408).

(i) This option is not available in all countries. Multimedia system:



- Select a parking option on the map.
- If a car park that can be paid for has been selected, scroll down in the parking details.
- Select Payment. Once the vehicle has reached a parking position with payment function and the vehicle is switched off, a message appears. Using this message you can pay from the vehicle and start the payment process.

Starting a payment procedure

- Acknowledge the message.
- Please note the maximum parking period displayed and any existing additional limitations. If required, a message will inform you about the necessity of displaying information confirming the online payment for the parking space.
- Select Start the payment process.
- If required, enter the Mercedes me PIN.

410 MBUX multimedia system

- Press OK to confirm. The successful start of your parking transaction is shown.
- Complete the booking with OK.
- ➤ To cancel a parking transaction: after receiving the confirmation request, select Cancel.

 Minimum charges may be incurred.

Ending a parking transaction

- Stop the active transaction using the Mercedes me app.
 - You receive a summary of the procedure and the costs.
 - If an uncompleted parking transaction is detected for your vehicle as you continue your journey, a message will appear asking whether you would like to end it.
- Acknowledge the message.
 When the parking transaction is stopped successfully, another message appears with the details about your completed parking.

Dashcam

Notes on the dashcam

NOTE Risk of legal consequences due to violation of legal regulations and data protection provisions

You are legally responsible for operation and use of the dashcam functions.

The legal requirements relating to operation and use of the dashcam can vary depending on the country in which the dashcam is operated.

This function is not permitted in all countries.

- Before using the dashcam, read up on the content of the legal regulations, in particular the data protection requirements in the respective country of use.
- Observe the legal regulations, in particular the data protection requirements.

- (i) Observe the following instructions for safe operation:
 - Only use FAT32 or exFAT formatted USB storage devices.
 - Use USB-IF certified USB storage devices.
 - USB-IF is a non-profit corporation and stands for USB Implementers Forum. Based on the USB specification, USB-IF certifies, for example, USB versions, corresponding cables and plugs as well as energy supply processes via the USB interface.
 - USB storage devices may be damaged if often or permanently overwritten at high speed. Mercedes-Benz recommends a high-quality SSD drive.
 - The abbreviation SSD stands for Solid State Drive.
- The file size and therefore the duration of single recording is limited by the limitations of the USB flash drive format. Therefore FAT32 formatted USB flash drives do not allow files larger than 4 GB, for example.

When the file size is reached, the recording stops and you receive a notification.

- The following functions are available in the Gallery app:
 - Switching write protection on or off
 - Deleting video files

Additional information about the Gallery app $(\rightarrow page 436)$.

Selecting a USB device for a video recording with the dashcam

Requirements:

 At least one USB device is connected with the multimedia system (\rightarrow page 456).

Multimedia system:

- → Apps → Dashcam
- Select the USB symbol.
- Select the USB device.
- When USB devices contain multiple partitions, recorded video files are not always displayed in the recording list.

Mercedes-Benz recommends that you use USB devices with one partition.

Starting or stopping video recording with the dashcam

Requirements:

- For recording and saving a video file: a USB device is connected with the multimedia system (\rightarrow page 456).
- The vehicle is switched on.

Multimedia system:

→ 📊 **>>** Apps **>>** Dashcam

- If several USB devices are connected with the multimedia system, select a USB device $(\rightarrow page 411)$. If no USB device is selected, a selection is made automatically when recording starts.
- To select a recording mode: select Loop recording or Individual recording. Loop recording records several short video files. When the memory is full, recording is continued automatically. In doing so, other

files will be overwritten starting with the oldest file.

Individual recording stops recording when the memory limit is reached. An individual recording is automatically protected against being overwritten.

- To start: select Start recording. The length of the recording is shown. The Do not remove the storage medium during recording. Before removing the storage medium, eject it first, message appears. The video file is stored on the USB device.
- To end: select End recording.
- In some countries, geo-coordinates (longitude and latitude) are shown in the video image. For technical reasons, the geo-coordinates may show greater inaccuracies.

A report may appear in the following cases:

• Individual recording: the memory is full or there are only a few minutes recording time available. The video recording stops or will be stopped imminently.

Change the USB device or delete a video file.

The camera is not functional, the Camera unavailable message appears.

Have the camera checked in a Mercedes-Benz service centre.

- If the country border indication has been switched on (→ page 412).
- If an outdoor recording is started with the camera app during a dashcam recording, the dashcam recording pauses and resumes automatically after the camera recording is finished. A notification to this effect is displayed.

Configuring dashcam settings

Requirements:

A USB device is connected with the multimedia system (→ page 456).

Multimedia system:

→ Apps → Dashcam

Select .

Receiving notifications after passing a border crossing

- Activate National border alert . A message is shown if video is being recorded and the vehicle passes a border.
- i This function is not available in all countries.

Starting automatic video recording

- Select Automatic loop recording.
- Activate Automatic loop recording.
 When the vehicle is started, video recording starts automatically.
- i This function is not available in all countries.

Telephone

Telephony

Notes on telephony



WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
 - If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

WARNING Risk of accident from operating mobile communication equipment while the vehicle is in motion

Mobile communication devices distract the driver from the traffic situation. This can also cause the driver to lose control of the vehicle.

- As a driver, only operate mobile communication devices when the vehicle is stationary.
- As a vehicle occupant, use mobile communication devices only in the designated area, e.g. in the rear passenger compartment.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system and mobile communication equipment in the vehicle.

WARNING Risk of injury due to objects being stowed incorrectly

If objects in the vehicle interior are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone receptacles cannot always retain all objects within.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects so that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, luggage nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the boot/load compartment.

Observe the additional information on stowing mobile communications devices correctly:

 Loading the vehicle (→ page 129) Further information can be obtained from a Mercedes-Benz service centre or at: https:// www.mercedes-benz-mobile.com/

Telephone menu overview



- Bluetooth® device name of the currently connected mobile phone/of the mobile phone
- Bluetooth® device name of the currently connected mobile phone/of the mobile phone (when several mobile phones are connected)
- Signal strength of the mobile phone network
- Battery status of the connected mobile phone

414 MBUX multimedia system

- Options
- Messages
- Calls up devices
- Numerical pad
- Starts contact search

Bluetooth® profile overview

Bluetooth® profile of the mobile phone	Function
PBAP (Phone Book Access Profile)	Contacts are automatically displayed in the multimedia system
MAP (M essage A ccess P rofile)	Message functions can be used
HFP (H ands F ree P rofile)	Wireless telephony is available

Overview of mobile phone usage

Depending on the equipment up to four mobile phones can be connected at once:

A mobile phone is connected to the multimedia system via Bluetooth[®] (→ page 414).

- Additional mobile phones are connected with the multimedia system via Bluetooth[®] (→ page 415).
 - You can use all the functions of the multimedia system with all mobile phones.
- (i) Irrespective of this, Bluetooth® audio functionality can by used with any mobile phone (→ page 456).

Information on telephony

The following situations can lead to the call being disconnected while the vehicle is in motion:

- There is insufficient network coverage in the area
- You move from one transmission/reception station to another and no communication channels are free
- The SIM card used is not compatible with the network available
- A mobile phone with "Twincard" is logged into the network with the second SIM card at the same time

The multimedia system supports calls in HD Voice® for improved speech quality. A requirement for this is that the mobile phone and the mobile phone network provider of the person you are calling support HD Voice® .

Depending on the quality of the connection, the voice quality may fluctuate.

Connecting a mobile phone

Requirements

- Bluetooth[®] is activated on the mobile phone (see the manufacturer's operating instructions).
- Bluetooth[®] is activated on the multimedia system (→ page 356).

Multimedia system:



Searching for a mobile phone

Select Connect new device.

Authorising a mobile phone

- Select a mobile phone. A code is displayed in the multimedia system and on the mobile phone.
- If the codes match: confirm the code on the mobile phone.
- For older mobile phone models, enter a one to sixteen-digit number code on the mobile phone and on the multimedia system for authorisation.
- (i) Up to 15 mobile phones can be authorised on the multimedia system.
- Up to four of the mobile phones activated in the driver's user profile are automatically reconnected.
- (i) A mobile phone can be used by the driver and front passenger as a Bluetooth® audio device $(\rightarrow page 456)$.

You can watch an animation on this topic via the following link:

Connecting an additional mobile phone

Requirements

• At least one mobile phone is already connected to the multimedia system via Bluetooth®.

Multimedia system:

→ 🔝 >> Phone >> 🐞 >> Devices Devices

- Select Connect new device.
- Select the mobile phone.

Switching between mobile phones Multimedia system:

¬→ 🔝 >>> Phone

The connected mobile phones are shown individually in separate tabs.

Select the tab with the desired mobile phone. Selecting the tab of a specific mobile phone displays the associated telephone contents. Selecting the other tab switches the view to the other telephone.

The submenus in the telephone menu (e.g. contacts, call lists, messages) relate to the currently selected mobile phone with the exception of the telephone settings. In the telephone settings, settings can be made for both mobile phones.

Changing the function of a mobile phone Multimedia system:

Devices

Activating a function

Select a grey symbol in the line of a mobile phone. The corresponding function is activated.

Deactivating a function

- One function is active: select the coloured symbol in the line of a mobile phone. The mobile phone is disconnected from the multimedia system.
- Several functions are active: de-select an active function in the line of one of the mobile phones.

The corresponding function is deactivated.

Deleting a mobile phone

Multimedia system:

- Select Devices.
- Select ••• in the line of the mobile phone.
- ➤ Select Delete device.

The mobile phone is deleted from the system.

Starting or stopping mobile phone voice recognition

Requirements:

- At least one mobile phone is connected to the multimedia system (→ page 414).
- The tab with the mobile phone for which voice recognition should be started is selected (→ page 415).

Starting mobile phone voice recognition

Press and hold the total button on the multifunction steering wheel for more than one second.

Voice recognition is started for the currently selected mobile phone.

Stopping mobile phone voice recognition

- Press the 🐧 or 🕥 button on the multifunction steering wheel.
- (i) If a mobile phone is connected via Smartphone Integration, the voice recognition of this mobile phone is always started or stopped.

Note about contact suggestions

The multimedia system can show contact suggestions based on frequently used contacts, outgoing calls and text messages. For this, the Allow contact suggestions option must be switched on (→ page 359).

When you open the call list or the message menu, contacts which you can call or write to will be suggested to you. Suggestions will be shown in the Suggestionstab.

- i The multimedia system does not use the content of messages for suggestions.
- Selecting options for contact suggestions

Requirements:

•

• The multimedia system has gathered sufficient data in order to show contact suggestions.

Multimedia system:

¬→ 🔝 >>> Phone

- Select Call list or Contacts.
- Select Suggestions.
- Select in the line of the suggested contact.

The following option is available for selection:

Do not suggest now

Calls

Telephone operation Multimedia system:

→ 🔐 >>> Phone

Making a call by entering the numbers

- Select .
- Enter a number.
- Select .
 The call is made.

Accepting a call

Select Accept .

Rejecting a call

► Select Reject.

Answering a call with a message

➤ Select = Reply.

Ending a call

Select <</p>

Activating functions during a call

The following functions are available during a call:

- End call
- Micro. off
- Keypad (show to send DTMF tones)
- Add call
- Hands-free Transfer the call, e.g. to Front, Rear or All seats.
- Private mode

Transfer the call the telephone or headphones. for example.

- Select a function.
- Observe that the functions and symbols can vary depending on the vehicle equipment.

Conducting calls with several participants

Requirements:

- There is an active call (→ page 416).
- Another call is being made.

Switching between calls

Select the contact. The selected call is active. The other call is on hold.

Activating a call on hold

Select the contact of the call on hold.

Conducting a conference call

Select Conference. The new participant is included in the conference call.

Ending an active call

- Select End call.
- On some mobile phones, the call on hold is activated as soon as the active call is ended.

Accepting or rejecting a waiting call

Requirements

There is an active call (→ page 416).

If you receive a call while already in a call, a message is displayed.

Depending on the mobile phone and mobile phone network provider you will hear a call waiting signal.

If several mobile phones are connected, you will hear an acoustic signal when the call goes through to the other (not yet active) mobile phone.

Select Accept. The incoming call is active.

If only one mobile phone is connected with the multimedia system, the previous call will be put on hold.

If several mobile phones are connected and during a call you accept a call with the other mobile phone then the existing call is ended.

or

Select Reply.

The incoming call is not accepted.

You answer with a message.

or

- Select Reject.
- This function and behaviour depends on your mobile phone network provider and the mobile phone (see the manufacturer's operating instructions).

International calls overview

Depending on your mobile phone network provider, you may have to use an international dialling code before you make an international call.

The international dialling code varies depending on the mobile phone network provider. You can contact your mobile phone network provider to obtain the dialling code.

Setting the international dialling code

Multimedia system:

- Select Modify.
- Enter numbers.
- Select OK.

Numbers in the phone book beginning with a "+", are extended with the international dialling code set when placing a call.

Using the international dialling code Multimedia system:

- → 🔝 → Phone → 🟢
- Press and "0" until a "+" appears in the selection field.
- Enter the numbers of the country code, regional code and the telephone number.
- Select .
 The call is made.

Contacts

Information about the contacts menu

The contacts menu contains all contacts from existing data sources, e.g. mobile phone or data storage medium.

Depending on the data source, it is possible to save/load the following number of contacts:

- Permanently saved contacts: 3,000 entries
- Contacts loaded from the mobile phone:
 5,000 entries per mobile phone

From the contacts menu, you can perform the following actions:

- Make a call, for example call a contact (→ page 419)
- Navigation (→ page 379)
- Compose messages (→ page 421)
- Additional options (→ page 420)

Mobile phone contacts are automatically displayed when a mobile phone is connected to the multimedia system (\rightarrow page 414).

Downloading mobile phone favourite contacts

If the mobile phone supports the function, the favourites of the mobile phone are automatically loaded and appear in the overview of the phone menu.

Calling up contacts

Multimedia system:



The following options can be used to search for contacts:

- Searching by initials
- Searching by name
- Searching by phone number
- Enter characters into the search field.
- Select the contact.

A contact can contain the following details:

- Phone numbers
- Navigation addresses
- Internet address
- Email addresses
- Relationship (if set)

Managing the format of a contact's name Multimedia system:

¬→ 🔝 >> Phone >> 💆

- Select Name format.
- Select an option.
- Overview of importing contacts

Importing contacts into the contacts menu

Source	Requirements
USB device	The USB device is connected with the USB port.
Mobile phone	A mobile phone is connected to the multimedia system via Bluetooth®.
	Contacts are available.

Note that the imported contacts remain in the vehicle and can be accessed at any time regardless of the connected mobile phones.

Importing contacts into the contacts menu Multimedia system:

→ Phone → Contacts

>> Import contacts

- Select a mobile phone <device name>, from which the contacts should be imported.
- Select an option.

Saving a mobile phone contact Multimedia system:

- Select in the line of the mobile phone contact.
- Select ···..
- Select Save.
 - Select Yes.

The contact saved in the multimedia system is identified by the MBUX symbol.

Calling a contact

Multimedia system:

→ 🔝 >> Phone >> Contacts

Search contacts.

420 MBUX multimedia system

- Enter characters into the search field.
- Select the contact.
- Select the telephone number.
 The number is dialled.

Selecting further options in the contacts menu Multimedia system:

- → Phone → Contacts
- ► Select > in the line of the contact.
- ► Select ····.
- Select an option.

Deleting contacts

Requirements:

- The contacts are saved in the vehicle.
- To delete an individual contact, this has been imported manually into the vehicle.

Multimedia system:



Deleting all contacts

Select .

- Select Contacts.
- Select Delete all MBUX contacts.
- Select an option.

Deleting a contact

- Select Contacts.
- Select in the line of the contact.
- Select
- Select Delete contact.
- Select Yes.

Call list

Overview of the call list

Depending on whether your mobile phone supports the PBAP Bluetooth® profile or not, this can have different effects on the presentation and functions of the call list.

If the PBAP Bluetooth® profile is supported, the effects are as follows:

 The call lists from the mobile phone are displayed in the multimedia system. When connecting the mobile phone, you may have to confirm the connection for the PBAP Bluetooth® profile.

If the PBAP Bluetooth[®] profile is not supported, the effects are as follows:

- The multimedia system generates a call list independently as soon as calls are made in the vehicle.
- The call list is not synchronised with the call lists in the mobile phone.

Making a call from the call list

Multimedia system:

- → 🔐 >> Phone
- ► Select Call list.
- Select an entry. The call is made.

Selecting additional options in the call list Multimedia system:

- → Phone
- Select 🜈 Call list.

- For contacts that are in the address book: select options. The contact details are called up.
- For contacts where only one number is shown (not in the address book): select [...

Deleting the call list

Multimedia system:

- → Phone → <device name> ▶ Devices
- Select Delete call list.
- Select Yes.
- This function is only available if your mobile does not support the PBAP Bluetooth® profile.

Text messages

Overview of message functions

In the message menu you can receive text messages and Apple iMessages and create and send them with the help of the MBUX Voice Assistant.

If the connected mobile phone supports the Bluetooth® MAP profile, the message function can be used on the multimedia system.

You can obtain further information about settings and supported functions of Bluetooth®-capable mobile phones at a Mercedes-Benz service centre or at: https://www.mercedes-benz-mobile.com/

Some mobile phones require further settings after being connected to the multimedia system to activate the messaging functionality (see manufacturer's operating instructions).

Setting message displays

Multimedia system:

→ Phone >> <device name> ▶ Devices

- Select Message display.
- Select On or Off.

Reading messages

Multimedia system:

>> Q(

Using the read-aloud function

A message list is shown.

- To read aloud, select the symbol at a conversation. The message is read aloud.
- Creating and sending a new message

Requirements:

There is an Internet connection.

Multimedia system:



Using the MBUX voice assistant, speak the voice command Send a message to, and name the desired contact (\rightarrow page 316).

Dictating text

- Say the message. You are guided by the voice dialogue.
- Replying to a message in the messaging history Multimedia system:



A message list is shown.

422 MBUX multimedia system

- ➤ Select next to a contact.

 The messaging history with this contact is shown. You will be guided through the steps with the help of a voice dialogue.
- Select .
 The dictation function is started.
- Say the message.

 After the voice message has been processed, it is shown as text.
- ► Select Send or speak in the dialogue.

Forwarding messages

Multimedia system:



A message list is shown.

- Speak the voice command Forward message. You are guided by the voice dialogue.
- Calling a message sender

Multimedia system:

A message list is shown.

- Select next to a contact. The messaging history with this contact is shown.
- ► Select ···..
- Select Call.
- Using telephone numbers, URLs or email addresses from a text message

Requirements

An Internet connection is available to call up a URL.

Multimedia system:



A message list is shown.

- Select \(\sum_ \) next to a contact.

 The messaging history with this contact is shown.
- Select a telephone number or a URL in the message.
 - If a URL is selected the web browser opens.

If a telephone number is selected the following options are available:

- Call
- · New message
- Select an option.

Deleting a message

Multimedia system:



A message list is shown.

- Select a contact.
- Press and hold on a message.
- ➤ To delete the message: select Delete.

In-Car Calendar

In-Car Calendar functions

Using In-Car Calendar, you can connect your online services to the multimedia system.

The following functions are available to you:

Calendar

- Showing appointments and triggering actions, e.g. reading aloud, placing a call, navigating
- Notifications or reminders from In-Car Calendar, such as appointments are shown in the zero layer (\rightarrow page 325).
- (i) Please note that certain functions are only available when the vehicle is stationary.

Calling up In-Car Calendar

Requirements

- You have a Mercedes me user account.
- The In-Car Calendar service is activated in vour Mercedes me user account.
- You have a user account with an online service, for example Office 365. In this way, appointments, e-mails and tasks can be synchronised and facilitated.

Multimedia system:



Select In-Car Calendar. Individual functions from In-Car Calendar can be called up.

Linking a user account

- Select the desired online service.
- Scan the QR code.
- Follow the instructions on the device.

Selecting calendar functions in In-Car Calendar Multimedia system:



- Select an appointment.
- Select a function. The following functions are available:
 - Read aloud
 - Call
 - Navigate
 - Delete
- (i) Functions are available if corresponding appointment information is saved.
 - Examples of this are:
 - If a telephone number has been saved for the appointment, Call is available.

 If a navigable address has been saved in the Online Account for the appointment, Navigate is available.

Apple CarPlay®

Overview of Apple CarPlay®

WARNING Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

iPhone® functions can be used via the multimedia system using Apple CarPlay®. They are operated using the touchscreen, Touch Control or the Siri® voice control system. You can activate the voice control system by pressing and holding the button on the multifunction steering wheel.

i) By briefly pressing the
 multifunction steering wheel you can continue
to operate the multimedia system using the
MBUX voice assistant (→ page 316).

Only one iPhone $^{\text{\tiny B}}$ at a time can be connected via Apple CarPlay $^{\text{\tiny B}}$ with the multimedia system.

As access to the iPhone[®] is restricted by MBUX when a CarPlay[®] session is active, not all MBUX functions (e.g. dialling from the address book) can be fully provided for the connected device. In this case use Apple CarPlay[®].

The full range of functions for Apple CarPlay[®] is only available with an Internet connection.

The availability of Apple CarPlay[®] may vary according to the country.

The service provider is responsible for this application and the services and content connected to it.

Apple $\mbox{CarPlay}^{\mbox{\scriptsize @}}$ is a registered trademark of Apple Inc.

You can watch an animation on this topic via the following link:

■ Information on Apple CarPlay®

The Apple CarPlay[®] symbol in the status line switches within Apple CarPlay[®] to the last active display.

If route guidance is active on the multimedia system, it is closed when route guidance is started on the mobile phone.

Connecting an iPhone® via Apple CarPlay® (wired)

Requirements

 The current version of your device's operating system is being used (see the manufacturer's operating instructions).

- (i) For safety reasons, the first activation of Apple CarPlay[®] on the multimedia system must be carried out when the vehicle is stationary and the parking brake applied.
- Connect the iPhone® to a USB port on the multimedia system using a suitable cable (→ page 456).

When the application is connected for the first time, a message about data protection regulations appears.

Select Accept & start if the application should be started.

or

- \triangleright Open the device manager (\rightarrow page 415).
- Start Apple CarPlay® using the relevant symbol next to the device name.
- i If applicable, a message about data protection regulations appears.
- If required confirm the use of Apple CarPlay® on your iPhone®.

Exiting Apple CarPlay®

► Select 🟠.

or

- Press the button on the multifunction steering wheel (MBUX multimedia system).
- If Apple CarPlay® was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Apple CarPlay® using the Apple CarPlay® symbol in the status line.

Connecting an iPhone® via Apple CarPlay® (wireless)

Requirements

- The current version of your device's operating system is being used (see the manufacturer's operating instructions).
- Bluetooth® is activated on the device (see the manufacturer's operating instructions).
- The device is "visible" for other devices.
- For safety reasons, the first activation of Apple CarPlay® on the multimedia system must be carried out when the vehicle is stationary and the parking brake applied.

Multimedia system:

→ 🚡 >> Phone >> 💍 >> Devices

- Connect the mobile phone using Bluetooth® $(\rightarrow page 414)$. When the application is connected for the first time, a message about data protection regulations appears.
- Select Accept & start Apple CarPlay if the application should be started.
- If required confirm the use of Apple CarPlay® on your iPhone®.
- It is possible at any time to switch between connection via Bluetooth® or Apple CarPlay® (wireless) in the device list.
- (i) If you have already connected a mobile phone via Bluetooth®, you can connect another iPhone® via Bluetooth® to use Apple CarPlay® via the device manager.

Exiting Apple CarPlay®

Select 🞧.

or

- Press the button on the Touch Control (MBUX multimedia system).
- If Apple CarPlay® was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Apple CarPlay® using the Apple CarPlay® symbol in the status line.
- Calling up Apple CarPlay® sound settings Multimedia system:
- → 🔝 ➤ Settings ➤ System ➤ Audio
- Select the sound settings.

Ending Apple CarPlay®

- Select the Apple CarPlay® symbol in the device manager (telephone, media) that is next to the device name of the iPhone®.
- Select the Apple CarPlay® symbol in the device manager in the telephone or media applications if Apple CarPlay® should be restarted.

If Apple CarPlay® was not displayed in the foreground before disconnecting, the application starts in the background the next time it is started automatically. You can call up Apple CarPlay® using the relevant symbol in the status line.

Android Auto

Android Auto overview

★ WARNING Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road

and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

i By briefly pressing the [■€] button on the multifunction steering wheel you can continue to operate the multimedia system using the MBUX voice assistant (→ page 316).

Only one mobile phone at a time can be connected via Android Auto with the multimedia system.

The full range of functions for Android Auto is only possible with an Internet connection.

The availability of Android Auto and Android Auto apps may vary according to the country.

The service provider is responsible for this application and the services and content connected to it.

You can watch an animation on this topic via the following link:

Information on Android Auto

The Android Auto symbol in the status line switches within Android Auto to the last active display.

If route guidance is active on the multimedia system, it is closed when route guidance is started on the mobile phone.

Connecting a mobile phone via Android Auto (wired)

Requirements

- The mobile phone supports Android Auto from Android 5.0.
- The current version of the Android Auto app is installed on the mobile phone.
- In order to use the telephone functions, the mobile phone must be connected to the multimedia system via Bluetooth[®] (→ page 414).

If there was no prior Internet connection, this is established with the use of the mobile phone with Android Auto.

- (i) For safety reasons, the first activation of Android Auto on the multimedia system must be carried out when the vehicle is stationary with the parking brake.
- Connect the mobile phone to a USB port on the multimedia system using a suitable cable $(\rightarrow page 456)$.

When the application is connected for the first time, a message about data protection regulations appears.

Select Accept & start if the application should be started.

- Open the device manager (\rightarrow page 415).
- Start Android Auto using the relevant symbol next to the device name.

Exiting Android Auto

Select 向.

- Press the button on the Touch Control (MBUX multimedia system).
- If Android Auto was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Android Auto using the Android Auto symbol in the status line.

Connecting a mobile phone via Android Auto (wireless)

Requirements

- The current version of your device's operating system is being used (see the manufacturer's operating instructions).
- The device supports the Android Auto function (wireless).
- Bluetooth® is activated on the device (see the manufacturer's operating instructions).
- The device is "visible" for other devices.
- Bluetooth® is activated on the multimedia system (\rightarrow page 356).
- (i) For safety reasons, the first activation of Android Auto on the multimedia system must

- be carried out when the vehicle is stationary with the parking brake.
- The Android Auto function (wireless) is not available in all countries.

Multimedia system:

- Connect the mobile phone using Bluetooth® $(\rightarrow page 414)$.
- Depending on the device configuration, the guery whether Android Auto should be started may appear on the central display after connecting the mobile phone via Bluetooth®. In this case, the guery must be answered with Yes.
- Select Start Android Auto. When the application is connected for the first time, a message about data protection regulations appears.
- Select Accept & start.
 - It is possible at any time to switch between connection via Bluetooth® or Android Auto (wireless) in the device list.

(i) If you have already connected a mobile phone via Bluetooth®, you can connect additional mobile phones via Bluetooth® to use Android Auto via the device manager.

Exiting Android Auto

► Select 🞧.

or

- Press the button on the Touch Control (MBUX multimedia system).
- i If Android Auto was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Android Auto using the Android Auto symbol in the status line.
- Calling up the Android Auto sound settings Multimedia system:
- → 😭 ➤ Settings ➤ System ➤ Audio
- Select the sound settings.

Ending Android Auto

Select the Android Auto symbol in the device manager (telephone, media) that is next to the device name of the mobile phone.

- i Select the Android Auto symbol in the device manager if Android Auto should be restarted.
- i If Android Auto was not displayed in the foreground before disconnecting, the application starts in the background the next time it is started automatically. You can call up Android Auto using the Android Auto symbol in the status line.

Transferred vehicle data with Android Auto and Apple CarPlay®

Overview of transferred vehicle data

When using Smartphone Integration, certain vehicle data is transferred to the mobile phone. This enables you to get the best out of selected mobile phone services. Vehicle data is not directly accessible.

The following system information is transmitted:

- Software release of the multimedia system
- System ID (anonymised)

The transfer of this data is used to optimise communication between the vehicle and the mobile phone. To do this, and to assign several vehicles to the mobile phone, a vehicle identifier is randomly generated.

This has no connection to the vehicle identification number (VIN) and is deleted when the multimedia system is reset (\rightarrow page 362).

The following driving status data is transmitted:

- Transmission position engaged
- Distinction between parked, standstill, rolling and driving
- Day/night mode of the driver's display
- Drive type

The transfer of this data is used to alter how content is displayed to correspond to the driving situation.

The following position data is transmitted:


- Coordinates
- Speed
- Compass direction
- · Acceleration direction

This data is used by the mobile phone to improve the accuracy of the navigation (e.g. for continuation in a tunnel).

Mercedes me calls

Making a call via the overhead control panel

Mercedes me calls are not possible in every country. Find out at a Mercedes-Benz service centre if these functions are available in your country.



- me button for service or information calls
- SOS button cover
- SOS button (emergency call system)

Making a Mercedes me call

Press me button ①.

Making an emergency call

- To open the cover of SOS button (2), press it briefly.
- Press and hold SOS button (3) for at least one second.

If a Mercedes me call is active, an emergency call can still be triggered. This has priority over all other active calls.

Information about the Mercedes me call using the me button

A call to the Mercedes-Benz Customer Centre has been initiated via the me button in the overhead control panel or the multimedia system $(\rightarrow page 429)$.

Using the voice dialogue system you access the desired service:

- · Accident and Breakdown Management
- Mercedes-Benz Customer Centre for general information about the vehicle

You can find information on the following topics:

- Activation of Mercedes me connect
- Operating the vehicle

- Nearest Mercedes-Benz service centre
- Other products and services from Mercedes-Benz

Data is transferred during the connection to the Mercedes-Benz Customer Centre (→ page 432).

Calling the Mercedes-Benz Customer Centre using the multimedia system

Requirements:

- Access to a GSM network is available.
- The contract partner's GSM network coverage is available in the respective region.
- The vehicle must be switched on so that vehicle data can be transferred automatically.

Multimedia system:





Call Mercedes me connect. After confirmation, the multimedia system sends the required vehicle data. The data transfer is shown in the display.

Then you can select a service and be connected to a specialist at the Mercedes-Benz Customer Centre.

■ Calling the Mercedes-Benz Customer Centre after automatic accident or breakdown detection

Requirements:

- The vehicle has detected an accident or breakdown situation.
- The vehicle is stationary.
- The hazard warning lights are switched on.
- This function is not available in all countries.

The vehicle can detect accident or breakdown situations under certain circumstances.

Requirements for collision detection in the context of accident management:

- The vehicle is equipped with an anti-theft alarm system (ATA) (code 551).
- The vehicle is equipped with the interior protection (code 882).
- The vehicle is equipped with the Anti-Theft Protection Package (code P54).

The collision detection service with theft notification has been activated on Mercedes me connect.

If a collision is detected when the tow-away protection is primed on a locked vehicle, you will receive a notification in the multimedia system when you switch the vehicle on.

Find out at a Mercedes-Benz service centre if this functions is available in your country.

In the event an accident or breakdown is detected, the emergency guide shows safety notes in the multimedia system display. This may take a few seconds.

The availability of collision detection depends on the vehicle.

After quitting the emergency guide display on the multimedia system, a prompt appears asking whether you would like to get support from the Mercedes-Benz Customer Centre.

- Select Call.
 - After your agreement, or if the Mercedes me connect service "Accident and Breakdown Management" is active, the vehicle

- data is transferred automatically $(\rightarrow page 434)$.
- The Mercedes-Benz Customer Centre takes your call and organises the breakdown and accident assistance.

You may be charged for these services.

- i) Depending on the severity of the accident, an automatic emergency call can be initiated. This has priority over all other active calls $(\rightarrow page 440)$.
- (i) In addition, if the Mercedes me connect service "Telediagnostics" is active, a similar prompt can appear after a delay in the event of a breakdown. If you are already in contact with the Mercedes-Benz Customer Centre or have already received support, this prompt can be ignored or declined.
- (i) If you answer the prompt for support from the Mercedes-Benz Customer Centre with Call later, the message will be hidden and appear again later.
 - The prompt triggered by the Mercedes me connect service "Telediagnostics", can either

be confirmed or declined. After being declined, this will not be shown again.

Arranging a service appointment via a Mercedes me call

If you have activated the maintenance management service, relevant vehicle data is transferred automatically to the Mercedes-Benz Customer Centre. You will then receive individual recommendations regarding the maintenance of your vehicle.

Regardless of whether you have consented to the maintenance management service, the multimedia system reminds you after a certain amount of time that a service is due. A prompt appears asking if you would like to make an appointment.

To arrange a service appointment: select Call. After your agreement, the vehicle data is transferred and the Mercedes-Benz customer centre takes your preferred appointment date. The information is then sent to your desired service outlet.

This will contact you to confirm the appointment and if necessary consult about the details.

(i) If you select Call later after the service message appears, the message is hidden and reappears at a later time.

Giving consent to data transfer during a Mercedes me call

Requirements

- There is an active Mercedes me call via the multimedia system or the me button in the overhead control panel (\rightarrow page 429).
- The prompt to confirm data transfer does not appear in all countries.

If the Accident and Breakdown Management services are not activated on Mercedes me, the Do you want to transfer your vehicle data and the vehicle's position to the Mercedes-Benz Customer Centre to improve the processing of your request? message is shown.

- (i) The exact phrase may differ depending on the multimedia system installed.
- Select Yes.
 - The relevant vehicle data is sent automatically (\rightarrow page 432).

or

- Select No and confirm.
 - Only call control data is transmitted (→ page 432).

More information on Mercedes me: https://www.mercedes.me

Data transferred during a Mercedes me call

If you initiate a service call using Mercedes me, data is transferred to enable targeted advice and an efficient service.

The following requirements must be fulfilled for the transfer of the data:

- · The vehicle is switched on.
- The required data transfer technology is supported by the mobile phone network provider.
- The quality of the mobile connection is sufficient.

Multi-stage transfer depends on the following factors:

- · Reason for the initiation of the call
- The available mobile phone transmission technology

- The activated Mercedes me connect services
- The service selected in the voice control system
- (i) A prompt for consent to the data transfer only occurs if the corresponding Mercedes me connect service is not activated.
- The scope of the data transmitted depends on the vehicle model and equipment. For technical reasons, not all data is available at all times.

Data transfer if Mercedes me connect services are not activated

If no Mercedes me connect services are activated and the data protection prompt has been confirmed the following data is transmitted:

- Vehicle identification number
- · Time of the call
- · Reason for the initiation of the call
- Confirmation of the data protection prompt
- · Country indicator of the vehicle
- Set language for the multimedia system

 Telephone number of the communication platform installed in the vehicle

If a call is made for a service appointment via the service reminder, the following data is also transmitted:

· Current mileage and maintenance data

If a call is made after automatic accident or breakdown detection using the multimedia system, the following data is also transmitted:

- · Current mileage and maintenance data
- Current vehicle location

If Accident and Breakdown Management is called via the voice control system and no service has been activated, but the data protection query has been confirmed, the following data can also be called up from the vehicle by the Mercedes-Benz Customer Centre:

· Current vehicle location

If the data protection prompt has been rejected, the following data is transmitted to enable targeted advice and an efficient service:

Vehicle identification number

- . Time of the call
- Reason for the initiation of the call
- Rejection of the data protection prompt
- Country indicator of the vehicle
- Set language for the multimedia system
- Telephone number of the communication platform installed in the vehicle

Data transfer if Mercedes me connect services are activated

Only if the respective service is activated will additional incident-specific data be transmitted in the second stage to enable an optimal service.

An overview of the data transferred is contained in the data protection information for the Mercedes me connect services. You can find these in your Mercedes me user account.

Data processing

The data transmitted within the scope of the call is deleted from the processing system after the call is finished, in so far as this data is not being used for other activated Mercedes me connect services.

The incident-specific data is processed and stored in the Mercedes-Benz Customer Centre and, if required to process the incident, forwarded to the service partner authorised by the Mercedes-Benz Customer Centre. Take note of the data protection information on the Mercedes me Internet page https://www.mercedes.me or in the recorded message immediately after calling the Mercedes-Benz Customer Centre.

The recorded message is not available in every country.

Mercedes me connect

Information on Mercedes me connect

Mercedes me connect or individual Mercedes me connect services are not available in every country. Find out at a Mercedes-Benz service centre if these functions are available in your country.

Mercedes me connect consists of multiple services.

You can use the following services via the multimedia system and the overhead control panel, for example:

- · Accident and Breakdown Management (me button or situation-dependent display in the multimedia system)
- Mercedes-Benz Emergency Call System (automatic emergency call and SOS button)

The Mercedes me connect Accident and Breakdown Management and the Mercedes-Benz emergency call centre are available to you around the clock.

The me button and the SOS button can be found on the vehicle's overhead control panel $(\rightarrow page 429)$.

You can also call the Mercedes-Benz Customer Centre using the multimedia system $(\rightarrow page 430)$.

Please note that Mercedes me connect is a Mercedes-Benz service. In emergencies, first call the national emergency services using the standard national emergency service telephone numbers. In emergencies, you can also use the

Mercedes-Benz emergency call system $(\rightarrow page 440)$.

Please note the Mercedes me connect terms of use and the data protection information for Mercedes me connect. You can find these in your Mercedes me user account.

■ Information on Mercedes me connect Accident and Breakdown Management

 Accident and Breakdown Management is not available in every country. Contact a Mercedes-Benz service centre to find out whether this function is available in your country.

The Accident and Breakdown Management can include the following functions:

 Supplement to the Mercedes-Benz emergency call system (→ page 440)
 If necessary, the contact person at the Mercedes-Benz emergency call centre forwards the call to Mercedes me connect Accident and Breakdown Management. Forward-

tries.

ing the call is however not possible in all coun-

- Breakdown assistance by a technician on location and/or the towing away of the vehicle to the nearest Mercedes-Benz service centre You may be charged for these services.
- Addition to the emergency guide after automatic accident or breakdown detection
 (→ page 430)

In the event of a breakdown or accident, further vehicle data is sent which enables optimal support by the Mercedes-Benz Customer Centre and the authorised service partner or breakdown assistance.

 Addition to the Mercedes me connect service Telediagnostics

With the Telediagnostics function, specific wear and failure reports are recorded by the service provider, in so far as these can be clearly interpreted and are available through the monitoring of components that are subject to diagnostics.

If your vehicle detects a breakdown or threat of a breakdown, you may be prompted via the multimedia system to contact the Mercedes-Benz Customer Centre for further help. This

- prompt in the multimedia system only appears when the vehicle is stationary.
- (i) These services are subject to technical restrictions such as the mobile phone coverage, mobile network quality and the ability of the processing systems to interpret the transferred data. In some circumstances, this can result in delays or the failure of the information to appear in the multimedia system.

Please note that the service and breakdown call is a Mercedes-Benz service. In emergencies, be sure to contact the usual national emergency number first or use the Mercedes-Benz emergency call system (→ page 438).

More information about Mercedes me connect services can be obtained in the Mercedes me Portal: https://me.secure.mercedes-benz.com

Data transferred during Mercedes me connect call services

The data transferred during a Mercedes me connect call depends on:

The reason for initiation of the call

- The service that is selected in the voice control system
- The activated Mercedes me connect services

You can find out which data is transferred when using the services in the currently valid Mercedes me connect terms of use and the data protection information for Mercedes me connect. You can find these in your Mercedes me user account.

Mercedes me Apps

Information about Mercedes me

With a Mercedes me user account you have access to Mercedes-Benz services and offers.

Availability is dependent both on the country and equipment.

You can obtain further information at a Mercedes-Benz service centre or in the Mercedes me Portal: https://me.secure.mercedes-benz.com

Further information about on-demand features via Mercedes me can be found in the "General notes" section (\rightarrow page 25).

- Make sure you always keep the Mercedes me apps updated.
- Calling up the Mercedes me user account Multimedia system:

→ Apps → Mercedes me

Vehicle is linked to user account and Mercedes me is available

Select Mercedes me ID. Information about the linked user account appears.

Your vehicle is not linked to the user account.

- (i) If you do not yet have a Mercedes me user account, you can create one at: https:// www.mercedes.me or in the Mercedes me App. A valid email address or phone number is required for this.
- Select 🞧.
- Select Apps.
- Select Mercedes me.
- Follow the instructions on the display to link the user account with the vehicle.

- (i) If the Mercedes me App is available on a mobile phone, the vehicle connection can be accomplished using the QR code shown.
- Calling up the Mercedes me services

Requirements:

 The vehicle is connected with the user account.

Multimedia system:

→ Apps → Mercedes me

Select My services.

The Mercedes me connect services for which you have a valid licence are displayed in alphabetical order.

Ordering or extending Mercedes me connect services

To order or renew Mercedes me connect services, use the Store.

Select ().

Select Store.

■ Deleting a connection between a user account and the vehicle

Requirements

- The user profile of the user account that was first linked to the vehicle is selected.
- The user profile is synchronised (→ page 339).
- A Mercedes me PIN has been set.

Multimedia system:

- → Apps → Mercedes me
- Select Mercedes me ID.
- Select Delete vehicle connection.
- Only the user, whose user account was first connected with the vehicle can delete the connection between all user accounts and the vehicle.

Selecting apps

Requirements:

 Depending on the app, the general terms and conditions are confirmed. Multimedia system:



Select an app.

The following apps are available, for example:

- Weather
- Browser
- Additional apps, which are purchased or installed subsequently
- i You can also access both of the first two apps via the quick access at Apps.
- i The available features are country-dependent. Licence fees may be applicable.

The following functions are available for apps, for example:

- Search function
- Filter function, for displaying search results at the current vehicle position or at the destination
- Display of detailed information
- Read-aloud function
- Setting functions

Using the Gallery app

Requirements

- For the use of the share content function:
 - The Mercedes me App is installed on the device, e.g. a mobile phone or a tablet.
 - For Internet connection, the multimedia system is used as a WLAN hotspot (→ page 357).

Multimedia system:



Select Gallery.

Images and video recordings are displayed from the following sources, for example:

- · Dashcam video recordings
- · Collision detection images
- Video recordings and images from other available sources
- Camera app
- Favourites
- Select a tab.

The Gallery app is also available on the front passenger display.

Filtering displays

- Select 🔘 .
- Select an option. All files, all images or all video recordings are displayed.

Playing back a video recording

- Select . Playback starts.
- To continue playback in full screen mode: tap on the display.
- To pause playback: select **1**.
- To continue playback from the desired position: move the position on the timeline by sliding it.
- To select the previous or next video recording: swipe to the right or left.

Scrolling and zooming images

To scroll: swipe on the image in one direction.

- To zoom: tap twice in quick succession on an image.
- To select the previous or next image: swipe to the right or left.

Adding or removing a file from the favourites

- Press and hold on a file.
- Select Add to favourites/Remove from favourites.

A corresponding message appears.

Switching write protection on or off

- (i) Active write protection is not supported by every app.
- Press and hold on a file.
- Activate or deactivate Write protection.

Deleting files

- Select /.
- To delete a single file: tap on a file. will appear.
- To delete all files: tap on :-

- To delete: select A prompt appears.
- Select Yes.

dia system.

A single file can be deleted even after a long press on the file.

Connecting the device to the MBUX multimedia system to use the share content function

- Select the share function in the Mercedes me App on the device. A QR code is displayed on the MBUX multime-
- Scan the QR code with the device. A numerical code is displayed on the MBUX multimedia system.
- Enter the numerical code on the device. The connection is established and the device is available in the vehicle.

Sharing content with a connected device

- Select
- Choose the content that you wish to share. The content is marked with a tick.
- Select .

 Select the device to which the content is to be transferred.

The transferred content is stored in the Mercedes me App, not in the memory of the device.

Mercedes-Benz emergency call system

Information on available emergency call systems

Two types of emergency call system are available to you in the vehicle:

• Mercedes-Benz emergency call system

• 112 emergency call system (EU eCall)

The Mercedes-Benz Emergency Call System is not available in all countries. You can find more information on the regional availability of the Mercedes-Benz emergency call system at: https://www.mercedes-benz-mobile.com/extra/ecall/

The following applies for both emergency call systems:

 The transfer of specific data is required for the intended function of both emergency call systems. This will be explained in the "Data transfer" section (→ page 441).

- Both emergency call systems are included as standard equipment in your vehicle and are activated at the factory.
- The use of both emergency call systems is exempt from charges.
- Both emergency call systems only function in areas in which the mobile phone network providers offer mobile phone coverage.

For both systems, insufficient network coverage from the mobile phone network providers can result in an emergency call not being transmitted.

Differences between the Mercedes-Benz emergency call system and the 112 emergency call system (EU eCall)

Mercedes-Benz emergency call system

- The Mercedes-Benz emergency call system is permanently logged in to the mobile phone network.
 Automatic and manual Mercedes-Benz emergency calls are transmitted
- to a Mercedes-Benz emergency call centre.

 In the event that the emergency call centre of the Mercedes-Benz emergency call system cannot be reached (e.g. due to a lack of network coverage), the 112 emergency call is carried out automatically.

112 emergency call system (EU eCall)

- If you decide on the 112 emergency call system (EU eCall) only, then the system only logs in to the mobile phone network after the triggering of a manual or automatic emergency call.
- The 112 emergency call system (EU eCall) transmits automatic and manual emergency calls directly to public coordination centres.

- (i) The 112 emergency call system (EU eCall) in your vehicle meets the delegated regulation EU 2017/79. Proper and full functionality of the 112 emergency call system (EU eCall) depends on circumstances beyond the influence of Mercedes-Benz AG. This includes mobile network coverage and the technical infrastructure of the public reception centres in the respective countries.
- (i) Please observe that in the event of a repair genuine Mercedes-Benz batteries must be used which have been certified pursuant to the delegated regulation EU 2017/79 (Appen-

dix I). Other manufacturers are also permitted provided their batteries are certified according to the delegated regulation EU 2017/79.

There is the option of deactivating the Mercedes-Benz emergency call system and using only the 112 emergency call system (EU eCall). Contact address for carrying out deactivation of the Mercedes-Benz emergency call system are the local dealers. Mercedes-Benz recommends the activation of the Mercedes-Benz emergency call system for the following reasons:

- In emergency situations when abroad, you can also get support in a language you speak.
- Several transmission technologies are used to accelerate the transfer of the accident data and improve reliability of the transmission.
- The Mercedes-Benz emergency call system is permanently logged in to the mobile phone network, which ensures faster placement of

the emergency call and faster transfer of the accident data.

Measures for rescue, recovery or towing away can then be initiated in quickly.

 With a Mercedes-Benz emergency call, the accident data is only transferred to the public coordination centre with the approval of the customer.

In the event of an automatically triggered emergency call in which there is no voice contact, the accident data is transmitted immediately to the public emergency call centre.

 If the Mercedes-Benz emergency call centre is not available, the 112 emergency call is carried out automatically.

Overview of emergency call systems

Both the Mercedes-Benz emergency call system as well as the 112 emergency call system (EU eCall) can help to reduce the time between an accident and the arrival of emergency services at the site of the accident. They help locate an accident site in places that are difficult to access.

Both emergency call systems can initiate an emergency call automatically (\rightarrow page 440) or manually (\rightarrow page 441).

Only make emergency calls if you or others are in need of rescue. Do not make an emergency call in the event of a breakdown or a similar situation.

Indicators in the displays

The following messages appear on the central display or the media display of both emergency call systems:

 SOS NOT READY: the vehicle is not switched on or the emergency call system is malfunctioning. This does not necessarily indicate complete failure of the emergency call system. Emergency calls can still be transmitted.

The display only refers to the vehicle and does not take account of the availability of mobile phone networks and the Mercedes-Benz emergency call centre.

The functional readiness of the emergency call system on the vehicle can be seen when the SOS NOT READY display disappears once the vehicle is switched on.

- **\(\sets^{\sos} \)**: the icon appears in the display during an active emergency call.
- i If there is a malfunction of the emergency call system, the loudspeakers, microphone, airbag or the SOS button, for example, are faulty. You can recognise a fault in the emergency call system by the following displays:
 - A corresponding message will also appear in the driver's display.
 - The SOS button lights up red continuously.

Triggering an automatic emergency call

Requirements:

- The vehicle is switched on.
- · The starter battery is sufficiently charged.

Both the Mercedes-Benz emergency call system as well as the 112 emergency call system (EU eCall) automatically initiate an emergency call:

 After activation of the restraint systems such as airbags or seat belt tensioners after an accident After an automatically initiated emergency stop by Active Emergency Stop Assist

The emergency call has been made:

- A voice connection is established with the emergency call centre.
- A message with accident data is transmitted to the emergency call centre.

The SOS button in the overhead control panel flashes until the emergency call is finished.

If no connection can be made to the public emergency services, a corresponding message appears in the display.

Dial the emergency number 112 or the appropriate local emergency call number on your mobile phone.

If an emergency call has been initiated:

 Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call centre.

- On the basis of the call, the emergency call centre decides whether it is necessary to call rescue teams and/or the police to the accident site.
- If no vehicle occupant answers, an ambulance is sent to the vehicle immediately.

Triggering a manual emergency call

To use the SOS button in the overhead control panel: press the SOS button at least one second long (\rightarrow page 429).

To use voice control: use the voice commands of the MBUX voice assistant (\rightarrow page 320).

The emergency call has been made:

- · A voice connection is established with an emergency call centre.
- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call centre.

- On the basis of the call, the emergency call centre decides whether it is necessary to call rescue teams and the police to the accident site.
- A message with accident data is transmitted to the emergency call centre.

If no connection can be made to the public emergency services, a corresponding message appears in the display.

Dial the emergency number 112 or the appropriate local emergency call number on your mobile phone.

Emergency call system data transfer

For both the Mercedes-Benz emergency call system as well as the 112 emergency call system (EU eCall) data is transferred to the Mercedes-Benz emergency call centre or the public emergency services call centre.

Depending on the emergency call system (→ page 438) activated different data is transmitted to the appropriate emergency call centre.

Transmitted data according to activated emergency call system:

Mercedes-Benz emergency call	112 emergency call
 Position data of the vehicle Position data on the route (a few 100 m before the incident) Direction of travel Vehicle identification number Drive type of the vehicle (e.g. petrol, diesel, CNG, LPG, electric or hydrogen) Number of people detected in the vehicle Whether the emergency call was initiated manually or automatically Time of the accident Language setting on the multimedia system Whether Mercedes me connect is available or not This is a requirement for the option of forwarding the call to the Mercedes-Benz Customer Centre if necessary. 	 Position data of the vehicle Position data on the route (a few 100 m before the incident) Direction of travel Vehicle identification number Drive type of the vehicle (e.g. petrol, diesel, CNG, LPG, electric or hydrogen) Number of people detected in the vehicle Whether the emergency call was initiated manually or automatically Time of the accident

(i) If only the 112 emergency call system (EU eCall) is activated in the vehicle, the accident data is transmitted directly to the public emergency call centre.

For accident clarification purposes, the following measures can be taken up to an hour after the emergency call has been initiated:

- The current vehicle position can be determined.
- A voice connection to the vehicle occupants can be established.
- Emergency call data can be called up.
- For Russia: various functions, e.g. receiving traffic information, cannot be performed for up to two hours after sending an emergency call.

Self diagnosis function of the emergency call system

Your vehicle checks the functionality of the emergency call system every time the vehicle is switched on. During this time, the SOS button lights up red continuously for five seconds. In the event of a system failure, you will be informed via a text message on the driver's display and the red SOS NOT READY indicator on the central display or media display.

Please, make sure, that during 30 seconds after switching vehicle ON the red indicator SOS NOT READY in the upper right corner of display is switched OFF, this means the emergency call system passed diagnostics successfully.

Starting/ending ERA-GLONASS test mode

Requirements:

- The starter battery is sufficiently charged.
- · The vehicle is switched on.
- The vehicle has been stationary for at least one minute.
- The test mode is currently available in the following countries, for example:
 - Russia
 - Belarus
 - Kazakhstan
 - Armenia
 - Kyrgyzstan

- To start the test mode: press and hold the button on the multifunction steering wheel for at least five seconds. The test mode is started and automatically
- ends after the language test has been performed. To stop manual test mode: switch off the vehi-
- cle. The test mode is ended.

Information on data processing

Processing of personal data via the Mercedes-Benz emergency call system

All processing of personal data via the Mercedes-Benz emergency call system corresponds with the specifications in the EU Regulation 2016/679 "on the protection of natural entities with regard to the processing of personal data (GDPR)".

The data is solely used by the Mercedes-Benz emergency call system for rescue and recovery in the event of an accident.

The owner of a vehicle, that is equipped with a Mercedes-Benz emergency call system in addition to the 112 emergency call system (EU eCall), has

the right to use the 112 emergency call system instead of the Mercedes-Benz emergency call system.

Contact address for carrying out deactivation of the Mercedes-Benz emergency call system are the local dealers.

Processing of personal data via the 112 emergency call system (EU eCall)

All processing of personal data via the 112 emergency call system (EU eCall) corresponds with the specifications in the EU Regulation 2016/679 "on the protection of natural entities with regard to the processing of personal data (GDPR)" and is based particularly on the necessity of upholding the vital interests of the affected person in accordance with Article 6, Clause 1, Letter d of the GDPR.

The processing of this type of data is strictly limited to the purpose of operating the emergency calls to the standard European emergency call number 112.

Data recipient

The recipients of data that is processed using the 112 emergency call system (EU eCall) are the rel-

evant emergency call inquiry terminals that are specified to first receive and handle emergency calls to the standard European emergency call number 112 by the respective country authorities in whose territory you are located.

Arrangements for data processing

Both emergency call systems are designed so that the following requirements are fulfilled:

- The data contained in the system memory is not accessible outside the system prior to the initiation of an emergency call.
- Both emergency call systems cannot be traced and there is no continuous tracking in normal operation.
- The data in the system's internal memory is automatically and continuously deleted.
- The location data of the vehicle is continuously overwritten in the system's internal memory, so that no more than the last three current locations required for the normal function of the system are available.
- The record of the activity data of both emergency call systems is only kept for as long as

is required to fulfil the purpose of handling the emergency call, and under no circumstances for more than 13 hours after the time that an emergency call is initiated.

Rights of persons affected by the data processing

The person affected by the data processing (the vehicle owner) has the right to access the data and if applicable can demand the correction, deletion or barring of data that affects him or her and that the processing of which does not correspond with the GDPR regulations. Each correction, deletion or barring carried out according to this regulation must be shared with the third party to which the data has been transmitted, provided this does not prove to be infeasible and does not incur disproportionate expenditure.

The person affected by the data processing has the right to complain to the appropriate data protection authority should they be of the opinion that their rights have been infringed by the processing of their personal data.

Responsible contact point for the processing of access rights: Konzernbeauftragter für den Daten-

schutz, Mercedes-Benz AG, HPC G353, D-70546 Stuttgart, Germany

In-Car Apps

In-Car Apps overview

You can install additional apps via the In-Car Mercedes me Store and use them in your vehicle. The available In-Car Apps cover various topics such as entertainment, news or games.

In order to install In-Car Apps you require a Mercedes me user account and the In-Car App Pass service must be activated. If you do not yet have a Mercedes me ID you have to create this and connect it with your vehicle. Make sure that the In-Car App Pass service has been activated in the Mercedes me services management for your vehicle.

If the In-Car App Pass service is not available for your vehicle or has expired, you can order or extend this via the Entertainment Package in the Mercedes me Store. The In-Car App Pass is automatically activated when the Entertainment Package is ordered. Use the In-Car App Pass to obtain access to our ever-growing library of apps and experience additional apps in your Mercedes.

- (i) It is only possible to install In-Car Apps with an Internet connection.
- The availability of In-Car Apps is countrydependent.

Installing In-Car Apps via the In-Car Mercedes me Store

Requirements

- You have a Mercedes me user account.
- The vehicle is linked to a Mercedes me user. account.
- You have agreed to the terms of use.
- The In-Car App Pass service is activated in the vehicle.

Multimedia system:



- Select Apps. The available apps are displayed.
- Select the desired app.

- Install the app.
 - The installed apps can be found on the home screen.
- It is only possible to install In-Car Apps with an Internet connection
- The availability of In-Car Apps is countrydependent.

Online and Internet functions

Internet connection

Information on connecting to the Internet

WARNING Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle

Only operate this equipment when the traffic situation permits.

If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

WARNING Risk of accident from operating mobile communication equipment while the vehicle is in motion

Mobile communication devices distract the driver from the traffic situation. This can also cause the driver to lose control of the vehicle.

- As a driver, only operate mobile communication devices when the vehicle is stationary.
- As a vehicle occupant, use mobile communication devices only in the designated area, e.g. in the rear passenger compartment.

You must observe the legal requirements for the country in which you are currently driving when operating mobile communication equipment in the vehicle.

Depending on the vehicle's equipment and availability in the country, you can establish an Internet connection in the following ways:

- · Vehicles with a communication module:
 - Using the communication module including data roaming (→ page 446)
 - Using Wi-Fi with a data-enabled mobile phone
- Vehicles without a communication module:
 - Using Wi-Fi with a data-enabled mobile phone

The Internet functions can only be used to a limited degree whilst driving.

Setting up an Internet connection using the communication module

Requirements:

The vehicle is equipped with a permanently installed communication module.

- A Mercedes me user account is available.
- The vehicle is linked to a Mercedes me user account.
- The "Internet in the Car" service is activated.

Multimedia system:

→ Settings → System

Internet and Bluetooth

- ➤ Manage Internet access
- Select Search for Internet access in the Internet device manager.
- Select Acquired data package.

For most Mercedes me connect services, data volume is available when purchasing the services.

Additional data volume is required to use some functions, e.g. web browser or Wi-Fi hotspot.

If the data volume limit is reached, the availability of Mercedes me connect services is limited.

Depending on the vehicle equipment, you can purchase a data package directly from a mobile phone network provider via the Mercedes me Store. To be able to use the data package, you

conclude a separate contract with a mobile phone network provider via the Mercedes me Store, which can be terminated at any time and for which there are no costs. This contract is a prerequisite for using the services from the previously purchased package. The availability of this option is dependent on the country.

If the data package option is not available or can be upgraded, you can purchase data volume directly from the mobile phone network provider for a fee.

- Visit a Mercedes-Benz service centre to find out whether it is possible to purchase data volume in your country directly from a mobile phone network provider.
- (i) Alternatively, and if available, you can utilise the tethering function of a mobile phone via Wi-Fi to use the web browser or Wi-Fi hotspot.
- (i) With external Wi-Fi hotspots, which are encrypted via TKIP, online software updates cannot be carried out via the external Wi-Fi hotspot.

Disconnecting the automatic Internet connection via communication module

Requirements:

· Wi-Fi tethering is available in the vehicle.

Multimedia system:

- → Settings → System
- >> Internet and Bluetooth
- >> Manage Internet access
- Select the ••• settings in the line of Acquired data package.
- To disconnect the automatic connection: select the Delete entry option.
- The communication module is removed from the list of known hotspots, but can be reconnected manually at any time (\rightarrow page 446).

The Delete entry option permits the use of purchased data volume to be limited. The system is prevented from automatically establishing a connection to the communication module after this option has been activated.

Setting up an Internet connection via Wi-Fi

Requirements:

- The Wi-Fi function is activated on the multimedia system (\rightarrow page 356).
- The Wi-Fi hotspot function is activated on the mobile phone (see the manufacturer's operating instructions).
- Internet access via Wi-Fi is activated (see the manufacturer's operating instructions).

Multimedia system:

- → Settings → System
- > Internet and Bluetooth
- ➤ Manage Internet access
- (i) This function is country-dependent.

The mobile phone is listed in the Internet device manager

Select the mobile phone with the Mi-Fi symbol.

The mobile phone is not listed in the Internet device manager

Select Search for access.

448 MBUX multimedia system

- Select the mobile phone with the Wi-Fi symbol.

 It may take a few seconds until the device is
- It may take a few seconds until the device is found by the Wi-Fi search.
- ► Log in to the Wi-Fi network (\rightarrow page 356).

The Internet connection via Wi-Fi is restricted or does not function in the following cases:

- · The mobile phone is switched off
- Mobile data use is deactivated on the mobile phone
- The Wi-Fi function is deactivated on the multimedia system
- The Wi-Fi function is deactivated on the mobile phone
- Internet access via Wi-Fi is deactivated on the mobile phone

Cancelling Internet access permission for a mobile phone

Multimedia system:

- → 🙀 ➤ Settings ➤ System
- >> Internet and Bluetooth
- >> Manage Internet access
- Select options ••• next to the name of the mobile phone.
- Select Delete configuration.
- Select Yes.
- Establishing an Internet connection Multimedia system:
- → 😭 >> Apps
- For example, select Browser.

If you select a function that requires an Internet connection and the system is currently offline, a menu opens with a selection of possible Internet accesses as well as all tethering devices that are within range.

Select an Internet access from the list.
 The Internet connection is established.

- (i) Depending on the vehicle equipment and country availability, you can establish an Internet connection via the communication module or connected mobile phones.
- (i) The availability of the web browser depends on the country.

Connection status

Connection status overview

Depending on the connection status, the following symbols can appear on the central display in the status line:

- Mobile phone standard (e.g. 4G + double arrow symbol): the communication module is selected as the hotspot.

Displaying the connection status

Multimedia system:

Briefly press the status line.
 The extended status line is displayed.

Briefly press the Internet symbol in the symbol overview.

The current connection status is displayed.

Notes on displaying the connection status

- When connecting via Wi-Fi, the connection status and device name are displayed.
- In the case of a connection via the communication module the following status information can be shown:
 - Type of network
 - Status (online, offline, data volumes available or used, limited service)
- For vehicles with a communication module, the connection data of non-user paid services can be displayed via Mercedes me connect.

Web browsers

Calling up a web page



WARNING Risk of distraction from information systems and communications equipment

If you operate information systems and communication devices integrated in the vehicle when driving, you could be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Multimedia system:

Apps >> S Browser

Calling up a new web page

- Select Search.
- Entering a web address.
- Select ok .
- The function is country-dependent.
- No web pages can be displayed on the multimedia system while driving.

Calling up a website from the browser history

To call up the previous page from the history: select <.

Web browser overview



- Previous website
- Next website
- Update
- URI
- Adds/removes bookmarks
- Options
- Settings

- Under ••• you have the following options:
 - Tabs
 - Bookmarks & history
 - Reading mode
 - Share link
 - Share content
 - Request mobile website
- Calling up web browser options Multimedia system:



The following functions are available:

- Bookmarks
- Browsing history
- Entered URLs
- Select an option.
- Change the settings.

Calling up the web browser settings

Multimedia system:



The following functions are available:

- Block popups
- **Enable cookies**
- **Enable Javascript**
- Switch a function on or off.

Deleting browser data

Multimedia system:



The following specific browser data can be deleted:

- Cache
- Cookies
- Form data
- Select one of the options shown.

Managing bookmarks

Multimedia system:



- Select Bookmarks & history.
- Select ••• after the bookmark. A menu with options opens.

The following options are available:

- Delete entry
- Delete all
- Edit
- Share
- Select one of the options shown.

Managing tabs

Multimedia system:



Opening a new tab

Select New tab.

Changing tab

Select the icon for the desired tab.

Closing a tab

- Press and hold the icon of the tab to be closed until a menu appears.
- Select Close.
 - The tab is closed.

Private mode

- Switch private mode on or off. If the private mode is switched on, an icon appears in the input line of the web browser.
- (i) In private mode, neither the history nor cookies are saved. Bookmarks can also be created in private mode.

Sharing URLs from the web browser

Requirements:

• To share via QR code: an app for scanning the QR code is installed on the mobile device.

Multimedia system:



Sharing URLs via QR code

- Select Share link. A QR code appears.
- Scan the displayed QR code with a mobile device.

Sharing URLs with another display

- Select Share content.
- In the menu drag and drop a display to another display. The displayed web page opens on the other
- (i) More information on sharing display content

Setting the web browser in the background Multimedia system:



Press | file |.

display.

Audio playback continues.

Audials Radio

Calling up Audials Radio

Requirements:

- There is a user account at https:// www.mercedes.me.
- The vehicle is linked to the Mercedes me user account.
- The Internet Radio service is activated.
- The data volume is available.
 Depending on the country, data volume may need to be purchased.
- A fast Internet connection for data transmission free of interference.
- The functions and services are countrydependent. For more information, consult a Mercedes-Benz service centre.

Multimedia system:



Select Audials Radio.

The Audials Radio menu appears. The last station set starts playing.

- i The connection quality depends on the local mobile phone reception.
- Selecting and connecting Audials Radio stations

Multimedia system:

- ► Radio ► Audials Radio ► Select := .
- Select a category.
- Select a station.
- The connection is established automatically.

or

- Select the search field.
- Enter a station name.
- A relatively large volume of data can be transmitted when using Internet Radio.
- Saving/deleting an Audials Radio station as a favourite

Multimedia system:



Saving favourites

Select a station.

▶ Press ☆.

Deleting favourites

- Select a station.
- Press 🛨 .

Setting Internet Radio options

Multimedia system:



The following options are available:

- Login to Audials account: log in to your Audials user account
- Log out of account: log out from your Audials user account
- Select an option.

Media

Information about media mode

Information about supported formats and data storage media



WARNING Risk of distraction when handling data storage media

If you handle a data storage medium while driving, your attention is diverted from the traffic conditions. This could also cause you to lose control of the vehicle.

Only handle a data storage medium when the vehicle is stationary.

Supported formats and data storage media:

Permissible file systems	FAT32, exFAT, NTFS
Permissible data storage media	USB mass storage device, iPod®/iPhone®, MTP devices, Bluetooth® audio devices

Supported audio formats	MP3, WMA, AAC, WAV, FLAC, ALAC
Supported video formats	MPEG, AVI, MKV, MP4, M4V, WMV

- Observe the following notes:
 - The multimedia system supports a total of up to 50,000 files.
 - Data storage media up to 2 TB are supported (32-bit address space).
 - Due to the large variety of available music and video files regarding encoders, sampling frequency and data transfer rates, playback cannot be guaranteed.
 - Due to the wide range of USB mass storage devices available on the market, playback cannot be guaranteed for all USB mass storage devices.
 - Videos up to FullHD (1920x1080) are supported.
 - Copy-protected music and video files or DRM (Digital Rights Management) encrypted files cannot be played back.

• MP3 players must support Media Transfer Protocol (MTP).

Information on copyright protection and trademarks

Audio files which you create yourself (e.g. copies of data storage media you make yourself) are generally subject to copyright protection. In many countries, reproductions are not permitted without the prior consent of the copyright holder, even for private use. Make sure that you know about the applicable copyright regulations and that you comply with these.



Manufactured under licence from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories.



For DTS Patents, see https://patents.dts.com. Manufactured under licence from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Tru-Volume is a trademark of DTS, Inc. ©. DTS, Inc. All Rights Reserved.



DTS[®] Connected Radio™

For DTS Patents, see http://patents.dts.com. Manufactured under licence from DTS Licensing Limited. DTS, DTS Connected Radio, and the DTS logo are registered trademarks or trademarks of DTS, Inc. in the United States and other countries. © 2020 DTS, Inc. ALL RIGHTS RESERVED. Lyrics licensed and provided by Lyric Find™. Content licensed and sourced from Radioplayer™.




Gracenote, the Gracenote logo and logotype, "Powered by Gracenote", MusicID and Playlist Plus are either registered trademarks or trademarks of Gracenote, Inc. in the United States and/or other countries.

This product incorporates Spotify software which is subject to 3rd party licences found here: https://www.spotify.com/connect/third-partylicenses



TIDAL and TIDAL logo are registered trademark of Aspiro AB in the European Union and other countries.

Overview of the media menu



- Album cover
- Active media source
- Track and artist
- Active data storage medium and current track number/track in playback list
- Repeat
- Settings

456 MBUX multimedia system

- Additional options
- Previous or next track and fast rewind or fast forward
- Additional categories
- Playlists and categories
- Random playback
- Timeline
- Controls playback
- Media search

When the control menu is called up on the zero layer, the following functions are available:

- Controlling media playback
- · Selecting tracks from the current playlist
- Selecting a playback list
- · Media search
- · Selecting a media source
- Creating favourites
- Configuring settings
- (i) Further information on:
 - Overview of the zero layer (\rightarrow page 326).
 - Operating the zero layer (\rightarrow page 328).

Connecting the data storage medium to the multimedia system

■ Connecting USB mass storage devices

! NOTE Damage due to high temperatures

High temperatures can damage USB mass storage devices.

- After use, remove USB mass storage devices from the vehicle.
- Connect the USB mass storage device with the USB port.
- Searching for and authorising a Bluetooth® audio device

Requirements:

- Bluetooth® is activated on the multimedia system and audio equipment.
- The audio equipment supports the Bluetooth[®] audio profiles A2DP and AVRCP.
- The audio equipment is "visible" for other devices.

Multimedia system:

→ Media → Bluetooth

Authorising a new Bluetooth® audio device

- Select Connect device.
 Detected equipment is displayed in the device list.
- Select an audio device. Authorisation starts. A code is displayed on the multimedia system and on the mobile phone.
- If the codes are identical, confirm on the audio equipment.
- Select No, only music. The Bluetooth[®] audio equipment is connected with the multimedia system.

Connecting previously authorised Bluetooth® audio equipment

Select a Bluetooth® audio device from the list. The connection is being established.

Starting media playback

Requirements:

• A data storage medium is connected to the multimedia system.

Multimedia system:

- → Media
- Select a media source.

Controlling media playback

Multimedia system:

- → 🔝 >> Media
- To pause playback: select .
- To continue playback: select .
- To repeat a track: select 1.

For the repeat function there are the following settings:

- Select once: the active playlist is repeated.
- **Select twice:** the current track is repeated.
- **Select three times:** the repeat function is deactivated.

- To play back tracks in random order: select 次.
- To rewind or fast-forward a track: tap on the desired point on the timeline.
- To select the next track: select .
- To select the previous track: select .
- To scroll through tracks quickly: press and hold or .
- To show the current track list: select

Additional options for setting media playback

Multimedia system:

¬→ 🔝 ▶ Media

Calling up additional options

Select

The additional options are shown.

Select an option.

Media search

- Notes about the search function in categories Under you can search through all available media files. There are several categories available
- for selection. The categories shown depend on the connected device and data format.
- The categories are available as soon as the entire media content has been read in and analysed.
 - Availability of the media search with Android devices may be limited.

Starting a search in categories

Multimedia system:

- → 🔝 >> Media >> 🗐
- Select a category.
- Enter a search term in the search bar.
- Using the keyword search

Multimedia system:

→ Media

You can look for content using the keyword search with free text input.

- Select \(\mathcal{D} \). A keyboard for character entry appears.
- Enter the term searched for.
- The search begins with the first character entered. The more characters entered the more concrete the search results become.
- Select the desired entry from the result list. If a list with several tracks is selected, then this is opened in the search.

To playback all of the tracks in the list, select ••• and then Play now.

Media mode on the front passenger display (only vehicles with MBUX Hyperscreen)

Information about media mode

You can also use functions of the MBUX multimedia system on the front passenger display.

You can find more information on the following topics:

 Information about supported formats and data storage media (\rightarrow page 453)

- Information on copyright protection and trademarks (\rightarrow page 453)
- Overview of the media menu (→ page 455)

WARNING Risk of injury from unsecured items in the vehicle

If objects such as headphones/headsets or external audio/video sources are not secured in the vehicle interior, they can be flung around and hit vehicle occupants.

Always stow these items or similar objects carefully so that they cannot be flung around, for example in a lockable vehicle stowage compartment.

Observe the notes on loading the vehicle.

WARNING Health hazard due to excessive volume on headphones

Excessive volume can damage your hearing.

Avoid wearing headphones for long periods of time and at too high a volume (85 decibels).

- Ensure that the volume is set to a comfortable level.
- The headphones are special equipment for the MBUX multimedia system. You can also obtain the headphones from Mercedes-Benz Customer Solutions or in a specialist shop (see the manufacturer's operating instructions).
- (i) The function of wireless headphones can be impaired by other radio-based electronic devices, such as mobile phones, for example.

Starting and operating media playback

Requirements:

· A data storage medium is connected to the multimedia system.

Multimedia system:



- Select a media source.
- To adjust the volume: select in the menu line and press - or +.

To set playback via vehicle loudspeakers: press [in the menu line.

The following functions are available:

- Controlling media playback (\rightarrow page 457)
- Options for setting media playback $(\rightarrow page 457)$
- Starting a search in categories (→ page 457)
- Using the keyword search (\rightarrow page 457)

Music online

Requirements

- · There is an account for the music streaming service.
- A subscription for the music streaming service has been obtained.
- A Wi-Fi hotspot with unrestricted or sufficient data volume is available. Depending on the country, data volume may need to be purchased.
- A fast Internet connection for data transmission free of interference.

The functions and services are countrydependent. For more information, consult a Mercedes-Benz service centre.

Multimedia system:



Adding a streaming provider the first time you start the application

- Select Online music. The overview of all supported streaming providers appears.
- Select a streaming provider. A QR code is shown on the display.
- Scan the QR code with the mobile phone.
- Confirm the connection request on the mobile phone.

Adding more streaming providers

- Select Online music. The last active streaming provider is active.
- Select 🔯 .

- Select Music services. The overview of all supported streaming providers appears.
- Select a streaming provider. A QR code is shown on the display.
- Scan the QR code with the mobile phone.
- Confirm the connection request on the mobile phone.

Logging out from a streaming provider

- Select Online music. The last active streaming provider is active.
- Select 🔯 .
- Select Music services. The overview of all supported streaming providers appears.
- Select next to the streaming provider.
- Tap on Log out.

Calling up music online Multimedia system:



Select Online music.

Music playback can be controlled with the Touch Control or by using the media application.

Searching for music in online music Multimedia system:

→ Media → Online music

Searching for categories in online music

The media content of the streaming provider can be scanned through in the category search. The available categories and the symbol for the category search depend on the streaming provider.

- Start the category search.
 The list of available categories appears.
- Select a category.

Keyword search in online music

You can look for content using the keyword search with free text input.

- Select . A keyboard for character entry appears.
- Enter the term searched for.
- (i) The more characters entered when using the keyword search, the more concrete the search results are.

- Select the desired entry from the result list. Depending on the selected hit, playback is started or a lower level in the search is opened.
- Calling up online music settings
 Multimedia system:
- → Media → Online music
- ► Select 🔯 .
- Select Music services.
- Select next to a streaming provider.
- Select a setting.
- i Information about the linked accounts can be displayed using the gear icon next to the configured streaming provider. The available information depends on what is offered by the provider of the streaming service.

Radio


Switching on the radio

Multimedia system:

- ¬→ 🝙 → 🕴 Radio
- Start the application on the multimedia system home screen.

The radio menu appears. You will hear the last station played on the last frequency band selected.

Radio overview



- Preview image
- Active frequency band
- Station name or set frequency
- Settings
- Sound settings
- Switches on traffic reports

With DAB equipment: switches on radio announcements

- Station list
- Search
- The availability of the frequency bands is dependent on the equipment.

When the control menu is called up on the zero layer, the following functions are available:

- Selecting a radio station
- Setting radio stations from the station list
- Storing radio stations
- Frequency band
- · Search function
- · Creating favourites
- Configuring settings
- (i) Further information on:
 - Overview of the zero layer (\rightarrow page 326).
 - Operating the zero layer (→ page 328).

You can watch an animation on this topic via the following link:

Setting the frequency band

Multimedia system:



Select a frequency band or a favourite.

Selecting a radio station

Multimedia system:



Swipe to the left or right on the control element or select a radio station.

Calling up the radio station list

Multimedia system:



Select := . The station list appears.

- Swipe the station list up or down.
- Select a station.

Searching for radio stations using station names or frequency entry

Multimedia system:



- Select .
- ► Enter a station name or frequency.
- Select a station.

Selecting a recommended radio station

Requirements

 The multimedia system has gathered sufficient data in order to show station suggestions.

Multimedia system:



Select .

The recommended stations are shown.

- Select a suggested station.
- The selected station is played.

Storing radio stations

Multimedia system:

- → 🔝 🍑 🛊 Radio
- Select a radio station.
- ➤ Select ☆.

Managing favourites

Multimedia system:



Moving stations

- Press : to the far right of the station name.
- Select Move.
- Move the station to the new position.

Calling up a slide show (FM/DAB radio mode)

Multimedia system:



The slide show displays additional information provided by the station as an image. This can include logos, album covers, music tracks, programmes, news or service information, for example.

- i The slide show is available for DAB+ channels that broadcast additional information.
- Press the station picture on the central display.
 The image is enlarged.

Switching a slideshow on or off (FM/DAB radio mode)

Multimedia system:



Switch DAB Slideshow or Expanded Radio Slideshow on or off .

When both slideshows are switched on, the contents of both slideshows alternate.

Activating/deactivating the frequency fix function

Multimedia system:



Activate or deactivate Frequency fix. If the function is activated, the set frequency is kept even if the reception is poor.

Activating/deactivating traffic announcements

Multimedia system:

Radio **~→** | ♠ | ▶>

Select TA.

The traffic information is switched on or off.

Activating/deactivating radio announcements

Multimedia system:



Switch on Radio announcements. The selected radio announcements are played. When Radio announcements are first switched on, Traffic information service (TA), Travel and Warning are preset.

Switch off Radio announcements. No radio announcements are played.

Selecting radio announcements

Multimedia system:



- >> Radio announcements
- Switch an announcement on $\mathbf{\nabla}$ or off. For example, Traffic information service (TA), Travel or Warning can be selected.
- The radio announcements are not stationdependent.

Setting the traffic information service volume increase

Multimedia system:



- Select Navigation & traffic announcements.
- Set a value for Traffic announc, vol. increase.

Displaying radio text

Multimedia system:



- >> Active frequency band
- Activate or deactivate Radio text information.

Showing or hiding lyrics

The function is equipment-dependent.

Multimedia system:



Showing lyrics

Select Show lyrics.

The lyrics, album cover, title and artist of the song currently playing on the radio are displayed.

Swipe up or down to go to the bottom or top section of the lyrics.

If no lyrics are available for the song currently playing on the radio, Show lyrics is greyed out.

Hiding lyrics

Select the cross at the top of the lyrics display.

or

Select 5.

The radio menu appears.

Sound

Sound settings

Information about the sound system

The sound system has a total output of 125 W and is equipped with seven speakers. It is available for all functions in the radio and media modes.

- (i) The call can also be made from other audio sources. Replace Media with, for example, Radio in the menu path.
- Calling up the sound menu Multimedia system:
 - → 🔝 >> Media >> 🐧
- Select one of the functions shown to make settings.
- Adjusting treble, mid-range and bass settings Multimedia system:
- → 🔝 >> Media >> 🔯
- Set Treble, Mid or Bass.

Setting the balance and fader

Multimedia system:

- → Media → O
- Balance and Fader

Adjusting the balance

 Move the volume distribution between the right and left sides of the vehicle in the grid shown.

The volume is distributed between the speakers on the left and right sides in the vehicle.

Adjusting the fader

Move the volume distribution between the front and rear of the vehicle in the grid shown. The volume is distributed between the speakers in the front and rear of the vehicle.

Burmester® 4D surround sound system

Information on the Burmester® 4D surround sound system

The Burmester® 4D surround sound system has a total output of 730 W and is equipped with 17 speakers including two speakers close to the driv-

er's ear to support navigation announcements and telephony. Furthermore the sound system is equipped with two tactile transducers each for the driver and front passenger seats. It is available for all functions in the radio and media modes.

- The navigation announcements from the speakers close to the driver's ears can be set in the system settings (\rightarrow page 394). Telephony with the speakers close to the driver's ears can be set in the telephone menu $(\rightarrow page 416)$.
- Calling up from other audio sources is also possible. Replace Media with, for example, Radio in the menu path.
- Calling up the sound menu in the Burmester® 4D surround sound system

Multimedia system:



Adjusting sound settings

Select one of the functions shown to make settings.

Setting 4D sound

- Select 4D sound adjustment.
- Select a seat.
- Use the controller to set the intensity of the bass vibrations.
- Adjusting the treble, mid and bass settings in the Burmester® 4D surround sound system Multimedia system:
- → 🔝 >> Media >> 🐞 >> Equaliser
- Set Treble, Mid or Bass.
- Adjusting the balance and fader in the Burmester® 4D surround sound system Multimedia system:
- → 🔝 >> Media >> 👸
- ▶ Balance and Fader

Adjusting the balance

- Move the volume distribution between the right and left sides of the vehicle in the grid shown.
 - The volume is distributed between the speakers on the left and right sides in the vehicle.

Adjusting the fader

- Move the volume distribution between the front and rear of the vehicle in the grid shown. The volume is distributed between the speakers in the front and rear of the vehicle.
- (i) Setting 0 is recommended for high quality music and voice reproduction.
- Selecting a sound profile in the Burmester® 4D surround sound system Multimedia system:

→ Media → Ö

Setting an existing sound profile

Select a sound profile.

Setting up a personal sound profile

Select Personal sound profile and select . Select Reconfigure and restart the setup assistant.

Setting up a personal sound profile for the first time:

- Select Personal sound profile.
- Open the set-up assistant with Start.

Observe the messages on the display and select the preferred settings. The personal sound profile is created with the selected settings and can be selected in the Sound profiles menu.

Changing individual settings of the personal sound profile at a later date:

- Select Personal sound profile, then select and adjust the desired settings.
- (i) The availability of a Personal sound profile is dependent on the equipment.

 The set-up assistant is available when the vehicle is stationary.

Adjusting the sound focus in the Burmester[®] 4D surround sound system

Multimedia system:

→ 🔝 ➤ Media ➤ 🐧 ➤ Sound focus

Select a seat or row of seats for the sound focus.

The sound focus is activated.

Select the seat or row of seats again.
The sound focus is deactivated.

Super Sport sound

■ Information on Super Sport sound

The Super Sport sound function enhances your experience of engine noise in your vehicle's interior. Your vehicle generates sporty engine noise content appropriate to the current driving situation and plays this back in the vehicle interior via the sound system speakers.

i The Super Sport sound function is an ondemand feature (→ page 25).

Camera app

Overview of the camera app

The laws concerning video and audio recordings of vehicle surroundings and vehicle occupants may differ depending on the country. Please observe the laws of the country in which you are recording.

With the camera app, you can take photos, multiple shots, and videos, both from Internal as well as from External. You can switch between the two cameras in the overview. It is operated using the touchscreen or Touch Control.

You can view your captured photos and videos in the Gallery app.

Additional information about the Gallery app $(\rightarrow page 436)$

- (i) The function is country-dependent.
- (i) No photos or videos can be taken while the vehicle is in motion.
- i If the USB flash drive is not recognised by the vehicle, you can try to fix the error by connecting the USB flash drive to a computer.
- i To ensure secure operation, only use FAT32 or exFAT formatted USB storage devices.
- Do not remove the USB flash drive during recording. This can damage the files. You can eject the USB flash drive in the settings (→ page 467)

Display messages

In the following situations display messages may be shown:

- The memory is full or there are only a few minutes recording time available. The video recording stops or will be stopped imminently. Change the USB device or delete a photo or video file.
- The camera is not functioning. A message appears.

Have the camera checked in a Mercedes-Benz service centre.

 No USB device is connected to save the recordings.

The Please insert a storage medium into the USB port to start recording. message appears.

· If a dashcam recording is started during a video recording with the Camera app, the video recording pauses.

The Recording interrupted by dashcam recording. message appears.

The camera is being used from another seat.

Taking photos and videos with the Camera app

Requirements:

- For recording and saving a photo or video file: a USB device is connected with the multimedia system (\rightarrow page 456)
- The vehicle is switched on.

Multimedia system:



The following recording modes are available:

- Video
- Photos
- Multiple shots
- Capture a video, photo, or multiple shots by selecting the appropriate icon.
- Every time the Camera app is launched, a liability notice appears. If the application should be started, select OK.
- You can view your captured photos and videos in the Gallery app. To do this, select the Gallery app icon in the overview.

Configuring Camera app settings

Multimedia system:



The following functions are available:

- Snapshot timer
- Multiple shots
- Interval between shots
- Select an option.
- Change the settings.

Ejecting the USB flash drive

- Select Storage medium.
- Select \triangle after the device name. The You can now disconnect the storage medium. message appears.

ASSYST PLUS service interval display

Function of the ASSYST PLUS service interval display

The ASSYST PLUS service interval display on the driver's display provides information on the remaining time or distance before the next service due date.

You can hide this service display using the back button on the steering wheel.

Depending on how the vehicle is used, the ASSYST PLUS service interval display may shorten the service interval, e.g. in the following cases:

- · Mainly short-distance driving
- When the engine is often left idling for long periods
- In the event of frequent cold start phases
- Vehicles with diesel particulate filters: in the event of frequently interrupted regeneration of the diesel particulate filter

Mercedes-Benz recommends avoiding such operating conditions.

You can obtain information concerning the servicing of your vehicle from a qualified specialist workshop, e.g. a Mercedes-Benz Service Centre.

Displaying the service due date

Driver's display:



The next service due date is displayed.

To exit the display: press the back button on the steering wheel.

Information on regular maintenance work

NOTE Premature wear through failure to observe service due dates

Maintenance work which is not carried out at the right time or incompletely can lead to increased wear and damage to the vehicle.

Adhere to the prescribed service intervals.

Always have the prescribed maintenance work carried out at a qualified specialist workshop.

Notes on special service requirements

The prescribed service interval is based on normal operation of the vehicle. Have the maintenance work carried out more often than prescribed if operating conditions are difficult or the vehicle is subject to increased stress.

The ASSYST PLUS service interval display is only an aid. It is the responsibility of the driver of the vehicle to have maintenance work carried out more often than prescribed due to actual operating conditions and/or stresses.

Examples of arduous operating conditions:

- Regular city driving with frequent intermediate stops
- Mainly short-distance driving
- Frequent operation in mountainous terrain or on poor road surfaces

- When the engine is often left idling for long periods
- Operation in particularly dusty conditions and/or if air-recirculation mode is frequently used

In these or similar operating conditions, have the interior air filter, air filter, engine oil and oil filter, for example, changed more frequently. Check the tyres more frequently if the vehicle is operated under increased stress. Further information can be obtained at a qualified specialist workshop.

Battery disconnection periods

The ASSYST PLUS service interval display can calculate the service due date only when the battery is connected.

Display and note down the service due date on the driver display before disconnecting the battery (\rightarrow page 468).

Maintenance Management

Notes about Maintenance Management

If the Maintenance Management service is activated, relevant data is automatically transferred to the Mercedes-Benz customer centre.

The customer centre transmits the data to the service partner that you have entered on the Mercedes me website at: http:// www.mercedes.me. You will then receive individual recommendations regarding the maintenance of vour vehicle.

- The calculation of the optimal transmission time of the maintenance request to the service partner is subject to technical limitations that may cause the maintenance recommendation to be perceived as too early or too late or not to be made at all. In this case, you can conveniently arrange a maintenance appointment with the customer centre via the maintenance reminder in the multimedia system.
- Maintenance Management and the maintenance reminder in the multimedia system are not available in every country. Contact a

Mercedes-Benz service centre to find out whether this function is available in your country.

Data transferred when using Maintenance Management

When the service is activated, relevant data is automatically transferred to determine the required scope of maintenance as well as fault detection and fault rectification.

Details on data transfer can be found in the data protection information for the Mercedes me connect services. These can be found at: https:// www.mercedes.me under "My Mercedes me account", "Terms of use".

Maintenance Management and the maintenance reminder in the multimedia system are not available in every country.

Telediagnostics

Notes about Telediagnostics

This service is not available in all countries.

The vehicle can detect if certain wear parts need to be replaced or if malfunctions have occurred in vehicle systems. If the Telediagnostics service is activated, relevant data is automatically transmitted to the manufacturer. If fault conditions are detected by the vehicle system self-diagnosis, the system transmits recommendations for action to the Mercedes-Benz customer centre depending on the fault detected. The customer centre transmits the data to the service partner that you have entered on the Mercedes me website at: http://www.mercedes.me.

For selected faults, the notification that a malfunction has been detected may appear in the multimedia system with a request to contact the Mercedes-Benz Customer Centre. From this message, a call can be made directly to the customer centre for assistance.

- The transmission of a notification to the multimedia system depends on the country, vehicle model and equipment and requires a fast data connection, over which the service provider has no influence.
- (i) Reliable fault detection is subject to technical limitations. Therefore, only a limited selection

of faults can be detected and recommendations for action transmitted to the customer centre and the service partners. Mercedes-Benz AG is continuously working on the expansion of this service. The fault detection depends on the country, vehicle model and equipment.

Data transferred when using Telediagnostics

When the service is activated, relevant data is automatically transferred to determine the required scope of maintenance as well as fault detection and fault rectification.

Details on data transfer can be found in the data protection information for the Mercedes me connect services. These can be found at: https://www.mercedes.me under "My Mercedes me account". "Terms of use".

 The scope of the data transmitted depends on the vehicle model and equipment. For technical reasons, not all data is available at all times.

Engine compartment

Active bonnet (pedestrian protection)

Operation of the active bonnet (pedestrian protection)

In certain accident situations, the actuation of the active bonnet reduces the risk of injury to pedestrians. The rear area of the bonnet is raised by approximately 80 mm.

After being triggered, the active bonnet remains in the raised position. Limited visibility due to the raised bonnet cannot be ruled out.

After the active bonnet has been actuated, pedestrian protection may be limited.

Have the full functionality of the active bonnet restored immediately in a qualified specialist workshop.

If necessary, adjust your seat position and drive carefully to a qualified specialist workshop. If a safe continued journey is not possible, contact a qualified specialist workshop.

Opening and closing the bonnet



WARNING Risk of accident due to driving with the bonnet unlocked

The bonnet may open and block your view.

- Never release the bonnet when driving.
- Before every trip, ensure that the engine bonnet is locked.

WARNING Risk of accident and injury when opening and closing the bonnet

The bonnet may suddenly drop into the end position.

There is a risk of injury for anyone in the engine bonnet's range of movement.

Do not open or close the bonnet if there is a person in the bonnet's range of movement.

WARNING Risk of burns when opening the bonnet

If you open the bonnet in the event of an overheated engine or fire in the engine compartment, the following situations may occur:

- You may come into contact with hot gases.
- · You may come into contact with other escaping hot operating fluids.
- Before opening the bonnet, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the bonnet closed and call the fire service.

WARNING Risk of injury due to moving parts

Components in the engine compartment may continue to run or start unexpectedly even when the drive system is switched off.

Observe the following if you must open the bonnet:

- Switch off the vehicle.
- Never touch the danger zones surrounding moving components, e.g. the rotation area of the fan.
- Remove jewellery and watches.
- Keep items of clothing and hair away from moving parts.

WARNING Risk of injury from touching components under voltage

The ignition system and the fuel injection system operate at high voltage. You could receive an electric shock.

Never touch ignition system or fuel injection system components when the vehicle is switched on.

The live components include the following, for example:

- · Ignition coils
- Fuel injectors

Electric lines to the ignition coils and the fuel injectors

WARNING Risk of burns from hot component parts in the engine compartment


Certain component parts in the engine compartment can be very hot, e.g. the engine, the cooler and parts of the exhaust system.

- Allow the engine to cool down and only touch component parts described in the following.
- WARNING Risk of injury from using the windscreen wipers when the bonnet is open


If the windscreen wipers start moving when the bonnet is open, you could be trapped by the wiper linkage.

Always switch off the windscreen wipers and the vehicle first if you need to open the bonnet.

Opening the bonnet



To release the bonnet, pull on handle ①.



 Push handle ② of the bonnet catch upwards and lift the bonnet until it opens automatically.

Closing the bonnet

! NOTE Damage to the bonnet

If the bonnet is closed manually, there is a risk of dents.

Do not close the bonnet manually.

- Lower the bonnet to a height of around 20 cm and then allow it to fall, applying a little force as you let it go.
- If the bonnet can still be lifted slightly, open the bonnet again and close it with a little more force until it engages correctly.

Engine oil

Checking the engine oil level using the driver's display

Requirements

- The engine has been warmed up.
- The vehicle is parked on a level surface.
- The engine is running at idle speed.
- The bonnet is closed.

Determining the engine oil level can take up to 30 minutes with a normal driving style and even longer with an active driving style.

Driver's display:

¬→ Service

The engine oil level is shown.

One of the following messages will appear on the driver's display:

- Engine oil level Measuring now...: the engine oil level cannot be determined yet.
- Repeat the request after a maximum of 30 minutes' driving.
- Engine oil level OK and the bar display for indicating the engine oil level on the driver's display is green and is between "min" and "max": the engine oil level is correct.
- Engine oil level Top up 1,0 I and the bar display for indicating the engine oil level on the driver's display is yellow and is below "min":
- Add 1 I of engine oil.
- Engine oil level Reduce and the bar display for indicating the engine oil level on the driver's display is yellow and is above "max":
- Drain off any excess engine oil that has been added. To do so, consult a qualified specialist workshop.
- For engine oil level, switch on vehicle

- Switch on the vehicle to check the engine oil level.
- Engine oil level System inoperative: The oil level sensor is defective or not connected.
- Consult a qualified specialist workshop.
- Engine oil level System currently inoperative
- Close the bonnet.
- Topping up engine oil

WARNING Risk of burns when opening the bonnet

If you open the bonnet in the event of an overheated engine or fire in the engine compartment, the following situations may occur:

- · You may come into contact with hot gases.
- You may come into contact with other escaping hot operating fluids.
- Before opening the bonnet, allow the engine to cool down.

474 Maintenance and care

In the event of a fire in the engine compartment, keep the bonnet closed and call the fire service.

WARNING Risk of injury due to moving parts

Components in the engine compartment may continue to run or start unexpectedly even when the drive system is switched off.

Observe the following if you must open the bonnet:

- Switch off the vehicle.
- Never touch the danger zones surrounding moving components, e.g. the rotation area of the fan.
- Remove jewellery and watches.
- Keep items of clothing and hair away from moving parts.

WARNING Risk of burns from hot component parts in the engine compartment

Certain component parts in the engine compartment can be very hot, e.g. the engine, the cooler and parts of the exhaust system.

- Allow the engine to cool down and only touch component parts described in the following.
- **MARNING** Risk of fire and injury from engine oil

If engine oil comes into contact with hot component parts in the engine compartment, it may ignite.

- Make sure that no engine oil is spilled next to the filler opening.
- Allow the engine to cool off and thoroughly clean the engine oil from component parts before starting the vehicle.

- NOTE Engine damage caused by an incorrect oil filter, incorrect oil or additives
- Do not use engine oils or oil filters which do not correspond to the specifications explicitly prescribed for the service intervals.
- Follow the instructions on the service interval display for changing the engine oil and observe the prescribed change intervals.
- Do not use additives.
- NOTE Damage caused by topping up too much engine oil

Excess engine oil can damage the engine or catalytic converter.

Have excess engine oil removed at a qualified specialist workshop. Depending on driving style, the vehicle consumes up to 0.8 litres of oil per 1000 km. The oil consumption may also be higher than this when the vehicle is new or if you frequently drive at high engine speeds.



- Turn cap 1 anti-clockwise and remove it.
 - Top up the engine oil.

- Replace cap
 and turn it clockwise until it engages.
- Check the oil level again (\rightarrow page 473).

Checking the coolant level

WARNING Risk of burns when opening the bonnet

If you open the bonnet in the event of an overheated engine or fire in the engine compartment, the following situations may occur:

- You may come into contact with hot gases.
- · You may come into contact with other escaping hot operating fluids.
- Before opening the bonnet, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the bonnet closed and call the fire service.

WARNING Risk of injury due to moving parts

Components in the engine compartment may continue to run or start unexpectedly even when the drive system is switched off.

Observe the following if you must open the bonnet:

- Switch off the vehicle.
- Never touch the danger zones surrounding moving components, e.g. the rotation area of the fan.
- Remove jewellery and watches.
- Keep items of clothing and hair away from moving parts.

WARNING Risk of burns from hot component parts in the engine compartment

Certain component parts in the engine compartment can be very hot, e.g. the engine, the cooler and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following.

WARNING Risk of scalding from hot coolant

If you open the cap, you could be scalded.

- Let the motor cool down before opening the cap.
- When opening the cap, wear protective gloves and safety glasses.
- Open the cap slowly to release pressure.
- Have the coolant checked or refilled only at a qualified specialist workshop.

Topping up the windscreen washer system

WARNING Risk of burns when opening the bonnet

If you open the bonnet in the event of an overheated engine or fire in the engine compartment, the following situations may occur:

- You may come into contact with hot gases.
- You may come into contact with other escaping hot operating fluids.
- Before opening the bonnet, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the bonnet closed and call the fire service.

WARNING Risk of injury due to moving parts

Components in the engine compartment may continue to run or start unexpectedly even when the drive system is switched off.

Observe the following if you must open the bonnet:

- Switch off the vehicle.
- Never touch the danger zones surrounding moving components, e.g. the rotation area of the fan.
- Remove jewellery and watches.
- Keep items of clothing and hair away from moving parts.


WARNING Risk of burns from hot component parts in the engine compartment

Certain component parts in the engine compartment can be very hot, e.g. the engine, the cooler and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following. **WARNING** - Risk of fire and injury due to windscreen washer concentrate

Windscreen washer concentrate is highly flammable. It could ignite if it comes into contact with hot engine component parts or the exhaust system.

Make sure that no windscreen washer concentrate spills out next to the filler opening.



- Open cap (1) by the tab.
- Top up the washer fluid.

Keeping the air/water duct free

Keep the area between the bonnet and the windscreen free of deposits, e.g. ice, snow or leaves.

Cleaning and care

Information on washing the vehicle in a car wash

WARNING Risk of an accident due to reduced braking power after washing the vehicle

Braking efficiency is reduced after washing the vehicle.

After the vehicle has been washed, brake carefully while paying attention to the traffic conditions until braking power has been fully restored.

NOTE Damage from automatic braking

If one of the following functions is activated, the vehicle will brake automatically in certain situations:

- Active Brake Assist
- Active Distance Assist DISTRONIC
- HOLD function
- Active Parking Assist

To avoid damage to the vehicle, deactivate these systems in the following or similar situations:

- During towing.
- In a car wash.
- NOTE Damage due to unsuitable car wash
- Before driving into a car wash make sure that the car wash is suitable for the vehicle dimensions.
- Ensure there is sufficient ground clearance between the underbody and the guide rails of the car wash.
- Ensure that the clearance width of the car wash, in particular the width of the guide rails, is sufficient.

To avoid damage to your vehicle when using a car wash, ensure the following beforehand:

- Active Distance Assist DISTRONIC is deactivated.
- · The HOLD function is switched off.

- The 360° camera or the reversing camera is switched off.
- The vehicle is locked and the door handles are retracted.
- The side windows and sliding sunroof are completely closed.
- . The outside mirrors are folded in.
- The blower for the ventilation and heating is switched off.
- The windscreen wiper switch is in position $oldsymbol{0}$.
- The key is at a minimum distance of 6 m away from the vehicle. Otherwise, the boot lid or a door could open unintentionally.

This also applies to the Digital Vehicle Key.

- For car washes with a conveyor system:
 - Neutral N is engaged.
 - The vehicle is locked from the inside.
- Do not make any hand movements in the area
 of the overhead control panel or deactivate
 (→ page 352) the Sliding sunroof and roller
 sunblind option in the settings for the MBUX
 interior assistant.

(i) If, after the car wash, you remove the wax from the windscreen and wiper rubbers, this will prevent smearing and reduce wiper noise.

Information on using a high-pressure cleaner

A

WARNING Risk of an accident when using high-pressure cleaners with round-spray nozzles

The water jet can cause externally invisible damage.

Components damaged in this way may unexpectedly fail.

- Do not use a high-pressure cleaner with round-spray nozzles.
- Have damaged tyres or chassis parts replaced immediately.

To avoid damage to your vehicle, observe the following when using a high-pressure cleaner:

 The key is at a minimum distance of 3 m away from the vehicle. Otherwise, the boot lid or a door could open unintentionally. This also applies to the Digital Vehicle Key.

- Maintain a distance of at least 30 cm to the vehicle.
- Vehicles with decorative films: Parts of your vehicle are covered with a decorative film. Maintain a distance of at least 70 cm between the film-covered parts of the vehicle and the nozzle of the high-pressure cleaner. Move the high-pressure cleaner nozzle around whilst cleaning. The water temperature of the highpressure cleaner must not exceed 60°C.
- Observe the information on the correct distance in the equipment manufacturer's operating instructions.
- Do not direct the nozzle of the high-pressure cleaner directly at sensitive parts, e.g. tyres, gaps, electrical components, batteries, illuminants or louvres.

Washing the vehicle by hand



Take care not to point the water jet directly towards the air inlet grille below the bonnet.

Observe the relevant legal requirements (e.g. in some countries, washing by hand is permitted only in specially designated wash bays).

- Use a mild cleaning agent (e.g. car shampoo).
- Wash the vehicle with lukewarm water using a soft car sponge. When doing so, do not expose the vehicle to direct sunlight.
- Carefully hose the vehicle off with water and dry using a chamois.
- Observe the notes on the care of car parts $(\rightarrow page 481)$.

Notes on paintwork/matt finish paintwork care

To avoid damaging the paintwork and interfering with the driving assistance systems, please observe the following notes:

Paint

- Insect remains: Soak with insect remover and rinse off the treated areas afterwards.
- Bird droppings: Soak with water and rinse off afterwards.
- Tree resin, oils, fuels and greases: remove by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.
- Coolant and brake fluid: remove with a damp cloth and clean water.
- Tar stains: use tar remover.
- Wax: use silicone remover.
- Do not attach stickers, films or similar materials. Only have film attached to the bumper at a qualified specialist workshop.
- Remove dirt immediately, where possible.

Matt finish

- Only use care products approved for Mercedes-Benz.
- Do not attach stickers, films or similar materials. Only have film attached to the bumper at a qualified specialist workshop.

- Do not polish the vehicle and light-alloy wheels.
- Only use car washes that correspond to the latest engineering standards.
- Do not use car wash programmes with a final hot wax treatment.
- Do not use paint cleaners, buffing or polishing products, gloss preservers, e.g. wax.

In the event of paintwork damage:

- Always have paintwork repairs carried out at a qualified specialist workshop.
- Make sure the radar sensors function (→ page 215).

Notes on cleaning decorative films

Observe the "Notes on paintwork/matt finish paintwork care" (\rightarrow page 479). They also apply to matt decorative films.

Observe the notes on cleaning decorative films to avoid damage.

Cleaning

- For cleaning, use plenty of water and a mild cleaning agent without additives or abrasive substances (e.g. a car shampoo approved for Mercedes-Benz).
- Remove dirt as soon as possible. Avoid rubbing too hard in order not to damage the decorative film irreparably.
- If there is dirt on the finish or if the decorative film is dull: use the paint cleaner recommended and approved for Mercedes-Benz.
- Insect remains: soak with insect remover and rinse off the treated areas afterwards.
- Bird droppings: soak with water and rinse off afterwards.
- To prevent water stains, dry a film-wrapped vehicle with a soft, absorbent cloth after every car wash.

Avoiding damage to the decorative film

- The service life and colouring of decorative films are impaired by:
 - Sunlight
 - Temperature (e.g. hot air blower)

- Weather conditions
 - Stone chippings and dirt
 - Chemical cleaning agents
- Oily products
- Do not use polish on matt decorative film. Polishing will have the effect of shining the film-wrapped surface.
- Do not treat matt or structured decorative films with wax. Permanent stains may occur.

Scratches, corrosive deposits, areas affected by corrosion and damage caused by incorrect care cannot always be completely repaired. In this case, contact a qualified specialist workshop.

You can obtain more information on care and cleaning agents from the manufacturer.

In the case of film-wrapped surfaces, visual differences may occur between the surfaces that were not protected by a decorative film after a decorative film has been removed.

i Have work or repairs to decorative films carried out at a qualified specialist workshop (e.g. at a Mercedes-Benz Service Centre).

Notes on care of car parts



WARNING Risk of entrapment if the windscreen wipers are switched on while the windscreen is being cleaned

If the windscreen wipers are set in motion while you are cleaning the windscreen or wiper blades, you can be trapped by the wiper arm.

Always switch off the windscreen wipers and the vehicle before cleaning the windscreen or wiper blades.

To avoid damage to the vehicle, observe the notes on cleaning and care of the following car parts:

Wheels and rims

- Use water and acid-free alloy wheel cleaners.
- · Do not use acidic alloy wheel cleaners to remove brake dust. This could damage wheel bolts and brake components.
- To avoid corrosion of the brake discs and pads, drive the vehicle for a few minutes after cleaning before parking it. The brake discs and pads will warm up and dry out.

Windows



NOTE Damage to electronic components due to excess fluids

When cleaning the windows from the inside, fluids such as cleaning agents or water may run down and get behind trim parts of the vehicle interior and cause damage to electronic components.

- Use cleaning agents as sparingly as possible.
- Immediately absorb any excess fluids.
- Clean the windows inside and outside with a damp cloth and with a cleaning agent recommended for Mercedes-Benz.
- · Do not use dry cloths or abrasive or solventbased cleaning agents to clean the insides of windows.
- After changing the wiper blades or treating the vehicle with wax, clean the windscreen thoroughly with cleaning agents recommended for Mercedes-Benz. Failure to observe the

- application instructions may result in damage, smear marks or dazzling spots.
- Remove external fogging or dirt on the windscreen in front of the multifunction camera. Otherwise, driving systems and driving safety systems may be impaired or unavailable $(\rightarrow page 215).$

Wiper blades

- Move the wiper arms into the replacement position (\rightarrow page 162).
- With the wiper arms folded out, clean the wiper blades with a damp cloth.
- (i) Make sure that the wiper blades are coated. The coating may leave residue on a cloth. Do not rub the wiper blades excessively or clean them too often

Exterior lighting

- Clean the lenses with a wet sponge and mild cleaning agent (e.g. car shampoo).
- Use only cleaning agents or cleaning cloths that are suitable for plastic lenses.

Sensors

- Clean the sensors in the front and rear bumpers with a soft cloth and car shampoo
 (→ page 215).
- When using a high-pressure cleaner, maintain a minimum distance of 30 cm.

Reversing camera and 360° camera

- Open the camera cover with the multimedia system (→ page 270).
- Use clean water and a soft cloth to clean the camera lens.
- Do not use a high-pressure cleaner.

Trailer hitch

- Observe the notes on care in the trailer hitch manufacturer's operator manual.
- Do not clean the ball neck with a high-pressure cleaner or solvent.
- Remove traces of rust on the ball (e.g. using a wire brush).
- · Remove dirt with a lint-free cloth.
- After cleaning, lightly oil or grease the ball head.

 Before using trailers with anti-torsional coupling, observe the manufacturer's operator manual.

Notes on care of the interior



WARNING Risk of injury from plastic parts breaking off after the use of solvent-based care products

Care and cleaning products containing solvents can cause surfaces in the cockpit to become porous. When the airbags are deployed, plastic parts may break away.

Do not use any care or cleaning products containing solvents to clean the cockpit.

A

WARNING Risk of injury or fatal injuries from bleached seat belts

Bleaching or dyeing seat belts can severely weaken them.

This can, for example, cause seat belts to tear or fail in an accident.

Never bleach or dye seat belts.

To avoid damage to the vehicle, observe the following notes on cleaning and care:

Seat belts

- Clean with lukewarm soapy water.
- Do not use chemical cleaning agents.
- Do not dry by heating them to over 80°C or exposing them to direct sunlight.

Display

- · Switch off the display and let it cool down.
- Clean the surface carefully with a microfibre cloth and a suitable display care product (TFT-LCD).
- Do not use any other agents.

Head-up display

- Clean with a soft, non-static, lint-free cloth.
- Do not use cleaning agents.

Plastic trim

- · Clean with a damp microfibre cloth.
- For heavy soiling: use a cleaning agent recommended for Mercedes-Benz.

- · Do not attach stickers, films or similar materials.
- · Do not allow cosmetics, insect repellent or sun cream to come into contact with the plastic trim.

Real wood and trim elements

- · Clean with a microfibre cloth.
- Black piano-lacquer look: clean with a damp cloth and soapy water.
- · For heavy soiling: use a cleaning agent recommended for Mercedes-Benz.
- Do not use solvent-based cleaning agents, polishes or waxes.

Roof lining

• Clean with a brush or dry shampoo.

Carpet

• Use a carpet and textile cleaning agent recommended for Mercedes-Benz.

Steering wheel made of genuine leather or DINA-MICA

- **NOTE** Damage caused by wrong cleaners
- Do not use solvent-based cleaning agents such as tar remover or wheel cleaner; neither should you use polishes or waxes. Otherwise you may damage the finish.
- Clean with a damp cloth and 1% soapy water solution and then wipe with a dry cloth.
- For heavy soiling: use a cleaning agent recommended for Mercedes-Benz.
- Leather care: use a leather care agent that has been recommended for Mercedes-Benz.
- Do not allow the leather to become too damp.
- Do not use a microfibre cloth.
- Leather is a natural product. It exhibits natural surface properties such as differences in structure, marks caused by growth and injury or subtle colour differences. These surface properties are characteristics of leather and

not material faults. Leather is also subject to a natural ageing process during which the surface properties change.

Genuine leather seat covers

- Vacuum up dirt such as crumbs or dust and then clean the seat covers with a damp cotton cloth and wipe down with a dry cloth. Regularly clean the seat covers.
- For heavy soiling: use a leather care agent recommended for Mercedes-Benz aftercare
- · Leather care: use a leather care agent that has been recommended for Mercedes-Benz.
- · Do not use a microfibre cloth.
- Do not allow the leather to become too damp.
- Do not use oil-based cleaning and care products.

Leather is a natural product. It exhibits natural surface properties such as differences in structure, marks caused by growth and injury or subtle colour differences. These surface properties are characteristics of leather and not material faults. Leather is also subject to a natural ageing process during which the surface properties change. Waves or wrinkling in the seat cover may occur due to the stress on the seat; this is caused by the natural leather material. Regular cleaning and care of the leather reduces soiling, wear marks and ageing damage and thus significantly extends its life span. Clothing that can leave stains (e.g. jeans) may discolour the leather.

DINAMICA seat covers

- Vacuum up dirt such as crumbs or dust and then use a damp cloth to clean.
- Do not use a microfibre cloth.

Imitation leather seat covers

• Vacuum up dirt such as crumbs or dust and then use a damp cotton cloth and a 1% soap


- solution to clean the entire seat cover. Do not spot clean.
- Use cleaning and care products recommended for Mercedes-Benz.
- · Do not use a microfibre cloth.
- Do not use oil-based cleaning and care products.

Fabric seat covers

- Vacuum up dirt such as crumbs or dust and then use a damp microfibre cloth and a 1% soap solution to clean the entire seat cover. Do not spot clean.
- Use cleaning and care products recommended for Mercedes-Benz.
- Do not use oil-based cleaning and care products.

Emergency

Removing the safety vest




The safety vests are located in the safety vest compartments of the door compartment of all doors, under the armrests.

To remove: pull out safety vest bag 1 by the loop 2.

- Open the safety vest bag (1) and pull out the safety vest.
- To stow: fold the safety vest, roll it up and stow it in the safety vest bag 1.
- Slide the safety vest bag along the lower edge of the armrest into the safety vest compartment. Make sure the loop 2 hangs out so it is easily accessible.
- For a new safety vest, remove the packaging film before sliding it into the safety vest compartment. Otherwise, it may cause unintentional slipping out or make it difficult to remove.

Observe the legal requirements for each individual country.



- Maximum number of washes
- Maximum wash temperature
- Do not bleach
- Do not iron
- Do not tumble dry
- Do not dry clean
- Class 2 safety vest

The requirements defined by the legal standard are only fulfilled if the safety vest is the correct size and is fully closed.

Replace the safety vest in the following cases:

The reflective strips are damaged or dirty

486 Breakdown assistance


- The maximum permissible number of washes is exceeded
- The fluorescence property decreases, e.g. due to permanent exposure to sunlight.

Dispose of the safety vest in an environmentally friendly manner:

Please contact your local waste disposal company.

Warning triangle

Removing the warning triangle




- Push both sides of warning triangle holder in the direction of the arrow and open it.
- Remove warning triangle ②.

The warning triangle is located in the boot lid.

Setting up the warning triangle

- Fold the side reflectors upwards to form a triangle and attach at the top using the upper press-stud.
- Fold the legs down and out to the side.

First-aid kit (soft sided) overview



First-aid kit (soft sided) ① is in the boot in the left-hand stowage net.

Removing the fire extinguisher



WARNING Risk of accident due to an incorrectly secured fire extinguisher in the driver's footwell

A fire extinguisher may impede pedal travel or block a depressed pedal.

This jeopardises the operating and road safety of the vehicle.

The fire extinguisher can be flung around and injure the driver or other vehicle occupants.

- Always store and secure the fire extinguisher in the bracket.
- Do not remove the fire extinguisher while driving.



- **Left-hand drive vehicle:** pull tab **1** upwards.
- **Right-hand drive vehicle:** pull tab **1** downwards.
- Remove fire extinguisher 2.

Flat tyre

Notes on flat tyres



WARNING Risk of accident due to a flat tyre

A flat tyre severely affects the driving characteristics as well as the steering and braking of the vehicle.

Tyres without run-flat characteristics:

- Do not drive with a flat tyre.
- Change the flat tyre immediately with an emergency spare wheel or spare wheel. Alternatively, consult a qualified specialist workshop.


Tyres with run-flat characteristics:

Observe the information and warning notes on MOExtended tyres (run-flat tyres).

In the event of a flat tyre, the following options are available depending on your vehicle's equipment:

- Vehicles with a TIREFIT kit: you can seal the tyre so that it is possible to continue the journey for a short period of time. To do this, use the TIREFIT kit (\rightarrow page 488).
- Vehicles with Mercedes me connect: you can make a call for breakdown assistance via the overhead control panel in the case of a breakdown (\rightarrow page 429).
- All vehicles: change the wheel (\rightarrow) page 519).

TIREFIT kit storage location



- Tyre sealant bottle
- Tyre inflation compressor

The TIREFIT kit is located under the boot floor when delivered.

Depending on the vehicle version, the TIREFIT kit may be in a different position in the boot.

- (i) Depending on the power category (LK), the tyre inflation compressor weighs as follows:
 - LK2 12 V/15 A, 180 W, 0.9 kg

You can find information on the power category (LK) and/or electrical data on the back of the tyre inflation compressor.

The tyre inflation compressor is maintenancefree. If there is a malfunction, please contact a qualified specialist workshop.

Using the TIREFIT kit

Requirements:

- Tyre sealant bottle and tyre inflator compressor are ready for use (→ page 488).
- TIREFIT sticker is present.
- · Gloves are present.

TIREFIT kit storage location: (\rightarrow page 488)

You can use TIREFIT tyre sealant to seal perforation damage of up to 4 mm, particularly those in the tyre contact surface. You can use TIREFIT in outside temperatures down to -20 °C.

A

WARNING Risk of accident when using tyre sealant

The tyre sealant may be unable to seal the tyre properly, especially in the following cases:

- there are large cuts or punctures in the tyre (larger than damage previously mentioned)
- the wheel rims have been damaged
- after journeys with very low tyre pressure or with flat tyres
- Do not continue driving.
- Consult a qualified specialist workshop.

WARNING Risk of injury and poisoning from tyre sealant

Tyre sealant is hazardous to health and causes irritation. Do not allow it to come into contact with your skin, eyes or clothing, and do not swallow it. Do not inhale any vapours. Keep the tyre sealant away from children.

Observe the following if you come into contact with the tyre sealant:

- Rinse off the tyre sealant from your skin using water immediately.
- If tyre sealant gets into your eyes, thoroughly rinse them using clean water immediately.
- If tyre sealant has been swallowed, thoroughly rinse out your mouth immediately and drink plenty of water. Do not induce vomiting and seek medical attention immediately.
- Change out of clothing which has come into contact with tyre sealant immediately.
- If an allergic reaction occurs, seek medical attention immediately.
- ! NOTE Overheating due to the tyre inflation compressor running too long
- Do not run the tyre inflation compressor for longer than ten minutes without interruption.

Comply with the manufacturer's safety notes on the sticker on the tyre inflation compressor.

Have the tyre sealant bottle replaced in a qualified specialist workshop every five years.

Do not remove any foreign objects which have entered the tyre.



- Affix part
 of the TIREFIT sticker to the instrument cluster within the driver's field of vision.
- Affix part ② of the TIREFIT sticker near the valve on the wheel with the defective tyre.



- Pull plug 4 with the cable and hose 5 out of the tyre inflation compressor housing.
- Push the plug of hose (5) into flange (6) of tyre sealant bottle (1) until the plug engages.
- Place tyre sealant bottle head downwards into recess for the tyre inflation compressor.



- Remove the valve cap from valve on the faulty tyre.
- Screw filling hose (3) onto valve (7).
- Insert plug (a) into a 12-V-socket in your vehicle.
- Switch on the vehicle.
- Press on and off switch (3) on the tyre inflation compressor.

The tyre inflation compressor is switched on. The tyre is inflated. First, tyre sealant is pumped into the tyre. The pressure may briefly rise to approximately 500 kPa (5 bar/73 psi).

Do not switch off the tyre inflation compressor during this phase!

Let the tyre inflation compressor run for a maximum of ten minutes.

The tyre should then have attained a tyre pressure of at least 200 kPa (2.0 bar/29 psi).

If tyre sealant leaks out, make sure you clean the affected area as quickly as possible. It is preferable to use clean water.

If you get tyre sealant on your clothing, have it cleaned as soon as possible with perchloroethylene.

If, after ten minutes, a tyre pressure of 200 kPa (2.0 bar/29 psi) has not been attained:

- Switch off the tyre inflation compressor.
- Unscrew the filling hose from the valve of the defective tyre.

Please note that tyre sealant may leak out when unscrewing the filling hose.

Drive forwards or in reverse very slowly for approximately 10 m.

Pump up the tyre again. After a maximum of ten minutes the tyre pressure must be at least 200 kPa (2.0 bar/29 psi).

WARNING Risk of accident due to the specified tyre pressure not being attained

If the specified tyre pressure is not attained after the specified time, the tyre is too badly damaged. The tyre sealant cannot repair the tyre in this instance.

The braking and driving characteristics may be greatly impaired.

- Do not continue driving.
- Consult a qualified specialist workshop.

If, after ten minutes, a tyre pressure of 200 kPa (2.0 bar/29 psi) has been attained:

WARNING Risk of accident from driving with sealed tyres

A tyre temporarily sealed with tyre sealant impairs the handling characteristics and is not suitable for higher speeds.

- Adapt your driving style accordingly and drive carefully.
- Do not exceed the maximum speed limit with a tyre that has been repaired using tyre sealant.
- Observe the maximum permissible speed of 80 km/h for a tyre sealed with tyre sealant.
- Affix the upper section of the TIREFIT sticker to the instrument cluster in a location where it will be easily seen by the driver.
- ! NOTE Staining from leaking tyre sealant

After use, excess tyre sealant may leak out from the filling hose.

- Therefore, place the filling hose in the plastic bag that contained the TIREFIT kit.
- ENVIRONMENTAL NOTE Environmental pollution caused by environmentally irresponsible disposal

Tyre sealant contains pollutants.

- Have the tyre sealant bottle disposed of professionally, e.g. at a Mercedes-Benz Service Centre.
- Switch off the tyre inflation compressor.
- Unscrew the filling hose from the valve of the defective tyre.
- Stow the tyre sealant bottle and the tyre inflation compressor.
- Pull away immediately.
- Stop driving after approximately ten minutes and check the tyre pressure using the tyre inflation compressor.

The tyre pressure must now be at least 130 kPa (1.3 bar/19 psi).

★ WARNING Risk of accident due to the specified tyre pressure not being attained


If the specified tyre pressure is not reached, the tyre is too badly damaged. The tyre sealant cannot repair the tyre in this instance.

The braking and driving characteristics may be greatly impaired.

- Do not continue driving.
- Consult a qualified specialist workshop.


Countries that have Mercedes-Benz Service24h: you will find a sticker with the telephone number, e.g. on the B-pillar on the driver's side.

- Correct the tyre pressure if it is still at least 130 kPa (1.3 bar/19 psi). See the tyre pressure table on the fuel filler flap for values.
- ➤ To increase the tyre pressure: switch on the tyre inflation compressor.



To reduce the tyre pressure: press pressure release button next to manometer 2.

- When the tyre pressure is correct, unscrew the filling hose from the valve of the sealed tyre.
- Screw the valve cap onto the valve of the sealed tyre.



- Pull the tyre sealant bottle out of the tyre inflation compressor. Press the locking tabs on the yellow cap together to do this.
 The filling hose stays on the tyre sealant bottle.
- Drive to the nearest qualified specialist workshop and have the tyre, tyre sealant bottle and filling hose replaced there.

Battery (vehicle)

Notes on the 12 V battery

WARNING Risk of an accident due to work carried out incorrectly on the battery

Work carried out incorrectly on the battery can, for example, lead to a short circuit. This can restrict functions relevant for safety systems and impair the operating safety of your vehicle.

You could lose control of the vehicle in the following situations in particular:

- · when braking
- in the event of abrupt steering manoeuvres and/or when the vehicle's speed is not adapted to the road conditions
- In the event of a short circuit or a similar incident, contact a qualified specialist workshop immediately.
- Do not drive on.
- Always have work on the battery carried out at a qualified specialist workshop.

- Further information on ABS (→ page 217)
- Further information on $ESP^{\mathbb{R}}(\rightarrow page 218)$

For safety reasons, Mercedes-Benz recommends that you only use batteries which have been approved for your vehicle by Mercedes-Benz.

All vehicles except vehicles with a lithium-ion battery



WARNING Risk of explosion due to electrostatic charge

Electrostatic charge can ignite the highly explosive gas mixture in the battery.

To discharge any electrostatic charge that may have built up, touch the metal vehicle body before handling the battery.

The highly flammable gas mixture is created while the battery is charging and during starting assistance.



WARNING Danger of chemical burns from the battery acid

Battery acid is caustic.

- Avoid contact with the skin, eyes or clothing.
- ▶ Do not lean over the battery.
- Do not inhale battery gases.
- Keep children away from the battery.
 - Immediately rinse battery acid off thoroughly with plenty of clean water and seek medical attention immediately.

All vehicles

ENVIRONMENTAL NOTE Environmental damage due to improper disposal of batteries

Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.

Dispose of batteries in an environmentally responsible manner.

Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

If you have to disconnect the 12 V battery, contact a qualified specialist workshop.

Comply with safety notes and take protective measures when handling batteries.



Risk of explosion if the 12 V battery is used improperly.



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes or clothing. Wear suitable protective clothing, in particular gloves, an apron and a face mask. Immediately rinse electrolyte or acid splashes off with clean water. Consult a doctor immediately.



Do not place heavy objects on the surface of the battery or use the battery to support a person in any way.



Wear safety glasses.



Keep children away.



Observe this Owner's Manual.

Observe the following if you do not intend to use the vehicle over an extended period of time:

 Connect the battery to a battery charger approved by Mercedes-Benz or consult a qualified specialist workshop to disconnect the battery.

Notes on the 48 V battery

WARNING Risk of an accident due to work carried out incorrectly on the battery

Work carried out incorrectly on the battery can, for example, lead to a short circuit. This can restrict functions relevant for safety sys-

tems and impair the operating safety of your vehicle.

You could lose control of the vehicle in the following situations in particular:

- when braking
- in the event of abrupt steering manoeuvres and/or when the vehicle's speed is not adapted to the road conditions
- In the event of a short circuit or a similar incident, contact a qualified specialist workshop immediately.
- Do not drive on.
- Always have work on the battery carried out at a qualified specialist workshop.
- Further information on ABS (→ page 217)
- Further information on $ESP^{\otimes}(\rightarrow page 218)$

For safety reasons, Mercedes-Benz recommends that you only use batteries which have been approved for your vehicle by Mercedes-Benz.



ENVIRONMENTAL NOTE Environmental damage due to improper disposal of batteries



Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.



Library Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

If you have to disconnect the 48 V battery, contact a qualified specialist workshop.

Comply with safety notes and take protective measures when handling batteries.



Risk of explosion if the 48 V battery is used improperly.



The surface of the 48 V battery may be hot.



Fire, naked flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes or clothing. Wear suitable protective clothing, in particular gloves, an apron and a face mask. Immediately rinse off splashes of electrolyte or acid with plenty of clean water. Consult a doctor immediately.



Do not place heavy objects on the surface of the battery or use the battery to support a person in any way.



Do not perform any work on the battery. Always have any work on the battery carried out at a qualified specialist workshop. Do not disconnect the battery yourself. Do not remove the battery yourself. Do not attempt to open the battery.



Keep children away.



Wear safety glasses.



Observe this Owner's Manual.

If you do not want to use the vehicle for a long period of time, consult a qualified specialist workshop.

Notes on starting assistance and charging the 12 V battery

All vehicles

When charging the battery and during starting assistance, always use the jump-start connection point in the engine compartment.

! NOTE Damage to the battery due to overvoltage

When charging using a battery charger without a maximum charging voltage, the battery or the on-board electronics may be damaged.

Only use battery chargers with a maximum charging voltage of 14.8 V.

WARNING Risk of explosion due to the ignition of hydrogen gas

If there is a short circuit or sparks are created, there is a danger of hydrogen gas igniting when you charge the battery.

- Make sure that the POSITIVE terminal of a connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- When connecting and disconnecting the battery, always observe the sequence of battery terminals described.
- During starting assistance, always take care to connect only battery terminals of identical polarity.
- During starting assistance, observe the sequence described for connecting and disconnecting the jump leads.

Do not connect or disconnect the battery terminals with the engine running.

WARNING Risk of explosion due to explosive mixture of gases

An explosive mixture of gases can escape from the battery during charging and starting assistance.

- Fire, naked flames, smoking and creating sparks must be avoided.
- Make sure there is adequate ventilation.
- Do not stand over the battery.

WARNING Risk of explosion from a frozen battery

A discharged battery may freeze at temperatures slightly above or below freezing point.

During starting assistance or battery charging, battery gas can be released.

Always allow a battery to thaw before charging it or performing starting assistance. If the indicator/warning lamps in the instrument cluster do not light up at low temperatures, it is very likely that the discharged battery has frozen. In this case you may neither jump-start the vehicle nor charge the battery.

The service life of a battery that has been thawed may be dramatically shortened. The starting characteristics may be impaired, especially at low temperatures.

It is recommended that you have a thawed battery checked at a qualified specialist workshop.

All vehicles

NOTE Damage caused by numerous or extended attempts to start the engine

Numerous or extended attempts to start the engine may damage the catalytic converter due to non-combusted fuel.

Avoid numerous and extended attempts to start the engine.

Observe the following points during starting assistance and when charging the battery:

- Only use undamaged jump lead/charging cables with a sufficient cross-section and insulated terminal clamps.
- Non-insulated parts of the terminal clamps must not come into contact with other metal parts while the jump lead/charging cable is connected to the battery/jump-start connection point.
- The jump lead/charging cable must not come into contact with any parts which may move when the engine is running.
- Always make sure that neither you nor the battery is electrostatically charged.
- Keep away from fire and naked flames.
- Do not lean over the battery.

Observe the additional following points when charging the battery:

- Only use battery chargers tested and approved for Mercedes-Benz.
- Read the battery charger's operating instructions before charging the battery.

Observe the additional following points during starting assistance:

- Starting assistance may only be provided using vehicles, batteries or other jump start devices with a nominal voltage of 12 V.
- · The vehicles must not touch.
- Vehicles with a petrol engine: jump-start the vehicle only when the engine and exhaust system are cold.

Starting assistance and charging the 12 V battery


Preparing starting assistance/charging

- Secure the vehicle by applying the electric parking brake.
- Switch the transmission to position **P**.
- Switch off the vehicle and all electrical consumers.
- Open the bonnet.



Open cover

of the jump-starting connection points.



Open cover 3 of positive contact 2 of the jump-starting connection points.

Starting assistance

Connect positive contact 2 on your vehicle to the positive terminal of the donor battery using the jump lead. Always begin with positive contact 2 on your own vehicle first.

- Start the engine of the donor vehicle and run it at idling speed.
- Connect the negative terminal of the donor battery to earth point 4 of your vehicle using the jump lead. Begin with the donor battery first.
- Start the engine of your own vehicle.
- Let the engines run for several minutes.
- Before disconnecting the jump leads, switch on an electrical consumer in your own vehicle, e.g. the rear window heater or the lighting.

When the starting assistance procedure is complete:

- First, remove the jump leads from earth point 4 and the negative terminal of the donor battery, then from positive contact 2 and the positive terminal of the donor battery. Begin each time with the contacts on your own vehicle first
- After removing the jump leads, close cover (3) of positive contact (2).
- Close cover 1.

Further information can be obtained at a qualified specialist workshop.

Charging

- Connect positive contact (2) of the vehicle to the positive terminal of the charger using the charging cable. Always begin with positive contact (2) of the vehicle.
- Connect the negative terminal of the charger and earth point on the vehicle with the charging cable. Start with the charger.
- Start the charging process.

When the charging process is complete:

- First, remove the charging cable from earth point (a) and the negative terminal of the charger, then from positive contact (a) and the positive terminal of the charger. Begin each time with the contacts of the vehicle.
- After removing the charging cable, close cover
 of positive contact ②.
- Close cover ①.

Further information can be obtained at a qualified specialist workshop.

Replacing the 12 V battery

Observe the notes on the 12 V battery $(\rightarrow page 492)$.

Mercedes-Benz recommends that you have the 12 V battery replaced at a qualified specialist workshop, e.g. at a Mercedes-Benz Service Centre.

Observe the following notes if you want to replace the battery yourself:

 Always replace a faulty battery with a battery which meets the specific vehicle requirements.

The vehicle is equipped with an AGM (Absorbent Glass Mat) technology battery or a lithiumion battery. Full vehicle functionality is only guaranteed with an AGM battery or lithiumion battery. For safety reasons, Mercedes-Benz recommends that you only use batteries which have been tested and approved for your vehicle by Mercedes-Benz.

- Carry over detachable parts, such as vent hoses, elbow fittings or terminal covers from the battery being replaced.
- Make sure that the vent hose is always connected to the original opening on the side of the battery.

Fit any existing or supplied cell caps. Otherwise, gases or battery acid could escape.

Make sure that detachable parts are reconnected in the same way.

Tow-starting or towing away

Permitted towing methods (not plug-in hybrid)

! NOTE Damage from automatic braking

If one of the following functions is activated, the vehicle will brake automatically in certain situations:

- · Active Brake Assist
- Active Distance Assist DISTRONIC

- HOLD function
- · Active Parking Assist

To avoid damage to the vehicle, deactivate these systems in the following or similar situations:

- When towing.
- In a car wash.

Mercedes-Benz recommends transporting your vehicle in the case of a breakdown, rather than towing it away.

For towing with both axles on the ground, use a tow rope or tow rod. Do not use tow bar systems.

- **NOTE** Damage to the vehicle due to towing away incorrectly
- Observe the instructions and notes on towing away.

Vehicles with rear wheel drive

Permitted towing methods	
Both axles on the ground	Yes, for a maximum of 50 km at 50 km/h
Front axle raised	No
Rear axle raised	Yes, if the steering wheel is fixed in the centre position with a steering wheel lock

4MATIC vehicles

Permitted towing methods

Both axles on the ground	Yes, for a maximum of 50 km at 50 km/h
Front axle raised	No
Rear axle raised	No

Towing with a raised axle: towing should be performed by a towing company.

Towing the vehicle with both axles on the ground

- Observe the notes on the permitted towing methods.
- Make sure that the battery is connected and charged.

Observe the following points when the battery is discharged:

- The vehicle cannot be started.
- The electric parking brake cannot be released or applied.
- Vehicles with automatic transmission: the transmission cannot be shifted to position N or P.
- Vehicles with automatic transmission: if the transmission cannot be shifted to position N or if the display does not show anything, transport the vehicle (\rightarrow page 502, 501). A towing vehicle with lifting equipment is required for vehicle transportation.

NOTE Damage due to towing away at excessively high speeds or over long distances

The drivetrain could be damaged when towing at excessively high speeds or over long distances.

- A towing speed of 50 km/h must not be exceeded.
- A towing distance of 50 km must not be exceeded.

WARNING Risk of accident when towing a vehicle which is too heavy

If the vehicle to be tow-started or towed away is heavier than the permissible gross mass of your vehicle, the following situations can occur:

- the towing eye may become detached.
- the vehicle/trailer combination may swerve or overturn.
- Before tow-starting or towing away, check if the vehicle to be tow-started or

towed away exceeds the permissible gross mass.

If a vehicle has to be tow-started or towed away, its permissible gross mass must not exceed the permissible gross mass of the towing vehicle.

- Information on the permissible gross mass of the vehicle can be found on the vehicle identification plate (→ page 630).
- ▶ Vehicles with automatic transmission: do not open the driver's door or front-passenger door; the transmission otherwise automatically shifts to position | P |.
- Fit the towing eye (\rightarrow page 504).
- Fasten the towing device.
- ! NOTE Damage due to incorrect connection of the tow bar
- Only connect the tow rope or tow bar to the towing eyes.
- Deactivate the automatic locking mechanism (→ page 90).

- Do not activate the HOLD function.
- Deactivate tow-away protection (→ page 109).
- Deactivate Active Brake Assist (→ page 248).
- Vehicles with automatic transmission: shift to position N.
- Release the electric parking brake.

WARNING Risk of accident due to limited safety-related functions during the towing process

Safety-related functions are limited or no longer available in the following situations:

- · the vehicle is switched off.
- the brake system or power steering system is malfunctioning.
- the energy supply or the on-board electrical system is malfunctioning.

When your vehicle is towed away, significantly more effort may be required to steer and brake than is normally required.

- Use a tow bar.
- Make sure that the steering wheel can move freely before towing the vehicle away.
- ! NOTE Damage due to excessive tractive power

If you pull away sharply, the tractive power may be too high and the vehicles could be damaged.

Pull away slowly and smoothly.

Loading the vehicle for transport (vehicles without AIRMATIC)

- Observe the notes on towing away (\rightarrow) page 499).
- Connect the towing device to the towing eye in order to load the vehicle.
- You can also attach the tow bar to the trailer hitch.

- Shift the automatic transmission to position [N].
- The automatic transmission may be locked in position P in the event of damage to the electrics. To shift to N, provide the on-board electrical system with power (→ page 496).
- Load the vehicle onto the transporter.
- Shift the automatic transmission to position P.
- Use the electric parking brake to secure the vehicle against rolling away.
- Only secure the vehicle by the wheels.

4MATIC vehicles/vehicles with automatic transmission



- Make sure that the front and rear axles come to rest on the same transportation vehicle.
- NOTE Damage to the drive train due to incorrect positioning of the vehicle
- Do not position the vehicle above the connection point of the transport vehicle.

Requirements

- The vehicle must be stationary.
- The vehicle must be switched off.
- The driver's display must be in the initial state with no menus open (→ page 305). Transport is also possible with a warning message visible.
- The 12 V battery is charged.
- Select vehicle transport.
- i The noise certification mode is intended exclusively for the technical test organisation. It restricts the drive power of the vehicle and must not be used in customer operation.
- If necessary, set the system language (→ page 358).
- Observe the notes on towing away (→ page 499).
- Connect the towing device to the towing eye in order to load the vehicle.

- (i) Vehicles with a trailer hitch: you can also attach the tow bar to the trailer hitch.
- Switch on the power supply (\rightarrow page 181).
- Shift the transmission to position N.
- (i) The transmission may be locked in position [P] in the event of damage to the electrics. To shift to [N], provide the on-board electrical system with power (→ page 496).
- ! NOTE Possible damage to the vehicle when loading or unloading

When loading or unloading, the vehicle must be raised to transport level.

If the transport settings are not shown or the Vehicle not ready for loading message is displayed, the vehicle may not be loaded or unloaded.

- If required, raise the vehicle to transport level again.
- A vehicle that cannot be raised to transport level may not be loaded or unloaded using a ramp. Consult a qualified specialist workshop.



WARNING Risk of accident due to activated transport level

If the vehicle is raised to transport level, driving and driving safety systems have only limited availability and the view from the vehicle is restricted.

Driving safety is severely restricted and there is a risk of an accident!

- Do not use transport level in normal road operation.
- Only activate and use transport level to load the vehicle and when not on public roads.

Ensure that no persons or obstacles are located in the area surrounding the vehicle.

Raising the vehicle to transport level

- Press the button for at least five seconds.
- Immediately press and hold the OK button for at least one second. The For transport level, switch vehicle on message is displayed.
- Switch on the vehicle(→ page 182). The transport settings are displayed.
- Swipe downward to select Transport level and press OK.
 The vehicle is raised and the Vehicle rising...
 Do not drive on ramp message is displayed for 5 seconds. The raising process can last up to 60 seconds and can be cancelled with the
- ▶ When raising, do not switch off the vehicle.

button.

While the vehicle is being raised, you can manoeuvre at a maximum speed of 40 km/h.



- Before loading the vehicle, wait until the transport level has been reached and the Transport level status is shown.
- (i) If the vehicle is raised to transport level, the transport settings will continue to be shown even after a restart. Operation of the driver's display is restricted.

When the vehicle is at transport level, it is lowered again in the following situations:


- When driving faster than 40 km/h.
- If the 12 V battery is discharged.

The vehicle is adjusted to the height of the last active level.

Transporting the vehicle

- Load the vehicle onto the transporter.
- Shift the transmission to position **P**.
- Use the electric parking brake to secure the vehicle against rolling away.
- Switch off the vehicle and the power supply.
- Only secure the vehicle by the wheels.

4MATIC vehicles



Make sure that the front and rear axles come to rest on the same transportation vehicle.

- ! NOTE Damage to the drive train due to incorrect positioning of the vehicle
- Do not position the vehicle above the connection point of the transport vehicle.

Unloading the vehicle

Make sure that the vehicle is raised to transport level before unloading (→ page 502, 501).

Lowering the vehicle after unloading

- Switch on the power supply.
- Start the vehicle.
- In Transport Settings, swipe up to select the Standard level and press OK.
 The vehicle is adjusted to the height of the last active level and the Lowering vehicle message is displayed.
- After the vehicle has been lowered, press the button for at least two seconds.

 Transport Settings closes.

Towing eye storage location


Not plug-in hybrid



The towing eye \bigcirc is located under the boot floor in the loading sill.

i Depending on the vehicle version, the towing eye is in a different position in the boot.

Fitting and removing the towing eye



- Press the mark on cover inwards and remove.
- Screw in the towing eye clockwise as far as it will go and tighten.

Vehicles with a trailer hitch: vehicles with a trailer hitch do not have a rear bracket for the towing eye. Fasten the tow bar to the trailer hitch.

- After removing the towing eye, secure the cover (1) in the bumper.
- NOTE Damage to the vehicle due to incorrect use of the towing eye or trailer hitch

When a towing eye or trailer hitch is used to recover a vehicle, the vehicle may be damaged in the process.

- Only use the towing eye or trailer hitch to tow away or tow start the vehicle.
- Do not use the towing eye or trailer hitch to tow the vehicle during recovery.

Tow-starting the vehicle

Vehicles with automatic transmission

NOTE Damage to the automatic transmission due to tow-starting

The automatic transmission may be damaged in the process of tow-starting vehicles with automatic transmission.

- Vehicles with automatic transmission must not be tow-started.
- Vehicles with an automatic transmission must not be tow-started.

Electrical fuses

Notes on electrical fuses

WARNING Risk of accident and injury due to overloaded lines

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric line could be overloaded.

This could result in a fire.

 Always replace faulty fuses with specified new fuses containing the correct amperage. NOTE Damage due to incorrect fuses

Using incorrect fuses can result in damage to electrical components or systems or their functions being considerably restricted.

 Use only fuses approved for Mercedes-Benz with the respective specified fuse rating.

Blown fuses must be replaced with fuses of the same rating, which you can recognise by the colour and the label. The fuse ratings and further information to be observed can be found in the fuse assignment diagram.

Fuse assignment diagram: on the fuse box in the boot (\rightarrow page 508).

! NOTE Damage or malfunctions caused by moisture

Moisture may cause damage to the electrical system or cause it to malfunction.

When the fuse box is open, make sure that no moisture can enter the fuse box. When closing the fuse box, make sure that the seal of the lid is positioned correctly on the fuse box.

If the newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop.

Ensure the following before replacing a fuse:

- The vehicle is secured against rolling away.
- All electrical consumers are switched off.
- · The vehicle is switched off.

The electrical fuses are located in various fuse boxes:

- Fuse box in the engine compartment on the driver's side (→ page 506)
- Fuse box on the driver's side of the cockpit
 (→ page 507)
- Fuse box in the front passenger footwell
 (→ page 508)
- Fuse box in the boot (→ page 508)

Opening and closing the fuse box in the engine compartment

Requirements

• A dry cloth and a screwdriver are available.

Observe the notes on electrical fuses (\rightarrow page 505).

Opening


WARNING Risk of injury from using the windscreen wipers when the bonnet is open

If the windscreen wipers start moving when the bonnet is open, you could be trapped by the wiper linkage.

- Always switch off the windscreen wipers and the vehicle first if you need to open the bonnet.
- \triangleright Open the bonnet (\rightarrow page 471).




- Turn both retaining clips ② on cover ① on the driver's side a quarter-turn clockwise.
- Fold cover 1 upwards.




- Remove any existing moisture from the fuse box using a dry cloth.
- Loosen screws 3 and remove fuse box lid 4 from the top.

Closing

Check whether the seal is positioned correctly in lid 🐠.




- Insert lid 4 into the bracket at the rear of the fuse box.
- Fold down lid 4 of the fuse box and tighten screws 3.



- Fold down cover 1.
- Turn both retaining clips 2 on cover 1 a quarter-turn anti-clockwise.
- Close the bonnet.

Opening and closing the fuse box in the cockpit

 Observe the notes on electrical fuses $(\rightarrow page 505)$.




Fuse box ① is on the driver's side on the side of the cockpit under a cover.

- Open cover
 in the direction of the arrow and remove it.
- Mercedes-Benz recommends you have the fuse box opened at a Mercedes-Benz Service Centre.

Opening and closing the fuse box in the front passenger footwell

Observe the notes on electrical fuses (\rightarrow page 505).



- To open: fold out and remove cover 1
- ► To close: reinsert cover ①.

Opening and closing the fuse box in the boot

Observe the notes on electrical fuses $(\rightarrow page 505)$.



Open cover ①.

Notes on noise or unusual handling characteristics

Make sure there are no vibrations, noises or unusual handling characteristics when the vehicle is in motion. This may indicate that the wheels or tyres are damaged. Hidden tyre damage could also be causing the unusual handling characteristics.

If you suspect that a tyre is defective, reduce your speed immediately and have the tyres and wheels checked at a qualified specialist workshop.

Notes on regularly inspecting wheels and tyres



WARNING Risk of injury due to damaged tyres

Damaged tyres can cause tyre pressure loss.

► Check the tyres regularly for signs of damage and replace any damaged tyres immediately.

WARNING Risk of aquaplaning due to insufficient tyre tread

Insufficient tyre tread will result in reduced tyre grip.

The risk of aquaplaning is increased on wet roads, especially when the speed of the vehicle is not adapted to suit the conditions.

Thus, you should regularly check the tread depth and the condition of the tread across the entire width of all tyres.

Minimum tread depth for:

- Summer tyres: 3 mm
- M+S tyres: 4 mm
- For safety reasons, replace the tyres before the legally-prescribed limit for the minimum tread depth is reached.

Carry out the following checks on all wheels regularly, at least once a month or as required, for example, prior to a long journey or driving offroad:

• Check the tyre pressure (\rightarrow page 510).

- Visually inspect wheels and tyres for damage.
- Check the valve caps.
- · Visual check of the tyre tread depth and the tyre contact surface across the entire width.

The minimum tread depth for summer tyres is 3 mm and for winter tyres 4 mm.

Notes on snow chains



WARNING Risk of accident due to incorrectly fitted snow chains

If you have fitted snow chains to the front wheels, they may drag against the vehicle body or chassis components.

- Never fit snow chains to the front wheels.
- Only fit snow chains on the rear wheels in pairs.

I NOTE Damage to components of the vehicle body or chassis due to fitted snow chains

If you fit snow chains to the front wheels of 4MATIC vehicles, you may damage components of the vehicle body or chassis.

- Only fit snow chains to the rear wheels of 4MATIC vehicles.
- NOTE Damage to wheel trims through fitted snow chains

If you fit snow chains on aluminium wheels you could damage the wheel trims.

Remove the wheel trims from the aluminium wheels before fitting snow chains.

Observe the following notes when using snow chains:

 Snow chains are only permissible for certain wheel/tyre combinations. You can obtain information about this from a Mercedes-Benz Service Centre.

- For safety reasons, only use snow chains that have been specifically approved for your vehicle by Mercedes-Benz, or snow chains with the same quality standard.
- Comply with the installation instructions of the snow chain manufacturer.
- If snow chains are fitted, the maximum permissible speed is 50 km/h.
- Vehicles with Active Parking Assist: do not use Active Parking Assist when snow chains are fitted.
- Vehicles with level control: if snow chains are fitted, only drive at raised vehicle level (→ page 262).
- You can permanently limit the maximum speed for driving with winter tyres (→ page 227).
- You can deactivate ESP[®] to pull away
 (→ page 220). This allows the wheels to spin, achieving an increased driving force.

Activating or deactivating snow chain mode

Multimedia system:



Activate or deactivate Snow chain mode.

When the function is active, the vehicle behaves as if snow chains were installed. For example, the maximum steering movement of the rear wheels is limited and the turning circle is thus increased.

Additionally, parts of the driving and driving safety systems are not available when snow chain mode is active.

Tyre pressure

Notes on tyre pressure



WARNING Risk of accident due to insufficient or excessive tyre pressure

Underinflated or overinflated tyres pose in particular the following risks:

The tyres can burst.

- The tyres can wear excessively and/or unevenly.
- The driving characteristics as well as the steering and braking characteristics may be greatly impaired.
- Comply with the recommended tyre pressure and check the tyre pressure of all tyres, including the spare wheel, regularly:
- monthly
- when the load changes
- before embarking on a longer journey
- if operating conditions change, e.g. offroad driving
- Adjust the tyre pressure, if necessary.

Tyre pressure which is too high or too low can:

- Shorten the service life of the tyres.
- Cause increased tyre damage.
- · Adversely affect driving characteristics and thus driving safety, e.g. due to aquaplaning.

WARNING Risk of accident due to repeated pressure drop in the tyres

The wheels, valves or tyres could be damaged.

Too low a tyre pressure can lead to the tyres bursting.

- Examine the tyres for foreign objects.
- Check whether the tyre has a puncture or the valve has a leak.
- If you are unable to rectify the damage, contact a qualified specialist workshop.

Information on the recommended tyre pressure for the vehicle's factory-fitted tyres can be found on the tyre pressure table on the inside of the fuel filler flap (\rightarrow page 511).

Use a suitable pressure gauge to check the tyre pressure. The outer appearance of a tyre does not permit any reliable conclusion about the tyre pressure.

Only correct tyre pressures when the tyres are cold. Conditions for cold tyres:

• The vehicle has been parked with the tyres out of direct sunlight for at least three hours.

The vehicle has travelled less than 1.6 km.


The vehicle's tyres heat up when driving. As the temperature of the tyres increases, so too does the tyre pressure.

Notes on trailer operation

Always inflate the rear axle tyres to the recommended tyre pressures on the tyre pressure table for increased load.

Tyre pressure table

The tyre pressure table is on the inside of the fuel filler flap.



The tyre pressure table shows the recommended tyre pressure for all tyres approved for this vehicle. The recommended tyre pressures apply for cold tyres under various operating conditions, i.e. loading and/or speed of the vehicle.

If one or more tyre sizes precede a tyre pressure, the following tyre pressure information is only valid for those tyre sizes and their respective load condition.

If the preceding tyre sizes are complemented by the [1] symbol, the tyre pressure information following shows alternative tyre pressures. Fuel consumption may then increase slightly.

The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of passengers and amounts of luggage. The actual number of seats may differ from this.

Tyre pressure monitoring system

Function of the tyre pressure monitoring system

The system checks the tyre pressure and the tyre temperature of the tyres fitted to the vehicle by means of a tyre pressure sensor.

The tyre pressure and the tyre temperature appear in the driver's display.

If there is a substantial pressure loss or if the tyre temperature is excessive, you will be warned with display messages (\rightarrow page 718) or the \bigcirc warning lamp in the driver's display (\rightarrow page 747).

The tyre pressure monitoring system is only an aid. It is the driver's responsibility to set the tyre pressure to the recommended cold tyre pressure suitable for the operating situation.

In most cases, the tyre pressure monitoring system will automatically update the new reference values after you have changed the tyre pressure. You can, however, also update the reference values by restarting the tyre pressure monitoring system manually (\rightarrow page 513).

System limits

The system may be impaired or may not function particularly in the following situations:

- · incorrect reference values were taught in
- sudden pressure loss caused by a foreign object penetrating the tyre, for example
- there is a malfunction caused by another radio signal source

■ Checking the tyre pressure with the tyre pressure monitoring system

Requirements

The vehicle is switched on.

Driver's display:

- Service
- Press **OK** to confirm.

One of the following displays appears:

• Current tyre pressure of each wheel:



- Tyre pressures will be displayed after a few minutes of driving: current values are not yet known to the system. The pressure/temperature values of each tyre are displayed as soon as they are known to the system.
- Tyre pressure monitor active: the teach-in process of the system is not yet complete. The tyre pressures are already being monitored.

- Compare the current tyre pressure with the recommended tyre pressure for the current operating condition (\rightarrow page 511). Additionally, observe the notes on cold tyres $(\rightarrow page 510)$.
- The values displayed in the driver's display may deviate from those of the tyre pressure gauge as they refer to sea level. At high elevations, the tyre pressure values indicated by a tyre pressure gauge are higher than those shown in the driver's display.

Restarting the tyre pressure monitoring system

Requirements:

 The recommended tyre pressure is correctly set for the respective operating status on each of the four wheels (\rightarrow page 510).

Restart the tyre pressure monitoring system in the following situations:

- The tyre pressure has changed.
- The wheels or tyres have been changed or newly fitted.

Driver's display:

- Service
- Select Tyre pressure and confirm with OK.
- Swipe downwards on Touch Control on the steering wheel.

The Use current tyre pressures as new reference values? message is shown in the driver's display.

Select Yes and confirm the restart with OK. The Tyre pressure monitor restarted message is shown in the driver's display.

Current warning messages are deleted and the yellow (!) warning lamp goes out.

After you have been driving for a few minutes, the system checks whether the current tyre pressures are within the specified range. The current tyre pressures are then accepted as reference values and monitored.

If the tyre pressure levels are not within the specified range, the Please correct tyre pressure message appears.

Tyre pressure loss warning system

■ Function of the tyre pressure loss warning system

The tyre pressure loss warning system warns the driver by means of display messages when there is a severe tyre pressure loss.

System limits

The system may be impaired or may not function particularly in the following situations:

- incorrect reference values were taught in
- sudden pressure loss caused by a foreign object penetrating the tyre, for example
- an even pressure loss on more than one tyre occurs

The system has a restricted or delayed function particularly in the following situations:

- poor ground conditions, e.g. snow or gravel
- · driving with snow chains
- when adopting a very sporty driving style with high cornering speeds or sudden acceleration
- driving with a very heavy or large trailer

driving with a high load

The tyre pressure loss warning system is only an aid. It is the driver's responsibility to set the tyre pressure to the recommended cold tyre pressure suitable for the operating situation and to check it.

Be sure to also observe the following further related subjects:

- Notes on tyre pressure (→ page 510)
- Display messages about the tyres (→ page 718)
- Restarting the tyre pressure loss warning system

Requirements:

 The recommended tyre pressure is correctly set for the respective operating condition on each of the four wheels (→ page 510).

Restart the tyre pressure loss warning system in the following situations:

- The tyre pressure has changed.
- The wheels or tyres have been changed or newly fitted.

Driver's display:

- ¬→ 🚡 >> Service
- Select Tyre pressure and confirm with OK. The Run Flat Indicator active message is shown in the driver's display.
- To initiate a restart, press OK on the steering wheel.

The Are the current pressure values OK? message is shown in the driver's display.

- Select Yes.
- To confirm restart, press OK on the steering wheel.

The Run Flat Indicator restarted message is shown in the driver's display.

Be sure to also observe the following further related subjects:

• Notes on tyre pressure (→ page 510)

Notes on selecting, fitting and replacing tyres

WARNING Risk of accident due to incorrect wheel and tyre dimensions

If wheels and tyres of the wrong size are fitted, the service brakes or components in the brake system and in the wheel suspension may be damaged.

Always replace wheels and tyres with those that fulfil the specifications of the original part.

For wheels, pay attention to the following:

- Designation
- Type

For tyres, pay attention to the following:

- Designation
- Manufacturer
- Type

WARNING Risk of injury through exceeding the specified tyre load-bearing capacity or the permissible speed rating

Exceeding the load-bearing capacity of the tyres can lead to tyre damage and could cause the tyres to explode.

- Therefore, only use tyre types and sizes approved for your vehicle model.
- Observe the tyre load-bearing capacity rating and speed rating required for your vehicle.
- **NOTE** Vehicle and tyre damage caused by non-approved tyre types and sizes

For safety reasons, only use tyres, wheels and accessories which have been specially approved by Mercedes-Benz for your vehicle.

These tyres are specially adapted to the active safety systems, such as ABS, ESP® and 4MATIC, and marked as follows:

MO = Mercedes-Benz Original

- MOE = Mercedes-Benz Original Extended (run-flat tyres only for certain wheels)
- MO1 = Mercedes-Benz Original (only certain AMG tyres)

Otherwise, certain properties, such as handling characteristics, vehicle noise emissions, consumption, etc. could be adversely affected. Furthermore, other tyre sizes could result in the tyres rubbing against the body and axle components when loaded. This could result in damage to the tyre or the vehicle.

Only use tyres, wheels and accessories that have been checked and recommended by Mercedes-Benz.

NOTE Risk to driving safety from retreaded tyres

Retreaded tyres are neither tested nor recommended by Mercedes-Benz, since previous damage cannot always be detected on retreaded tyres.

For this reason driving safety cannot be guaranteed.

- Do not use used tyres if you have no information about their previous usage.
- ! NOTE Possible wheel and tyre damage when driving over obstacles

Large wheels have a smaller section width. As the section width decreases, the risk of wheels and tyres being damaged when driving over obstacles increases.

- Avoid obstacles or drive especially carefully.
- Reduce your speed when driving over kerbs, speed bumps, manhole covers and potholes.
- Avoid particularly high kerbs.
- **!** NOTE Possible wheel and tyre damage when parking on kerbs or in potholes

Parking on kerbs or in potholes can damage the wheels and tyres.

- Only park on level surfaces if possible.
- Avoid kerbs and potholes when parking.

! NOTE Damage to electronic component parts due to the use of tyre-fitting tools

Vehicles with tyre pressure monitoring system: there are electronic component parts in the wheel.

If tyre-fitting tools are positioned in the area of the valve, the electronic components could be damaged.

- Tyre-fitting tools should not be applied in the area of the valve.
- Always have tyres changed at a qualified specialist workshop.
- NOTE Damage to summer tyres at low ambient temperatures

At low ambient temperatures, tears could form when driving with summer tyres, causing permanent damage to the tyre.

At temperatures below 7 °C use M+S tyres.

Accessory parts which are not approved for your vehicle by Mercedes-Benz, or which are not used correctly, can impair the operating safety.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and enquire about:

- Suitability
- Legal stipulations
- Factory recommendations

WARNING Risk of accident with high performance tyres

The special tyre tread in combination with the optimised tyre compound means that the risk of skidding and hydroplaning on wet roads is increased.

In addition, the tyre grip is greatly reduced at a low outside temperature and tyre running temperature.

Switch on the ESP® and adapt your driving style accordingly.

- Use A M+S tyres at outside temperatures of less than 10 °C.
- Only use the tyres for their intended purpose.

Observe the following when selecting, fitting and replacing tyres:

- Country-specific requirements for tyre approval that define a specific tyre type for vour vehicle.
- Furthermore, the use of certain tyre types in certain regions and areas of operation can be highly beneficial.
- Only use tyres and wheels of the same type (summer tyres, winter tyres, MOExtended tyres) and the same make.
- Only fit wheels of the same size on one axle (left and right).
 - It is only permissible to fit a different wheel size in the event of a flat tyre in order to drive to the specialist workshop.
- Do not make any modifications to the brake system, the wheels or the tyres.

The use of shims or brake dust shields is not permitted and may invalidate the vehicle's general operating permit.

- Vehicles with a tyre pressure monitoring system: all fitted wheels must be equipped with functioning sensors for the tyre pressure monitoring system.
- At temperatures below 7 °C use winter tyres or all-season tyres marked A M+S for all wheels.

Winter tyres provide the best possible grip in wintry road conditions.

- For M+S tyres, only use tyres with the same tread.
- Observe the maximum permissible speed for the M+S tyres fitted.
 - If the tyre's maximum speed is below that of the vehicle, this must be indicated by an appropriate label in the driver's field of vision.
- Run in new tyres at moderate speeds for the first 100 km.
- Replace the tyres after six years at the latest, regardless of wear.

- . When replacing with tyres that do not feature run-flat characteristics: vehicles with MOExtended tyres are not equipped with a TIREFIT kit at the factory. Equip the vehicle with a TIREFIT kit after replacing with tyres that do not feature run-flat characteristics, e.g. winter tyres.
- You can permanently limit the maximum speed for driving with winter tyres $(\rightarrow page 227)$.

For more information on wheels and tyres, contact a qualified specialist workshop.

Notes on interchanging wheels

WARNING Risk of injury through different wheel sizes

Interchanging the front and rear wheels can severely impair the driving characteristics.

The disk brakes or wheel suspension components may also be damaged.

Only interchange the front and rear wheels if the wheels and tyres have the same dimensions.

Interchanging the front and rear wheels if the wheels or tyres have different dimensions can render the general operating permit invalid. Observe the instructions and safety notes on "Changing a wheel" (\rightarrow page 515)

The wear patterns on the front and rear wheels differ:

- front wheels wear more on the tyre shoulder
- rear wheels wear more in the centre of the tyre

Do not drive with tyres that have too little tread depth. This significantly reduces traction on wet roads (aquaplaning).

On vehicles with the same front and rear wheel size, you can interchange the wheels every 5,000 to 10,000 km, depending on the wear. Ensure the direction of rotation is maintained for the wheels.

Notes on storing wheels

When storing wheels, observe the following notes:

- After removing wheels, store them in a cool, dry and preferably dark place.
- Protect the tyres from contact with oil, grease or fuel.

Overview of the tyre-change tool kit

Apart from some country-specific variants, vehicles are not equipped with a tyre-change tool kit. Consult a qualified specialist workshop to find out which wheel change tools are necessary and approved for changing the wheel on your vehicle.


You require the following tools, forexample, to change a wheel:

- Jack
- Chock
- Wheel wrench
- Centring pin
- i The jack weighs approximately 3.4 kg.

The maximum load capacity of the jack can be found on the sticker affixed to the jack. The jack is maintenance-free. If there is a malfunction, please contact a qualified specialist workshop.

The tyre-change tool kit is located in tool bag in the boot.

i When stowing the tool bag, make sure that it is adequately secured.



The tool bag contains:

- Jack
- Gloves
- · Wheel wrench

- Centring pin
- Folding chock
- Ratchet for iack

Preparing the vehicle for a wheel change

Requirements:

- The vehicle is not on a slope.
- The vehicle is on solid, non-slippery and level ground.
- The required tyre-change tool kit is available.
- (i) If your vehicle is not equipped with the tyrechange tool kit, consult a qualified specialist workshop to find out about suitable tools.
- Apply the electric parking brake manually.
- Move the front wheels to the straight-ahead position.
- Shift the transmission to position **P**.
- Vehicles with level control system: set the normal vehicle level (\rightarrow page 262).
- Switch off the vehicle.
- Make sure that the vehicle cannot be started.

- Place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.
- If necessary, remove the wheel trim/hub caps $(\rightarrow page 519)$.
- Raise the vehicle (\rightarrow page 520).

Removing and fitting the wheel trim/hub caps

Requirements

• The vehicle is prepared for a wheel change $(\rightarrow page 519)$.

Wheel trim

The wheel trim covers the wheel bolts on vehicles with aluminium wheels. Before unscrewing the wheel bolts, remove the wheel trim.



To remove: using both hands, carefully reach into two wheel trim openings and remove the wheel trim.


Plastic hub cap To remove:

Turn the centre cover of the hub cap anticlockwise and remove the hub cap.

To fit:

- Make sure that the centre cover of the hub cap is turned anti-clockwise.
- Position the hub cap and turn the centre cover clockwise until the hub cap engages physically and audibly.

Aluminium hub cap



To remove:

- Position socket 2 from the tyre-change tool kit on hub cap 1.
- Position wheel spanner 3 on socket 2.
- Using wheel spanner (3), turn hub cap (1) anti-clockwise and remove it.

To fit:

- Follow the instructions above in reverse order.
- Specified tightening torque: 25 Nm.


Raising the vehicle when changing a wheel

Requirements

- There are no persons in the vehicle.
- The vehicle has been prepared for a wheel change (\rightarrow page 519).
- The wheel trims and hub caps have been removed (\rightarrow page 519).

Important notes on using the jack:

- Use only a vehicle-specific jack that has been approved by Mercedes-Benz to raise the vehicle.
- The jack is only designed for raising and holding the vehicle for a short time while a wheel is being changed and not for maintenance work under the vehicle
- The jack must be placed on a firm, flat and non-slip surface. If necessary, use a large, flat, load-bearing, non-slip underlay.
- The foot of the jack must be positioned vertically under the jack support point.






Rules of conduct when the vehicle is raised:

- Never place your hands or feet under the vehi-
- Never lie under the vehicle

- Do not start the vehicle and do not release the electric parking brake.
- Do not open or close any doors or the boot lid.



Using the wheel wrench, loosen the wheel bolts on the wheel you wish to change by about one full turn. Do not unscrew the screws completely.



Position of the jack support points

WARNING Risk of injury from incorrect positioning of the jack


If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip with the vehicle raised.

Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically under the jacking point of the vehicle.

NOTE Damage to the vehicle due to the

If you do not position the jack at the jack support points provided for this purpose, you could damage your vehicle.

- Only position the jack at the jack support points provided for this purpose.
- Take the ratchet out of the tyre-change tool kit and place it on the hexagon nut of the jack so that the letters "AUF" are visible.



- Position support 2 of jack 4 on jack support point 1.
- Turn ratchet (3) clockwise until support (2) sits completely on jack support point 1 and the base of the jack lies evenly on the ground.
- Turn ratchet (3) until the tyre is raised a maximum of 3 cm from the ground.
- Loosen and remove the wheel (\rightarrow page 522).

Removing a wheel

Requirements:

• The vehicle is raised (\rightarrow page 520).

When changing a wheel, avoid applying any force to the brake discs, as this could impair the level of comfort when braking.

NOTE Damage to the wheels' plastic elements when changing a wheel

Plastic elements on wheels may be damaged when removing and repositioning the wheel.

- Do not raise the wheels by the plastic elements when removing and repositioning.
- **NOTE** Damage to threading from dirt on wheel bolts
- Do not place wheel bolts in sand or on a dirty surface.
- Unscrew the uppermost wheel bolt completely.



- Screw centring pin (1) into the thread instead of the wheel bolt.
- Unscrew the remaining wheel bolts completely.
- Remove the wheel.

Fitting a new wheel

Requirements

• The wheel to be changed is removed and the centring pin is screwed in (\rightarrow page 522).

WARNING Risk of accident from losing a wheel

Oiled or greased wheel bolts can cause the wheel bolts to come loose, as too can damaged wheel bolts or wheel hub threads.

- Never oil or grease the threads.
- In the event of damage to the threads, contact a qualified specialist workshop immediately.
- Have the damaged wheel bolts or damaged hub threads replaced.
- Do not continue driving.
- Observe the information on the choice of tyres $(\rightarrow \text{ page } 515)$.

For tyres with a specified direction of rotation, an arrow on the side wall of the tyre indicates the correct direction of rotation. Observe the direction of rotation when fitting.

NOTE Damage to the wheels' plastic elements when changing a wheel

Plastic elements on wheels may be damaged when removing and repositioning the wheel.

- Do not raise the wheels by the plastic elements when removing and repositioning.
- Slide the wheel to be mounted onto the centring pin and push it on.
- **WARNING** Risk of injury from tightening wheel bolts and nuts

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip.

- Only tighten wheel bolts or wheel nuts when the vehicle is on the ground.
- Be sure to observe the instructions and safety notes on "Changing a wheel" (→ page 515).
- ► For safety reasons, only use wheel bolts which have been approved by Mercedes-Benz and for the wheel in question.

- Tighten the wheel bolts evenly in a diagonal pattern in the order indicated until they are finger-tight.
- Unscrew and remove the centring pin.
- Tighten the last wheel bolt until it is fingertight.
- ▶ Lower the vehicle (\rightarrow page 523).

Lowering the vehicle after a wheel change

Requirements

- The new wheel has been fitted (\rightarrow page 522).
- NOTE Risk of vehicle jack becoming trapped by the AIRMATIC system

If the AIRMATIC system has released air when raising the vehicle, the jack can become trapped when the vehicle is lowered.

- Start the engine. This adapts the vehicle level.
- Remove the jack from under the vehicle.

To lower the vehicle: place the ratchet onto the hexagon nut of the jack so that the letters "AB" are visible and turn anti-clockwise.



- ➤ Tighten the wheel bolts evenly in a diagonal pattern in the order indicated ① to ⑤ with an initial maximum force of 80 Nm.
- ➤ Tighten the wheel bolts evenly in a diagonal pattern in the order indicated to with the specified tightening torque of 150 Nm.

A

WARNING Risk of accident due to incorrect tightening torque

The wheels could come loose if the wheel bolts or wheel nuts are not tightened to the prescribed torque.

- Ensure that the wheel bolts or wheel nuts are tightened to the prescribed tightening torque.
- ▶ If you are not sure, do not move the vehicle. Contact a qualified specialist workshop and have the tightening torque checked immediately.
- Check the tyre pressure of the newly fitted wheel and adjust it if necessary.
- i The following does not apply if the new wheel is an emergency spare wheel.
- Vehicles with a tyre pressure loss warning system: restart the tyre pressure loss warning system (→ page 514).
- Vehicles with a tyre pressure monitoring system: restart the tyre pressure monitoring system (→ page 513).

Emergency spare wheel

Notes on the emergency spare wheel



WARNING Risk of accident caused by incorrect wheel and tyre dimensions

The wheel or tyre size and the tyre type of the emergency spare wheel or spare wheel and the wheel to be replaced may differ. The emergency spare wheel or spare wheel can significantly impair driving characteristics of the vehicle.

To prevent hazardous situations:

- Drive carefully.
- Never fit more than one emergency spare wheel or spare wheel that differs in size.
- Only use an emergency spare wheel or spare wheel briefly.
- Do not deactivate ESP®.
- Have the emergency spare wheel or spare wheel of a different size replaced at the nearest qualified specialist work-

shop. The new wheel must have the correct dimensions.

Observe the following notes on fitting an emergency spare wheel:

- The maximum permissible speed with an emergency spare wheel fitted is 80 km/h.
- Do not fit the emergency spare wheel with snow chains.
- Replace the emergency spare wheel after six years at the latest, regardless of wear.
- Use the wheel bolts that are included with the emergency spare wheel.
- Check the tyre pressure of the emergency spare wheel fitted. Correct the pressure as necessary.
- i The specified tyre pressure is stated on the label of the emergency spare wheel.
- (i) Vehicles with a tyre pressure loss warning system: if an emergency spare wheel is fitted, the tyre pressure loss warning system cannot function reliably. Only restart the system

again when the emergency spare wheel has been replaced with a new wheel.

Vehicles with a tyre pressure monitoring system: if an emergency spare wheel is fitted, the tyre pressure monitoring system cannot function reliably. For a few minutes after an emergency spare wheel is fitted, the system may still display the tyre pressure of the removed wheel. Only restart the system again when the emergency spare wheel has been replaced with a new wheel.

Be sure to also observe the following further related subjects:

- Notes on tyre pressure (→ page 510)
- Tyre pressure table (→ page 511)
- Notes on fitting tyres (→ page 515)
- Fitting an emergency spare wheel (→ page 519)

Notes on technical data

The technical data was determined in accordance with EU Directives. The data stated only applies to vehicles with standard equipment. You can obtain further information from a Mercedes-Benz Service Centre.

Only for certain countries: you can find vehiclespecific vehicle data in the COC documents (CER-TIFICATE OF CONFORMITY). These documents are supplied when the vehicle is delivered.

On-board electronics

Notes on tampering with the engine electronics

! NOTE Premature wear through improper maintenance

Improper maintenance may cause vehicle components to wear more quickly and the vehicle's operating permit may be invalidated.

Always have work on the engine electronics and related components carried out at a qualified specialist workshop.

Two-way radios

Notes on fitting two-way radios

WARNING Risk of accident due to improper work on two-way radios

If two-way radios are manipulated or retrofitted incorrectly, the electromagnetic radiation from the two-way radios can interfere with the vehicle electronics and jeopardise the operating safety of the vehicle.

You should have all work on electrical and electronic components carried out at a qualified specialist workshop.

WARNING Risk of accident due to improper operation of two-way radios

If you use two-way radios in the vehicle improperly, their electromagnetic radiation can disrupt the vehicle's electronics. This is the case in the following situations, in particular:


- The two-way radio is not connected to an exterior aerial.
- The exterior aerial is fitted incorrectly or is not a low-reflection aerial.

This could jeopardise the operating safety of the vehicle.

- Have the low-reflection exterior aerial fitted at a qualified specialist workshop.
- When operating two-way radios in the vehicle, always connect them to the lowreflection exterior aerial.
- I NOTE Invalidation of the operating permit due to failure to comply with the instructions for installation and use

The operating permit may be invalidated if the instructions for installation and use of two-way radios are not observed.

- Only use approved frequency bands.
- Observe the maximum permissible output power in these frequency bands.
- Only use approved aerial positions.



Vehicles without panorama sliding sunroof

Rear roof area

On vehicles with a panorama sliding sunroof, fitting an aerial is not permitted.

Use Technical Specification ISO/TS 21609 (Road Vehicles – "EMC guidelines for installation of aftermarket radio frequency transmitting equip-

ment") when retrofitting two-way radios. Comply with the legal requirements for detachable parts. If your vehicle has fittings for two-way radio equipment, use the power supply and aerial connectors provided in the pre-installation. Observe the man-

ufacturer's supplements when fitting. Two-way radio transmission output

The maximum transmission output (PEAK) at the base of the aerial must not exceed the values in the following table.

Frequency band and maximum transmission output

Frequency band	Maximum transmis- sion output
2-m- frequency band 144 - 174 MHz	50 W
Terrestrial Trunked Radio (TETRA) 380 - 460 MHz	10 W

Frequency band	Maximum transmis- sion output
70-cm- frequency band 430 - 470 MHz	35 W
Two-way radio 2G	2 W
Two-way radio 3G/4G/5G	0.5 W

The following devices can be used in the vehicle without restrictions:

- two-way radios with a maximum transmission output of up to 100 mW
- two-way radios with transmitter frequencies in the 380 - 420 MHz frequency band and a maximum transmission output of up to 2 W (TETRA)
- mobile phones (2G/3G/4G/5G)

There are no restrictions when positioning the aerial on the outside of the vehicle for the following frequency bands:

- TFTRA
- 2G/3G/4G/5G

Notes on pyrotechnical vehicle components

Registration information on pyrotechnic actuators



Manufacturer information:

Autoliv NCS Pyrotechnie et Technologies, Rue de la Cartoucherie, 95470 Survilliers, France Registration number: 2806 - P1 - 004163

Model designation:

PSS-1, PSS-2, PSS-3, PSS-4, PSS-6, PSS-6 Gen.1, PSS-6 Gen.2

Regulatory radio information

Specific information on wireless applications in accordance with 2014/53/EU

Besides the typical frequencies for mobile communication cars by Mercedes-Benz make use of the following automotive radio applications.

Type of wireless applications and specifications in accordance with 2014/53/EU

Technology	Frequency range	Transmission output/magnetic field strength
Remote Keyless Entry	20 kHz (9-90 kHz)	≤ 72 dBµA/m at 10m
Wireless Power Transmission	105 kHz (90–119 kHz)	≤ 42 dBµA/m at 10m
Remote Keyless Entry	120 kHz (119–135 kHz)	≤ 42 dBµA/m at 10m

Technology	Frequency range	Transmission output/magnetic field strength
Carsharing Module	NFC: 13.553–13.567 MHz Bluetooth®: 2402–2480 MHz	NFC: ≤ 42 dBµA/m at 10 m Bluetooth®: ≤ +4 dBm (class 2)
Rear Seat Entertainment System	Bluetooth®: 2400-2483.5 MHz WLAN 2.4 GHZ: 2400-2483.5 MHz WLAN 5 GHz: 5150-5250 MHz 5725-5875 MHz	Bluetooth®: -0.8 dBm WLAN 2.4 GHZ: 14.5 dBm WLAN 5 GHz: 20.5 dBm 13.3 dBm
Two-way radio (Tel7 telephone control unit)	E-GSM (900 MHz) GSM (1800 MHz)	+33 dBm +30 dBm
	UMTS (Band I, III, VIII) LTE (Band 1, 3, 7, 8, 20, 28)	+24 dBm (+1/-3 dB) +23 dBm (±2 dB)

Technology	Frequency range		Transmission output/magnetic field strength	
	LTE (TDD B38, B40, B4	1, Class 3)	< +23 dBm (±1 dB)	
	GNSS (1559-1610 MH	z)	Receiving only	
Regulatory radio identifiers and specific notes	Overview of manufactur	ers	Manufacturer	Manufacturer informa-
The tables and sections contain the following reg-	Manufacturer			tion
 ulatory radio information: Manufacturer information Required regulatory radio identifiers listed by country/region: Manufacturer's specifications 	ADC	ADC Automotive Distance Control Systems GmbH, Peter-Dornier- Straße 10, 88131 Lin-	Continental Automotive Gentex	Continental Automotive GmbH, Siemensstraße 12, 93055 Regensburg, Germany Gentex Corporation,
 Model designations Radio equipment approval numbers Specific notes on radio-based vehicle compo- 	Bosch Robert Bosch GmbH, Daimlerstraße 6, 71229 Leonberg, Ger-	Gentex	600 North Centennial Street, Zeeland MI 49464, USA	
nents		Harman Becker	Harman Becker Auto-	
	Continental Antenna	Continental Advanced Antenna GmbH, Römerring 1, 31137		motive Systems GmbH, Becker-Goehr- ing-Strasse 18, 76307 Karlsbad, Germany

Antenna GmbH, Römerring 1, 31137 Hildesheim, Germany

Référence du Certificat de conformité

Manufacturer	Manufacturer informa- tion				Manufacturer	Model desig- nation
Veoneer	Veoneer Sweden AB, Wallentinsvägen 22, 44737 Vårgårda, Swe-		nologué par l'A du Certificat d		HELLA	DM4 (locking system)
WITTE-Velbert GmbH & Co. KG, Hoeferstr.					Hirschmann	920287A (locking system)
	3-15, 42551 Velbert, Germany	Regulatory radio	identification		Hirschmann	920287B
Algeria		Manufacturer Model designation	sig- Radio equip- ment approval		(locking sys- tem)	
				number	LEOPOLD	KK1 (locking
		Continental	RKE223GNS	71/H/ANF/	KOSTAL	system)
Agré	é par l'ANF	Antenna	(locking sys- tem)	2021	MARQUARDT	DC12A (lock- ing system)

CMKG1 (lock-

MARS Keyless

(locking sys-

tem)

ing system)

122/H/ANF/

122/H/ANF/

2021

2021

MARQUARDT

MARQUARDT

DC12B (lock-

DC12K (lock-

ing system)

ing system)

Continental

Automotive

Continental

Automotive

Radio equipment approval number 123/H/ANF/ 2021

106/H/ANF/ 2020

107/H/ANF/ 2020

172/H/ANF/ 2021

188/H/ANF/ 2021

189/H/ANF/

190/H/ANF/

2021

2021

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS5 (locking system)	195/H/ANF/ 2021
MARQUARDT	MK1 (locking system)	193/H/ANF/ 2021
MARQUARDT	MK2 (locking system)	194/H/ANF/ 2021
MARQUARDT	3350.38 (locking system)	186/H/ANF/ 2021
Schrader	AG5SP4 (tyre pressure sensor)	3681/1-73.0 A 1639/DT/DG /ARPT/15
Schrader	AG3PF4 (tyre pressure sensor)	652/1/DT/D G/ARPCE/ 2020

Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	BG3FP4 (tyre pressure sensor)	56/H/ANF/ 2021
Schrader	GG4T (tyre pressure sen- sor)	3994/1.69- DA/ 2098/DT/DG /ARPT/17
Schrader	DG6W2D4 (tyre pressure sensor)	2695/1- NO.431396/ DT/DG/ ARPT/17
Huf Baolong	TSSRE4A (tyre pressure sensor)	2695/1- NO.431396/ DT/DG/ ARPT/17
WITTE-Velbert	SDHTAG3NFC (locking system)	32/H/ANF/ 2021

Argentina

Regulatory radio identification

R!		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Antenna	RKE213E1 (aerial ampli- fier)	H-26206
Continental Antenna	RKE223E1 (aerial ampli- fier)	H-24637
Continental Automotive	CMKG1 (lock- ing system)	H-24376
Continental Automotive	MARS Keyless (locking system)	H-17929
Continental Automotive	D-WMI2020A (control unit)	H-23974

R!		
Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	H-17845
Hirschmann	920287A (locking system)	H-15694
Hirschmann	920287B (locking system)	H-15695
Huf Baolong	TSSRE4A (tyre pressure sensor)	H-20027
HUF	HUF14632 (locking system)	H-15541

R!		
Manufacturer	Model desig- nation	Radio equip- ment approval number
HUF	HUF4761 (locking system)	H-11545
LEOPOLD KOSTAL	KK1 (locking system)	H-16874
MARQUARDT	DC12A (lock- ing system)	H-17689
MARQUARDT	DC12B (lock- ing system)	H-21034
MARQUARDT	DC12K (lock- ing system)	H-21035
MARQUARDT	MS2 (locking system)	H-17598

R!		
Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS4 (locking system)	H-23101
MARQUARDT	MS5 (locking system)	H-24933
MARQUARDT	MK1 (locking system)	H-17213
MARQUARDT	MK2 (locking system)	H-17212
MARQUARDT	3350.38 (locking system)	H-23166
Schrader	AG5SP4 (tyre pressure sensor)	H-4788

Manufacturer Model desig-Radio equipnation ment approval number Schrader H-23292 AG3PF4 (tyre pressure sensor) Schrader BG3FP4 (tyre H-25586 pressure sensor) Schrader GG4T (tyre H-20495 pressure sensor) Schrader DG6W2D4 H-20959 (tyre pressure sensor) WITTE-Velbert SDHTAG3NFC H-24664 (locking sys-

tem)

Australia

Regulatory radio identification



Manufacturer	Model designation
ADC	ARS4-A (radar sensor)
ADC	ARS4-C (radar sensor)
Bosch	MRR1Rear (radar sensor)
Bosch	MRRe14FCR (radar sensor)
Bosch	FR5CPCCF (radar sensor)
Huf Baolong	TSSRE4A (tyre pressure sensor)
Schrader	AG5SP4 (tyre pressure sensor)



Manufacturer	Model designation
Schrader	AG3PF4 (tyre pressure sensor)
Schrader	BG3FP4 (tyre pressure sensor)
Schrader	GG4T (tyre pressure sensor)
Schrader	DG6W2D4 (tyre pressure sensor)
Veoneer	77V12BSM (radar sensor)
Veoneer	77V12CRN (radar sensor)

<u>&</u>			
Manufacturer	Model designation		
Veoneer	77V125CRN (radar sensor)		
Veoneer	MMRV1 (radar sensor)		

Bahamas

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
ADC	ARS4-A (radar sensor)	URCA_TA_20 14_082
ADC	ARS4-C (radar sensor)	URCA_TA_20 19_167
Bosch	MRR1Rear (radar sensor)	URCA_TA/ 2017_184

Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRRe14FCR (radar sensor)	URCA_TA/ 2017_157
Bosch	FR5CPCCF (radar sensor)	URCA_TA_20 19_195
Continental Automotive	CMKG1 (lock- ing system)	URCA_TA/ 2020_068
Continental Automotive	MARS Keyless (locking system)	URCA_TA/ 2017_119
Continental Antenna	RKE213E1 (aerial ampli- fier)	UCRA_TA/ 2016_009
Continental Antenna	RKE223E1GN S (aerial amplifier)	UCRA_TA/ 2020_032
HELLA	DM4 (locking system)	URCA_TA/ 2017_078

Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287A (locking system)	URCA_TA/ 2019_053
Hirschmann	920287B (locking system)	URCA_TA/ 2019_052
HUF	HUF4761 (locking system)	URCA_TA/ 2015_087
Huf Baolong	TSSRE4A (tyre pressure sensor)	URCA_TA/ 2017_094
LEOPOLD KOSTAL	KK1 (locking system)	URCA_TA/ 2015_081
MARQUARDT	DC12A (lock- ing system)	URCA_TA_20 17_042

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12B (lock- ing system)	URCA_TA_20 19_128
MARQUARDT	DC12K (lock- ing system)	URCA_TA_20 19_129
MARQUARDT	MS2 (locking system)	URCA_TA/ 2017_021
MARQUARDT	MS4 (locking system)	URCA_TA_20 19_141
MARQUARDT	MS5 (locking system)	URCA_TA_20 20_141
MARQUARDT	MK1 (locking system)	URCA_TA/ 2015_031
MARQUARDT	MK2 (locking system)	URCA_TA/ 2015_033

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	3350.38 (locking system)	URCA_TA/ 2019_250
Schrader	AG5SP4 (tyre pressure sensor)	URCA_TA_TA /2015_009
Schrader	AG3PF4 (tyre pressure sensor)	URCA_TA_20 19_101
Schrader	BG3FP4 (tyre pressure sensor)	URCA_TA_20 21_001
Schrader	GG4T (tyre pressure sensor)	URCA_TA_20 20_046
Schrader	DG6W2D4 (tyre pressure sensor)	URCA_TA_20 19_247

Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77V12BSM (radar sensor)	URCA_TA_20 19_169
Veoneer	77V12CRN (radar sensor)	URCA_TA_20 19_168
Veoneer	77V125CRN (radar sensor)	URCA_TA_20 21_027
Veoneer	MMRV1 (radar sensor)	URCA_TA/ 2015_063
WITTE-Velbert	SDHTAG3NFC (locking system)	URCA_TA_20 20_056

Belarus



Manufacturer	Model designation
ADC	ARS4-A (radar sensor)
ADC	ARS4-C (radar sensor)
Bosch	MRR1Rear (radar sensor)
Bosch	MRRe14FCR (radar sensor)
Bosch	FR5CPCCF (radar sensor)
Continental Antenna	RKE223E1 (aerial amplifier)
Continental Automotive	CMKG1 (locking system)



Manufacturer	Model designation
Continental Automotive	MARS Keyless (lock- ing system)
Harman Becker	HERMES 3.0 (communication module)
HELLA	DM4 (locking system)
MARQUARDT	DC12A (locking system)
MARQUARDT	DC12B (locking system)
MARQUARDT	DC12K (locking system)
MARQUARDT	MS2 (locking system)
MARQUARDT	MS4 (locking system)



Manufacturer	Model designation
MARQUARDT	MS5 (locking system)
MARQUARDT	MK1 (locking system)
MARQUARDT	MK2 (locking system)
Veoneer	77V12BSM (radar sensor)
Veoneer	77V12CRN (radar sensor)
Veoneer	77V125CRN (radar sensor)
Veoneer	MMRV1 (radar sensor)
WITTE-Velbert	SDHTAG3NFC (locking system)

Botswana

Manufacturer	Model desig- nation	Radio equip- ment approval number
ADC	ARS4-A (radar sensor)	BOCRA/TA/ 2018/2026
ADC	ARS4-C (radar sensor)	BOCRA/TA/ 2020/5186
Bosch	MRRe14FCR (radar sensor)	BOCRA/TA/ 2019/4674
Bosch	FR5CPCCF (radar sensor)	BOCRA/TA/ 2019/4975
Bosch	MRR1Rear (radar sensor)	BOCRA/TA/ 2017/3788
Continental Antenna	RKE213E1 (aerial ampli- fier)	BOCRA/TA/ 2019/4387

Manufacturer	Model desig- nation	Radio equip- ment approval number	Mai
Continental Antenna	RKE223E1GN S (aerial amplifier)	BOCRA/TA/ 2019/5050	HUI
Continental Automotive	CMKG1 (lock- ing system)	BOCRA/TA/ 2019/5075	LEC KOS
Continental Automotive	MARS Keyless (locking sys- tem)	BOCRA/TA/ 2019/4661	MA MA
HELLA	DM4 (locking system)	BOCRA/TA/ 2019/4662	
Hirschmann	920287A (locking system)	BOCRA/TA/ 2019/4724	MA
Hirschmann	920287B (locking system)	BOCRA/TA/ 2019/4723	MA

Manufacturer	Model desig- nation	Radio equip- ment approva number
HUF	HUF4761 (locking system)	BOCRA/TA/ 2019/4664
LEOPOLD KOSTAL	KK1 (locking system)	BOCRA/TA/ 2019/4593
MARQUARDT	DC12A (lock- ing system)	BOCRA/TA/ 2019/4389
MARQUARDT	DC12B (lock- ing system)	BOCRA/TA/ 2019/4388
MARQUARDT	DC12K (lock- ing system)	BOCRA/TA/ 2019/4390
MARQUARDT	MS2 (locking system)	BOCRA/TA/ 2019/5135
MARQUARDT	MS4 (locking system)	BOCRA/TA/ 2019/4758

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS5 (locking system)	BOCRA/TA/ 2020/5473
MARQUARDT	MK1 (locking system)	BOCRA/TA/ 2019/4359
MARQUARDT	MK2 (locking system)	BOCRA/TA/ 2019/4360
MARQUARDT	3350.38 (locking system)	BOCRA/TA/ 2019/4687
Veoneer	77V12BSM (radar sensor)	BOCRA/TA/ 2019/4975
Veoneer	77V12CRN (radar sensor)	BOCRA/TA/ 2019/4980

Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77V125CRN (radar sensor)	BOCRA/TA/ 2021/6191
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	BOCRA/TA/ 2020/5342

Brazil Note on two-way radio systems in the vehicle:

These systems are not protected against harmful interference and must not cause interference in properly approved systems.

Regulatory radio identification			
• AMATEE			
Manufacturer	Model desig- nation	Radio equip- ment approval number	
Continental Antenna	RKE213E1 (aerial ampli- fier)	07359-21-12 817	
Continental Antenna	RKE213E1 (aerial ampli- fier)	3691-15-529 8	
Continental Automotive	CMKG1 (lock- ing system)	00325-20-02 149	
Continental Automotive	MARS Keyless (locking sys- tem)	03189-1 <i>7</i> -02 856	
HELLA	DM4 (locking system)	04689-1 <i>7</i> -05 364	

ANATEC

Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287A (locking system)	1855-12-576 2
Hirschmann	920287B (locking system)	1787-12-805 8
HUF	HUF14632 (locking system)	03627-15-06 643
HUF	HUF4761 (locking system)	00053-13-06 643
MARQUARDT	DC12A (lock- ing system)	01333-17-02 930



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12B (lock- ing system)	01395-11-02 930
MARQUARDT	DC12K (lock- ing system)	01392-11-02 930
MARQUARDT	MS2 (locking system)	00616-17-02 930
MARQUARDT	MS4 (locking system)	06218-19-02 930
MARQUARDT	MS5 (locking system)	11149-20-02 930
MARQUARDT	3350.38 (locking system)	03149-19-02 930



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK1 (locking system)	03756-15-02 930
MARQUARDT	MK2 (locking system)	03757-15-02 930
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	03034-20-07 018


Further specific information Rear Seat Entertainment System:

This system is not protected against harmful interference and must not cause interference in properly approved systems.


This product is approved by ANATEL in accordance with the procedures set out in Resolution

242/2000 and complies with the relevant technical requirements. Further information can be found on the https://www.anatel.gov.br

Brunei Darussalam



À¥AITI		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRRe14FCR (radar sensor)	DTA-006678
Continental Antenna	RKE213E1 (aerial ampli- fier)	DTA-006665
Continental Antenna	RKE223E1GN S (aerial amplifier)	DTA-004998
Continental Automotive	CMKG1 (lock- ing system)	DTA-005043
Continental Automotive	MARS Keyless (locking sys- tem)	LPD-39004





Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSSG4G6b (tyre pressure monitoring system con- trol unit)	DTA-003757
HUF	HUF14632 (locking system)	DTA-006138
HUF	HUF4761 (locking system)	DTA-000615
LEOPOLD KOSTAL	KK1 (locking system)	DTA-007245




Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12A (lock- ing system)	LPD-38937
MARQUARDT	DC12B (lock- ing system)	DTA-000068
MARQUARDT	DC12K (lock- ing system)	DTA-000066
MARQUARDT	MS2 (locking system)	LPD-38890
MARQUARDT	MS4 (locking system)	DTA-003525
MARQUARDT	MS5 (locking system)	DTA-005850




Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK1 (locking system)	DTA-011312
MARQUARDT	MK2 (locking system)	DTA-011313
MARQUARDT	3350.38 (locking system)	DTA-003662
Schrader	AG5SP4 (tyre pressure sensor)	LPD-29665
Schrader	AG3PF4 (tyre pressure sensor)	LPD-29665



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	BG3FP4 (tyre pressure sensor)	DRQ-D- JATI-07-2000- 109000
Schrader	DG6W2D4 (tyre pressure sensor)	DTA-001514
Schrader	MFR (tyre pressure monitoring system control unit)	DTA No. 003893






Eurasian Economic Union

ERE	H
Manufacturer	Model designation
ADC	ARS4-A (radar sensor)
ADC	ARS4-C (radar sensor)
Bosch	FR5CPCCF (radar sensor)
Bosch	LRR3 (radar sensor)
Bosch	MRR1Rear (radar sensor)
Bosch	MRRe14FCR (radar sensor)
Continental Antenna	RKE213E1 (aerial amplifier)

ERE	
Manufacturer	Model designation
Continental Antenna	RKE223E1GNS (aerial amplifier)
Continental Automotive	MARS Keyless (lock- ing system)
HELLA	DM4 (locking system)
Hirschmann	920287A (locking system)
Hirschmann	920287B (locking system)
Huf Baolong	TSSRE4A (tyre pressure sensor)
HUF	HUF4761 (locking system)

ERE	H
Manufacturer	Model designation
HUF	HUF14632 (locking system)
LEOPOLD KOSTAL	KK1 (locking system)
MARQUARDT	DC12A (locking system)
MARQUARDT	DC12B (locking system)
MARQUARDT	DC12K (locking system)
MARQUARDT	MS2 (locking system)
MARQUARDT	MS4 (locking system)
MARQUARDT	MS5 (locking system)
MARQUARDT	MK1 (locking system)



ERC	
Manufacturer	Model designation
Veoneer	77GHz MMRV1 (radar sensor)
Veoneer	77V12BSM (radar sensor)
Veoneer	77V12CRN (radar sensor)
Veoneer	77V125CRN (radar sensor)
WITTE-Velbert	SDHTAG3NFC (locking system)

Ghana

Manufacturer	Model desig- nation	Radio equip- ment approval number		
		NCA APPROVED		
ADC	ARS4-C (radar sensor)	ZRO-1H-7E3- 152		
Bosch	FR5CPCCF (radar sensor)	ZRO- M8-7E3-230		
Continental Antenna	RKE213E1 (aerial ampli- fier)	ZRO-M8-7E3- X53		
Continental Antenna	RKE223E1GN S (aerial amplifier)	ZRO- M8-7E3-225		
Continental Automotive	CMKG1 (lock- ing system)	ZRO- M8-7E3-277		

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	MARS Keyless (locking system)	BR3-1M- GE2-16A
HELLA	DM4 (locking system)	BR3-1M- GE2-157
Hirschmann	920287A (locking system)	ZRO-M8-7E3- X45
Hirschmann	920287B (locking system)	ZRO-M8-7E3- X47
HUF	HUF4761 (locking system)	EX6-6M- GE2-16C
LEOPOLD KOSTAL	KK1 (locking system)	ZRO-M8-7E3- X49

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12A (lock- ing system)	ZRO-M8-7E3- X50
MARQUARDT	DC12B (lock- ing system)	ZRO-M8-7E3- X51
MARQUARDT	DC12K (lock- ing system)	ZRO-M8-7E3- X52
MARQUARDT	MS2 (locking system)	BR3-1M- GE-129
MARQUARDT	MS4 (locking system)	ZRO-1H-7E3- 26E
MARQUARDT	MS5 (locking system)	SRO-1M-7E4- 11B
MARQUARDT	MK1 (locking system)	ZRO-M8-7E3- X4A
MARQUARDT	MK2 (locking system)	ZRO-M8-7E3- X4C

Manufacturer	Model desig- nation	Radio equip- ment approval number		
MARQUARDT	3350.38 (locking system)	ZRO-M8-7E3- X3C		
Veoneer	77V12BSM (radar sensor)	ZRO-1H-7E3- 142		
Veoneer	77V12CRN (radar sensor)	ZRO- M8-7E3-230		
Veoneer	77V125CRN (radar sensor)	7E5-7M-X72- RDR		
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	SRO-1M-7E4- X59		

Indonesia Regulatory radio Manufacturer	Regulatory radio identification		Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Manufacturei	nation ment numb	Radio equip- ment approval number	Bosch	LRR3 (radar sensor)	74264/ SDPPI/2021	Bosch	MRRevo14F (radar sensor)	74265/ SDPPI/2021
ADC	ARS4-C (radar sensor)	68676/ SDPPI/2020 7163			7163			7163
ADC	ARS4-A (radar sensor)	70266/ SDPPI/2020 7163	Bosch	MRR1Rear (radar sensor)	74267/ SDPPI/2021 7163	Bosch	MRRe14FCR (radar sensor)	74266/ SDPPI/2021 7163

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacture	nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	57882/SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya				Continental Antenna	RKE213E1 (aerial amplifier)	76621/ SDPPI/2021 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			Continental Antenna	RKE223E1GN S (aerial amplifier)	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	CMKG1 (lock-ing system)	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya				Continental Automotive	MARS Keyless (locking system)	69379/ SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			Continental Automotive	D-WMI2020A (Steuergerät)	66678/ SDPPI/2020 7163			
					Dilarang mel- akukan peru- bahan spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromag- netik terha- dap lingkun- gan sekitar- nya			

ition	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
		Continental Automotive	NTG7 PRE- MIUM (Headunit)	70731/ SDPPI/2020 7163			
				Dilarang mel- akukan peru- bahan spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromag- netik terha- dap lingkun- gan sekitar- nya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	NTG7 PRE- MIUM PLUS (Headunit)	70734/ SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya				Harman Becker	NTG6N ENTRY/MID (Headunit) Production: Germany	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			Harman Becker	NTG6N HIGH (Headunit) Production: Germany	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			Harman Becker	NTG7 MID (Headunit)	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Harman Becker	NTG7 HIGH (Headunit)	70513/ SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya				Harman Becker	NTG7 PRE- MIUM (Headunit)	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			Harman Becker	NTG7 PRE- MIUM PLUS (Headunit)	70512/ SDPPI/2020 7163 Dilarang mel- akukan peru- bahan spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromag- netik terha- dap lingkun- gan sekitar- nya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Harman Becker	NTG7 RSU (control unit)	Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya				HELLA	DM4 (locking system)	69378/ SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			Hirschmann	920287A (locking system)	71369 / SDPPI/2020 7163			
Huf Baolong	TSSRE4A (tyre pressure sensor)	72438/ SDPPI/2021 7163			Dilarang mel- akukan peru- bahan spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromag- netik terha- dap lingkun- gan sekitar- nya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287B (locking system)	72974 / SDPPI/2021 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya				HUF	HUF14632 (locking system)	78368/ SDPPI/2021 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			HUF	HUF4761 (locking system)	26742/ SDPPI/2015 3533 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya	LEOPOLD KOSTAL	KK1 (locking system)	41121/ SDPPI/2018 5125

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			MARQUARDT	DC12K (locking system)	80621/SDPPI/2022 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS2 (locking system)	57372/ SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya				MARQUARDT	MS4 (locking system)	o4126/ SDPPI/2019 7163 Dilarang mel- akukan peru- bahan spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromag- netik terha- dap lingkun- gan sekitar- nya

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model designation	Radio equip- ment approval number
		number	MARQUARDT	MS5 (locking system)	number 69077/ SDPPI/2020 7163 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau			number
					elektromag- netik terha- dap lingkun- gan sekitar- nya			

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
			MARQUARDT	3350.38 (locking system)	62233/ SDPPI/2019 7163 Dilarang mel- akukan peru- bahan spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromag- netik terha- dap lingkun- gan sekitar- nya			

574 Technical data

number		nation	ment approval number		nation	ment approval number
	Molex	WCH-302e (Steuergerät)	71669/ SDPPI/2020 7163			
			Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya			
		Molex	4392 (E.S.	Osteuergerät) SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitar-	(Steuergerät) Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitar-	SDPPI/2020 7163 Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitar-

576 Technical data

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG3PF4 (tyre pressure sensor)	ssure sen- SDPPI/2020	Veoneer	77GHz MMRV1 (radar sensor)	74749/ SDPPI/2021 7163	Veoneer	77V125CRN (radar sensor)	78366/ SDPPI/2021 7163
			Veoneer	77V12CRN (radar sensor)	66830/ SDPPI/2020 7163			
Schrader	GG4T (tyre pressure sensor)	72023/ SDPPI/2020 7163						

Manufacture	Madal dask	Dadia assis	
Manufacturer	Model desig- nation	Radio equip- ment approval number	N
Veoneer	77V12BSM (radar sensor)	66792/ SDPPI/2020 7163	W

Manufacturer	Model desig- nation	Radio equip- ment approval number
WITTE-Velbert	SDHTAG3NFC (locking system)	67233/ SDPPI/2020 10325
		Dilarang mel- akukan peru- bahan spesifi- kasi yang dapat menim- bulkan gang- guan fisik dan/atau elektromag- netik terha- dap lingkun- gan sekitar- nya

Manufacturer	Model desig- nation	Radio equip- ment approval number

Israel

Manufacturer	Model desig- nation	Radio equip- ment approval number
		Approval number of the Ministry of Communica- tions:
ADC	ARS4-A (radar sensor)	55-09697

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equi ment appr number
ADC	ARS4-C (radar sensor)	55-07525	Continental Automotive	D-WMI2020A (Steuergerät)	55-08179	Schrader	BG3FP4 (tyre pressure sen-	51-77898
Bosch	FR5CPCCF (radar sensor)	55-08783	Huf Baolong Huf Baolong	TSSRE4A (tyre pressure	63-63571	Schrader	DG6W2D4 (tyre pressure sensor)	51-64111
Bosch	LRR3 (radar sensor)	55-08334		sensor) TSSSG4G6b	63-66757			
Bosch	MRR1Rear (radar sensor)	55-08333		Hul Baolong (tyre pressure monitoring system control unit) Schrader AG3PF4 (tyre pressure sensor)	03-00/3/	Schrader	GG4T (tyre pressure sensor)	55-09441
Bosch	MRRe14FCR (radar sensor)	55-08395				Schrader	MC34MA4 (tyre pressure monitoring system con- trol unit)	51-29611
Continental Automotive	D-WMI2017B (Steuergerät)	51-75654	Schrader		51-78338			
Continental Automotive	D-WMI2017A (Steuergerät)	51-75367	Schrader AG5SP4 (tyre pressure sensor)	51-73152	Schrader	MFR (tyre pressure	55-06040	
Continental Automotive	D-WMI2016A (Steuergerät)	55-08177		,			monitoring system con- trol unit)	55-06040

	Manufacturer	Model desig- nation	Radio equip- ment approval number
	Schrader	MFR3 (tyre pressure monitoring system con- trol unit)	51-79817
	Veoneer	77V12BSM (radar sensor)	55-08176
	Veoneer	77V12CRN (radar sensor)	55-08301

Jamaica


Regulatory radio identification

Manufacturer	Model designation	
Continental Automotive	CMKG1 (locking system)	
HELLA	DM4 (locking system)	

Manufacturer	Model designation
MARQUARDT	DC12A (locking system)
MARQUARDT	DC12B (locking system)
MARQUARDT	DC12K (locking system)
MARQUARDT	MS2 (locking system)
MARQUARDT	MS4 (locking system)
MARQUARDT	MS5 (locking system)
MARQUARDT	MK1 (locking system)
MARQUARDT	MK2 (locking system)
MARQUARDT	3350.38 (locking system)
WITTE-Velbert	SDHTAG3NFC (locking system)

Japan

Regulatory radio identification



Transmitter)

Canada

Regulatory radio identification


Manufacturer	Model desig- nation	Radio equip- ment approval number
Sennheiser	M3IETW2R (Earbud)	IC:2099A- M3IETW2R
Sennheiser	M3IETW2L (Earbud)	IC:2099A- M3IETW2L
Sennheiser	BTT100 (Blue- tooth Audio Transmitter)	IC:2099A- BTT100
Sennheiser	M3IETW2 C (Charging Case)	CAN ICS-3(B)/ NMB-3(B)

Kuwait

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Sennheiser	M3IETW2 (Momentum True Wireles 2)	Ref. 4870
Sennheiser	BTT100 (Blue- tooth Audio Transmitter)	Ref. 4871

Malaysia





	Manufacturer	Model desig- nation	Radio equip- ment approval number
	Bosch	MRRevo14F (radar sensor)	CIDF1500049 0
	Continental Antenna	RKE213E1 (aerial ampli- fier)	RAUU/28C/ 0915/ S(15-2703)
	Continental Antenna	RKE223E1GN S (aerial amplifier)	RDDK/34B/ 1219/ S(19-5319)
	Continental Automotive	CMKG1 (lock- ing system)	RFCP/13A/ 0220/ S(20-0197)
	Continental Automotive	MARS Keyless (locking sys- tem)	CIDF1500057 8




Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	D-WMI2020A (control unit)	RGEZ/12A/ 1019/ S(19-4128)
HELLA	DM4 (locking system)	CIDF1500057
Hirschmann	920287A (locking system)	RAUU/63A/ 0311/ S(11-0432)
Hirschmann	920287B (locking system)	RAUU/22C/ 0615/ S(15-1864)
Huf Baolong	TSSRE4A (tyre pressure sensor)	CIDF1700018 4



Manufacturer	Model desig- nation	Radio equip- ment approval number
HUF	HUF14632 (locking system)	RAYN/25A/ 0715/ S(15-2385)
HUF	HUF4761 (locking system)	RAAU/16B/ 1112/ S(12-2053)
LEOPOLD KOSTAL	KK1 (locking system)	RAUU/27C/ 0815/ S(15-2953)
MARQUARDT	DC12A (lock- ing system)	RDDK/33A/ 0317/ S(17-0669)







MILNIL.		
Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS5 (locking system)	RGLO/02A/ 0720/ S(20-2580)
MARQUARDT	MK1 (locking system)	RAAU/14C/ 0615/ S(15-1057)
MARQUARDT	MK2 (locking system)	RAAU/12C/ 0515/ S(15-1059)
MARQUARDT	3350.38 (locking system)	RDDK/17B/ 0819/ S(19-1082)



Manufacturer	Model desig- nation	Radio equip- ment approval number
Meta System	ITS/TPS (interior protection)	RAVG/18Q/ 0212/ S(11-2068)
Meta System	MUW II (interior protection)	RAVG/17Q/ 0212/ S(11-2067)
Schrader	AG5SP4 (tyre pressure sensor)	RCDD/03A/ 0615/ S(19-2094)
Schrader	AG3PF4 (tyre pressure sensor)	RBEF/28A/ 0419/S/ (19-1542)



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	BG3FP4 (tyre pressure sensor)	RBEF/51A/ 0121/S/ (20-5642)
Schrader	MFR (tyre pressure monitoring system con- trol unit)	RAQP/62A/ 0419/ S(19-1694)
Schrader	MFR3 (tyre pressure monitoring system con- trol unit)	RAQP/62A/ 0419/ S(19-1694)



Manufacturer	Model designation	Radio equip- ment approval number
Veoneer	77GHz MMRV1 (radar sensor)	HIDF1500015
Veoneer	77V12BSM (radar sensor)	HIDF1500015
Veoneer	77V12CRN (radar sensor)	HIDF1500015
Veoneer	77V125CRN (radar sensor)	HIDF1500015
WITTE-Velbert	SDHTAG3NFC (locking system)	RDDK/43B/ 0420/ S(20-1749)

Morocco

Manufacturer	Model desig- nation	Radio equip- ment approval number
		AGREE PAR L'ANRT MAROC
ADC	ARS4-A (radar sensor)	MR 9490 ANTR 2014-07-23
ADC	ARS4-C (radar sensor)	MR 20231 ANRT 2019-06-27
Bosch	FR5CPCCF (radar sensor)	MR 20575 ANRT 2019-07-29
Bosch	LRR3 (radar sensor)	MR 5371 ANRT 2010 2019-12-05

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number		
Bosch	MRR1Rear (radar sensor)	MR 9186 ANTR 2014-04-22	HELLA	DM4 (locking system)	MR 14426 ANTR 2017-07-28	HUF	HUF14632 (locking system)	MR 10506 ANTR 2015-06-22		
Bosch	MRRe14FCR (radar sensor)	MR 13900 ANTR 2017-05-04	Hirschmann	920287A (locking system)	MR 6700 ANTR 2011-11-16	HUF	HUF4761 (locking system)	MR 7829 ANTR 2013-02-14		
Continental Antenna	RKE213E1 (aerial ampli- fier)	MR 10631 ANTR 2015-07-16	Hirschmann	920287B (locking system)	MR 7260 ANTR 2012-06-13	LEOPOLD KOSTAL	KK1 (locking system)	MR 10697 ANTR 2015-08-05		
Continental Antenna	RKE223E1GN S (aerial amplifier)	MR 21174 ANTR 2019-10-14	Huf Baolong	(tyl	Huf Baolong	TSSRE4A (tyre pressure monitoring	MR 14320 ANTR 2017-07-07	MARQUARDT	DC12A (lock- ing system)	MR 13429 ANTR 2017-03-03
Continental Automotive	CMKG1 (lock- ing system)	MR 21701 ANTR 2019-12-05	Huf Baolong	system control unit) TSSSG4G6b	MR 19561	MARQUARDT	DC12B (lock- ing system)	MR 6698 ANTR 2021-11-04		
Continental Automotive	MARS Keyless (locking sys- tem)	MR 13681 ANTR 2017-04-04		(tyre pressure monitoring system con- trol unit)	ANTR 2019-04-26	MARQUARDT	DC12K (lock- ing system)	MR 6699 ANTR 2021-11-04		

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	
MARQUARDT	MS2 (locking system)	MR 13300 ANTR 2017-02-15	Schrader	AG5SP4 (tyre pressure monitoring	MR 10216 ANRT 2015	Schrader	MFR3 (tyre pressure monitoring	MR 19527 ANRT 2019	
MARQUARDT	MS4 (locking system)	MR 19199 ANTR		system con- trol unit)			system con- trol unit)		
	System	2019-03-25 MR 23805 ANRT	Schrader	AG3PF4 (tyre	MR 19241	Schrader	GG4T (tyre	MR 14777	
MARQUARDT	MS5 (locking system)			pressure sen- sor)	ANRT 2019		pressure sen- sor)	ANRT 2017-09-20	
	Systemy		Schrader	BG3FP4 (tyre	MR00026829	Schrader	DG6W2D4	MR 16355	
MARQUARDT	MK1 (locking system)			pressure sen- sor)	ANRT2020		(tyre pressure sensor)	ANRT 2018-04-19	
	System	2015-07-21	Schrader	MFR (tyre	MR 19527		Schrader	MC34MA4	MR 6706
MARQUARDT	MK2 (locking system)	MR 10987 ANTR 2015-10-22		pressure monitoring system con- trol unit)	monitoring system con-	ANRT 2019-04-30		(tyre pressure monitoring system con- trol unit)	ANRT 2011-11-17
MARQUARDT	3350.38 (locking system)	MR 18817 ANTR 2019-02-12				Veoneer	77GHz MMRV1 (radar sensor)	MR 10436 ANRT 2015-05-25	

Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77V12BSM (radar sensor)	MR 20097 ANRT 2019-06-14
Veoneer	77V12CRN (radar sensor)	MR 20149 ANRT 2019-06-19
Veoneer	77V125CRN (radar sensor)	MR 27966 ANRT 2021-03-29
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	MR 23310 ANRT 2020-03-10

Mexico

NOM	NYCE	ANCE
Manufacturer	Model desig- nation	Radio equip- ment approval number
ADC	ARS4-A (radar sensor)	IFETEL: RCPCOAR14- 1191
ADC	ARS4-C (radar sensor)	IFETEL: RLVCOR19-1 062
Bosch	LRR3 (radar sensor)	IFETEL: RCPBOLR09- 0828
Bosch	MRR1Rear (radar sensor)	IFETEL: RCPBOMR14- 0922


NOM	NYCE	ANCE
Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRRe14FCR (radar sensor)	IFETEL: RCPBOMR17- 0598
Continental Antenna	RKE213E1 (aerial ampli- fier)	IFETEL: RLVKARK15-1 741
Continental Antenna	RKE223E1 (aerial ampli- fier)	IFETEL: RLVCORK19- 2174
Continental Automotive	CMKG1 (lock- ing system)	IFETEL: RCPCOCM19- 2315

















Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287B (locking system)	IFETEL: RLVHI9212-0 608
Huf Baolong	TSSRE4A (tyre pressure sensor)	IFETEL: RLVHUTS17-0 806
HUF	HUF14632 (locking system)	IFETEL: RLVHUHU15- 1204
HUF	HUF4761 (locking sys- tem)	IFETEL: RLVHUHU12- 1587







MUM	NYCE	
Manufacturer	Model desig- nation	Radio equip- ment approval number
LEOPOLD KOSTAL	KK1 (locking system)	IFETEL: RLVKOKK15-0 891
MARQUARDT	DC12A (lock- ing system)	IFETEL: RLVMEDC17- 0348
MARQUARDT	DC12B (lock- ing system)	IFETEL: RLVMADC11- 0446
MARQUARDT	DC12K (interior protection)	IFETEL: RLVMADC11- 0446



















	NYCE	
Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS2 (locking system)	IFETEL: RLVMAMS17- 0222
MARQUARDT	MS4 (locking system)	IFETEL: RLVMAMS19- 0449
MARQUARDT	MS5 (locking system)	IFETEL: RLVMEMS20- 0957
MARQUARDT	MK1 (locking system)	IFETEL: RLVMAMK15- 1042

NUM	NYCE	*
Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK2 (locking system)	IFETEL: RLVMAMK15- 1043
MARQUARDT	3350.38 (locking system)	IFETEL: RCPMA3319- 0530
Schrader	AG5SP4 (tyre pressure sensor)	IFETEL: RCPSCAG15- 0627
Schrader	AG3PF4 (tyre pressure sensor)	IFETEL: RLVSCAG19-0 705

Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	BG3FP4 (tyre pressure sensor)	IFETEL: RLVSCBG21-0 750
Schrader	MFR (tyre pressure sensor)	IFETEL: RLVSCMF15- 0959
Schrader	MFR3 (tyre pressure sensor)	IFETEL: RLVSCMF19- 0777
Schrader	GG4T (tyre pressure sensor)	IFETEL: RLVSCGG17- 1665















Manufacturer	Model desig- nation	Radio equip- ment approval number
Sennheiser	BTT100 (Blue- tooth Audio Transmitter)	IFETEL: RCPSEBT18-1 407
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	IFETEL: RCPWISD20- 0943

Mongolia


Regulatory radio identifiers



Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	CMKG1 (lock- ing system)	A19000633
Continental Automotive	MARS Keyless (locking system)	A18000328
HELLA	DM4 (locking system)	A18000329
MARQUARDT	DC12A (lock- ing system)	A19000400
MARQUARDT	DC12B (lock- ing system)	A19000371



Manufacturer	Model designation	Radio equip- ment approval number
MARQUARDT	DC12K (lock- ing system)	A19000372
MARQUARDT	MS2 (locking system)	A18000289
MARQUARDT	MS4 (locking system)	A19000516
MARQUARDT	MS5 (locking system)	A20000085
MARQUARDT	MK1 (locking system)	A19000374



Niger

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Antenna	RKE213E1 (aerial ampli- fier)	029/ ARCEP/DG/1 9
Continental Automotive	MARS Keyless (locking sys- tem)	083/ ARCEP/DG/1 9
HELLA	DM4 (locking system)	082/ ARCEP/DG/1 9
Hirschmann	920287A (locking system)	097/ ARCEP/DG/1 9
Hirschmann	920287B (locking system)	098/ ARCEP/DG/1 9

Manufacturer	Model desig- nation	Radio equip- ment approval number
HUF	HUF4761 (locking sys- tem)	053/ ARCEP/DG/1 9
KATHREIN	RKE223E1 (locking system)	029/ ARCEP/DG/1 9
LEOPOLD KOSTAL	KK1 (locking system)	037/ ARCEP/DG/1 9
MARQUARDT	DC12A (lock- ing system)	010/ ARCEP/DG/1 9
MARQUARDT	DC12B (lock- ing system)	008/ ARCEP/DG/1 9
MARQUARDT	DC12K (lock- ing system)	009/ ARCEP/DG/1 9

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS2 (locking system)	014/ ARCEP/DG/1 9
MARQUARDT	MS4 (locking system)	HOMO-0096/ ARCEP/DG/ 2019
MARQUARDT	MK1 (locking system)	034/ ARCEP/DG/1 9
MARQUARDT	MK2 (locking system)	035/ ARCEP/DG/1 9
MARQUARDT	3350.38 (locking system)	015/ ARCEP/DG/1 9
MARQUARDT	MU1 (locking system)	HOMO-0095/ ARCEP/DG/ 2019

Nigeria

Manufacturer	Model designation
ADC	ARS4-A (radar sensor)
ADC	ARS4-C (radar sensor)
Bosch	FR5CPCCF (radar sensor)
Bosch	MRR1Rear (radar sensor)
Bosch	MRRe14FCR (radar sensor)
Continental Antenna	RKE213E1 (aerial amplifier)
Continental Antenna	RKE223E1GNS (aerial amplifier)
Continental Automotive	CMKG1 (locking system)

Manufacturer	Model designation	Manufacturer	Model designation	Manufacturer	Model	designation
Continental Automotive	MARS Keyless (lock- ing system)	MARQUARDT	DC12K (locking system)	Veoneer	77V12 sor)	CRN (radar sen-
HELLA	DM4 (locking system)	MARQUARDT	MS2 (locking system)	Veoneer		5CRN (radar
Hirschmann	920287A (locking sys-	MARQUARDT	MS4 (locking system)	\\(\dagger_{\text{\tint{\text{\tin}\text{\tin}\text{\tin}}\tint{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\texi}\tint{\text{\text{\texit{\ti}\tint{\text{\text{\tin}}\tint{\tint{\tiint{\text{\tin}\ti	sensor	,
	tem)	MARQUARDT	MS5 (locking system)	WITTE-Velbert	SDHIA	AG3NFC (locking
Hirschmann	920287B (locking system)	MARQUARDT	MK1 (locking system)	Oman		,
HUF	HUF14632 (locking	MARQUARDT	MK2 (locking system)	Regulatory radio	identification	
	system)	MARQUARDT	3350.38 (locking sys-	Manufacturer	Model desig-	Radio equip-
HUF	HUF4761 (locking sys-	tem)	na	nation	ment approval number	
	tem)	Schrader	AG3PF4 (tyre pressure			
LEOPOLD KOSTAL	KK1 (locking system)		sensor)	ADC	ARS4-A (radar	TRA/TA-R/
MARQUARDT	DC12A (locking system)	Schrader	BG3FP4 (tyre pressure sensor)		sensor)	2016/14 D080134
MARQUARDT	DC12B (locking sys-	Schrader	MFR3 (control unit)	ADC	ARS4-C	TRA/TA-R/
	tem)	Veoneer	77V12BSM (radar sensor)		(radar sensor)	7769/19 D172338

Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	TRA/TA-R/ 7983/19 D172338
Bosch	LRR3 (radar sensor)	TRA/TA-R/ 1049/09
Bosch	MRR1Rear (radar sensor)	TRA/TA-R/ 1849/14
Bosch	MRRe14FCR (radar sensor)	TRA/TA-R/ 4353/17
Continental Antenna	RKE213E1 (aerial ampli- fier)	TRA/TA-R/ 2715/15 D090258
Continental Antenna	RKE223E1GN S (aerial amplifier)	TRA/TA-R/ 8337/19

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	CMKG1 (lock- ing system)	TRA/TA-R/ 8642/19 D172338
Continental Automotive	MARS Keyless (locking sys- tem)	TRA/TA-R/ 4158/17 D080134
HELLA	DM4 (locking system)	TRA/TA-R/ 4548/17 D080134
Hirschmann	920287A (locking system)	TRA/TA-R/ 0210/11 D080353
Hirschmann	920287B (locking system)	TRA/TA-R/ 0655/12 D080353

Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSRE4A (tyre pressure sensor)	TRA/TA-R/ 4516/17 D100428
Huf Baolong	TSSSG4G6b (tyre pressure sensor)	TTRA/TA-R/ 7506/19
HUF	HUF14632 (locking system)	TRA/TA-R/ 2665/15
HUF	HUF4761 (locking system)	TRA/TA-R/ 0920/12
LEOPOLD KOSTAL	KK1 (locking system)	TRA/TA-R/ 3129/16
MARQUARDT	DC12A (lock- ing system)	TRA/TA-RD/ 4056/17 D100428

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12B (lock- ing system)	TRA/TA-R/ 0227/11 D080353	MARQUARDT	MK1 (locking system)	TRA/TA-R/ 2848/15 D080353	Schrader	BG3FP4 (tyre pressure sensor)	TRA/TA-R/ 10694/20 D172338
MARQUARDT	DC12K (lock- ing system)	TRA/TA-R/ 0228/11 D080353	MARQUARDT	MK2 (locking system)	TRA/TA-R/ 2900/15 D080353	Schrader	MFR (tyre pressure monitoring system con-	TRA/TA-R/ 7464/19 D090258
MARQUARDT	MS2 (locking	TRA/TA-R/	MARQUARDT	3350.38	TRA/TA-R/		trol unit)	
	system)	4136/17 D080134		(locking sys- tem)	7051/19 D172249	Schrader	MFR3 (tyre pressure	TRA/TA-R/ 7467/19
MARQUARDT	MS4 (locking system)	TRA/TA-R/ 7316/19 D172249	Schrader	AG5SP4 (tyre pressure sensor)	TTRA R/ 2380/15 D080134		monitoring system con- trol unit)	D090258
MARQUARDT	MS5 (locking system)	TRA/TA-R/ 9324/20 D100428	Schrader	AG3PF4 (tyre pressure sensor)	TRA R/ 7287/19 D172338	Schrader	GG4T (tyre pressure sensor)	TRA/TA-R/ 4686/17 D080134

Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	DG6W2D4 (tyre pressure sensor)	TRA/TA-R/ 5511/18 D172249
Sennheiser	M3IETW2R (Earbud)	TRA/TA-R/ 10988/21
Sennheiser	BTT100 (Blue- tooth Audio Transmitter)	TRA/TA-R/ 10976/21
Veoneer	77GHz MMRV1 (radar sensor)	TRA/TA-R/ 2706/15
Veoneer	77V12BSM (radar sensor)	TRA/TA-R/ 7706/19 D172338
Veoneer	77V12CRN (radar sensor)	TRA/TA-R/ 7707/19 D172338

Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77V125CRN (radar sensor)	TRA/TA-R/ 11335/21 D172338
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	TRA/TA-R/ 9150/20

Pakistan





Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Antenna	RKE223E1GN S (aerial amplifier)	TAC NO: 9.100169/20 19
Continental Automotive	CMKG1 (lock- ing system)	TAC NO:9.100175 /2019
Continental Automotive	MARS Keyless (locking system)	TAC NO: 9.213/2017
Continental Automotive	D-WMI2020A (control unit)	TAC NO: 9.9836/2019
HELLA	DM4 (locking system)	TAC NO: 9.409/2017



Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287A (locking system)	TAC NO: 9.845/2013
Hirschmann	920287B (locking system)	TAC NO: 9.846/2013
HUF Baolong	TSSRE4A (tyre pressure sensor)	TAC NO: 9.620/2017
HUF	HUF14632 (locking system)	TAC NO: 9.598/2015



Manufacturer	Model desig- nation	Radio equip- ment approval number
HUF	HUF4761 (locking system)	TAC NO: 9.790/2013
LEOPOLD KOSTAL	KK1 (locking system)	TAC NO: 9.118/2016
MARQUARDT	DC12A (lock- ing system)	TAC NO: 9.131/2017
MARQUARDT	DC12B (lock- ing system)	TAC NO: 9.829/2013
MARQUARDT	DC12K (lock- ing system)	TAC NO: 9.830/2013
MARQUARDT	MS2 (locking system)	TAC NO: 9.133/2017



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS4 (locking system)	TAC NO: 9.100171/20 19
MARQUARDT	MS5 (locking system)	TAC.NO: 9.774/2020
MARQUARDT	MK1 (locking system)	TAC NO: 9.486/2015
MARQUARDT	MK2 (locking system)	TAC NO: 9.497/2015
Schrader	AG3PF4 (tyre pressure sensor)	TAC NO:9.039/20 16



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG5SP4 (tyre pressure sensor)	TAC NO:9.9167/2 019
Schrader	BG3FP4 (tyre pressure sensor)	TAC NO:9.68/202
Schrader	GG4T (tyre pressure sensor)	TAC NO:9.538/20 17
Schrader	DG6W2D4 (tyre pressure sensor)	TAC NO: 9.789/2018



Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77GHz MMRV1 (radar sensor)	TAC NO: 9.9284/2019
Veoneer	77V12BSM (radar sensor)	TAC NO: 9.9391/2019
Veoneer	77V12CRN (radar sensor)	TAC NO: 9.9391/2019
Veoneer	77V125CRN (radar sensor)	TAC NO: 9.477/2021
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	TAC NO: 9.527/2020

Paraguay



Manufacturer	Model desig- nation	Radio equip- ment approval number
ADC	ARS4-A (radar sensor)	2019-05- I-0271
ADC	ARS4-C (radar sensor)	2019-11- I-0602
Bosch	FR5CPCCF (radar sensor)	2019-09- I-0508
Bosch	MRRe14FCR (radar sensor)	2017-06- I-0000162
Bosch	MRR1Rear (radar sensor)	2019-05- I-000236



Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Antenna	RKE213E1 (aerial ampli- fier)	2021-02- I-00101 y 2016-02- I-0000038
Continental Antenna	RKE223E1GN S (aerial amplifier)	2019-12- I-0656
Continental Automotive	CMKG1 (lock- ing system)	2020-02- I-0110
Continental Automotive	MARS Keyless (locking sys- tem)	2017-05- I-0000136
HELLA	DM4 (locking system)	2017-08- I_0000261



Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287A (locking system)	2016-5- I-000134 y 2011-06- I-0059
Hirschmann	920287B (locking system)	2017-04- I-0000119 y 2012-05- I-0096
Huf Baolong	TSSRE4A (tyre pressure sensor)	2017-09- I-0000328
HUF	HUF14632 (locking system)	2020-06- I-0284 y 2015-08- I-0000226



Manufacturer	Model desig- nation	Radio equip- ment approva number
HUF	HUF4761 (locking system)	2017-12- I-0000409 y 2012-10- I-0178
LEOPOLD KOSTAL	KK1 (locking system)	2015-06- I-0000181
MARQUARDT	DC12A (lock- ing system)	2017-07- I-0000199
MARQUARDT	DC12B (lock- ing system)	2021-05- I-0304; 2016-5- I-000144 y 2011-06- I-0067



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12K (lock- ing system)	2021-05- I-0305; 2016-5- I-000143 y 2011-06- I-0068
MARQUARDT	MS2 (locking system)	2017-04- I-0000101
MARQUARDT	MS4 (locking system)	2019-10- I-0581
MARQUARDT	MS5 (locking system)	2020-08- I-0604



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK1 (locking system)	2020-07- I-0390 y 2015-07- I-0000200
MARQUARDT	MK2 (locking system)	2020-07- I-0391 y 2015-07- I-0000201
MARQUARDT	3350.38 (locking system)	2019-04- I-000216
Schrader	AG5SP4 (tyre pressure sensor)	2015-04- I-0000150



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG3PF4 (tyre pressure sensor)	2019-05-1-00 0261
Schrader	BG3FP4 (tyre pressure sensor)	2021-02- I-0063
Schrader	GG4T (tyre pressure sensor)	2020-02-1-00 44
Schrader	DG6W2D4 (tyre pressure sensor)	2019-11-1-06 32



Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77GHz MMRV1 (radar sensor)	2020-07- I-0510
Veoneer	77V12BSM (radar sensor)	2019-07- I-0399
Veoneer	77V12CRN (radar sensor)	2019-07- I-0398
Veoneer	77V125CRN (radar sensor)	2021-04- I-0188
WITTE-Velbert	SDHTAG3NFC (locking system)	2020-06- I-0326

Charging unit for wireless charging of mobile devices (WMI)

D-WMI2020A:

This vehicle has the following radio frequency component approved by CONATEL - Paraguay: Wireless interface for mobile devices, Continental brand, model D-WMI2020A manufactured by Continental Automotive GmbH.

Radio equipment approval number: 2019-11-I-0600


Rear Seat Entertainment System:

DAIRSE:

Importer: Condor S.A.C.I Casa Central, J.B. Gorostiaga 315 y Guaraníes, Asunción, Paraguay, (595 21) 569 7000, sac@condor.com.py

Further specific information

Philippines





Manufacturer	Model designation	Radio equip- ment approval number
Continental Antenna	RKE213E1 (aerial ampli- fier)	ESD-1511856 C
Continental Antenna	RKE223E1GN S (aerial amplifier)	ESD-1921015 C
Continental Automotive	CMKG1 (lock- ing system)	ESD-2021556 C
Continental Automotive	MARS Keyless (locking system)	ESD-1714865 C
HELLA	DM4 (locking system)	ESD-1715539 C



Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287A (locking system)	ESD-1105246 C
Hirschmann	920287B (locking system)	ESD-1206044 C
Huf Baolong	TSSRE4A (tyre pressure sensor)	ESD-1715393 C
HUF	HUF14632 (locking system)	ESD-1511236 C



Manufacturer	Model desig- nation	Radio equip- ment approval number
HUF	HUF4761 (locking system)	ESD-1206521 C
LEOPOLD KOSTAL	KK1 (locking system)	ESD-1510698 C
MARQUARDT	DC12A (lock- ing system)	ESD-1714489 C
MARQUARDT	DC12B (lock- ing system)	ESD-1105216 C
MARQUARDT	DC12K (lock- ing system)	ESD-1105215 C
MARQUARDT	MS2 (locking system)	ESD-1715652 C



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS4 (locking system)	ESD-1919133 C
MARQUARDT	MS5 (locking system)	ESD-2022426 C
MARQUARDT	MK1 (locking system)	ESD-1510644 C
MARQUARDT	MK2 (locking system)	ESD-1510645 C
MARQUARDT	3350.38 (locking system)	ESD-1919198 C




Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG5SP4 (tyre pressure sensor)	ESD-1715393 C
Schrader	AG3PF4 (tyre pressure sensor)	ESD-1919585 C
Schrader	BG3FP4 (tyre pressure sensor)	ESD- RCE-2124846
Schrader	GG4T (tyre pressure sensor)	ESD-1715977 C



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	DG6W2D4 (tyre pressure sensor)	ESD-1817081 C
Veoneer	77GHz MMRV1 (radar sensor)	ESD-1510921 C
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	ESD-2022599 C

Zambia




yk.	ZIC	TA	
360	ZPC	LA	


FEREIN		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Hirschmann	920287B (locking system)	ZMB/ ZICTA/TA/ 2019/7/11
HUF	HUF4761 (locking system)	ZMB/ ZICTA/TA/ 2018/12/18
LEOPOLD KOSTAL	KK1 (locking system)	ZMB/ ZICTA/TA/ 2019/3/48
MARQUARDT	DC12A (lock- ing system)	ZMB/ ZICTA/TA/ 2019/5/16



Manufacturer	Model designation	Radio equip- ment approval number
MARQUARDT	DC12B (lock- ing system)	ZMB/ ZICTA/TA/ 2019/5/17
MARQUARDT	DC12K (lock- ing system)	ZMB/ ZICTA/TA/ 2019/5/18
MARQUARDT	MS2 (locking system)	ZMB/ ZICTA/TA/ 2018/9/30
MARQUARDT	MS4 (locking system)	ZMB/ ZICTA/TA/ 2019/7/123



Serbia





Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	MRRe14FCR (radar sensor)	И005 17
Continental Antenna	RKE213E1 (aerial ampli- fier)	И005 21
Continental Antenna	RKE223E1GN S (aerial amplifier)	И005 19
Continental Automotive	CMKG1 (lock- ing system)	И005 20
Continental Automotive	MARS Keyless (locking system)	И005 17



Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	И005 20
Hirschmann	920287A (locking system)	И005 18
Hirschmann	920287B (locking system)	И005 18
Huf Baolong	TSSRE4A (tyre pressure sensor)	И005 20
HUF	HUF14632 (locking system)	И005 21



Manufacturer	Model desig- nation	Radio equip- ment approval number
HUF	HUF4761 (locking sys- tem)	И005 21
LEOPOLD KOSTAL	KK1 (locking system)	И005 18
MARQUARDT	DC12A (lock- ing system)	И005 20
MARQUARDT	DC12B (lock- ing system)	И005 20
MARQUARDT	DC12K (lock- ing system)	И005 20
MARQUARDT	MS2 (locking system)	И011 17




Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS4 (locking system)	И005 19
MARQUARDT	MS5 (locking system)	И005 20
MARQUARDT	MK1 (locking system)	И005 21
MARQUARDT	MK2 (locking system)	И005 21
MARQUARDT	3350.38 (locking system)	34540-124/1 9-5



<u> </u>		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Meta System	MUW II (inte- rior protec- tion)	И011 19
Schrader	AG5SP4 (tyre pressure sensor)	И005 15
Schrader	AG3PF4 (tyre pressure sensor)	И005 15
Schrader	BG3FP4 (tyre pressure sensor)	И005 20



44		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	GG4T (tyre pressure sensor)	И005 17
Schrader	DG6W2D4 (tyre pressure sensor)	И005 18
Schrader	MC34MA4 (tyre pressure monitoring system con- trol unit)	И011 11
Veoneer	77GHz MMRV1 (radar sensor)	И011 18



Singapore

Manufacturer	Model desig- nation	Radio equip- ment approval number
		Complies with IMDA Stand-ards
ADC	ARS4-A (radar sensor)	DA103365
ADC	ARS4-C (radar sensor)	DA103365
Bosch	FR5CPCCF (radar sensor)	DA103365
Bosch	LRR3 (radar sensor)	DA103365
Bosch	MRR1Rear (radar sensor)	DA103365
Bosch	MRRe14FCR (radar sensor)	DA103365


Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Antenna	RKE213E1 (aerial ampli- fier)	DA105282
Continental Antenna	RKE223E1GN S (aerial amplifier)	DA107248
Continental Automotive	CMKG1 (lock- ing system)	DA103365
Continental Automotive	MARS Keyless (locking system)	DA103365
Continental Automotive	D-WMI2020A (control unit)	DA103365
Harman Becker	HERMES 3.0 (communica- tion module)	DB107091

Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number	Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	DA103365	HUF	HUF4761 (locking sys-	DA103365	MARQUARDT	MS5 (locking system)	DB107091
Hirschmann	920287A	DA103365		tem)		MARQUARDT	MK1 (locking	DA103365
	(locking sys-		LEOPOLD	KK1 (locking	DA103365		system)	
	tem)		KOSTAL	system)		MARQUARDT	MK2 (locking	DA103365
Hirschmann 920287B	DA103365	MARQUARDT		DA103787	system)			
	(locking sys- tem)			ing system)		MARQUARDT	3350.38	DA103787
HUF Baolong	TSSRE4A	DA30668	MARQUARDT	DC12B (lock- ing system)	DA103365		(locking sys- tem)	
	(tyre pressure sensor)		MARQUARDT	DC12K (lock- ing system)	DA103365	Meta System	ITS/TPS (interior protec-	DA103365
HUF Baolong	TSSSG4G6b	DA28467					tion)	
	(tyre pressure sensor)		MARQUARDT	MS2 (locking system)	DA103787	Meta System	MUW II (inte-	DA103365
HUF	HUF14632 (locking system)	DA105282	MARQUARDT	MS4 (locking system)	DA103787		rior protec- tion)	

Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG5SP4 (tyre pressure sensor)	DA103787
Schrader	AG3PF4 (tyre pressure sensor)	DA107968
Schrader	BG3FP4 (tyre pressure sensor)	DA103365
Schrader	GG4T (tyre pressure sensor)	DA105282
Schrader	DG6W2D4 (tyre pressure sensor)	DA105282
Veoneer	77GHz MMRV1 (radar sensor)	DA103365

Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77V12BSM (radar sensor)	DA103365
Veoneer	77V12CRN (radar sensor)	DA103365
Veoneer	77V125CRN (radar sensor)	DA103365
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	DA107248

South Africa





Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	LRR3 (radar sensor)	TA-2009/464
Continental Antenna	RKE213E1 (aerial ampli- fier)	TA-2015/143 8
Continental Antenna	RKE223E1 (aerial ampli- fier)	TA-2020/043
Continental Automotive	CMKG1 (lock- ing system)	TA-2019/540 5
Continental Automotive	MARS Keyless (locking sys- tem)	TA-2016/350 0



7.		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Gentex	MUAHL 5 (convenience system)	TA-2015/138 6
HELLA	DM4 (locking system)	TA-2017/251
Hirschmann	920287A (locking system)	TA-2011/374
Hirschmann	920287B (locking system)	TA-2013/126 2
Huf Baolong	TSSRE4A (tyre pressure sensor)	TA-2017/139



25.			
Manufacturer	Model desig- nation	Radio equip- ment approval number	
Huf Baolong	TSSSG4G6b (tyre pressure sensor)	TA-2019/144 0	
HUF	HUF14632 (locking system)	TA-2015/107 7	
HUF	HUF4761 (locking system)	TA-2012/154 3	
LEOPOLD KOSTAL	KK1 (locking system)	TA-2015/595	
Meta System	ITS Master (interior pro- tection)	TA-2011/163 6	



Manufacturer	Model desig- nation	Radio equip- ment approval number
Meta System	ITS Sensor (interior pro- tection)	TA-2011/122 7
Meta System	MUW II (interior protection)	TA-2019/261
MARQUARDT	DC12A (lock- ing system)	TA-2017/312
MARQUARDT	DC12B (lock- ing system)	TA-2011/370
MARQUARDT	DC12K (lock- ing system)	TA-2012/154 2




.24.		
Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS2 (locking system)	TA-2016/331 4
MARQUARDT	MS4 (locking system)	TA-2019/843
MARQUARDT	MS5 (locking system)	TA-2020/576 5
MARQUARDT	MK1 (locking system)	TA-2015/179
MARQUARDT	MK2 (locking system)	TA-2015/180
MARQUARDT	3350.38 (locking system)	TA-2018/398 5



1.00		
Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG5SP4 (tyre pressure sensor)	TA-2015/072
Schrader	AG3PF4 (tyre pressure sensor)	TA-2019-133
Schrader	BG3FP4 (tyre pressure sensor)	TA-2020/773
Schrader	MFR (control unit)	TA-2019/273
Schrader	MFR3 (control unit)	TA-2019-273




Manufacturer	Model designation	Radio equip- ment approval number
Schrader	GG4T (tyre pressure sensor)	TA-2017/388 4
Schrader	DG6W2D4 (tyre pressure sensor)	TA-2017/293 3
Schrader	MC34MA4 (tyre pressure monitoring system con- trol unit)	TA-2011/137 0
Veoneer	77GHz MMRV1 (radar sensor)	TA-2015/208 7




South Korea

Regulatory radio identification





Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	MFR3 (control unit)	KCC R-R-SRD- MFR3A
Schrader	MC34MA4 (tyre pressure monitoring system con- trol unit)	KCC-REM- SRD- MRXMC34MA 4
Schrader	AG5SP4 (tyre pressure sensor)	MSIP-CRM- SRD-AG5SP4
Schrader	AG3PF4 (tyre pressure sensor)	R-C-SRD- AG3PF4



Togo

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Antenna	RKE223E1 (aerial ampli- fier)	No. 024/19
Continental Automotive	MARS Keyless (locking sys- tem)	No. 040/19
HELLA	DM4 (locking system)	No. 039/19
Hirschmann	920287A (locking system)	No. 089/19
Hirschmann	920287B (locking sys- tem)	No. 088/19


614 Technical data

Manufacturer	Model desig- nation	Radio equip- ment approval number
HUF	HUF4761 (locking system)	No. 041/19
LEOPOLD KOSTAL	KK1 (locking system)	No. 060/19
MARQUARDT	DC12A (lock- ing system)	No. 055/19
MARQUARDT	DC12B (lock- ing system)	No. 057/19
MARQUARDT	DC12K (lock- ing system)	No. 056/19
MARQUARDT	MS2 (locking system)	No. 008/19
MARQUARDT	MS4 (locking system)	No. 101/19

Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK1 (locking system)	No. 021/19
MARQUARDT	MK2 (locking system)	No. 022/19
MARQUARDT	3350.38 (locking system)	No. 016/20

Ukraine

Regulatory radio identification



tem)



Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	UA.TR.109
Hirschmann	920287A (locking system)	UKR.355-7/2 0
Hirschmann	920287B (locking system)	UKR.355-8/2 0
Huf Baolong	TSSRE4A (tyre pressure sensor)	UA 1.001.01856 8-19-TE



Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSSG4G6b (tyre pressure monitoring system con- trol unit)	UA 1.001.01928 9-19-TE
HUF	HUF14632 (locking system)	UKR.355-113 /19
HUF	HUF4761 (locking system)	UA1.001.018 653-19-TE
LEOPOLD KOSTAL	KK1 (locking system)	10094.00668 2-19



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12A (lock- ing system)	UA.R.TR.052. 307-19
MARQUARDT	DC12B (lock- ing system)	UA.R.TR.052. 308-19
MARQUARDT	DC12K (lock- ing system)	UA.R.TR.052. 309-19
MARQUARDT	MS2 (locking system)	UA1.001.019 129-19-TE
MARQUARDT	MS4 (locking system)	UA.R.TR.052. 528-19
MARQUARDT	MS5 (locking system)	632.16-CET



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK1 (locking system)	UA1.001.019 233-19-TE
MARQUARDT	MK2 (locking system)	UA1.001.019 234-19-TE
MARQUARDT	3350.38 (locking system)	UA1.001.018 888-19-TE
Schrader	AG5SP4 (tyre pressure sensor)	UA.TR. 032
Schrader	AG3PF4 (tyre pressure sensor)	UA-TR-001



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	BG3FP4 (tyre pressure sensor)	UA-TR-109
Schrader	GG4T (tyre pressure sensor)	UA.TR. 028
Schrader	DG6W2D4 (tyre pressure sensor)	UA.TR. 028
WITTE-Velbert	SDHTAG3NFC (locking system)	UA.R.TR.052. 120-20

Uzbekistan

Regulatory radio identification




Manufacturer	Model designation
Continental Automotive	CMKG1 (locking system)
HELLA	DM4 (locking system)
MARQUARDT	DC12A (locking system)
MARQUARDT	DC12B (locking system)
MARQUARDT	DC12K (locking system)
MARQUARDT	MS2 (locking system)
MARQUARDT	MS4 (locking system)




Manufacturer	Model designation
MARQUARDT	MS5 (locking system)
MARQUARDT	MK1 (locking system)
MARQUARDT	MK2 (locking system)
MARQUARDT	3350.38 (locking system)
WITTE-Velbert	SDHTAG3NFC (locking system)

United Arab Emirates

Regulatory radio identification







Manufacturer	Model desig- nation	Radio equip- ment approval number
Bosch	FR5CPCCF (radar sensor)	TA RTTE: 74533/19, DA36758/14
Continental Antenna	RKE213E1 (aerial ampli- fier)	TRA ER64693/18, DA65993/17
Continental Antenna	RKE223E1GN S (aerial amplifier)	TRA E76442/19, DA65993/17



Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Automotive	CMKG1 (lock- ing system)	TRA ER77964/20, DA0018994/ 09
Continental Automotive	MARS Keyless (locking system)	TRA ER56005/15, DA44932/15
Gentex	MUAHL 5 (convenience system)	TRA ER41849/15, DA35176/14
Haram Becker	HERMES 3.0 (communication module)	TRA ER03601/21, DA0028019/ 10



Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	TRA ER56616/17, DA44932/15
Hirschmann	920287A (locking system)	TRA ER52213/17, DA35219/14
Hirschmann	920287B (locking system)	TRA ER42011/5, DA35219/14
Huf Baolong	TSSRE4A (tyre pressure sensor)	TRA ER57806/17, DA36976/14



Manufacturer	Model desig- nation	Radio equip- ment approval number
Huf Baolong	TSSSG4G6b (tyre pressure monitoring system con- trol unit)	TRA ER7307/19, DA0086237/ 12
HUF	HUF14632 (locking system)	TRA ER63716/18, DA36976/14
HUF	HUF4761 (locking system)	TRA ER55496/17, DA36976/14
LEOPOLD KOSTAL	KK1 (locking system)	TRA ER62622/18, DA0105247/ 13



Manufacturer	Model designation	Radio equip- ment approval number
MARQUARDT	DC12A (lock- ing system)	TRA ER53465/17, DA0018994/ 09
MARQUARDT	DC12B (lock- ing system)	TRA ER0067828/ 11, DA0018994/ 09
MARQUARDT	DC12K (lock- ing system)	TRA ER0067829/ 11, DA0018994/ 09



Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MS2 (locking system)	TRA ER52668/17, DA0018994/ 09
MARQUARDT	MS4 (locking system)	TRA ER71616/19, DA0018994/ 09
MARQUARDT	MS5 (locking system)	TRA ER80720/20, DA0018994/ 09




Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK1 (locking system)	TRA ER64145/18, DA0018994/ 09
MARQUARDT	MK2 (locking system)	TRA ER64146/18, DA0018994/ 09
MARQUARDT	3350.38 (locking system)	TRA ER69280/19, 0018994/09
Schrader	AG5SP4 (tyre pressure sensor)	TRA ER37156/15, DA0047074/ 10





Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG3PF4 (tyre pressure sensor)	TRA ER70533/19, DA0047074/ 10
Schrader	BG3FP4 (tyre pressure sensor)	TRA ER96175/21, DA0047074/ 10
Schrader	GG4T (tyre pressure sensor)	TRA ER57985/17, DA0047074/ 10



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	DG6W2D4 (tyre pressure sensor)	TRA ER960528/1 8, DA0047074/ 10
Schrader	MC34MA4 (tyre pressure monitoring system con- trol unit)	TRA ER37066/15, DA0047074/ 10
Sennheiser	M3IETW2L (Earbud)	ER78231/20
Sennheiser	BTT100 (Blue- tooth Audio Transmitter)	ER64728/18









Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77V125CRN (radar sensor)	TA RTTE: ER95775/21; 0020858/10
WITTE-Velbert	SDHTAG3NFC (locking sys- tem)	TRA ER79695/20, DA0018994/ 09

United Kingdom

Regulatory radio identification



Manufacturer	Model designation
Huf Baolong	TSSRE4A (tyre pressure sensor)
Schrader	AG5SP4 (tyre pressure sensor)
Schrader	AG3PF4 (tyre pressure sensor)
Schrader	BG3FP4 (tyre pressure sensor)
Schrader	GG4T (tyre pressure sensor)
Schrader	DG6W2D4 (tyre pressure sensor)

Further specific information

Charging unit for wireless charging of mobile devices (WMI)

D-WMI2016A, D-WMI2017A, D-WMI2017B:

Restrictions or Requirements in the UK: A separation distance of at least 10 cm between all persons and the device must be provided at all times. The Device must not be co-located or operating in conjunction with any other antenna or transmitter. D-WMI2020A:

Restrictions or Requirements in the UK: A separation distance of at least 0 cm between all persons and the device must be provided at all times. The Device must not be co-located or operating in conjunction with any other antenna or transmitter.

United States

Regulatory radio identification

Manufacturer	Model desig- nation	Radio equip- ment approval number
Sennheiser	M3IETW2R (Earbud)	FCC ID: DMOM3IETW 2R
Sennheiser	M3IETW2L (Earbud)	FCC ID: DMOM3IETW 2L
Sennheiser	BTT100 (Blue- tooth Audio Transmitter)	FCC ID: DMOBTT100

Information on installation clearances Charging unit for wireless charging of mobile devices (WMI)

The charging unit for wireless charging of mobile devices (WMI) complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0 cm (in contact) between the source of radiation and your body. This transmitter must not be placed in the same location as or used at the same time as another transmitter or aerial.

Rear Seat Entertainment System:

USA: "This device complies with part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device must not cause any harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device must be installed and used at a distance of at least 6 cm from the body."

Canada: "This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This

device must not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

This equipment complies with ISED radiation exposure limits established for an uncontrolled environment. This equipment must be installed and operated with a minimum distance of 5 cm between the radiation source and your body."

Radar sensors

ARS4-C (ADC), ARS4-B (ADC), ARS4-A (ADC), FR5CPCCF (Bosch), MRR1REAR (Bosch), MRREVO14F (Bosch), LRR3 (Bosch), 77V12BSM (Veoneer), 77V12CRN (Veoneer), MMRV1 (Veoneer)

For the USA only: Information on exposure to high-frequency radiation:

This equipment complies with FCC radiation exposure limits established for an uncontrolled environment. This equipment must be installed and operated with a minimum distance of 20 cm between the radiation source and your body.

This transmitter must not be placed in the same location as or used at the same time as another aerial or transmitter.

For Canada only: This equipment should be installed and operated with a minimum distance of 20 cm between the radiation source and your body.

BT Audio Transmitter (BTT100):

This equipment complies with FCC and IC radiation exposure limits established for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 9 cm between the radiation source and your body.

This transmitter must not be placed in the same location as or used at the same time as another aerial or transmitter.

Vietnam

Regulatory radio identification




Manufacturer	Model desig- nation	Radio equip- ment approval number
ADC	ARS4-A (radar sensor)	SUNTECH VN C00082015
ADC	ARS4-C (radar sensor)	SUNTECH VN C00082015
Bosch	FR5CPCCF (radar sensor)	SUNTECH VN C00082015
Bosch	MRR1Rear (radar sensor)	SUNTECH VN C00082015
Bosch	MRRe14FCR (radar sensor)	SUNTECH VN C00082015



Manufacturer	Model desig- nation	Radio equip- ment approval number
Continental Antenna	RKE213E1 (aerial ampli- fier)	Suntech Viet- nam Technol- ogy Company Limited C027415111 8AF04A2
Continental Antenna	RKE223E1GN S (aerial amplifier)	Suntech Viet- nam Technol- ogy Company Limited B152201112 1AF04A3







Manufacturer	Model desig- nation	Radio equip- ment approval number
HELLA	DM4 (locking system)	Mercedes- Benz Vietnam Company Limited CO20403032 1AF04A3
Huf Baolong	TSSRE4A (tyre pressure sensor)	C011220071 7AF04A2
LEOPOLD KOSTAL	KK1 (locking system)	Mercedes- Benz Vietnam Company Limited C031314042 1AF0403




Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	DC12A (lock- ing system)	Suntech Viet- nam Technol- ogy Company Limited C020803032 1AF04A3
MARQUARDT	DC12B (lock- ing system)	Suntech Viet- nam Technol- ogy Company Limited C007621012 1AF04A3











Manufacturer	Model desig- nation	Radio equip- ment approval number
MARQUARDT	MK1 (locking system)	Suntech Viet- nam Technol- ogy Company Limited C002118011 9AF04A2
MARQUARDT	MK2 (locking system)	Suntech Viet- nam Technol- ogy Company Limited C002218011 9AF04A2







Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	AG3PF4 (tyre pressure sensor)	Suntech Viet- nam Technol- ogy Company Limited C012022051 9AF04A2
Schrader	GG4T (tyre pressure sen- sor)	Suntech Viet- nam Technol- ogy Company Limited C017019101 7AF04A2



Manufacturer	Model desig- nation	Radio equip- ment approval number
Schrader	DG6W2D4 (tyre pressure sensor)	Suntech Viet- nam Technol- ogy Company Limited C007807051 8AF04A2
Veoneer	77GHz MMRV1 (radar sensor)	SUNTECH VN C00082015
Veoneer	77V12BSM (radar sensor)	SUNTECH VN C00082015
Veoneer	77V12CRN (radar sensor)	SUNTECH VN C00082015



Manufacturer	Model desig- nation	Radio equip- ment approval number
Veoneer	77V125CRN (radar sensor)	SUNTECH VN C00082015
WITTE-Velbert	SDHTAG3NFC (locking system)	Mercedes- Benz Vietnam Company Limited A084713082 0AF04A3

Information about the specific absorption rate (SAR)

Information about the specific absorption rate For France only:

The values have been determined and tested in accordance with the Décret n° 2019-1186 guide-line regarding the indication of the specific absorption rate (SAR) of wireless vehicle components.

Further information and updates are available at the following web address:

https://moba.i.mercedes-benz.com/baix/cars/SAR/fr_FR/index.html



Information about the specific absorption rate

Vehicle components	SAR value in W/kg	Applicable limit value
Compensator ECE DE003 & ECE DE004	< 0.2 W/kg	2 W/kg
DAI RSE	1.8 W/kg	2 W/kg

Vehicle components	SAR value in W/kg	Applicable limit value
HERMES communication module	< 0.4 W/kg	2 W/kg
RAMSES communication module	0.036 W/kg	2 W/kg
NRCS2P	0.003 W/kg	2 W/kg
NTG6	0.199 W/kg	4 W/kg
NTG7	0.08 W/kg	2 W/kg
NTG7RSU	0.07 W/kg	2 W/kg
Tablet PC SM-T230NZ	0.7 W/kg	4 W/kg
Radio data transmission telephone system	0.24 W/kg	2 W/kg

Importer information for regulatory radio components

For Moldova only: Importer

S.C. GRAND PREMIUM S.R.L. Moldova mun. Chisinau, str. Hîncesti sos., 2/2

For Turkey only: Importer

A.Ş. Genel Merkez Akçaburgaz Mah. Süleyman Şah Cad. No: 6/1 34522 Esenyurt/İstanbul

Mercedes Benz Otomotiv Ticaret ve Hizmetler

For Ukraine only: Importer

PISC "AUTOCAPITAL"

Velyka Vasylkivska str. 15/2

01004 Kyiv

Ukraine


For the United Kingdom only: Importer


Mercedes-Benz Cars UK Limited

Delaware Drive, Tongwell
Milton Keynes, MK15 8BA
England
Importer of Mercedes-Benz spare parts
Mercedes-Benz Parts Logistics
Delaware Drive, Tongwell
Milton Keynes, MK15 8BA
England

Vehicle identification plate, VIN and engine number overview


Vehicle identification plate





Vehicle identification plate (example: Kuwait)

- Vehicle manufacturer
- Place of manufacture
- Manufacturing date
- 4 Vehicle model
- VIN




Vehicle identification plate (example: all other countries)

- Vehicle manufacturer
- EU general operating permit number (only for certain countries)
- VIN (vehicle identification number)
- Maximum permissible gross vehicle weight (kg)

- Maximum permissible gross weight of vehicle combination (kg) (only for specific countries)
- Maximum permissible front axle load (kg)
- Maximum permissible rear axle load (kg)
- Paint code
- The data shown in the illustration is example data.

VIN below the front right-hand seat



- Imprinted VIN (vehicle identification number)
- Floor covering

VIN at the lower edge of the windscreen



VIN (vehicle identification number) as label

The VIN as a label at the lower edge of the windscreen is only available in some countries.

Engine number

The engine number is stamped into the crankcase. Further information can be obtained at a qualified specialist workshop.

Operating fluids

Notes on operating fluids



Operating fluids can be toxic.

- When using, storing and disposing of operating fluids, observe the imprints on the respective original containers.
- Always keep operating fluids in the sealed original container.
- Always keep children away from operating fluids.



Incorrect disposal of operating fluids can cause considerable damage to the environment.

Dispose of operating fluids in an environmentally responsible manner.

Operating fluids include the following:

- fuels
- DeNOx agent AdBlue[®] for exhaust gas aftertreatment
- lubricants
- Coolant
- Brake fluid
- windscreen washer fluid
- climate control system refrigerant

Only use products approved by Mercedes-Benz. Damage caused by the use of products that have not been approved is not covered by the Mercedes-Benz warranty or goodwill gestures.

The operating fluids approved by Mercedes-Benz can be identified by the following inscriptions on the container:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB-Approval (e.g. MB-Approval 229.51)

Further information on approved operating fluids:

 in the Mercedes-Benz Specifications for Operating Fluids by entering the designation

- At https://operatingfluids.mercedesbenz.com
- At a qualified specialist workshop

WARNING Risk of fire or explosion from fuel

Fuels are highly flammable.

- Fire, naked flames, smoking and creating sparks must be avoided.
- Before and during refuelling, switch off the vehicle and, if fitted, the stationary heater.

WARNING Risk of injury from fuels

Fuels are poisonous and hazardous to your health.

- Do not swallow fuel or let it come into contact with skin, eyes or clothing.
- Do not inhale fuel vapour.
- Keep children away from fuel.
- Keep doors and windows closed during the refuelling process.

If you or other people come into contact with fuel, observe the following:

- Immediately rinse fuel off your skin with soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical attention. immediately.
- If you swallow fuel, seek medical attention immediately. Do not induce vomiting.
- Change immediately out of clothing that has come into contact with fuel.

Flexible-fuel vehicles can be refuelled with the following fuel types:

- unleaded petrol
- E85 fuel
- a mixture of E85 fuel and unleaded petrol

Flexible-fuel vehicles can be identified by the Ethanol up to E85 sticker on the inside of the fuel filler flap.

Depending on the country, the fuels you can use in your vehicle may differ from the information in the Owner's Manual. The fuels that have been approved for your vehicle can be found on the instruction label on the inside of the fuel filler flap.

Fuel

Information on fuel quality for vehicles with petrol engines

Observe the notes on operating fluids $(\rightarrow page 632)$.

NOTE Damage caused by the wrong fuel

Even small amounts of the wrong fuel could result in damage to the fuel system, the engine and the emission control system.

Only refuel using unleaded, sulphur-free spark-ignition engine fuel that conforms to European EN 228, or an equivalent specification.

Fuel of this specification may contain up to 10% ethanol by volume. Your vehicle is suitable for use with F10 fuel

See the information label in fuel filler flap for other compatible fuels .

Never refuel with one of the following fuels:

- Diesel
- Regular petrol with an octane number lower than 91 RON
- Petrol with more than 3% methanol by volume, e.g. M15, M30
- Petrol with additives containing metal

If you have accidentally refuelled with the wrong fuel:

- Do not switch on the vehicle.
- Consult a qualified specialist workshop.

The following compatibility indications for fuel apply to your vehicle:



- For petrol with maximum 5% ethanol by volume
- For petrol with maximum 10% ethanol by volume

The compatibility indications for fuel on the vehicle according to the European standard EN 16942 can be found on the information label in the fuel filler flap or on the fuel dispenser or pump nozzle suitable for your vehicle throughout Europe.

If the available fuel is not sufficiently low in sulphur, it may produce unpleasant odours.

The recommended octane number for your vehicle can be found on the information label in the fuel filler flap.

 Vehicles with petrol engine M256: when using 95 RON, there may be slight limitations in performance that have no further consequences.

E 350: Only refuel using super unleaded petrol with at least 98 RON if you wish to achieve maximum engine output. Alternatively, you can also refuel using premium-grade unleaded petrol with an octane number of at least 95 RON.

As a temporary measure, if the recommended fuel is not available, you may also refuel with regular unleaded petrol with at least 91 RON.

This may reduce engine output and increase fuel consumption.

Never refuel using petrol with a lower RON.

Further information on fuel can be obtained at a filling station or a qualified specialist workshop.

Information on additives in petrol (vehicles with petrol engine)

Observe the notes on operating fluids $(\rightarrow page 632)$.

! NOTE Damage from use of unsuitable additives

Even small amounts of the wrong additive may lead to malfunctions occurring.

Only add cleaning additives recommended by Mercedes-Benz to the fuel.

Mercedes-Benz recommends that you use brandname fuels with additives.

In some countries, the fuel available may not have sufficient additives. Deposits could build up in the fuel injection system as a result. In this case, in consultation with a qualified specialist workshop (e.g. a Mercedes-Benz service centre), mix the fuel with the cleaning additive recommended by Mercedes-Benz. Observe the notes and mixing ratios indicated on the tank.

Information on fuel quality for vehicles with a diesel engine

General notes

Observe the notes on operating fluids $(\rightarrow page 632)$.

A WARNING Risk of fire from fuel mixture

If you mix diesel fuel with petrol, the flash point of the fuel mixture is lower than that of pure diesel fuel.

- Never refuel using petrol in diesel engines.
- Never mix petrol with diesel fuel.

! NOTE Damage caused by the wrong fuel

Even small amounts of the wrong fuel could result in damage to the fuel system, the engine and the emission control system.

Vehicles with a diesel particulate filter:

Only refuel using sulphur-free diesel fuel that conforms to European standard EN 590, or an equivalent specification. In countries without sulphur-free diesel fuel, refuel using only low-sulphur diesel fuel with a sulphur content less than 50 ppm.

Vehicle without diesel particulate filter:

Only refuel using diesel fuel with a sulphur content less than 500 ppm.


Never refuel with one of the following fuels:

- Petrol
- Marine diesel
- Heating oil
- Pure fatty acid methyl ester or vegetable oil
- · Paraffin or kerosene

If you have accidentally refuelled with the wrong fuel:

- Do not switch on the vehicle.
- Consult a qualified specialist workshop.

The following compatibility indications for fuel apply to your vehicle:



- For diesel fuel with a maximum of 7% fatty acid methyl ester by volume (bio-diesel)
- For diesel fuel with a maximum of 10% fatty acid methyl ester by volume (bio-diesel)

According to European standard EN 16942 you can find the compatibility indications at the following locations:

- On the vehicle on the information label on the fuel filler flap (\rightarrow page 203)
- On the fuel dispenser or pump nozzle suitable for your vehicle throughout Europe

Information on low outside temperatures

Refuel your vehicle with as much winter diesel fuel as possible at the beginning of winter.

Before changing over to winter diesel fuel, the fuel tank should be empty, if possible. When first refuelling with winter diesel fuel, keep the fuel level low, e.g. to reserve level. The fuel tank can be filled as usual when next refuelling.

Further information on fuel can be obtained at a filling station or a qualified specialist workshop.

■ Tank content and fuel reserve

The total capacity of the fuel tank may vary, depending on the vehicle equipment.

Total fuel tank capacity

Model	
All models	50.0 litres
	or
	66.0 litres

Fuel tank reserve

Model	
All models	7.0 litres

AdBlue® (vehicles with a diesel engine only)

■ Notes on AdBlue[®]

Observe the notes on operating fluids $(\rightarrow page 632)$.

AdBlue® is a water-soluble fluid for the NOx exhaust gas aftertreatment of diesel engines.

It may be improper or punishable in some countries to operate a vehicle that uses no AdBlue® or one that does not comply with the specifications of this Owner's Manual

NOTE Malfunctions due to the dilution of AdBlue® or the use of additive-enhanced AdBlue[®]

The function of the NOx exhaust gas aftertreatment can be impaired by the use of unsuitable denoxification agents.

- Only use AdBlue® in accordance with ISO 22241.
- ▶ Do not dilute AdBlue® with water.
- ► Do not use additive-enhanced AdBlue[®].
- I NOTE Damage and malfunctions due to impurities in AdBlue®

Consequences of impurities in AdBlue®:

- · increased emission values
- damage to the catalytic converter
- NOx exhaust gas aftertreatment malfunctions
- Avoid impurities in AdBlue®.

AdBlue® residues crystallise after a period of time, and contaminate the surfaces with which they come into contact. Clean the dirty surfaces with water as soon as possible.

When you open the AdBlue® tank, small amounts of ammonia vapour may escape. Do not inhale

any ammonia vapours that may be released. Only fill the AdBlue® tank in well-ventilated areas.

■ AdBlue[®] filling capacity and consumption

Total capacity of AdBlue® tank

Model	Total capacity
E 220 d	24.0 litres

AdBlue® consumption

The average AdBlue® consumption is between 1% and 5% of fuel consumption. Like fuel consumption, AdBlue® consumption is highly dependent upon driving style and operating conditions. For this reason, your vehicle's actual consumption figures in day-to-day operating conditions may differ from the average consumption figures calculated. The frequency at which you will have to top up AdBlue® will also vary. Have the AdBlue® supply checked at a qualified specialist workshop before making journeys outside Europe. Before a longer stay outside Europe, consult a qualified specialist workshop.

AdBlue® fill level and range

The AdBlue[®] fill level and range can be displayed via the on-board computer. The AdBlue[®] range shown depends strongly on the driving style and operating conditions. The actual range may therefore deviate from the range currently displayed on the on-board computer. The information supplied in the Owner's Manual regarding the reserve quantity at the first display warning and the minimum top-up quantity when the fuel tank is empty is also to be understood as guide values.

Engine oil

Notes on engine oil

Observe the notes on operating fluids (\rightarrow page 632).



- ! NOTE Engine damage caused by an incorrect oil filter, incorrect oil or additives
- Do not use engine oils or oil filters other than those which meet the specifications necessary for the prescribed service intervals.
- Do not alter the engine oil or oil filter in order to achieve longer change intervals than prescribed.
- Do not use additives.
- Have the engine oil changed after the prescribed intervals.

Mercedes-Benz recommends having the oil changed at a qualified specialist workshop.

Only use engine oils approved for your vehicle by

■ Engine oil quality and filling quantity

Mercedes-Benz.

Engine oil specification (petrol engines)

Petrol engines	MB-Freigabe or MB- Approval
All models	229.71 229.72*

Engine oil specification (diesel engines)

Diesel engines	MB-Freigabe or MB- Approval
E 220 d	229.52, 229.61, 229.71 229.72*

* recommended for lowest possible fuel consumption (lowest SAE viscosity class in each case; observe possible restrictions of the approved SAE viscosity classes)

E 200; E 300: use only engine oils of viscosity class SAE 0W-20.

i) If the engine oils listed in the table are not available, you may add a maximum of 1.0 litre of the following engine oils once only.

Vehicles with petrol engines: MB-Freigabe or MB-Approval 229.31 or ACEA C3

Vehicles with diesel engines: ACEA C3

Engine oil filling quantity

Model	Capacity
All models	6.0 litres

The specified filling quantity refers to an oil change with the oil filter.

Notes on brake fluid

Observe the notes on operating fluids $(\rightarrow page 632)$.



WARNING Risk of an accident due to vapour pockets forming in the brake system

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point is too low, vapour pockets may form in the brake system when the brakes are applied hard.

This impairs the braking effect.

Have the brake fluid renewed at the specified intervals.

Have the brake fluid regularly replaced at a qualified specialist workshop.

Only use a brake fluid approved by Mercedes-Benz according to MB-Freigabe or MB-Approval 331.0.

Coolant

Notes on coolant

Observe the notes on operating fluids (\rightarrow page 632).

MARNING Risk of fire- and injury from antifreeze

If antifreeze comes into contact with hot component parts in the engine compartment, it may ignite.

- Allow the engine to cool down before you top up the antifreeze.
- Make sure that no antifreeze spills out next to the filler opening.
- Thoroughly clean the antifreeze from component parts before starting the vehicle.
- ! NOTE Damage caused by incorrect coolant
- Only use coolant that has been premixed with the required antifreeze protection.

Information on coolant is available at the following locations:

 In the Mercedes-Benz Specification for Operating Fluids 320.1

- At https://operatingfluids.mercedesbenz.com
- At a qualified specialist workshop
- NOTE Overheating at high outside temperatures

If an inappropriate coolant is used, the cooling system is not sufficiently protected against overheating and corrosion at high outside temperatures.

- Only use coolant approved for Mercedes-Benz.
- Observe the instructions in the Mercedes-Benz Specifications for Operating Fluids 320.1.

Have the coolant regularly replaced at a qualified specialist workshop.

Proportion of antifreeze concentrate in the cooling system:

 A minimum of 50% (antifreeze protection down to about -37°C) A maximum of 55% (antifreeze protection down to -45°C)

Notes on windscreen washer fluid

Observe the notes on operating fluids $(\rightarrow page 632)$.

WARNING - Risk of fire and injury due to windscreen washer concentrate

Windscreen washer concentrate is highly flammable. It could ignite if it comes into contact with hot engine component parts or the exhaust system.

- Make sure that no windscreen washer concentrate spills out next to the filler opening.
- ! NOTE Damage to the exterior lighting due to unsuitable windscreen washer fluid

Unsuitable windscreen washer fluids may damage the plastic surface of the exterior lighting.

- Only use windscreen washer fluids which are also suitable for use on plastic surfaces, e.g. MB SummerFit or MB WinterFit.
- ! NOTE Blocked spray nozzles caused by mixing windscreen washer fluids
- Do not mix MB SummerFit and MB WinterFit with other windscreen washer fluids.

Do not use distilled or de-ionised water. Otherwise, the fill level sensor may be triggered erroneously.

Recommended windscreen washer fluid:

- above freezing point: e.g. MB SummerFit
- below freezing point: e.g. MB WinterFit

For the correct mixing ratio, refer to the information on the antifreeze container.

Mix washer fluid with windscreen washer fluid all year round.

Vehicle data

Vehicle dimensions

The heights specified may vary as a result of the following factors:

- Tyres
- Load
- · Condition of the suspension
- · Optional equipment

Vehicle dimensions

All models	
Vehicle length	4949 mm
Vehicle width including exterior mirrors	2065 mm
Vehicle width excluding exterior mirrors	1904 mm
Wheelbase	2961 mm

Vehicle height

Model	Vehicle height
E 300	1469 mm
All other models	1468 mm

Weights and loads

Please observe the following notes for the specified vehicle data:

- · Items of optional equipment increase the unladen weight and reduce the payload.
- Vehicle-specific weight information can be found on the vehicle identification plate $(\rightarrow page 630)$.

Roof load

Model	Maximum roof load
All models	100 kg

Maximum design speeds

The maximum design speed can differ from the stated figures in practice. It depends on the operating conditions, the optional equipment and the size of the tyres.

Missing values were not yet available at the time of going to press.

Maximum design speed

Model	
All models	


Trailer hitch


General notes on the trailer hitch

Modifications to the cooling system may be necessary, depending on the vehicle model. The retrofitting of a trailer hitch is only permissible if a towing capacity is specified in your vehicle documents.

Further information can be obtained at a qualified specialist workshop.

Mounting dimensions





- Fastening points
- Overhang dimension
- Rear axle centre line

The overhang dimension and fastening points are valid for a trailer hitch installed at the factory.

Overhang dimension length

Model	Overhang dimension
All models	1245 mm

Towing capacity

The trailer drawbar noseweight is not included in the towing capacity. The values for the trailer load, braked trailer apply with a minimum start-off climbing ability of 12 %.

Missing values were not yet available at the time of going to press.

Towing capacity, braked

Model	
E 300	
All other models	2100 kg

Towing capacity, unbraked

Model	
E 300	
All other models	750 kg

Maximum trailer drawbar noseweight -and load capacity

NOTE Damage caused by the trailer coming loose

If the tongue weight used is too low, the trailer may come loose.

- The tongue weight must not be below 50 kg.
- Use a tongue weight that is as close as possible to the maximum permissible tongue weight.

- NOTE Damage caused by the bicycle rack coming loose

 When using a bicycle rack, both the maximal tongue weight and the maximal load capacity
 - Do not exceed the permissible load capacity.

Observe the additional notes on load capacity (\rightarrow page 300).

Missing values were not yet available at the time of going to press.

Trailer drawbar noseweight

should be observed.

Model	Maximum trailer draw- bar noseweight
E 300	
All other models	84 kg

Load capacity

All models	Maximum load capa- city
When attaching the bicycle rack to the ball head	75 kg
When attaching the bicycle carrier to the ball head and additionally to the guide pins	100 kg

Axle load when towing trailer

Model	Axle load
E 200	1462 kg
E 220 d	1500 kg
E 300	

Permissible rear axle load (trailer operation)

Missing values were not yet available at the time of going to press.

Display messages

Introduction

Information about display messages

Display messages appear on the driver's display.

Display messages with graphical symbols are simplified in the Owner's Manual and may differ from the symbols on the driver's display. The driver's display shows high-priority display messages in red. Certain display messages are accompanied by a warning tone.

Please act in accordance with the display messages and follow the additional notes in the Owner's Manual.

For some display messages, symbols will also be shown:

- (i) Further information
- Hide display message

With the left-hand Touch Control, you can select the respective symbol by swiping to the left or right. Pressing (i) displays further information on the central display. Press the x symbol to hide the display message.

Display messages to be acknowledged can be hidden by pressing the back button or with the left-hand Touch Control. The display messages will then be stored in the message memory.

Rectify the cause of a display message as quickly as possible.

High-priority display messages cannot be hidden. The driver's display will show these display messages continuously until the cause of the display message has been rectified.

Calling up saved display messages Driver's display:

¬→ Service

The Message memory: XX message appears on the driver's display.

- Scroll through the display messages by swiping upwards or downwards on the left-hand Touch Control.
- To exit the display: press the back button.

Occupant safety

Display messages



Restraint system malfunction Consult workshop

Possible causes/consequences and ▶ Solutions

* The restraint system is malfunctioning (\rightarrow page 40).

WARNING Risk of injury due to malfunctions in the restraint system

Components in the restraint system may be activated unintentionally or not deploy as intended in an accident.

▶ Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Recognition of a restraint system fault:

- the prestraint system warning lamp does not light up when the vehicle is switched on
- the prestraint system warning lamp lights up continuously or repeatedly during a journey
- Consult a qualified specialist workshop immediately.



WARNING Risk of injury due to malfunctions in the restraint system

Components in the restraint system may be activated unintentionally or not deploy as intended in an accident.

▶ Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Recognition of a restraint system fault:

• the prestraint system warning lamp does not light up when the vehicle is switched on



Front left malfunction Consult workshop

Display messages	Possible causes/consequences and ▶ Solutions	
	• the 🔭 restraint system warning lamp lights up continuously or repeatedly during a journey	
	Consult a qualified specialist workshop immediately.	
	* The restraint system is malfunctioning (\rightarrow page 40).	
	▲ WARNING Risk of injury due to malfunctions in the restraint system	
Front right malfunction Consult workshop	Components in the restraint system may be activated unintentionally or not deploy as intended in an accident. Have the restraint system checked and repaired immediately at a qualified specialist workshop.	
	Recognition of a restraint system fault:	
	• the 🔀 restraint system warning lamp does not light up when the vehicle is switched on	
	• the 🔭 restraint system warning lamp lights up continuously or repeatedly during a journey	
	Consult a qualified specialist workshop immediately.	
	* The restraint system is malfunctioning (\rightarrow page 40).	
	▲ WARNING Risk of injury due to malfunctions in the restraint system	
Second row of seats, left	Components in the restraint system may be activated unintentionally or not deploy as intended in an accident.	
Malfunction Consult work- shop	Have the restraint system checked and repaired immediately at a qualified specialist workshop.	

Display messages Possible causes/consequences and > Solutions Recognition of a restraint system fault: • the prestraint system warning lamp does not light up when the vehicle is switched on • the prestraint system warning lamp lights up continuously or repeatedly during a journey Consult a qualified specialist workshop immediately. * The restraint system is malfunctioning (\rightarrow page 40). **WARNING** Risk of injury due to malfunctions in the restraint system Components in the restraint system may be activated unintentionally or not deploy as intended in an accident. Second row of seats, right Malfunction Consult work-▶ Have the restraint system checked and repaired immediately at a qualified specialist workshop. shop Recognition of a restraint system fault: • the prestraint system warning lamp does not light up when the vehicle is switched on • the prestraint system warning lamp lights up continuously or repeatedly during a journey Consult a qualified specialist workshop immediately. * The restraint system is malfunctioning (\rightarrow page 40). WARNING Risk of injury or fatal injury due to a malfunction in the windowbag The windowbag might be triggered unintentionally or might not be triggered at all in the event of an accident. Left window airbag malfunction Consult workshop

Display messages	Possible causes/consequences and ▶ Solutions
	► Have the windowbag checked and repaired immediately at a qualified specialist workshop.
	Consult a qualified specialist workshop immediately.
	* The restraint system is malfunctioning (\rightarrow page 40).
	▲ WARNING Risk of injury or fatal injury due to a malfunction in the windowbag
Right window airbag mal-	The windowbag might be triggered unintentionally or might not be triggered at all in the event of an accident.
function Consult workshop	Have the windowbag checked and repaired immediately at a qualified specialist workshop.
	Consult a qualified specialist workshop immediately.
Front passenger airbag dis- abled See Owner's Manual	* The front passenger airbag has been disabled even though an adult or a person of adult build is on the front passenger seat. If additional forces are applied to the seat, the weight the system detects may be too low.
	WARNING - Risk of injury or even fatal injury when the front passenger airbag is disabled
	If the front passenger airbag is disabled, It will not be deployed in the event of an accident and cannot perform its intended protective function.
	A person in the front passenger seat could then, for example, come into contact with the vehicle interior, especially if the person is sitting too close to the dashboard.
	▶ Be aware of the status of the front passenger airbag both before and during the journey.

Display messages	Possible causes/consequences and ▶ Solutions
	 Stop the vehicle immediately in accordance with the traffic conditions. Make sure that no objects are trapped under the front passenger seat. Check the status of the automatic front passenger airbag shutoff (→ page 49). If necessary, consult a qualified specialist workshop immediately.
Front passenger airbag enabled See Owner's Manual	 * The front passenger airbag will be enabled while the vehicle is in motion in the following situations: even when a child, a small adult or an object weighing less than the system weight threshold is located on the front passenger seat even when the front passenger seat is not occupied The system may detect objects or forces that are adding to the weight applied to the seat.
	 WARNING Risk of injury or death when using a child restraint system while the front passenger airbag is enabled If you secure a child in a child restraint system on the front passenger seat and the front passenger airbag is enabled, the front passenger airbag can deploy in the event of an accident. The child could be struck by the airbag. ▶ Ensure, both before and during the journey, that the status of the front passenger airbag is correct. NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.

Display messages	Possible causes/consequences and ▶ Solutions
	Stop the vehicle immediately in accordance with the traffic conditions.
	Make sure that no objects are trapped under the front passenger seat.
	\blacktriangleright Check the status of the automatic front passenger airbag shutoff (\rightarrow page 49).
	If necessary, consult a qualified specialist workshop immediately.
Occupant presence reminder inoperative	 * The occupant presence reminder is malfunctioning Consult a qualified specialist workshop.
**	* The occupant presence reminder suspects that there are persons or animals in the rear of the vehicle. Do not leave any persons or animals behind when leaving the vehicle.
Do not leave persons or animals in the vehicle	

Display messages	Possible causes/consequences and ▶ Solutions
Replace key	 * Have the key replaced. Consult a qualified specialist workshop.
Change key batteries	 * The key battery is discharged. ▶ Replace the battery (→ page 78).
Key not detected (white display message)	 * The key is currently undetected. Change the location of the key in the vehicle. Try to start the vehicle. If the key is still not detected, place it in the slot for starting with the key (→ page 185). Start the vehicle.

Display messages	Possible causes/consequences and ▶ Solutions
Key not detected (red display message)	 * The key can no longer be detected during a journey and may no longer be in the vehicle. If the key is no longer in the vehicle and you switch off the vehicle: You can no longer start the vehicle. You cannot centrally lock the vehicle. Ensure that the key is in the vehicle. If the key is in the vehicle and is still not detected: Stop the vehicle immediately in accordance with the traffic conditions. Place the key in the slot for starting the engine with the key (→ page 185). The key battery is weak or discharged. Check the battery using the indicator lamp (→ page 76). Replace the key battery, if necessary (→ page 78).
Key being taught in Please wait	* The vehicle is processing in order to teach in the new key. • Wait until processing is complete.

Display messages	Possible causes/consequences and ▶ Solutions
Place the key in the marked space See Owner's Manual	 * Key detection is malfunctioning. ➤ Change the location of the key in the vehicle. ➤ Place the key in the slot for starting the engine with the key (→ page 185).
Please place key in the cup holder or Digital Vehicle Key in inductive charging bracket See Owner's Man- ual	 * The key was not detected. ▶ Place the key in the stowage compartment (→ page 185). If the key is still not detected: ▶ Consult a qualified specialist workshop. * The Digital Vehicle Key has not been detected. ▶ Place the Digital Vehicle Key in the stowage space (→ page 183). If the Digital Vehicle Key is still not detected: ▶ Consult a qualified specialist workshop.
(Rey not detected	 * The key or the Digital Vehicle Key is currently undetected. ▶ Change the location of the key or the Digital Vehicle Key in the vehicle. ▶ Try to start the vehicle. ▶ If the key is still not detected, place the key in the stowage compartment (→ page 185). ▶ If the Digital Vehicle Key is still not detected, place the Digital Vehicle Key in the stowage space (→ page 183). ▶ Start the vehicle.



Key not detected Place Digital Vehicle Key in inductive charging bracket

Possible causes/consequences and > Solutions

- * The key or the Digital Vehicle Key are no longer detected during a journey and may no longer be in the vehicle. If the key or the Digital Vehicle Key is no longer in the vehicle and you switch off the vehicle:
 - You can no longer start the vehicle.
 - · You cannot centrally lock the vehicle.
 - Ensure that the key or the Digital Vehicle Key is in the vehicle.

If the key or the Digital Vehicle Key is in the vehicle and is still not detected:

- Stop the vehicle immediately in accordance with the traffic conditions.
- Place the key in the stowage compartment (\rightarrow page 185).
- Place the Digital Vehicle Key in the stowage space (\rightarrow page 183).

The key battery is weak or discharged.

- Check the battery using the indicator lamp (\rightarrow page 76).
- Replace the key battery, if necessary (\rightarrow page 78).

The charge status of the rechargeable battery of the end device with the Digital Vehicle Key is too low.

Immediately charge the rechargeable battery of the Digital Vehicle Key end device.

Otherwise, it may not be possible to restart the vehicle after it has been switched off. If the key or the Digital Vehicle Key is still not detected:

Display messages	Possible causes/consequences and ▶ Solutions
	Consult a qualified specialist workshop.
Replace key See Owner's Manual	* If the Digital Vehicle Key is not renewed, the vehicle cannot be unlocked/locked or started. The system automatically renews the Digital Vehicle Key. When the renewal is complete, the message disappears and the Digital Vehicle Key is available again.
Do not forget key	* A warning tone will also sound. This message reminds you to take your key with you when you leave the vehicle. This also applies to the Digital Vehicle Key.
Digital Vehicle Key Charge device	* The charge status of the rechargeable battery of the end device with the Digital Vehicle Key is too low. Immediately charge the rechargeable battery of the Digital Vehicle Key end device.

Display messages Possible causes/consequences and ▶ Solutions * The vehicle is processing in order to teach in the new Digital Vehicle Key. ▶ Wait until processing is complete. * The vehicle cannot be unlocked/locked or started. ▶ Use the Digital Vehicle Key belonging to the vehicle. Key does not belong to vehicle

Lights

Display messages



Malfunction See Owner's Manual

Possible causes/consequences and ▶ Solutions

- * The exterior lighting is malfunctioning.
 - Consult a qualified specialist workshop.
- * Vehicles with a trailer hitch: a fuse may have blown.
 - Stop the vehicle in accordance with the traffic conditions.
 - \rightarrow Check the fuses and replace them if necessary (\rightarrow page 505).

Display messages	Possible causes/consequences and ▶ Solutions
- <u>;</u> Ö-	 * The light sensor for automatic driving lights is malfunctioning. Consult a qualified specialist workshop.
Automatic driving lights inoperative	
\ <u>\</u>	* You are driving without low-beam headlamps.
<u>-Ò-</u>	► Turn the light switch to the ☑ or • position.
Switch on headlamps	
Switch off lights	* You are leaving the vehicle and the lights are still switched on. Turn the light switch to the AUTO position.
DIGITAL LIGHT Functions limited	* The DIGITAL LIGHT system is malfunctioning. The lighting system will continue to work even without the functions of the DIGITAL LIGHT system. Consult a qualified specialist workshop.
Check low beam setting (left/right-side traffic)	 * The type of traffic has been selected manually. ▶ Check the setting and change it manually if necessary (→ page 158).

Display messages	Possible causes/consequences and ▶ Solutions
Low beam setting (left/right-side traffic) Manual adjustment only	 * The automatic headlamp conversion for left-hand/right-hand traffic has malfunctioned. ▶ Change the headlamps over manually (→ page 158).
Adaptive Highbeam Assist currently unavailable See Owner's Manual	 * Adaptive Highbeam Assist is temporarily unavailable. The system limits have been reached (→ page 155). Once the cause of the problem is no longer present, the system will be available again. The Adaptive Highbeam Assist available again display message will appear. Drive on Operate the high beam manually until Adaptive High Beam Assist is available again.
Adaptive Highbeam Assist inoperative	 * Adaptive Highbeam Assist is malfunctioning. Drive on or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop. Until then, operate the high beam manually.
Adaptive Highbeam Assist Plus currently unavailable See Owner's Manual	* Adaptive Highbeam Assist Plus is temporarily unavailable. The system limits have been reached (→ page 156). Once the cause of the problem is no longer present, the system will be available again. The Adaptive Highbeam Assist Plus available again display message will appear.

Display messages	Possible causes/consequences and ▶ Solutions
	Drive onOperate the high beam manually until Adaptive High Beam Assist Plus is available again.
Adaptive Highbeam Assist Plus inoperative	* Adaptive Highbeam Assist Plus is malfunctioning. Drive on or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop. Until then, operate the high beam manually.
Hazard warning lamp system Malfunction	 * The hazard warning lamp switch is malfunctioning. Consult a qualified specialist workshop.
Front left parking lights	* The front left parking light is malfunctioning. Consult a qualified specialist workshop.
Front right parking lights	* The front right parking light is malfunctioning. Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Left low beam	* The left low beam is malfunctioning. Consult a qualified specialist workshop.
Right low beam	* The right low beam is malfunctioning. Consult a qualified specialist workshop.
Left main beam	* The left high beam is malfunctioning. Consult a qualified specialist workshop.
Right main beam	* The right high beam is malfunctioning. ▶ Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Left daytime running lights	 * The left daytime running lights are malfunctioning. Consult a qualified specialist workshop.
Left daytime running lights	* The sight hand doubles associated take one walf or attention
- Ö-	 * The right-hand daytime running lights are malfunctioning. Consult a qualified specialist workshop.
Right daytime running lights	
- <u>'</u> Ö-	 * The left cornering light is malfunctioning. Consult a qualified specialist workshop.
Left cornering light	
Right cornering light	 * The right cornering light is malfunctioning. Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Front left turn signal	* The front left turn signal lamp is malfunctioning. Consult a qualified specialist workshop.
Rear left turn signal	* The rear left turn signal lamp is malfunctioning. Consult a qualified specialist workshop.
Front right turn signal	* The front right turn signal lamp is malfunctioning. Consult a qualified specialist workshop.
Rear right turn signal	* The rear right turn signal lamp is malfunctioning. Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Left mirror turn signal	 * The turn signal lamp on the left mirror is malfunctioning. Consult a qualified specialist workshop.
Right mirror turn signal	 * The turn signal lamp on the right mirror is malfunctioning. Consult a qualified specialist workshop.
Left brake lamp	* The left brake light is malfunctioning. Consult a qualified specialist workshop.
Right brake lamp	 * The right brake light is malfunctioning. Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Third brake lamp	* The third brake light is malfunctioning. Consult a qualified specialist workshop.
Left tail light	* The left tail light is malfunctioning. ▶ Consult a qualified specialist workshop.
Right tail light	* The right tail light is malfunctioning. Consult a qualified specialist workshop.
Reversing light	* The reversing light is malfunctioning. Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Rear fog light	 * The rear fog light is malfunctioning. Consult a qualified specialist workshop.
Number plate lamp	* The number plate lamp is malfunctioning. Consult a qualified specialist workshop.
Trailer left turn signal	 * The left turn signal lamp on the trailer is malfunctioning. E Consult a qualified specialist workshop.
Trailer right turn signal	 * The right turn signal lamp on the trailer is malfunctioning. Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Trailer brake lamp	 * The brake light on the trailer is malfunctioning. Consult a qualified specialist workshop.
Trailer tail light	* A tail light on the trailer is malfunctioning. Consult a qualified specialist workshop.
Inoperative indicator lamp in driver display. Consult workshop	 * An indicator lamp on the driver's display is defective. Consult a qualified specialist workshop.

Climate control

Display messages	Possible causes/consequences and ▶ Solutions
inoperative See Owner's Man. (stationary heater)	 * The stationary heater is temporarily malfunctioning. When the vehicle is stationary on a level surface and the engine has cooled down, make up to four attempts to switch on the stationary heater, waiting several minutes between each attempt. If the stationary heater does not switch on, consult a qualified specialist workshop.
Currently unavailable Outside temperature too high	* The stationary heater cannot be activated if the outside temperature is above 15°C.
Currently unavailable Battery low	 * The on-board electrical system voltage is too low. The stationary heater has switched itself off. Drive an extended distance until the battery has reached a sufficient charge level again.



Currently unavailable Refuel

Possible causes/consequences and ▶ Solutions

- * There is too little fuel in the fuel tank. The stationary heater cannot be switched on.
 - Refuel the vehicle.

Vehicle


Display messages



Possible causes/consequences and ▶ Solutions

* The driver's display is inoperative due to a failed software update.

The display message will be shown every time the engine is started.



If the driver display has failed or is malfunctioning, function restrictions in systems relevant to safety cannot be detected.

The operating safety of your vehicle may be impaired.

- Drive on carefully.
- ► Have the vehicle checked immediately at a qualified specialist workshop.

If the operating safety of your vehicle is impaired, park the vehicle immediately and safely. Contact a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
	If the driver's display fails, you may not recognise function restrictions affecting systems relevant to safety or the speed display, for example. The operating safety of the vehicle may be impaired (→ page 361). ► Have the vehicle checked by a qualified specialist workshop immediately.
Vehicle is ready to drive Shutdown occurs when locked or automatically in a few minutes	* You are leaving the vehicle in a ready-to-drive state. Get out of the vehicle, secure it against rolling away and take the key with you. If you do not leave the vehicle, switch off the electrical consumers, e.g. the seat heating. Otherwise, the 12-V battery may discharge and starting the engine may be possible only with the help of a second battery (jump start).
Vehicle is ready to drive Shutdown occurs when locked or automatically in XX mins	 * You are about to leave the vehicle and the engine is running. The vehicle will switch off automatically in 20 minutes. To prevent the vehicle from switching off automatically, confirm the message in the central display of the multimedia system. * You are in the vehicle. Park position P is engaged and the engine is running. After ten minutes, this display message appears in the driver display. The vehicle is switched off automatically after a further ten minutes. To prevent the vehicle from switching off automatically, confirm the message in the central display of the multimedia system.

Display messages	Possible causes/consequences and ▶ Solutions
	▶ Initiate a new swivel movement (\rightarrow page 295).
	▶ When the display message disappears, couple up the trailer and drive on.
	If the display message does not disappear, the trailer hitch is malfunctioning and the ball neck is not locked.
	Do not couple up the trailer. Drive on without the trailer. Note the reduced ground clearance due to the unlocked ball neck.
	Consult a qualified specialist workshop.
	* When the vehicle is stationary with a coupled trailer, the trailer hitch is not operational.
	Uncouple the coupled trailer and secure it against rolling away.
	If the ball neck has been retracted: initiate a new swivel movement (→ page 295). The ball neck will engage vertically in the locked position and then engage beneath the bumper.
	If the ball neck has been extended: initiate a new swivel movement (→ page 295). The ball neck will engage beneath the bumper.
	If the display message does not disappear, the trailer hitch is malfunctioning and the ball neck is not locked.
	Do not couple up the trailer. Drive on without the trailer. Note the reduced ground clearance due to the unlocked ball neck.
	Consult a qualified specialist workshop.
	ball neck.



Trailer coupling Check lock(red display message)

Possible causes/consequences and > Solutions

* The trailer hitch is not operational during a journey with a trailer.

WARNING Risk of an accident if the ball neck is not locked

The trailer may become detached.

- > Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.
- Uncouple the trailer and secure it against rolling away.
- Initiate a new swivelling procedure and do not re-couple the trailer until the display message disappears.
- Stop immediately in accordance with the traffic conditions and switch off the vehicle.
- Uncouple the trailer and secure it against rolling away.
- Initiate a new swivel movement (\rightarrow page 295).
- When the display message disappears, couple up the trailer and drive on.

If the display message does not disappear, the trailer hitch is malfunctioning and the ball neck is not locked.

- Do not couple up the trailer. Drive on without the trailer. Note the reduced ground clearance due to the unlocked ball neck.
- Consult a qualified specialist workshop.
- * When the vehicle is stationary with a coupled trailer, the trailer hitch is not operational.
 - Uncouple the coupled trailer and secure it against rolling away.

Display messages	Possible causes/consequences and ▶ Solutions
	 If the ball neck has been retracted: initiate a new swivel movement (→ page 295). The ball neck will engage vertically in the locked position and then engage beneath the bumper. If the ball neck has been extended: initiate a new swivel movement (→ page 295). The ball neck will engage beneath the bumper. If the display message does not disappear, the trailer hitch is malfunctioning and the ball neck is not locked.
	 Do not couple up the trailer. Drive on without the trailer. Note the reduced ground clearance due to the unlocked ball neck. Consult a qualified specialist workshop.
Please teach in trailer cou- pling again using the but- ton in load compartment Wait for it to extend/ retract	* The swivel movement of the trailer hitch is impaired. Use the button on the boot lid to trigger a new, complete swivel movement until the ball neck engages beneath the bumper.
Head-up display currently unavailable See Owner's Manual	 * The head-up display is temporarily unavailable. Possible causes: • malfunctions in the power supply • signal interference Stop in accordance with the traffic conditions and switch the vehicle off and on again. If the display message still appears, consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Head-up display inoperative	 * The head-up display has an internal error. Consult a qualified specialist workshop.
Head-up display Brightness currently reduced See Own- er's Manual	 * The brightness of the head-up display is reduced. Possible causes: Dirt on the windscreen in the camera's field of vision Faulty exterior brightness signals Switch on the windscreen wipers. Clean the windscreen if necessary. Switch the vehicle off and switch it back on If the display message still appears, consult a qualified specialist workshop.
Steering malfunction Drive carefully Visit workshop	 * A power steering malfunction has occurred. Steering characteristics may be impaired as a result. Drive on carefully. Consult a qualified specialist workshop.



Steering malfunction Increased physical effort See Owner's Manual

Possible causes/consequences and > Solutions

* The power steering assistance is malfunctioning.

WARNING Risk of an accident due to altered steering characteristics

If the power assistance of the steering fails partially or completely, you will need to use more force to steer.

- If safe steering is possible, drive on carefully.
- Visit or consult a qualified specialist workshop immediately.
- If safe steering is possible, drive on carefully.
- Visit or consult a qualified specialist workshop immediately.
- * The steering is malfunctioning. Steering capability is significantly impaired.

Steering malfunction Stop immediately See Owner's Manual

▲ WARNING Risk of accident if steering capability is impaired

If the steering does not function as intended, the vehicle's operating safety is jeopardised.

- > Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- Consult a qualified specialist workshop.
- Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.
- Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Rear axle steering currently malfunctioning	 * The rear-axle steering is temporarily unavailable. The turning circle may become wider. Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: Drive on carefully. Consult a qualified specialist workshop.
Rear axle steering Malfunction Visit workshop	 * The rear axle steering is malfunctioning. The rear axle has no steering capability. The steering wheel may be at an angle when you drive in a straight line. Adapt your speed and drive on carefully. Consult a qualified specialist workshop immediately.
Rear axle steering Malfunction Stop immediately	* The rear axle steering is malfunctioning. The rear axle has no steering capability. The steering wheel may be tilted considerably when you drive in a straight line. Depending on the steering wheel's tilted position, the steering wheel will also vibrate and a continuous warning tone will sound.
	WARNING Risk of accident if steering capability is impaired If the steering does not function as intended, the vehicle's operating safety is jeopardised.

Display messages	Possible causes/consequences and ▶ Solutions
	 Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Consult a qualified specialist workshop.
	 Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving. When stopping, bear the enlarged vehicle width in mind. Consult a qualified specialist workshop.
Snow chain mode Maximum speed exceeded	 * The maximum permissible speed for snow chain mode has been exceeded. Drive more slowly.
Active bonnet malfunction See Owner's Manual	* The active bonnet (pedestrian protection) is malfunctioning or inoperative after having already been triggered. Consult a qualified specialist workshop.
Ambient light warning support inoperative	 * The ambient lighting may not provide full visual warning support. Lock the vehicle and unlock it again after a few minutes. If the display message appears regularly, contact a qualified specialist workshop.
	* At least one door is open. Close all doors.

Display messages	Possible causes/consequences and ▶ Solutions
	* The boot lid is open.
	▲ DANGER Risk of exhaust gas poisoning
	Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the boot lid is open when the engine is running, especially if the vehicle is in motion.
	Always switch off the engine before opening the boot lid.
	Never drive with the boot lid open.
	Close the boot lid.
← n	* The seat backrest of the corresponding seat is not engaged.
	Fold the seat backrest back until it engages.
Rear left seat backrest not locked	
← 0	* The seat backrest of the corresponding seat is not engaged.
	Fold the seat backrest back until it engages.
Rear right seat backrest not locked	

Display messages	Possible causes/consequences and ▶ Solutions
Top up washer fluid	 * The washer fluid level in the washer fluid reservoir has dropped below the minimum. ▶ Top up the washer fluid (→ page 476).
Wiper Malfunction	 * The windscreen wiper is malfunctioning. ▶ Restart the vehicle. If the display message still appears: ▶ Consult a qualified specialist workshop.

Engine

Display messages	Possible causes/consequences and ▶ Solutions
To switch off the vehicle, press the Start/Stop button for at least 3 seconds or 3 times	 You have pressed the start/stop button while the vehicle is in motion. ▶ Information about switching off the vehicle while driving (→ page 182).
Cannot start vehicle See Owner's Manual	* The vehicle cannot be started. Switch the vehicle off and switch it back on

Display messages	Possible causes/consequences and ▶ Solutions
	If the display message still appears, consult a qualified specialist workshop.
	* The coolant level is too low.
1	NOTE Engine damage due to insufficient coolant
Top up coolant See Owner's Manual	Avoid long journeys with insufficient coolant.
	► Add coolant (→ page 475).
	▶ Have the engine cooling system checked at a qualified specialist workshop.
	* The coolant is too hot. Stop immediately in accordance with the traffic conditions and switch off the vehicle.
Coolant Stop Switch off	▲ WARNING Risk of burns when opening the bonnet
the vehicle	If you open the bonnet in the event of an overheated engine or fire in the engine compartment, the following situations may occur:
	You may come into contact with hot gases.
	You may come into contact with other escaping hot operating fluids.
	▶ Before opening the bonnet, allow the engine to cool down.
	In the event of a fire in the engine compartment, keep the bonnet closed and call the fire service.

Display messages	Possible causes/consequences and ▶ Solutions
	 Wait until the engine has cooled down. Make sure that the air supply to the radiator is not obstructed. Avoiding high loads on the engine, drive to the nearest qualified specialist workshop. In doing so, ensure that the coolant temperature display remains below 120°C.
**	 * There is a malfunction in the engine cooling system. Avoiding high loads on the engine, drive to the nearest qualified specialist workshop. In doing so, ensure that the coolant temperature display remains below 120°C.
Reserve fuel level	* The fuel supply has dropped into the reserve range. Refuel.
Clean the fuel filter	* Vehicles with diesel engines: the fuel filter is dirty or the water in the fuel filter needs to be drained. Consult a qualified specialist workshop.

Replace air filter

Possible causes/consequences and ▶ Solutions

- * Vehicles with diesel engines: the engine air filter is dirty and must be replaced.
 - Consult a qualified specialist workshop.

Transmission

Display messages	Possible causes ∕ consequences and ► Solutions
Only select P when vehicle is stationary	 * It is possible to select the park position P only if the vehicle is stationary. Depress the brake pedal to stop. Shift the transmission to park position P when the vehicle is stationary.
Apply brake to deselect P position	 You have attempted to shift the transmission out of park position P and into another transmission position. Depress the brake pedal. Select transmission position D, R or neutral N.
Apply brake and start vehicle to shift out of P or N	 You have attempted to shift the transmission out of park position P or neutral N and into another transmission position. Depress the brake pedal. Start the vehicle.

Display messages	Possible causes/consequences and ▶ Solutions
	► Change the transmission position.
Apply brake to engage D or R	 You have attempted to select transmission position
Apply brake to engage R	 You have attempted to select transmission position R. Depress the brake pedal. Select transmission position R.
Apply parking brake to park Visit workshop	 * A malfunction has occurred in the emergency power supply to park position P. Consult a qualified specialist workshop. Until then, always select park position P manually before you switch off the vehicle. Before leaving the vehicle, apply the electric parking brake.
Risk of vehicle rolling away Driver's door open Trans- mission not in P	 * The driver's door is not fully closed and transmission position D, R or neutral N is selected. The vehicle may roll away. Select park position P when switching off the vehicle.
Risk of vehicle rolling away Apply parking brake to park	 * The transmission is malfunctioning. Park position P cannot be selected. Park the vehicle safely. Use the electric parking brake to secure the vehicle against rolling away.

Display messages	Possible causes/consequences and ▶ Solutions
	On gradients, turn the front wheels so that the vehicle will roll towards the kerb if it starts moving.
Risk of vehicle rolling away N activated manually No automatic switch to P	* While the vehicle was at a standstill or driving at very low speed, neutral N was engaged with the engine running or the vehicle switched on.
datomatio owitom to i	NOTE Damage to the vehicle due to rolling away
	When the vehicle is switched off or the driver's door is opened, automatic engagement of park position P is deactivated.
	The vehicle may roll away.
	Be ready to brake.
	▶ Do not leave the vehicle unattended.
	Depress the brake pedal until the vehicle comes to a standstill.
	► Engage park position P when the vehicle is stationary with the brake pedal depressed.
	► To continue driving with the brake pedal depressed, select transmission position D or R .
N automatically activated Please engage transmis- sion position again	* Neutral N was automatically engaged when the vehicle was rolling or being driven.
	i) When you open the driver's door in neutral N, park position P will be engaged automatically.
	► Engage park position P when the vehicle is stationary with the brake pedal depressed.
	► To continue driving with the brake pedal depressed, select transmission position D or R .

Display messages	Possible causes/consequences and ▶ Solutions
N is selected Please select desired transmission position	* The accelerator pedal was depressed while the vehicle was rolling or moving in neutral N. To accelerate the vehicle, select transmission position D or R.
Reversing not poss. Consult workshop	 * The transmission is malfunctioning. It is not possible to select transmission position ▶ Consult a qualified specialist workshop.
Transmission Malfunction Stop	 * The transmission is malfunctioning. The transmission shifts to neutral N automatically. Stop the vehicle immediately in accordance with the traffic conditions. Depress the brake pedal. Engage park position P. Consult a qualified specialist workshop.
Consult workshop without changing the transmission position	 * The transmission is malfunctioning. It is no longer possible to change the transmission position. If transmission position
Auxiliary battery malfunction (white display message)	 * There is a malfunction in the auxiliary battery. Consult a qualified specialist workshop. Until then, always select park position P manually before you switch off the vehicle.

Display messages	Possible causes/consequences and ▶ Solutions
	Before leaving the vehicle, apply the electric parking brake.
Auxiliary battery malfunction (red display message)	 * There is a malfunction in the auxiliary battery. Consult a qualified specialist workshop. Until then, always select park position P manually before you switch off the vehicle. Before leaving the vehicle, apply the electric parking brake.

Brakes

Possible causes/consequences and ➤ Solutions * The yellow (②) indicator lamp is lit. The electric parking brake is malfunctioning. To apply: Switch the vehicle off and switch it back on Apply the electric parking brake manually (→ page 212). If it is not possible to apply the electric parking brake: Consult a qualified specialist workshop. Where necessary, also secure the parked vehicle against rolling away. * The yellow (③) indicator lamp and the red (⑤) indicator lamp are lit. The electric parking brake is malfunctioning. To release:

Display messages	Possible causes/consequences and ▶ Solutions
	* The yellow place indicator lamp is lit and the red place indicator lamp flashes for approximately ten seconds after the electric parking brake has been applied or released. It then remains lit or goes out. The electric parking brake is malfunctioning.
	If the state of charge is too low:
	Charge the 12 V battery.
	To apply:
	Apply the electric parking brake manually.
	If it is not possible to apply the electric parking brake:
	Consult a qualified specialist workshop.
	Where necessary, also secure the parked vehicle against rolling away.
	To release:
	If the conditions for automatic release are fulfilled and the electric parking brake is not released automatically, release the electric parking brake manually (→ page 212).
	If it is still not possible to release the electric parking brake:
	Do not continue driving. Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Release parking brake	 * The red indicator lamp is flashing. The electric parking brake is applied while you are driving: • A condition for automatic release of the electric parking brake has not been fulfilled (→ page 212). • You are performing emergency braking using the electric parking brake (→ page 213).
	Check the conditions for automatic release of the electric parking brake.Release the electric parking brake manually.
Parking brake Switch on vehicle to release	* The red (n) indicator lamp is lit. You have attempted to release the electric parking brake with the vehicle switched off. Switch on the vehicle.
Brake immediately	* A malfunction has occurred while the HOLD function was activated. A horn may also sound at regular intervals. You cannot start the vehicle system. Immediately depress the brake pedal firmly until the display message disappears. You cannot start the vehicle system again.



Malfunction See Owner's Manual

Possible causes/consequences and > Solutions

* The brake force boosting function is impaired. Hill Start Assist may be impaired.

WARNING Risk of an accident due to a brake system malfunction

If the brake system is malfunctioning, braking characteristics may be impaired.

- Drive on carefully.
- ► Have the brake system checked immediately at a qualified specialist workshop.
- Adjust your speed and drive on carefully, leaving a suitable distance to the vehicle in front.
- Consult a qualified specialist workshop.
- * The brake force boosting function is impaired and the braking characteristics may be affected.

WARNING Risk of accident and injury if brake force boosting is malfunctioning

If brake force boosting is malfunctioning, increased brake pedal force may be necessary for braking. The braking characteristics may be impaired. The braking distance can increase in emergency braking situations.

- Stop in a safe location immediately. Do not continue driving!
- Consult a qualified specialist workshop.
- Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving.
- Consult a qualified specialist workshop.



Malfunction Stop vehicle

Display messages Possible causes/consequences and > Solutions * There is insufficient brake fluid in the brake fluid reservoir. WARNING Risk of an accident due to low brake fluid level If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired. Check brake fluid level Stop the vehicle as soon as possible, paying attention to road and traffic conditions. Do not continue driving. Consult a qualified specialist workshop. Do not top up the brake fluid. Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving. Do not top up the brake fluid. Consult a qualified specialist workshop. Check brake pads See The brakepads have reached the wear limit. Owner's Manual Consult a qualified specialist workshop.

Driving and driving safety systems

Display messages



currently unavailable See Owner's Manual (ABS and ESP®)

Possible causes/consequences and ▶ Solutions

* ABS and ESP® are temporarily unavailable.

Other driving systems and driving safety systems (e.g. BAS) may also be temporarily unavailable.

The brake system will continue to operate normally. Braking distance may increase in an emergency braking situation.

WARNING Risk of skidding if ABS and ESP® are malfunctioning

The wheels may lock during braking and ESP[®] does not perform any vehicle stabilisation.

The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.

- ▶ Drive carefully on a suitable stretch of road, making slight steering movements at a speed above 30 km/h.
- If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully.
- Drive carefully on a suitable stretch of road, making slight steering movements at a speed above 30 km/h.
- If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully.



Manual (ABS and ESP®)

Possible causes/consequences and > Solutions

* ABS and ESP® are malfunctioning.

Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.

The brake system will continue to operate normally. Braking distance may increase in an emergency braking situation.

WARNING Risk of skidding if ABS and ESP® are malfunctioning

The wheels may block during braking and ESP® does not perform any vehicle stabilization.

The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- ► Have ABS and ESP® checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Consult a qualified specialist workshop immediately.
- * ESP® is temporarily unavailable.

Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.


MARNING Risk of skidding if ESP is malfunctioning®

If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilisation. In addition, other driving safety systems are switched off.



Display messages	Possible causes/consequences and ▶ Solutions
	 Drive carefully on a suitable stretch of road, making slight steering movements at a speed above 30 km/h. If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully.
	 Drive carefully on a suitable stretch of road, making slight steering movements at a speed above 30 km/h. If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully.
inoperative See Owner's Manual (ESP®)	* ESP® is malfunctioning. Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning. The brake system will continue to operate normally. Braking distance may increase in an emergency braking situation.
	MARNING Risk of skidding if ESP® is malfunctioning If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilisation. In addition, other driving safety systems are
	switched off.
	 Drive on carefully. Have ESP[®] checked at a qualified specialist workshop.
	► Drive on carefully.
	Consult a qualified specialist workshop immediately.

Display messages inoperative See Owner's Manual (EBD, ABS and ESP®)



* EBD, ABS and ESP® are malfunctioning.

Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning.

WARNING Risk of skidding if EBD, ABS and ESP® are malfunctioning

The wheels may block during braking and ESP® does not perform any vehicle stabilization.

The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Consult a qualified specialist workshop immediately.
- * The HOLD function is deactivated because the vehicle is slipping or a condition for activation is not fulfilled.
- Reactivate the HOLD function later or check the activation conditions for the HOLD function (\rightarrow page 220).



Display messages	Possible causes/consequences and ▶ Solutions
ATTENTION ASSIST: Take a break!	 * ATTENTION ASSIST has detected fatigue or an increasing lack of concentration on the part of the driver (→ page 222). ▶ If necessary, take a break.
ATTENTION ASSIST Microsleep Take a break!	 * ATTENTION ASSIST has detected indicators of microsleep (→ page 222). A warning tone will also sound. ▶ Take a break. ▶ Press the left-hand Touch Control and acknowledge the display message.
ATTENTION ASSIST Remain alert! (white display message)	 * ATTENTION ASSIST has detected that the driver is looking away from the traffic situation (→ page 222). A warning tone will also sound. ▶ Look back at the traffic situation.
ATTENTION ASSIST Remain alert! (yellow dis- play message)	 * ATTENTION ASSIST has detected that the driver is not looking at the traffic situation after the warning has been issued (→ page 222). A continuous warning tone will also sound. Immediately return your gaze to the traffic situation. Press the left-hand Touch Control and acknowledge the display message.

Display messages	Possible causes/consequences and ▶ Solutions
	If the driver still does not react to the warning, an emergency stop can be initiated by the system (\rightarrow page 239).
km/h	 * Cruise control cannot be activated as not all activation conditions are fulfilled. ▶ Observe the activation conditions for cruise control (→ page 225).
Cruise control inoperative	* Cruise control is malfunctioning. Consult a qualified specialist workshop.
Cruise control and Limiter inoperative	 * Cruise control and the limiter are malfunctioning. Consult a qualified specialist workshop.
Cruise control off	* Cruise control has been deactivated. If there is an additional warning tone, cruise control has been deactivated automatically (→ page 224).
LIM km/h	* The limiter can temporarily not be engaged. Once the cause of the problem is no longer present, the system will be available again.

Display messages	Possible causes/consequences and ▶ Solutions
LIM passive	* If you depress the accelerator pedal beyond the point of resistance (kickdown), the limiter will be switched to passive mode (→ page 225).
Limiter inoperative	* The limiter is malfunctioning.
	Consult a qualified specialist workshop.
Speed limit (winter tyres) XXX km/h	* You have reached the maximum permissible stored speed for winter tyres. It is not possible to exceed this speed.
120 km/h!	* You have exceeded the maximum permissible speed (for certain countries only). Drive more slowly.
·	* Casad Limit Assist is temperarily uppysitable
Speed Limit Assist cur- rently unavailable See Own- er's Manual	* Speed Limit Assist is temporarily unavailable. Drive on
	Once the cause of the problem is no longer present, the system will be available again.
Speed Limit Assist inoperative	* Speed Limit Assist is malfunctioning.
	▶ Drive on
	or

Display messages	Possible causes/consequences and ▶ Solutions
	 Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
Traffic Sign Assist currently unavailable See Owner's Manual	 * Traffic Sign Assist is temporarily unavailable. Once the cause of the problem is no longer present, the system will be available again. Continue driving in compliance with the traffic regulations.
Traffic Sign Assist inoperative	 * Traffic Sign Assist is malfunctioning. Continue driving in compliance with the traffic regulations. or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
Fault Drive at max. 80 km/h	* AIRMATIC is functioning only to a limited extent. The vehicle's handling characteristics may be affected. NOTE The tyres on the front axle or the fenders could be damaged by large steering movements Avoid large steering movements while driving and listen for scraping sounds. If you hear scraping sounds, pull over and stop the vehicle in accordance with the traffic conditions, and set a higher vehicle level if possible.
	 Drive in a manner appropriate for the current level, but do not exceed 80 km/h. Consult a qualified specialist workshop.



STOP Vehicle level too low

Possible causes/consequences and > Solutions

- * You have pulled away despite the vehicle level being too low.
 - Stop the vehicle in accordance with the traffic conditions. The vehicle will be raised to the selected vehicle level.
 - Wait until the display message disappears before pulling away.

If the display message does not disappear and a warning tone also sounds, AIRMATIC is malfunctioning:

- No faster than 80 km/h and consult a qualified specialist workshop immediately.
- **NOTE** The tyres on the front axle or the fenders could be damaged by large steering movements
- Avoid large steering movements while driving and listen for scraping sounds.
- If you hear scraping sounds, pull over and stop the vehicle in accordance with the traffic conditions, and set a higher vehicle level if possible.
- Set a higher vehicle level (\rightarrow page 262). Depending on the malfunction, the vehicle will be raised.
- * The vehicle level is too low. The vehicle will be raised to the selected vehicle level.
 - Wait until the display message disappears before pulling away.



Vehicle rising Please wait



Max. speed 20km/h



Compressor is cooling

Possible causes/consequences and > Solutions

* AIRMATIC is functioning only to a limited extent.

The current level is too high. The vehicle's handling characteristics may be affected.

- No faster than 20 km/h.
- Consult a qualified specialist workshop.
- * Due to frequent level changes within a short space of time, the compressor first needs to cool down in order to set the selected vehicle level.

When the compressor has cooled down, the vehicle will continue rising to the selected vehicle level.

Drive on in a manner appropriate for the current level. Make sure that there is sufficient ground clearance.

Driver assistance systems

Display messages



--- km/h

Possible causes/consequences and ▶ Solutions

- * Active Distance Assist DISTRONIC cannot be activated as not all activation conditions are fulfilled.
 - Comply with the activation conditions of Active Distance Assist DISTRONIC (\rightarrow page 231).

Display messages	Possible causes/consequences and ▶ Solutions
suspended	* If you depress the accelerator pedal beyond the setting of Active Distance Assist DISTRONIC, the system will switch to passive mode (→ page 228).
Off	* Active Distance Assist DISTRONIC was deactivated. If a warning tone also sounds, Active Distance Assist DISTRONIC has deactivated automatically (→ page 231).
Active Distance Assist currently unavailable See Owner's Manual	 * Active Distance Assist DISTRONIC is temporarily unavailable. The ambient conditions are outside the system limits (→ page 228). As soon as the ambient conditions are within the system limits, the system will become available again. ▶ Drive on carefully. or ▶ If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.
Active Distance Assist inoperative	* Active Distance Assist DISTRONIC is malfunctioning. Other driving systems and driving safety systems may also be malfunctioning. Drive on carefully.

Display messages	Possible causes/consequences and ▶ Solutions
	or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
Active Distance Assist available again	 * Active Distance Assist DISTRONIC is operational again. ▶ Switch on Active Distance Assist DISTRONIC (→ page 231).
Active Brake Assist Func- tions currently limited See Owner's Manual	 Drive on carefully. As soon as the ambient conditions are within the system limits, the system will become available again. or If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.
Active Brake Assist Functions limited See Owner's Manual	 * For vehicles with the Driving Assistance Package, the following functions may be temporarily unavailable or only partially available: Active Brake Assist with cross-traffic function Evasive Steering Assist PRE-SAFE® PLUS Drive on carefully. or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Active Steering Assist currently unavailable See Owner's Manual	 * Active Steering Assist is temporarily unavailable. The ambient conditions are outside the system limits (→ page 237). As soon as the ambient conditions are within the system limits, the system will become available again. Drive on Check the tyre pressure if necessary.
Active Steering Assist inoperative	 * Active Steering Assist is malfunctioning. Active Distance Assist DISTRONIC remains available. Drive on Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
	 * Active Steering Assist has reached the system limits (→ page 237). You have not steered independently for a considerable period of time. ► Take over the steering and drive on in accordance with the traffic conditions.
Active Steering Assist cur- rently unavailable due to multiple emergency stops	 * Active Steering Assist is temporarily unavailable due to multiple emergency stops. Take over the steering and stop in accordance with the traffic conditions. Switch the vehicle off and switch it back on Active Steering Assist is available once more.

Display messages	Possible causes/consequences and ▶ Solutions
Beginning emergency stop	 * Your hands are not on the steering wheel. Active Steering Assist will initiate an emergency stop (→ page 237). ▶ Put your hands on the steering wheel. Information on cancelling an emergency stop (→ page 239).
Active Emergency Stop Assist currently unavailable See Owner's Manual	 * Active Emergency Stop Assist is temporarily unavailable. The ambient conditions are outside the system limits (→ page 239). As soon as the ambient conditions are within the system limits, the system will become available again. Drive on. or If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle. * Vehicles without the Driving Assistance Package: Active Emergency Stop Assist is temporarily unavailable due to multiple emergency stops. Take over the steering and stop in accordance with the traffic conditions. Switch the vehicle off and switch it back on Active Emergency Stop Assist is available once more.
Active Emergency Stop Assist inoperative	* Active Emergency Stop Assist is malfunctioning. Drive on or

706 Display messages and warning/indicator lamps

Display messages	Possible causes/consequences and ▶ Solutions
	 Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
Active Lane Change Assist currently unavailable See Owner's Manual	 * Active Lane Change Assist is temporarily unavailable. The ambient conditions are outside the system limits (→ page 241). As soon as the ambient conditions are within the system limits, the system will become available again. ▶ Drive on or ▶ If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.
Active Lane Change Assist inoperative	 * Active Lane Change Assist is malfunctioning. Drive on or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
Active Stop-and-Go Assist currently unavailable see Owner's Manual	 * Active Stop-and-Go Assist is temporarily unavailable. Active Distance Assist DISTRONIC and Active Steering Assist are still available. The ambient conditions are outside the system limits (→ page 228). As soon as the ambient conditions are within the system limits, the system will become available again. ▶ Drive on

Display messages	Possible causes/consequences and ▶ Solutions
Active Stop-and-Go Assist inoperative See Owner's Manual	 * Active Stop-and-Go Assist is malfunctioning. Active Stop-and-Go Assist has been deactivated. Active Distance Assist DISTRONIC and Active Steering Assist are still available. Drive on Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
Active Blind Spot Assist currently unavailable See Owner's Manual	 * Active Blind Spot Assist is temporarily unavailable. The system limits have been reached (→ page 255). Once the cause of the problem is no longer present, the system will be available again. ▶ Drive on or ▶ If the display message does not disappear, stop the vehicle in accordance with the traffic conditions and restart the vehicle.
Active Blind Spot Assist inoperative	 Active Blind Spot Assist is malfunctioning. Drive on Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Active Blind Spot Assist unavailable when towing a trailer See Owner's Manual	* When you establish the electrical connection to the trailer, Active Blind Spot Assist will be unavailable. Press the left-hand Touch Control and acknowledge the display message.
Active Lane Keeping Assist	* Active Lane Keeping Assist is temporarily unavailable.
currently unavailable See Owner's Manual	The ambient conditions are outside the system limits (\rightarrow page 258).
Owner's ivialidat	As soon as the ambient conditions are within the system limits, the system will become available again.
	▶ Drive on
Active Lane Keeping Assist	* Active Lane Keeping Assist is malfunctioning.
inoperative	▶ Drive on
	or
	 Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.
Active Lane Keeping Assist functions restricted See Owner's Manual	* Active Lane Keeping Assist is available but restricted.
	▶ Drive on
	or
	Stop the vehicle in accordance with the traffic conditions and restart the vehicle.If the display message does not disappear: consult a qualified specialist workshop.



Beginning emergency stop



temporarily unavailable Sensors dirty

Possible causes/consequences and > Solutions

- * Your hands are not on the steering wheel. The Active Lane Keeping Assist will initiate an emergency stop $(\rightarrow page 258)$.
- Put your hands on the steering wheel.

Information on cancelling an emergency stop (\rightarrow page 239).

- * Front and corner radar sensors (hereafter "sensors") are malfunctioning. Possible causes:
 - The sensors are dirty
 - Heavy rain or snow
 - Extended country driving without other traffic, e.g. in the desert

Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. The brake system, steering and drive system will continue to function normally.

Drive on carefully.

Once the causes of the problem are no longer present, the driving systems and driving safety systems will be available again and the corresponding symbols will be switched off.

If the display message does not disappear:

- Stop the vehicle in accordance with the traffic conditions.
- Clean all sensor covers from outside (\rightarrow page 215).
- Restart the vehicle.



Camera view restricted See Owner's Manual

Possible causes/consequences and > Solutions

- * The view of the multifunction camera is restricted. Possible causes:
 - Dirt on the windscreen in the field of vision of the multifunction camera
 - Heavy rain, snow or fog
 - Mist on the inside of the windscreen; in certain weather conditions, mist can form on the inside of the windscreen during cold times of year in particular.
 - This mist on the windscreen will be removed automatically within a short time with the aid of a heater. The restriction is temporary.

Driving systems and driving safety systems may be malfunctioning or temporarily unavailable. The brake system, steering and drive system will continue to function normally.

Drive on carefully.

Once the causes of the problem are no longer present, the driving systems and driving safety systems will be available again and the corresponding symbols will be switched off.

If the display message does not disappear:

- Stop the vehicle in accordance with the traffic conditions.
- Clean the windscreen, especially in the position of the multifunction camera (\rightarrow page 215).
- Restart the vehicle.

Display messages Restricted during trailer operation

er's Manual

Driver camera view currently restricted See Own-

Possible causes/consequences and > Solutions

- * When the trailer socket is occupied, some driving systems will be available only to a limited extent.
 - ▶ Drive carefully if you are towing a trailer or have the bicycle rack mounted.

- * The view of the driver camera is reduced. Possible causes:
 - Objects or stickers are projecting into the driver camera's field of vision.
 - · The driver camera is dirty.
 - Keep the driver camera's field of vision free.
 - Clean the driver camera if necessary. Please comply with the notes on caring for the interior relating to the display $(\rightarrow page 482)$.

Display messages	Possible causes/consequences and ▶ Solutions
Change steering wheel/ seat position until 6 dots are visible on the upper edge of the screen	* The driver camera cannot capture your line of sight. Change the steering wheel and seat position until six dots are visible on the top edge of the screen. The display message will appear again if the driver camera is again unable to detect your line of sight after 30 minutes. The display message will no longer appear if you confirm the display message and the driver camera cannot detect your line of sight during the entire journey.
Driver camera inoperative See Owner's Manual	* The driver camera is malfunctioning.Consult a qualified specialist workshop.
PRE-SAFE inoperative See Owner's Manual	* The PRE-SAFE® functions are malfunctioning. Consult a qualified specialist workshop.
PRE-SAFE impulse side inoperative See Owner's Manual	* The PRE-SAFE® Impulse Side system is malfunctioning or inoperative after having already been triggered. Consult a qualified specialist workshop.
PRE-SAFE PLUS inoperative See Owner's Manual	* The PRE-SAFE® system is malfunctioning. Drive on or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message does not disappear: consult a qualified specialist workshop.

Parking assistance systems

Display messages	Possible causes/consequences and ▶ Solutions
PARKTRONIC inoperative See Owner's Manual	 * Parking Assist PARKTRONIC is malfunctioning. Once the cause of the problem is no longer present, the system will be available again. Continue driving while paying attention to the vehicle's surroundings. or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message still appears, consult a qualified specialist workshop.
PARKTRONIC and manoeuvring assistant unavailable at rear when towing a trailer	* If transport equipment, e.g. a trailer or bicycle rack, is attached to the trailer hitch and the electrical connection is correctly established, Parking Assist PARKTRONIC is not available at the rear when reversing. The rear manoeuvring assistant is also unavailable in this situation. Press the left-hand Touch Control and acknowledge the display message.
Active Parking Assist and PARKTRONIC inoperative See Owner's Manual	 * Active Parking Assist and Parking Assist PARKTRONIC are malfunctioning. Once the cause of the problem is no longer present, the system will be available again. Continue driving while paying attention to the vehicle's surroundings. or Stop the vehicle in accordance with the traffic conditions and restart the vehicle. If the display message still appears, consult a qualified specialist workshop.

714 Display messages and warning/indicator lamps

Display messages
Limited availability of
Active Parking Assist
manoeuvring assistant See

Possible causes/consequences and ▶ Solutions

- * Active Parking Assist's manoeuvring assistant is temporarily unavailable or only partially available.
 - ightharpoonup Clean all sensors of the parking and camera system (ightharpoonup page 481).
 - If the display message still appears, consult a qualified specialist workshop.

Mercedes-Benz emergency call system


Display messages SOS Inoperative

Owner's Manual

Possible causes/consequences and ▶ Solutions

- * The Mercedes-Benz emergency call system is malfunctioning. The Mercedes me connect system is also malfunctioning.
- Consult a qualified specialist workshop.

Battery



Display messages	Possible causes/consequences and ▶ Solutions
Start the vehicle to charge the 12 V battery	 * The vehicle is off and the state of charge of the 12 V battery is too low. Switch off electrical consumers that are not required. Drive for 30-60 mins. or Charge the 12 V battery when stationary (→ page 496).
Stop vehicle Leave vehicle on to charge the 12 V battery	 * The 12 V battery charge level is too low. Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving. Leave the vehicle running If the display message disappears: drive on. If the display message does not disappear: consult a qualified specialist workshop.
Stop vehicle See Owner's Manual	 * The 48 V on-board electrical system is malfunctioning. Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving. Switch off the vehicle. Consult a qualified specialist workshop.

Display messages Possible causes/consequences and > Solutions * The 48 V battery is overheating. There is a risk of fire. Stop the vehicle immediately in accordance with the traffic conditions. If possible, stop the vehicle in the open air and ensure that all vehicle occupants get out. Battery overheated Stop, Supporting vehicle functions may activate automatically, e.g. air-recirculation mode as part of climate control. everybody out! Outdoors if possible Do not continue driving. If smoke is present, leave the danger zone and call the fire service immediately. Consult a qualified specialist workshop even if there are no external signs of a fire. * The 48 V on-board electrical system has function restrictions. Comfort functions may be restricted. Consult a qualified specialist workshop immediately. 48 V battery See Owner's Manual * The 48 V battery is discharged. You have switched on the vehicle while the 12 V battery was being charged with a suitable charger or while another vehicle was providing starting assistance. The discharged 48 V battery is charged automatically via the voltage converter. After a few minutes, the Possible to start the vehicle again display message will be shown on the driver's display. Please wait 48 V battery charging Start the vehicle.

718 Display messages and warning/indicator lamps

Display messages	Possible causes/consequences and ▶ Solutions
	Drive the vehicle for a while to charge the 12 V battery and the 48 V battery after disconnecting the charger from the vehicle.
	If the Possible to start the vehicle again display message does not appear after a few minutes: Try to start the vehicle.
	If the vehicle does not start, consult a qualified specialist workshop.
Cannot start vehicle See	* The state of charge of the 48 V battery is too low. You can no longer start the vehicle.
Owner's Manual	Switch off electrical consumers that are not required.
	Connect a suitable charger approved for Mercedes-Benz with sufficient charge output to the jump-start connection point of the 12 V battery (→ page 496).
	The 48 V battery is charged via the voltage converter in the vehicle.
Possible to start the vehi- cle again	* The 48 V battery has been charged automatically via the voltage converter.
	Start the vehicle and drive for a while to charge the 12 V battery and the 48 V battery.

Tyre pressure monitor

Display messages	Possible causes/consequences and ▶ Solutions
Tyre press. monitor currently unavailable	* There is interference from a powerful radio signal source As a result, no signals from the tyre pressure sensors are being received. The tyre pressure monitoring system is temporarily unavailable.
	The tyre pressure monitoring system will restart automatically as soon as the cause has been rectified.

Display messages	Possible causes/consequences and ▶ Solutions
	▶ Drive on
Tyre press. monitor inoperative	* The tyre pressure monitoring system is malfunctioning.
ative	▲ WARNING There is a risk of an accident if the tyre pressure monitoring system is malfunctioning
	The tyre pressure monitoring system cannot issue a warning if there is pressure loss in one or more of the tyres.
	Tyres with insufficient tyre pressure may impair the driving characteristics as well as steering and braking.
	Have the tyre pressure monitoring system checked at a qualified specialist workshop.
	Consult a qualified specialist workshop.
Tyre pressure monitor inop-	* The wheels fitted do not have suitable tyre pressure sensors. The tyre pressure monitoring system is deactivated.
erative No tyre pressure sensors	Fit wheels with suitable tyre pressure sensors.
	* There is no signal from the tyre pressure sensor in at least one wheel. No pressure value is displayed for the affected tyre.
	► Have the faulty tyre pressure sensor replaced at a qualified specialist workshop.
Wheel sensor(s) missing	

Display messages



Check tyre(s)

Possible causes/consequences and > Solutions

* The tyre pressure in one or more tyres has dropped significantly.

The wheel position is displayed. A warning tone will also sound.

WARNING Risk of an accident due to insufficient tyre pressure

- The tyres can burst.
- The tyres can wear excessively and/or unevenly.
- The driving characteristics as well as the steering and braking may be greatly impaired.

You could then lose control of the vehicle.

- Observe the recommended tyre pressures.
- Adjust the tyre pressure if necessary.
- Stop the vehicle in accordance with the traffic conditions.
- Check the tyre pressure (\rightarrow page 510) and the tyres.



Rectify tyre pressure

- * The tyre pressure is too low in at least one of the tyres, or the difference in tyre pressure between the individual wheels is too great.
 - Check the tyre pressure and add air, if necessary.
- When the tyre pressure is correct, restart the tyre pressure monitor (\rightarrow page 513).

Display messages



Warning tyre malfunction

Possible causes/consequences and > Solutions

* The pressure in one or more tyres has dropped suddenly. The wheel position is displayed.

WARNING Risk of an accident from driving with a flat tyre

- The tyres can overheat and be damaged.
- The driving characteristics as well as the steering and braking characteristics may be greatly impaired.

You could then lose control of the vehicle.

- Do not drive with a flat tyre.
- Do not exceed the maximum permissible driving distance in emergency mode and the maximum permissible speed with a flat MOExtended tyre.
- Observe the notes on flat tyres.

Notes on flat tyres (\rightarrow page 487).

- Stop the vehicle in accordance with the traffic conditions.
- Check the tyres.






Tyre(s) overheated

WARNING Risk of an accident from driving with overheated tyres

Overheated tyres can burst.



Tyre pressure loss warning system

Display messages Possible causes/consequences and ▶ Solutions Tyre pressure Check tyres * The tyre pressure loss warning system has detected a significant loss of pressure. ♠ WARNING Risk of an accident due to insufficient tyre pressure


The tyres can burst.

Display messages	Possible causes/consequences and ▶ Solutions
	 The tyres can wear excessively and/or unevenly. The driving characteristics as well as the steering and braking may be greatly impaired.
	You could then lose control of the vehicle.
	Observe the recommended tyre pressures.Adjust the tyre pressure if necessary.
	 Stop the vehicle in accordance with the traffic conditions. Check the tyre pressure (→ page 510) and the tyres.
	When the tyre pressure is correct, restart the tyre pressure loss warning system (→ page 514).
Check tyre pressure, then restart Run Flat Indicator	 * The tyre pressure loss warning system generated a display message and has not been restarted since. ▶ When the tyre pressure is correct, restart the tyre pressure loss warning system (→ page 514).
Run Flat Indicator inoperative	 * The tyre pressure loss warning system is malfunctioning. Consult a qualified specialist workshop.


Exhaust gas aftertreatment

Display messages	Possible causes/consequences and ▶ Solutions
AdBlue	 * The AdBlue[®] level has fallen into the reserve range. ▶ Top up AdBlue[®] immediately (→ page 207).
Refill AdBlue See Owner's Manual	
Top up AdBlue Emergency op. in XXX km See Owner's Manual	* The low AdBlue [®] level will lead to limited performance after the remaining distance displayed has been covered. ▶ Top up with AdBlue [®] immediately (→ page 207).
Top up AdBlue XX,X I Emerg. op.: max. XXX km/h Start not poss. in XXX km	 * The low AdBlue[®] level will lead to limited performance from the speed displayed. After the remaining distance displayed has been covered, it will no longer be possible to start the vehicle. ▶ Top up with at least the indicated amount of AdBlue[®] (→ page 207).

Display messages Possible causes/consequences and > Solutions * The AdBlue® tank is empty. You can no longer start the vehicle. Top up with at least the indicated amount of AdBlue[®] (\rightarrow page 207). Switch on the vehicle and wait for approximately 60 seconds. Top up AdBlue XX,X I Start the vehicle. Switch vehicle on, wait 60 sec. or engine start not poss. * The AdBlue® system is malfunctioning. Consult a qualified specialist workshop immediately. AdBlue system fault See Owner's Manual * The AdBlue® system is malfunctioning. Performance will be reduced once the remaining distance displayed has been covered. Consult a qualified specialist workshop immediately. AdBlue system malfunction Emergency op. in XXX km See Owner's Manual



Engine oil



Display messages	Possible causes/consequences and ▶ Solutions
	 Switch off the vehicle. Add 1 I of engine oil (→ page 473). Check the engine oil level. Notes on engine oil (→ page 637).
Engine oil pressure Stop Switch off the vehicle	* The oil pressure is too low. ■ NOTE Engine damage caused by driving with insufficient oil pressure ■ Avoid driving with insufficient oil pressure. ■ Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving. ■ Switch off the vehicle.
Engine oil level cannot be measured	 Consult a qualified specialist workshop. * The electrical connection to the oil level sensor has been interrupted or the oil level sensor is faulty. Consult a qualified specialist workshop.

Display messages



Engine oil Quality loss Oil change required

Possible causes/consequences and > Solutions


- * Vehicles with a diesel engine: the engine oil quality is no longer sufficient.
 - Visit a qualified specialist workshop and have the oil changed.

Warning and indicator lamps

Overview of indicator and warning lamps

Some systems will perform a self-test when the vehicle is switched on. Some indicator and warning lamps may briefly light up or flash. This behaviour is non-critical. These indicator and warning lamps indicate a malfunction only if they light up or flash after the vehicle has been started or during a journey.

Driver's display



Driver's display with driver camera



Indicator and warning lamps

Occupant safety



Restraint system (\rightarrow page 731)



Seat belt (→ page 731)

Occupant presence reminder (white) (→ page 731)

Occupant presence reminder (yellow)
(→ page 731)

Vehicle

ightharpoonup Trailer hitch (ightharpoonup page 733)

 Θ ! Power steering (yellow) (\rightarrow page 733)

 \bigcirc Power steering (red) (\rightarrow page 733)

Rear axle steering (yellow) (\rightarrow page 733)

Engine

 \bot Coolant temperature (\rightarrow page 735)

Engine diagnostics (\rightarrow page 735)

Vehicles with a petrol engine: engine operating temperature (\rightarrow page 735)

Vehicles with a diesel engine: preglow

Electrical fault (\rightarrow page 735)

Reserve fuel with fuel filler flap location indicator (\rightarrow page 735)

Brakes

Poff

(●) Electric parking brake (yellow)(→ page 739)

(e) Electric parking brake (red) (→ page 739)

 \bigcirc Brakes (yellow) (\rightarrow page 739)

Brakes (red) (→ page 739)

Driving and driving safety systems

(**a**) ABS (→ page 741)

ESP® OFF (→ page 741)

Traffic Sign Assist (→ page 741)

ATTENTION ASSIST (→ page 741)

 \triangle Distance warning (\rightarrow page 741)

Active Brake Assist (\rightarrow page 741)

off Active Brake Assist (→ page 741)

Active Brake Assist (→ page 741)

AIRMATIC (→ page 741)

Mercedes-Benz emergency call system

Mercedes-Benz emergency call system (→ page 746)

Tyre pressure monitoring system

Tyre pressure monitoring system (→ page 747)

Exterior lighting

Parking lights (→ page 147)

Low beam (→ page 147)

High beam (→ page 149)

Turn signal lights (→ page 149)

Rear fog light (\rightarrow page 147)

Symbols on the central display

A Drive Away Assist (→ page 285)

 \triangle Rear cross traffic warning (\rightarrow page 286)

 \bigcirc Manoeuvring brake function (\rightarrow page 287)

Occupant safety

flashes

Possible causes/consequences and ▶ Solutions Warning/indicator lamp * The restraint system red warning lamp is lit while the vehicle is on. The restraint system is malfunctioning (\rightarrow page 40). WARNING Risk of injury due to malfunctions in the restraint system Restraint system warning Components in the restraint system may be activated unintentionally or not deploy as intended in an accident. lamp ▶ Have the restraint system checked and repaired immediately at a qualified specialist workshop. Drive on carefully. Note the messages on the driver's display. Consult a qualified specialist workshop immediately. * The red seat belt warning lamp flashes and an intermittent warning tone sounds. The driver or front passenger has not fastened their seat belt while the vehicle is in motion. \triangleright Fasten your seat belt (\rightarrow page 43). There are objects on the front passenger seat. Seat belt warning lamp

Remove the objects from the front passenger seat.

Vehicle

Warning/indicator lamp Possible causes/consequences and ▶ Solutions * The red trailer hitch warning lamp is lit. The trailer hitch is not operational or is swivelling. WARNING Risk of an accident if the ball neck is not locked Trailer hitch warning lamp The trailer may become detached. Stop the vehicle immediately in accordance with the traffic conditions. Do not continue driving. Uncouple the trailer and secure it against rolling away. Initiate a new swivelling procedure and do not re-couple the trailer until the display message disappears. Note the messages on the driver's display. If the trailer hitch is swivelling: ▶ Wait until the ball neck has reached the operational position. * The yellow power steering warning lamp is lit while the vehicle is running. The power assistance or the steering itself is malfunctioning. Note the messages on the driver's display. Power steering warning lamp (yellow)

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
!	* The red power steering warning lamp is lit while the vehicle is running. The power assistance or the steering itself is malfunctioning.
Power steering warning	▲ WARNING Risk of accident if steering capability is impaired
lamp (red)	If the steering does not function as intended, the vehicle's operating safety is jeopardised.
	Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
	Consult a qualified specialist workshop.
	Note the messages on the driver's display.
	* The yellow rear axle steering warning lamp is lit while the vehicle is running. The rear axle steering is malfunctioning.
🐼:	Note the messages on the driver's display.
Rear axle steering warning lamp (yellow)	
@ !	* The red rear axle steering warning lamp is lit while the vehicle is running. The rear axle steering is malfunctioning.
Rear axle steering warning	WARNING Risk of accident if steering capability is impaired
lamp (red)	If the steering does not function as intended, the vehicle's operating safety is jeopardised.

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
	 Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances. Consult a qualified specialist workshop.
	Note the messages on the driver's display.

Engine

Warning/indicator lamp Possible causes/consequences and ▶ Solutions * The red coolant warning lamp is lit while the engine is running. Possible causes: · The temperature sensor is malfunctioning Coolant warning lamp (red) . The coolant level is too low · The air supply to the radiator is obstructed • The radiator fan is faulty • The engine coolant pump is faulty If there is an additional warning tone, the coolant temperature has exceeded 120°C.

Warning/indicator lamp	Possible causes/consequences and ► Solutions
	WARNING Risk of burns when opening the bonnet
	If you open the bonnet in the event of an overheated engine or fire in the engine compartment, the following situations may occur:
	You may come into contact with hot gases.
	You may come into contact with other escaping hot operating fluids.
	▶ Before opening the bonnet, allow the engine to cool down.
	In the event of a fire in the engine compartment, keep the bonnet closed and call the fire service.
	 Stop immediately in accordance with the traffic conditions and switch off the vehicle. Do not continue driving. Note the messages on the driver's display.
	If the coolant temperature display is at the lower end of the temperature scale:
	Consult a qualified specialist workshop.
	If the coolant temperature display is at the upper end of the temperature scale:
	Exit the vehicle and keep a safe distance from it until the engine has cooled down.
	► Check the coolant level (\rightarrow page 475).
	► Make sure that the air supply to the radiator is not obstructed.
	Avoiding high loads on the engine, drive to the nearest qualified specialist workshop. In doing so, ensure that the coolant temperature display remains below 120°C.

Warning/indicator lamp Coolant warning lamp (yellow)

Possible causes/consequences and > Solutions

- * The yellow coolant warning lamp is lit while the engine is running.
 - Possible causes:
 - The temperature sensor is malfunctioning
 - The charge air, transmission oil or battery cooling is faulty
 - The radiator shutters are blocked or defective
 - Avoiding high loads on the engine, drive to the nearest qualified specialist workshop.

Engine diagnostics warning lamp


* The yellow engine diagnostics warning lamp is lit while the engine is running. A malfunction has occurred in the engine, the exhaust system or the fuel system.

The emissions limit value may have been exceeded and the engine may be running in emergency operation mode.

► Have the vehicle checked as soon as possible at a qualified specialist workshop.

Vehicles with a diesel engine: the fuel tank may have been run dry.

- Start the engine three to four times after refuelling.
- If the yellow engine diagnosis warning lamp goes out, emergency operation mode is cancelled. The vehicle need not be checked.



Electrical fault warning lamp

- * The red electrical fault warning lamp is lit. There is a fault in the electrics.
- Note the messages on the driver's display.

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
Engine operating temperature warning lamp	*Vehicles with a petrol engine: after a cold start, the blue engine operating temperature warning lamp is on. Engine output and engine torque are reduced. Take this into consideration in your driving style.
Fuel reserve warning lamp lights up	* The yellow fuel reserve warning lamp lights up while the engine is running. The fuel supply has dropped into the reserve range. Refuel.

Brakes

Warning/indicator lamp



Electric parking brake indicator lamp (red)



Electric parking brake indicator lamp (yellow)



Brakes warning lamp (yellow)

Possible causes/consequences and ▶ Solutions

- * The red electric parking brake indicator lamp flashes or is lit.
- The yellow electric parking brake indicator lamp is also lit in the event of a malfunction.
- Note the messages on the driver's display.

* The yellow brakes warning lamp is lit while the vehicle is running.

WARNING Risk of an accident due to a brake system malfunction

If the brake system is malfunctioning, braking characteristics may be impaired.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.

The Hill Start Assist may be malfunctioning.

Adjust your speed and drive on carefully, leaving a suitable distance to the vehicle in front.

Warning/indicator lamp	
(())	
Brakes warning lamp (red)	

Possible causes/consequences and ▶ Solutions

- If the driver's display shows a display message, observe it.
 - Consult a qualified specialist workshop.
- * The red brakes warning lamp is lit while the vehicle is running. Possible causes:
- The brake force boosting is malfunctioning and the braking characteristics may be affected.
- There is insufficient brake fluid in the brake fluid reservoir.
- Note the messages on the driver's display.

A WARNING Risk of accident and injury if brake force boosting is malfunctioning

If brake force boosting is malfunctioning, increased brake pedal force may be necessary for braking. The braking characteristics may be impaired. The braking distance can increase in emergency braking situations.

- Stop in a safe location immediately. Do not continue driving!
- Consult a qualified specialist workshop.

▲ WARNING Risk of an accident due to low brake fluid level

If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired.

- Stop the vehicle as soon as possible, paying attention to road and traffic conditions. Do not continue driving.
- Consult a qualified specialist workshop.

Warning/indicator lamp Possible causes/consequences and > Solutions ▶ Do not top up the brake fluid.

Driving and driving safety systems

Warning/indicator lamp



ABS warning lamp

Possible causes/consequences and > Solutions

* The yellow ABS warning lamp is lit while the vehicle is running. ABS is malfunctioning.

If an additional warning tone sounds, EBD is malfunctioning.

Other driving systems and driving safety systems may also be malfunctioning.

Note the messages on the driver's display.

WARNING There is a risk of skidding if EBD or ABS is malfunctioning

The wheels may lock during braking.

The steerability and braking characteristics are heavily impaired and the braking distance may increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully.

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
	Consult a qualified specialist workshop.
ESP® warning lamp flashes	 * The yellow ESP® warning lamp flashes while the vehicle is in motion. One or more wheels have reached their grip limit (→ page 218). ▶ Adapt your driving style to suit the road and weather conditions.
ESP® warning lamp lights up	* The yellow ESP® warning lamp is lit while the vehicle is running. ESP® is malfunctioning. Other driving systems and driving safety systems (e.g. BAS) may also be malfunctioning. Note the messages on the driver's display.
	★ WARNING Risk of skidding if ESP [®] is malfunctioning
	If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilisation. In addition, other driving safety systems are switched off. Drive on carefully. Have ESP® checked at a qualified specialist workshop.
	Drive on carefully.Consult a qualified specialist workshop immediately.

Warning/indicator lamp



ESP® OFF warning lamp

Possible causes/consequences and > Solutions

* The yellow ESP® OFF warning lamp is lit while the vehicle is running. ESP® is deactivated.

Other driving systems and driving safety systems may also be inoperative.

WARNING Risk of skidding when driving with ESP® deactivated

ESP® does not act to stabilise the vehicle. The availability of further driving safety systems is also limited.

- Drive on carefully.
- Deactivate ESP® only for as long as the situation requires.

If ESP® cannot be activated, ESP® is malfunctioning.

- ► Have ESP® checked immediately at a qualified specialist workshop.
- Observe the notes on deactivating ESP[®] (\rightarrow page 218).
- * The ATTENTION ASSIST warning lamp is lit. ATTENTION ASSIST is malfunctioning.

ATTENTION ASSIST warning lamp

Consult a qualified specialist workshop.

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
Warning lamp for distance warning	 * The red distance warning lamp lights up while the vehicle is in motion. The distance to the vehicle in front is too small for the speed selected. If there is an additional warning tone, you are approaching an obstacle at too high a speed. Be prepared to brake immediately. Increase the distance. Function of Active Brake Assist (→ page 243).
Active Brake Assist warning lamp	* The Active Brake Assist warning lamp is on. Due to dirty sensors or a malfunction, the system is not available or the range of functions is restricted. Note the messages on the driver's display.
OFF Active Brake Assist warning lamp	* The Active Brake Assist warning lamp is on. The system is switched off or the range of functions has been automatically restricted. This may be the case if the driver is not wearing a seat belt or another driving system has been activated. ▶ Observe the notes on Active Brake Assist (→ page 243).

746 Display messages and warning/indicator lamps

Warning/indicator lamp



Traffic Sign Assist warning lamp

Possible causes/consequences and ▶ Solutions

* The Traffic Sign Assist warning lamp is lit.

Traffic Sign Assist is malfunctioning.

Note the messages on the driver's display.

Mercedes-Benz emergency call system

Warning/indicator lamp

SOS NOT READY

Mercedes-Benz emergency call system warning lamp

Possible causes/consequences and ▶ Solutions

- *The Mercedes-Benz emergency call system is malfunctioning. The Mercedes me connect system is also malfunctioning.
- Consult a qualified specialist workshop.

Tyre pressure monitor

Warning/indicator lamp



Tyre pressure monitoring system warning lamp flashes

Possible causes/consequences and ▶ Solutions

*The yellow tyre pressure monitor warning lamp (pressure loss/malfunction) flashes for approximately one minute and then remains lit

The tyre pressure monitoring system is malfunctioning.

WARNING There is a risk of an accident if the tyre pressure monitoring system is malfunctioning

The tyre pressure monitoring system cannot issue a warning if there is pressure loss in one or more of the tyres.

- Tyres with insufficient tyre pressure may impair the driving characteristics as well as steering and braking.
- ► Have the tyre pressure monitoring system checked at a qualified specialist workshop.
- Consult a qualified specialist workshop.
- * The yellow tyre pressure monitoring system warning lamp (pressure loss/malfunction) is lit.
- The tyre pressure monitoring system has detected tyre pressure loss in at least one of the tyres.

Tyre pressure monitoring system warning lamp lights up

- WARNING Risk of an accident due to insufficient tyre pressure
- The tyres can burst.
- The tyres can wear excessively and/or unevenly.
- The driving characteristics as well as the steering and braking may be greatly impaired.

You could then lose control of the vehicle.

748 Display messages and warning/indicator lamps

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
	Observe the recommended tyre pressures.Adjust the tyre pressure if necessary.
	Stop the vehicle in accordance with the traffic conditions.Check the tyre pressure and the tyres.

1, 2, 3 3D driver's display, 3D instrument cluster Function/notes	Activating / deactivating		Active Lane Change Assist Activating/deactivating Function Active Lane Keeping Assist	
48 V on-board electrical system Displays in the driver's display	Brake application	257 255 255 257	Activating/deactivatingFunction	258 261 258
A	Active bonnet	470	Active light function	150
A/C function Activating/deactivating (operating unit)	Active Distance Assist DISTRONIC Activate/deactivate variable limiter Active Emergency Stop Assist	248 231 231 239 241 231 228 231	Active Parking Assist Automatic braking function Cross traffic warning Drive Away Assist Exiting a parking space Function Manoeuvering brake function Memory Parking Assist Parking Pausing Remote Parking Assist Active Service System PLUS	285 279 275 287 288 277 280 281
Accident prevention 28	Route-based speed adaptation Storing a speed	235 231	Active Service System PLUS Active Speed Limit Assist	
Accident, emergency call 44	Active Emergency Stop Assist	239	Active Speed Limit Assist	

750 Index

Active Emergency Stop AssistActive Lane Change Assist		Engine oilFuel		Calling upClimate control	171 172
Function		Adjusting bass, mid-range and treble set-		Fragrance system	175
Active Stop-and-Go Assist	236	tings		Front air conditioning	
Adaptive brake lights	222	Burmester [®] 4D surround sound system	465	Ionisation Rear compartment climate control	
Adaptive cruise control	235		403	Air distribution	
Adaptive Highbeam Assist Activating/deactivating	156	Adjusting mid-range, treble and bass set- tings Burmester® 4D surround sound sys-		Overview	
Adaptive Highbeam Assist Plus		tem	465	Air freshener system	
Switching on/off	158	Adjusting the balance/fader		Air inlet	
AdBlue® Additives	636	Burmester® 4D surround sound system	465	Air pressure	510
CapacityFill level	309	Adjusting the sound focus Burmester® 4D surround sound sys-		Air suspension	
Notes Purity	206 636	tem	466	SettingAir/water duct	
Range Topping up	309	Adjusting treble, mid-range and bass settings		Airbag Deployment	
Additional door lock	. 85	Burmester® 4D surround sound sys-	4.75	Overview	45
Additional mobile phone Connecting	415	After-sales service		PASSENGER AIR BAG indicator lamps Protection	47
Additives AdBlue [®]	, 636	Air conditioning menu Air distribution	173	Reduced protection	

Airflow		Animals	. 75	ASSYST PLUS	
Setting 1	68	Anti-lock braking system	217	Battery disconnection periods	
AIRMATIC Setting the vehicle level	:62	Anti-theft alarm system		Service interval display Service requirements	
Vehicle levels		Anti-theft protection	85	ATA	
Alarm system 10	07	Additional door lockImmobiliser		Deactivating the alarmFunction	
All-wheel drive	:03	Apple CarPlay®		Interior protection	
Alternative route	87	Connecting an iPhone® (cable)	424	Interior protection function	10
Ambient lighting 1 c	60	Connecting an iPhone® (wireless)	425	Tow-away protection	
AMG TRACK PACE		0		Tow-away protection function	10
Configuring 30	66	Notes		ATTENTION ASSIST	
Drag Race 30		Overview		Function	
Function 30	63	Sound settings		Setting	
Telemetry display 30	66	Transferred vehicle data	428	Attention assistant	22
Track Race 30	63	Apps, Mercedes me		Audials	
Android Auto			429	Deleting stations	45
Connecting a mobile phone (wired) 4:	26	Mercedes me connect		Logging out	
Connecting a mobile phone (wireless) 4:	27	Selecting (MBUX multimedia system)		Registering	45
	28	Assembly licence plate, front	. 28	Saving stations	45
	-26	Assistance system	216	Selecting and connecting a station	
Sound settings 42		Assistant display		Selecting stream	45
Transferred vehicle data 42	-28	Menu (driver display)	310	Setting options	45
Android smartphone 42	26	(4	0.0		

Augmented reality MBUX route guidance	400	Engaging reverse gear Gear shift	196	0,	495
Authorisations Setting	356	Kickdown	201	ReplacingStarting assistance	498 496
Authorised workshop Automatic car wash Automatic climate control		Oil temperature (driver's display) Selecting park position Steering wheel gearshift paddles Transmission position display	199 201	Battery (48 V) Notes Battery (key)	
Automatic distance control	148	Transmission positions		Belt Adjusting the height Fastening Releasing	43
		Trailer operation	043	Bicycle rack	
Automatic engine start/stop Automatic front passenger airbag shutoff PASSENGED AIR BAG indicator lamps		В	1.50	Load capacityTrailer operation	
	49	Bad weather light		Load capacity	300 257
Automatic front passenger airbag shutoff PASSENGER AIR BAG indicator lamps Automatic measures after an accident Automatic mirror folding function Automatic seat adjustment Automatic transmission DIRECT SELECT lever Drive programs	49 53 167 120 196 194	Bad weather light	138 295 297 218	Load capacity Trailer operation	300257206414356

Opening/closing	311 . 94 . 96 . 98 . 93 . 94	BAS (Brake Assist System) Driving tips EBD (Electronic Brakeforce Distribution) Electric parking brake	213	Adjusting the sound focus	46! 46! 46! 46!
ture on/off Brake Assist Active Brake Assist Brake Assist System	243	New/replaced brake pads/brake discs Parking brake	186 213 53	Deleting Making a call Overview Selecting options	420 420
Brake Assist System		Braking assistance Brake Assist System		Calling the customer centre for Mercedes-Benz	
Brake fluid	638 220	Breakdown Flat tyre Overview of aids Tow-starting	487 20	Calling up a web page Calling up the sound menu Burmester® 4D surround sound system Calls, Telephone operation	
Brake pads Brakes ABS (Anti-lock Braking System) Active Brake Assist	217	Transporting the vehicle 501,	519	Accepting	417

Ending a call	416	Car key	76	Seat belt	
Incoming call during an existing call	417	Car wash		Steering wheel	482
International calls overview	418		477	Trailer hitch	481
Making	416	High-pressure cleaner		Vehicle interior	482
	429	Washing by hand		Washing by hand	479
Setting the international dialling code	418	0 ,	1//	Wheels/rims	
	416	Car-to-X communication	000	Caring for plastic trim	
and the second s	429	Hazard warnings	399		
Using the international dialling code	418	Car-to-X-Communication		Caring for rims	
Camera		Overview	398	Caring for the roof lining	482
	265	Sending hazard warnings	399	Caring for the steering wheel	482
Button	270	Care		Carrier	129
Cleaning	481				330
Driver camera	352	Automatic car wash	477		330
Function	265		481	Central locking system	
Information	215	Car parts	481	Button	
Opening the camera cover (reversing		Decorative foil	480	Key	. 77
	270	Display	482	Centre airbag (driver's backrest)	45
Reversing camera	263	Exterior lighting	481	Charging	
Selecting the view	270	Head-up display	482	12 V battery	406
Camera app		High-pressure cleaner	478	USB port	
	466	Paint	479	Wirelessly charging a mobile phone	
	467	Plastic trim	482	, , , , ,	
		Real wood/trim elements	482	Checking the coolant level	475
Taking a photo		Roof lining	482		

Child safety lock	70	Without automatic co-driver airbag sh utoff	. 69	Climate bar, Air conditioning system, Air	
Rear door		Children	. 09	conditioning system menu, Climate menu Configuring	
Child seat		Avoiding dangers in the vehicle	54	Operating	17
Approval categories 5	59	Basic instructions	53	Climate control	
	53	Chock	518	Activating/deactivating	16
,	62	City lighting		Activating/deactivating (rear operat-	
	70		102	ing unit)	1/
Notes on fastening (MBUX Interior		Classic menu display content	000	Activating/deactivating the A/C func-	
,	49	Selecting	308	tion (control panel)	
Recommendations for child restraint		Clean varnish	479	Air conditioning menu	
-,	57	Cleaning		Air distribution	16
,8	54	Air/water duct	477	Air distribution settings	17
Seats suitable for belt-secured child		Automatic car wash	477	Air vents (front)	17
restraint systems 6	66			Air vents (rear)	17
Seats suitable for i-Size child restraint		Car parts Decorative foil	480	Airflow	
systems	62			Automatic control	17
Seats suitable for ISOFIX child		High-pressure cleaner		Automatically controlling (rear operat-	
restraint systems	60	Paint	479	ing unit)	17
	58	Real wood/trim elements	482	Defrosting the windscreen	
Securing to the front passenger seat		Sensors	481	Demisting the windscreen	
	71	Vehicle interior		Demisting windows	17
Securing to the rear seat with the		Washing by hand	479	Fine particle status display	
S S S S S S S S S S S S S S S S S S S	68	Cleaning carpets	482	Fragrance system	
Top Tether	64	Cleaning seat covers	482	,	

Inserting/removing the flacon (fra- grance system)	Combination switch Lights		120 116
Operating unit	Disconnecting automatically from the Internet	Control element (MBUX multimedia system)	
Stationary heater/ventilation	Components subject to radio regulations Declaration of conformity	Control elements:	25
Switching the A/C function on/off (MBUX)	Configuring settings Camera app	Convenience opening 10	00
Temperature	Displaying	Cooling 16	68
Cockpit Overview (central display)	Contacts 419 Deleting 420 Importing 419	Cornering light	51 33
Collision detection (parked vehicle) Setting	Importing (overview)	Cross traffic (warning)	286

Cruise control activating/deactivating Calling up a speed Function Requirements: Setting a speed	225 224 225	Electronic control units Online services Deactivating the alarm Dealership Declaration of conformity	37 108	Entering geo-coordinates	379 387 380 380
Storing a speed		Components subject to radio regulations Electromagnetic compatibility	28 . 30	Destination entry (multimedia system) Notes Selecting a POI Detecting inattentiveness	37
Damping system ADS PLUS AIRMATIC Setting the vehicle level Dashcam		TIREFIT kit Decorative foil Defrost function DeNOx agent	480 172	Diagnostics connection Diesel Low outside temperatures Notes	635
Configuring settings Selecting a USB device Starting/stopping a video recording Data processing in the vehicle Data protection	411 411 . 35	AdBlue® Destination Editing a suggestion Editing intermediate destinations Editing the previous destinations	395 386 395	DIGITAL LIGHT Activating/deactivating Active headlamps Assistance functions Bad weather light	154 150 152 152
Granting authorisations Data protection rights Data storage Data protection rights	38	Saving as a favourite Destination entry Accepting a destination suggestion Entering a 3 word address Entering an intermediate destination	377 379	City lighting Cornering light Enhanced fog light function Intelligent Light System Motorway mode	15 ¹ 15 ¹

Overview	Display Care	482	AdBlue system malfunction Emerg. op.: max. XXX km/h Start not	
Digital Owner's Manual	Display (driver's display) Overview of displays	314	poss. in XXX km	726
Function	Display (MBUX multimedia system) Settings	354	AdBlue system malfunction Emergency op. in XXX km See Own-	
managing	Display message Calling up on driver display	644	er's Manual	725
remove	Notes Display messages	644	refuelling	727
Unlocking setting	km/h		Take a break!	696
DIRECT SELECT lever Automatic transmission	km/h	697		696
Engages neutral	tem Visit workshop	715	ative	657
Engaging park position automatically	ual	717	Battery overheated Stop, everybody out! Outdoors if possible	
Gearshift recommendation	AdBlue system fault Engine start not possible	726	Beginning emergency stop 705, Brake immediately	
Selecting park position	AdBlue system fault See Owner's Manual	725	Camera view restricted See Owner's Manual	710

Change key batteries	651	♣ Do not leave persons or ani-		inoperative See Owner's Man-	
(D) Check brake fluid level		mals in the vehicle	650	ual (ABS and ESP®)	69:
Check tyre(s)		Engine oil level cannot be		EBD inoperative See Owner's Man-	0/0
Clean the fuel filter		measured	728	ual (EBD, ABS and ESP®)	695
Compressor is cooling		Engine oil level Reduce oil level	727	inoperative See Owner's Man-	0,
Coolant Stop Switch off the		Engine oil level Stop Switch off		ual (ESP®)	694
vehicle	680	the vehicle	727	©sos Inoperative	
Currently unavailable Battery		Engine oil pressure Stop Switch			
low	667	off the vehicle	728	(C) Key being taught in Please wait	656
Currently unavailable Outside		Engine oil Quality loss Oil		(a) Key does not belong to vehicle	656
temperature too high	667	change required	729	Key not detected (red display	
Currently unavailable Refuel	668	Fault Drive at max. 80 km/h	699	message)	652
currently unavailable See Own-		Front left malfunction Consult		Key not detected (white dis-	
er's Manual (ABS and $\text{ESP}^{\text{\tiny (R)}})$	692	workshop	645	play message)	65
eurrently unavailable See Own-		Front left parking lights	659	(C) Key not detected Place Digital	
er's Manual (ESP®)	693	Front left turn signal	662	Vehicle Key in inductive charging	
Digital Vehicle Key Charge		Front right malfunction Consult		bracket	654
device	655	workshop		(C) Key not detected	650
© Do not forget key	655	Front right parking lights		🔅 Left brake lamp	663
		Front right turn signal	662	Left cornering light	661

🛱 Left daytime running lights	661	Parking brake See Owner's		Rectify tyre pressure	720
Left low beam	660	Manual	686	Reduce speed	722
Left main beam	660	Parking brake Switch on vehi-		Refill AdBlue See Owner's Man-	
Left mirror turn signal	663	cle to release	689	ual	724
Left tail light	664	LIM passive	698	(P) Release parking brake	689
Left window airbag malfunction		Please wait 48 V battery charg-		Replace air filter	682
Consult workshop	647	ing	717	Replace key See Owner's Man-	
Malfunction See Owner's Man-		Rear axle steering currently		ual	655
ual	656	malfunctioning	676	Replace key	651
(1) Malfunction See Owner's Man-		Rear axle steering Malfunction		Reserve fuel level	681
ual	690	Stop immediately	676	Restraint system malfunction	
(D) Malfunction Stop vehicle	690	Rear axle steering Malfunction		Consult workshop	645
Max. speed 20km/h	701	Visit workshop	676	Restricted during trailer opera-	
120 km/h! Maximum speed exceeded	698	Rear fog light	665	tion	711
Number plate lamp	665	Rear left seat backrest not		Reversing light	664
□ Off	702	locked	678	Right brake lamp	663
	695	Rear left turn signal	662	Right cornering light	661
Operation only possible in		Rear right seat backrest not		Right daytime running lights	661
transmission position P	670	locked	678	Right low beam	
•		Rear right turn signal	662	Right main beam	660

Right mirror turn signal	663	Stop vehicle See Owner's Man-		Top up washer fluid	67
Right tail light	664	ual	715	Trailer brake lamp	66
Right window airbag malfunc-		Stop vehicle See Owner's Man-		Trailer coupling Check lock	
tion Consult workshop	648	ual	716	(white display message)	67
Second row of seats, left Mal-		suspended	702	Trailer coupling Check lock (red	
function Consult workshop	646	Switch off lights	657	display message)	67
Second row of seats, right Mal-		Switch on headlamps	657	Trailer coupling in motion	67
function Consult workshop	647	temporarily unavailable Sen-		Trailer left turn signal	66
Start the vehicle to charge the		sors dirty	709	Trailer right turn signal	66
12 V battery	716	Third brake lamp	664	Trailer tail light	66
Steering malfunction Drive		Top up AdBlue Emergency op.		Tyre(s) overheated	72
carefully Visit workshop	674	in XXX km See Owner's Manual	724	★ Vehicle is ready to drive Shut-	
Steering malfunction Increased		Top up AdBlue XX,X I Emerg.		down occurs when locked or automat-	
physical effort See Owner's Manual	675	op.: max. XXX km/h Start not poss.		ically in a few minutes	66
Steering malfunction Stop		in XXX km	724	Vehicle rising Please wait	70
immediately See Owner's Manual	675	Top up AdBlue XX,X I Switch		Warning tyre malfunction	72
Stop vehicle Leave vehicle on		vehicle on, wait 60 sec. or engine		Wheel sensor(s) missing	71
to charge the 12 V battery	716	start not poss	725	Active Blind Spot Assist currently	
STOP Vehicle level too low	700	Top up coolant See Owner's		unavailable See Owner's Manual	70
		Manual	680	Active Blind Spot Assist inoperative	70

Auxiliary battery malfunction (white		Driver camera inoperative See Own-		Limiter inoperative	60
display message)	695	er's Manual	71.2	Low beam setting (left/right-side traf-	0,7
	000		/ 1 Z	0 (, 0	4 5
Cannot start vehicle See Owner's	=	Driver camera view currently restric-		fic) Manual adjustment only	00
Manual	, /18	ted See Owner's Manual	711	N automatically activated Please	
Change steering wheel/ seat position		Front passenger airbag disabled See		engage transmission position again	68
until 6 dots are visible on the upper		Owner's Manual	648	N is selected Please select desired	
edge of the screen	712	Front passenger airbag enabled See		transmission position	68
Check brake pads See Owner's Man-		Owner's Manual	649	Occupant presence reminder inopera-	
ual	691	Hazard warning lamp system Malfunc-		tive	65
Check low beam setting (left/right-		tion	659	Only select P when vehicle is station-	
side traffic)	657	Head-up display Brightness currently		ary	68
Check tyre pressure, then restart Run		reduced See Owner's Manual	674	PARKTRONIC and manoeuvring assis-	
Flat Indicator	723	Head-up display currently unavailable		tant unavailable at rear when towing a	
Consult workshop without changing		See Owner's Manual	673	trailer	71
the transmission position	685	Head-up display inoperative	674	PARKTRONIC inoperative See Own-	
Cruise control and Limiter inoperative	697	Inoperative indicator lamp in driver		er's Manual	71
Cruise control inoperative	697	display. Consult workshop	666	Place the key in the marked space	
Cruise control off	697	Limited availability of Active Parking		See Owner's Manual	65
DIGITAL LIGHT Functions limited	657	Assist manoeuvring assistant See			
		Owner's Manual	714		

Please place key in the cup holder or Digital Vehicle Key in inductive charg- ing bracket See Owner's Manual Please teach in trailer coupling again	653	Run Flat Indicator inoperative Snow chain mode Maximum speed exceeded Speed limit (winter tyres) XXX km/h	723 677 698	Vehicle is ready to drive Shutdown occurs when locked or automatically in XX mins	669 679
using the button in load compartment		Speed Limit Assist currently unavaila-		Displaying road names/house numbers	401
Wait for it to extend/retract	673	ble See Owner's Manual	698	Distance control	228
Possible to start the vehicle again	718	Speed Limit Assist inoperative	698	Distance warning	243
PRE-SAFE impulse side inoperative		To switch off the vehicle, press the		DISTRONIC	228
See Owner's Manual	712	Start/Stop button for at least 3 sec-		Door	
PRE-SAFE inoperative See Owner's		onds or 3 times	679	Additional door lock	
Manual	712	Traffic Sign Assist currently unavaila-		Child safety lock (rear door)	
PRE-SAFE PLUS inoperative See Own-		ble See Owner's Manual	699	Emergency key Opening (from the inside)	. 90 86
er's Manual	712	Traffic Sign Assist inoperative	699	Power closing function	
Reversing not poss. Consult workshop	685	Transmission Malfunction Stop	685	recessed door handles	
Risk of vehicle rolling away Apply		Tyre press. monitor currently unavaila-		Unlocking (inside)	86
parking brake to park	683	ble	718	Door control panel	4.0
Risk of vehicle rolling away Driver's		Tyre press. monitor inoperative	719	Seat operation	18
door open Transmission not in P	683	Tyre pressure Check tyres	722	Door handles	0.7
Risk of vehicle rolling away N activa-		Tyre pressure monitor inoperative No		Extending/retracting	
ted manually No automatic switch to P	684	tyre pressure sensors	719	Drag Race, Drag race	365
•				Drinks holder	140

Drive Away Assist	285	Seat heating	121	Driving tips	
Drive position	200	Driving abroad		General driving tips	
Drive program display	195	Light adjustment low beam	147	Light adjustment when driving abroad Optimised acceleration	
Drive programs	195	Driving safety system ABS (Anti-lock Braking System) Active Brake Assist		Rear axle steeringRunning-in notes	191
Driver camera Activating/deactivating Function		Adaptive brake lightsATTENTION ASSIST		Drowsiness detection Duplicate key	. 80
Menus Navigation menu Notes	310 312 306 311 304 305 468	Blind Spot Assist/Active Blind Spot Assist	255 215 224 220 218 221 220	Dynamic handling control system DYNAMIC SELECT Configuring drive program I Displaying engine data Displaying vehicle data Drive program display Drive programs Function Selecting the drive program.	195 196 195 195 194
Status displays		OverviewRadar and ultrasonic sensors	216 215	E	
Warning/indicator lamps 12, 14,	729	STEER CONTROL	220	E-mails	320
Driver's seat Adjusting (Seat Comfort) Adjusting electrically Easy entry and exit feature	114	Traffic Sign Assist Trailer Manoeuvering Assist Your responsibility Driving system	292 215	E10 petrol Easy entry feature Setting	
	0	Dilville System	210		

Easy exit feature		Emergency		ENERGIZING Coach	
Setting	126	Fire extinguisher	487	Calling up	373
EBD, Electronic Brakeforce Distribution	220	First-aid kit (soft sided)	486	Function	371
ECO Assist 48 V on-board electrical system	193	Overview of aids	485	ENERGIZING COMFORT Overview of programmes Starting the programme	
ECO display	192	Emergency braking		Engine	007
ECO start/stop button Automatic engine start/stop ECO start/stop function Automatic engine start	191	Active Brake Assist	218 213	Emergency operation mode Engine number Starting (Digital Vehicle Key) Starting assistance	630 183
Automatic engine stop Function Switching off/on	191	Emergency call Automatic Manual	440 441	switching off (start/stop button)	209
Electric parking brake Applying automatically	211	Emergency call system Mercedes me connect		Displaying DYNAMIC SELECT	196 196
Emergency braking		Emergency key		Engine electronics	526
Manually applying/releasing Releasing automatically		DoorInserting/removing		Engine number	
Electrical fuses Electromagnetic compatibility Declaration of conformity Electronic Stability Program		Emergency operation mode Start the vehicle Emergency stop assistant ENERGIZING Biofeedback Calling up	239	Engine oil Additives Capacity Checking the oil level using the driver display MB-Freigabe or MB-Approval	638 473

Quality Temperature (driver's display) Topping up	311	Exhaust gas aftertreatment, diesel engine Exit warning MBUX Interior Assistant	636 348	Filling station search Starting automatic search Switching the automatic search on/off	
Engine oil temperature (driver's display) Engine output, current (driver's display) Engine starting Start/stop button Entering characters Function/notes On the touchscreen Setting the keyboard language	311 182 342 343	Exiting a parking space Active Parking Assist	275 285 271	Fine particle status display Fingerprint sensor MBUX multimedia system Fire extinguisher First aid First-aid kit (soft sided) Fitting Snow chains	33 48 48
Environmentally friendly driving ERA-GLONASS test mode ESC, Electronic Stability Control	443	Factory settings MBUX reset function		Tyres/wheels	2
ESP® Activating/deactivating	219 218 219 630	Fault message Driver's display Favourites Adding a destination Home address Work address Fill level AdBlue®	380 380 380	Flat towing Pulling/towing Flat tyre Notes TIREFIT kit Wheel change Floor mats Fog light (extended range).	48 48 51 14

Foil covering		Diesel		Operating	436
On camera/sensors		Diesel quality		Gearshift	
Radar and ultrasonic sensors	215	E10		DIRECT SELECT lever	196
Fragrance	175	Low outside temperatures		Manual	
Fragrance system		Petrol	633 633	Gearshift paddles	
Activating/deactivating	175	Quality (petrol)		Steering wheel gearshift paddles	201
Inserting/removing the flacon		Refilling Reserve	636	General driving tips	187
Perfume vial		Sulphur content		Genuine parts	
Setting	175	Tank content			
Free software	. 38	Fuel reserve	636	Glide mode	202
Frequencies		Function seat		Glove compartment	
Mobile phone	527		. 10	Locking/unlocking	133
Two-way radio		Fuses	F00	Grab handles	
Front airbag	. 45	Boot		Notes	111
Front headlamps		Cockpit Engine compartment		Gross mass	630
Front passenger display		Front passenger footwell		н	
Information	458	Fuse assignment diagram			
Operating	458	Notes	505	Handbrake	211
Front passenger seat		•		Handling characteristics	
Adjusting (Seat Comfort)	112	G		Unusual	509
Adjusting electrically		G-meter, Accelerometer	311	HANDS-FREE ACCESS	. 96
Fuel		Gallery app		Hands-free system	412
Additives	634	Content sharing	436	Hazard warning lights	
				5 5	

Hazard warnings		Help call		In-Car App Pass	44
Car-to-X communication	399	Mercedes-Benz emergency call system	440	In-Car Apps	
Head restraint		High beam	149	Installing	44
Adjusting (rear)		High-pressure cleaner	478	In-Car Calendar	
adjusting manually (front, 4-way)		Hill Start Assist	221	Calling up	
Removing/fitting (rear)	119	HOLD function		Selecting functions (calendar entry)	42
Head-up display	482	Function	220	Increase in traffic information volume	
Care Function		Switching on/off	221	Setting	46
Memory function		Home screen		Indicator lamps/warning lamps	
Operating		Central display	330	PASSENGER AIR BAG	
Switching on/off				Indicator/warning lamps	72
Headlamp flashing	149			Individual drive program	
Headlamp range control	152	i-Size child restraint system		Configuring	19
Headlamps		Fitting	. 62 . 62	Inside rearview mirror	16
Heating		Suitable seats	. 02	Intelligent Light System	
Activating/deactivating	169	Identification plate	(00	Activating/deactivating	15
Centre console		EngineVehicle	630 630	Active headlamps	
Climate control				Adaptive Highboom Assist	
Panel heating	122	Immobiliser		Adaptive Highbeam Assist Plus Assistance functions	
Rear window		Implied warranty	. 34	Bad weather light	
SeatStationary hoater		Importer information		City lighting	
Stationary heaterSteering wheel		Regulatory radio information	629	Cornering light	
	. 20				

Enhanced fog light function	151	Setting up a Wi-Fi hotspot	357	Storage location	518
Motorway mode	151	Web browser in the background	451	Jump-start connection	496
Overview		Web browsers	450	Jump start sommostion	., .
Topographical compensation	152	Internet connection		K	
Interior lighting		Cancelling permission (mobile phone)	448	Key	
Ambient lighting	160	Disconnecting automatically (commu-		acoustic locking verification signal	77
MBUX reading light	349	nication module)	447	Battery	
Setting	159	Displaying the connection status		Deactivating a function	
Switch-off delay time	161	Establishing	448	Emergency key	
Interior protection	110	Information		Energy consumption	
	110	Overview of connection status	448	Function	
Intermediate destination	204	Restrictions	445	Key ring attachment	
Editing	300	Setting up (communication module)		Problem	
Starting an automatic filling station search	389	Setting up (Wi-Fi)	447	Replacement key	
Starting the automatic service station	309	Ionisation	175	Unlocking setting	
search	389	iPhone®		KEYLESS-GO	
Internet		Smartphone integration	423	Deactivating	. 77
Calling up a web page	449	ISOFIX child restraint system		Locking/unlocking the vehicle	
Calling up the web browser settings		Fitting	62	Problem	
Calling up web browser options		Suitable seats	. 60 60	Unlocking setting	77
Deleting a bookmark		Cultuble Scuto	. 00	Kickdown	
Deleting browser data					
Managing bookmarks		look		Knee airbag	. 45
Mercedes me connect		Jack	20		
		Declaration of conformity	. 30		

		Adaptive brake lights	222	Turn signal light	14
Long Change Assistant	2.41	Adaptive Highbeam Assist	155	Limiter	
Lane Change Assistant		Adaptive Highbeam Assist Plus	156	Activating/deactivating 225,	. 23
Lane Keeping Assist	258	Assistance functions	152	Buttons	
Lane recognition		Automatic driving lights		Calling up a speed	
Active Lane Change Assist	241	Bad weather light	152	Function	22
Lane recognition (automatic)		City lighting	152	Passive mode	22
Active Lane Keeping Assist	258	Combination switch	149	Permanent setting	
· -	200	Cornering light	151	Requirements:	
Language	250	DIGITAL LIGHT		Selecting	
NotesSetting	338 350	Fog light (extended range)	151	Setting a speed	
_	336	Hazard warning lights		Storing a speed	22
Last destinations		High beam		LINGUATRONIC	
Selecting	377	Intelligent Light System		Live Traffic Information	٠.
Level control		Interior lighting			20
AIRMATIC	261	Light adjustment when driving abroad	147	Displaying traffic map	
Light adjustment		Locator lighting	159	Displaying traffic incidents	
Driving abroad	147	Motorway mode	151	Extending a subscriptionInformation of the service provider	
_		Reading lamp	159 148	Registering on Mercedes me	
Light switch	147	Rear fog light			07
Lighting		Responsibility for lighting systems		Load capacity	, ,
Intelligent Light System		Setting low beam Switch-off delay time		Bicycle rack	64
Interior lighting	159	Switching the Intelligent Light System	1 39	Loading	
Lights		on/off	154	Bag hook	13
Active headlamps	150	Topographical compensation		Roof luggage rack	13

Tie-down eyes	137	Lumbar support	117	Changing an area	403
Loading guidelines	129			Deleting an area	
Loads		M		Displaying online map contents	
		Maintaining safe distance		1 7 8 -	
Locator lighting	159	Active Distance Assist DISTRONIC	231	1 7 0 1	405
Locking/unlocking		Maintenance	468	Displaying the map version	
Additional door lock			100	Displaying the range	
Automatic locking (MMS)		Maintenance Management	4.70	1 7 8	
Digital Vehicle Key		Notes		1 7 0	397
Doors (from the inside)	86	Transferred data	469	1 7 8	406
Emergency key	90	Malfunction		Map data	405
KEYLESS-GO	87	Restraint system	. 40	Moving	401
Mercedes me connect	85	Manoeuvering brake function	287	Route overview after start	
Loud sound			207	Selecting additional information	
PRE-SAFE® Sound	51	Manoeuvring	005	Selecting POI symbols	
	01	Drive Away Assist			401
Low beam	4.47	Manoeuvering brake function	287		
Activating/deactivating		Manoeuvring assistant		Updating	404
Left-hand/right-hand traffic		Activating/deactivating		Map functions	401
Light adjustment when driving abroad		Cross traffic warning	286	Massage programmes	
Setting	158	Drive Away Assist	285		
Low-emission zone		Manoeuvering brake function	287	Maximum full-stop braking	218
Avoiding/exiting	382	Map		Maximum permissible gross vehicle mass	630
lubricants	632	Avoiding an area	403	Maximum speeds	641
Luggage	129	Avoiding an area (overview)	403	•	

MBUX Interior Assistant		Home screen	330	Operable functions	317
Camera & parking	352	Language settings	316	Operating safety	316
Driver camera	352	MBUX Interior Assistant		Setting	317
Exit warning	348	Memory Park Assist	292	Speech quality	318
Lasers and laser classification	345	Mercedes me & Apps		Voice commands	319
Notes on fastening the child seat	349	Operating the zero layer	328	Voice prompting	316
Opening/closing the roller sunblind		Overview		Mecca	405
on the rear window	350	Set collision detection		Media mode	
Opening/closing the roller sunblind		Setting route-based speed adaptation		Adding a favourite song	157
on the sliding roof		Snow chain mode	510		437
Opening/closing the sliding sunroof		Starting the ENERGIZING COMFORT		Connecting Bluetooth® audio equip-	456
Overview		programme	369	ment	
Preselection outside mirrors	350	Steering wheel heater/seat heating	125	Connecting USB mass storage devices	
Reading light	349	Switching the sound on/off	342	Controlling media playback	457
Search light	349	Touchscreen	333	Copyright and trademarks	
Selecting settings	352	Zero layer	325	InformationInformation about the search function	458
MBUX multimedia system		MBUX reading light	349	in categories	457
Air conditioning menu		MBUX search light	349	Overview of the media menu	455
Authorisations		MBUX voice assistant		Playing back similar music tracks	457
Calling up the zero layer		E-mails	320	Removing a favourite song	457
Display settings		Function		Starting a search in categories	457
Drive programs		Language setting		Starting and operating playback	458
ENERGIZING seat kinetics		Media voice commands		Starting media playback	457
Factory setting		Online voice commands		Supported formats and data storage	
Fingerprint sensor	334	Online voice control		media	453

Surprise mix	457 457	Calling up your user accountUnlinking the user account		OverviewSelf-diagnosis	
Medical aids		Mercedes me Apps	435	Mercedes-Benz GenuineParts	. 24
Memory function		Mercedes me calls		Mercedes-Benz service centre	33
1 1 2	128	Arranging a service appointment	431	Message memory	644
	128	Calling the Mercedes-Benz Customer		Messages	
SeatSteering wheel		Centre after automatic accident/ breakdown detection	430		422
	120	Calls via the overhead control panel	429	Configuring the displayed text mes-	
Memory Parking Assist	291	Consenting to the transfer of data	431	sages	
0 1 0 1	291 288	Information	429	Deleting	
	200 290	Mercedes-Benz Customer Centre	430	Dictating	421
	290 289	Transferred data		0	
8		Mercedes me connect			
0	292		121	Overview	
Menus (driver's display)		Accident/Breakdown Management		Read-aloud function	421
Assistant display	310	Information		Reading	421
Navigation	311	Transferred data	434	Replying	421
Notes	306	Mercedes-Benz emergency call system		Sending	421
Operating	307	Automatic emergency call	440	Using a phone number or URL	422
	309	Data processing		Mirrors	
Sport	311	Data transfer		Mirror folding function	167
Mercedes me App		ERA-GLONASS test mode	443	Outside mirrors	164
Activating on-demand features Calling up services		InformationManual emergency call			165
outilities ab oct vioco	100	÷ ,			

Additives	P		PARKTRONIC	
Brake fluid	Paint code	630	Remote Parking Assist	281
Coolant			Parking brake	211
Diesel	Panel heating	IZZ	Parking charges	
Engine oil	Park position	10/	Paying	409
Petrol	DIRECT SELECT lever	196	Parking lights	
Windscreen washer fluid	Parking		Parking option	
Operating safety	Active Parking Assist	275	Displaying on the map	408
48 V on-board electrical system	PARKTRONIC			+00
	0	408	Parking position Outside mirrors	166
Outside mirrors Automatic anti-dazzle mode	Parking Assist		Storing the position of the passenger	100
Automatic mirror folding function	Active Larking Assist	275	outside mirror using reverse gear	166
Blind Spot Assist/Active Blind Spot	Memory Parking Assist	288	0 0	100
Assist	PARKTRONICRemote Parking Assist		Parking service Displaying a parking option on the map	4 ΩΩ
Folding in/out	_	201	Paying parking charges	
Memory function 128	Parking Assist PARKTRONIC	0.74	Prior booking of a parking space	
Parking position	Activating/deactivating		Selecting parking options	
Preselection MBUX	Adjusting warning tones Function		Parking space	
Setting		2/1	Finding	407
Warning lamp	Parking assistance systems	0.75	_	
Overhead control panel 16	Active Parking Assist		Parking up	
Overview of airbags 45	Drive Away Assist		PARKTRONIC	271
	Manoeuvering brake function Memory Parking Assist		PASSENGER AIR BAG	
	Michiory Larking Assist	200	Status display, front passenger airbag	. 49

Setting a channelSetting station tracking	463	Rain sensor Side windows		Recordings Camera app	467
Setting the frequency band Setting the traffic information service	461	Sliding sunroof		Recycling	. 23
volume increaseShowing/hiding lyrics	463 463	Range AdBlue®	309	Reducing agent AdBlue®	207
Station suggestionStoring radio stations	462	REACH regulation		Refuelling Fuel	
Switching a slide show off/on Radio (audio system)	462	Reading lamp Interior lighting	159	Refuelling the vehicle Topping up AdBlue [®]	203 207
Switching traffic announcements	463	Rear axle steering		Registration	. 33
on/off	463	Rear compartment climate control	. 72	Remote Parking Assist Authorising a mobile phone Function Operating	281
Radio regulations Importer information Regulatory radio identification Specific absorption rate	629 532 628	Rear fog light	148	Replacement key Reserve Fuel	
Wireless applications	528	Rear window Roller sunblind		Resetting MBUX reset function	
		Rear window heater Rear-view mirror Automatic anti-dazzle mode		Residual heat Responsibility Driving safety systems	

Restraint system	Rear window	107	Starting the automatic service station	
Basic instructions for children 53	Side windows	106	search	389
Function in the event of an accident 40			Switching the automatic filling station	
Functionality	Roof load		search on/off	389
Limited protection	Roof luggage rack		Route guidance	
Malfunction	Loading	139	Cancelling	39
Protection	Securing		Changing direction	39
Self-test	, <u> </u>	107	Destination reached	39
Warning lamp 40		000	Lane recommendations	39
Reverse gear	Adjusting on the map		Motorway information	39
DIRECT SELECT lever 196	Alternative route	-	Notes	
Reversing camera	Calculating	381	Off-road	39
360° Camera	Calculating alternative routes		Route guidance with augmented reality	
) Commuter route 301			40
Activating/deactivating	, Diopinging describation in crimation		0	40
	Displaying the route list	387	Activating/deactivating the traffic	0.5
Function	Luiting a stored route	389	light view	25
Opening the camera cover		382	Displaying road names/house num-	4.0
Setting	Navigation	374	bers	
Roll away protection			Overview	40
Roller sunblind	Recording		Route-based speed adaptation	
Opening/closing on the rear window	Saving a recorded route	390	Function	23
(MBUX Interior Assistant)	Selecting a type	383	Setting	23
Opening/closing on the roof (MBUX	Selecting notifications		Running-in notes	
Interior Assistant)	Colocting antique		Talling III 110000	10
interior Addictanty	Starting a saved route			

S		Resetting settings (massage pro-		Seat heating	
Safety system	216	gramme)		Activating/deactivating	121
Safety vest		Settings		Seat height	114
		Side airbag Workout programme		Seat kinetics	
Satellite map	400		121	Setting	368
Saving a destination suggestion as a	205	Seat belt Activating/deactivating seat belt		Seat ventilation	123
favourite	395	adjustment	. 44	Selecting a gear	201
Searching for a channel	462	Adjusting the height	. 43	Selecting the sound profile	
Seat		Automatic tightening	. 44	Burmester® 4D surround sound sys-	
Adjusting (Seat Comfort)		Care	482	tem	465
Adjusting electrically		Fastening	. 43	Selector lever	
Automatic adjustment Centre airbag (driver's backrest)		Protection		Self-test	1,0
Configuring settings		Rear seat belt status display		Automatic front passenger airbag shut	
Correct driver's seat position		Reduced protection Releasing		off	49
ENERGIZING seat kinetics		Warning lamp		Restraint system	
Folding back the backrest (rear)		Seat belt adjustment		Sensors	
Folding the backrest forwards (rear)		Activating/deactivating	. 44	Cleaning	481
Locking the backrest (rear)		Function		Service	
Lumbar support		Seat belt tensioners		Menu (driver's display)	309
Massage programmes Memory function	128	Deployment	. 40	Service centre	
Panel heating		Seat belt warning		Service due date	
<u> </u>					
				Service interval display	468

Service station search		Roller sunblind	106	Setting the balance and fader	464
Starting automatic search 3	389	Skid chains	509	Spare parts	. 24
Setting the date format	355	Sliding sunroof		Spare wheel	
Setting the distance unit	358	Automatic functions	104	Emergency spare wheel	524
Shifting		Close with key		Specialist workshop	. 30
•	201	Opening with the key		Specific absorption rate (SAR)	
Gearshift recommendation 2	202	Opening/closing	102		020
Manual 2	201	Opening/closing (MBUX Interior	0.51	Speed	221
Steering wheel gearshift paddles	201	Assistant)	351 105	Limit, Limiter Save, cruise control	
Shortening the braking distance		ProblemRain closing function		Save, DISTRONIC	
Brake Assist System 2	218	_		Save, Limiter	
Shunting assistant	292	Snow chain mode		Speed adjustment, route-based	
_	286	Snow chains	509		20.
Side airbag		Socket		Speed control Active Distance Assist DISTRONIC	220
_	45	12 V (front passenger footwell)	143	Cruise control	
Side windows	1.00	Trailer operation	297	Limiter	
Automatic function		SOS button	429	Speed limit	22\
	101	Sound		Winter tyres	228
	101	PRE-SAFE® Sound	. 51	-	220
	100	Wheels/tyres	509	Speed Limit Assist	240
Opening/closing	99	Sound settings		System limits	
Problem1		Adjusting treble, mid-range and bass		Standing lights	14,
Rain closing function 1	100	settings	464		

Start-off assist		Storing	462	Manually adjusting	123
Drive Away Assist	285	Station list		Memory function	128
Hill Start Assist	221	Calling up	461	Steering wheel adjustment	124
Optimised acceleration	186	Station presets		Steering wheel gearshift paddles	201
Start/stop button	000	Managing	462	Steering wheel heater	
Parking the vehicle		Station suggestion		Linking to seat heating	125
Switching on the power supply / vehi-	102	Radio	462	Stop/start	
cle	181	Station tracking		ECO start/stop function	192
Start/stop function	191	Setting	463	Stopping	
Starting assistance		Stationary heater/ventilation		Parking the vehicle	209
Starting the engine	170	Activating/deactivating	177	Stowage areas	131
Emergency operation mode	185	Status display		Stowage space	
Start/stop button	182	Front passenger airbag	. 49	Centre console (front)	132
Starting-off aid		Rear seat belt	. 44	Stowage spaces	
Drive Away Assist	285	Steer Assist		Armrest	131
Hill Start Assist	221	Active Steering Assist	237	Centre console (front)	131
Optimised acceleration	186	STEER CONTROL		Door	131
Station		STEER CONTROL	220	Glove compartment	131
Deleting	462	Steering		Streaming online music	459
Entering a frequency directly		Rear axle steering	191	Suggestions	
Frequency fix	463	Steering wheel		Configuring	359
Moving		Adjusting electrically		Deleting	
Setting	461	Driver's airbag	45		

Sulphur content	633	T		Telediagnosis	
Suspension		Tabs		Diagnostic data	46
AIRMATIC	261	Managing	451	Telediagnostics	
Setting the suspension level (AIR-				Transferred data	47
MATIC)	262	Take-back of end-of-life vehicles	. 23	Telemetry display	36
SVHC		Tank content			00
Substances of very high concern	34	AdBlue [®]	637	Telephone	4.4
, 0	. 01	Fuel	636	Activating functions during a call	41
Switch-off delay time	1.50	Reserve	636	Authorising a mobile phone Remote	0.0
Exterior		Tank filler cap / flap	203	Parking Assist	
Interior	161		200	Calls with several participants	
Switching air-recirculation mode on/off	174	Technical data	(10	Changing a function	
System PIN protection		Axle load (trailer operation)		Connecting a mobile phone	41
Activating/deactivating	358	Fastening points of the trailer hitch	641	Deleting a mobile phone	
	000	Information		Emergency call	
System settings		Maximum speeds		Importing contacts	
Activating/deactivating system PIN	0.50	Mounting dimensions of a trailer hitch		Importing contacts (overview)	
protection		Overhang dimension of the trailer hitch		Incoming call during an existing call	
MBUX reset function		Pyrotechnical vehicle components	528	Information	
Setting the distance unit		Radio frequencies		MBUX voice commands	
Setting the time zone		Radio regulations		Mobile phone usage	
Setting the time/date format		Roof load		Notes	41
Transmission of the vehicle position	355	Specific absorption rate (SAR)		Notes on wireless charging (mobile	
		Tongue weight		phone)	
		Towing capacity		Secure Simple Pairing	41
		Vehicle dimensions	640	Switching between mobile phones	41

Telephone menu overview		Tone settings		Towing methods	498
Telephone operation		Calling up the sound menu	464	Towing eye	
Voice recognition	416	Information		Fitting/removing	504
Wirelessly charging a(mobile phone,	144	Tongue weight	642	Storage location	504
front)	144	Top Tether	. 64	Towing methods	
Television, Digital TV	320	Topographical compensation, Predictive		Both axles on the ground	499
MBUX voice commands	320	headlamp range control	152	Overview	498
Temperature	1 / 0	Torque (driver's display)		Track Race	363
Setting	108	Touch Control		Traffic announcements (audio system)	
Temperature and airflow	. = 0	Driver's display	305	Switching on/off	463
Setting	1/0	MBUX	332	Traffic information	
Text messages	320	Setting the sensitivity		Activating	398
THERMOTRONIC		Touch-sensitive controls		Car-to-X-Communication	398
Air conditioning control panel	168	Touchscreen	. 20	Displaying the traffic map	
Tie-down eyes	137	Entering characters	343	Displaying traffic incidents	397
Time		Switching haptic operation on and off		Extending a Live Traffic Information	00/
Manual time setting	355	Tow bar system	001	· ·	396
Setting the time zone		Towing away	302	Information about Live Traffic Informa- tion	306
Setting the time/date format	355	9 ,		Overview	
TIREFIT kit		Tow-away protection		Registering Live Traffic Information	
Declaration of conformity	. 31	Tow-starting	505	Traffic Jam Assistant	
Storage location		Towing		-	230
		Pulling/towing	302	Traffic light view	055
				Activating/deactivating	255

Information	254	Trailer Manoeuvering Assist		Transporting	
Traffic light warning/display	250	Function	292	Vehicle501	
Traffic restrictions		Trailer Manoeuvring Assist, Manoeuvring assistant		Turn signal indicator	
Activating/deactivating Service		Operation	293	Turn signal lightTV	149
Traffic Sign Assist		Trailer operation	257	MBUX voice commands	320
Function Setting		Active Blind Spot AssistActive Lane Keeping Assist	258	Two-way radios Frequencies	527
Trailer coupling	295	Bicycle rack		Installation	526
Trailer drawbar, Pulling/towing	302	Coupling up/uncoupling a trailer	297	Transmission output	
Trailer hitch		Extending/retracting the ball neck	295	Type approval number EG	630
Axle load	643	Making settings	300	Tyre pressure	
Bicycle rack		Notes		Checking	512
Care		Socket		TIREFIT kit	488
Coupling up/uncoupling a trailer		Trailer stabilisation	219	Tyre pressure loss warning system,	- 4
Extending/retracting the ball neck		Transferred vehicle data		function	514
Fastening points	641 641	Android Auto	428	Tyre pressure loss warning system,	E 1 .
General notes		Apple CarPlay [®]	428	restarting Tyre pressure table	51.
Overhang dimension		Transmission position display	196		51
Socket		Transmission positions		Tyre pressure loss warning system	Г1.
Tongue weight		DIRECT SELECT lever	196	Function	
Towing capacity		DINEOT OLLLOT ICVCI	1/0	Restarting	514
Trailer Manoeuvering Assist					

	512	Tyre pressure loss warning system,	514	USB port (multimedia system) Connecting mass storage devices	456
Tyre sealant		Tyre pressure loss warning system, restarting Tyre pressure table Unusual handling characteristics	511	User profiles, Personalisation Adding a user Notes Overview	335 335
Tyre-change tool		U	4.4	Requirements for use	335 339 337
Tyre-change tool kit Overview Tyres	518	Units of measurement Setting		Selecting options	339
Breakdown Checking Fitting Interchanging Noise Notes on fitting Removing Removing/fitting hub cap Replacing Selection Shows a series of the series of t	509 522 517 509 515 522 519 519 515 509 518	Unlocking setting Digital Vehicle Key Updating software Error message Information Performing URL Sharing USB port Rear Stowage compartments (front)	85 361 360 360 451 143	V Variable limiter Vehicle 48 V on-board electrical system Additional door lock Correct use Data storage Diagnostics connection Emergency key Implied warranty KEYLESS-GO lock automatically (MMS) Locking (digital vehicle key)	. 26 . 85 33 . 35 32 90 . 34 87

Locking/unlocking (from inside)	Vehicle camerasVehicle data	215	Vehicle level Setting (AIRMATIC)	26
gency key	Displaying, DYNAMIC SELECT Displaying, MBUX	195	Vehicle location Switching transmission on/off	35
Medical aids	Maximum speeds	641	Vehicle position Storing	39
Raising 520 REACH regulation 34	Transferring to Android Auto Transferring to Apple CarPlay [®] Vehicle height		Vehicle sensors Vehicle start	21
Registration	Vehicle length Vehicle width	640 640	Emergency operation modeStart/stop button	
Starting (Digital Vehicle Key)	Wheelbase Vehicle dimensions	640 640	Vehicle tool kit TIREFIT kit	
Stopping	Vehicle emergency start Vehicle identification number	505 630	Towing eye Ventilating	10
Switching off	Vehicle identification plate Axle load	630	Ventilation Vents	17
Switching on (start/stop button) 181 Towing 302 Towing away 498	EU type approval numberGross mass	630 630	Air vents Video recordings	17
Transporting	Model typePaint code	630 630	Gallery appVIN	43
ventilate / comfort opening	VIN Vehicle key		Engine compartmentldentification plate Seat	630

VISION Domisting windows		tric parking brake indicator		Power steering warning lamp	
Demisting windows	/ 4 lamp (yellov	N)	739	(yellow)	733
Voice assistant Voice prompting	16	trical fault warning lamp		Rear axle steering warning	70.4
Voice recognition4	16	ne diagnostics warning		lamp (red)	/34
				Rear axle steering warning	
W	■ Engir	ne operating temperature		lamp (yellow)	734
Warning system 10)7 warning lan	np	738	Restraint system warning lamp	731
Warning triangle 48	B6 ₽ ESP®	® OFF warning lamp	743	Seat belt warning lamp flashes	731
Warning/indicator lamp	₽ ESP®	warning lamp flashes	742	§ Seat belt warning lamp lights up	732
(ABS warning lamp 74	41 📳 ESP®	warning lamp lights up	742	Suspension warning lamp (red)	745
Active Brake Assist warning	Fuel	reserve warning lamp		Suspension warning lamp (yel-	
lamp 744, 74	lights up		738	low)	745
ATTENTION ASSIST warning	sos Not READY Merc	cedes-Benz emergency call		Traffic Sign Assist warning lamp	746
lamp 74	43 system war	ning lamp	746	Trailer hitch warning lamp	733
(D) Brakes warning lamp (red) 74	4.0	upant presence reminder		(!) Tyre pressure monitoring sys-	
(D) Brakes warning lamp (yellow) 73	39 warning lan	np (white)	732	tem warning lamp flashes	747
Coolant warning lamp (red) 73	35 🕌 Occi	upant presence reminder		(!) Tyre pressure monitoring sys-	
Loolant warning lamp (yellow) 73	37 warning lan	np (yellow)	732	tem warning lamp lights up	747
Electric parking brake indicator	9 ! Power	er steering warning lamp		Warning lamp for distance	
lamp (red)73	39 <u>(red)</u>		734	warning	744

Warning/indicator lamps		What3words		TIREFIT kit	48
Driver's display	729	Destination entry with a 3 word		Tyre pressure	51
PASSENGER ÁIR BAG	. 49	address	379	Tyre pressure monitoring system	
Washer fluid		Wheel change		Unusual handling characteristics	50
Topping up	476	Fitting a new wheel	522	Wi-Fi	
Windscreen washer fluid		Lowering the vehicle		Activating/deactivating	35
Washing by hand		Preparation		Information on connection	
		Raising the vehicle	520	Setting up a hotspot	35
Water tank	4//	Removing a wheel	522	Setting up an Internet connection	
Weather information	406	Removing/fitting hub caps		Window airbag	. 4
Web browser		Wheel rotation	517	Windows	
Calls up options		Wheels		Care	48
Deleting a bookmark		Breakdown	487	De-icing	
Deleting browser data		Care	481	Opening/closing	. 9
Managing bookmarks	451	Checking	509	Rear window	10
Web browsers		Fitting		Removing mist	
Calling up a web page	449	Interchanging		Roller sunblind	
Calling up the settings	450	Noise		Windscreen	
Setting in the background	451	Notes on fitting	515	De-icing	17
Sharing URLs	451	Removing		Demisting	
Wedge	518	Removing/fitting hub cap	519	Replacing the wiper blades	
Weight information		Replacing 515	, 519		
Weight information	030	Selection		Windscreen heater	
		Snow chains	509	Windscreen washer fluid	640
		Storing	518	Windscreen washer system	47

Windscreen wipers	4.40	Z	
Activating/deactivating Replacing the wiper blades Replacing the wiper blades (wind-		Zero layer Function	325
screen)	162	Overview	326
Winter operation Activating/deactivating snow chain			
modeSnow chains			
Winter tyres			
Limiter Setting the permanent speed limit	228 228		
Wiper blades			
Care	481		
Replacing (windscreen)	162		
Wipers	162		
Wireless applications	528		
Wireless charging			
Mobile phone (front)	144		
Overview	143		
Workout programme	121		
Workshop	. 33		

Publication details

Germany

Internet

Further information about Mercedes-Benz vehicles and about Mercedes-Benz AG can be found on the following websites:

https://www.mercedes-benz.com

https://group.mercedes-benz.com

Documentation team

You are welcome to forward any queries or suggestions you may have regarding this Owner's Manual to the technical documentation team at the following address:

Mercedes-Benz AG, HPC: CAC, Customer Service, 70546 Stuttgart, Germany

[©]Mercedes-Benz AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Mercedes-Benz AG.

Vehicle manufacturer

Mercedes-Benz AG

Mercedesstraße 120

70372 Stuttgart



Digital - in the vehicle

Familiarise yourself with the contents of the Owner's Manual directly via the vehicle's multimedia system (menu item "Vehicle information"). Start with the quick guide or broaden your knowledge with practical tips.



Vehicle document wallet

Here you can find comprehensive information about operating your vehicle and about services and guarantees in printed form.



Digital – on the Internet

You can find the Owner's Manual on the Mercedes-Benz homepage.



Digital – as an App

The Mercedes-Benz Guides App is available free-of-charge in familiar App stores.



Order no. ohne Part no. ohne Edition NA2023-03a



Apple® iOS



Android™