

# User Manual

# XORAYA N4000+





Edition: 1.0.1 / January 2022

#### © 2022 X2E GmbH

This user manual is copyrighted; all customary rights reserved. Reproduction of this manual, even in part, is only allowed with permission of X2E GmbH. Offenders shall be liable to pay compensation and may be subject to prosecution.

All product names and trademarks used in this manual are the property of their respective owners.

X2E GmbH Grosse Ahlmühle 19 76865 Rohrbach GERMANY

 Phone:
 +49 6349 99599 200

 E-Mail:
 xoraya@x2e.de

 Internet:
 www.x2e.de

 Wiki:
 wiki.x2e.de



TABLE OF CONTENTS

# Table of contents

1	Intro	duction	5
	1.1 1.2 1.3 1.4 1.5	About this user manual Validity of the user manual Representation conventions Pictograms X2E-Wiki	6 6 7
2	Safet	y and warranty	9
	2.1 2.2 2.3 2.4 2.5 2.6	Intended use Safety label on the device General safety instructions Product liability Terms of use Warranty	. 10 . 10 . 13 . 13
3	Produ	uct description	.15
	3.1 3.2 3.3	Identification Scope of delivery Connections and controls	. 17
4	Comr	nissioning	.25
	4.1 4.2 4.3 4.4 4.5 4.6 4.7	Unpacking Selecting an installation location Installing the N4000+ Installing the XORAYASuite Connecting the N4000+ to the measuring environment Connecting the N4000+ to the PC Configuring switches	25 25 26 27 30
5	XORAY	YASuite	.32
	5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14	Starting Menu bar Status bar Connecting and disconnecting the N4000+ Configuration Resetting to factory defaults Data recording Hdd-Download Viewer Statistic Convert Firmware-Update TK Commandline Common elements	. 33 . 36 . 37 . 40 109 110 118 124 143 145 148 150
6	-	tenance	
	6.1	Safety measures	
	6.2	Cleaning	

### **USER MANUAL**

### TABLE OF CONTENTS



	6.3	Repair	
7	Stor	age, transport and disposal	
	7.1 7.2 7.3	Storage Transport Disposal	
8	Арр	endix	
	8.1 8.2 8.3	Technical data N4000+ pin assignments Output formats	



# 1 Introduction

# 1.1 About this user manual

- Read this user manual completely before using the XORAYA N4000+ for the first time.
- Please consider this user manual as part of the product and make sure it is easily accessible.
- Provide this user manual upon transfer of the N4000+ to a third party.
- Request a replacement user manual upon loss.

This user manual contains important information for safe, proper and efficient operation of the N4000+. Following this user manual strictly helps in avoiding dangers, reduces repair costs and downtime, while increasing the reliability and service life of the N4000+. It should be read, understood and applied by those using the N4000+ according to the user manual.

Pay particular attention to:

- the safety section (→ Safety and warranty)
- the text warnings of each section

Bear in mind that this user manual does not replace your responsibility as a N4000+ user.

Subject to change without prior notice. This applies especially to changes relating to technical enhancements.

INTRODUCTION



### 1.2 Validity of the user manual

This user manual applies to X2E's dataloggers of the XORAYA N4000+ series. The exact type specifications can be found on the nameplate. ( $\rightarrow$  Identification)

The following instructions are key to operate the N4000+ and must be strictly observed under all circumstances.

Information in this user manual is subject to change without prior notice due to further technical developments and subsequent modifications. New features may not be described yet or may be described incompletely. Please ensure that you have the most current and complete user manual.

Users can change certain properties and functions via the included software, so that the N4000+ behaves differently than described herein. Users may revert to factory defaults at any time by pressing the default button on the front panel or via the supplied software. ( $\rightarrow$  Resetting to factory defaults)

### 1.3 Representation conventions

Representation	Meaning
<instruction></instruction>	User-executed action
<ul> <li><instruction 1="" option=""> or</instruction></li> <li><instruction 2="" option=""></instruction></li> </ul>	Instruction options
☑ <outcome></outcome>	Outcome of an action or a series thereof
<ul> <li><level 1a=""></level></li> <li>- <level 2a=""></level></li> <li>- <level 2b=""></level></li> <li><level 1b=""></level></li> </ul>	Maximum two-level enumeration
→ <cross-reference></cross-reference>	Clickable cross-reference to a section or heading
	(In most Windows programs, you can return to the previous position by pressing <i>ALT</i> + <i>Left arrow</i> )
<text></text>	Housing label, GUI element or other highlighting
#	Placeholder for numbers
(1) or (A)	Reference to numbered markers in graphics



# 1.4 Pictograms

This manual uses pictograms to highlight and ensure faster recognition of important or especially useful information.

Warning:



This type of symbols indicate warnings which must be observed.

The following subsections contain a description of the basic structure and relevance of different warning levels.

#### General information:



This symbol indicates general information.

General information includes application tips and particularly useful information excluding warnings or hazards.

#### Licence information:



This symbol indicates licence information.

Licence information contains either general information about licences for the N4000+ or indicates whether a licence is required for a particular function.

#### 1.4.1 Meaning of warnings

Warnings are systematised according to the severity and probability of their occurrence.



This pictogram in conjunction with the word *Caution* warns of a potentially dangerous situation, or an unsafe procedure.

Ignoring this warning information could result in injury or property and environmental damage.



This pictogram used in conjunction with the word *Warning* warns of a potentially imminent danger to the health and lives of people.

Ignoring this warning could cause serious personal injury, including death in the worst case.

#### INTRODUCTION





This pictogram used in conjunction with the word *Danger* warns of an imminent danger to the health and life of people.

Ignoring this warning causes serious personal injury, including death in the worst case.

#### 1.4.2 Structure of warnings

Warnings are separated from the surrounding text by lines set above and below.



#### Danger types and sources

Explanation and consequence of danger

Actions to prevent danger

#### 1.5 X2E-Wiki

The X2E-Wiki at *http://wiki.x2e.de* provides the following information:

- Latest software
- Latest firmware
- Latest licence file

For access details, please send an email stating your contact data to <u>wiki@x2e.de</u>. We will send you the appropriate access data. You may request your access details at any time if necessary.



SAFETY AND WARRANTY

# 2 Safety and warranty

The XORAYA N4000+ dataloggers were developed according to the latest state of the art and offer outstanding safety levels. During operation, however, this safety level can only be achieved if the user complies with all relevant safety regulations.

Upon measuring, safety regulations of the professional associations must be observed.

Please contact an expert or the service of X2E GmbH when in doubt about the operation, safety, or connection of the N4000+.

### 2.1 Intended use

The N4000+ is used for real-time acquisition of data communication in automotive bus systems. You can perform, store and transfer measurements to a PC, where you can read and analyse them using the GUI of the XORAYASuite.

- The N4000+ is intended for use only by trained personnel.
- The N4000+ must not be used in residential or living areas. Its use is strictly limited to industrial environments.
- The N4000+ must also not be used in outdoor areas or hazardous areas.
- Always operate the N4000+ within its technical specifications.
   (→ Technical data)
- The N4000+ may only be used under the conditions and for the purposes for which it was designed.
- Repairs may only be carried out by trained personnel of X2E GmbH.
- Operational safety cannot be guaranteed after modifications or conversions.
- Except for data buses, never perform measurements on live parts.
- The 4-mm plug of the power supply cable delivered must never be introduced in low-voltage sockets.
- The data lines may be extended up to a maximum of 30 m (USB: 3 m, eSATA: 1 m) provided that they are shielded like the supplied cables.
- The voltage supply may be extended up to a maximum of 3 m with sufficient cross-section.

SAFETY AND WARRANTY



#### 2.2 Safety label on the device

You find the following safety label on the N4000+ top side:



#### Burning hazard due to hot surfaces

Continuous operation can strongly heat up the N4000+. As a result, it can burn the skin on the hands when touching it.

Wear temperature-resistant ESD gloves when in contact with the N4000+.

#### **General safety instructions** 2.3



Electric shock caused by damage to components

Any damage to the N4000+, power source or connection cable may cause an electric shock.

- Switch on the N4000+ only if all components appear undamaged.
  - Only commission the N4000+ after a proper installation or repair.
  - Check the connecting cable regularly for defects to prevent damage to the power source.
- ► Always install the N4000+ in de-energised status.



WARNING

#### Defects influencing the environment

The incorrect N4000+ configuration can lead to the temporary or permanent functional failure of connected vehicles.

Connected vehicles being operated on public roads bear an increased risk of injury and damage.

- ▶ If available, use configuration templates provided by the vehicle manufacturer.
- Use preferably the passive recording modes of the interfaces.



#### Device damage due to short circuit

Bent connector pins pose a short circuit risk. This can lead to abnormal behaviour or destruction of the N4000+.

- Likewise, devices connected to the measurement setup may be also compromised.
  - Make sure that connector pins are not bent.
  - Check the N4000+ regularly for any deficiencies.



SAFETY AND WARRANTY



Device damage due to electrostatic discharge

Electronic components can be destroyed by electrostatic discharge.

- Avoid touching connectors and connector pins.
- Ground yourself before carrying the N4000+ in your hands.
- Operate the N4000+ in an ESD-compliant environment.



#### Device damage due to overheating

Overheating can lead to abnormal behaviour or destruction of the N4000+.

- Do not operate the N4000+ outside the specified
  - temperature range.
  - Never operate the N4000+ near heat sources.
  - Please ensure adequate air circulation for operation.
  - ▶ Do not cover the N4000+ with other objects.



#### Device damage due to shocks

Excessive vibration can lead to abnormal behaviour or destruction of the N4000+.

CAUTION



#### Device damage due to pollution

Avoid any contamination in plugs and sockets to ensure a reliable contact.

Avoid exposing the N4000+ to excessive vibration.



► Keep the N4000+ clean.




#### Device damage due to device opening

Unauthorised opening of the N4000+ can lead to abnormal behaviour or destruction of the device.

CAUTION

- Never open the N4000+.
- Contact X2E GmbH should maintenance and repairs be required.







# 2.4 Product liability

In the following cases, the intended protection of the N4000+ may be adversely affected. The liability is then transferred to the user.

- The N4000+ is not used according to the manual.
- The N4000+ is used outside the scope described in this manual.
- The user modifies the N4000+ without proper authorisation.

### 2.5 Terms of use

If the installation of the N4000+ in a vehicle is intended for operation on public roads, the user and the X2E GmbH must jointly perform a risk analysis beforehand. This analysis must take into account the specific installation requirements and the valid factory standards at the user's site.

Conditions set forth in framework contracts shall apply.

The N4000+ is continuously developed. The development process relies on the cooperation between the user and X2E GmbH.

#### 2.6 Warranty

The warranty period is 12 months. Device batteries, whether internal or external, are excluded from the warranty. The warranty also excludes damages arising from improper handling.

X2E GmbH guarantees that the media on which the software is located are free of material errors under normal operating conditions. Users can return any defective or materially erroneous media to X2E GmbH within a period of 30 days from date of original purchase. Media shall be replaced immediately at no cost.

X2E GmbH guarantees that the software as described herein is basically usable. X2E GmbH, however, shall assume no liability for the correctness and the continued use of the software, given that the current state of the art prevents the production of software suitable for all combinations of hardware and software.

In particular, X2E GmbH cannot guarantee that the software meets any user requirements, or that it is compatible with any programs the latter may have selected. Responsibility for program selection and the consequences of program use lie entirely with the user.



X2E GmbH shall assume no liability for damages arising from faulty recorded data, as well as damage due to incorrect configuration, data entry and data transfer.

After configuring, we recommend to verify the proper operation and plausibility of each sensor using some manual measurement over the entire measuring range.

X2E GmbH shall assume no further liability. This limitation of liability also applies to the personal liability of employees, representatives and organs of X2E GmbH.

# 2.7 FCC notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications made to this equipment not expressly approved by X2E GmbH may void the FCC authorization to operate this equipment.



**PRODUCT DESCRIPTION** 

# 3 Product description

The XORAYA dataloggers are processor-controlled storage units, designed to record data from several and different data sources simultaneously. These dataloggers are indeed unique in the automotive industry thanks to their central 100-ns timestamp on all interfaces. Furthermore, its modular design allows for a rapid and flexible adjustment to future demands. This is stressed by the fact that all product phases, i.e. from design and development to programming and production, are completed in-house.

The dataloggers can be equipped with many different interfaces:

- Lowspeed-CAN, Highspeed-CAN and CAN-FD
- FlexRay
- LIN
- RS-232
- PSI5
- Analog
- BroadR-Reach
- MOST25 and MOST150
- Ethernet 100Base-T and 1000Base-T
- GNLog and DLT via Ethernet and RS-232
- CCP and XCP
- GPS

The N4000+, based on the Xilinx Zynq<sup>®</sup> UltraScale+<sup>™</sup> MPSoC, is the new generation of the XORAYA datalogger. The built-in supercapacitor unit is able to bridge power fluctuations and to shut the N4000+ down safely in case of power failures.

Data can be directly saved to the storage medium (internally or externally) or to a computer system via Ethernet interface. Both modes can also be operated in parallel.

Operation can be managed via the graphical user interface XORAYASuite, whereby the N4000+ can be configured, and data recorded and downloaded from the N4000+. Moreover, you can evaluate the recorded data and export them to many popular formats.



# 3.1 Identification

The bottom side of the N4000+ bears a silver nameplate, which contains the following information:



- Type Product variant
- Config. First block: Product ID 0200 XORAYA Datalogger

Second block: Product variant 0720 XORAYA N4000+

Third block: Hardware revision

- Input Maximum current consumption at given standard input voltage
- S/N Unique serial number for this N4000+
- DMF Date of manufacture

Upon device-specific issues, always provide the serial number and configuration.

The interface configuration of a N4000+ is variable and, therefore, not recorded on the nameplate.



**PRODUCT DESCRIPTION** 

# 3.2 Scope of delivery

The following components are part of the delivery:

- XORAYA N4000+ with impact protection
- Power supply cable
- Software
- User manual
- Cable set, depending on the interface configuration

The following accessories are optionally available:

- Power supply cable with AC adapter (recommended)
- XORAYA External Storage Unit
- Additional cables
- Mounting material
- Device bag

Additionally, we recommend the following third-party accessories:

- USB 3.1 standard cable, screwable, 1 m, from IDS (item number AD00223)
- SFP+ module FTLX8573D3BTL from Finisar

**PRODUCT DESCRIPTION** 



# 3.3 Connections and controls

The front side of the N4000+ contains ports, buttons and LEDs for operation and elementary functions.

The back side of the N4000+ contains the log interfaces.

Fro	nt side		
		**** <b>[</b>	B Ebernel 10 Gaz er Storage LAA Heel
А	Status LEDs of custom log interfaces	Н	Default button
В	Status LEDs of built-in log interfaces	Ι	Service interface
С	USB host interface	J	USB device interface
D	General status LEDs	К	Trigger button
Е	LAN host interfaces	L	Power button
F	ESU interface	М	Power/trigger/wake port
G	10 Gbit Ethernet interface		

#### Status LEDs of custom log interfaces (A):

A constantly lit status LED indicates an existing and activated log interface on the corresponding slot. The LED flashes when messages are received.

#### Status LEDs of built-in log interfaces (B):

A constantly lit status LED indicates an existing and activated log interface or in case of CAN that at least one of both assigned channels is activated. The LED flashes when messages are received.



#### USB host interface (C):

By using a USB flash drive, the following functions are available:

- Data recording
  - Label the USB flash drive *XORAYALOG* and create the folder *usb\_queue* there.
  - Check *Record on USB stick* in the *Hard Disk* category of the system settings. (→ Hard Disk)
  - Start data recording in HDD mode. ( $\rightarrow$  HDD mode)
- Updating the firmware
  - Create the folder *xoraya\_update* on the USB flash drive and copy the firmware archive there.
  - Connect the drive and the firmware is automatically updated.
- Generating the supportfile
  - The supportfile is a set of files that you can send to X2E support to help solve technical issues.
  - Create the folder *xoraya\_supportfile* on the USB flash drive.
  - Connect the drive and the supportfile is automatically generated. The *Info* LED flashes during the process.

Additionally, use the trigger input (M) or the trigger button (K) to safely disconnect the USB flash drive after use. Check the corresponding action of the Button interface. ( $\rightarrow$  Button)

**PRODUCT DESCRIPTION** 



#### General status LEDs (D):

These LEDs indicate the operating status of the N4000+.

LED	Meaning
Connect	Connection between N4000+ and XORAYASuite is established
Info	N4000+ is DHCP server
Logging	Logging in progress LED flashes as the logging stops, because the stopping process may take longer depending on the queue fill level
Error	Flashes when restarting after the power supply was interrupted and the N4000+ could not shut down safely In addition, the <i>HDD</i> LED flashes while the file system is being repaired
Service	Lights up constantly when the N4000+ is in firmware update or recovery mode Displays different error codes by flashing
HDD	Flashes when accessing the internal storage medium
USB	Flashes when accessing a connected USB flash drive
ext.HDD	Lights up when XORAYA ESU is connected Red (constantly): connection enabled (locked) Red (flashing): accessing the XORAYA ESU Green: connection disabled via button (unlocked)

#### LAN host interfaces (E):

The N4000+ features four ports to connect to a switch or directly to a PC. This is necessary to control the N4000+ via software and exchange data.

#### ESU interface (F):

This port is used to connect the additional device XORAYA External Storage Unit (ESU). If the N4000+ detects this device, the measurements in HDD mode are saved there instead of to the internal storage medium. ( $\rightarrow$  HDD mode)

The LEDs in the following table are both on the front and on the back side of the XORAYA ESU.



**PRODUCT DESCRIPTION** 

LED	Meaning
Ъ	Lights up when cable connection to N4000+ is established Red: connection enabled (locked) Green: connection disabled (unlocked)
с	Lights up green when XORAYA ESU is voltage-supplied from the N4000+
8	Flashes red when accessing the XORAYA ESU



#### Remove XORAYA ESU safely 🏻 🏠

To avoid data loss, always press this button for at least one second before disconnecting the cable connection. When the corresponding LED is lit green, you can pull the cable.

#### 10 Gbit Ethernet interface (G)

This interface can be used for data recording or as a faster alternative to the 1 Gbit host interfaces (E). A plugged-in SFP+ module is required. X2E recommends the module FTLX8573D3BTL from Finisar.

#### Default button (H):

Press the default button with a pointed object for at least 3 seconds to reset all N4000+ settings to factory defaults.

#### Service interface (I):

In case of errors, this interface is used as a debugging interface by the X2E support team.

#### USB device interface (J):

This port has currently no function for the user.

#### Trigger button (K):

The function of this button depends on the N4000+ state. The following table describes these functions as delivered. Users can configure this behaviour via the XORAYASuite in the settings of the button interface. ( $\rightarrow$  Button)



State of the N4000+	Function
Sleep mode	N4000+ wakes up
Switched on	Start HDD recording
Switched on, recording active	<ul> <li>Short press: Setting a mark (an event) in the recording</li> <li>Long press (3 seconds at least): Stop current recording</li> </ul>

#### Power button (L):

If you press this button while the N4000+ is operational, the device switches to sleep mode.

If the N4000+ is operational and this button is pressed together with the trigger/wake button **(B)**, the N4000+ turns off completely.

You cannot turn off the N4000+ using this button when the device is connected to a PC and the *Connect* LED is lit. In this case, you can turn off the N4000+ via the *Logger* menu of the XORAYASuite. Here, you may choose between two options, i.e. *Shutdown* and *Shutdown* (*no wake up*). ( $\rightarrow$  Logger)

#### Power/trigger/wake port (M):


By default, the N4000+ must be supplied with 12 V DC voltage. Optionally, it can also operate with power supplies in a certain specified range. Appendix

Trigger input and trigger button offer an analogous operation. A +12 V signal level at the trigger input is equivalent to pressing the trigger button. ( $\rightarrow$  Trigger button)

The wake input allows waking up the N4000+ from sleep. To that end, the wake signal must shift from 0 V to +12 V.



**PRODUCT DESCRIPTION** 



#### 24x LIN add-on (N):

This card adds 24 LIN channels to the available log interfaces of the N4000+.

The switch allows changing between internal and external power supply.

Use the internal power supply of the LIN measurement card only if the connected LIN device uses the N4000+ voltage as a reference voltage. Bear in mind that this is not possible when using the N4000+ in a 24-V electrical system, for example. In this case, connect the external power supply port to the corresponding reference voltage.



#### Custom interfaces (O):

The slots can be variably equipped with up to three additional interfaces.

Slot and channel number of each hardware interface are also displayed in multiple locations of the XORAYASuite tool *Configuration*: (→ Interface configuration)

- Main overview for all interfaces
- Main overview for all channels of one interface type
- Settings for the corresponding interface channel

You find the rotary switch assignments in the chapter *Comissioning*.  $(\rightarrow$  Configuring switches)

#### Built-in interfaces (P):

The built-in interfaces of each N4000+ are:

- 2x Gigabit Ethernet
- 6x 100/1000Base-T1
- 12x 100Base-T1
- 20x CAN
- 2x Digital Out



Commissioning

# 4 Commissioning

# 4.1 Unpacking

Upon unpacking, check whether the delivery is complete and all components appear in perfect condition. ( $\rightarrow$  Scope of delivery)

- Please contact X2E GmbH immediately should the delivery be incomplete or upon damaged components.
- Do not put any defective component into operation.

X2E GmbH can only accept your complaint and replace the affected component upon prompt notification.



#### Keep original packaging

Keep the original packaging and packing materials for later storage or further transport.

# 4.2 Selecting an installation location

The N4000+ installation location must meet the following criteria:

- Location of the DC power supply (12 V by default)
- Distance of at least 4 cm to other devices
- Solid and stable base
- Adequate airflow
- N4000+ front, back and top sides must not be covered

# 4.3 Installing the N4000+

X2E GmbH provides no special requirements for N4000+ installation. Install the N4000+ in the vehicle so as to avoid a damage risk at any time.



# 4.4 Installing the XORAYASuite

Zur Konfiguration Ihres N4000+ und zum Auslesen der aufgezeichneten Messwerte installieren Sie die grafische Benutzeroberfläche XORAYASuite auf einem PC mit den folgenden Mindestanforderungen.

Unterstützte Betriebssysteme:

- Microsoft<sup>®</sup> Windows<sup>®</sup> 7 (32 Bit oder 64 Bit)
- Microsoft<sup>®</sup> Windows<sup>®</sup> 8 (32 Bit oder 64 Bit)
- Microsoft<sup>®</sup> Windows<sup>®</sup> 10 (32 Bit oder 64 Bit)

Hardwareanforderungen:

- Prozessorgeschwindigkeit mindestens 1GHz
- Arbeitsspeicher mindestens 2 GB
- Speicherplatz
   ca. 120 MB verfügbar

Softwareanforderungen:

Microsoft<sup>®</sup> .NET Framework Version 4.5 oder höher

Installation:

- Close all open programs.
- Use the XORAYASuite setup wizard from the supplied data medium. or
- Download the latest version of the XORAYASuite from the X2E-Wiki.
   (> X2E-Wiki)
- Start the setup wizard and follow the instructions.

R	Welcome to X2E Xoraya Suite x32 2019-10-17 Setup This ward will guide you through the installation of X2E Xoraya Safe x32 2019-10-17. Versions included in this package: SDN: XorayaSuite: 03.06.00.14 Toolkit: 02.05.00.04 Toolkit: 02.05.00.04 It is recommended that you does all other applications before starting Setup. The apps depend on the Microsoft Redistibuitable CRT=12.0, which is part of installation.
	Next > Cancel



# 4.5 **Connecting the N4000+ to the measuring environment**

This section describes how to connect the N4000+ to the measuring environment.



#### Device damage due to incorrect connection sequence

The incorrect connection sequence can lead to abnormal behaviour or destruction of the N4000+.

- According to the numbering of the subsections, connect the interfaces first and then the power supply.
  - Please note the correct connection sequence from top to bottom within the subsection.

#### 4.5.1 Interfaces



#### Observe pin assignments

Please note the port pin assignments when connecting the N4000+ with the measuring environment. Wrong pin assignments lead to measurement errors.

Please note the following sequence:

- Connect the data cables of all data buses to be monitored in the measuring environment.
- Connect the data cables to the appropriate N4000+ ports.
- Wherever possible, tighten the connector screws on the N4000+ and in the measuring environment.

 $\blacksquare$  The N4000+ is connected to all data buses to be monitored.



#### Loss of data due to port disconnections

To avoid data loss, never disconnect the N4000+ during the current recording from connected data buses.

Furthermore, make sure that all connectors are firmly attached and the screws are tightened.



#### 4.5.2 Power supply

This chapter describes the default connection to a DC power supply via the supplied power cable. If you use the optionally available power cable with AC adapter, please note the specifications on the adapter label.



DANGER

# Electric shock due to improper connection of the power supply

Introducing the 4-mm plugs of the supplied power cable into low-voltage sockets can be fatal.

Never introduce the 4-mm plugs into low-voltage sockets.

Connect the supplied power cable only to a power source that meets the prescribed technical conditions.



#### Damage due to incorrect power supply

Using an incorrect power supply can lead to abnormal behaviour or destruction of the N4000+.

- Use only the supplied power cable.
- Please ensure correct polarity upon connection.
- Make sure that the power supply used meets the prescribed technical conditions.
- Make sure that the power supply lies within permissible operating voltage of the N4000+.
- Please note the allowable voltage level when feeding external signals.
- Please note the technical specifications on the label when using the optionally available power cable with AC adapter.



#### Damage due to faulty connection

When connecting with live contacts, transient fault currents with entrained mass may arise on interface connections which have been already connected.

Please ensure contacts are de-energised when connecting the N4000+ to the power supply.





#### Continuous current of the DC power supply


A 12 V DC power supply must deliver a continuous current of 7.0 A. Use a regulated power supply or a car battery and note the required voltage and current levels.

Please note the following sequence:

- Connect the power cable to port (L) on the N4000+.
   (→ Connections and controls)
- ► Tighten the connector screws.
- Connect the black plug of the cable to 0 V or ground.
- Connect the red plug to the power supply.

 $\blacksquare$  The N4000+ is securely connected to the measuring environment.

Once the supply voltage is established, the N4000+ turns on and displays its operational status via the power button LED (L).





Der N4000+ ist mit einem intelligenten Energiemanagement ausgestattet, das für ein Absenken der Stromaufnahme auf max. 1 mA (bei 12 V Versorgungsspannung) im Ruhezustand sorgt.

The device goes into sleep mode via the following actions or under the following conditions:

- Pressing and holding the power button (L) for at least 2 seconds. Current recording stops automatically.
- If no data reach the log interfaces and no connection to the XORAYASuite is established for 10 minutes, the N4000+ shuts down automatically. This behaviour is configured using the main setting Automatically Switch Off. (→ Main Settings)

Users can wake up the N4000+ from sleep mode as follows:

- Pressing the power button (L)
- Switching the power supply off and on
- Signal change from 0 V to +12 V at the trigger or wake input (M)
- Pressing the trigger/wake button (K)
- Activity on a wakeable log interface

### 4.6 Connecting the N4000+ to the PC

This section describes how to connect the N4000+ to the PC. To do so, you will need a standard network cable.

Proceed as follows to connect:

- Connect the network cable to a switch.
   or
- Connect the network cable directly to your PC.
- Connect the network cable to one of the LAN host interfaces (E) or the 10 Gbit Ethernet interface (G). (→ Connections and controls)

 $\square$  The N4000+ is fully connected.




COMMISSIONING

# 4.7 Configuring switches


- Configure the built-in terminators via the rotary switches on the back of the N4000+. (→ Connections and controls)
- Configure the switching thresholds for the 4 Digital-In interface channels separately.
- ► For the LIN interface, select between internal or external power supply via the toggle switch.

#### 4.7.1 2x FlexRay



Position	Resistance
0	Open (∞)
1	2.6 kΩ
2	90 Ω

#### 4.7.2 4x Digital-In



Position	Threshold
0	3.3 V
1	5 V
2	12 V
3	24 V

#### 4.7.3 24x LIN



Position	Power supply
Vi	Internal
Ve	External

Use the internal power supply of the LIN measurement card only if the connected LIN device uses the N4000+ voltage as a reference voltage. Bear in mind that this is not possible when using the N4000+ in a 24-V electrical system, for example. In this case, connect the external power supply port to the corresponding reference voltage.



# 5 XORAYASuite

This chapter describes the operation of the graphical user interface XORAYASuite.

# 5.1 Starting

- ▶ Perform all commissioning steps. (→ Commissioning)
- Start the XORAYASuite by double-clicking the desktop icon.

or

Start the XORAYASuite from the Windows Start menu.

various tools.



Function Tool Configuration Customise the N4000+ behaviour **Online-Logging** Start and stop logging Hdd-Download Download measurements from the N4000+ storage medium Viewer Evaluate measurements Evaluate bus statistics Statistic Convert Convert log data to other formats Update firmware Firmware-Update **TK Commandline** Command line access to the XORAYAToolkit

Upon start, XORAYASuite provides access to the

 $\square$  The XORAYASuite is started.



#### Windows notification area

Even after closing the launcher, the XORAYASuite continues to operate in the background. Click the icon in the Windows notification area to access tools or to close the XORAYASuite.



# 5.2 Menu bar

This section describes the five main menus of the menu bar.

File	Logger	View	Help	Language				
se	lect logger		•	Logger	Logger	Logger	Logger	¥=

Individual menu commands are not available in every tool.

#### 5.2.1 File

Among other things, you can use the *File* menu to open and save files, or close the tool.

Command	Description		
Open configuration	Opens a configuration file (XML)		
Save configuration	Saves the current configuration		
Save configuration as	Saves the current configuration under a different name		
Save interface configuration as	Saves the current interface configuration under a different name		
	The subitem <i>System settings and signals</i> saves everything except the interface configuration		
Open	Opens an info file (DLI) and the associated log data Alternatively: ZIP archive containing info file and log data		
Close	Closes the open log data		
Open SWU/XSWU file	Opens a firmware image		
Refresh properties	Reloads the current configuration of a selected interface from the N4000+		
Recent files	Displays the most recently opened info files (DLI) and opens them when needed		
Export preferences	Exports the output format settings in a preference file (XML)		
Import preferences	references Imports the output format settings from a preference file (XML)		
Exit	Closes the tool		



#### 5.2.2 Logger

Among other things, you can use the *Logger* menu to connect or disconnect the N4000+ with the XORAYASuite.

Command	Description		
Connect	Connects the selected N4000+		
Disconnect	Disconnects the active connection to the N4000+		
Offline-Logging > Start	Starts the logging process on the N4000+ storage medium		
Offline-Logging > Stop	Stops the logging process on the N4000+ storage medium		
Online-Logging > Start	Starts the logging process on the PC		
Online-Logging > Stop	Stops the logging process on the PC		
Probe-Logging > Start	Starts probe logging (further information in the quick manual XORAYA µT-Z7/Probe)		
Probe-Logging > Stop	Stops probe logging		
Save changed configuration permanently	Stores the changed settings permanently on the N4000+		
Customer default configuration > Create	Stores the current permanent configuration (profile <i>active</i> ) in the <i>customer-default</i> profile		
Customer default configuration > Load	Loads the <i>customer-default</i> configuration profile into the <i>active</i> profile		
Reset configuration to factory settings > Interfaces	Resets the N4000+ interface configuration to factory defaults		
Reset configuration to factory settings > System	Resets the N4000+ system configuration to factory defaults		
Format HDD Formats the N4000+ storage medium			
Synchronize time with > Local	Sets the system time of the N4000+ to the current system time of the PC		
Synchronize time with > Vehicle	Sets the system time of the N4000+ to the current system time of the connected vehicle		
Restart	Restarts the N4000+		
Restart and reconnect	Restarts the N4000+ and reconnects		
Shutdown	Puts the N4000+ in sleep mode		
Shutdown (no wake up)	Shuts down the N4000+ completely		

This menu does not appear in the *Viewer* and *Convert* tools.



#### 5.2.3 View

Among other things, you can use the *View* menu to switch between normal and detail view.

Command/Setting	Description	
Normal	Normal view	
Detail	Detail view that displays all categories and properties in the <i>Configuration</i> and <i>Online-Logging</i> tools	
Tab selection	Determines which tabs are shown in the Online-Logging tool	
Tile windows vertically/ horizontally	Determines whether the elements <i>Export settings</i> and <i>Output formats selection</i> in the <i>Hdd-Download</i> tool are displayed next to or below the list of sessions or measurements	
Autosize columns	Adjusts the width of the columns in the <i>Hdd-Download</i> tool to ensure all are visible simultaneously.	
1 Comment  22 Type spread	Hdd-Download tool	
Legend	Determines whether the legend is shown in the <i>Hdd-Download</i> tool	

This menu does not appear in the tools *Viewer*, *Convert* and *Firmware-Update*.

#### 5.2.4 Help

Among other things, you can use the *Help* menu to access this manual.

Command	Description	
Logger manual	Opens the N4000+ user manual	
About	Displays system information on the software and, if connected, on the N4000+	
Update software	Opens the X2E-Wiki to download the current XORAYASuite version	
Show logfile	Displays a log file for the tool	
Supportfile	Generates a set of files that you can send to X2E support to help solve technical issues	

#### XORAYASUITE



#### 5.2.5 Language

Use the *Language* menu to change the language of the XORAYASuite.

Setting Description	
German (Deutsch) Changes the language of the XORAYASuite to German	
English (Englisch)         Changes the language of the XORAYASuite to English	



#### Other menus

The *Edit*, *Download*, *Convert* and *Settings* menus are only available in two tools at the most. Their descriptions can be found in the corresponding sections of this user manual.

### 5.3 Status bar

The status bar on the bottom of the window provides information about the connected N4000+, for example the storage medium usage. In addition, the user interface is also adjustable for smaller displays there. The following buttons do not appear in the tools *Viewer*, *Statistics* and *Convert*.

1	Show/hide menu bar	3	Show control dialogue
2	Show/hide toolbar	4	Show message queue

The control dialogue (3) allows quick access to the most important commands of the menu or tool bar.



# 5.4 Connecting and disconnecting the N4000+

The N4000+ is connected and disconnected in the same way regardless of the XORAYASuite tool. This section shows the process for the *Configuration* tool as an example.

## 5.4.1 Connecting the N4000+

Fi	le Logger View Help Language select logger A XorayaN4000-0001 XorayaMLZ7-0001 Offline Configuration	Logge	t Logger Logger	<b>≸</b> ≡ <b>6</b>
1	Display available loggers	6	Display settings	
2	Establish connection to logger			

- Connect the N4000+ to the PC. ( $\rightarrow$  Connecting the N4000+ to the PC)
- ► Turn on the N4000+.
- ► Start the desired XORAYASuite tool. (→ Starting)
- Click *Display available loggers* (1) to start scanning for dataloggers.
- Select the desired N4000+ (alternative name: MLZU) using the assigned name.
- Click Establish connection to logger (2).
   or
- ▶ In the *Logger* menu, click *Connect*. (→ Logger)

 $\square$  The N4000+ is connected to the XORAYASuite.

Icons and text colours indicate the status of the N4000+:

Զ 😢 and name red	Network error, the N4000+ is located on a different subnet
and name <b>black</b>	Disconnected N4000+
and name <b>red</b>	Another user is connected to the N4000+
and name blue	You are connected to the N4000+
2 =	Measurements are currently transferred from the N4000+ storage medium to the PC
Ŷ	N4000+ is in favourites list ( $\rightarrow$ Favourites)





## Edit the configuration file

You can edit a configuration file (XML) previously created without connecting to the N4000+. To do so, select *Offline Configuration* in the drop-down list *Display available Loggers* (1) in the *Configuration* tool.

# 5.4.2 Disconnecting the N4000+

F	le Lo	ogger	View	Help	Language		
	Xora	yaN40	00-0001	•	Logger 2	Logge	
2	Relea	ase co	onnectio	on to lo	gger	5	Display settings
3	Start	Hdd	logging	J			

• Click Release connection to logger (2).

or

▶ In the Logger menu, click Disconnect. (→ Logger)

☑ N4000+ and XORAYASuite are disconnected.



#### HDD mode

Start the recording on the internal or external storage medium of the N4000+ via *Start Hdd logging* (3) or autonomously without a PC, as described in the relevant section. ( $\rightarrow$  HDD mode)



## 5.4.3 Favourites

You access the favourites list via *Display settings* button in the *Configuration*, *Online-Logging* or *Hdd-Download* tools.

Interfaces	Favorites Logger			
Interface color	Doger name	_	16 IP-address	Scan Ping
Signal description			172.28.2.21 172.28.2.42	
Alternative BusSpec				
Favorites Logger				
			Accept	Cancel
1 Refresh the de	vice list	4	Devices in the netwo	ork
2 Add currently favourites	connected device to	5	Add selected device	to favourites

Save frequently used dataloggers in the favourites list. Favourites are displayed first in the list of available dataloggers and are marked with the star symbol.

Add N4000+ manually:

- Click Add a device to favourites manually (3).
- Specify Logger name and IP-address.
- Click OK.

Add N4000+ automatically:

- Click *Devices in the network* (4) to start scanning for dataloggers.
- ► Select the desired N4000+.
- Click Add selected device to favourites (5).

Additionally, you can add the currently connected N4000+ directly via button (2).



The symbols in the columns *Scan* and *Ping* display the current reachability of the dataloggers in the list. *Ping* reaches beyond subnet boundaries.

Meaning of the symbols:

💿 and 😑 🔹 reachable



not reachable

# 5.5 Configuration

This tool allows the configuration of the N4000+ and its interfaces.

- Connect the N4000+ to the PC. ( $\rightarrow$  Connecting the N4000+ to the PC)
- ► Turn on the N4000+.
- ► Start the *Configuration* tool of the XORAYASuite. (→ Starting)
- ► Connect to the desired N4000+. (→ Connecting the N4000+)

 $\blacksquare$  The configuration can be performed.



#### Defects influencing the environment

The incorrect N4000+ configuration can lead to the temporary, delayed or permanent functional failure of connected vehicles.

Connected vehicles being operated on public roads bear an increased risk of injury and damage.

- If available, use configuration templates provided by the vehicle manufacturer.
- Use preferably the passive recording modes of the interfaces.

All settings in the *Configuration* tool are stored permanently in the N4000+. Therefore, you can configure each N4000+ differently to meet the requirements of various application areas.



File Logger View Help Language XorayaN4000-0001		Logge	
System Settings     Versions     Main Settings     Snapshot     Hard Disk     Profile	Defau	lt Pro	perties XorayaN4000-0001
Network     Upload     Export     DLN     State Interfaces		ent IP	172 28 2 21 0200 0700 0100 000001
CAN     Eneret     RS-232     VIDEO	Syste	em Tin ntenan	e 18 Dezember 2019 - 10:24:38 PC
DiagCCP     DiagXCP     Event     Button		0.02.222	
2 Release connection to logger		5	Display settings
3 Start Hdd logging		6	Save configuration file
4 Save changed configuration perma	nently	7	Categories

The tree structure on the left side of the window displays system settings, available interfaces and signals at the highest level. Expand the tree at the desired position and to the desired depth to access the sub-items.

The current configuration of the selected sub-item is displayed on the right side of the window. This is where you can perform any changes required and optionally save them as a configuration file (XML) on your PC via button **(6)**. The toolbar **(7)** allows a quick jump to all categories of this level.

Use the *Default* tab to access the screen for the main default settings.

Use the *Properties* tab to access properties and thereby all available settings. This tab is only visible if the detail view is enabled.



#### Enabling the detail view

In the View menu, click Detail to enable the detail view.

# **USER MANUAL**

#### XORAYASUITE



You can view the properties sorted either alphabetically or by category. Properties that cannot be modified by the user are greyed out.

Configuration changes can be saved temporarily or permanently.

#### Save temporarily:

• Change the desired default setting or property.

 $\blacksquare$  The configuration is saved temporarily.

Changes to default settings or properties are discarded after the N4000+ restarts.

#### Save permanently:

- Click Save changed configuration permanently (4).
   or
- ▶ In the Logger menu, click Save changed configuration permanently.

 $\square$  The configuration is saved permanently.



#### Delayed change update

For certain settings, such as *Name* and *IP Address*, changes are not applied immediately but only after a N4000+ restart.

The *Maintenance* symbol indicates whether there is a N4000+ malfunction and, where appropriate, the error source.



#### HDD mode

Start the recording on the internal or external storage medium of the N4000+ via *Start Hdd logging* (3) or autonomously without a PC, as described in the relevant section. ( $\rightarrow$  HDD mode)

Use *Display settings* (5) to customise the following:

- Colour assignments for the interfaces
- Load signal description file (→ Signal description settings)
- Load configuration template (Busspec)
- Manage logger favourites (→ Favourites)



## 5.5.1 System configuration

System settings are configured via properties stored on the N4000+.

These properties fall under various categories:

- Main Settings
- Network
- Hard Disk
- Snapshot
- Versions
- Profile

Select the category:

Click the root element of System Settings to display the main settings of all categories.

or

• Click a category to view the main settings of this category.

System Settings > Main Settings:

XorayaN4000-0001 18 Dezember 2019 - 1	0.29.30			
18 Dezember 2019 - 1	0.29.30	-		
			PC ]	Vehicle
18 Dezember 2019 - 1	0:22:31			
10 min	•	Ac	coustic fe	eedback
Not available				Reload
Seen at	Not ava	ailable		
	10 min Not available	Not available Seen at Not ava	10 min  Ad Not available Seen at Not available	10 min   Acoustic fe Not available  Seen at Not available



Setting	Description	Default
Name	Freely selectable name of the N4000+	XorayaN4000+- <serialnumber></serialnumber>
Comment	omment Current system time, internally with a precision of 100 ns	
	Also used as a timestamp during logging	
System Time	Internally used property for the system time	
Automatically Switch Off	<ul> <li>Time period after which the N4000+ shuts down, provided:</li> <li>there is no connection to the XORAYASuite</li> <li>there is no activity on any interface for which <i>Prevent Sleep Mode</i> is activated</li> </ul>	10 min
	Values: Never, 1 min, 10 min, 20 min, 30 min, 60 min	
Acoustic feedback	Acoustic feedback when: data recording is starting N4000+ is shutting down/sleeping	Off



# System Time

Click the appropriate button to synchronise with the PC or the vehicle time.



#### System Settings > Network:

The sub categories are assigned to the following interfaces ( $\rightarrow$  Connections and controls):

- LAN Host eth0 LAN host interfaces (E)
- LAN Host eth1 10 Gbit Ethernet interface (G)

Ø dynamic assigned I	P-Address	S					
CHCP-Server>							
IP Address	10 .	104 . 2 .	21				
Gateway Address	0.	0.0.	0				
Netmask	255	255 . 255 .	0				
fixed IP-Address							
IP Address	10	104 _ 2 _	21				
Gateway Address	0	0 0	0				
Netmask	255	255 255	0				
Current IP-Address	172	28 2	38				
Current Mac Address	00:21	d5:02:00:06					
Current Mac Address Current DHCP mode	00:21:	d5:02:00:06					
	00:21: 1 <b>Dec</b>						
Current DHCP mode	1		bottom_left	top_left	bottom_right	top_right	host
Current DHCP mode max transmit unit (mtu)	1	1500 Source \	bottom_left	top_left	bottom_right	top_right	host
Current DHCP mode max transmit unit (mtu)	1 Dec	1500 Source \ Target		112			
Current DHCP mode max transmit unit (mtu)	1 Dec	1500 Source \ Target bottom_left		V			V
Current DHCP mode max transmit unit (mtu)	1 Dec	1500 Source \ Target bottom_left top_left bottom_right top_right		V V V		V V V	× × ×
Current DHCP mode max transmit unit (mtu)	1 Dec	1500 Source \ Target bottom_left top_left bottom_right		<b>7</b>		V V V	V V V



Setting	Description	Default
dynamic assigned IP- Address	Activate DHCP	On
<dhcp-server></dhcp-server>	N4000+ DHCP mode <i>On</i> : DHCP server <i>Off</i> : DHCP client	On
IP Address	IP address assigned to the N4000+ if: • <dhcp-server> = On or • fixed IP-Address = On</dhcp-server>	10.104.2.21
Gateway Address	Gateway address assigned to the N4000+ if: <ul> <li><dhcp-server> = On or</dhcp-server></li> <li>fixed IP-Address = On</li> </ul>	0.0.0.0
Netmask	Netmask that divides the IP address into network and host part	255.255.255.0
fixed IP-Address	N4000+ with static IP address	Off
max transmit unit (mtu)	maximum packet size on the network layer (in Bytes)	1500

Provided the check box is selected, the N4000+ is only DHCP server if it cannot find another DHCP server within the network. Otherwise, the N4000+ requests the IP address from this server, acting as DHCP client.

Edit connection matrix (4):

- Activate or deactivate the connections between the front switch ports.
- Activate or deactivate the ports as hosts.

If the button *Symmetrical editing* (3) is enabled, changing a connection automatically changes the opposite direction.

Change between Overall view (1) and Separate view by ports (2) as desired.



	M	AC		IP				
	00:00:00:00	> 🔻 00:00:	10.1	104 .	2	. 0	×	
	00:00:00:00	:00:00 🔻 <>	10.1	104 .	2	. 0	X	
	00:00:00:00	> 🔻 00:00:	10 . 1	104 .	2	. 0		
	00:00:00:00	:00:00 🔻 <>	10.1	104 .	2	. 0	- X	
	00:00:00:00	:00:00 🔻 <>	10.1	104 .	2	. 0	_ X	
							50	
	eth	MAC		IP				
	eth0 eth0	00:11:22:33:44 66:77:88:99:aa		172.2 172.2				
5	Close MAC-	IP assignments	\$		7	Ref	fresh table of PCs in the netv	vork
6	Delete MAC	-IP assignment	τ					

Static MAC to IP assignment when DHCP server is active:

DHCP server mode is intended for direct connections to PCs. You can bind MAC addresses of up to five PCs to IP addresses. Type them in manually or double-click in a row of the table that contains the addresses of the PCs in the network.

Red exclamation marks flag PCs outside the IP range.



#### Special care in network settings

Exercise extreme caution when changing these settings. Under certain circumstances, incorrect network settings of the N4000+ cannot be corrected.

In this case, you should reset the N4000+ back to factory defaults by pressing the default button **(H)** for 3 seconds. ( $\rightarrow$  Connections and controls)



	🔄 🕢 🖬 📼 🏦 🏭 🔛 🟠 Ha	rd Dis	k =
De	fault Properties		
	Hdd Usage		
	84956 from 230709 MB Used (262 Measurer	nents)	
			Format
	Verwrite		
	Autostart		
	Compression ZIP		
	Boost		
	Available Hdd's		
	36%		
	ext 🥑		
	Record on USB stick		
	ੴ <del>~</del>		
1	Compression method	3	Activate ESU*
2	Activate internal storage medium	4	Remove ESU safely*

\* Only with connected XORAYA ESU

These settings and displays refer to the currently active storage medium, represented by the blue background colour.

If a XORAYA ESU is connected to interface (I), you change the active storage medium via the buttons (2) and (3). ( $\rightarrow$  Connections and controls)



Setting	Description	Default
Overwrite	Control the N4000+ behaviour if the storage medium is full	On
	On: Oldest session or measurement is overwritten	
	Off: Recording is terminated	
Autostart	Immediate recording after switching on the N4000+ or after disconnecting with the XORAYASuite	Off
Compression	Compress data before saving	Off
Boost	Increase write speed on the storage medium when processing the default-queue for packet data	On
Record on USB stick	HDD mode recording on a connected USB flash drive instead of on the internal or external storage medium	Off
	<i>Off</i> : Disabled	
	<i>Loop</i> : Circular buffer, which contains the most recent minutes of the recording	
	Linear: Ongoing	



## Compression

Compression reduces the data volume and, as a result, the download time, because data are decompressed on the PC.

After selecting the check box *Compression*, choose the compression method via the drop-down list (1):

- ZIP (slower, higher compression rate)
- LZ4 (faster, lower compression rate)

In addition to the settings, this view presents the usage of the storage medium and the number of stored measurements.

Use the *Format* button to delete all existing data from the storage medium.



## **Record on USB stick**

For this mode, it is required that the connected USB flash drive is named *XORAYALOG* and contains the folder *usb\_queue*.



#### System Settings > Snapshot:

Snapshots can be created during the measurement to track particularly interesting time periods. The moment you raise the corresponding trigger, all data received for a user-definable time before and after this moment, are Measurement data are processed as queues on the log interfaces. In addition to the default-queue for packet data, the N4000+ is able to use the faster stream-queue where Ethernet data are saved directly without creating statistics. You can set snapshots for both queues separately.

Setting the snapshot:

- Configure the snapshot of the desired queue.
- Create one or multiple triggers for the action *logger.snapshot*.
   (> Trigger)

or

Activate the property snapshot\_on\_log\_press of the button interface.
 (→ Button)

ault Properties			
Default' - queue			
rigger Pre-time	0	ms	
rigger Post-time	0	ms	
Stream' - queue			
frigger Pre-time	0	ms	
rigger Post-time	0	ms	
.og mode	Linear	1 <b></b>	
.oop size	3	X 200 MB	

# USER MANUAL



XORAYASUITE

Setting	Description	Default
Trigger Pre-time (Default-queue)	Leading time of the snapshot for the default-queue (in ms)	0
Trigger Post-time (Default-queue)	Trailing time of the snapshot for the default-queue (in ms)	0
Trigger Pre-time (Stream-queue)*	Leading time of the snapshot for the stream-queue (in ms)	0
Trigger Post-time (Stream-queue)*	Trailing time of the snapshot for the stream-queue (in ms)	0
Log mode (Stream-queue)*	Snapshot recording mode for the stream-queue Linear: Ongoing Loop: In a loop that is overwritten as the specified size is reached	Linear
Loop size (Stream-queue)*	Factor determining the size of the loop (in MB, multiplied by a fixed predefined value)	3
Interval	Time range (in ms) during which multiple triggered snapshots are prevented Too many snapshots in very little time may lead to abnormal behaviour of the N4000+	0



### System Settings > Profile:

You can save different N4000+ configurations using profiles. The following names are reserved for special profiles:

- active the permanently saved configuration, which is loaded when the N4000+ starts
- default the factory default configuration
- customer-default a customer default configuration

Passw Passw	0	]	]	
Profile	in the second	P.L.		
<u>8</u>	Profile name customer-default	Delete X	Load	

Create customer-default profile:

- Enter customer-default in the text box and click Create. or
- ▶ In the Logger menu, click Customer default configuration > Create.

Load customer-default profile:

Click Load in the row of the customer-default profile.

or

- In the Logger menu, click Customer default configuration > Load. or
- Press the default button (H) for at least 1 second, but no more than 3 seconds. (→ Connections and controls)



Load *default* profile:

Press the default button for at least 3 seconds.

Protect active profile:

- Enter a Password.
- Click Activate password protection (1).
- ▶ In the main toolbar, click *Save changed configuration permanently*.
- ▶ Disconnect and reconnect again to the N4000+.

☑ The *active* profile is protected:



With enabled password protection, you can still temporarily save settings and create profiles, without needing to enter the password.

🔚 🗟 🖲 📾 🖴 🏄 🖼 🙀 🔚 🏠 Profile
Default Properties
Password Password
1 Unlock password protection

Unlock password protection for active profile:

- Click Unlock password protection (1).
- ▶ In the newly opened window, enter the correct *Password*.
- Click OK.

☑ The password protection is unlocked:





## **Reset password**

If you have forgotten your password, you can reset the N4000+. ( $\rightarrow$  Resetting to factory defaults)

As you do so, the password as any other configuration changes will be reset.



#### System Settings > Export:

You can save the export settings and output formats for the *Hdd-Download* tool on the N4000+ itself. This way, the settings are centrally defined and do not depend on the PC used for downloading later.

<b>D</b> efa	🚨 🕢 📧 🖃 🛃 🚑 🕷 🖬 🏠 ult Properties	Export		
1	port settings			
File	ename %DateTimeStart%-%DateTime Store Sessions in separate Files Overwrite files	eEnd%_%Na	ime%	*
O	tput formats selection		1 La	- 🖬 🗙
	•	7	%FileNamePrefix%	<b>*</b> X
	Jpload client settings onto the ogger	2	Delete client settin logger	ngs from the

Save settings on the N4000+:

- ► Specify the export settings. (→ Export settings)
- ► Specify the output formats. (→ Output formats selection)
- Click Upload client settings onto the logger (1).
  - $\checkmark$  The settings are temporarily or permanently saved on the N4000+ and can be loaded in the *Hdd-Download* tool.

Reset settings:

• Click Delete client settings from the logger (2).



### System Settings > DLN:

Set up a *Distributed Logging Network*, consisting of data sink (master) and one or multiple probes. For further information, see the quick manual for the XORAYA  $\mu$ T-Z7 probe.

. 🖌 🔜	) 📷 🖃 🛃 🟯 🙀 🔚 🏠 DLN 👘		
Default Prop	erties		
Enable	🔂 Distributed Logging Network	PTP settings	
Device ID		Domain Interface	Dec 0 eth0,Timestar
Mode Protocol	Undefined -	State	/ UN
Target VLan Id	: 1	A. V	
This device IP address	Current         New           0 . 0 . 0 . 0         .	/ .	]: [1
Synchron State	nize logging state (global log state) -		
Connect	ted probe devices		



### System Settings > Versions:

All properties in this category are immutable and purely informative. Among other things, this displays version numbers for various N4000+ components, as well as additionally activated licences.

🖬   🕰 🖲 🖬 🖃 🛃	🛓 🕷 📕 🏠 Versions
Default Properties	
Firmware Version	4.0a.0015
Protocol Version	0.01.0000
FPGA Version	6002.0a03
Power Version	2.02.0500
SerialNo	0200_0700_0100_000001
Recommended software	Suite_03.04.05 TK_02_03 SDK_02.03.05
Licenses	Licenses



## 5.5.2 Interface configuration

Interface settings are configured via properties stored on the N4000+.

These properties fall under various categories:

- Settings
- Filter
- Trigger
- Routing
- Other
- Advanced

Interface or channel selection:

Click the root element *Interfaces* to display the main settings of all interfaces.

or

 Click an interface to display the main settings for all channels of this interface.

or

• Click an interface channel to display the main settings for this channel.

Cross-references to the interfaces					
→ CAN	→ Ethernet	→ Event			
→ FlexRay	→ VIDEO	→ Button			
→ LIN	→ DiagCCP				
→ RS-232	→ DiagXCP				



Interfaces:

📕   Int	erface	s								
Default	Properti	es								
Enable	Wake	Prevent Sleep	Acknowledge / Send	Channel	Instance	Alias	Bus-Id	Rate of Transfer [kB]	High level interfaces	Slot
<b>V</b>	<b>V</b>	<b>V</b>		Can	1	can1		500		
<b>V</b>	<b>V</b>	<b>V</b>		Can	2	can2		500		
1	<b>V</b>	<b>V</b>		Can	3	can3		500		
1	<b>V</b>	<b>V</b>		Can	4	can4		500		
<b>V</b>	<b>V</b>	<b>V</b>		Can	5	can5		500		
<b>V</b>	<b>V</b>	<b>V</b>		Can	6	can6		500		
<b>V</b>	<b>V</b>	<b>V</b>		Can	7	can7		500		
<b>V</b>	<b>V</b>	<b>V</b>		Can	8	can8		500		
				Can	9	Paso 9		500		

Double-click a row in the table to jump directly to the corresponding interface or to the corresponding channel.



#### Reducing power consumption of the N4000+

To reduce the N4000+ power consumption, disable all channels unneeded.



#### CAN:

4 of the 20 CAN channels are always FD-capable. By default, the FD-specific settings are missing on the remaining channels.



#### CANFD\_4PLUS\_#

For each of these licences, the number of CAN-FD-capable channels is increased by 4.

Check in category *Versions* of system settings to verify which licences are activated for your XORAYA Z7. (→ Versions)

#### CAN > Settings:

efault Properties				
V Enable		FD	V iso	
Alias	can1			
Description				
Bus ID	[			
Baudrate	500 k	-	bit/s	
Protocol	Classic CAN	870		
Baudrate (FD)	2000 k	Ψ.	bit/s	
Use Busspec	Not availab	le		
Prevent Sleep	Mode			
🗸 Wake				
Acknowledge/Ser	nd pas	sive (not se	end/acknowloedge)	



Setting	Description	Default
Enable	Turn on logging for this channel	On
iso	CAN FD standard <i>On</i> : ISO 11898-1 <i>Off</i> : original standard by Bosch	On
Alias	Freely selectable channel name	can#
Bus ID	Additional ID for subsequent evaluation	
Baudrate	Transfer rate (in bit/s) Values: 100 k, 125 k, 200 k, 250 k, 400 k, 500 k, 666 k, 800 k, 1000 k	500 k
Protocol	Classic CAN or CAN-FD	Classic CAN
Baudrate (FD)	Transfer rate for the payload section of a CAN FD message (in bit/s) Values: 500 k, 1000 k, 2000 k	2000 k
Use Busspec	Load configuration template provided by the vehicle manufacturer	Off
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	On
Wake	N4000+ wakes up from sleep mode as soon as there is activity on this channel	On
Acknowledge/ Send	Acknowledgment and transmission capacity Send and acknowledge: N4000+ operates in active mode on the CAN bus (transmission possible, acknowledgment of CAN messages, generation of error frames) passive (not send/acknowledge): N4000+ operates in passive mode on the CAN bus (receipt possible, no acknowledgment of CAN messages, no generation of error frames) Send but NOT acknowledge: N4000+ operates in semi-passive mode on the CAN bus (transmission possible, no acknowledgment of CAN messages, no generation of error frames)	passive (not send/ acknowledge)
autoacknowledge self transmitted message	Messages sent by the N4000+ are automatically acknowledged	Off





# CAN > Trigger:

	🧼 🗶 🐚 🔅 In	terface-type:Can Chan	nel:1							
Default	Properties									
EF	nable Trigger from f	ollowing CAN message:								
	ld	anothing crist mesosge.								
	<b>Ox</b> 1d6	Extended frame		64	1		1-5	9-16	17-24	25-3
	🔲 Can FD	🔲 Bit Rate Switch	С	1 8 💽	2 1X		XX	Ī	4 XX	G
			110	01000	00013	xxx	XXXX	XXXX	XXXX	XXX
E	nable Trigger from f	ollowing CAN message:								
	ы			_	_	_				
	<b>Ox</b> 1d6	Extended frame		64	1	L	1-8 1	9-16	17-24	25-3
	Can FD	🔄 Bit Rate Switch	С		1X	J	XX	·	4 XX	
			110	00100	00012	CXXX	XXXX	XXXX	XXXX	XXX
E	nable Trigger from f	ollowing CAN message:								
	ld			_		-				-
	<b>Ox</b> 1d6	Extended frame		64	1		1-8 2	9-16	17-24	25-3
	🔄 Can FD	Bit Rate Switch	F		DX		XX	·	4 XX	6
			111	11000	11012	CXXX	XXXX	XXXX	XXXX	XXX
	nable Trigger from fr	ollowing CAN message:								
	la la	onowing CAR message.								
	<b>0x</b> 1d6	Extended frame		64			1-8	9-16	17-24	25-3
	Can FD	Bit Rate Switch	E	1 4 🔍	DX	o	XX	Ū	4 XX	6
			111	10100		1.1	1000	S	XXXX	XXX
	nable i rigger from to	ollowing CAN message:								
	0x 7b7	Extended frame		64	~		1-8	9-16	17-24	25-3
	🔄 Can FD	🔲 Bit Rate Switch	0	1 0 💽	2 XX	Ð	XX	Ī	4	6
				00000						1.000
			<u></u>							
S	end as response foll	owing CAN message:	Тга	insmit						
1:	Ox 1	Extended frame	643	00	00	00	00	00	00	00
	📰 Can FD	🔲 Bit Rate Switch		00	00	00	00	00	00	00
				00	00	00	00	00	00	00
				00	00	00	00	00	00	00
S	end as response foll	owing CAN message:	Tra	insmit						
1 N	umber of bytes	for the trigger	3	Numb	or of	hytor	for t	he ro	cnone	A
	byte blocks of t		3 4	Byte v		-			-	0C
2 0	האוב הוחרעז חן ו	ne trigger	4	byte V	aiues	or th	6162	μυπε	-	



The following check boxes affect the IDs of the specified CAN messages in this category:

- Extended frame Use 29-bit ID instead of 11-bit ID
- Can FD Activate CAN FD mode
- Bit Rate Switch Transfer payload with CAN FD baudrate (Requirement: Can FD selected)

Configure triggers:

- Select the check box *Enable Trigger from following CAN message*.
- Under *Id*, specify the ID of the CAN message that raises a trigger.
   (→ Changing the numbering system)
- Select the check boxes Extended Frame, Can FD and Bit Rate Switch as desired.
- Specify the Number of bytes for the trigger (1).
- Select one of the *8-byte blocks of the trigger* (2) for editing.
- ► Specify the bytes of this payload block. (→ Set bits)
- Specify further 8-byte blocks of this trigger.
- Repeat as necessary for up to a total of five triggers.

The following CAN messages are preconfigured as triggers:

ID	Byte 1	Byte 2 (X = "don't care")
1d6	C8	1X
1d6	C4	1X
1d6	F8	DX
1d6	F4	DX
7b7	00	XX



Configure trigger responses:

- Select the check box *Send as response following CAN message*.
- Specify the ID of the CAN message that is sent as response to a trigger.
- Select the check boxes Extended Frame, Can FD and Bit Rate Switch as desired.
- Specify the Number of bytes for the response (3).
- Specify the Byte values of the response (4).
- Repeat as necessary to configure a second trigger response.



#### CAN trigger responses

Trigger responses are only sent if the setting *Acknowledge/Send* is not set to *passive*.

To test the transmission of a CAN response, click the corresponding button.



#### CAN > Routing:

Here, you configure the routing of messages received on other CAN channels via the currently selected channel. The payload is not changed while the IDs of source and target message can differ.

	] 🧼 🌋 🖏 🚸 L	nterface-type:Can Ch	annel:1			
De	efault Properties					
1	Mirror messages				666	
	Source interface	Source msg ID	Targe	et msg ID	Source interface	
	CAN 2 (can2)	0x120	0x12	1	Source msg ID	Ox 120
					Target msg ID	Ox 121
1	Add routing		3	Save rou	ting	
2	Delete routing					

Configure routing:

- Select the check box *Enable*.
- Click Add routing (1).
- Under *Source interface*, choose the receiving CAN channel.
- Under Source msg ID, specify the ID of the source message.
   (→ Changing the numbering system)

Select the check box *Ext. ID* for a 29-bit ID instead of a 11-bit ID.

 Optional: Under Target msg ID, specify content and length of the target message ID.

If you do not specify a target message ID, the source message ID is applied.

- ► Click Save routing (3).
- Repeat as necessary for further routings via this channel.

Meaning of the symbols for the available CAN channels:

🗸 enabled

🗡 🛛 not enabled



#### CAN > Other:

Here, you specify if the N4000+ sends general system statistics and interface statistics as CAN messages during data recording. These CAN messages contain signals, which hold the specific values.

General system statistics are, for example:

- RAM queue fill level
- CPU load
- Storage medium usage

Interface statistics:

- Transfer speed in kB/s
- Messages per second
- Overflow counter
- Error counter

	🧼 🔏 國 🚸 Sc	hnittstellen	-Typ:Can Kana	<b>l:1</b>				
Defa	ault Properties							
Ιſ	<ul> <li>Interface statistic or</li> </ul>	ver CAN mes	sages					
	Enable					L.		
	Offset	<b>Ox</b> 0			DE			
	Generated frame IDs a	re in extended	d range. See folo	wing bui	d:			
	28	20 19			4 3	0		
	HUUUUU	NUU	KKKKKK					
	Offset		Interface ID		Msg	g off		
	📉 user define	d						
	reserved							
1. 5								

Setting	Description	Default
Enable	Enable interface statistic over CAN messages	Off
Offset	User-defined ID offset of the sent statistic messages	0



The user-defined *Offset* within the 29-bit ID is displayed in green. This offset applies to each generated ID. The rest of the ID in orange is reserved and is automatically adjusted for each interface channel by the software.

Click the *DBC* button to open the generated messages and signals as a DBC file in a text editor and to save them for later analysis.



## **Restriction of statistic over CAN**

Statistic over CAN messages can only be activated on one CAN channel at the same time.





# FlexRay:

# FlexRay > Settings:

efault Propertie	s		
✓ Enable	DI		
Alias	flexray1		
Description			
Bus ID			
Channel	Α 👻		
🔲 Use Busspec	Not available	+	
V Prevent Slee	p Mo <mark>d</mark> e		
🔽 Wake			
Allow sendin	g		
MFR config (Fibe	x file)		
MFR state	- UNDEFINED		

Setting	Description	Default
Enable	Turn on logging for this channel	On
Alias	Freely selectable channel name	flexray#
Bus ID	Additional ID for subsequent evaluation	
Channel	Selection, which one of both bus channels is used Values: A, B	А
Use Busspec	Load configuration template provided by the vehicle manufacturer	Off
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	On
Wake	N4000+ wakes up from sleep mode as soon as there is activity on this channel	On
Allow sending	Allow sending on this channel (requirement for XCP on FlexRay) Additionally, a FIBEX file is required	Off
MFR config (Fibex file)*	Path and name of the FIBEX file for the configuration of the FlexRay controller (MFR)	

\* Only for channel 1 of 1x dual



LIN:

LIN > Settings:

V Enable				Slot 1	1.1	
A.F.	P					
Alias	lin1					
Description						
Bus ID						
Baudrate	19200	•	bit/s			
Use Busspec	Not available				Ŧ	

Setting	Description	Default
Enable	Turn on logging for this channel	On
Alias	Freely selectable channel name	lin#
Bus ID	Additional ID for subsequent evaluation	
Baudrate	Transfer rate (in bit/s) Values: 20000, 19200, 9600, 4800, 2400	19200
Use Busspec	Load configuration template provided by the vehicle manufacturer	Off
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	On
Wake	N4000+ wakes up from sleep mode as soon as there is activity on this channel	On





## LIN > Trigger:

ault Propert	ties	
	igger from following LIN message:	
Ы		
Ox 0		
	5 6 7 8	
	XXXXXXXX XXXXXXXX XXXXXXXX XXXXXXXX	
Enable Trig	igger from following LIN message:	
ы	1 2 3 4	
Ox 0		
	XXXXXXXX XXXXXXXX XXXXXXXX XXXXXXXX	
	5 6 7 8	
	XX E XX E XX E	
	XXXXXXXX XXXXXXX XXXXXXX XXXXXXXX	
Enable Triv	igger from following LIN message:	
	igger from lonowing Lin message.	
Ы		
Ox 0		
	XXXXXXXX XXXXXXX XXXXXXX XXXXXXXX	
	xxxxxxxx  xxxxxxxx  xxxxxxxx  xxxxxxxx	
Enable Triv	igger from following LIN message:	
Ы		
Ox 0		
	XXXXXXXX XXXXXXX XXXXXXXX XXXXXXXX	
	5 6 7 8	

Configure triggers:

- Select the check box *Enable Trigger from following LIN message*.
- Under *Id*, specify the ID of the LIN message that raises a trigger.
   (→ Changing the numbering system)
- ► Specify the payload bytes from 1 to 8. (→ Set bits)
- Repeat as necessary for up to a total of five triggers.



## No trigger response

Because of the missing transmission capability, there are no trigger responses available for the LIN interface.



# RS-232:

📕 💥 Interface-ty	pe:RS232 Channel:1		
Default Properties			
Protocol			
Raw	GNLog	© DLT	_
🔽 Enable			
Alias rs2	32_1		
Description			
Bus ID			
Use Busspec	lot available	Ŧ	
Baudrate	115200	•	
Bits	8 bit	•	
Parity	None	•	
Stopbits	1 bit	•	
Message Delimiter	LF(10/0x0A)	•	
Max packet size	1000	Bytes	
RX Timeout	250	ms	
Prevent Sleep Mo	de		
✓ Wake			

# USER MANUAL



XORAYASUITE

Setting	Description	Default
Protocol	Raw, GNLog or DLT	Raw
Enable	Turn on logging for this channel	On
Alias	Freely selectable channel name	rs232_# or gnlog# or DLT#
Bus ID	Additional ID for subsequent evaluation	
Use Busspec	Load configuration template provided by the vehicle manufacturer	Off
Debug level**	Detail level of the debug information GNLog: 0 to 3 (max) DLT: 0 (None) to 6 (Verbose)	GNLog: 2 DLT: 0 (None)
Trace state***	Send trace messages	Off
Verbose mode***	<i>Off</i> : Send only dynamic data <i>On</i> : Send dynamic and static data	Off
Baudrate	Transfer rate (in bit/s) Values: 4800, 9600, 19200, 38400, 57600, 115200, 230400	115200
Bits	Number of data bits of a data block Values: 5 bit, 6 bit, 7 bit, 8 bit	8 bit
Parity	Parity check for error detection Values: None, Odd, Even	None
Stopbits	Number of stop bits that mark the end of a data block Values: 1 bit, 2 bit	1 bit
keep low level data stream**	Underlying RS-232 data are saved	Off
Message Delimiter*	Delimiter that marks the end of a message Values: $LF(10/0x0A) =$ end of line, None	LF(10/0x0A)
Max packet size*	Maximum packet size (in Bytes)	1000
RX Timeout*	If no new character is received during this period (in ms), then the previously received data are interpreted as completed message <i>O</i> : Function disabled	250
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	On
Wake*	N4000+ wakes up from sleep mode as soon as there is activity on this channel	On





# Ethernet:

# Ethernet > Settings:

efault Properties			
V Enable		rear side	
Nias	ethemet1		
Description			
Bus ID			
Use Busspec	Not available		

Setting	Description	Default
Enable	Turn on logging for this channel	On
Alias	Freely selectable channel name	ethernet#
Bus ID	Additional ID for subsequent evaluation	
Use Busspec	Load configuration template provided by the vehicle manufacturer	Off
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	On

# Ethernet > Filter:

Pre-filter conditions				
CC1111000000011100	lagat Op 12 12	0	inclum metan weator AC abbrea	BAC * 18 Tegel 25 South * 18 Tegel **
Gumer dispetching M William Type		X E X E E NO	, [	Rest Frate
(2) HID VG How Tag	7FD 54100 +			
19) BEZ YOHO OverTag Load presets	hillAl • 20		2	
				Traditio packet logging
Add pre-f	filter		4	Increase pre-filter priority
Delete pr			5	Decrease pre-filter priority
Save pre-	filter			

The filter is executed in two successive steps:

- Pre-filter
   MAC address
- Queue dispatching filter EtherType and VLAN

Configure pre-filters:

- ► Click Add pre-filter (1).
- Choose the *Filter type* (only *MAC* is available at the current development stage).
- Under Direction, choose if the filter applies to a participant who is Source and/or Target.
- ► Under *Operator*, choose if the filter is added to the whitelist (==) or the blacklist (!=).
- ► Specify the *MAC* address.
- ► Click Save pre-filter (3).
- Repeat as necessary for further pre-filters.





#### **Priorities of pre-filters**

Change the priorities of the pre-filters with the buttons (4) and (5).

The XORAYASuite applies the first pre-filter from the top that matches the condition. The other pre-filters are ignored.

The N4000+ processes packet data in Online mode and HDD mode via the so-called default-queue. In the stream-queue, only HDD mode recording is possible, and streaming data are directly stored without creating statistics.

The queue dispatching filter compares *EtherType* and both VLAN tags (*InnerTag*, *OuterTag*) of received Ethernet frames with the bytes specified here. ( $\rightarrow$  Set bits)

If all selected filter conditions are matched, the Ethernet frame is assigned to the streaming data, otherwise to the packet data. If the Ethernet frame contains no or only one VLAN tag, the filter conditions for the non-existing fields are ignored.

Via *Load presets*, you can configure filter conditions in such way that either all frames are assigned to streaming data (*Streaming logging only*) or all frames to packet data (*Packet logging only*).

Setting	Description	Default			
EtherType	Expected result of the check on the EtherType field if matching				
TPID (InnerTag)	Tag protocol identifier of the inner VLAN tag for Ethernet frames (always 0x8100)	0x8100			
TCI (InnerTag)	Expected result of the check on the inner VLAN tag if matching	0x0			
TPID (OuterTag)	Tag protocol identifier of the outer VLAN tag for Ethernet frames Values: 0x88A8, 0x9100, 0x9200, 0x9300	0x88A8			
TCI (OuterTag)	Expected result of the check on the outer VLAN tag if matching	0x0			
NOT	Invert filter condition	Off			
Enable packet logging	Record filtered packet data	On			
Enable streaming logging	Record filtered streaming data	On			



# Ethernet protocols:

au	t Properties				
99	riopenies				
<u></u>					
	Add GNLog	Add I	NT		
	Add Gracog	Audi	JLI		
	Abd Ghilog	Add			
	Add Ghilog	Add I			
	Interface	Alias	State	Update	Delete
	7			Update 5	Delete

In this configuration section, you can add, update and delete GNLog and DLT channels. Both protocols are recorded via the LAN host ports or the BroadR-Reach interface.

Interface-type:D	DLT Channel:1
Default Properties	
Enable	
Alias	DLT1
Description	
Bus ID	
Source	✓ TCP ▼
	IP
	Port 3490 🚔 Default
Use Busspec No	t available 👻
Prevent Sleep Mod	e
Debug level	Debug Level 0 (None 👻
Trace state	Off 🔹
Verbose mode	Off 🔹
VLan Id	Chx 1
	urrent New
IP address 0 0	. 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0 . 0
IP mask 0 . 0	
	Accept
State	



Setting	Description	Default			
Enable	Turn on logging for this channel	Off			
Alias	Alias Freely selectable channel name				
Bus ID	Bus ID Additional ID for subsequent evaluation				
Source	Source TCP (GNLog, DLT) or UDP (only DLT) IP address and port of the ECU Default sets the port to 851 (GNLog) or 3490 (DLT)				
Use Busspec	Load configuration template provided by the vehicle manufacturer	Off			
Prevent Sleep Mode					
Debug level	Detail level of the debug information GNLog: 0 to 3 (max) DLT: 0 (None) to 6 (Verbose)	GNLog: 2 DLT: 0 (None)			
Trace state*	Send trace messages	Off			
Verbose mode*	<i>Off</i> : Send only dynamic data <i>On</i> : Send dynamic and static data	Off			
VLan Id	Check box activates VLAN ID according to IEEE 802.1Q Values: 1 to 4095	1			
IP address	IP address which the N4000+ uses in the communication with the ECU	0.0.0.0			
IP mask	Network mask which the N4000+ uses in the communication with the ECU	0.0.0.0			

\* Only for DLT



# VIDEO:

Connect camera:

- Connect the camera to one of the Ethernet log interfaces (N/P).
   (→ Connections and controls)
- Connect another Ethernet log interface (N/P) to one of the LAN host ports (E).
- Connect another LAN host port (E) to the PC.

Control video recordings:

- Create one or multiple signal-based triggers of the VIDEO interface. or
- ► Activate one or multiple trigger actions of the button interface that effect the video recording. (→ Button)



# INTERFACE\_NET\_CAMERA

This licence is required for video recordings.

Check in category *Versions* of system settings to verify which licences are activated for your N4000+. (→ Versions)

#### VIDEO > Settings:

efault Prop	erties	
Enable		
Alias	video1	
Description		
Bus ID		
URL		default



Setting	Description	Default			
Enable	Turn on logging for this channel	Off			
Alias	Freely selectable channel name vi				
Bus ID	Text box <i>Bus ID</i> Additional ID for subsequent evaluation				
URL	To control an IP camera <i>default</i> enters the sample configuration of a Basler camera				
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	On			

#### VIDEO > Trigger:

	al 🧼 📰 💥 Interface-type:VIDEC	O Channel:1				
(	Create replay 🕕					
	Message1.Signal1 > 500 mv	Z X A U				
	On Message1.Signal2 & Message2.Signal2	nal3	<b>B</b> ABB			
1	Take screenshot (i)					
	Trigger type	2	05			
1	Add trigger	4	Delete trigger			
2	Trigger type	5	Move trigger up			
3	Edit trigger	6	Move trigger down			

Here, you create conditions that trigger the following pre-defined actions:

- Create replay (the video stream currently stored in the circular buffer is saved permanently)
- Take screenshot
- Start Stream
- Stop Stream



Configure triggers:

- On the header of the desired trigger action, click *Add trigger* (1).
- Select the desired *Trigger type* (2).
- ► Create a single condition or multiple combined conditions for this trigger. (→ Create trigger conditions)
- ▶ If required, repeat the above steps for further triggers.



# Number of configurable triggers

You can configure a maximum of ten triggers per VIDEO interface channel.



# DiagCCP:

DiagCCP > Settings:

efault Propert	ies			
Enable				Spy CCP traffic
Alias	ccp1			
Description				
Bus ID				
Prevent Sle	ep Mode			
Source	🕜 Can_1 (c	an1)	<b>*</b>	
A2L configurat	14 ST 11			0 0 -
A2L file	C:\CCF	Description_file.a2	ţ.	
				EPK
Signal configur	ration			7
<ul> <li>Selection</li> </ul>		\CCP\Signal_filter_fi	le xml	
Manual	-	Signal selection		
Overview		-11 C		
	100_ms	2,2%		50 signals 🔺
6	10_ms	10,5%		selected 100 ms:
	seg_sync	34,9%		50 signals
	Polling	50 signals / 53 By	tes	- Polling: =
Bus load	+	8,6%		selected
Workflow settir	ngs			
Retry max	Dec 3	Connections	with E	CU
Data timeout	Dec 10	s		
State				
			5	Open selection file
Clear all s	settings		5	open selection me





#### PROTOCOL\_CCP PROTOCOL\_CCP\_SPY

The available modes (Master, Spy) depend on the activation of these licences.

Check in category *Versions* of system settings to verify which licences are activated for your N4000+. (→ Versions)

Setting	Description	Default		
Enable	nable Turn on logging for this channel			
Spy CCP traffic	CCP mode On: Spy (external communication is monitored, no sending) Off: Master	Off		
Alias	Freely selectable channel name	ccp#		
Bus ID	Additional ID for subsequent evaluation			
Prevent Sleep Mode				
Source	Physical CAN channel to be used	Can_1 (can1)		
A2L file	Description file, which is suitable for the ECU and is loaded to configure the CCP connection			
Selection file	Selection file Signal filter file (XML, CFG or LAB), which contains a (pre-)selection of the signals to be monitored			
Retry max	Retry max Maximum number of retries after unsuccessful connection attempt			
Data timeout	No data received for this period of time (in s) leads to an error	10		

Meaning of the symbols for the physical CAN channels:

- transmission-capable
- transmission-capable, but currently set to passive
- × not transmission-capable
- 🗡 not enabled

Via *Edit CAN interface channel* (2) button, you can enable it, activate its transmission capability or change its baudrate if necessary.



## A2L configuration:

- Click Open A2L file (3) and select the description file that corresponds with the ECU.
  - The XORAYASuite reads the A2L file and configures the CCP connection accordingly.
  - ☑ If Overwrite alias with ECU name under Settings (6) is activated, Alias is also changed.
  - ✓ If supported by the A2L file, the XORAYASuite automatically runs an EPK version check with the ECU and displays the result via the Traffic light for the EPK check (4).

You can also execute this check manually via the *EPK* button.

Levels of the *Traffic light for the EPK check* (4):

- green check successful
- yellow check not possible
- red check not successful

Signal configuration:

- Click Open selection file (5) and select a suitable XML, CFG or LAB file. or
- ► Click *Signal selection* and select the signals manually. (→ Filter)
  - ☑ The XORAYASuite calculates the expected percentage of the bus load increase.

The result evaluation is displayed via the *Traffic light for the bus load* (7).

Configure the levels of the *Traffic light for the bus load* (7):

- Right-click on the traffic light and then on Edit traffic light settings for this interface type.
- Specify the percentage limit between green and yellow (standard: 50).
- Specify the percentage limit between yellow and red (standard: 80).
- Click OK.



# DiagCCP > Filter:

	iault	Properties	-	erface-type:D		han	9 10				
lr	ndex	Name	Address	seg_sync	1 9 10	ns		100_ms	4	Polling	
0		Signal1	E0010000		<b>W</b>	<b>U</b>				none	÷
1		Signal2	E0020000		6	V				none	
2		Signal3	E0030000			1975				none	
3		Signal4	E0040000							1000ms 🔹	
	Sho	w all sig	gnals	1	7	E	kport	signals		r	
2	Sea	rch box			8	D	isplay	CCP main	n set	ttings	
;	Ref	resh sig	nal list		9	Α	Add polling channel*				
ŀ	Dis	play sel	ected signa	ls	10	St	atus (	of the sig	nal c	definition	file
,	Cle	ar select	ted signals		11	P	rescal	er*			
;	Imp	ort sigr	nals								

\* Only if supported by the A2L file

Select signals for the DAQ measurement mode:

- Select the check box of the signal (row) for the event channel (column). or
- Highlight one or multiple rows and right-click to activate these signals simultaneously for one event channel.

Select signals for the polling measurement mode:

• Click Add polling channel (9).

The button is inactive if the A2L file does not support polling.

In the row of the signal, select the polling cycle from the drop-down list.

Filter signal list:

Enter the term or partial term in the search box (2) and click *Refresh* signal list (3).

or

Click Display selected signals (4) to only display signals with selected check boxes or selected polling cycle.

Clear signal list filter:

► Click Show all signals (1).



To allow a later MDF export of the data without A2L file, generate a signal definition file in the *Other* category and save it, optionally encrypted, on the N4000+. ( $\rightarrow$  Other)

*Status of the signal definition file* (10) displays the current state of the file and changes its state by clicking:

- not generated
- saved on N4000+
- saved encrypted on N4000+
- not saved on N4000+

If supported by the A2L file, you can reduce the sampling rate of each event channel by increasing the *Prescaler* (11).



# DiagCCP > Trigger:

	fault Properties	agCCP C	hannel:1
	Start CCP logging 🕕		
	Message1.Signal1 > 500 mv		Z X 1 U
	On Message 1. Signal 2 & Message 2. Signal 3		S A A A
	Stop CCP logging 🕕		
	Trigger type	Ž	05
	Add trigger	4	Delete trigger
)	Trigger type	5	Move trigger up
3	Edit trigger	6	Move trigger down

Here, you create conditions that trigger the following pre-defined actions:

- Start CCP logging
- Stop CCP logging



#### Start and stop without trigger conditions

Even when you do not create trigger conditions, the CCP recording, provided it is activated, starts and stops automatically at the beginning or ending of the data recording in online mode or HDD mode.

Configure triggers:

- On the header of the desired trigger action, click *Add trigger* (1).
- Select the desired *Trigger type* (2).
- ► Create a single condition or multiple combined conditions for this trigger. (→ Create trigger conditions)
- ▶ If required, repeat the above steps for further triggers.



#### Number of configurable triggers

You can configure a maximum of ten triggers per DiagCCP interface channel.



#### DiagCCP > Other:

	🛛 💥 🍸 🤯 Interf	ace-type:Diag	CCPC	hannel:1			
MDF-Exp	ort of signals ate signal definition file o crypt the signal definition ort of additional sign	file	t witho	ut A2L file	)		
	Message	Signal		Can ID	Source	_	Delete
CAN CAN	Botschaft 1 Botschaft 2	Signal1 Signal3		0x120 0x121	[1] CAN 1 (ca [1] CAN 1 (ca	1923	×
					Tech, name	Botso	haft
i di ∎	Message1 (0x120)	Sign	11.49		Signal3	ALC: NOT	nge2 (0x121)
	Message2 (0x121) Signal3	Sign			Signal4		age2 (0x121)
	Signal4	5	m			60	•
1 Show/h	nide A2L signals		4	Additi	onal signals		
2 Delete	signal		5	Signal	selection		
3 Delete	signal definition f	ile					

To allow a later MDF export of the data without A2L file, generate a signal definition file as a reduced A2L file and save it, optionally encrypted, on the N4000+.

Create and encrypt the signal definition file by selecting the check boxes under *MDF-Export of signals*.

Add additional signals (4) to the signal definition file by selecting the desired signals (5). ( $\rightarrow$  Signal selection)

By clicking (1), you also display the signals which are imported from the A2L file.

By clicking (2), you delete the selected signals and with (3) the whole signal definition file.



# DiagCCP > Advanced:

This category displays an overview of the configured event channels and allows the definition of a seed and key function for the encrypted communication with the ECU.

Create and test the seed and key function:

- Click Add basic structure of the function (1).
- ▶ Insert the algorithm that corresponds with the ECU.
- Define the *Input data* (2) to test the function.
- Click Execute function (3).
  - The XORAYASuite calculates the output data (key) from the input data (seed) and compares it with the key calculated by the ECU.



# DiagXCP:

# DiagXCP > Settings:

	😤 🍸 🤯 Interface-type:Dia	gXCP (	hannel:1
Default Properti	ies		
🕅 Enable			Spy XCP traffic
Alias	xcp1		
Description			
Bus ID	-		
Prevent Sle	ep Mode		
Source	🖉 Can_1 (can1)	-	
A2L configurati	1		õ
A2L file	C:\XCP\Description_file.a	2	💾 🗋
//22 110			CAN TEPK
	Transport layer 0 : Exa	mpie -	
Signal configur	1967 A.	- Array Intel	
Selection f	file Y C:\XCP\Signal_filter	_file.xml	
Manual	Signal selection	1	
Overview			
	100 0.0DT / C1 D.		E0 sizes la
	100_ms 9 ODT / 61 By		50 signals 🔺
	10_ms 9 ODT / 61 By seg_sync 9 ODT / 61 By	1400 M 1	100_ms:
	seg_sync 9 ODT / 61 By	tes	50 signals
	Polling 50 signals / 61 B	Bytes	- Polling: E 50 signals
Bus load	+ 15,6%	100000000	0 RPM
Workflow settir	ngs		
Retry max	Dec 3 Connection	ns with E	CU
Data timeout	Dec 10 s		
×1320-7	n n n		
State			
Clear all s	settings	5	Open selection file
Edit inter	face channel	6	Settings
Open A2L	file	7	Traffic light for the bus load
Traffic lig	ht for the EPK check	8	Engine RPM*

\* Only for angle-synchronous event channels





## PROTOCOL\_XCP\_MASTER PROTOCOL\_XCP\_SPY PROTOCOL\_XCP\_ON\_CAN PROTOCOL\_XCP\_ON\_FLEXRAY

The available modes (Master, Spy) and physical buses (CAN, FlexRay) depend on the activation of these licences.

Check in category *Versions* of system settings to verify which licences are activated for your N4000+. (→ Versions)

Setting	Description	Default
Enable	Turn on logging for this channel	Off
Spy XCP traffic	XCP mode	Off
	<i>On</i> : Spy (external communication is monitored, no sending)	
	<i>Off</i> : Master	
Alias	Freely selectable channel name	xcp#
Bus ID	Additional ID for subsequent evaluation	
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	Off
Source	Physical CAN or FlexRay channel to be used	Can_1 (can1)
A2L file	Description file, which is suitable for the ECU and is loaded to configure the XCP connection	
Transport layer	Selection if the A2L contains multiple transport layer descriptions	
Selection file	Signal filter file (XML, CFG or LAB), which contains a (pre-)selection of the signals to be monitored	
Retry max	Maximum number of retries after unsuccessful connection attempt	3
Data timeout	No data received for this period of time (in s) leads to an error	10



Meaning of the symbols for the available CAN or FlexRay channels:

- transmission-capable
- transmission-capable, but currently set to passive
- × not transmission-capable (only for CAN)
- 🗡 🛛 not enabled

Via *Edit interface channel* (2) button, you can enable it, activate its transmission capability or change its baudrate if necessary.

A2L configuration:

- Click Open A2L file (3) and select the description file that corresponds with the ECU.
  - The XORAYASuite reads the A2L file and configures the XCP connection accordingly.
  - ☑ If Overwrite alias with ECU name under Settings (6) is activated, Alias is also changed.
- If the A2L contains multiple transport layer descriptions, select the layer from the appearing window.

You can change this selection afterwards via the drop-down list *Transport layer*.

If the time value T7 is equal to 0, increase this value in the appearing window to avoid protocol errors with the ECU.

You can change this value and all the other time values in the category Advanced. ( $\rightarrow$  Advanced)

✓ If supported by the A2L file, the XORAYASuite automatically runs an EPK version check with the ECU and displays the result via the Traffic light for the EPK check (4).

You can also execute this check manually via the *EPK* button.

Levels of the *Traffic light for the EPK check* (4):

- green check successful
- yellow check not possible
- red check not successful



Signal configuration:

- Click Open selection file (5) and select a suitable XML, CFG or LAB file. or
- ► Click *Signal selection* and select the signals manually. (→ Filter)
  - ☑ The XORAYASuite calculates the expected percentage of the bus load increase.

The result evaluation is displayed via the *Traffic light for the bus load* (7).

► If angle-synchronous (RPM-dependent) event channels are used, select the *Engine RPM* (8), which influences the bus load calculation.

Configure the levels of the *Traffic light for the bus load* (7):

- Right-click on the traffic light and then on Edit traffic light settings for this interface type.
- Specify the percentage limit between green and yellow (standard: 50).
- Specify the percentage limit between yellow and red (standard: 80).
- Click OK.



# DiagXCP > Filter:

> 🖪 🐰	Y 🥥 Int	erface-type:Diag	XCP CI	hannel:1			
Properties 2	l g	<b>99 9</b> 9		99	ł.		_
Name	Address	seg_sy	10ms	-	100ms 🔬 🔒	Polling	
Signal1	E0010000			-ww	60	none	•
Signal2	E0020000			V		none	•
Signal3	E0030000			1971	V	none	
Signal4	E0040000			<b>F</b>		1000ms	. H
ow all sig	gnals		7	Export	signals		
arch box			8	Display XCP main settings			
fresh sig	nal list		9	Add polling channel*			
splay sel	ected signa	als	10	Status of the signal definition file			
ear select	ted signals		11	Prescal	er*		
port sigr	nals		12	Change	e column orde	er	
	Properties Name Signal1 Signal2 Signal3 Signal4 ow all sig arch box fresh sig splay sele ear select	Properties 2 Name Address Signal1 E0010000 Signal2 E0020000 Signal3 E0030000 Signal4 E0040000 ow all signals arch box fresh signal list splay selected signa	Properties       3       4       5       6         Name       Address       seg_sy       1         Signal1       E0010000       Image: Signal2       E0020000       Image: Signal3         Signal3       E0030000       Image: Signal4       E0040000       Image: Signal4         Signal4       E0040000       Image: Signal5       Image: Signal5         ow all signals       arch box       Image: Signal list         splay selected signals       sear selected signals	Properties       3       4       5       6       3         Name       Address       seg_sy       10ms         Signal1       E0010000       10ms         Signal2       E0020000       1         Signal3       E0030000       1         Signal4       E0040000       1         ow all signals       7         arch box       8         fresh signal list       9         splay selected signals       10         ear selected signals       11	2       3       4       5       6       7       8       9       10ms         Signal1       E0010000       Image: Constraint of the second stress of the seco	Properties       3       4       5       6       8       9       10ms         Name       Address       seg_sy       10ms       100ms       100ms <td< td=""><td>Properties       3       4       5       6       7       10ms       100ms       Polling         Name       Address       seg_sy       10ms       10ms       100ms       Polling         Signal1       E0010000       Image: seg_sy       10ms       10ms       100ms       Polling         Signal2       E0020000       Image: seg_sy       Polling       Image: seg_sy       Image: seg_sy       Polling       Image: seg_sy       Image: seg_sy       Polling       Image: seg_sy       Image: seg_sy</td></td<>	Properties       3       4       5       6       7       10ms       100ms       Polling         Name       Address       seg_sy       10ms       10ms       100ms       Polling         Signal1       E0010000       Image: seg_sy       10ms       10ms       100ms       Polling         Signal2       E0020000       Image: seg_sy       Polling       Image: seg_sy       Image: seg_sy       Polling       Image: seg_sy       Image: seg_sy       Polling       Image: seg_sy       Image: seg_sy

\* Only if supported by the A2L file

Select signals for the DAQ measurement mode:

- Select the check box of the signal (row) for the event channel (column). or
- Highlight one or multiple rows and right-click to activate these signals simultaneously for one event channel.

Select signals for the polling measurement mode:

Click Add polling channel (9).

The button is inactive if the A2L file does not support polling.

In the row of the signal, select the polling cycle from the drop-down list.

Filter signal list:

Enter the term or partial term in the search box (2) and click *Refresh* signal list (3).

or

Click Display selected signals (4) to only display signals with selected check boxes or selected polling cycle.

Clear signal list filter:

► Click Show all signals (1).



To allow a later MDF export of the data without A2L file, generate a signal definition file in the *Other* category and save it, optionally encrypted, on the N4000+. ( $\rightarrow$  Other)

*Status of the signal definition file* (10) displays the current state of the file and changes its state by clicking:

- not generated
- saved on N4000+
- saved encrypted on N4000+
- not saved on N4000+

If supported by the A2L file, you can reduce the sampling rate of each event channel by increasing the *Prescaler* (11).

The column order of the event channels is adjustable via the drop-down lists (12).



# DiagXCP > Trigger:

	fault Properties	9XCP (	hannel:1
	Start XCP logging 🕕		
	Message1.Signal1 > 500 mv		XIV
	On Message1.Signal2 & Message2.Signal3		XII
	Stop XCP logging ①		
	Trigger type	Ž	05
1	Add trigger	4	Delete trigger
2	Trigger type	5	Move trigger up
3	Edit trigger	6	Move trigger down

Here, you create conditions that trigger the following pre-defined actions:

- Start XCP logging
- Stop XCP logging



# Start and stop without trigger conditions

Even when you do not create trigger conditions, the XCP recording, provided it is activated, starts and stops automatically at the beginning or ending of the data recording in online mode or HDD mode.

Configure triggers:

- On the header of the desired trigger action, click *Add trigger* (1).
- Select the desired *Trigger type* (2).
- Create a single condition or multiple combined conditions for this trigger. (> Create trigger conditions)
- ▶ If required, repeat the above steps for further triggers.



#### Number of configurable triggers

You can configure a maximum of ten triggers per DiagXCP interface channel.



#### DiagXCP > Other:

	🖹 💥 🏹 🥥 Interfa	ace-type:Diag	XCP Channe	l:1	
MDF-Expe Created Enc	erties ort of signals ate signal definition file o anypt the signal definition ort of additional sign	file	without A2L f	ile)	
1862					
Туре	Message	Signal	Can I	D Source	Delete
CAN CAN	Botschaft1 Botschaft2	Signal1 Signal3	0x120 0x121		00.0207
	1 (0001)		1 := •	Tall	Dave 1 0
	Message1 (0x120)	Nan	100	Tech. name	Botschaft
□ • • • • •	Message2 (0x121) Signal3	Signa		Signal3 Signal4	Message 2 (0x121) Message 2 (0x121)
	■ Signal4	5	m		,
1 Show/h	ide A2L signals		4 Add	itional signals	
2 Delete	-		1 1	al selection	
3 Delete	signal definition f	ام			

To allow a later MDF export of the data without A2L file, generate a signal definition file as a reduced A2L file and save it, optionally encrypted, on the N4000+.

Create and encrypt the signal definition file by selecting the check boxes under *MDF-Export of signals*.

Add additional signals (4) to the signal definition file by selecting the desired signals (5). ( $\rightarrow$  Signal selection)

By clicking (1), you also display the signals which are imported from the A2L file.

By clicking (2), you delete the selected signals and with (3) the whole signal definition file.



# DiagXCP > Advanced:

3 🖃	🧼 🔄 💥 🔽	🤯 Interface-type:Diag	XCP Channel:1	L.		
	fault Properties					
	ropenes					
	Event channels of	verview				
	Short name	Long name	Number	Rate	Priority	DAQ / STIN
	seg_sync	segment synchronous	0	Not Cyclic	3	DAQ
	10_ms	10ms time synchronous	1	10 ms	2	DAQ
	100_ms	100ms time synchronous	2	100 ms	1	DAQ
	- ⊞ FlexRay Buffer c	onfiguration				
	 ☐ ⊞ FlexRay Buffer m	happing				
	Seed and Key —					
	Test environment					
	Test environment	<u>a:</u>				
		<u>a:</u>				
	Input data	<u>a:</u>				
	Input data 2 Result: 3	a: ure of the function	3 Execu	te functio	n	

This category consists of the following elements:

- Overview of the configured event channels
- Timeout values (changeable)
- FlexRay buffer configuration (partly changeable)
- Mapping of the FlexRay buffers to the event channels (changeable)
- Definition of a seed and key function for the encrypted communication with the ECU



Create and test the seed and key function:

- Click Add basic structure of the function (1).
- ▶ Insert the algorithm that corresponds with the ECU.
- Define the *Input data* (2) to test the function.
- Click Execute function (3).
  - The XORAYASuite calculates the output data (key) from the input data (seed) and compares it with the key calculated by the ECU.



# Event:

This interface must be activated for proper functioning of:

- Triggers
- Snapshots
- the Button interface

# Event > Settings:

Default Prope	Interface-type:Event Channel	:1	
Enable			
Alias	event1		
Description			
Bus ID			

Setting	Description	Default
Enable	Turn on logging for this channel	On
Alias	Freely selectable channel name	event#
Bus ID	Additional ID for subsequent evaluation	
Prevent Sleep Mode	N4000+ will not go into sleep mode as long as there is activity on this channel	On



#### Event > Trigger:

De	fault Properties		
	Message1.Signal1 > 500 mv On Message1.Signal2 & Message2.Signal3		0000
	Trigger type	2	0
1	Add trigger	4	Delete trigger
2	Trigger type	5	Move trigger up
3	Edit trigger	6	Move trigger down

Here, you create trigger conditions that write custom event messages.

Configure triggers:

- ► Click Add trigger (1).
- Select the desired *Trigger type* (2).
- ► Create a single condition or multiple combined conditions for this trigger. (→ Create trigger conditions)
- ▶ If required, repeat the above steps for further triggers.



# Number of configurable triggers

You can configure a maximum of ten event triggers.



#### Button:

Use this interface to define which actions are triggered by the following trigger types.

Each trigger type is assigned a channel of the button interface as follows ( $\rightarrow$  Connections and controls):

- trigger\_button Pressing the trigger button (K)
- wake\_line Signal at the trigger input (M)

Actions with a yellow background and a blue outline are enabled.

fault Properties	s			
V Enable				
Nias	trigger_button			
Description				
Bus ID				
Prevent Slee	p Mode			
Send Event	Rising edge	i <b>▼</b> :		
🗸 Wake				
Debounce time	<b>Dec</b> 1000	μs		
Actions on trigg	er-activation			

# USER MANUAL



XORAYASUITE

Setting	Description	Default			
Enable	Turn on logging for this channel	On			
Alias	Freely selectable channel name	trigger_button or wake_line			
Bus ID	Additional ID for subsequent evaluation				
Prevent Sleep Mode					
Send Event	Send Event Generate an additional event message either at the falling or at the rising edge Values: Falling edge, No event, Rising edge				
Wake	N4000+ wakes up from sleep mode as soon as there is activity on this channel	On			
Debounce time	Bridging time (in µs) to prevent undesired multiple events when a trigger is raised	1000			
Action (1)	Start logging	On			
Action (2)	Stop logging Long press is required (at least 3 s)	On			
Action (3)	Create snapshot	Off			
Action (4)	Eject USB device Long press is required (at least 3 s)	Off			
Action (5)	The video stream currently stored in the circular buffer is saved permanently	Off			
Action (6)	Create screenshot	Off			
Action (7)	Start video stream	Off			
Action (8)	Stop video stream	Off			
Action (9)	Send CAN trigger response 1	Off			
Action (10)	Send CAN trigger response 2	Off			



# 5.5.3 Signal configuration

In this section, you configure signals and define signal processings and triggers.



## Messages and signals

The payload of a message consists of signals with variable bit length.

Messages and signals are assigned names for easier handling.

#### Settings:

Def	fault Propertie		gs									
	000 Message	0 Signal	Frame ID	Source		Int	Raw	Phy	Counter	Upd	Del	
1.1	Message1 Message2	Signal1 Signal3	<ul><li>✓ 0x120</li><li>⊙ 0x121</li></ul>	[1] CAN 1 [1] CAN 1			123 122	18 28	0	90	××	
	📑 🔤 🗗 can 1 (X		00-0001)		: <b>#</b> [		Tech.	name	Bote	chaft		
	D Mes	sage1 (Ox	120)	Signal				name	in the second second	Message2 (0x121)		
		sage2 (Ux Signal3	121)	Signal4			Signal4		A CONTRACTOR OF A	Message2 (0x121)		
		Signal4		6	III						•	
1	Add signa	l manua	ally		4 R	efres	h sign	als				
2	Edit signa				5 C	onfig	gured s	ignals	5			
3	Delete sig	nal			6 Si	gnal	select	ion				

Select the desired signals from (6) to add them to the list of configured signals (5). ( $\rightarrow$  Signal selection)

This list is stored temporarily or permanently on the N4000+.

Click (1) or right-click anywhere in the list (5) to add additional signals manually.

Click (2) or right-click a configured signal in the list (5) to edit this signal.



## Signal processing:

Default Propertie	- 5. J	processing					
Туре	Interval	1st signal	2nd signal	Extra	Used /	Upd	Del
🛃 Log	500 ms	Message1.Signal1	2 <b>2</b> 2)		( <b>2</b> 4	9	×
La Count	1000 ms	Message 1. Signal 2	121	Binni	12	9	×
Compound	100 ms	Message2.Signal3	Message2.Signal4	Binni	1070	5	×
2. 0 X	15						
Configured	d signal	processings	2 Add sig	nal pro	cessing		

Add the desired signal processing to the list (1).

This list is stored temporarily or permanently on the N4000+.

II.	
I	
II.	- (O)
U,	

# DATA\_BINNING

This licence is required for signal processing.

Check in category *Versions* of system settings to verify which licences are activated for your N4000+. (→ Versions)

Add signal processing:

- Click Add signal processing (2).
- Select the desired signal processing type.

The following signal processing types are available:

- Log Only recording, no binning
- ≌ Count Signal binning
- Compound Combined binning of two signals



#### Signal binning

Classes reflect signal value ranges. Classification, or binning, allows a quick overview of how often the value of a signal fits into which class during measurement.



## Log:

Si	gnal			3 <b></b>	
In	terval	Dec 0	Ì	ms	
1	Save signal processi	ng	2	Cancel signal proce	ssing

Add signal processing:

- ► Select an already configured *Signal*. (→ Settings)
- Specify the *Interval*.
- Click Save signal processing (1).

 $\blacksquare$  The log signal processing is stored on the N4000+.



# Interval of the log signal processing

If you specify an interval, the last measured value of the signal is counted in this time range.

If you do not set an interval (corresponding to a *0* in the text box), the value of the signal is stored on each occurrence.



#### Count:

	- 🔗 X 🖉 🛜								
Sig	gnal logging with simple	count	binning						
	Binning name								
	Signal					•			
0	Calculation Overview								
	Assignment way	Autor	natic			•			
		F	law values		Ph	ys. values			
	Number of classes	Dec	0			unit			
	Begin	Ox	0						
	End	0x	0						
	Width	0x	0			Ŧ			
	Span width	0x	0			Ŧ			
	Interval	De	<b>c</b> 0	ms					
1	Save signal proc	cessi	ng		2	Cancel signa	al proc	essing	

Add signal processing count:

- Specify a *Binning name*.
- ► Select an already configured *Signal*. (→ Settings)
- Select from Assignment way which three out of five text boxes, i.e. Number of classes, Begin, End, Width and Span width you would like to specify.

or

- Select Automatic to create classes of constant width uniformly over the entire value range.
- Complete all active text boxes in the *Calculation* tab.
  - $\checkmark$  The XORAYASuite calculates the remaining values and fills the text boxes accordingly.
- Specify the Interval.
- Click Save signal processing (1).
  - $\square$  The count signal processing is stored on the N4000+.





# Interval of count signal processing

If you specify an interval, the first measured value of the signal is counted in this time range.

If you do not set an interval (corresponding to a 0 in the text box), each signal value is counted.

#### Compound:

	1- <mark>8</mark> X	1										
Sig	gnal logging		ound b	inning					_			
3	Binning nam	ie								4	Binning nar	ne
	Signal							•			Signal	
(	Calculation	Overview							_	(	Calculation	Overvie
	Assignment	way	Auton	natic				•			Assignment	way
			R	law values		Ph	iys. values					
	Number of	classes	Dec	0				unit			Number of	classes
	Begin		0x	0				-			Begin	
	End		Ox	0				-			End	
	Width		Ox	0				-			Width	
	Span width	ı	0x	0				-			Span widt	n
	Interval		De	<b>c</b> 0	ms							
1	Save sig	gnal proc	cessi	ng		3	Signal <sup>·</sup>	1				
2	Cancel	signal pr	4	Signal 2	2							

The compound signal processing corresponds to a combined count-signal processing for two signals and is processed by the XORAYASuite as a twodimensional matrix. Therefore, the total class count is a product of the number of classes for both signals.

Add compound signal processing:

- Configure the binning for the first signal (3).
- Configure the binning for the second signal (4).
- Specify the *Interval*.
- Click Save signal processing (1).

 $\blacksquare$  The compound signal processing is stored on the N4000+.



# Edit or delete signal processing:

fault Propertie	s									
Туре	Interval	1st signal	2nd sign	nal	Extra	Used /	Upd	De		
Log	500 ms	Message1.Signal1	122			14	5	×		
Σ Count	1000 ms	Message 1. Signal 2	323		Binni	12 C	9	X		
Compound	100 ms	Message2.Signal3	Messag	e2.Signal4	Binni		9	X		
Signal logging v	vitheut binn	ing								
Signal		Message1.Sig	gnal1		*					
Interval		Dec 500		] ms						
Configure	d signal	processing	3	Edit sig	nal pro	cessing				
Delete signal processing										

Edit signal processing:

- Select the signal processing in the list (1).
- Click Edit signal processing (3).
   or
- ▶ Right-click the signal processing and then click *Edit signal processing*.

Delete signal processing:

- Select the signal processing in the list (1).
- Click Delete signal processing (2).



#### Trigger:

1	fault Properties		
5	Start Logging 🕕		
	Message1.Signal1 > 500 mv		Z X A U
	On Message1.Signal2 & Message2.Signal3		<b>BAABAABAAAAAAAAAAAAA</b>
5	Stop Logging 🕕		
	Trigger type	2	
1	Add trigger	4	Delete trigger
2	Trigger type	5	Move trigger up
3	Edit trigger	6	Move trigger down

Here, you create conditions that trigger the following actions:

- Start Logging
- Stop Logging
- Shutdown Logger
- Shut down logger without wake up
- Create Snapshot (→ Snapshot)

Add trigger:

- On the header of the desired trigger action, click *Add trigger* (1).
- Select the desired *Trigger type* (2).
- ► Create a single condition or multiple combined conditions for this trigger. (→ Create trigger conditions)
- ▶ If required, repeat the above steps for further triggers.



# Number of configurable triggers

You can configure a maximum of five general signal triggers.



# 5.6 Resetting to factory defaults

For unwanted or defective system or interface configurations, it is recommended to reset the N4000+ back to its factory defaults.

Logger View Help Language	
Disconnect	
Offline-Logging Online-Logging Probe-Logging	) 🖬 📼 🕌 🚑 🕱 🛄 🏠 System Set
Save changed configuration permanently Customer default configuration	XorayaN4000-0001
Reset configuration to factory settings	Interfaces
Format HDD	System 21
Synchronize time with	0200_0700_0100_000001
Restart	0200_0700_0700_000001
Restart and reconnect	18 Dezember 2019 - 10:24:38
Shutdown Shutdown (no wake.up)	ce No maintenance needed

In the Logger menu, click Reset configuration to factory settings to reset the system configuration or one or all interfaces to their factory defaults.

or

▶ Press the default button (D) for at least 3 seconds to reset all N4000+ settings. (→ Connections and controls)

The N4000+ goes into idle state by way of confirmation.

 $\blacksquare$  The configuration is reset.



# Updating the firmware

Factory setting are automatically restored whenever features are added or eliminated upon a firmware update. (→ Firmware-Update)

Therefore, you should check your configuration status after each firmware update.



# 5.7 Data recording

Data may be recorded in two ways:

Online mode

The N4000+ transmits received messages directly to a PC, where they are stored in log files. To do so, the N4000+ must be connected to the PC.

HDD mode

Received messages are stored on the internal N4000+ storage medium, on a USB flash drive or on the XORAYA ESU. No PC is required in this case, as the N4000+ is fully autonomous in this mode. HDD logging may still be started and stopped from the PC.



#### Simultaneous recording modes

Both modes can be operated in parallel, but separately controlled.

#### 5.7.1 Online mode

The Online-Logging tool enables data recording in online mode.

- Connect the N4000+ to the measurement environment.
   (→ Connecting the N4000+ to the measuring environment)
- Connect the N4000+ to the PC. ( $\rightarrow$  Connecting the N4000+ to the PC)
- ► Turn on the N4000+.
- ► Start the Online-Logging tool of the XORAYASuite. (→ Starting)
- Connect to the desired N4000+. ( $\rightarrow$  Connecting the N4000+)



	Ligger V ode 4200 Ster 2 Tes refer databas * Dissogn	0 Magaria - 1	Linguage States 1 Sect. [Spec.]		3 Series	<b>Q</b>	E.	
biter	tain	Alan	Messigen	Maga/s	Enten / Overflow	Errors/e	Denice	
1			ection to	logger		8	-	latest created session or
2	Start o	online l	ogging				measuren	nent in the <i>Viewer</i> tool
3	Start I	Hdd log	jging			10		coustic signal to identify
6	Displa	ay settii	ngs				N4000+	
7	Displa	ays the	current bu	us traffic				

Use *Display settings* (6) to customise the following:

- Path and filename (→ Export settings)
- Output format (→ Output formats)
- Acoustic warning or executing a script if a bus error is detected
- Buses to be recorded
- Colour assignments for the interfaces
- Signal description (→ Signal description settings)
- Load configuration template (Busspec)
- Manage logger favourites (→ Favourites)

Store data on the PC:

- Click Start online logging (2).
  - $\square$  Data received via interfaces are recorded on the PC.



#### HDD mode

Start the recording on the internal or external storage medium of the N4000+ via *Start Hdd logging* (3) or autonomously without a PC, as described in the relevant section. ( $\rightarrow$  HDD mode)

Both modes can be operated simultaneously.



Beter	A4-4306-5601			<b>8</b> . d		iila 🍕		泪	alla alla alla	<u>a</u> 1		000	
lag Tur	der statistics	00-02-18 0 Maga/a 0		System signals	0		C			U			
	How No.	Haw No.	Iver	Alexandre and a second	Device	Timestamp	les	100.071	Tunodil.	Level	Base	Huster	ID
	73		fame 1	trape, ballow	1	14.48.30 748394	1 00 00	DO MUNICIA		2		1.4	
	x	π	front_1	evers?	4	14.45.35 745515	6 00 m					1.0.0	
	8	1.00	Batan,1	Nam John		14.48.36 301210	1 00.00	05.7627036					
	76	82	System_1	system 1		14.46 39 686806	3 00:00	10.5081534		875			
	77.	183	liyeten_1	Autori 1	4	14 46 42 703797	00.00	135101043		875		1.8	
	78	85	System_1	area (	8	14 46 45 755858	7 00.00	16.5152460		875		7.8	
	79	17	System_1	system 1	4	14-46-42 705284	0,00,00	155170518		875		P.8.	
	80	19	Bysten_1	southern ?	8	14.46(81.711233	8 00.00	22.5206212		875		0.8	
	Releas	e conne	ection	o logge	r		7	Displ	ays the	curren	t bus t	traffic	
		nline lo					10					identify	
		Idd log						N400		-	-	-	
				evaluati									

Online logging information is distributed over several tabs.

The following table describes the general function of each tab and the options offered in the context menu when right-clicking.

# USER MANUAL



XORAYASUITE

Tab	Function and context menu
Interface	Summary of recorded messages and errors grouped by interfaces and channels Context menu: Show or hide columns Hide inactive interfaces or channels
Message	Summary of recorded messages and errors grouped by messages Context menu: • Fix selected rows • Filter data by interfaces or channels • Legend of the error flags
ССР / ХСР	Summary of recorded CCP / XCP signals Context menu: • Fix selected rows • Hide selected messages • Accelerate ECU registration of signals • Represent data graphically (→ Graph View) • Display physical properties
Signals	<ul> <li>Monitoring of defined signals (→ Signal selection)</li> <li>Context menu:</li> <li>Show or hide columns</li> <li>Hide selected signals</li> <li>Save, load and delete signal lists</li> </ul>
Send	Send user-defined CAN, RS-232 or Ethernet UDP messages once or cyclically
System signals	Display of system signals (core temperature, for example) as widgets
Live	<ul> <li>Live view of the current recording, where a row corresponds to a message</li> <li>Context menu: <ul> <li>Show or hide columns</li> <li>Filter data by interfaces, channels or CAN/FlexRay IDs</li> <li>Set Timemaster</li> <li>Freeze display</li> <li>Free up display area: Delete displayed rows</li> <li>Set the number of rows displayed (default: 500)</li> <li>Set details of the selected row: Specify whether the detail view will jump to new incoming messages or remains constant</li> <li>Represent data graphically (→ Graph View)</li> </ul> </li> </ul>
Config	Current N4000+ configuration





#### Messages and signals

The payload of a message consists of signals with variable bit length.

Messages and signals are assigned names for easier handling.



#### Timemaster

An additional column *Timediff.* is displayed when you set the Timemasters on a particular record. This column contains the time difference of each record to the Timemaster.

Represent data in graphical form:

- Click Displays the current bus traffic (7).
- ► Choose among Bus statistics, Message statistics and Interface statistics the desired source data for graphical output. (→ Graph View)

Stop data recording:

Click Stop online logging (2).



# 5.7.2 HDD mode

In this mode, the N4000+ saves to one of the following media:

- Internal storage medium (default)
- USB flash drive if *Record on USB stick* in the *Hard Disk* category is checked and the conditions described there are met (→ Hard Disk)
- Additional device XORAYA ESU (automatically if detected by the N4000+)

Start data recording:

- Connect the N4000+ to the measurement environment.
   (→ Connecting the N4000+ to the measuring environment)
- ► Optionally:

Connect a USB flash drive to the USB host interface (C). ( $\rightarrow$  Connections and controls)

► Optionally:

Connect a XORAYA ESU to the corresponding interface (F).

- ► Turn on the N4000+.
- ► Start the HDD recording by pressing the trigger button (K) on the N4000+.

 $\blacksquare$  Data received via the interfaces are recorded.

Stop data recording:

Press the trigger button (K) for at least 3 seconds.



# Configuration of trigger button

The behaviour of the trigger button can be configured via the button interface. ( $\rightarrow$  Button)



# HDD mode in the XORAYASuite

You can also start and stop the HDD mode from the Configuration, Online-Logging, Hdd-Download and Firmware-Update tools.

Data recorded on the storage medium is stored as sessions. Sessions always contain complete messages and are limited to a maximum size which defaults to 1000 MB.



New sessions are created under the following conditions:

- The HDD recording is started manually by a trigger or via the XORAYASuite.
- The N4000+ is turned on or woken up and Autostart in the Hard Disk category is checked. (→ Hard Disk)
- The session size exceeds the maximum size specified. In this case, the current session is closed, and a new session for the current measurement starts.

Sessions are closed under the following conditions:

- Recording is stopped manually
- The N4000+ goes into sleep mode
- The maximum size is exceeded

Existing sessions and measurements on the storage medium can be displayed, downloaded or deleted in the *Hdd-Download* tool of the XORAYASuite. ( $\rightarrow$  Hdd-Download)



#### 5.7.3 Log data

The storage location for log data to be recorded is specified in the text boxes *Path* and *Filename*. This applies both to the online logging as well as to log data downloaded from the storage medium.

Log data in *X2E-Native* format are stored in various files with the same base name but different file extensions. ( $\rightarrow$  X2E-Nativ)

The master file with the file extension DLI serves as link. This file contains information about the included log interfaces and references to the corresponding binary files.

File	Format	Meaning
<name>.dli</name>	ASCII	<ul> <li>Master file:</li> <li>Contains information about log interfaces and references to the binary files</li> </ul>
<name>.dlm</name>	Binary	<ul><li>Meta file:</li><li>Contains index information for faster search within binary data</li></ul>
<name>_0000.dlf <name>_0001.dlf </name></name>	Binary	<ul> <li>Binary file:</li> <li>Contains recorded data for all log interfaces</li> <li>To limit the file size, data are spread across multiple sequentially numbered files as needed</li> </ul>
<name>.dls</name>	ASCII	<ul> <li>Statistics file:</li> <li>optionally created if the property WriteStatistics is checked</li> </ul>



# 5.8 Hdd-Download

This tool allows downloading log data stored on the datalogger storage medium or a USB flash drive.

- Connect the N4000+ to the PC. ( $\rightarrow$  Connecting the N4000+ to the PC)
- Optionally:

Connect a XORAYA ESU to the corresponding interface (F). ( $\rightarrow$  Connections and controls)

- ► Turn on the N4000+.
- ► Start the *Hdd-Download* tool of the XORAYASuite. (→ Starting)

Logger	<b>i</b> ≢	Ĩ
		1
Start	Stop	Start
	Start (Vehicle Absolut)	TRANSFER STORES

- ► Connect to the desired N4000+. (→ Connecting the N4000+) or
- Connect to a USB flash drive that contains recorded measurements. or
- Connect to a directory on your PC that contains a measurement recorded via USB.



# USB flash drive in list

The connected USB flash drive is only available in the list if it is named *XORAYALOG* and contains the folder *usb\_queue*.

The following descriptions refer to the connection with a N4000+. Connecting with a USB flash drive or a directory works principally in the same way.



F.br	********	CAL 14		Dinto	100 C	-0	E	6	87		
See	clad 4	Connect	de Ineis FAS/Sne		35	D4	Equat an	Inge			
			-	08 10.2019 10.55-52 08 12.2019 10.47 48	10, 12, 2019 11, 20, 20 00, 12, 2019 10, 06, 20 00, 12, 2019 10, 17, 44 00, 12, 2019 10, 17, 44 00, 12, 2019 10, 45, 45, 12		0 Overant	mats infection		Sheers (A*) Stellererses	- 9 × 9
	Rele	ase co	nnecti	on to logg	1711201516100 17112015155720 er	001	5	Display se	ttinas	SHeffereifield S	
2		t Hdd I					6		-	ath in Windo	ws Explorer
3	1	t down		-			7	Show dow			•
4	Cha	nge dis	sk*								

\* Only with connected XORAYA ESU

Click *Change disk* (4) to change between the internal storage medium and a connected XORAYA ESU.

Use *Display settings* (5) or the *Settings* command in the *Download* menu to customise the following:

- Miscellaneous settings, for example, enable/disable time groups or eject the USB flash drive automatically after disconnecting
- Colour assignments for the interfaces
- Manage logger favourites (→ Favourites)



#### Change temporary download folder

When downloading measurements that include a stream queue part, by default, the XORAYASuite saves data in the Windows temporary folder. If there is not sufficient disk space available on this drive, it is possible to specify an alternative path in the user or system environment variable *X2E\_XORAYA\_SHADOW\_DIR*.

Please note that restarting Windows might be necessary after setting the environment variable. For further questions, contact your system administrator.



There are different ways to select the log data to download:

- Edit menu: Select all or Select none
- Sessions and Measurements tabs
- Calendar tab
- Time range tab

#### Sessions/Measurements:

You can show and hide the *Sessions* tab in the settings.

Xora	ayaN4000-(	0001 -	Logger	Logger	Logger	3
Sessio	ns Measure	ements Cale	ndar Time rar	nge		
Sele	cted 👻	Comment	FAS/Snap.	Start	Stop	Du
4		08.12	2019			H
4		2		08.12.2019 11:06:20	08.12.2019 11:08:38	00:1
				08.12.2019 11:08:10	08.12.2019 11:08:20	00:0
	V	۲		08.12.2019 10:58:00	08.12.2019 10:58:26	00:1
		()		08.12.2019 10:56:32	08.12.2019 10:57:44	00:1
		(B)		08.12.2019 10:50:02	08.12.2019 10:55:07	00:1
		(B)		08.12.2019 10:47:48	08.12.2019 10:49:02	00:1
4		07.12	2019			
		<b>9</b>		07.12.2019 15:57:59	07.12.2019 16:00:03	00:1
		2		07.12.2019 15:57:08	07.12.2019 15:57:28	00:1

Select the check boxes in the *Selected* column.

or

 Right-click to access the advanced selection options in the context menu.

Select	•	83	All
Deselect	►		None
Erase	•	=	Marked
Refresh		8	Not Archived
Fehlerflags Legende			Till End
View column	•	8	Till Begin





#### Calendar:

File Edit XorayaN400		Logger V	iew Help	Language	ogger	Q.	
essions Mea	surements Cale	ndar Time r	ange			~	Ex
Displayed of	date and Zoom	E I	Selection	with date en	ntry		1
Display Filter G	lueue : default_qu		From			7:07	10
Date 🥑	10.12.2019		Duration	16.		7:07 🗊 • (h) 360:00:00 (i)	File
Display unit	Week	-0		Apply se	lection	Û	
8	19 03.12.2019	04.12.2019	05.12.2019	06.12.2019	07.12.2019	08.12.2019	0.
5				<b>O</b>			

Displayed date and Zoom:

- ► Filter the displayed measurements, for example, by default or streaming queue (a).
- Specify a start date (b).
- Choose between *Week* and *Day* (c) as the displayed time unit.
- Click the single arrows (d) to jump one day or one week forward or backward.
- Click the double arrows (e) to jump three days or three weeks forward or backward.
- Click the graphical representation of a measurement (f) to select it. or
- Click and drag to select all measurements in this time range.

Select with date entry:

- Specify start date and start time (g).
- Specify end date and end time (h). or
- Enter the duration (i).
- ► Click Apply selection (j).



#### Time range:

Xoraya	N4000-00	01 -	ogger Logger	Logger	
essions	Measurem	nents Calendar	Time range		E
Selection	with date e	entry			
From	07.12.	2019 [ 🗐	13:00 1		
				9	Pa
			d)	12:00 15:00	1.1
То	<mark>07.12</mark> .	2019 30	16:00 (e)	12:00 15:00 07.12.2019	FI
To Selected		2019 C	16:00 e	N 10 10 10 10 10 10 10 10 10 10 10 10 10	FI
Selecter	4 <del>v</del>	0.0000000000	Start	07.1 <mark>2</mark> .2019 Stop	Duratior
Selected		0.0000000000		07.12.2019	FI
Selecter [	v v	0.0000000000	Start 07.12.2019 15:57:59	07.12.2019 Stop 07.12.2019 16:00:03	Duratior 00:02:04 00:00:20
ĺ		0.0000000000	Start 07.12.2019 15:57:59 07.12.2019 15:57:08	07.12.2019 Stop 07.12.2019 16:00:03 07.12.2019 15:57:28	Duratior 00:02:04 00:00:20

- Specify start date (a) and start time (b) of the desired time range.
- Specify the end date (c). Use the arrows (d) optionally to apply the start date or to jump one day forward or backward.
- Specify the end time (e).
- Click *Apply* (f).
- ► Limit the time range further by clicking and dragging inside the graphical representation (g).



#### History

The time ranges defined since starting the tool can be selected again via the *History* button (h).



Settings:

- ► Specify the *Export settings*. (→ Export settings)
- ▶ Specify the *Output formats*. (→ Output formats selection)



#### Load settings from N4000+

If you have previously used the *Export* category to save client settings on the N4000+, then you can load these via this button. ( $\rightarrow$  Export)

J.

Additionally, you are asked if you want to apply the settings when connecting to the N4000+.

Download log data:

Click Start download (3).

or

▶ In the *Download* menu, click *Start*.

 $\blacksquare$  The selected sessions or measurements are transmitted to the PC.

the	GM Divertal Logge Wes Hep Larguage		States and second	
Xer	🚵 🖮 💑 🏷	行	10 00	
3	Stop download from logger	7	Show download statistics	
6	Open last used path in Windows Explorer			



#### **Statistical data**

Click the arrow behind *Show download statistics* (7) to switch between different statistics.

The symbol displays the current value during download and the average as the process completes.

Click *Show download statistics* (7) to show statistical data graphically. ( $\rightarrow$  Graph View)

Cancel download:

► Click Stop download from logger (3).

or

▶ In the *Download* menu, click *Cancel*.



# 5.9 Viewer

This tool allows display and analysis of records. No N4000+ connection is necessary to do this.

► Start the *Viewer* tool of the XORAYASuite. (→ Starting)

rie Hele Lengosje	Latto / feed a reasonage # (5 0 10 All A 8 0 8 Mine (5 0) Catto in Societanet 0 0 10 King (5 0) 0 0 0 King (5 0) 0
Control Millionations 20121	
He Zalal Seath Soc Spale Commen	Overree Datafac Mee

The subsequent view is divided into four panels, which can be resized at will:

- Data (1)
- Information (2)
- Search, filter and export (3)
- Graphical output (4)



#### 5.9.1 Data

This panel displays the record set of the opened measurement.

File	Help La	nguage						
	· ·		¥=					
Measu	rement 1.dl	2 7 Measurement	2.dli	9				
Icon	Row No.	Raw No.	Туре	Alias	1	Device	Timestamp	Time
	75	75	Button_1	trigger	button	0	14:46:38 7489941	00:00:
۲	76	76	Event_1	event1		0	14:46:38 7499766	00:00:
	77	77	Button_1	trigger	button	0	14:46:38 9513163	00:00:
	78	78	System_1	system	1	0	14:46:39 6988063	00:00:
	79	79	System_1	system	1	0	14:46:42 7037970	00:00:
	80	80	System_1	system	1	0	14:46:45 7058587	00:00:
	81	81	System_1	system	1	0	14:46:48 7082643	00:00:
	02	00	Suntan 1	austan	1	0	14-46-61 7110000	00.00.
I 0	pen measu	rement		3	Displ	ay setting	JS	
2 C	loco coloct	d measurement		4	Opened measurements			

#### Open measurement:

- Click Open measurement (1) and select the DLI file.
   or
- In the File menu, click Open and select the DLI file. or
- Drag-and-drop the DLI file from the Windows Explorer into the Data panel.

Display recently opened measurements:

- Click the arrow behind Open measurement (1).
   or
- ▶ In the *File* menu, click *Recent* files.



#### Opened measurements and filter

Each open measurement is represented by a tab (4).

A filter icon in the respective tab identifies a configured interface filter. ( $\rightarrow$  Interface)

To delete the filter, right-click the desired tab and select *Cancel filter*.



Close measurement:

• Click Close selected measurement (2).

or

▶ In the *File* menu, click *Close*.

or

• Right click the desired measurement tab and then on *Close the file*.

Right-click the desired record to view further options in the context menu:

- Set timemaster
- Set custom region
  - by manually selecting the start and stop row
  - automatically a certain time span before and after the selected row
- Add record to bookmarks
- Set time format (with date, 100 nanoseconds or standard)
- Show or hide columns
- Draw record signal in the *Graphic* tab of the *Graphical output* panel
   (→ Graphic)



#### Timemaster

An additional column *Timediff.* is displayed when you set the timemaster on a particular record. This column contains the time difference of each record to the Timemaster.



#### **Custom region**

Use a custom region to restrict your export scope. To do so, select the appropriate option in the source region selection. ( $\rightarrow$  Export)

In addition, the start and stop rows will be automatically added to the bookmarks.



#### Bookmarks

Adding records to the bookmarks allows jumping to a favourite record position immediately. ( $\rightarrow$  Browse)

# **USER MANUAL**



XORAYASUITE



On the right edge of the panel, there are two scroll bars that can be adjusted independently.

Left-click (1) to specify whether scrolling is by row numbers or time.

Right-click (1) to specify how many rows or how much time is scrolled per click on the double-arrow buttons (2).

Left-click the single-arrow buttons (3) to move only one row at a time.



#### Fine zone

If a Fine zone is specified in the *Overview* tab of the *Graphical output*, the left scroll bar refers to this zone. (→ Overview)



## 5.9.2 Information

This panel displays information about active measurement and search results.

Tabs:

- Info
- Detail
- Search
- Trace
- Signals
- Comment

#### Info:

This tab displays general information about all records for the open measurement.

G	eneral informations				
1	2				
۵	1 - General				
	DLF file 0	C:\Users'	User	\AppData\Local\Temp\Measurement1_0000.dlf	
	DLI file	C:\Users'	Useri	\AppData\Local\Temp\Measurement1.dli	Ξ
	DLM file	C:\Users'	Useri	\AppData\Local\Temp\Measurement1.dlm	
۵	2 - Messung				
	Begin	01.12.20	19 14	I:46:29 1906127 GMT +01:00	
	End	01.12.20	19 14	1:49:36 8895851 GMT +01:00	
	Messages	138			
	Size	0,19 MiB			
۵	3 - Device				
	Comment				
	Firmeware	4.0a.001	5		
	Name	XorayaN4	4000-0	001	
	SerialNo	0200_07	00_01	00_00001	
۵	4 - Interfaces				
	Button 1 (triager button)	2			
1	Sort by categories		2	Sort alphabetically across categories	



#### Detail:

This tab displays detailed information about the currently selected record. The display changes depending on the interface type.

Detail	#0 Syste	em_2 18.12.2019 09:59:40 6164661 GMT +01:00	
E	1 Data	SYS_INFO Version 2 1 of 1 Application GXHddGet SKD_Version 2.5.0.16 SDK_BuildDate "Nov 18 2019" "00:41:51" RawMsgProcessing 1.0	*
•	Flags		
ystem	Raw Length	129 Global Flags 0x0	
	Timestamp	0x3803A2A657F6B5 Interface 0x2000211	
9	2 Raw Data	0000         53         59         53         5F         49         4E         46         4F         SYS_INFO           0008         0A         56         65         72         73         69         6F         6E         .Version	•
		0016 20 32 0A 31 20 6F 66 20 2.1 of 0024 31 0A 41 70 70 6C 69 63 1.Applic	
		0032 61 74 69 6F 6E 20 47 58 ation GX 0040 48 64 64 47 65 74 0A 53 HddGet.S	-
1 Da	ta	3 Data values	
2 Rav	w data	4 Raw data values	

Right-click anywhere on the white or green background part of the user interface to select whether the underlying raw data (2) is also displayed alongside the data (1).

Right-click anywhere on the data values (3) or raw data values (4) to change the display between:

- Hexadecimal (base 16)
- Decimal (base 10)
- Octal (base 8)
- Binary (base 2)
- ASCII
- Automatically selected display



#### Search:

This tab displays records found by search processes using the button *All since cursor*.

The button All since cursor can be found in the following panels and tabs:

- Information panel, Signals tab
- Search, filter and export panel, Browse tab
- Search, filter and export panel, Find tab

Se	Search results : (msg.type — Button) 🚺									
		*	k							
Ту	pe Nr		Timestamp	Title						
<i>i</i>	75		01.10.2019 14:46:38	72 69 73 65	00					
de la	77		01.10.2019 14:46:38	66 61 6C 6C	00					
	12	h	0							
FO	und 2 r	esuits	0							
1	Searc	h cor	ondition			Go to next search result				
2	Go to	sele	ected search result			Delete selected search result				
3	Go to	prev	vious search result			Number of search results				

#### Trace:


This tab displays status and error messages.



### Signals:

Use this tab to search for specific signals in the records of the opened measurement. The right-side view is different depending on whether *Show* signal details (13) or Manage signal lists (12) is activated.





Add signals to signals overview (14):

- ► Click Signal description settings (1).
- Add one or more description files to the current signal group.
   (→ Signal description settings)

Sort the signals overview (14):

- Click Sort alphabetically (2) to sort by message name.
   or
- Click *Sort by ID* (3) to sort by message ID.

Search by message, signal or ID in the signals overview (14):

- Enter the term or partial term in the search box (5).
- Click Find previous (4).
   or
- Click Find next (6).



Display signal details (15):

Select a message in the signals overview (14) to view details for all signals of this message.

or

• Select a signal to view details for this signal.

Display signals graphically:

Select a signal in the signal details (15).

or

- Select multiple signals by using the Shift key or the Ctrl key.
- ► Click Draw selected signals (7) to display the graphical representation in the Graphic tab. (→ Graphic)

Search message in open log data:

- ▶ In the signals overview (14), select the message to be searched for.
- Click Previous (8) to move to the previous record of this message. or
- Click *Next* (9) to move to the next record of this message.

or

► Click All since cursor (10) to display all records of this message, starting at the current position, in a list. (→ Search)

Cancel search:

Click Cancel (11).





#### Manage signal lists (12) is activated:

Sig	nals overview		* 3	F M 🛛 🏢 🗖		
	Can1 (Device 0) 	0 0 0 0 0		gnal list2	Framename Message1 Message2	
		200	1	m		
12	Manage signal lists		17	Add signal to list		
14	Signals overview		18	Delete signal from	list	
15	Signal lists		19	Find signal		
16	Add new signal list		20	Draw signal		

Create new signal list:

► Click Add new signal list (16).

Add signal to signal list:

- Select the signal list (15).
- Select the signal in the signals overview (14).
- Click Add signal to list (17).

Delete signal from signal list:

- Select the signal in the signal list (15).
- ► Click Delete signal from list (18).

Delete signal list:

- Select the signal list (15).
- Click Delete signal from list (18).

Display signal from signal list (15) in the signals overview (14):

- Select the signal in the signal list (15).
- ► Click Find signal (19).



#### 5.9.3 Search, filter and export

Use this panel to search the open measurement according to different criteria, filter records and export them to other output formats.

Tabs:

- Browse
- Event
- Find
- Interface
- Export

#### Browse:

Use this tab to specify search criteria to move to the corresponding records in the *Data* panel. In addition, you can manage the bookmarks list.

#	to / find a message 1 2 3 4 5 # msg 6 7 9 9 10 0 0 0 22 1 2 2 3 4 5 # msg 6 7 9 10 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
1	Previous	11	Search message by payload
2	Next	12	Search message by Interface, ID
3	All since cursor		and payload
4	Paste current selection value	13	Go to message
5	Cancel	14	History
6	Search criterion	15	Go to selected bookmark
7	Search message by number	16	Go to previous bookmark
8	Search message by date and time	17	Go to next bookmark
9	Search message by interface	18	Delete selected bookmark
10	Search message by ID		



Depending on the search criteria, the search condition is either unique or not.

You will find one record at the most when searching by:

- Message number (7)
- Date and time (8)

In certain circumstances, you may find multiple records in the search for:

- Messages of certain interfaces (9)
- Message IDs (10)
- Message payloads (11)
- Combination of the previous three (12)

To go to the (next) record that meets the desired search condition:

Select search criteria from the tabs (7) to (12).

or

- Select the corresponding criterion from the drop-down list (6).
- Specify the search condition.

or

- Click Paste current selection value (4) to apply the value of the currently selected record.
- ► Click Go to message (13).

Navigate between records:

- Click *Previous* (1) to go to the previous record found.
   or
- Click *Next* (2) to go to the next record found.

or

► Click All since cursor (3) to display all records of this message, starting at the current position, in a list. (→ Search)

Cancel search:

Click Cancel (5).





#### History

Click *History* (14) to access the latest search conditions. This list is reset every time you exit the tool.



#### Bookmarks

To add a record to the bookmarks, right-click it in the *Data* panel and select the appropriate option.

Use the *Browse* tab to navigate between bookmarks or to delete them.

#### Event

This tab displays all events generated by the user or by the N4000+ itself. For example, events are triggered and stored by pressing the trigger button **(K)**. ( $\rightarrow$  Connections and controls)

Ev	ent o	vervie	w Max			
1y	pe N	<b>9</b> -	4 imestamp	Title		
•	76		01 10 2019 14 46 38	Trigger (Rise)		
1	Go t	o sele	ected event		3	Go to next event
2	Go t	o pre	vious event		4	Delete selected event





### Search:

Fi	nd						
÷ ÷	- Analog - Debug - System - Ethemet - Event - Event - FlexRay	4 M M	Relatio	er Rise er_Fall Add constraint			2- - - - -
(e	vent.event == Trigger_Rise) 5	)					
•		vious		8	Cancel		9
<u>a</u> n	All since cursor 7					0%	
1	Field		6	Next			
			_				
2	Relation		7	All since c	ursor		
	Relation Value		8	All since co Previous	ursor		
2			-		ursor		

User this tab to build complex searches.

- Select the *Field* (1) that you would like to add to your search.
- Select the *Relation* (2) between field and value.
- ► Specify the *Value* (3). Depending on the field, this is either presented as a text box or as a drop-down list with all available values.
- Click Add constraint (4).
  - $\square$  The condition is added to the *Constraint expression* (5).
- Repeat the above steps to add further constraints to the constraint expression.



Navigate between records:

• Click *Previous* (8) to go to the previous record found.

or

• Click *Next* (6) to go to the next record found.

or

► Click All since cursor (7) to display all records of this message, starting at the current position, in a list. (→ Search)

Cancel search:

Click Cancel (9).

#### Interface:

Use this tab to filter the displayed records in the Data panel.

In	terface selection				
X	🕘 WholeFile 💦 🕻 🥵	Linner			
R	All interfaces	9			
6	Can				
	RexRay				
	MOST25				
	Ethemet				• E
	Event				
1	Start		5	Select FlexRay IDs	
2	Cancel		6	Interfaces	
3	Filter region		7	Interface channels	
4	Select CAN IDs				

Filter options:

- Filter region (3)
  - WholeFile All records
  - FineZone Zone specified in the Overview tab of the Graphical output panel (→ Overview)
  - ScreenWide Records that are currently visible on the screen
- CAN IDs (4) and FlexRay IDs (5)
- Interfaces (6) and interface channels (7)

# **USER MANUAL**



XORAYASUITE

Apply filter:

- ► Add the desired filter.
- Click Start (1).

 $\square$  Records in the *Data* panel are filtered.

Cancel filter:

Click Cancel (2).

#### Export:

Use this tab to export the records to various output formats.

Ex	port settin	gs	0						
4	0								
Pat	th	%OriginalP	athName%						• (1112)
File	ename	%OriginalF	ileName%						
	Overwrite fi	les							
Ou	tput forma	ts selectio	n 2				Q-		- 🛛 🗡
V	X2E-Nativ	e 🔹		1	2	FileNameF	refix%		- 🛛
		5.50		*	2	FileNameF	refix%		- 🛛
So	ource regio	n selectior	• 3	<u></u>					
	whole n	neasurement	Ę						
	Fine zor	ne							
	Custom	region							
	Selection	n							
	Pre-/po	st-triggers (se	ec.)						
		01.10.201	9 14:46:38	Trigger (Rise	)	60	60		
1	Export s	ettings			3	Source	e region se	lection	
2	Output	formats s	election		4	Start			



Source region selection:

•	Whole measurements	All records
•	Fine zone	Zone specified in the <i>Overview</i> tab of the <i>Graphical output</i> panel (+ Overview)
•	Custom region	Region specified in the <i>Data</i> panel ( $\rightarrow$ Data)

- Selection
   Selected records
- Pre-/post-triggers (sec.) Period before and after raised triggers



#### Pre-/post-triggers

If this option is selected, you can double-click to change the time period before and after a trigger is raised.

Default values are configured in the *Hdd-Download* tool settings. ( $\rightarrow$  Hdd-Download)

Export records:

- ► Specify the export settings (1). (→ Export settings)
- ► Select the output formats (2). (→ Output formats selection)
- Select the source region (3).
- Click Start (4).

 $\blacksquare$  Selected records are exported.

Ex	port settings
	<b>3</b>
5	Cancel

Cancel export:

Click Cancel (5).





# 5.9.4 Graphical output

This panel displays the open measurement graphically.

Tabs:

- Overview
- Graphic
- Video

#### **Overview:**

This tab displays the timeline of the opened measurement. Icons represent events, bookmarks and search results. You can also specify a Fine zone to filter the records to display and export.

01.10.2019 14:46:29 1906127	٠		4	
01.10.2019 14:47:06 7296127				
01.10.2019 14:47:44 2696127				
01.10.2019 14:48:21 8096127				
01.10.2019 14:48:59 3496127				
		- fi		1

Set Fine zone:

- Click and drag over the area of the desired Fine zone.
- ► Confirm your choice by clicking <Set Fine Zone>.

 $\blacksquare$  The Fine zone is set.



# Graphic:

This tab shows selected values of the open measurement as time curves.

Display data graphically:

- ► In the *Data* panel, right-click a record of the interface channel that you would like to see in graphical format. (→ Data)
- ▶ Point to *Draw signal*.
- Select the desired value.

 $\square$  The time curve of the value is displayed graphically. ( $\rightarrow$  Graph View)

• Repeat the above steps to add further values to the chart.



# Draw message signals

Choose individual message signals in the *Signals* tab of the *Information* panel. ( $\rightarrow$  Signals)



# 5.10 Statistic

This tool allows the evaluation of statistical data during N4000+ operation, also simultaneous to data recording.

- Connect the N4000+ to the PC. ( $\rightarrow$  Connecting the N4000+ to the PC)
- ► Turn on the N4000+.
- ► Start the *Statistic* tool of the XORAYASuite. (→ Starting)
- Connect to the desired N4000+. ( $\rightarrow$  Connecting the N4000+)

				/	3				
Load Queue Usage	Offline	logging on l	68	.208 Byte		0 < %)	Absolute stat		evice
face	Messages/s	kBit/s	Messages	Bytes	Errors	Overflows	Busload	Watch	Device
_1 (can1)	81	10	1.854	29.664	0	0	2,1%		0
_2 (can2)	3.405	435	22.767	364.272	0	0	87,2%	1	0
_3 (can3)	3.382	432	23.020	368.320	0	0	86,6%		0
Release	e connection to logger				Minim	nise view			-
Freeze	statistic				Monit	or interfa	ıce		
	Queue Usage face 1 (can1) 2 (can2) 3 (can3) Release	Queue Usage         Messages/s           face         Messages/s           1 (can1)         81           2 (can2)         3.405           3 (can3)         3.382	Queue UsageMessages/skBit/sfaceMessages/skBit/s1 (can1)81102 (can2)3.4054353 (can3)3.382432Release connection to logger	Queue         501           Usage         117           fface         Messages/s         kBit/s         Messages           _1 (can1)         81         10         1.854           _2 (can2)         3.405         435         22.767           _3 (can3)         3.382         432         23.020	Queue Usage         501.208 Byte 117.169 MByt           fface         Messages/s         kBit/s         Messages         Bytes           1 (can1)         81         10         1.854         29.664           2 (can2)         3.405         435         22.767         364.272           3 (can3)         3.382         432         23.020         368.320           Release connection to logger         4	Queue Usage         501.208 Byte (0,37%) 117.169 MByte (99.26           face         Messages/s         kBit/s         Messages         Bytes         Errors           1 (can1)         81         10         1.854         29.664         0           2 (can2)         3.405         435         22.767         364.272         0           3 (can3)         3.382         432         23.020         368.320         0           Release connection to logger         4         Minim	Queue Usage         501.208 Byte (0,37%) 117.169 MByte (99,26%)           fface         Messages/s         kBit/s         Messages         Bytes         Errors         Overflows           1 (can1)         81         10         1.854         29.664         0         0           2 (can2)         3.405         435         22.767         364.272         0         0           3 (can3)         3.382         432         23.020         368.320         0         0	Queue Usage         501.208 Byte (0,37%) 117.169 MByte (99,26%)           face         Messages/s         kBit/s         Messages         Bytes         Errors         Overflows         Busload           1 (can1)         81         10         1.854         29.664         0         0         2,1%           2 (can2)         3.405         435         22.767         364.272         0         0         87.2%           3 (can3)         3.382         432         23.020         368.320         0         0         86.6%	Queue Usage         501.208 Byte (0,37%) 117.169 MByte (99,26%)         501.208 Byte (0,37%) 117.169 MByte (99,26%)           face         Messages/s         kBit/s         Messages         Bytes         Errors         Overflows         Busload         Watch           1 (can1)         81         10         1.854         29.664         0         0         2,1%         Image: Constraint of the second

Monitor a specific interface individually:

- ▶ In the corresponding row, click the check box *Watch* (5).
  - $\square$  The row is highlighted when messages are received.
  - $\square$  The buttons in the toolbar change to reflect the current state of the statistic display:

# USER MANUAL

# XORAYASUITE



	Freeze statistic
	Continue statistic
2	Display remote statistic counter Statistic since the start of the tool and connection to the N4000+
	Display local statistic counter Statistic since last click on <i>Reset local statistic counter</i> (3)



## 5.11 Convert

This tool allows converting the log data recorded in the *X2E-Native* output format into various formats. ( $\rightarrow$  Output formats)

No N4000+ connection is necessary to do this.

► Start the *Convert* tool of the XORAYASuite. (→ Starting)

Fi	le Edit C	onvert	Help	Languag	e				
III F			G	Stop	Messages	Logger	name		
	🗶 General 📡	Filter	🖌 Res	ults			,		
	Export settin	gs		7					
	Path	%Origin	alPathNa	me%					<b>•</b>
	Filename	%Origin	al File Nan	ne%					
	Store files i	n separate	e files						
	Overwrite f	iles							
	Output forma	its selec	tion	8			<u>a</u> -		- <b> ×</b>
	Start cor	nvert	9					Time left	
1	Add DLI file	e to list	:			6	Open sel	ection in View	ver
2	2 Remove selected DLI files from list			7	Export se	ettings			
3	3 Move selection up			8	Output f	ormats selecti	on		
4	Move selec					9	Start con	vert	
5	Auto sort b	oy start	time						

Add log files to the list:

- ► Click Add DLI file to list (1).
- Select the desired DLI file.
- Repeat as necessary for further log files.



Manually sort log files in the list:

- Select a row in the list.
- Click Move selection up (3).

or

Click Move selection down (4).



### Automatic sorting

Start and stop times of log files are displayed in red colour if shown out of chronological order in the list.

Click *Auto sort by start time* (5) to sort the log files in chronological order.

View log files in the *Viewer* tool:

- Select one or multiple rows in the list by using the Shift and Ctrl key.
- Click Open selection in Viewer (6).

Select or deselect log files in the list:

Select the relevant check boxes.

or

Select or clear the check box in the table header to select all log files or none.

or

▶ In the Edit menu, click Select all or Select none.

Delete log files from the list:

- ► Select the log files to be deleted.
- Click Remove selected DLI files from list (2).



### Filter messages

If necessary, you can reduce the number of messages to be converted using the *Filter* tab.




Convert log files:

- Select the log files to be converted.
- ► Specify the export settings (7). (→ Export settings)
- ► Select the output formats (8). (→ Output formats selection)
- Click Start convert (9).

or

▶ In the *Convert* menu, click *Start*.

 $\blacksquare$  Recorded log files are converted.



Cancel conversion:

Click Cancel convert (9).

or

▶ In the *Convert* menu, click *Cancel*.



### **Open converted files**

After the successful conversion, click *Open result DLI file* (10) to open the path of the converted files in the Windows Explorer.

If you select the output format *X2E-Native*, you have the choice between opening the DLI files in the Explorer of directly in the *Viewer* tool for analysis purposes.



## 5.12 Firmware-Update

Use this tool to update the N4000+ firmware. The firmware update expands the N4000+ functionality and performs any required bug fixing.

- Connect the N4000+ to the PC. ( $\rightarrow$  Connecting the N4000+ to the PC)
- ► Turn on the N4000+.
- ► Start the *Firmware-Update* tool of the XORAYASuite. (→ Starting)
- Connect to the desired N4000+. ( $\rightarrow$  Connecting the N4000+)

File Logger Option Help Language XorayaN4000-0001  SWU/XSWU file (Logger-HW 1.00)	2	3
Device Info: ESN : 0200_0700_0100_000001 Device: Xoraya N4000 Current Versions: Firmware: 4.0a.0015 FPGA : 6002.0a03 Power : 2.02.0500 Licenses:		Logger 4
1 Release connection to logger	3	Open SWU/XSWU file
2 Start Hdd logging	4	Launch firmware update


Perform firmware update

- ▶ Download the latest firmware version from the X2E-Wiki. (→ X2E-Wiki)
- Click Open SWU/XSWU file (3).

or

- ▶ In the File menu, click Open SWU/XSWU file.
- Select the firmware file.
- ▶ Make sure that the file corresponds to the N4000+.
- Click Launch firmware update (4).
  - $\blacksquare$  The firmware is updated.





### Do not interrupt the update process

Power supply interruptions can destroy the N4000+.

- Do not interrupt the N4000+ power supply while updating the firmware.
- Confirm the N4000+ restart twice, if Ask before restart in the Option menu is activated.
- Confirm the formatting of the N4000+ storage medium that may be necessary for compatibility reasons.
  - ☑ If *Skip restoring the configuration* in the *Option* menu is not activated, the tool tries to restore the last N4000+ configuration.

Fi	ile Logger Option Help Language
x	KorayaN4000-0001 - Cogger RESET
5	Reset software

Repeat the firmware update:

► If the update fails, click button (5) to reset the user interface to the initial state.



### Activate licences

Activating and updating additionally acquired licences for the N4000+ works in the same way. Instead of the firmware file, select the provided licence file.



### Firmware update via USB flash drive

Alternatively, you can also update the N4000+ firmware without the XORAYASuite. Connect a USB flash drive that contains the firmware archive in the *xoraya\_update* folder to the USB host interface (C). ( $\rightarrow$  Connections and controls)

The N4000+ automatically updates the firmware and disconnects the USB flash drive afterwards.



## 5.13 TK Commandline

This tool provides access to the XORAYAToolkit, a collection of commands optimised for script-oriented application.

- Connect the N4000+ to the PC. ( $\rightarrow$  Connecting the N4000+ to the PC)
- ► Turn on the N4000+.
- ► Start the *TK Commandline* tool of the XORAYASuite. (→ Starting)

☑ You can access the XORAYAToolkit via TK Commandline.

Setting env	ironment for using Xoraya-Cmdline tools
XHelp XScan XLogfile XConvFile XJoinFile XFileInfo XCmpFile XHddGet XHddGet XHddErase XHddLog XConfig XSend XStat XShutdown XFWUpdate XBateTime XHddDirM XHddGetM XHddEraseM XHddEraseM XLinuxation XProfile	- Display list of available commands
	ata\Microsoft\Windows\Start Menu\Programs\X2E\Xoraya_x32\Documenta

## USER MANUAL



XORAYASUITE

## The following commands are available:

Tool	Function			
XHelp	Displays the available commands			
XScan	Scans the network for dataloggers			
XLogFile	Starts data recording in online mode and writes log data in various output formats			
XConvFile	Filters X2E-Native log files and converts them into different output formats			
XJoinFile	Joins X2E-Native log files			
XFileInfo	Displays information about X2E-Native log files			
XCmpFile	Compares two X2E-Native log files			
XHddDir	Displays the sessions on the N4000+ storage medium			
XHddGet	Downloads sessions from N4000+ in various output formats			
XHddErase	Deletes sessions from N4000+ or formats the storage medium			
XHddLog	Starts/stops data recording in HDD mode or sets a snapshot			
XConfig	Reads/overwrites the N4000+ configuration or compares two configurations			
XSend	Sends CAN messages via the N4000+			
XStat	Displays N4000+ statistics			
XShutdown	Shuts down or restarts the N4000+			
XFWUpdate	Performs a firmware update			
XDateTime	Converts between different date and time formats or compares PC time with N4000+ time			
XHddDirM	Displays the measurements on the N4000+ storage medium			
XHddGetM	Downloads measurements from the N4000+ in various output formats			
XHddEraseM	Deletes measurements from the N4000+ or formats the storage medium			
XLinuxation	Performs a system recovery of the N4000+			
XProfile	Manages the user profiles of the N4000+			



## 5.14 Common elements

This section describes GUI elements used in different parts of the XORAYASuite albeit in substantially the same way.

This manual makes reference to subsections of this section as required.

### 5.14.1 Changing the numbering system

For numerical values in text boxes, you can switch the display between three numbering systems. Already entered values are converted accordingly if possible.



Click the symbol of the numbering system (1).

or

• Right-click in the text box (2) and select the numbering system.

Abbreviations stand for the following numbering systems:

- 0x hexadecimal (base 16)
- Dec decimal (base 10)
- Bin Binary (base 2)



### 5.14.2 Set bits

In certain interface configuration categories, you specify the bytes of messages:

- CAN Trigger
- LIN Trigger
- Ethernet Filter



- Click an X in the bottom row of a byte (1) once or twice to set the desired bit to 0 or 1.
- ► Highlight an X in the top row of a byte (2) and enter one hexadecimal digit to specify the half-byte.
- ► Highlight XX in the top row of a byte (2) and enter two hexadecimal digits to specify the byte.
- ► If a byte is not fully defined, click the arrow (3) to display all possible values remaining for this byte.



### 5.14.3 Export settings

This control element can be found in the following tools: *Configuration*, *Online-Logging*, *Hdd-Download*, *Viewer* and *Convert*.

Eq	port sett	ings		
Patl	h	C:\Users\User1\AppData\Loc	al\Temp	
Filename %DateTimeStart%-%DateTimeEnd%			End%_%Nam	e% 🖉 🔮
	Overwrite		4	
I	Download from N4000+*			Store sessions in separate files**
2	Attributes		5	Overwrite files
3	Browse	e for folder		

\* Only in Hdd-Download \*\* Only in Hdd-Download and Convert

► Click Browse for folder (3) to select the Path.

(Path is not available in the *Configuration* tool, because the settings are saved on the N4000+ itself.)

• Enter the desired *Filename*.



### Special attributes

You can automatically name the path and filename using special attributes. Select the desired attribute from the respective drop-down list (2).

Repeat the process to combine multiple attributes.

- Specify whether all selected sessions or DLI files are stored as separate files (4).
- Specify whether existing files with the same file name are overwritten (5).



### 5.14.4 Output formats selection

This control element can be found in the following tools: *Configuration*, *Hdd-Download*, *Viewer* and *Convert*.

O	tput formats selection		a 5 5
	X2E-Native	<b>%</b> F	ileNamePrefix%
2		<b>%</b> F	ileNamePrefix%
1	Activate	6	Delete
2	Output format	7	Show log file of export filter
3	Filter settings	8	Export settings
4	Interface filter	9	Save this export setting
5	Attributes	10	Delete this export setting

Create export filters:

- ► Select the desired output format (2). (→ Output formats)
- Check the settings of the selected output format (3).
- Filter the exported interface channels (4).



### Special attributes

You can also separately change the original filename for each export filter by means of special attributes. Select the desired attribute from the respective drop-down list (5).

Repeat the process to combine multiple attributes.

Create further export filters:

- Repeat as necessary for further table rows.
- Select the check boxes (1) for all export filters you want to apply.

Delete export filters:

Click Delete (6).

In case of failure, open the log file of the export filter:

• Select the desired log file from *Show log file of export filter* (7).



Save export setting for later reuse:

- Enter a name in the text box *Export settings* (8).
- Click Save this export setting (9).

Load export setting:

• Select the desired export setting in *Export settings* (8).

Delete export setting:


- Select the desired export setting in *Export settings* (8).
- Click Delete this export setting (10).



### 5.14.5 Signal selection

This control element can be found in the following tools: *Configuration* and *Online-Logging*. The right-side view is different depending on whether *Show signal details* (9) or *Manage signal lists* (8) is activated.

Show signal details (9) is activated:



Add signals to signals overview (10):

- ► Click Signal description settings (1).
- Add one or more description files to the current signal group.
   (→ Signal description settings)

Sort the signals overview (10):

- Click Sort alphabetically (2) to sort by message name.
   or
- Click *Sort by ID* (3) to sort by message ID.

Search by message, signal or ID in the signals overview (10):

- Enter the term or partial term in the search box (5).
- Click Find previous (4).

or

Click Find next (6).



Display signal details (11):

Select a message in the signals overview (10) to view details for all signals of this message.

or

• Select a signal to view details for this signal.

Add signal:

Select the signal in the signal overview (10).

or

- Select the signal in the signal details (11).
- Click Add this signal (7).

Manage signal lists (8) is activated:

	↑       Image: Constraint of the state of	000		gnal list2	Framename Message1 Message2	
	1	Y		III		
8	Manage signal lists		13	Add signal to list		
10	Signals overview		14	Delete signal from	list	
11	Signal lists		15	Find signal		
12	Add new signal list		16	Draw signal		

Create new signal list:

Click Add new signal list (12).

Add signal to signal list:

- Select the signal list (11).
- Select the signal in the signals overview (10).
- Click Add signal to List (13).

Delete signal from signal list:

- Select the signal in the Signal List (11).
- ► Click Delete signal from list (14).

### **USER MANUAL**



XORAYASUITE

Delete signal list:

- Select the signal list (11).
- Click Delete signal from list (14).

Display signal from signal list (11) in the signals overview (10):

- Select the signal in the signal list (11).
- ► Click Find signal (15).



# Storage location for signals, signals overview and signal lists

Added signals are stored on the connected N4000+.

The signals overview and signal lists are stored on your PC, being thus available for the configuration of other dataloggers.



### 5.14.6 Signal description settings

This control element can be found in the following tools: *Configuration*, *Online-Logging* and *Viewer*.

Here, load description files and assign them to signal groups.

Supported description file types:

- DBC
- LDF
- FIBEX (XML)
- A2L
- AUTOSAR (ARXML)

Si	gnal Description s					
	Interface Alias	Description file			Add	Del
)   +	can1 C:\Users\User1\x2e.dbc					
1	Add new signa	al group	6	Interface alias		
2	Clone selected signal group			Description file		
3	Delete selected signal group			Add		
4	Set signal grou	ıp as default	9	Delete		
5	Signal groups					




### 5.14.7 Create trigger conditions

You use this control element to configure general signal triggers or triggers of the VIDEO, DiagCCP, DiagXCP and Event interfaces.

The following trigger types are available:

- Value compare Raise trigger if a single condition or combined conditions are met
- Signal list Raise trigger if the N4000+ detects one of these signals on the data buses

#### Value compare:



The following *Relation types* (11) are available:

- <sup>111</sup> Signal value
- # Number of occurrences of this signal
- Time since the last occurrence of this signal (in ms)



Add condition:

- ► Select an already configured *Signal* (9). (→ Settings)
- Select the *Relation* (10) between signal and value.
- Select the *Relation type* (11).
- ▶ Depending on the relation type, specify the *Raw value* or the time (in ms). (→ Changing the numbering system)

Combine multiple conditions:

- Click Add condition (3).
- Configure this condition as described above.
- Select the *Operator* (12) that combines this and the previous condition.
- ▶ If required, repeat the above steps to combine further conditions.



### **Operator precedence**

According to the rules of Boolean algebra, the AND operator (&&) precedes the OR operator (||). You can influence precedence by parentheses.

Add parentheses:

- Click the desired conditions and operators to mark them blue.
- Click Parenthesise selection (7).

or

Click Move selection to right (5).

Remove parentheses:

- Click the desired conditions and operators to mark them blue.
- Click Move selection to left (6).



### Visualisation of parentheses

The GUI displays conditions of the same precedence level, meaning parenthesised conditions, also on the same horizontal level. The corresponding operator is connected to the left border.

Being further to the right is equivalent to a higher precedence. Therefore, *Parenthesise selection* (7) and *Move selection to right* (5) have the same effect.



Apply conditions:

- Select the *Execution time*.
- ▶ If necessary, change the automatically generated *Description*.
- Only for event triggers:

Under *Arguments*, specify the payload (32 bit) and the ID (8 bit) of the event message to be sent.

Click Apply trigger (1).

 $\square$  The value compare trigger is stored on the N4000+.

Signal	l list:
--------	---------

Trigg	ger type Signal list Description Signal	<ul> <li>▼</li> <li>On Message 1. Signal 2 &amp; I</li> <li>Message 1. Signal 1</li> <li>✓ Message 1. Signal 2</li> <li>✓ Message 2. Signal 3</li> <li>Message 2. Signal 4</li> </ul>	Message2.Signal3
	Arguments	payload	0x 0
		msg_id	<b>Ox</b> 0
1 Ap	ply trigger	2	Cancel trigger configuration

Add signal list trigger:

- Select the check boxes of the desired signals.
- ▶ If required, change the automatically generated *Description*.
- Only for event triggers:

Under *Arguments*, specify the payload (32 bit) and the ID (8 bit) of the event message to be sent.

Click Apply Trigger (1).

 $\square$  The signal list trigger is stored on the N4000+.



### 5.14.8 Graph View

This control can be found in the following tools: *Online-Logging*, *Hdd-Download* and *Viewer*.

70       50         30       10         2       Density of Button 1 (Msgs/s) 5         0       Msgs/s         1       09.10.2019         09.10.2019       09.36:33         4822852       GMT + ©.00         09.10.2019       09:36:33         4822852       GMT + ©.00         09.10.2019       09:36:42         510       8         6       Time pointer area         2       Timeline         3       To the left         8       Blue time pointer*	•	. Q Q Q Q <b>Q (∆</b> ) <b>™</b> • <b>№</b> 1	2	▼ × 🝁 《 ≫ ⊠ 🛃 🐵 <b>①</b> 09.10.2019 09:36:40
70       1475       675       675         30       0       10       10       10         2       10       10       10       10         2       10       10       10       10         1       10       10       10       10       10         1       10       10       10       10       10         1       10       10       10       10       10         1       10       10       10       10       10         1       10       10       10       10       10         1       10       10       10       10       10       10         1       10       10       10       10       10       10       10         1       10			09.028	80082
30       10 <td< td=""><td></td><td>70 14 22</td><td></td><td>6% 6%</td></td<>		70 14 22		6% 6%
1       Toolbar       6       Time pointer area         2       Timeline       7       Red time pointer         3       To the left       8       Blue time pointer*		30		
IToolbar6Time pointer area2Timeline7Red time pointer3To the left8Blue time pointer*		1		2 Msgs/s0 Msgs/s
2Timeline7Red time pointer3To the left8Blue time pointer*		09.10.2019 09:36:33 4822852 GMT +	6.00	09.10.2019 09:36:42 510 34 GMT +01:00 9
3     To the left     8     Blue time pointer*	1	Toolbar	6	Time pointer area
	2	Timeline	7	Red time pointer
	3	To the left	8	Blue time pointer*
	4	To the right	9	Green time pointer
5 Graph name	5		1	

\* Only in Viewer

- Click and drag over an area to zoom in.
- Double-click to jump to the corresponding period in the Data panel of the Viewer tool.
- Click the timeline (2) to display arrows, which allow you to move in small steps to the left (3) and right (4).
- Click the respective graph title (5) to select that graph.
- Left-click in the time pointer area (6) to set the red time pointer (7).
- ▶ Right-click in the time pointer area (6) to set the green time pointer (9).

The blue time pointer (8) represents the currently selected record in the *Data* panel of the *Viewer* tool.



The following table describes the control elements on the toolbar (1) from left to right.


Symbol	Function
( )	Zoom in
Q	Zoom out
2	Adjust the zoom level so that the Fine zone is visible
Q.	Adjust the zoom level so that the entire measurement is visible
5	Switch between previous and current zoom level
$\triangle$	Change the visibility of the blue time pointer, which represents the current position in the <i>Data</i> panel*
$\triangle$	Change the visibility of the red time pointer, which represents the left-clicked position.
$\wedge$	Change the visibility of the green time pointer, which represents the right-clicked position.
$\sim$	Connect the graph points as lines, curves, stairs or do not connect Draw the graph points or not
	Display the time and value of the current mouse position next to the mouse pointer
1	Move the selected graphs up
Ļ	Move the selected graphs down
	Switch colour of background and labelling
×	Close the selected graphs
-	Display graphs over the full height of the window
<b>«</b>	Move to previous time area
>>	Move to next time area
X	Defines the currently visible time area as the Fine zone
	Open Graph View in separate window*
•	Freeze graph drawing**
	iewer ** Only in Online-Logaina

\* Only in Viewer \*\* Only in Online-Logging



# 6 Maintenance

## 6.1 Safety measures







## 6.2 Cleaning

$\triangle$	<b>Device damage due to pollution</b> Avoid any contamination in plugs and sockets to ensure a reliable contact.	
CAUTION	<ul> <li>Keep the N4000+ clean.</li> </ul>	
^	Device damage due to penetration of dust or liquids	
∠!\	Dust or moisture inside the N4000+ may cause abnormal behaviour or destruction of the device.	
CAUTION	Only operate the N4000+ with a closed housing.	
	Do not operate the N4000+ outdoors.	
	Do not operate the N4000+ outside the specified temperature range.	
	Turn off the N4000+ and disconnect it from the power supply before you start cleaning.	

Observe the following instructions to prevent damage to the N4000+:

- ▶ If necessary, clean the N4000+ with a damp, soft, lint-free cloth.
- Make sure that no moisture penetrates into the housing.
- Use only clear water and a mild detergent to moisten the cloth. Avoid sprays, solvents, alcohol or abrasive cleaners.
- Only reconnect the N4000+ to the power supply if the housing appears completely dry.



## 6.3 Repair



### Device damage due to device opening

Unauthorised opening of the N4000+ can lead to abnormal behaviour or destruction of the device.

CAUTION

- ▶ Never open the N4000+.
  - Contact X2E GmbH should maintenance and repairs be required.

Upon malfunction or defect, return the N4000+ without any accessories to X2E GmbH. You can find the address on page 2 of this manual.

Before submission, please take the following measures:

- ► Clean the N4000+. ( $\rightarrow$  Cleaning)
- ▶ Pack the N4000+ safely in its original packaging.
- Include the completed return form. You can download this form from the X2E Wiki or receive via email upon request to xoraya-return@x2e.de.



STORAGE, TRANSPORT AND DISPOSAL

# 7 Storage, transport and disposal

## 7.1 Storage

If the N4000+ will remain unused for an extended time, we recommend storing it in the original packaging.

Adopt the following precautions to avoid damage to the N4000+:

- Protect the N4000+ from intense sun, heat, as well as from severe shocks.
- ▶ Do not place heavy objects on the N4000+.
- Store the N4000+ in a dry, dust-free and ESD safe area.

### 7.2 Transport

Transport the N4000+ only in the original packaging.

## 7.3 Disposal

Please observe local legal requirements should you need to dispose of the N4000+.



Within the European Union, the disposal is regulated by national regulations for electrical devices, which are based on the Directive 2012/19 / EU of the European Parliament and of the Council on electrical and electronic equipment waste.

Therefore, electrical and electronic equipment must not be disposed of with household waste.



The N4000+ requires batteries. Used batteries may not be disposed with household waste because, amongst other, they contain lead, cadmium or mercury.



# 8 Appendix

## 8.1 Technical data

The following table provides an overview of technical data and properties of the N4000+.

Property	Value/Characteristic
Timestamp resolution	100 ns for all interfaces
Storage capacity	256 GB (internal)
	1 TB (external)
Operating temperature range*	-40 to +65 °C
Air humidity range	10 to 95 % (non-condensing)
Supply voltage	12 V DC (temporarily from 6 to 32 V)
Current consumption	<ul> <li>(12 V, standard configuration, everything connected)</li> <li>PCAPs are charged: 7.0 A</li> <li>PCAPs are not charged: 4.5 A (until about 10 s after power on)</li> </ul>
Standby current consumption	Max. 1 mA (at 12 V)
Dimensions (H $\times$ W $\times$ D)	70 x 255 x 207 mm (with impact protection)
Housing protection type	IP 20, NEMA Type 1
Pollution degree	Pollution degree 3
Altitude	Max. 2000 m
Automatic sleep mode	<ul> <li>Wakeable interfaces and signals:</li> <li>CAN</li> <li>FlexRay</li> <li>LIN</li> <li>RS-232</li> <li>Wake input</li> <li>Trigger</li> </ul>
Recording modes	<ul> <li>Over TCP/IP on the PC</li> <li>On internal storage medium or externally on XORAYA ESU</li> <li>Combination of both modes</li> </ul>
Allowed voltage on additional ports	<ul> <li>Digital In: 0 to 24 V DC</li> <li>Analog: 0 to 60 V DC</li> <li>USB Host: 0 to 6 V DC</li> <li>eSATA: 0 V DC</li> </ul>


\* Are the internal temperatures too high, for example due to insufficient air flow, the data logger automatically switches off for safety reasons.



## 8.2 N4000+ pin assignments

The following tables show the pin assignments of the interfaces and of the power/trigger/wake port. Figures show the external view of the N4000+ contacts.

### 8.2.1 6x 1000Base-T1




3x HARTING ix Industrial type A

Pin	Function
1	CH 2 P
2	CH 2 N
3	GND
4	-
5	-
6	CH 1 P
7	CH 1 N
8	GND
9	-
10	-
11	CH 4 P
12	CH 4 N
13	GND
14	-
15	-
16	CH 3 P
17	CH 3 N
18	GND
19	-
20	-
21	CH 6 P
22	CH 6 N
23	GND
24	-
25	-
26	CH 5 P
27	CH 5 N
28	GND
29	-
30	



#### 8.2.2 12x 100Base-T1



3x HARTING ix Industrial type A

Pin	Function
1	CH 2 P
2	CH 2 N
3	GND
4	CH 4 P
5	CH 4 N
6	CH 1 P
7	CH 1 N
8	GND
9	CH 3 P
10	CH 3 N
11	CH 6 P
12	CH 6 N
13	GND
14	CH 8 P
15	CH 8 N
16	CH 5 P
17	CH 5 N
18	GND
19	CH 7 P
20	CH 7 N
21	CH 10 P
22	CH 10 N
23	GND
24	CH 12 P
25	CH 12 N
26	CH 9 P
27	CH 9 N
28	GND
29	CH 11 P
30	CH 11 N




## 8.2.3 2x Digital Out



Pin	Function
1	D 1
2	GND
3	D 2
4	GND


### 8.2.4 10x CAN



Pin	Function
1	CAN 1 High
2	CAN 1 Low
3	CAN 2 High
4	CAN 2 Low
5	CAN 3 High
6	CAN 3 Low
7	CAN 4 High
8	CAN 4 Low
9	CAN 10 High
10	CAN 10 Low
11	CAN 5 High
12	CAN 5 Low
13	CAN 6 High
14	CAN 6 Low
15	CAN 7 High
16	CAN 7 Low
17	CAN 8 High
18	CAN 8 Low
19	CAN 9 High
20	CAN 9 Low




## 8.2.5 24x LIN



Pin	Function
1	LIN 1
2	LIN 2
3	LIN 3
4	LIN 4
5	LIN 5
6	LIN 6
7	LIN 7
8	LIN 8
9	LIN 9
10	LIN 10
11	LIN 11
12	LIN 12
13	LIN 13
14	LIN 14
15	LIN 15
16	LIN 16
17	LIN 17
18	LIN 18
19	LIN 19
20	LIN 20
21	LIN 21
22	LIN 22
23	LIN 23
24	LIN 24
33	VBAT
34	VBAT
35	GND
36	GND




## 8.2.6 4x Digital In



HARTING ix Industrial type B

Pin	Function
1	D 4
2	-
3	D 1
4	-
5	D 2
6	D 3
7	-
8	-
9	GND
10	-


8.2.7 8x RS-232



Pin	Function
1	RX 8
2	TX 8
3	RX 7
4	TX 7
5	RX 6
6	TX 6
7	RX 5
8	TX 5
9	RX 4
10	TX 4
11	GND
12	TX 1
14	RX 1
16	TX 2
18	RX 2
19	RX 3
20	TX 3




## 8.2.8 6x Analog



Pin	Function
1	A 6 N
2	A 5 N
3	A 6 P
4	A 5 P
5	A 4 N
6	-
7	A 4 P
8	A 3 N
9	A 2 N
10	A 3 P
11	A 2 P
12	A 1 N
13	-
14	A 1 P

## 8.2.9 2x FlexRay




Pin	Function
1	-
2	FR BM A
3	GND
4	FR BM B
5	-
6	-
7	FR BP A
8	FR BP B
9	-





## 8.2.10 Power/trigger/wake



Pin	Function
A1	GND
A2	VIN
1	-
2	Wake
3	Trigger/Wake GND
4	Trigger
5	-



## 8.3 Output formats

Die folgende Tabelle zeigt eine Übersicht aller für den N4000+ relevanten Ausgabeformate, die Sie beim Herunterladen und beim Konvertieren von Logdaten wählen können.

Ausgabeformat	Dateiendung	Exportierte Nachrichtentypen
X2E-Nativ	DLI/DLM/DLF/DLS	alle
X2E Ascii	DLASC	alle
Carmen-Journal (V3.0)	JRL	alle
Wireshark PCAP	PCAP	Ethernet
Vector BLF	BLF/DBC	alle
Vector ASC	ASC	alle
XAA für GNLog	ХАА	GNLog, RS-232, Event, System
DLT-Autosar (V4.0)	DLT	DLT, Event, System
System Events	ТХТ	Event, System
Raw für RS232/RawSocket	RAW	RS-232, RawSocket, Event
CSV für Analog/CCP/PSI5	CSV	Analog, DiagCCP, DiagXCP, PSI5
CSV für Signale	SCSV/IFF	CAN- und FlexRay-Signale
Video extrahieren	JPG/MP4/H264	Video, Ethernet
MDF Export (V4.1)	MF4	DiagCCP- und DiagXCP-Signale, Event



### Eigene Ausgabeformate

Mit dem XORAYASDK (Software Development Kit) können Sie eigene Ausgabeformate schreiben und in die XORAYASuite importieren.

Für weitere Informationen und Beispielcode kontaktieren Sie bitte X2E.

In den folgenden Unterkapiteln finden Sie für jedes Ausgabeformat Beschreibungen der jeweiligen Eigenschaften.



### 8.3.1 X2E-Native

Einstellung	Beschreibung	Standard
NewDLIonMaxFileSizeReached	neue Infodatei (DLI) für jede Binärdatei (DLF) anlegen	aus
MaxFileSize_MB ( x )	maximale Dateigröße einer Binärdatei (DLF) in MB	100
WriteStatistics	Statistikdatei (DLS) anlegen	aus
CreateZIP	Logdateien als komprimiertes ZIP- Archiv speichern	aus

### 8.3.2 X2E Ascii

Einstellung	Beschreibung	Standard
ShowTimestamp	Zeitstempel für jede Nachricht ausgeben	ein
ShowCounter	Zähler für jede Nachricht ausgeben	ein
ShowTimestampDelta	Differenz zum Zeitstempel der vorherigen Nachricht ausgeben	aus
ShowDebug	Debug-Informationen ausgeben	aus
ShowSystem	Nachrichten der System-Schnittstelle ausgeben	aus
ShowMediaConfig	komplette Konfiguration der Schnittstellenkanäle ausgeben	ein
ShowFormatDescription	prinzipieller Nachrichtenaufbau jeder Schnittstelle ausgeben	ein
ShowInterfaces	Auflistung der Schnittstellenkanäle mit interner ID, Alias und BUS-ID ausgeben	ein

### 8.3.3 Carmen-Journal

Einstellung	Beschreibung	Standard
Ein Journal schreiben für alle Sessions	alle gewählten Sessions zusammen in einer Datei ausgeben	aus

### 8.3.4 Wireshark PCAP

Einstellung	Beschreibung	Standard
FileFormat( TcpDump )	Zeitstempel mit Mikrosekunden- Auflösung verwenden	ein
FileFormat( NanoSecond )	Zeitstempel mit Nanosekunden- Auflösung verwenden	aus
NewPCAPonMaxFileSizeReached	neue Datei anlegen, wenn maximale Dateigröße erreicht wird	aus
MaxFileSize_MB(x)	maximale Dateigröße in MB	100



### 8.3.5 Vector BLF

Einstellung	Beschreibung	Standard
UseCommonStartTimeStamp	einheitlichen Start-Zeitstempel verwenden	aus
WriteCANmsg4Trigger ( x )	<ul> <li>Trigger als virtuelle CAN-Nachrichten ausgeben:</li> <li>benutzerdefiniert oder</li> <li>automatisch generiert (kompatibel mit CANoe)</li> </ul>	

### 8.3.6 Vector ASC

Einstellung	Beschreibung	Standard
NewASConMaxFileSizeReached	neue Datei anlegen, wenn maximale Dateigröße erreicht wird	aus
MaxFileSize_MB(x)	maximale Dateigröße in MB	100
WriteCarmenBusMapping	Nummer und zugehörigen Alias der Schnittstellenkanäle zur Weiterverarbeitung mit CARMEN ausgeben	aus
UseEcosCompatMode	fallende Flanken von Button-Triggern nicht ausgeben (aus Kompatibilitätsgründen unter Umständen erwünscht)	aus
WriteOneFilePerInterface	eigene Datei für jeden Schnittstellenkanal ausgeben	aus
WriteCANmsg4Trigger ( x )	<ul> <li>Trigger als virtuelle CAN-Nachrichten ausgeben:</li> <li>benutzerdefiniert oder</li> <li>automatisch generiert (kompatibel mit CANoe)</li> </ul>	

## 8.3.7 XAA for GNLog

Einstellung	Beschreibung	Standard
NewXAAonMaxFileSizeReached	neue Datei anlegen, wenn maximale Dateigröße erreicht wird	aus
MaxFileSize_MB(x)	maximale Dateigröße in MB	100

### 8.3.8 DLT-Autosar

Einstellung	Beschreibung	Standard
ConnectionEvents	TCP-Connection-Events ausgeben	aus
NewDLTonMaxFileSizeReached	neue Datei anlegen, wenn maximale Dateigröße erreicht wird	aus
MaxFileSize_MB ( x )	maximale Dateigröße in MB	100



## 8.3.9 System Events

Einstellung	Beschreibung	Standard
Ein Journal schreiben für alle Sessions	alle gewählten Sessions zusammen in einer Datei ausgeben	aus

### 8.3.10 Raw for RS232/RawSocket

Einstellung	Beschreibung	Standard
NewRAWonMaxFileSizeReached	neue Datei anlegen, wenn maximale Dateigröße erreicht wird	aus
MaxFileSize_MB ( x )	maximale Dateigröße in MB	100
Extension ( x )	Dateiendung	raw
TimestampPrefix	Zeitstempel-Präfix für jede Nachricht ausgeben	aus
AllowMarker	Events als Marker ausgeben Voraussetzungen: <i>TimestampPrefix</i> ist <i>ein</i> Event-Nachrichtentyp ist im Schnittstellenfilter aktiviert	aus

## 8.3.11 CSV for Analog/CCP/PSI5

Einstellung	Beschreibung	Standard
WriteTrigger	Trigger ausgeben	aus
WriteButtonFallAsTrigger	fallende Flanken von Button-Triggern ausgeben	aus
WriteButtonRiseAsTrigger	steigende Flanken von Button-Triggern ausgeben	aus
WriteOneFile	alle Nachrichten einer Schnittstelle in einer Datei ausgeben statt getrennt für jeden Kanal	aus



## 8.3.12 CSV for Signale

Einstellung	Beschreibung	Standard
Raster	wenn innerhalb dieser Rasterzeit (in ms) mehrere Nachrichten eines Signals auftreten, wird der letzte Wert verwendet <i>0</i> : Raster deaktiviert	0
AddSignalDefinition ( x )	selbst erstellte Signalliste hinzufügen (→ Signal selection)	
NewSCSVonMaxFileSizeReached	neue Datei anlegen, wenn maximale Dateigröße erreicht wird	aus
IFF-Format	IFF- statt SCSV-Dateiformat verwenden	aus
ExportRawValue	Rohdatenwerte der Signale ausgeben	ein

### 8.3.13 Video Extractor

Einstellung	Beschreibung	Standard
DoJPEG	Bilder im JPEG-Format ausgeben	ein
DoMPEG	Videos im MPEG-2-Format ausgeben	ein
DoH264	Videos im MPEG-4-/H.264-Format ausgeben	aus

### 8.3.14 MDF Export

Einstellung	Beschreibung	Standard
a2l_file_alternative_path ( x )	Alternativ-Pfad für A2L-Datei	
TimezoneOffsets_min ( x )	Zeitverschiebung zur UTC in Minuten:   <zeitzone> <sommerzeit> </sommerzeit></zeitzone>	0 0
NewFileOnMaxFileSizeReached	neue Datei anlegen, wenn maximale Dateigröße erreicht wird	aus
MaxPartFileSizeMegaBytes ( x )	maximale Dateigröße in MB	100
DTBlockSizeMegaBytes ( x )	Größe eines Datenblocks in MB	1
compression	Kompression aktivieren	aus
AddSignalDefinition ( x )	selbst erstellte Signalliste hinzufügen (→ Signal selection)	
AddSignalDefinitionToFiles	für jedes Signal der hinzugefügten Signalliste eine eigene Datei ausgeben	aus

## **Declaration of conformity**

CE

X2E GabH Entwicklungssentrum Große Ahlmühle 19 76865 Rohrbach Tel. +49 6349 99599 100 Fax +49 6349 99599 109

Declares the conformity for the product

#### Product name:

### DATENLOGGER XORAYA N4000+

According to the following requirements:

#### EMC Directive 2014/30/EU

OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 26 February 2014 on the harmonisation of the laws of the Member States relating to electromagnetic compatibility and repealing Directive 2004/108/EC.

The following standards have been applied:

DIN EN 61326-2-1 :2013

DIN EN 55011 :2016 + A1:2017

DIN EN 61000-4-2 :2009

DIN EN 61000-4-3 :2006 + A1:2008 + A2:2010

DIN EN 61000-4-4 :2012

DIN EN 61000-4-6 :2009

IEC 61010-1:2010, IEC 61010-1:2010/AMD1:2016

Signature: / Position in company:

Robrbach, 01.12.2021

Place and date:





X2E GmbH Grosse Ahlmühle 19 76865 Rohrbach GERMANY

Phone E-mail Internet Wiki +49 6349 99599 200 xoraya@x2e.de www.x2e.de wiki.x2e.de