

## 13 CARE AND MAINTENANCE

## A. Symptom: walk belt off centered or slips.







### Centering walk belt process as follow:

- 1. Power off appliance and unplug the power cord.
- 2. Manual centering process as follow:
  - If the walk belt has shifted to left, use the hex tool to turn the left idler roller screw clockwise 1/4 of a turn(refer to figure 1).
  - If the walk belt has shifted to right, use the hex tool to turn the right idler roller screw clockwise 1/4 of turn(refer to figure 2).
- Appliance MUST work 1-2mintutes. Repeat manual centering process untill the walk belt is centered.

#### Belt slip correcting process as follow:

- 1. Power off appliance before operation.
- 2. Using the hex tool, turn both idler roller screws clockwise **1/2** of turn (refer to figure 3).
- 3. After corrected, please attempts to walking 1-2 minutes under 1.0mph speed setting. Repeat until the walk belt is properly tightened.

#### **Attentions**

- 1. To prevent any injury, don't place any debris around appliance before maintenance process.
- 2. MUST use associated hex tool.
- 3. Take care at maintenance process. Do not pinch fingers.

## B. Belt lubrication process, follow instruction below to lubricate belt.



- 1. Power off appliance and unplug cord.
- 2. Using the hex tool, turn both idler roller screws counterclockwise till belt loosen and lifting easily.
  - Tips: please markdown hex tool rotating cycles when loosen belt, which use for adapting belt tension after lubrication process.
- 3. Lifting edges of belt and spraying lubrication oil at center of walk platform evenly. Not necessary to apply spray lubrication oil on entire walk platform.
- 4. Lubrication oil volume Per time of maintenance: 5-10mL. Attention: it would causes of belt slip if spray too much.
- 5. Using the hex tool, turn the both idler screws clockwise as previous markdown number of turns untill walk belt tighten properly.
- Power on appliance and workout for a few minutes, in order to spread lubrication oil to whole belt surface evenly. Lubrication frequency: High recommend 125 Miles Per time.

## C : Appliance cleaning.



- 1. Power off appliance and unplug power cord before cleaning.
- Wipe and clean with damp cloth, Do not cleaning with acidic or caustic detergents.
- 3. Do not clean opposite of walk belt.
- 4. Its normal few black powders residual under appliance after long working.

# 14 WARRANTY

#### MANUFACTURER'S LIMITED WARRANTY

UREVO warrants to the original purchaser that this product is free from defects in material and workmanship when used for the purpose intended, under the conditions that it has been installed and operated in accordance with UREVO Owner's Manual. UREVO's obligation under this warranty applies to the following:

#### COMPONENT LENGTH OF WARRANTY

Structural Frame 1 year For Home Use Only All Other Components 90 days For Home Use Only

## **Exclusions from Warranty Coverage:**

UREVO does not warrant against and is not responsible for, and no implied warranty shall be deemed to cover, any product failure, product malfunction, or damages attributable to:

- Improper installation and/or failure to abide by UREVO's installation guidelines;
- 2. Use of this product beyond normal home use, or in an application for which it was not designed;
- 3. Cosmetic items such as scratches, dents or discolorations:
- 4. Damage caused by normal wear and tear, vandalism, accidental or by animals;
- 5. Any act of Nature (such as fire, flooding, snow, ice,

- hurricanes, earthquakes, lightnings or other natural disasters), environmental condition (such as air pollution, mold, mildew, etc.), or staining from foreign substances (such as dirt, grease, oil, etc.);
- Normal weathering due to exposure to sunlight, weather and atmosphere which can cause colored surfaces to among other things, flake, chalk, accumulate dirt or stains.
- 7. Improper operation, alteration, handling, storage, abuse or neglect of the products.

UREVO, using its sole discretion, will either repair or replace free of charge any part(s) proven to be defective under normal home use. Any repair or replacement shall provide no new warranty coverage, but shall retain only the remaining portion of the original product's warranty. This warranty is offered only to the original purchaser and is not transferable. Proof of original purchase is required.

When ordering replacement parts please have the following information ready:

- 1. Order Number
- 2. Description of Parts
  (Adding photos or videos would be helpful)
- 3. Part Number
- 4. Date of Purchase