

M-500 UHF RFID Evaluation Kit

User Manual v1.1




©2017 RodinBell All Rights Reserved

Catalogue

1. D-10X View.....	3
1-1: Front View	错误！未定义书签。
1-2: Back View.....	错误！未定义书签。
1-3: Plan View.....	错误！未定义书签。
2. Reader Configurations	3
2.1 Initial Use	3
2.1.1 Step 1: Connect The Reader to PC via USB or Serial Port	3
2.1.2 Step 4: Operating Reader via Demo.....	4
2.2 Setting RF Parameter	5
2.2.1 Setting RF Output Power	5
2.2.2 Setting RF Spectrum.....	5
2.3 ISO-18000-6C tag inventory	6
2.3.1 Real Time Mode & Buffer Mode.....	6
2.4 Accessing ISO-18000-6C Tag.....	9
2.4.1 Read tags.....	9
2.4.2 Write Tags	10
2.4.3 Lock Tags.....	10
2.4.4 Kill Tags.....	11
2.4.5 Tag Selection	11
2.4.6 Error Display Might Be Returned	12
3. Develop your own RFID Application	14
4. Installing Driver.....	15

1. M-500 Evaluation Kit View



2. Reader Configurations

2.1 Initial Use

2.1.1 Step 1: Connect The Reader to PC via USB or Serial Port

Method NO.1: You can connect the reader to your PC via USB Cable.

Next, please switch the DIP to the position as illustrated below:



Method NO.2: You can also connect the reader to PC via RS-232 serial port

Next, please switch the DIP to the position as illustrated below:




When the indicator light on and sound of a short beep, reader is ready.

Note: Driver will be installed automatically when reader is connected to PC for the first time. But some computers may fail. In this case, please install driver manually. (please see: Installing Driver at page 21).

2.1.2 Step 4: Operating Reader via Demo

Put the files that named **UHFDemo.exe**, **reader.dll**, **customControl.dll** into a same folder, and double-click **UHFDemo.exe** to run the software.


1. Open the software and it will shows as below:



2. Please select **RS232** as **Connection** if the reader is connected via RS -232 port, or select **USB** as **Connection** if the reader is connected via USB. Choose the corresponding **Serial Port** and **Baudrate**(default baudrate is 115200). As illustrated below:




3. Click **Connect** , if it succeeds, the **Operation History** will display as below:



4. Text communication with the reader:


Click on **Get** in **Firmware Version** or in **Reader Identifier**, the following screen displays:



Now the reader has been connected to PC successfully.


2.2 Setting RF Parameter

After connecting the reader with PC, we need to set some basic RF parameters: RF Output Power & RF Spectrum. Please select **RF Setup** as illustrated below:



2.2.1 Setting RF Output Power

RF Output Power is the strength of RF output signal from antenna port whose unit is dBm.



The output power range is 0 - 26dBm. When this setting completes, it will be saved in the reader automatically even if the power is cut off. The default output power is 26dBm.

2.2.2 Setting RF Spectrum


Set the RF spectrum manually.

- Please defer to Frequency parameter tablet in Communication protocol for more information about

the carrier frequency.

- Frequency range the reader supports: 865MHz-868MHz(ETSI), 902MHz -928MHz(FCC).

You can set the reader in **RF Spectrum Setup->User Define**, as illustrate below:



The image shows the 'RF Spectrum Setup' dialog box. It has two main sections: 'System Default Frequencies' and 'User Defined Frequencies'. In the 'System Default Frequencies' section, there are radio buttons for 'FCC', 'ETSI', and 'CHN'. The 'FCC' radio button is selected. To the right of these are two dropdown menus for 'Freq Range' and 'MHz', with a minus sign between them. In the 'User Defined Frequencies' section, there are input fields for 'Start Frequency' (in KHz), 'Freq Space' (in KHz), and 'Quantity'. There are 'Get' and 'Set' buttons on the right side of the dialog.

Users can set RF spectrum via these three parameters: Start Frequency, Frequency Interval, The number of Frequency points.

2.3 ISO-18000-6C tag inventory

Connect the Reader correctly. Tag operation could be started when RF Setup is completed.


Tag inventory means reader identifying multiple tags'EPC number at the same time. This is the core function of UHF RFID Reader and one of the standards to judge a reader's performance.

2.3.1 Real Time Mode & Buffer Mode

The most commonly used mode for tag inventory is **Real-time Mode**. Data will be uploaded meanwhile you can get the tags'EPC number instantly. **RSSI** and **Parameter of Frequency** are changed and recorded in real time. Due to its dual CPU architecture, performance of multi-tag identification under **Real-time** mode is the best.


The other is **Buffer Mode**, the data will be cached and uploaded together when you need them. Under this mode, the data are without repeat data and can keep in small volume, because the data will be filtered before being uploaded. But it will take some time to filter duplicate data when reader identifies a large number of tags. Therefore, its identification efficiency will be slightly lower than real-time mode. Note: Tags can't be operated when you extract data in the cache.

Users can choose the appropriate method based on actual situation as illustrated below:



Method NO.1: Real-time Mode


1. Click **Tag Inventory (Real Time Mode)**. Select the connected antenna(s) port. Set the number of **Repeat Per Command**, which is the times of repeat inventory command. For example, inventory command will execute anti-collision algorithm one time when you set the value to 1. It will execute anti-collision algorithm two times when you set the value to 2...
2. Click **Inventory**, you will find that the EPC number is uploaded immediately and it is real-time updating. The reader will keep inventory until you click **stop** as shown below:



Inventoried Quantity	Total number of inventory tags since click on Inventory .
Speed	Speed of identification Tag, unit: piece / sec
Total Tag Communication	Total return EPC data of tags (Including repeated data)
Command Duration	Time of each inventory command takes, unit: ms
Total Inventory Duration	Total elapsed time since click on Inventory , unit: ms.
ID	The serial number of data.
EPC	EPC number of tag.
PC	Protocol Control word of tag.
Identification Count	Times of tag identified.
RSSI	The signal strength when tag was identified at the last time.
Carrier Frequency	Carrier frequency of tag which is identified at the last time.


Method NO.2: Buffer Mode

1. Click **Inventory**, the screen will display as below(single tag & multi-tag inventory):



Note: the identified tags won't be shown in the **Tag list**.

2. Click **Stop** first, then click **Get Buffer**. All the data in cache will be uploaded as illustrated below:



Functions description under Buffer Mode:


Get and Clear: Read the data from cache and then clear the cache. It will be empty when you read the cache again.

Query tag Quantity: If you just want to know how many tags are there in cache without details, click on this button.

Clear Buffer: Clear the cache and refresh the screen.


2.4 Accessing ISO-18000-6C Tag

Click **Access Tag**, and the screen will display as following:



2.4.1 Read tags


You can set the parameter(zones to be read, Start Address and Data Length) as illustrated below:




Note: the unit of Starting Address and Data Length is WORD which is 16 bit double-byte.

Click **Read** when the parameter setting is completed.

Picture as below shows that one tag has been identified successfully.




After choosing the tag, please click **Select** and the screen will display as follows:



We could see that the column on the left for **Selected Tag** has been selected. Next, all the operations are based on the tag with this EPC NO.


If you want to cancel the match of EPC, just deselect the column for **Selected Tag**, as below:



2.4.6 Error Display Might Be Returned

Errors occur if wrong operations done:

◆ Inventory success, access failure:




There are two steps to get access to tags: firstly, tag inventory; secondly, access tags. Picture above shows the inventory is successful, failed to access to tags.

Two reasons why:

1. Parameters incorrect: for example, zones(password/ EPC/ TID/ User) to be read do not exist.
2. Tags beyond the area that the RF could cover: distance of accessing to tags is about 60%-70% of tag inventory; in this case, please put the tag closer to the antenna.

◆ Wrong password:



Reason why: wrong password is set.

◆ No tags to be operated:


Operation History: ☒ Auto Clear	☐ Activate Serial Port Monitor
2014-04-10 17:32:52 Lock tag failed, due to There is no tag to be operated	

Reason why: Tags beyond the area that the RF could cover.

For more information about the operation history returned, please defer to the document: **UHF RFID Reader Serial Interface Protocol V3.1**.

3. Develop your own RFID Application

Most functions of the reader can be operated through the demo. But in practical applications, user might need to develop their own applications. Please defer to the document: **UHF RFID Reader Serial Interface Protocol V3.1**. The reader follows the definition both of the RS - 232 and TCP / IP interface. Demo provides an important function of recording serial transmission, so that users can quickly grasp the content of communication protocol in practice. Please defer to the screenshot below and select **Activate Serial Port Monitor**, all uplink and downlink serial data will be recorded, as illustrated below:




Notes:


1. Response speed of Demo will slow down after opening the **Activate Serial Port Monitor**. Please turn off this function when it is not needed.
2. Data in violet blue color is sent to the reader by PC, and data in red color is the returned information from reader to PC.
3. Manual **Input Command** is used to debug serial command, which could calculate the checksum automatically.
4. **UHF RFID Reader Serial Interface Protocol V3.1**, this document includes the integral source codes of the demo (Based on C # of .Net platform) to help users develop applications on the reader. Thank you!

4. Installing Driver

1. Open the D-100 Driver folder.
2. Double click on CDM20828_Setup.exe, the following screen displays:



3. Click on Extract:



After installation is complete, we could connect reader to PC successfully.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The modular can be installed or integrated in mobile or fix devices only. This modular cannot be installed in any portable device, for example, USB dongle like transmitters is forbidden. This modular complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This modular must be installed and operated with a minimum distance of 20 cm between the radiator and user body.

The device is indoor use only.

If the FCC identification number is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module. This exterior label can use wording such as the following: "Contains Transmitter Module FCC ID: 2AKQD-M500 Or Contains FCC ID: 2AKQD-M500"

when the module is installed inside another device, the user manual of this device must contain below warning statements;

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment. The device is indoor use only
The devices must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the product

Any company of the host device which install this modular with limit modular approval should perform the test of radiated emission and spurious emission according to FCC part 15C 15.247 and 15.209 requirement , Only if the test result comply with FCC part 15C 15.247 and 15.209 requirement , then the host can be sold legally.

Device is equipped with unique antennaconnector and non-replaceableantenna.