



## The device zoom function operation instructions

**Note:** This operation is only available for devices that support the zoom function.

1. Click the device play button in the device list to enter the real-time video interface;


2. You can adjust the focal length and magnification speed of the device lens by sliding up and down the zoom axis on the right side of the gimbal or zooming with two fingers in the video area.



11

## 4G Camera working network diagram

Mobile direct connection (as the pictureshows)



12

**Note:**


1.If you cannot find the QR code on the device body, please choose other adding methods according to the device type:

(1).Insert the SIM card or connect the network cable to use the device, please click "Manual Add", enter the device ID to add the device;

(2).For the device used to connect to the router WiFi, please click "Camera scan code to add" or "Camera hots pot add" to add the device according to the interface guidance;

2.If the location where you install the camera cannot be connected to the Internet, please click the "WiFi Connection" button in the upper right corner of the WiFi selection interface, and switch to "Direct Connection" in the pop-up window.

**Note:** The local direct connection needs to be connected to the camera's own WiFi to preview the camera screen normally, it cannot be viewed remotely.



13

Adding method 2: To use with wireless NVR, please first power the wireless NVR and connect it to the Internet. After adding the wireless NVR by scanning the ID QR code on the body of NVR or displayed on the screen with the APP, you can check the battery camera on the APP.

1. When the WNVR (base station, network hard disk recorder and touch screen) is powered on, connect the WLAN network (some models support wireless connection) to the router which is already connected to the Internet;

2. Open the APP and click on the "+" in the upper right corner to enter the scan code interface;

3. Scan the ID QR code on the wireless NVR body or the screen, and add the device according to the simple setting guided by the APP. The camera paired to the wireless NVR will be directly displayed in the device list.




14

## 3.3


### 3.3.1 Battery camera

1.Place on a desk or table, As shown below.



2. Fix the battery camera on the wall or glass


First fix the mounting guide sticker to the wall with 3M glue (smooth surface such as glass) or screws (brick wall, etc.), put the magnetic base of the battery camera on the iron sheet, and adjust the angle.



15

### 2. The pole installation


- (1). Fix the iron plate behind the battery compartment of the dome camera with screws;
- (2). Install the camera on the pole by holding the hoop;
- (3). Solar holder installation;
- (4). The solar panel is installed outdoors, and then connected to the camera;




16

### 3.3.3

(1). Use the mounting sticker to locate and bore holes, and the cement wall must be nailed into the rubber plug;



(3). Adjust the camera's pitch angle to a proper position and tighten the fixing screws;



**Warning** PIR is sensitive to hot and cold disturbances, please note:

- Avoid installing the camera where the air flow is agitated. Foreexample: the air outlet of the air conditioner, the heat dissipation port of the equipment, the side of the fan, the vicinity of the curtain, etc.
- Please do not install the camera in front of the glass or mirror.
- The height of the camera installation should be 2.5M-3M, the best distance of PIR trigger.
- Do not install the camera upside down.

17

## SIM card distribution network description

### SIM card distribution network

1. Open the EseeCloud APP and click Add Device;
2. Scan the QR code of the device body to identify the device type (current, battery machine, different equipment types corresponding to different indicator light position guidance);
3. Insert the SIM card and open the device, check the device indicator status according to the instructions, and click Next;
4. Enter the distribution network, and until the distribution network is successful;
5. The page shows that the device was successfully added to launch the SIM card, modify the device name, and complete the addition.

### SIM card APN distribution network

In the equipment distribution network, the distribution network time overtime or the equipment side broadcast "distribution network failure", the APN distribution network can be selected.

1. Device distribution network fails to enter the "Configuration Network Failure" page, and confirm that the device selects "Use entity SIM card" under using SIM card networking;

2. Enter the Physical SIM Card help page to confirm that the SIM card status is OK, and select APN Settings;
3. Obtain the SIM card APN information by consulting the SIM card instructions or contacting the SIM card channel customer service;
4. Enter the corresponding APN information and click Next;
5. Restart the device (let the device enter the scanning state), restart and click the next step to generate the QR code;
6. Scan the QR code on the screen of the device to enable the device SIM card to obtain the configuration APN information, and the device can scan the code to successfully broadcast the prompt sound. Click Next step;
7. Enter the distribution network, and until the distribution network is successful;
8. Device was added successfully, modify the device name, and complete the addition.

### Exceptional case

During the equipment boot guide process, the indicator light is not flashing or always on after the device is turned on. Click the problem button in the upper right corner of the device boot guide page to view the common problems of the indicator light.

### APN enable shortcut entry

Need to configure APN for the device SIM card, you can choose to enter in the boot FAQ page.

18


## Warning



In case of fire or lightning, pls don't put product in damp and draining place, operate or maintain the device according to the user manual.



Be careful when you see attachment with a Dangerous Voltage which might cause serious electric accident.



## Notice:

1. Ensure your equity, pls read the user manual carefully before you use the product
2. Pls contact professional people if you need install and maintain the product
3. Working Environment: temperature of -20°C~+60°C, relative humidity under 85%
4. Pls don't exceed the user manual's standard range of temperature, humidity and voltage.

## Attention

1.Product failure caused by the following conditions is not covered by the warranty:

- A. Product failure due to accident, negligence, disaster, improper operation or mishandling;
- B. Improper use of the environment or conditions, such as power failure, ambient temperature, lightning strikes, etc., resulting in product failure;
- C. Products that have been repaired by a non-factory authorized maintenance unit;
- D. The products sell more than 12 months.

2. When the user finds that the product appeared faulty, please contact the distributor or local service organization for technical service with the user registration card.

3. When the user has any objection to the technical service provided by the distributor, he can complain to the manufacturer's customer support service center.

4. The warranty card must be valid after being stamped by the warranty unit.



尺寸: 70x125mm  
材质: 128克铜版纸  
风琴折

20

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.