

aiwa

Prodigy View


True Wireless Earphones




WHAT'S INCLUDED



AI1008N Earphones and Charging Case




Silicone Eartips




USB-C Cable

A CLOSER LOOK



Charging Port



Left Earphone
Battery Icon

LED Display Screen

Right Earphone
Battery Icon

Charging Case
Battery Level

Multi-function button
(Touch Control)

LED Indicator



Multi-function button
(Touch Control)

LED Indicator



CHARGING



Charging the Earphones

Place the earphones in the charging case in order to charge.



Charging the Case

Insert the included charging cable's USB-C end into the charging port on the case. Insert the other end into a USB port on a computer or a suitable wall adapter. Leave to charge.



Charging Status


The digits on the LED display screen will flash while the case charges and will display a solid '100%' once the case is fully charged.

The earphone battery icons will flash while the earphones are charging inside the charging case. The right earphone battery icon will flash while the right earphone charges, and the left earphone battery icon will flash while the left earphone charges.

POWERING ON/OFF


When first using your earphones place them into the case. Remove them from the case and they will automatically turn ON. Place them back into the case and they will automatically turn off.

Note: If the earphones are out of the charging case, put them into the case and take out again to turn ON.




BLUETOOTH PAIRING


Remove your earphones from the case and they will power ON and go into pairing mode. When your earphones are in pairing mode, one earphone will flash red and blue and the indicator of other earphone will turn off.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "AIWA Prodigy View."



Both earphone's LED Indicator will turn off once paired to your phone.



After setting up Bluetooth, the earphones will automatically re-connect to the device everytime you take them out of the charging

case.

USING YOUR earphones



LEFT EARPHONE

Previous Track: Double Press
Volume Down: Press
Activating Phone Assistant: Press and Hold for approximately 2 seconds.
Answer Call: Press
Reject Call: Double Press
End Call: Press and Hold for approximately 2 seconds
Low Latency ON/OFF: Triple Press

RIGHT EARPHONE

Play/Pause: Press and Hold for approximately 2 seconds
Next Track: Double Press
Volume Up: Press
Answer Call: Press
Reject Call: Double Press
End Call: Press and Hold for approximately 2 seconds
Low Latency ON/OFF: Triple Press



MONO MODE

While only one earphone is active and paired, it has the following limited functionality:

Decrease Volume: Press
Increase Volume: Double Press
Voice Assistant: Press and hold for 2 seconds

RESET

To reset your earphones and return them to original default factory settings, make sure that Bluetooth on your phone is turned off, and then insert the earphones into the charging case. Remove one earphone from the charging case and press the touch button four times to turn off. Place back into the charging

case and repeat for the second earphone.

SPECIFICATIONS

BLUETOOTH RANGE: Up to 33 feet (10 meters)

CHARGING INPUT: 5V ---1A max

PLAY TIME: 5.5 Hours**

**Applicable at 50% of maximum volume.

Results will be lower when volume is higher.

SAFETY PRECAUTIONS

When using your earphones, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARPHONES AND CHARGING CASE.
2. Do not use the product near water. Do not put on wet surfaces.
3. Only clean using a clean cloth.
4. Do not allow children to play with this product. This product contains small pieces that can be a choking hazard. Parental supervision is advised.
5. Do not expose this product to excessive heat or fire.
6. Do not expose this product to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.
8. Do not drop, crush, or expose this product to excessive physical force.
9. This product is not intended for commercial use.
10. When charging, keep all charging cables well ventilated. Do not keep your charging cable in contact with flammable materials such as bedding, linens or synthetic fabrics.

Maintenance and Care

-Use a soft cloth or paper towel to clean your earphones. Never use any harsh chemicals or detergents for cleaning. Make sure your earphones are dry before charging.

-When your earphones are not in use, they should be stored in a cool, dry place.

-Never tug or yank on a cable while it is connected to your charging case. Connect and disconnect cables as carefully as possible.

-Never expose your earphones to high temperatures, extreme cold.

-Please recycle or dispose of your earphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earphones for further information.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must

accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates, uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If

this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's

authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled

environment. This device and its antenna(s) must not be co-located or conjunction with any

other antenna or transmitter.

WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered By Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call (877) 397-8200 or visit our website at www.aiwa.co.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.



©2024 Sakar International
195 Carter Drive
Edison, NJ 08817
www.sakar.com Support:
(877)-397-8200
support@sakar.com