


Front



WIRELESS SPORT SLEEK EARHOOKS
USER MANUAL

FCC Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.

Federal Communications Commission (FCC) Statement
This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Tested to comply with FCC standard. FOR HOME OR OFFICE USE.

FCC ID:2AML6BB666

Warning :

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

Wireless Earhooks

Thank you for purchasing Everlast® Wireless Earhooks. For the best use of this device we recommend carefully reading this user manual and keeping it for your records.

Package contains

- a. Wireless Earhooks
- b. USB charging cable
- c. User manual
- d. 2 pair extra ear cushions

a.



b.



c.



d.



Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two to three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out.

Do not leave a fully charged battery connected to a charger, overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Never use any charger that is damaged.

Leaving the device in hot or cold places will reduce the capacity and lifetime of the battery. Optimal temperature for the battery is between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.

EVERLAST™, the Ecom device™ and GREATNESS IS WITHIN™ are trade marks of Everlast World's Boxing Headquarters Corporation and used under license by

Manufactured by Tech Support: 212-883-8838
ESI Cases & Accessories Techsupport@Esicellular.com
44 East 32nd Street
New York, NY 10016

All other trademarks are property of their respective companies.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc.






It may damage your hearing if you listen with high volume for a long time. It is recommended you use the lowest volume possible for speaking and listening to music.

All other trademarks are property of their respective companies.

Back

Device Guide



1. Multifunction Button (MFB) Answer, end reject call, Play, Pause, ON/OFF, re-dial the last phone number
2. Previous song/Volume down
3. Next song/Volume up
4. LED Indicator Light
5. Microphone
6. Charging Port

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING YOUR WIRELESS EARHOOKS KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Your Wireless Earhooks has an internal rechargeable battery. Improper usage may result in the Wireless Earhooks becoming hot, ignite or burst and cause injury if exposed to conditions of abuse. Be sure to follow the safety warnings listed below:

1. Do not disassemble, throw away or damage the Wireless Earhooks.
2. Store the Wireless Earhooks in a dry place, keeping it away from damp corrosive materials and environments such as salt air.
3. Keep the Wireless Earhooks away from direct sunlight, fire and high voltage equipment. Do not store the Wireless Earhooks inside a car during hot weather. Remember a closed car acts as a green house allowing the inside temperature to possibly reach over 200F.
4. The Wireless Earhooks is not a toy. Please keep it out of the reach of young children.
5. Please do not discard the Wireless Earhooks. Consult your local waste collection agency for proper disposal or recycling methods. You may also contact "Call2Recycle" at 877-273-2925 or online at "call2recycle.org" for a battery recycling drop off location near you.

Charging the battery

This device has an internal, rechargeable battery.

1. Plug the charger cable into the earhooks.
2. Connect the charger to a USB power source. The red indicator light will display during charging. If charging does not start, disconnect the charger plug it in again, and retry. Charging the battery fully may take up to 1-2 hours.
3. When the battery is fully charged, the red indicator light will turn off. Disconnect the charger from the USB power source and the earhooks. The fully charged battery has power for up to 3 hours of talk-time or up to 120 hours of standby time. However, the talk and standby times may vary when used with different devices, settings, and environments.

2. Instruction

■ Key Function

Power switch	To turn the power on, hold the Multifunction Button for 2 seconds until the LED light flashes blue and red. To turn the power off, hold the Multifunction Button for 2 seconds until LED light flashes blue twice.
Pairing to Device	Power on the wireless earhooks, hold Multifunction Button on control bar 2 seconds, earhooks will enter pairing mode. Activate the Bluetooth® feature on your device, and set the device to search for wireless devices. (See the User Manual for your device) The earhooks will show on your device as EV6944. (If pass code is requested enter 0000) If the pair is successful, the earhook's LED indicator will flash blue every 4 seconds. Once the earhooks has paired with your device, no password will be need to reconnect. If not paired, the earhooks will turn off automatically after 3 minutes.
Receive Hang up phone call	Press Multifunction Button to receive phone call, press again to end phone call, Press twice to re-dial the last phone number, Press and hold for 2 seconds to decline phone call.
Play Pause	In music mode, press once to pause, and again to play, (music will automatically when device receives phone call and will continue once call ends)
Next Song	In music mode, press the + button to play next track
Previous song	In music mode, press the - button press to play previous track
Volume Increase	Press and hold the + button to increase volume
Volume Decrease	Press and hold the - button to decrease volume

LIMITED WARRANTY

ESI Cases and Accessories warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser, will be free from defective workmanship and materials for one year and agrees that it will, at its option, either repair the defect or replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.

This warranty does not apply to any appearance items of the product nor to the additional excluded item(s) set forth below nor to any product the exterior of which has been damaged or defaced which has been subjected to misuse, abnormal service or handling or which has been altered or modified in design or construction. The limited warranty described herein is in addition to an applicable law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW. Some states do not allow limitations on how long an implied warranty last, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of ESI Cases and Accessories.

The warranties described herein shall be the sole and exclusive warranties granted by ESI Cases and Accessories and shall be the sole and exclusive remedy available to the purchaser corrections of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of ESI Cases and Accessories to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liability or otherwise. In no event shall ESI Cases and Accessories be liable or in any way responsible, for any incidental or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

This warranty does not cover cables that have become frayed, cracked, or broken from use. The user should immediately replace this, or any, charge cable that has become frayed, cracked, or broken, as it may constitute a serious safety risk, including electrocution, if it is continued to be used.

Send your device and the product to:

ESI Cases and Accessories,
44 East 32nd Street, 6th floor
New York, New York 10016

*Enclose proof of purchase and \$11.95 for Shipping and Handling.

CONTACT TECHNICAL SUPPORT phone: 212-883-8838 or email: techsupport@esicellular.com

EARBUDS PAIR AS EV6944