


aiwa

Fit One


True Wireless Earphones




WHAT'S INCLUDED



AI1101 Earphones and Charging Case






Eartips



USB-C Cable

A CLOSER LOOK



CHARGING

Charging the Earphones


Place the earphones in the charging case in order to charge. Make sure the charging contacts of the earphones are touching the charging contacts inside the case. Charge your earphones before using.



Charging (Indicator is RED)




Charging Complete (Indicator is OFF)



Charging the Case

Connect one end of the included USB-C cable into the charging port on the case. Plug the other end into a suitable 5V/1A USB charging adapter.

Unplug once each indicator light is white (charging complete).




Charging (Indicator is White & Flashing)




Charging Complete (Indicator is White)

POWERING ON/OFF

When first using your earphones place them into the case. Remove them from the case and they will automatically turn on. Place them back into the case and close the lid and they will automatically turn off.



OR




Press and hold the touch sensor on both earphones for 3 seconds to power on.

Press and hold the touch sensor on both earphones for 5 seconds to power off.

BLUETOOTH PAIRING

Remove your earphones from the case and they will power on and go into pairing mode.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "AIWA Fit One."



Pairing Mode

(Red & Blue Flashing Both Earphones)




L&R Paired to Each Other

(Red & Blue Flashing One Earphone)




L&R Paired to Phone

(OFF Both Earphones)



USING YOUR EARPHONES



LEFT EARPHONE

Decrease Volume: Press
Previous Track: Double Press
Voice Assistant: Press and Hold for 3 Seconds
Answer Call: Press
End Call: Press and Hold for 3 Seconds
Decline Call: Double Press

RIGHT EARPHONE

Increase Volume: Press
Next Track: Double Press
Play/Pause: Press and Hold for 3 Seconds
Answer Call: Press
End Call: Press and Hold for 3 Seconds
Decline Call: Double Press



SPECIFICATIONS

BLUETOOTH VERSION: 5.0

SUPPORTED PROFILES: A2DP,AVRCP,HFP

WORKING DISTANCE: UP TO 10 METERS

MUSIC TIME: UP TO 3 HOURS

TALK TIME: > 2 HOURS

STANDBY TIME: > 20 HOURS

CHARGING VOLTAGE: 5V DC

BATTERY CAPACITY (CHARGING CASE): 350mAH

CHARGE TIME (CHARGING CASE): AROUND 2 HOUR

BATTERY CAPACITY (EARPHONES): 2 X 30 mAH

CHARGE TIME (EARPHONES): ~40 MINS

SAFETY PRECAUTIONS

When using your earphones, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARPHONES AND CHARGING CASE.
2. Do not use the product near water. Do not put on wet surfaces.
3. Only clean using a clean cloth.
4. Do not allow children to play with this product. This product contains small pieces that can be a choking hazard. Parental supervision is advised.
5. Do not expose this product to excessive heat or fire.
6. Do not expose this product to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.
8. Do not drop, crush, or expose this product to excessive physical force.
9. This product is not intended for commercial use.
10. When charging, keep all charging cables well ventilated. Do not keep your charging cable in contact with flammable materials such as bedding, linens or synthetic fabrics.

Maintenance and Care

- Use a soft cloth or paper towel to clean your earphones. Never use any harsh chemicals or detergents for cleaning. Make sure your earphones are dry before charging.
- When your earphones are not in use, they should be stored in a cool, dry place.
- Never tug or yank on a cable while it is connected to your charging case. Connect and disconnect cables as carefully as possible.
- Never expose your earphones to high temperatures, extreme cold.
- Please recycle or dispose of your earphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earphones for further information.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered By Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call (877) 397-8200 or visit our website at www.aiwa.co.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepared.



©2022 Sakar International
195 Carter Drive
Edison, NJ 08817
www.sakar.com
Support: (877)-397-8200
support@sakar.com