
iPod



Features	Description
1 Mode	Displays the current operating mode
2 Song Index	Shows the current song/total songs
3 Repeat/Shuffle	From Repeat/Shuffle, displays the current operating function
4 Play Time	Displays the current play time/total play time
5 Song Info	Displays the artist/title/album info
6 List	Moves to the list screen

Features	Description	
7 Previous File	If button is pressed (less than 0.8 seconds): Moves to the previous file or play the current file from the beginning (Depends on the play time) If play time is less than 3 seconds, moves to previous file If play time is more than 3 seconds, play the current file from the beginning If button is pressed (over than 0.8 seconds) it rewinds the track	
8 Play/Pause	Plays/pauses the current file	
9 Next File	 If button is pressed (less than 0.8 seconds): Moves to the next file. If button is pressed (over than 0.8 seconds): It fast-forwards the track. 	
10 Repeat	Repeats the current file Select the Repeat button to switch between repeating 1 track, and turning repeat off	
11 Shuffle	Plays files in random order When selecting the Shuffle button, it changes to shuffle category → deactivate shuffle then repeat • Shuffle Category: Shuffle song in the current category	
12 Back Button	Move to home/previous mode screen	
13 Menu	Sound Settings: Moves to the Sound Settings.	

Features	Description
14 TUNE	Turn the TUNE knob to search a desired track. If the desired track is displayed, press the TUNE knob to play the track. If you do not anything with the TUNE knob for 5 seconds of searching tracks, the track info for the current track is restored.



Features	Description
1 Category Name	Displays the category name
2 Category List	Displays the contents of selected category If there are many items in the list, items are added in order and the scroll bar on the right is adjusted accordingly.
3 Back Button	Converts to basic mode screen
4 Upper Category	Moves to Upper Category
5 Search Menu	Search songs by the list type.
6 SEEK/TRACK	 If button is pressed (less than 0.8 seconds): Plays previous/next track If button is pressed (over than 0.8 seconds): Moves to play screen, and then it will rewind or fast-forward the track.
7 TUNE	Turn the TUNE knob to search a desired track. If the desired track is displayed, press the TUNE knob to play the track. If you do not anything with the knob for 5 seconds, the TUNE knob search will be terminated.

AUX

Connecting an External Device

If an external device connector is connected with the AUX terminal, then AUX mode will automatically operate. Once the connector is disconnected, the previous mode will be restored.

- AUX mode can be used only when an external audio player has been connected.
- The AUX volume can also be controlled separately through the connected device.





- If only a cable is connected to the AUX without an external device, the mode will be changed to AUX, but noise may occur. When an external device is not being used, remove the connector jack.
- When the external device power is connected to the power jack, playing the external device may output noise. In such cases, disconnect the power connection before use.



* The actual image in the vehicle may differ from the illustration.

Bluetooth® Audio



Features	Description
1 Mode	Displays the current operating mode
2 Phone Name	Displays name of connected phone
3 Artist Info	Name of current artist


Features	Description
- I Galuies	Description
4 Title	Name of current song
5 Previous File	 If play time is less than 3 seconds, moves to the previous file If play time is more than 3 seconds, plays the current file from the beginning This function may differ depending on the model of mobile phone.
6 Play/Pause	Plays/Pauses Bluetooth Audio
Next File	Moves to the next file
8 Repeat	Repeats the current file. This function may differ depending on the model of mobile phone.
9 Shuffle	Plays files in random order. This function may differ depending on the model of mobile phone.
10 Menu	 Connections: Moves to the Bluetooth Settings screen. You can pair a new device or change/ delete paired device(s). Sound Settings: Moves to the Sound Settings.
III SEEK/TRACK	Plays the previous/next file
12 TUNE	● TUNE is not supported

information

- Artist info and Title may not be supported by mobile phone.
- While in use of other functions after connecting your mobile phone through a USB cable, the Bluetooth audio is disabled.

Bluetooth Connection Settings

Settings for pairing, connection and disconnection of a Bluetooth device.



• In Bluetooth Audio play screen, select

Menu and then Connections.

Information

- If the music in the mobile phone is not played after changing to audio streaming mode, press the play button. Thus check if the music is playing in the Bluetooth device after changing to audio streaming mode.
 Audio streaming may not be supported for some mobile phones.
- Please check the Bluetooth compatibility in below website: KIA Motors Corporation http://www.kia.com

part.3 Bluetooth

Before Using the Bluetooth® Handsfree Bluetooth Connection Bluetooth Phone

Bluetooth

Before Using the Bluetooth® Handsfree

What is *Bluetooth*® Wireless Technology?

- Bluetooth® Wireless Technology refers to a short-distance wireless networking technology which uses a 2.45GHz frequency to connect various devices within a certain distance.
- Supported within PCs, external devices, Bluetooth[®] phones, PDAs, various electronic devices, and automotive environments, *Bluetooth*[®] Wireless Technology to be transmitted at high speeds without having to use a connector cable.
- Bluetooth[®] Handsfree refers to a device which allows the user to conveniently make phone calls with Bluetooth[®] mobile phones through the Multimedia system.

 The Bluetooth[®] Handsfree feature may not be supported in some mobile phones.
 For more information on mobile phone compatibility, visit the KIA Motor website
 KIA Motors Corporation: http://www.kia.com

WARNING

- Distracted Driving

- Focus on the road while driving. The driver's primary responsibility is in the safe and legal operation of the vehicle. Drivers should not use any hand held devices or other equipment or vehicle systems that distract the driver during vehicle operation.
- Do not stare at the multimedia screen for long periods of time while driving. Staring at the screen for prolonged periods of time can lead to traffic accidents and can result in personal injuries.

Precautions for Safe Driving

- Bluetooth[®] is a feature that enables drivers to make handsfree calls. Connecting the head unit with a Bluetooth[®] phone allows the user to conveniently make calls, receive calls, and manage the phonebook. Before using Bluetooth[®] Wireless Technology, carefully read the contents of this user's manual.
- Excessive use or operations while driving may lead to negligent driving practices and be the cause of accidents. Do not operate the device excessively while driving.
- Viewing the screen for prolonged periods of time is dangerous and may lead to accidents. When driving, view the screen only for short periods of time.

CAUTIONS upon Connecting Bluetooth® Phone

- Before connecting the head unit with the mobile phone, check to see that the mobile phone supports Bluetooth[®] features.
- Even if the phone supports Bluetooth Wireless Technology, the phone will not be found during device searches if the phone has been set to hidden state or the Bluetooth power is turned off. Disable the hidden state or turn on the Bluetooth power prior to searching/connecting with the head unit.
- If Auto Connection is used, the Bluetooth[®] phone is automatically connected when the ignition is turned on, making it unnecessary to have to connect the phone with the head unit every time.

- If you do not want automatic connection with your Bluetooth[®] device, turn the Bluetooth[®] feature off of the Bluetooth[®] device.
- Park the vehicle when connecting the head unit with the mobile phone.
- Bluetooth[®] connection may become intermittently disconnected in some mobile phones. Follow these steps to try again.
 - 1. Turn the Bluetooth[®] function within the mobile phone OFF/ON and try again.
 - 2. Turn the mobile phone power OFF/ ON and try again.
 - 3. Completely remove the mobile phone battery, reboot, and then again.
 - 4. Reboot the Multimedia System and try again.
 - Delete all paired devices from both of Phone and Head Unit sides and then try again.

- The Handsfree call volume and quality may differ depending on the mobile phone.
- Pairing Bluetooth[®] devices and use of other Bluetooth[®] features are not supported when the vehicle is in motion. For safety, please first park your vehicle.
- If you continue having issue downloading your contacts to your vehicle, contact your mobile phone provider.

Bluetooth Connection

Pairing a New Device

Before you can use the Bluetooth feature, you must first pair/connect your mobile phone to your car.

Up to 5 Bluetooth devices can be paired. Only one Bluetooth device can be connected at a time.

Pairing a New Device by Selecting Phone/Call

Press the key in the steering wheel control. ▶ Pair your car after your mobile phone detects the Bluetooth device. ▶ Enter the passkey or accept the authorization popup. ▶ Connect Bluetooth.

Pairing a New Device Through the Phone Settings

Press the SETUP key. ▶ Select Bluetooth.

▶ Select Bluetooth Connection. ▶ Select Add New. ▶ Pair your car after your mobile phone detects the Bluetooth device. ▶ Enter the passkey or accept the authorization popup. ▶ Connect Bluetooth.



The default passkey is 0000.

The vehicle name above is an example. Check the actual information on the product.

Connecting Bluetooth Devices

Connects the Bluetooth devices that you add.

Connecting Devices by Selecting Phone/Call


Press the key in the steering wheel control. Select the name of the device to connect. Connect Bluetooth.



Connecting Devices Through the Phone Settings

Press the SETUP key. ▶ Select Bluetooth.

▶ Select Bluetooth Connection. ▶ Select the name of the device to connect. ▶ Connect Bluetooth.



Disconnecting Bluetooth Devices

Disconnects Bluetooth devices that are connected.

Press the SETUP key. ▶ Select Bluetooth.
▶ Select Bluetooth Connection. ▶ Select the name of the device to disconnect.



Deleting Bluetooth Devices

Deletes the Bluetooth devices that you added. Note that deleting a Bluetooth device will delete all Call History and Contact Info downloaded along with it.

Press the SETUP key. ➤ Select Bluetooth. ➤ Select Bluetooth Connection. ➤ Select Delete Devices. ➤ Select the device name to delete. ➤ Select Delete.



Bluetooth Phone

Phone Status Icons

Shows the current phone status in the right top of the display.



Icons	Description
₿ ე	You can use Bluetooth phones when a Bluetooth Hands-free connection is established.
*1	You can use Bluetooth audio features when a Bluetooth audio connection is established.
3 1	You can use Bluetooth phones and audio features when both Bluetooth Hands-free and audio connections are established.
® ₹.⊞	Call signal strength indicator
	Battery level of the Bluetooth devices connected
C+	Downloading Call History list
(Downloading Contacts
C:	In a Bluetooth phone call
₽₽	Microphone muted

Information

- The battery level icon and the call signal strength indicator may not be supported in some Bluetooth devices.
- The battery level may differ from the actual level remaining.

Dial

Dials a call after the Bluetooth devices are connected.





Name	Description
1 Keypad	Use the keypad to enter the phone number that you want to call. Press and hold the last number of a speed dial to dial a number that you added to the Speed Dial list in the phone
2 Call	Makes a call after you dial a number and select CALL. If the number is listed in Dialed Calls, you can select the number and press CALL to automatically dial that number again.
3 Settings	Moves to a screen of Bluetooth Connection.
4 Delete	Deletes the numbers that you entered.

Information

• Some types of mobile phones may not support the Speed Dial function.

Accept/Reject Call



If there is an incoming call after you made a Bluetooth connection, a popup message will appear.

Name	Description
Accept	Answers the call.
2 Reject	Ignores the call.

Information

 In some mobile phones, the caller's number may not be displayed, and the Reject feature may not be supported.

Using the Menu During a Phone Call





When making a call, you can use the following menu items.

Name	Description
1 Use Private	Switches a voice call from the car Hands-free to the mobile phone.
2 End	Ends a call.
Contacts	Displays the Contacts list.
4 Outgoing Volume	Displays the Mic Volume settings. You can adjust the in-call volume that the other party hears (level 1 - 5).
5 Keypad	Moves to a screen for entering ARS numbers.
6 Switch	Switches to a call on hold, if any. You can also switch calls by selecting the number in the Information Display. The Switch function switches the current call to a waiting call in order to answer a new incoming call.

Information

- If the caller's number is listed in Contacts, the caller's name will be displayed. Otherwise, only the number will be displayed. In some mobile phones, the phone number may not be displayed.
- In some Bluetooth devices, the Use Private feature may not be supported.
- In some Bluetooth devices, the Switch feature may not be supported.
- During a phone call on a Bluetooth Handsfree, you cannot access other modes, such as Radio and Settings.
- Depending on handset types, the in-call volume the other party hears may differ. If the other party hears your voice too low or too loud, adjust the mic volume.