



MC3300x

Mobile Computer



ZEBRA

Product Reference Guide for Android [™] 9.0 Pie

Copyright

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corporation, registered in many jurisdictions worldwide. Google, Android, Google Play and other marks are trademarks of Google LLC. All other trademarks are the property of their respective owners. ©2019 Zebra Technologies Corporation and/or its affiliates. All rights reserved.

COPYRIGHTS & TRADEMARKS: For complete copyright and trademark information, go to www.zebra.com/copyright.

WARRANTY: For complete warranty information, go to www.zebra.com/warranty.

END USER LICENSE AGREEMENT: For complete EULA information, go to www.zebra.com/eula.

Terms of Use

- **Proprietary Statement**

This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries ("Zebra Technologies"). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

- **Product Improvements**

Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

- **Liability Disclaimer**

Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

- **Limitation of Liability**

In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Revision History

Changes to the original guide are listed below:

Change	Date	Description
-01 Rev A	12/2019	Initial release.

Table of Contents

Copyright	2
Terms of Use	2
Revision History	2
About This Guide	14
Configurations	14
Notational Conventions	16
Service Information	16
Software Versions	16
Getting Started	18
Unpacking	18
MC3300x-G Features	19
MC3300x-R Features	21
Rotating Scan Turret	23
MC3300x-S Features	24
Setting Up the Device	26
Installing a microSD Card	26
Installing the MC3300x-G Battery	28
Installing the MC3300x-R/S Battery	29
Charging the Battery	30
Charging Indicators	32
Backup Power	32
Charging Temperature	32
Charging Spare Batteries	33
Hot Swap Mode	33
Zebra Visibility Services	33
Replacing the Battery in the MC3300x-G	33
Replacing the Battery in the MC3300x-R/S	36
Real-Time Clock Backup	38

Using the Device	39
Home Screen	39
Setting Home Screen Rotation	40
Status Bar	40
Status Icons	41
Notification Icons	42
Managing Notifications	42
Quick Access Panel	43
Editing Icons on Quick Settings	44
Battery Management	44
Monitoring Battery Usage	45
Low Battery Notification	45
Battery Optimization	45
Interactive Sensor Technology	46
Suspend Mode	46
USB Communication	46
Transferring Files	46
Transferring Photos	47
Disconnect from the Host Computer	47
 Settings.....	 48
Accessing Settings	48
Display Settings	48
Setting the Screen Brightness	48
Setting Night Light	48
Setting Screen Rotation	49
Setting Screen Timeout	49
Ambient Display	50
Setting Font Size	50
Setting Display Size	50
Touch Panel Mode	51
General Sound Setting	51
Sound Options	51
Setting Device Advertisement	52
Wake-Up Sources	53
Remapping a Button	53
Remappable Keys	54
UI Listed Keys	54
Other Remappable Keys	54
Non-Remappable Keys	55
Keyboards	55

Table of Contents

Keyboard Configuration	55
Enabling Keyboards	55
Switching Between Keyboards	55
Using the Android and Gboard Keyboards	56
Editing Text	56
Entering Numbers, Symbols, and Special Characters	56
Using the Enterprise Keyboard	56
Numeric Tab	56
Alpha Tab	57
Additional Character Tab	57
Scan Tab	58
Language Usage	58
Changing the Language Setting	58
Adding Words to the Dictionary	58
Notifications	58
Setting App Notifications	58
Viewing Notification Settings for All Apps	59
Controlling Lock Screen Notifications	59
Blink Light	59
Applications	60
Apps	60
Accessing Apps	63
Switching Between Recent Apps	63
Battery Manager	64
Camera	67
Taking Photos	67
Taking a Panoramic Photo	68
Recording Videos	69
Photo Settings	70
Rear Camera	70
Video Settings	70
Rear Camera	70
DataWedge Demonstration	72
Scanner Selection	73
Device Central	74
Scan and Pair Tab	74
Scan and Pair	74
Scan to Pair	75
Manually Pairing	75
Peripherals Tab	75
My Device Tab	75
Unpairing a Peripheral	76

Paging an RS6000 Ring Scanner	76
Diagnostic Tool	77
Settings	80
Battery Test Information	80
GPS Test Information	81
System Test Information	81
WLAN Test Information	81
WWAN Test Information	81
Bluetooth Test Information	81
PTT Express Voice Client	82
PTT Express User Interface	82
PTT Audible Indicators	83
PTT Notification Icons	83
Enabling PTT Communication	83
Selecting a Talk Group	84
PTT Communication	84
Creating a Group Call	84
Responding with a Private Response	84
Disabling PTT Express Voice Client Communication	84
RxLogger	85
RxLogger Configuration	85
Configuration File	85
Enabling Logging	85
Disabling Logging	85
Extracting Log Files	85
RxLogger Utility	86
App View	86
Viewing Logs	86
Backup	87
Archive Data	88
Overlay View	88
Initiating the Main Chat Head	88
Removing the Main Chat Head	88
Viewing Logs	88
Removing a Sub Chat Head Icon	90
Backing Up In Overlay View	90
SimulScan Demo	91
Printing the Sample Forms	92
Using the Postal, Transportation and Logistics Example	93
Using the Manufacturing Example	95
Settings	96
Advanced Settings	97
Creating a Demo Customization	97

Default Templates	99
Sound Recorder	100
Data Capture.....	101
Integrated Imager	101
Operational Modes	101
Laser Scanner	102
RS507/RS507X Hands-Free Imager	102
RS6000 Bluetooth Ring Scanner	102
DS3678 Digital Scanner	102
Scanning Considerations	103
Scanning with Internal Imager	103
Scanning with Laser Scanner	105
Scanning with RS507/RS507X Hands-Free Imager	105
Scanning with RS6000 Bluetooth Ring Scanner	107
Scanning with the DS3608 USB Scanner or DS3678 Bluetooth Scanner	108
Pairing the RS507/RS507X/RS6000 Hands-Free Imager	109
Pairing Using Near Field Communication	109
Pairing in HID Mode Using Near Field Communication	110
Pairing Using Simple Serial Interface	111
Pairing Using Bluetooth Human Interface Device	112
Pairing a Bluetooth Scanner	113
Pairing Using Bluetooth Human Interface Device	113
DataWedge	114
Enabling DataWedge	114
Disabling DataWedge	114
Decoders	114
Wireless	117
Wireless Local Area Networks	117
Accessing Settings	118
Connecting to a Wi-Fi Network	118
Removing a Wi-Fi Network	118
WLAN Configuration	119
Configuring a Secure Wi-Fi Network	119
Manually Adding a Wi-Fi Network	120
Configuring for a Proxy Server	120
Configuring the Device to Use a Static IP Address	121
Wi-Fi Preferences	122
Additional Wi-Fi Settings	122

Wi-Fi Direct	123
WPS Push Button	123
WPS Pin Entry	123
Bluetooth	123
Adaptive Frequency Hopping	124
Security	124
Bluetooth Profiles	125
Bluetooth Power States	125
Bluetooth Radio Power	126
Enabling Bluetooth	126
Disabling Bluetooth	126
Discovering Bluetooth Device(s)	126
Changing the Bluetooth Name	127
Connecting to a Bluetooth Device	127
Selecting Profiles on the Bluetooth Device	127
Unpairing a Bluetooth Device	127
Using a Bluetooth Headset	128
Near Field Communications	128
Reading NFC Cards	128
Sharing Information Using NFC	129
Cast	130
 Accessories	 131
Introduction	131
MC3300x Accessories	131
Compatibility	135
Battery Comparison	136
Battery Compatibility	136
Battery Charging	136
Main Battery Charging	136
Spare Battery Charging	136
Charging Temperature	137
1-Slot USB Charge Cradle	137
Setup	139
Charging the MC3300x Battery	139
Charging an MC3300x Spare Battery	139
Battery Charging in 1- Slot USB Charge Cradle	140
5-Slot Charge Only ShareCradle	140
Setup	141
Charging the MC3300x Battery	142
Battery Charging in the 5-Slot Charge Only ShareCradle	142

5-Slot Ethernet ShareCradle	142
Setup	144
Charging the MC3300x Battery	144
Battery Charging in the 5-Slot Ethernet ShareCradle	144
Daisy-chaining Ethernet ShareCradles	145
Ethernet Settings	145
Configuring Ethernet Proxy Settings	146
Configuring Ethernet Static IP Address	146
Establishing Ethernet Connection	147
LED Indicators	148
5-Slot ShareCradle with 4-Slot Battery Charger	148
Setup	150
Charging the MC3300x Battery	150
Charging Spare Batteries	150
Battery Charging in the 5-Slot ShareCradle with 4-Slot Battery Charger	150
5-Slot Ethernet ShareCradle with 4-Slot Battery Charger	151
Setup	152
Charging the MC3300x Battery	152
Charging Spare Batteries	152
Battery Charging in the 5-Slot Ethernet ShareCradle with 4-Slot Battery Charger	153
Daisy-chaining Ethernet Cradles	153
Ethernet Settings	154
Configuring Ethernet Proxy Settings	154
Configuring Ethernet Static IP Address	155
Establishing Ethernet Connection	156
LED Indicators	156
4-Slot Spare Battery Charger	156
Setup	157
Charging Spare Batteries	157
20-Slot Spare Battery Charger	158
Setup	159
Charging Spare Batteries	159
USB Charge Cable	160
Connecting the USB Charge Cable to Device	161
Connecting the USB Charge Cable to Host Computer	161
Main Battery Charging	162
Charging the Device	162
Main Battery Charging	163
Disconnecting the USB Charge Cable	163
MC3300x Charge Only Adapter	164
Adapter Installation	164
MC3300x-G Rubber Boot	166

MC3300x-R Rubber Boot	167
MC3300x-S Rubber Boot	169
Rigid Holster	169
MC3300x-G Fabric Holster	171
Belt Strap	171
Shoulder Strap	172
Using the Belt Strap	173
Using the Shoulder Strap	175
MC3300x-R/S Fabric Holster	176
Belt Clip	176
Shoulder Strap	177
Using the Belt Clip	178
Using the Shoulder Strap	179
Un-powered Forklift Mount	180
Replacement Hand Strap for MC3300x-G	182
Replacement Hand Strap for MC3300x-R/S	183
Lanyard	185
Install Lanyard on MC3300x	186
Using the Cross-body Strap	187
Using the Belt Clip	188
Charging the MC3300x with the Lanyard	189
Application Deployment.....	190
Security	190
Secure Certificates	190
Installing a Secure Certificate	190
Configuring Credential Storage Settings	191
License Manager	191
Android Versions Supported	191
Requirements	191
Start Application	191
Active License Display	192
Activate License	193
Add License Source	195
Refresh a License	196
Settings	197
Notifications Settings	197
License Sources Settings	198
About Settings	200
Development Tools	201
Android Application Development	201

Table of Contents

Development Workstation	201
Target Device	201
EMDK for Android	201
StageNow	201
ADB USB Setup	202
Enabling USB Debugging	202
Application Installation	203
Installing Applications Using the USB Connection	203
Installing Applications Using the Android Debug Bridge	203
Installing Applications Using a microSD Card	204
Uninstalling an Application	205
Performing a System Update	205
Downloading the System Update Package	205
Using microSD Card	205
Using ADB	206
Verify System Update Installation	207
Performing an Enterprise Reset	207
Downloading the Enterprise Reset Package	207
Using microSD Card	207
Using ADB	208
Performing a Factory Reset	208
Downloading the Factory Reset Package	208
Using microSD Card	209
Using ADB	209
Storage	210
Random Access Memory	210
Internal Storage	211
External Storage	211
Formatting a microSD Card or USB Drive as Portable Storage	211
Formatting a microSD Card as Internal Memory	211
Enterprise Folder	212
App Management	212
Viewing App Details	212
Managing Downloads	213
Maintenance and Troubleshooting	214
Maintaining the Device	214
Battery Safety Guidelines	214
Cleaning Instructions	215
Approved Cleanser Active Ingredients	215
Harmful Ingredients	216

Table of Contents

Device Cleaning Instructions	216
Special Cleaning Notes	216
Cleaning Materials Required	216
Cleaning Frequency	216
Cleaning the Device	217
Housing	217
Display	217
Camera and Exit Window	217
Cleaning Battery Connectors	217
Cleaning Cradle Connectors	217
Troubleshooting	218
Resetting the Device	218
Performing a Soft Reset	218
Performing a Hard Reset	218
MC3300x	218
1-Slot USB Charge Cradle	221
5-Slot Charge Only ShareCradle	222
5-Slot Ethernet ShareCradle	222
5-Slot ShareCradle with 4-Slot Battery Charger	223
5-Slot Ethernet ShareCradle with 4-Slot Battery Charger	224
4-Slot Spare Battery Charger	224
20-Slot Spare Battery Charger	225
USB Charge Cable	226
Technical Specifications	227
Introduction	227
Data Capture Supported Symbolologies	227
SE965 Decode Zone	227
SE4720 Decode Zone	228
SE4770 Decode Zone	228
SE4850-ER Decode Zone	229
1-Slot USB Charge Cradle with Spare Battery Charger Technical Specifications	230
5-Slot Charge Only ShareCradle Technical Specifications	231
5-Slot Ethernet ShareCradle Technical Specifications	232
5-Slot Charge ShareCradle with 4-Slot Battery Charger Technical Specifications	232
5-Slot Ethernet ShareCradle with 4-Slot Battery Charger Technical Specifications	233
4-Slot Spare Battery Charger Technical Specifications	233
20-Slot Spare Battery Charger Technical Specifications	234
USB Charge Cable Technical Specifications	235
Keypads	236

Table of Contents

Introduction	236
MC3300x 29-Key Keypad	236
MC3300x 38-Key Keypad	239
MC3300x 47-Key Keypad	242

Index

About This Guide

Configurations

MC3300x used in this guide refers to all configurations, except where noted. MC3300x-G refers to the Trigger configuration. MC3300x-R refers to the Rotate configuration. MC3300x-S refers to the Straight configuration. MC3300x-S45 refers to the 45 degree angle Straight configuration.

This guide covers the following configurations:

Table 1 *Configurations*

Configuration	Radios	Display	Memory	Data Capture Options	Operating System
MC3300x-G	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 16 GB Flash	SE965 1D SE4720 2D	Android-based AOSP 9.0
MC3300x-G	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 32 GB Flash	SE965 1D SE4770 2D SE4850-ER 2D	Android-based GMS 9.0
MC3300x-R	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 32 GB Flash	SE965 1D	Android-based GMS 9.0

Table 1 Configurations (Continued)

Configuration	Radios	Display	Memory	Data Capture Options	Operating System
MC3300x-R Camera	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 32 GB Flash	SE965 1D Color Camera	Android-based GMS 9.0
MC3300x-S	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 16 GB Flash	SE965 1D SE4720 2D	Android-based AOSP 9.0
MC3300x-S	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 32 GB Flash	SE965 SE4770 2D SE4850-ER 2D	Android-based GMS 9.0
MC3300x-S Camera	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 32 GB Flash	SE965 Color Camera SE4770 2D Color Camera SE4850-ER 2D Color Camera	Android-based GMS 9.0
MC3300x-S45	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 32 GB Flash	SE4770 2D	Android-based GMS 9.0
MC3300x-S45 Camera	WLAN: IEEE® 802.11a/b/g/n/ac WPAN: Bluetooth V5.0, V2.1 + EDR w/ Bluetooth Low Energy (BLE) NFC	4.0" color	4 GB RAM / 32 GB Flash	SE4770 2D Color Camera	Android-based GMS 9.0

Notational Conventions

The following conventions are used in this document:

- **Bold** text is used to highlight the following:
 - Dialog box, window and screen names
 - Drop-down list and list box names
 - Check box and radio button names
 - Icons on a screen
 - Key names on a keypad
 - Button names on a screen.
- Bullets (•) indicate:
 - Action items
 - Lists of alternatives
 - Lists of required steps that are not necessarily sequential.
- Sequential lists (for example, those that describe step-by-step procedures) appear as numbered lists.

Service Information

If you have a problem with your equipment, contact Customer Support for your region. Contact information is available at: www.zebra.com/support.

When contacting support, please have the following information available:

- Serial number of the unit (found on manufacturing label)
- Model number or product name (found on manufacturing label)
- Software type and version number

Customer Support responds to calls by email or telephone within the time limits set forth in support agreements.

If the problem cannot be solved by Customer Support, you may need to return the equipment for servicing and will be given specific directions. We are not responsible for any damages incurred during shipment if the approved shipping container is not used. Shipping the units improperly can possibly void the warranty. Remove the microSD card from the device before shipping for service.

If the device was purchased from a business partner, contact that business partner for support.

Software Versions

To determine the current software versions:

1. Go to **Settings**.
2. Touch **System**.
3. Touch **About phone**.

4. Scroll to view the following information:

- **Model**
- **Android version**
- **Build number.**

To determine the device serial number, touch **About phone > Status**.

- **Serial number**

Getting Started

Unpacking

1. Carefully remove all protective material from the device and save the shipping container for later storage and shipping.
2. Verify that the following are included:
 - Mobile computer
 - Lithium-ion battery
 - Regulatory Guide.
3. Inspect the equipment for damage. If any equipment is missing or damaged, contact the Global Customer Support center immediately.
4. Prior to using the device for the first time, remove the protective shipping film that covers the scan window, display, and camera window.

MC3300x-G Features

Figure 1 MC3300x-G Front View




Table 2 MC3300x-G Features - Front View

Number	Item	Function
1	Display	Displays all information needed to operate the device.
2	Charge /Application Notification LED or Scan/Decode Status	Indicates the battery charge state while charging, an application notification was received, or the scan/decode status.
3	Trigger	Initiates data capture when a scan application is enabled.
4	Battery Release Latch	Release the battery from the device.
5	Hand Strap	Use for securely holding the device.
6	Microphone	Use for communications in Handset mode.

Table 2 MC3300x-G Features - Front View (Continued)

Number	Item	Function
7	Power Button	Press and hold to turn on the device. Press to turn on or off the screen. Press and hold to select one of these options: Power off - Turn off the device. Reboot - Reboot the device when software stops responding. Airplane mode - Disable all wireless connections. Silent mode - All notifications are disabled except for alarms.
8	Keypad	Use to enter data and navigate on screen functions.
9	Scan Button	Initiates data capture when a scan application is enabled.

Figure 2 MC3300x-G Back View




Table 3 MC3300x-G Features - Back View

Number	Item	Function
10	Battery	Provides power for operating the device.
11	Battery Release Latch	Release the battery from the device.

Table 3 MC3300x-G Features - Back View (Continued)

Number	Item	Function
12	Speaker	Provides audio output for video and music playback.
13	Scanner Exit Window	Provides data capture using the scanner.
14	NFC Antenna	Provides communication with other NFC-enabled devices.

MC3300x-R Features

Figure 3 MC3300x-R Front View




Table 4 MC3300x-R Features - Front View

Number	Item	Function
1	Rotating Turret	Rotates for easy scanning positions.
2	Display	Displays all information needed to operate the device.
3	Charge /Application Notification LED or Scan/Decode Status	Indicates the battery charge state while charging, an application notification was received, or the scan/decode status.
4	Side Key Scan Button	Initiates data capture when a scan application is enabled.
5	Battery Release Latch	Release the battery from the device.

Table 4 MC3300x-R Features - Front View (Continued)

Number	Item	Function
6	Power Button	Press and hold to turn on the device. Press to turn on or off the screen. Press and hold to select one of these options: Power off - Turn off the device. Reboot - Reboot the device when software stops responding. Airplane mode - Disable all wireless connections. Silent mode - All notifications are disabled except for alarms.
7	Microphone	Use for communications in Handset mode.
8	Keypad	Use to enter data and navigate on screen functions.
9	Scan Button	Initiates data capture when a scan application is enabled.

Figure 4 MC3300x-R Back View




Table 5 MC3300x-R Features - Back View

Number	Item	Function
10	Battery	Provides power for operating the device.
11	Battery Release Latch	Release the battery from the device.
12	Side Key Scan Button	Initiates data capture when a scan application is enabled.

Table 5 MC3300x-R Features - Back View (Continued)


Number	Item	Function
13	Speaker	Provides audio output for video and music playback.
14	Scanner Exit Window	Provides data capture using the scanner.
15	NFC Antenna	Provides communication with other NFC-enabled devices.
16	Camera/Flash	Provides illumination for the camera.
17	Hand Strap	Use for securely holding the device.

Rotating Scan Turret

The MC3300x-R features a Rotating Turret with three position stops. This feature offers greater scanning flexibility.



CAUTION: Do not try to rotate the turret past the side position stops. Damage to device may occur.

Figure 5 MC3300x-R Rotating Turret

MC3300x-S Features

Figure 6 MC3300x-S Front View




Table 6 MC3300x-S Features - Front View

Number	Item	Function
1	Display	Displays all information needed to operate the device.
2	Charge /Application Notification LED or Scan/Decode Status	Indicates the battery charge state while charging, an application notification was received, or the scan/decode status.
3	Side Key Scan Button	Initiates data capture when a scan application is enabled.
4	Battery Release Latch	Release the battery from the device.
5	Power Button	Press and hold to turn on the device. Press to turn on or off the screen. Press and hold to select one of these options: Power off - Turn off the device. Reboot - Reboot the device when software stops responding. Airplane mode - Disable all wireless connections. Silent mode - All notifications are disabled except for alarms.

Table 6 MC3300x-S Features - Front View (Continued)

Number	Item	Function
6	Microphone	Use for communications in Handset mode.
7	Keypad	Use to enter data and navigate on screen functions.
8	Scan Button	Initiates data capture when a scan application is enabled.

Figure 7 MC3300x-S Back View




Table 7 MC3300x-S Features - Back View

Number	Item	Function
9	Battery	Provides power for operating the device.
10	Battery Release Latch	Release the battery from the device.
11	Side Key Scan Button	Initiates data capture when a scan application is enabled.
12	Speaker	Provides audio output for video and music playback.
13	Scanner Exit Window	Provides data capture using the scanner.
14	NFC Antenna	Provides communication with other NFC-enabled devices.
15	Camera/Flash	Provides illumination for the camera.
16	Hand Strap	Use for securely holding the device.

Setting Up the Device

To start using the device for the first time:

- Install a micro secure digital (SD) card (optional)
- Install the battery
- Charge the device
- Power on the device.

Installing a microSD Card


The microSD card slot provides secondary non-volatile storage. The slot is located under the battery pack. Refer to the documentation provided with the card for more information, and follow the manufacturer's recommendations for use.



CAUTION: Follow proper electrostatic discharge (ESD) precautions to avoid damaging the microSD card. Proper ESD precautions include, but are not limited to, working on an ESD mat and ensuring that the operator is properly grounded.


1. Using a coin or finger, remove the microSD card cover.

Figure 8 Remove microSD Card Cover




2. Slide the microSD card holder to the Open position.

Figure 9 Unlock microSD Card Holder




3. Lift the microSD card holder.

Figure 10 Lift microSD Card Holder




4. Place the microSD card into the contact area with the contacts facing down.

Figure 11 Install microSD Card




5. Close the microSD card holder and slide the microSD card holder to the Lock position.

Figure 12 Lock microSD Card Holder



6. Replace the microSD card cover and ensure that it is installed properly.

Figure 13 Replace Cover



Installing the MC3300x-G Battery


The MC3300x-G is compatible with the following batteries:

- MC3300x 5200 mAh PowerPrecision+ extended battery.
- MC32N0 5200 mAh PowerPrecision extended battery.

To install the battery:

1. Loosen the hand strap, if needed.
2. Align the battery into the battery compartment.


Figure 14 Inserting the Battery



3. Rotate the bottom of the battery into the battery compartment.

4. Press battery down firmly. Ensure that both battery release buttons on the sides of the MC3300x-G return to the home position.

Figure 15 Press Battery Down



5. Tighten the hand strap, if needed.
6. Press the Power button to turn on the device.

Installing the MC3300x-R/S Battery

The MC3300x-R/S is compatible with the following batteries:


- MC3300x 2740 mAh PowerPrecision+ standard battery.
- MC3300x 5200 mAh PowerPrecision+ extended battery.
- MC32N0 2740 mAh PowerPrecision standard battery.
- MC32N0 5200 mAh PowerPrecision extended battery.

To install the battery:

1. Loosen the hand strap, if needed.


2. Align the top of the battery into the battery compartment.

Figure 16 Inserting the Battery



3. Rotate the bottom of the battery into the battery compartment.
4. Press battery down firmly. Ensure that both battery release buttons on the sides of the MC3300x-R/S return to the home position.

Figure 17 Press Battery Down



5. Tighten the hand strap, if needed.
6. Press the Power button to turn on the device.

Charging the Battery



CAUTION: Ensure that you follow the guidelines for battery safety described in Battery Safety Guidelines on page 214.

Use the mobile computer cradles, cables and spare battery chargers to charge the mobile computer main battery.

The main battery can be charged before insertion into the mobile computer or after it is installed. There are two main batteries for the MC3300x, the 2740 mAh PowerPrecision+ standard battery (1X) and the 5200 mAh PowerPrecision+ extended battery (2X). The MC3300x-G is compatible with the 5200 mAh PowerPrecision+ extended battery. The MC3300x-R/S are compatible with both the 2740 mAh PowerPrecision+ standard battery and the 5200 mAh PowerPrecision+ extended battery. Use one of the spare battery chargers to charge the main battery (out of the mobile computer) or one of the cradles to charge the main battery while it is installed in the mobile computer.

Before using the mobile computer for the first time, fully charge the main battery until the green Charge LED indicator remains lit and charge the battery using a cable or a cradle with the appropriate power supply. For information about the accessories available for the MC3300x, see Accessories. The 2740 mAh PowerPrecision+ standard battery fully charges (0% to 90% capacity) in less than 2.2 hours and the 5200 mAh PowerPrecision+ extended battery fully charges (0% to 90% capacity) in less than 3.8 hours.

The MC3300x retains data in memory for at least five minutes when the mobile computer's main battery is removed.

When the main battery reaches a very low battery state, the battery retains data in memory for at least 15 hours.

Batteries must be charged within the 0° to +40° C (32° to 104° F) ambient temperature range.

The following accessories can be used to charge batteries:

- Cradles (and a power supply):
 - 1-Slot USB Charge Cradle
 - 5-Slot Charge Only ShareCradle
 - 5-Slot Ethernet ShareCradle
 - 5-Slot Charge ShareCradle + 4-Slot Spare Battery Charger
 - 5-Slot Ethernet ShareCradle + 4-Slot Spare Battery Charger.
- Cables (and a power supply):
 - USB Charge Cable.
- Spare Battery Chargers (and a power supply):
 - 4-Slot Spare Battery Charger
 - 20-Slot Spare Battery Charger.

To charge the mobile computer using the cradles:

1. Insert the mobile computer into a cradle. See Accessories for accessory setup.
2. The mobile computer starts to charge automatically. The Charge LED Indicator indicates the charge status. See the table below for charging indications.

To charge the mobile computer using the cables:

1. Connect the MC3300x Communication/Charge Cable to the appropriate power source and connect to the mobile computer. See Accessories for accessory setup.
2. The mobile computer starts to charge automatically. The Charge LED Indicator indicates the charge status.

Charging Indicators

Table 8 LED Charge Indicators

Status	Indications
Off	<ul style="list-style-type: none"> The battery is not charging. The battery is not inserted correctly in the cradle or connected to a power source. Cradle is not powered.
Slow Blinking Amber Every 3 seconds	<ul style="list-style-type: none"> Battery is charging, but the battery is fully depleted and does not yet have sufficient charge to power the device.
Solid Amber	<ul style="list-style-type: none"> Battery is charging.
Solid Green	<ul style="list-style-type: none"> Battery charging is complete.
Fast Blinking Red 2 blinks/second	Charging error, e.g.: <ul style="list-style-type: none"> Temperature is too low or too high. Charging has gone on too long without completion (typically eight hours).
Solid Red	<ul style="list-style-type: none"> Spare battery is charging and battery is at the end of useful life. Charging complete and battery is at the end of useful life.

The MC3300x 2740 mAh PowerPrecision+ standard battery charges from 0% to 90% in less than 2.2 hours at room temperature.

The MC3300x 5200 mAh PowerPrecision+ extended battery charges from 0% to 90% in less than 3.8 hours at room temperature.

The MC32N0 2740 mAh PowerPrecision standard battery charges from 0% to 90% in less than 3 hours at room temperature.

The MC32N0 5200 mAh PowerPrecision extended battery charges from 0% to 90% in less than 5.5 hours at room temperature.

Backup Power

The device is equipped with a supercapacitor (supercap) to provide backup power to the device when the main battery is removed. The supercap will retain random access memory (RAM) data in memory for approximately five minutes after the main battery is removed during Hot Swap.



IMPORTANT: The supercap is automatically charged from the main battery and requires approximately ten minutes to fully charge.

Charging Temperature

Charge batteries in ambient temperatures from 0°C to 40°C (32°F to 104°F) or up to 45°C (113°F) as reported by the battery. To view battery temperature, go to **Settings > System > About phone > Battery information**.

The device or cradle always performs battery charging in a safe and intelligent manner. At higher temperatures (for example, approximately +37°C (+98°F)) the device or cradle may for small periods of time alternately enable and disable battery charging to keep the battery at acceptable temperatures. The device and cradle indicates when charging is disabled due to abnormal temperatures via its LED.

Charging Spare Batteries

See the Accessories section for information on using accessories to charge spare batteries.

Hot Swap Mode

The device provides a Hot Swap mode where the user can replace the battery without powering off the device. When the user removes the battery, the display turns off and the device enters a low power state while in Hot Swap mode. In Hot Swap mode, the device retains RAM data for approximately 5 minutes. Replace the battery within 5 minutes to preserve memory persistence. If the user does not install a charged battery within 5 minutes, data in RAM will be lost. During Hot Swap mode, Wi-Fi and Bluetooth remain connected for 30 seconds. If the battery is not inserted within 30 seconds, Wi-Fi is disabled and then re-enabled when the device comes out of Hot Swap mode and Bluetooth is reset when the device comes out of Hot Swap mode.




IMPORTANT: The supercap requires time to recharge after performing a Hot Swap or after the main battery is fully depleted. Hot Swap mode will not retain data unless the supercap is fully charged.

Zebra Visibility Services

The device captures and provides device analytics to a system administrator. The first time the device boots (or after a Factory reset), the **Zebra Services** agreement screen displays.

Figure 18 Zebra Services



Touch the **Device Data** switch to disable the device from sending analytics data.


Replacing the Battery in the MC3300x-G

To replace the battery:

1. Push in the two Battery Release buttons.


The battery ejects slightly. With Hot Swap mode, when the user removes the battery, the display turns off and the device enters a low power state. The MC3300x-G retains RAM data for approximately five minutes. Replace the battery within five minutes to preserve memory persistence.

Figure 19 Release Battery




2. Remove the battery from the battery compartment.

Figure 20 Remove Battery




3. Align the battery into the battery compartment.

Figure 21 Inserting the Battery



4. Rotate the bottom of the battery into the battery compartment.
5. Press battery down firmly. Ensure that both battery release buttons on the sides of the MC3300x-G return to the home position.

Figure 22 Press Battery Down



6. Press the Power button to turn on the device.


Replacing the Battery in the MC3300x-R/S

To replace the battery:

1. Push in the two Battery Release buttons.


The battery ejects slightly. With Hot Swap mode, when the user removes the battery, the display turns off and the device enters a low power state. The MC3300x-R/S retains RAM data for approximately five minutes. Replace the battery within five minutes to preserve memory persistence.

Figure 23 Release Battery




2. Remove the battery from the battery compartment.

Figure 24 Remove Battery



3. Align the battery into the battery compartment.


Figure 25 Inserting the Battery



4. Rotate the bottom of the battery into the battery compartment.

5. Press battery down firmly. Ensure that both battery release buttons on the sides of the MC3300x-R/S return to the home position.

Figure 26 Press Battery Down



6. Press the Power button to turn on the device.

Real-Time Clock Backup

The device provides a Real-time Clock (RTC) backup feature. After boot-up, the device saves the system time in a file in persistent storage. When the device re-boots, it compares the system time to the time saved in a file. If the system time is not the latest, it restores the time from the file.

Using the Device

Home Screen

Turn on the device to display the Home screen. Depending on the configuration, the Home screen may appear different. Contact your system administrator for more information.

After a suspend or screen time-out, the Home screen displays with the lock slider. Touch the screen and slide up to unlock. For screen locking information, see Un-Locking the Screen.

The Home screen provides additional screens for placement of widgets and shortcuts. Swipe the screen left or right to view the additional screens.




NOTE:

By default, non-GMS devices do not have the same icons on the Home screen as GMS. Icons are shown below for example only.

Home screen icons can be configured by the user and may look different than shown.



GMS



AOSP

The Home screen consists of the following:

Table 9 Home Screen Items

Item	Description
1 — Status Bar	Displays the time, status icons (right side), and notification icons (left side). For more information see Status Bar on page 40 and Managing Notifications on page 42 .
2 — Widgets	Launches stand-alone applications that run on the Home screen.
3 — Shortcut Icons	Opens applications installed on the MC3300x.
4 — Folder	Contains apps.
5 — Settings Icon	Opens the Settings window.
6 — Back	Displays the previous screen.
7 — Home	Displays the Home screen.
8 — Recent Button	Displays recently used applications.
9 — All Apps Icon	Opens the APPS window.

Setting Home Screen Rotation

By default the **Home** screen rotation is disabled.

To enable **Home** screen rotation:

1. Touch and hold anywhere on the **Home** screen until the options appear.
2. Touch **Home settings**.
3. Touch the **Allow Home screen rotation** switch.
4. Touch ☐.
5. Rotate the device.

Status Bar

The Status bar displays the time, notification icons (left side), and status icons (right side).















NOTE: Some Status icons may not appear in the Status bar if there are too many icons to display.

Figure 27 Notification and Status Icons

If there are more notifications than can fit in the Status bar, a dot displays indicating that more notifications exist. Swipe down from the Status bar to open the Notification panel and view all notifications and status.



















Status Icons

Table 10 *Status Icons*

Icon	Description
	Alarm is active.
	Main battery is fully charged.
	Main battery is partially drained.
	Main battery charge is low.
	Main battery charge is very low.
	Main battery is charging.
	All sounds, except media and alarms, are silenced and vibrate mode is active.
	Do Not Disturb mode active.
	Airplane Mode is active. All radios are turned off.
	Bluetooth is on.
	The device is connected to a Bluetooth device.
	Connected to a Wi-Fi network.
	Not connected to a Wi-Fi network or no Wi-Fi signal.
	Connected to an Ethernet network.
	Speakerphone enabled.
	Indicates that all sounds except media and alarms are silenced.
	Indicates that the Orange key is locked.
	Indicates that the Blue key is pressed.
	Indicates that the ALT key is pressed.
	Indicates that the CTRL key is pressed.
	Indicates that the Shift key is pressed.
	Indicates that the Shift key is locked.
	Indicates that a BT headset is connected to the MC3300x.

Notification Icons

Table 11 *Notification Icons*


Icon	Description
	Main battery is low.
	More notifications are available for viewing.
	Data is syncing.
	Indicates an upcoming event. Non-GMS devices only.
	Indicates an upcoming event. GMS devices only.
	Open Wi-Fi network is available.
	Song is playing.
	Problem with sign-in or sync has occurred.
	Device is uploading data.
	Device is downloading data when animated and download is complete when static.
	Device is connected to or disconnects from a virtual private network (VPN).
	Preparing internal storage by checking it for errors.
	USB debugging is enabled on the device.
	Headset is connected to the device.
	PTT Express Voice client status. See the PTT Express PTT Notification Icons for a complete list.
	Indicates that RxLogger app is running.
	Indicates the RS6000 is connected to the device.
	Indicates the RS507 or RS6000 is connected to the device in HID mode.

Managing Notifications

Notification icons report the arrival of new messages, calendar events, alarms, and ongoing events. When a notification occurs, an icon appears in the Status bar with a brief description. See Notification Icons for a list of possible notification icons and their description. Open the Notification panel to view a list of all the notifications.

To open the Notification panel, drag the Status bar down from the top of the screen.

Figure 28 Notification Panel



To respond to a notification, open the Notification panel and then touch a notification. The Notification panel closes and the corresponding app opens.

To clear all notifications, open the Notification panel and then touch **CLEAR ALL**. All event-based notifications are removed. Ongoing notifications remain in the list.

To close the Notification panel, swipe the Notification panel up.

Quick Access Panel


Use the Quick Access panel to access frequently used settings (for example, Airplane mode).

To see the full Quick Access panel:

- If the device is locked, swipe down once.
- If the device is unlocked, swipe down once with two fingers, or twice with one finger.
- If the Quick Settings bar is open, touch the Down arrow.

- If the Notification panel is open, swipe down from the Quick Settings bar.

Figure 29 Quick Access Panel



NOTE: Not all icons are pictured. Icons may vary.


To change a setting, touch the icon:

- Display brightness - Use the slider to decrease or increase the brightness of the screen.
- Wi-Fi network - Turn Wi-Fi on or off. To open Wi-Fi settings, touch the Wi-Fi network name.
- Bluetooth settings - Turn Bluetooth on or off. To open Bluetooth settings, touch **Bluetooth**.
- Battery power - Indicates percentage of battery power remaining. Touch to view battery usage.
- Do not disturb - Control how and when to receive notifications.
- Airplane mode - Turn Airplane mode on or off. When Airplane mode is on the device does not connect to Wi-Fi or Bluetooth.
- Auto-rotate - Lock the device's orientation in portrait or landscape mode or set to automatically rotate.
- Flashlight - Turn flashlight on or off. Turn camera flash on or off.

The thermal protection safety feature for the camera provides the following behavior if the temperature range is 40°C or above:

- If the flashlight is kept on for a certain period of time, it is automatically turned off and cannot be turned back on for a period of time until it has cooled off.
- During the cooling off period, the camera cannot be turned on. If you attempt to use the camera, a message displays indicating to try again after a period of time.
- Cast - Share phone content on Chromecast or a television with Google Cast built-in. Touch cast screen to display a list of devices, then touch a device to begin casting.

Editing Icons on Quick Settings

The first several setting tiles from the Quick Access panel become the Quick Settings bar. Open the Quick Access panel and touch  to edit, add, or remove settings tiles.

Battery Management



NOTE: Prior to checking the battery charge level, remove the device from any AC power source (cradle or cable).

To check the charge status of the main battery, open **Settings** and touch **System > About phone > Battery Information**.



IMPORTANT: At temperatures below 0°C, the Battery level may report a reduced value. This is normal due to temperature compensation.

Battery present status indicates if the battery is present and **Battery level** lists the battery charge (as a percentage of fully charged). The battery percentage can also be viewed next to the battery icon in the quick access panel. Swipe down with two fingers from the status bar to open the quick access panel.

Monitoring Battery Usage

The **Battery** screen provides battery charge details and power management options to extend battery life.

1. Go to **Settings**.
2. Touch **Battery**.

To display battery information and power management options for a specific app:

1. Go to **Settings**.
2. Touch **Apps & notifications**.
3. Touch an app.
4. Touch **Advanced > Battery**.

Different apps display different information. Some apps include buttons that open screens with settings to adjust power use. Use the **DISABLE** or **FORCE CLOSE** buttons to turn off apps that consume too much power.

Low Battery Notification

When the battery charge drops below 23% (MC3300x 2740 mAh PowerPrecision+ standard battery) or 15% (MC3300x 5200 mAh PowerPrecision+ extended battery) to a low level, the MC3300x displays a notice to connect the MC3300x to power. The user should charge the battery using one of the charging accessories.

When the battery charge drops below 15% (MC3300x 2740 mAh PowerPrecision+ standard battery) or 8% (MC3300x 5200 mAh PowerPrecision+ extended battery) to a very low level, the MC3300x displays a notice to connect the MC3300x to power. The user should charge the battery using one of the charging accessories.

When the battery charge drops below 8% (MC3300x 2740 mAh PowerPrecision+ standard battery) or 4% (MC3300x 5200 mAh PowerPrecision+ extended battery), the MC3300x goes into critical suspend mode to save data. The screen turns off.

The user must replace the battery or charge the MC3300x using one of the charging accessories to retain data.

Battery Optimization

Observe the following battery saving tips:

- Set the screen to turn off after a short period of non-use.
- Reduce screen brightness.
- Turn off all wireless radios when not in use.
- Turn off automatic syncing for Email, Calendar, Contacts, and other apps.
- Minimize use of apps that keep the device from suspending, for example, music and video apps.

Interactive Sensor Technology

The MC3300 contains sensors that monitor movement and orientation:

- Gyroscope - Measures angular rotational velocity to detect rotation of the device.
- Accelerometer - Measures the linear acceleration of movement to detect the orientation of the device.

In order to take advantage of these sensors, applications use API commands. Refer to the Zebra Android EMDK for more information.

Suspend Mode

The device goes into suspend mode when you press the Power button or after a period of inactivity (set in the Display settings window).

To wake the device from Suspend mode, press the Power button. The Lock screen displays. Swipe the screen up to unlock. If the Pattern screen unlock feature is enabled, the Pattern screen appears instead of the Lock screen. If the PIN or Password screen unlock feature is enabled, enter the PIN or password after unlocking the screen. See Un-Locking the Screen.



NOTE: If you enter the PIN, password, or pattern incorrectly five times, you must wait 30 seconds before trying again. If you forget the PIN, password, or pattern contact your system administrator.

USB Communication

Connect the device to a host computer using a USB cable or a USB cradle to transfer files between the device and the host computer.

When connecting the device to a host computer, follow the host computer's instructions for connecting and disconnecting USB devices, to avoid damaging or corrupting files.

Transferring Files



NOTE: Use Transfer files to copy files between the device (internal memory or microSD card) and the host computer.

1. Connect a USB cable to the device or place the device into a USB cradle.
2. Pull down the Notification panel and touch **USB charging this device**.
By default, **Charge this device** is selected.
3. Touch **Transfer files**.
4. On the host computer, open a file explorer application.
5. Locate the **device** as a portable device.

6. Open the **SD card** or the **Internal storage** folder.
7. Copy files to and from the device or delete files as required.

Transferring Photos

To transfer photos using Photo Transfer Protocol:



NOTE: Use Photo Transfer Protocol (PTP) to copy photos from either the microSD card or internal memory to the host computer.

1. Connect USB cable to the device or place the device into a USB cradle. See [Accessories](#) for setup information.
2. Pull down the Notification panel and touch **USB charging this device**.
3. Touch **Transfer photos (PTP)**.
4. On the host computer, open a file explorer application.
5. Open the **SD card** or the **Internal storage** folder.
6. Copy or delete photos as required.

Disconnect from the Host Computer

To disconnect the device from the host computer:






CAUTION: Carefully follow the host computer's instructions to unmount the microSD card and disconnect USB devices correctly to avoid losing information.

1. On the host computer, unmount the device.
2. Remove the USB from the device or remove the device from the cradle.

Settings

Accessing Settings

Access Settings in any of the following ways:

- Swipe down with two fingers from the top of the Home screen to open the Quick Access panel and touch .
- Double-swipe down from the top of the Home screen to open the Quick Access panel and touch .
- Swipe up from the bottom of the Home screen to open APPS and touch  **Settings**.

Display Settings


Use Display settings to change the screen brightness, enable night light, change the background image, enable screen rotation, set sleep time, and change font size.

Setting the Screen Brightness

To manually set the screen brightness using the touchscreen:

1. Swipe down with two fingers from the top of the Home screen to open the Quick Access panel.
2. Slide the icon to adjust the screen brightness level.

To let the device automatically adjust the screen brightness using the built-in light sensor:

1. Go to **Settings**.
2. Touch **Display**.
3. If disabled, touch **Adaptive brightness** to automatically adjust the brightness.
By default, **Adaptive brightness** is enabled. Toggle the switch to disable.
4. Touch .

Setting Night Light

The Night Light setting tints the screen amber, making the screen easier to look at in low light.

To enable night light:

1. Go to **Settings**.

2. Touch **Display**.
3. Touch **Night Light**.
4. Touch **Schedule**.
5. Select one of the schedule values:
 - None (default)
 - Turns on at custom time
 - Turns on from sunset to sunrise.
6. Touch **Status**.
By default, **Night Light** is disabled. Toggle the switch to enable.
7. Adjust the tint using the **Intensity** slider.
8. Touch ☐.

Setting Screen Rotation

By default, screen rotation is enabled.

To disable screen rotation:

1. Go to **Settings**.
2. Touch **Display > Advanced**.
3. Touch **Auto-rotate screen**.



NOTE: To change the Home screen rotation, see Setting Home Screen Rotation.

4. Touch ☐.

Setting Screen Timeout


To set the screen sleep time:

1. Go to **Settings**.
2. Touch **Display > Advanced > Sleep**.
3. Select one of the sleep values.
 - **15 seconds**
 - **30 seconds**
 - **1 minute** (default)
 - **2 minutes**
 - **5 minutes**
 - **10 minutes**
 - **30 minutes** (default).
4. Touch ☐.

Ambient Display


The Ambient display setting wakes the screen when notifications are received.

To disable ambient display:

1. Go to **Settings**.
2. Touch **Display > Advanced**.
3. Touch **Ambient display**.
4. In the **When to show** section, enable or disable an option using the switch.
5. Touch .

Setting Font Size


To set the size of the font in system apps:

1. Go to **Settings**.
2. Touch **Display > Advanced**.
3. Touch **Font size**.
4. Select one of the font size values.
 - Small
 - Default
 - Large
 - Largest.
5. Touch .

Setting Display Size

By default, display size is set to default.

To change the display size:


1. Go to **Settings**.
2. Touch **Display > Advanced**.
3. Touch **Display size**.
4. Touch - and + to change the display size.
 - Small
 - Default
 - Large.
5. Touch .

Touch Panel Mode

The device display is able to detect touches using a finger, a conductive-tip stylus, or gloved finger.



NOTE: A glove can be made of medical latex, leather, cotton, or wool.
For optimal performance use a Zebra certified stylus.

1. Go to **Settings**.
2. Touch **Display > Advanced**.
3. Touch **Touch panel mode**.
4. Select:
 - a. **Glove and Finger (Screen Protector off)** to use a finger or a gloved finger on the screen without a screen protector.
 - b. **Stylus and Finger (Screen Protector off)** to use a finger or a stylus on the screen without a screen protector.
 - c. **Finger Only** to use a finger on the screen.
 - d. **Glove and Finger (Screen Protector on)** to use a finger or a gloved finger on the screen with a screen protector.
 - e. **Stylus and Finger (Screen Protector on)** to use a finger or a stylus on the screen with a screen protector.
5. Touch .




General Sound Setting

Use the **Sound** settings to configure media and alarm volumes.

To access sound settings:

1. Go to **Settings**.
2. Touch **Sound**.
3. Touch an option to set sounds.

Sound Options

- **Zebra volume controls**
 - **Ring volume** - Controls the ringtone volume.
 - **Media volume** - Controls the music, games, and media volume.
 - **Alarm volume** - Controls the alarm clock volume.
 - **Notifications volume** - Controls the notification volume.
 - **Scanner volume** - Controls the scanner volume.
- **Volume presets**
 -  - Mutes the ring, notifications, and scanner so that the device does not make sounds or vibrate.
 -  - All sounds except media and alarms are silenced and vibrate mode is active.
 -  - Enables all sounds at the user defined levels.

- Also vibrate for calls - Switch on or off.
- **Do Not Disturb preferences** - Mutes some or all sounds and vibrations.
 - **Priority only allows** - Use to set the priorities for the following:
 - **Reminders** - Switch on or off.
 - **Events** - Switch on or off.
 - **Alarms** - This is always enabled.
 - **Messages** - Choose to allow messages from anyone, starred contacts, any contact, or none. To star contacts, use the Contacts app.
 - **Calls** - Choose to allow calls from anyone, starred contacts, any contact, or none. To star contacts, use the Contacts app.
 - **Repeat callers** - Choose whether or not the phone rings if the same person calls again within 15 minutes.
 - **Block visual disturbances**
 - **Block when screen is on** - This option prevents notifications from displaying over the screen (peeking) while you are actively using the device.
 - **Block when screen is off** - This option prevents notifications from turning on the screen or pulsing the LED light when a new notification is received while you are not using the device.
 - **Automatic rules** - Choose when to automatically silence the device. Touch a default rule, such as Weekend or Weeknight, or create your own rule. To create your own rule, tap **Add more** and then **Time rule**.
- **Advanced** - Touch to display advanced sound options.
 - **Default notification sound** - Touch to select a sound to play for all system notifications.
 - **Default alarm sound** - Touch to select a sound to play for alarms.
 - **Other sounds and vibrations**
 - **Screen locking sounds** - Play a sound when locking and unlocking the screen (default – enabled).
 - **Charging sounds** - Not applicable.
 - **Touch sounds** - Play a sound when making screen selections (default – enabled).
 - **Vibrate on tap** - Vibrate the device when making screen selections (default – disabled).
 - **Emergency alerts** - Touch to configure emergency broadcast settings and notifications.

Setting Device Advertisement

Device Advertisement consists of **Inactivity notification** and **Device paging** functionalities. Inactivity notification is based on the device sensor support (accelerometer). If the device doesn't have an accelerometer sensor, only the Device paging option is available.

To access Device Advertisement settings:

1. Go to **Settings**.
2. Touch **Device Advertisement**.

3. Select from the following options:

- **Inactivity notification** - Enable to have the device notify the user with audible and/or LED notifications. The notification starts once the device battery level goes below the **Battery warning level** and the **Inactivity timeout** criteria is met (Default - disabled).
- **Device paging** - The device must be connected to WLAN and be MDM managed. The MDM sends the device notification intent to the necessary device which has to be paged. This option is configurable through an MDM (StageNow, SOTI, or AirWatch) (Default - disabled).

Configurations

- **Battery warning level** - Enable **Inactivity notification** to activate this option. Set by the user. (Default - 20%).
- **Inactivity timeout** - Enable **Inactivity notification** to activate this option. Once the device is in an idle state (not in motion) and not charging or in a cradle, this is the time period after which the device will start sending notifications. Set between 1 - 60 minutes. (Default - 30).
- **LED notification** - Enable or disable this option to receive an LED notification.
- **Audible notification** - Enable or disable this option to receive an audible notification.
- **Audible timeout** - Enable this option to set the **Timeout of audible notification** option.
- **Timeout of audible notification** - Enable **Audible timeout** to activate this option. This is the time period for which the notification is played continuously. If the **Audible timeout** is disabled and **Audible notification** is enabled, then the audio notification will keep playing without a timeout period. Set between 1-30 minutes (Default - 3).
- **Audible type** - valid options: **Ring**, **Notification**, and **Alarm**.
- **Audible file** - The user can select from various pre-defined files, based on the audible type, or add a custom ringtone.

4. Touch ☐.

Wake-Up Sources

By default, the device wakes from suspend mode when the user presses the power button. The device can be configured to wake when the user presses the Trigger or the Scan button.

1. Go to **Settings**.
2. Touch **Wake-Up Sources**.
3. Touch a checkbox. A check appears in the checkbox.
4. Touch ☐.

Remapping a Button

Buttons on the device can be programmed to perform different functions or as shortcuts to installed apps.




NOTE: It is not recommended to remap the scan button.

1. Go to **Settings**.
2. Touch **Key Programmer**. A list of programmable buttons displays.
3. Select the button to remap.

4. Touch the **BUTTON REMAPPING** tab or the **SHORTCUT** tab that lists the available functions and applications.
5. Touch a function or application shortcut to map to the button.




NOTE: If you select an application shortcut, the application icon appears next to the button on the Key Programmer screen.

6. Touch .

Remappable Keys

Figure 30 Key Positions



UI Listed Keys

- GRIP_TRIGGER
- SCAN
- P1
- P2
- LEFT_TRIGGER_1
- RIGHT_TRIGGER_1

Other Remappable Keys

- 0-9
- A-Z
- F1-F10
- LEFT
- UP
- DOWN

- RIGHT
- ENTER
- SPACE
- ESC
- DOT (via XML only, not SN)
- TAB
- DELETE
- COMMA

Non-Remappable Keys

- POWER
- SHIFT
- CTRL
- ALT
- BLUE
- ORANGE
- BACK
- HOME
- RECENT

Keyboards

The device provides the following types of keyboards:

- Android Keyboard - Non-GMS devices only.
- Gboard - GMS devices only
- Enterprise Keyboard



NOTE: By default the Enterprise and Virtual Keyboards are disabled.

Keyboard Configuration


Enabling Keyboards


To enable keyboards:

1. Go to **Settings**.
2. Touch **System > Languages & input > Virtual keyboard > Manage keyboards**.
3. Touch a keyboard to enable.

Switching Between Keyboards

To switch between keyboards, touch in a text box to display the current keyboard.

- On the Android or Gboard keyboards, touch and hold .

- On the Enterprise keyboard, touch .

Using the Android and Gboard Keyboards

Use the Android or Gboard keyboards to enter text in a text field. To configure the keyboard settings, touch and hold , (comma) and then select **Android keyboard settings**.

Editing Text

Edit entered text and use menu commands to cut, copy, and paste text within or across apps. Some apps do not support editing some or all of the text they display; others may offer their own way to select text.

Entering Numbers, Symbols, and Special Characters

To enter numbers and symbols:

- Touch and hold one of the top-row keys until a menu appears then select a number or special character.
- Touch the Shift key once for a single capital letter. Touch the Shift key twice to lock in uppercase. Touch the Shift key a third time to unlock Capslock.
- Touch **123** to switch to the numbers and symbols keyboard.
- Touch the **=\<** key on the numbers and symbols keyboard to view additional symbols.

To enter special characters, touch and hold a number or symbol key to open a menu of additional symbols. A larger version of the key displays briefly over the keyboard.

Using the Enterprise Keyboard

The Enterprise Keyboard contains the following keyboards:

- Numeric
- Alpha
- Special characters
- Data capture.

Numeric Tab

To access the numeric keyboard, touch the **123** tab. The keys displayed vary on the app being used. For example, an arrow displays in **Contacts**, however **Done** displays in **Email** account setup.

Figure 31 Numeric Keyboard

