



### **Microphone light Details** Butiran Lampu Mikrofon 麦克风灯光详情

Chi tiết đèn Microphone

Solid Yellow	Microphone functioning normally
Kuning Padat	Mikrofon berfungsi normal
固定黄色	麦克风正常工作
Màu vàng	Micrô hoạt động bình thường
Quick Flashing Yellow	Microphone in pairing mode
Kuning Berkelip Cepat	Mikrofon dalam mode berpasangan
快速闪烁黄色	麦克风处于配对模式
Màu vàng nhấp nháy nhanh	Micro ở chế độ ghép nối
Solid Red	Low power (<10%)
Merah Padat	Daya rendah (<10%)
固定红色	电量低 (<10%)
Màu đỏ	Công suất thấp (<10%)
Quick Flashing Green	Microphone is charging
Hijau Berkelip Cepat	Mikrofon sedang diisi daya
快速闪烁绿色	麦克风正在充电
Màu xanh lá cây nhấp nháy nhanh	Micro đang sạc
Solid Green	Microphone is fully charged
Hijau padat	Mikrofon terisi penuh
固定绿色	麦克风已充满电
Màu xanh lá cây rắn	Micro đã được sac đầy

### FCC Statement

undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause

FCC Radiation Exposure Statement for receiver hub: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This station should be installed and operated with minimum distance 20cm between the radiator& your body.RF warning for microphone: The device has been evaluated to meet general RF

exposure requirment. The wireless microphone can be used in portable exposure condition without restriction.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirment. The device can be used in portable exposure condition without restriction.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## 注意

请将产品远离高温和潮湿的地方,以避免任何故障 发生。

常见问题

**麦克风指示灯未亮** 请给麦克风充电,可能电池已耗尽

麦克风没有声音

1.检查麦克风是否已开启,其LED指示灯为固定的黄 色; 2.确保混音接收器已正确插入电视的接口 3.如果混音器指示灯未亮,请扫描封面上的QR码,查 看我们的配对指南。

扬声器没有声音

·请确保音频电缆正确连接到扬声器。 ·请确保在扬声器上选择了正确的音频输入。

## Bảo hành & Đổi trả

Trao đổi

Trong vòng 14 ngày kế từ ngày mua hàng, người dùng có thể đổi sản phẩm cùng mẫu nếu lỗi xuất hiện trong quá trình sử dụng bình thường do yếu tố không phải là con người gây ra và đã được xác định qua kiểm tra.

#### Bảo hành

Bạn có quyền yêu cầu bảo hành trong vòng 12 tháng kể từ ngày mua hàng.

# Quy định không được bảo hành

1.Sửa chữa không được ủy quyền, lạm dụng, va đập, lơ là, lạm dụng, nước dầu, sửa đổi, việc sử dụng sản phẩm và phụ kiện không đúng cách.

Ngoài thời gian bảo hành.
Hỏng hóc do yếu tố con người gây ra.

## Thông báo

Vui lòng tránh để sản phẩm ở nơi có nhiệt độ cao và ẩm ướt để tránh gặp sự cố.

## Câu hỏi thường gặp

Đèn chỉ thị Microphone không sáng -Vui lòng sạc micro, nó có thể hết pin.

Không có âm thanh từ Microphone 1. Kiểm tra xem microphone đã bật chưa và đèn LED của nó có màu vàng đặc không; 2. Đảm bảo rằng bộ thu mixer đã được cắm đúng vào

giao diện của TV; 3. Nếu đèn chỉ thị mixer không sáng, vui lòng tham khảo hướng dẫn ghép đôi bằng cách quét mã QR trên bìa hướng dẫn.

## Không có âm thanh từ Loa · Hãy đảm bảo cáp âm thanh được kết nổi đúng cách với

loa của bạn. · Vui lòng đảm bảo bạn đã chọn đầu vào âm thanh chính xác trên loa của bạn.

