


amazonbasics



Bluetooth Stereo Speaker with Water Resistant Design

Enceinte Stéreo Bluetooth Résistante à l'Eau

Bluetooth-Stereo-Lautsprecher mit Wasserfestem Design

Altoparlante Stereo Bluetooth con Design Resistente all'Acqua

Altavoz Estéreo Bluetooth con Diseño Resistente al Agua

Bluetooth Stereo-Luidspreker met Waterbestendig Ontwerp

Bluetooth ステレオスピーカー耐水デザイン付


B07PDYW6VM, B07PLCY3PV, B07PJ67Q7Z,
B07PKBTB4X, B07PH2HVGGM, B07PKBWYRT





English	3
Français	21
Deutsch.....	38
Italiano	54
Español	69
Nederlands.....	84
日本語	99

Welcome Guide • English

Contents: Before getting started, ensure the package contains the following components:





A Speaker

G On/off switch

B AUX IN socket

H Decrease volume switch

C Reset switch

I Play/pause/call switch

D USB Micro B port

J Increase volume switch

E USB cable

K Bluetooth® switch

F Status indicator

L Microphone

NOTICE

To keep the splash proof properties of this product, keep the side flap closed.

IMPORTANT SAFEGUARDS



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

- Read these instructions.
- Keep these instructions.
- Heed all instructions.
- To avoid accidental falls into pools, bathtubs or other water containers, do not place it at the edge.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
- Refer all servicing to qualified service personnel.
- No naked flame sources, such as lighted candles, should be placed on the product.
- This product is only suitable for use in moderate climates. Do not use it in tropical or in particularly humid climates.



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Battery Warnings



WARNING

Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

- The battery contained in this product is non-replaceable. Do not throw the product into a fire.
- Before disposal the battery must be removed from the product. Contact qualified professional.
- Do not leave the battery charging for a prolonged period of time when the product is not in use.
- Do not charge overnight.
- If the product appears to be bulging or shows other undesirable phenomena (e.g. excess noise), stop using it immediately.
- Do not drop this product.
- Do not cover while charging.
- Charge this product once every 3 months to avoid shortening its battery life.
- Batteries produce heat when charging and discharging. If the product becomes too hot to touch, turn it off and unplug it immediately.
- Charge this product only with a compatible power

source from reputable manufacturers e.g. a power adapter.

- If the battery leaks avoid contact with skin and eyes. Rinse affected areas immediately with plenty of clean water, then consult a doctor.

Symbols Explanation



This symbol stands for “Conformité Européenne”, which means “Conformity with EU-directives”. With the CE-marking the manufacturer confirms that this product complies with applicable European directives and regulations.



Direct current (DC).



Protected against splashing water from any direction. Do not immerse in water.

Intended Use

- This product is intended for household use only. It is not intended for commercial use.
- This product is intended to be used indoors and outdoors. It is protected against splashing water from any direction. Do not immerse in water.
- No liability will be accepted for damages resulting from improper use or non-compliance with these instructions.

Before First Use

- Check for transport damages.

**DANGER**

Risk of suffocation! Keep any packaging materials away from children – these materials are a potential source of danger, e.g. suffocation.

Operation

Charging built-in battery

- When the voice indicator “Low Battery” is heard, the product needs to be charged.
- Connect the USB cable (E) to the USB Micro B port (D).
- Connect the other end of the USB cable (E) to a USB-A port on a computer or a suitable power adaptor 5 V $\equiv$ 2 A. The status indicator (F) flashes red during charging.
- The product is fully charged when the status indicator (F) stops flashing.

Switching on/off

Press and hold the on/off switch (G) to switch on/off.

This prompts the voice indicator respectively, for each step.

NOTICE

The product automatically switches off approximately after 20 minutes of inactivity.

Pairing mode

NOTICE

Bluetooth® pairing is required if the speaker is used the first time with a new Bluetooth® enabled device.

- After switching on the product, the status indicator blinks blue slowly for approximately 12 seconds. After which, the product goes to pairing mode automatically.
- If the product does not automatically start pairing mode, press the Bluetooth® button (K) to enter pairing mode. The status indicator flashes blue.
- Activate Bluetooth® on the device you wish to pair and search for a new device.



- Select the Bluetooth® device name from the list on your device.

Model number:	Bluetooth® device name:
B07PDYW6VM B07PLCY3PV B07PJ67Q7Z	AmazonBasics WP926
B07PKBTB4X B07PH2HVGGM B07PKBWYRT	AmazonBasics WP927

- Once the devices are paired, the status indicator (F) lights up blue.

Disconnecting Bluetooth®

Press and hold down the Bluetooth® button (K) to disconnect connected device.

NOTICE

The product continuously attempts to reconnect a lost Bluetooth® connection. If it cannot, manually reconnect via the device's Bluetooth® menu.

Auxiliary input mode

Connect an 3.5 mm audio cable (not included) to the AUX IN socket (B) and to the desired playback device e.g. MP3 player.

Music playback

 : Press to play/pause the playback.

 : Press to skip to the next track.

 : Press to return to the previous track.

Calling

 : Press to accept/end call.

 : Press and hold to reject call.

Volume control

NOTICE

The volume of the playback resets to the medium volume after each start up.

 : Press and hold to increase volume.

 : Press and hold to decrease volume.

Factory reset

If the product is not functioning properly, press the reset switch (C) with a pointed object (for example a paper clip) to reset to original factory settings.

Cleaning and Maintenance

NOTICE

Switch the product off before cleaning.

NOTICE

During cleaning do not immerse the electrical parts of the product in water or other liquids. Never hold the product under running water.

- To clean, wipe with a soft, slightly moist cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

FCC Compliance Statement

1. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

- This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
 - (1) this device may not cause interference, and
 - (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.
- This Class B digital apparatus complies with Canadian CAN ICES-3(B) / NMB-3(B) standard.

Simplified EU Declaration of Conformity

- Hereby, Amazon EU Sarl declares that the radio equipment type B07PDYW6VM, B07PLCY3PV, B07PJ67Q7Z, B07PKBTB4X, B07PH2HVGM, B07PKBWYRT is in compliance with Directive 2014/53/EU.
- The full text of the EU declaration of conformity is available at the following internet address:
https://www.amazon.co.uk/amazon_private_brand_EU_compliance

Disposal



The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimize the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources.

Each country should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your house hold waste disposal service.

English

Français

Deutsch

Italiano

Español

Nederlands

日本語

Battery Disposal



Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.

Trademarks

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Amazon.com, Inc. or its affiliates is under license.



Specifications

Model number:

B07PKBTB4X
B07PH2HVGGM
B07PKBWYRT

Input:

5 V $\overline{\text{---}}$ 2 A, Lithium
battery 3.7 V, 4400 mAh

Operation frequency:

2402 - 2480 MHZ

RF power:

4 dBm

Charging time:

4 hours

Power consumption:

Max. 9 W

Frequency response:

70 Hz to 20 kHz

Sensitivity:

- 3.9 dB

Impedance:

R= 4 Ω ; L= 4 Ω

Bluetooth® version

4.2

Operating distance (range):

32. 8' (10 m)

IP Rating:

IPX4

Net weight:

approx. 12.2 oz (346 g)

Dimensions
(L x W x H):

approx. 7 x 1.8 x 2.3 in
(178 x 45 x 58 mm)

Specifications

Model number:	B07PDYW6VM B07PLCY3PV B07PJ67Q7Z
Input:	5 V $\overline{=}$ 2 A, Lithium battery 7.4 V, 2200 mAh
Operation frequency:	2402 - 2480 MHz
RF power:	4 dBm
Charging time:	3 hours
Power consumption:	Max. 15 W
Frequency response:	50 $\pm$ 20 Hz to 20 kHz
Sensitivity:	- 5.2 dB
Impedance:	R= 8 Ω ; L= 8 Ω
Bluetooth® version	4.2
Operating distance (range):	32. 8' (10 m)
IP Rating:	IPX4
Net weight:	approx. 15.8 oz (450 g)
Dimensions (L x W x H):	approx. 7.4 x 2.3 x 2.6 in (189 x 58 x 65 cm)

English

Français

Deutsch

Italiano

Español

Nederlands

日本語

Feedback and Help

Love it? Hate it? Let us know with a customer review.

AmazonBasics is committed to delivering customer-driven products that live up to your high standards. We encourage you to write a review sharing your experiences with the product.



US: amazon.com/review/review-your-purchases#

UK: amazon.co.uk/review/review-your-purchases#






US: amazon.com/gp/help/customer/contact-us

UK: amazon.co.uk/gp/help/customer/contact-us

Guide de Démarrage • Français

Contenu : Avant de commencer, veuillez vous assurer que l'emballage contient les composants suivants :





A Enceinte

B Prise AUX IN
(Entrée auxiliaire)

C Bouton de
réinitialisation

D Port USB Micro B

E Câble USB

F Voyant d'état

G Interrupteur Marche/
Arrêt

H Touche de réduction
du volume

I Touche lecture/pause/
appel

J Touche d'augmentation
du volume

K Touche Bluetooth®

L Microphone

REMARQUE

Pour conserver les propriétés
antiprojection de ce produit, gardez le
volet latéral fermé.

MESURES DE SÉCURITÉ IMPORTANTES



Veuillez lire attentivement les présentes instructions et les conserver afin de pouvoir vous y référer ultérieurement. En cas de cession de ce produit à un tiers, le présent manuel d'utilisation doit également lui être remis.

Lorsque vous utilisez des appareils électriques, vous devez toujours prendre des mesures de sécurité de base afin de réduire tout risque d'incendie, d'électrocution et/ou de blessures corporelles. Ces précautions incluent notamment les suivantes :

- Veuillez lire les présentes instructions.
- Veuillez conserver les présentes instructions.
- Veuillez respecter l'intégralité des instructions.
- Pour éviter les chutes accidentelles dans les piscines, baignoires ou autres installations contenant de l'eau, ne pas la placer sur le bord.
- Ne pas installer le produit à proximité de sources de chaleur, notamment radiateurs, bouches de chaleur, poêles ou tout autre appareil (comprenant les amplificateurs) qui dégage de la chaleur.
- Confiez tout entretien du produit à du personnel qualifié.

- Aucune source de flamme nue, telle que des bougies allumées, ne doit être posée sur le produit.
- Ce produit ne peut être utilisé que dans des climats tempérés. Ne l'utilisez pas dans des régions au climat tropical ou particulièrement humide.



Afin de prévenir toute altération éventuelle de l'ouïe, n'écoutez pas de la musique à un volume élevé de façon prolongée.

Avertissements Relatifs aux Batteries



AVERTISSEMENT

Les batteries ne doivent pas être exposées à une source de chaleur excessive telle que la lumière directe du soleil, le feu ou autre.

- La batterie contenue dans ce produit n'est pas remplaçable. Ne pas incinérer le produit.
- Avant de procéder à la mise au rebut, la batterie doit être retirée du produit. Contactez un professionnel qualifié.
- Ne pas laisser la batterie en charge pendant une période prolongée lorsque le produit n'est pas utilisé.
- Ne pas recharger le produit de nuit.

- Si le produit semble bombé ou présente d'autres signes anormaux (comme un surcroît de bruit), cessez immédiatement de l'utiliser.
- Ne faites pas tomber ce produit.
- Ne pas couvrir le produit pendant le chargement.
- Rechargez ce produit une fois tous les 3 mois afin de ne pas réduire la durée de vie de sa batterie.
- Les batteries produisent de la chaleur lors du chargement et du déchargement. Si le produit devient trop chaud au toucher, mettez-le hors tension, puis débranchez-le immédiatement.
- Ne rechargez ce produit qu'avec une source d'alimentation compatible, comme un adaptateur secteur provenant d'un fabricant réputé fiable.
- En cas de fuite de la batterie, évitez tout contact avec la peau et les yeux. Rincez immédiatement et abondamment les zones affectées à l'eau propre, puis consultez un médecin.

Signification des Symboles



Ce symbole signifie « Conformité Européenne ». En apposant le marquage CE, le fabricant confirme que ce produit est conforme aux directives et réglementations européennes en vigueur.



Courant continu (CC).

IPX4

Protégé contre l'eau projetée de toutes les directions. Ne pas immerger dans l'eau.

Utilisation Prévue

- Ce produit est exclusivement destiné à un usage domestique. Il n'est pas conçu pour un usage commercial.
- Ce produit est destiné à être utilisé à l'intérieur comme à l'extérieur. Il est protégé contre les projections d'eau provenant de toutes les directions. Ne pas immerger dans l'eau.
- Toute responsabilité sera déclinée en cas de dommages résultant d'une utilisation incorrecte de l'appareil ou du non-respect de ces instructions.

Avant La Première Utilisation

- Vérifiez que le produit ne présente aucun dommage dû au transport.



DANGER

Risque d'étouffement ! Maintenez tous les matériaux d'emballage hors de la portée des enfants. Ces matériaux constituent une source de danger potentiel comme l'étouffement.

Utilisation

Charger la batterie intégrée

- Lorsque le message vocal « Low Battery » (batterie faible) se fait entendre, le produit doit être chargé.
- Branchez le câble USB (E) au port USB Micro B (D).
- Connectez l'autre extrémité du câble USB (E) à un port USB A d'un ordinateur ou à un adaptateur secteur 5 V $\equiv$ 2 A adapté. Le voyant d'état (F) clignote en rouge pendant le chargement.
- Lorsque le produit est complètement chargé, le voyant d'état (F) cesse de clignoter.

Mise sous/hors tension

Pressez et maintenez pressé l'interrupteur marche/arrêt (G) pour mettre sous/hors tension.

Des messages vocaux se déclenchent en conséquence pour chaque étape.

REMARQUE

Le produit s'éteint automatiquement après environ 20 minutes d'inactivité.

Mode appariement

REMARQUE

L'appariement Bluetooth® est nécessaire si l'enceinte est utilisée pour la première fois avec un nouvel appareil compatible Bluetooth®.

- Après la mise sous tension du produit, le voyant d'état clignote lentement en bleu pendant environ 12 secondes. Après quoi, le produit passe automatiquement en mode appariement.
- Si le produit ne démarre pas automatiquement le mode appariement, pressez la touche Bluetooth® (K) pour accéder au mode appariement. Le voyant d'état clignote en bleu.
- Activez la fonction Bluetooth® sur l'appareil que vous souhaitez appairer, puis recherchez un nouveau périphérique.



- Sélectionnez le nom de l'appareil Bluetooth® dans la liste de l'appareil à appairer.

Référence du modèle :	Nom de l'appareil Bluetooth® :
B07PDYW6VM B07PLCY3PV B07PJ67Q7Z	AmazonBasics WP926
B07PKBTB4X B07PH2HVGGM B07PKBWYRT	AmazonBasics WP927

- Une fois les appareils appariés, le voyant d'état (F) s'allume en bleu.

Déconnexion du Bluetooth®

Pressez et maintenez pressée la touche Bluetooth® (K) pour déconnecter l'appareil apparié.

REMARQUE

Le produit tente continuellement de rétablir une connexion Bluetooth® perdue. S'il n'y parvient pas, rétablissez manuellement la connexion via le menu Bluetooth® de l'appareil.

Mode entrée auxiliaire

Branchez un câble audio avec jack de 3,5 mm (non fourni) entre la prise AUX IN (B) et le lecteur choisi comme un lecteur MP3.

Lecture de musique

 : Pressez pour lire ou mettre en pause la lecture.

 : Pressez pour passer à la piste suivante.

 : Pressez pour passer à la piste précédente.

Appels

 : Pressez pour prendre ou clore un appel.

 : Pressez et maintenez pressé pour rejeter un appel.

Commande de volume

REMARQUE

Le volume de la lecture est ramené au volume intermédiaire après chaque démarrage.

⊕ : Pressez et maintenez pressé pour augmenter le volume.

⊖ : Pressez et maintenez pressé pour réduire le volume.

Réinitialisation (Retour aux paramètres d'usine)

Si le produit ne fonctionne pas correctement, appuyez sur le bouton de réinitialisation (C) avec un objet pointu (comme un trombone) pour revenir aux paramètres par d'usine par défaut.

Nettoyage et Entretien

REMARQUE

Mettez le produit hors tension avant le nettoyage.

REMARQUE

Pendant le nettoyage, ne pas plonger les composants électriques du produit dans l'eau ni dans tout autre liquide. Ne jamais exposer le produit à l'eau courante.

- Nettoyez le produit en l'essuyant à l'aide d'un chiffon doux légèrement humide.
- Ne jamais utiliser de détergents corrosifs, de brosses métalliques, de lavettes abrasives ou d'ustensiles tranchants ou en métal pour nettoyer le produit.

Énoncé d'Industrie Canada (IC)

- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
 - (1) l'appareil ne doit pas produire de brouillage, et
 - (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- Cet équipement est conforme à l'exposition aux rayonnements Industry Canada limites établies pour un environnement non contrôlé.
- Cet appareil numérique de Classe B est conforme à la norme canadienne CAN ICES-3(B) / NMB-3(B).

Déclaration UE de Conformité Simplifiée

- Le soussigné, Amazon EU Sarl, déclare que l'équipement radioélectrique du type B07PDYW6VM, B07PLCY3PV, B07PJ67Q7Z, B07PKBTB4X, B07PH2HVGGM, B07PKBWYRT est conforme à la directive 2014/53/UE.
- Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante : <https://www.amazon.fr/marque-privée-amazon-conformite-EU>

Mise Au Rebut



La directive relative aux déchets d'équipements électriques et électroniques (DEEE) vise à réduire au minimum l'impact des produits électriques et électroniques sur l'environnement, en augmentant la réutilisation et le recyclage et en réduisant la quantité de DEEE mis en décharge. Le symbole figurant sur ce produit ou sur son emballage signifie que ce produit doit être mis au rebut séparément des ordures ménagères ordinaires en fin de vie. Gardez à l'esprit que la responsabilité vous incombe de mettre au rebut les équipements électroniques dans des

centres de recyclage afin de contribuer à la préservation des ressources naturelles. Chaque pays doit disposer de centres de collecte dédiés au recyclage des équipements électriques et électroniques. Pour plus d'informations sur les zones de recyclage de votre localité, veuillez contacter les autorités responsables de la gestion des déchets d'équipements électriques et électroniques de votre commune, votre mairie ou le service local de traitement des ordures ménagères.

Mise au Rebut des Batteries



Ne mettez pas au rebut les batteries usagées avec vos déchets ménagers. Déposez-les à un point de collecte approprié.

Marques

Le nom et les logos Bluetooth® sont des marques commerciales enregistrées appartenant à Bluetooth SIG, Inc. et toute utilisation desdites marques par Amazon.com, Inc. ou ses filiales leur est concédée sous licence.



Caractéristiques

Référence du modèle :	B07PKBTB4X B07PH2HVGMM B07PKBWYRT
Entrée :	5 V $\overline{=}$ 2 A, batterie au lithium 3,7 V, 4 400 mAh
Fréquence de fonctionnement :	de 2 402 à 2 480 MHz
Puissance de RF :	4 dBm
Temps de chargement :	4 heures
Consommation électrique :	Max. 9 W
Réponse en fréquence :	de 70 Hz à 20 kHz
Sensibilité :	-3,9 dB
Impédance :	D = 4 Ω , G = 4 Ω
Version Bluetooth®	4,2
Distance de fonctionnement (portée) :	32, 8' (10 m)
Indice de protection :	IPX4
Poids net :	env. 12,2 oz (346 g)
Dimensions (L x l x H) :	env. 7 x 1,8 x 2,3 po (178 x 45 x 58 mm)

Caractéristiques

Référence du modèle :

B07PDYW6VM
B07PLCY3PV
B07PJ67Q7Z

Entrée :

5 V $\overline{\text{---}}$ 2 A, batterie au lithium 7,4 V, 2 200 mAh

Fréquence de fonctionnement :

de 2 402 à 2 480 MHz

Puissance de RF :

4 dBm

Temps de chargement :

3 heures

Consommation électrique :

Max. 15 W

Réponse en fréquence :

de 50 $\pm$ 20 Hz à 20 kHz

Sensibilité :

-5,2 dB

Impédance :

D = 8 Ω , G = 8 Ω

Version Bluetooth®

4,2

Distance de fonctionnement (portée) :

32, 8' (10 m)

Indice de protection :

IPX4

Poids net :

env. 15,8 oz (450 g)

Dimensions (L x l x H) :

env. 7,4 x 2,3 x 2,6 po
(189 x 58 x 65 cm)