



SAFETY & CARE INSTRUCTIONS

Do NOT expose any portion of this product to liquid, humidity, moisture, sharp objects or extreme temperatures as this can damage the product and void the warranty.
Do NOT attempt to modify or disassemble in any way.
Spot Clean ONLY.
Only power with the provided cable.

CONTENTS:
Multifunction Speaker, Charging cable, User manual

SPECIFICATIONS:
Bluetooth Version 5.3
Output Power: 2 x 5W
Speaker Unit: 70mm
Battery Capacity: 1,200mAh
Music Play Time: 5-6 hours at 30% volume
Charging Time: 3-4 Hours
Wireless Range: 33ft/10m
Waterproof Rating: IPX4
Speaker Functions:
Bluetooth, FM Radio, MicroSD Slot,
True Wireless Connectivity
Frequency Range: 20Hz-20KHz
Frequency Response: 80Hz-15KHz
FM Radio Frequency: 87.5-108MHz
Type C Cable Included: Rechargeable
Material: ABS + Fabric
Product Size: 330 x 133 x 173mm



HOW TO USE SPEAKER:
CHARGING & POWERING ON:

- 1. Use the included USB cable to fully charge the speaker for a minimum of 4 hours before first use. When charging, the LED indicator light will be on. Once fully charged, the LED indicator will turn off.
- 2. Press and hold the ON/OFF button for 3 seconds to turn the speaker on or off.

BLUETOOTH PAIRING
WITH YOUR DEVICE

- 1. Once powered on, the speaker will automatically go into PAIRING MODE.
- 2. Pairing mode will last for 5 minutes. While in pairing mode, turn on the Bluetooth connection on your device, Scan/Search & select 'CRUISIN XL SPEAKER'.
- 3. Once paired, successfully speaker will voice prompt 'CONNECTED'.

TRUE WIRELESS MODE
CONNECTING TWO CRUISIN' XL SPEAKERS

- 1. Turn both speakers on at the same time and keep in default Bluetooth Mode.
- 2. Press and hold the LED lights button on ONE of the speakers to enter True Wireless Mode.

3. The speakers will then voice-prompt that they have been connected to each other and will sync the audio being played.

HANDS-FREE FUNCTION

NOTE: When in Bluetooth mode, the music will automatically pause when there is an incoming call. Once the call has ended, the music will resume automatically.

FM RADIO MODE

Charging cable must be connected to the charging port of the Speaker during use, Press Once the "M" Mode button to switch to the Radio Mode. Once Radio mode is selected, Press & Hold for 2 Seconds "Pause" button to scan available FM radio stations (please allow 1-2 minutes for the initial scan to be completed, the scan is complete once it remains on one radio station), and then use the "+" and "-" buttons to scroll through the available FM radio stations.

PREVIOUS SONG

Press & Hold for 2 seconds

NEXT SONG

Press & Hold for 2 seconds

PLAY/ PAUSE

Press Once

MODE

Press Once

POWER ON/OFF

Press & Hold for 3 seconds

FM MODE

Press & Hold for 2 seconds

LED LIGHTS

Press Once

VOLUME DOWN

Press Once

VOLUME UP

Press Once

ANSWER CALL

Press Once

END CALL

Press Once

REDIAL LAST CALL

Press Twice

REJECT CALL

Press & Hold for 2 seconds

FCC ID: 2BKTL-XLCRU01



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which

can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This equipment should be installed and operated with minimum distance **5mm** between the radiator and your body.

TECHNICAL SUPPORT &
WARRANTY INFO

This product is backed by a One Year Warranty from any defects. For warranty replacements, questions or if you have any issues about this product, contact us at help@SimplyTechCorp.com.
SimplyTech Electronics Inc declared that radio equipment is compliant with Directives 2014/53/EU, 2011/65/EU & 2012/19/EU.
EU Declaration of Conformity for this product can be viewed at www.SimplyTechCorp.com/docs.
DISTRIBUTED BY: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018
MADE IN CHINA
Please read before using this product and retain manual for future reference.



SICHERHEITS- UND PFLEGEHINWEISE

Setzen Sie keinen Teil dieses Produkts Flüssigkeiten, Feuchtigkeit, scharfen Gegenständen oder extremen Temperaturen aus, da dies das Produkt beschädigen und die Garantie ungültig machen kann.
Versuchen Sie NICHT, oder zu ändern irgendwie zerlegen.
NUR Fleckenreinigung.
Stromversorgung nur mit dem mitgelieferten Kabel oder hochwertigen Lithium-Batterien.

INHALT: Multifunktionslautsprecher, Aufladekabel, Benutzerhandbuch

SPECIFICATIONS:
Bluetooth Version 5.3
Output Power: 2 x 5W
Speaker Unit: 70mm
Battery Capacity: 1,200mAh
Music Play Time: 5-6 hours at 30% volume
Charging Time: 3-4 Hours
Wireless Range: 33ft/10m
Waterproof Rating: IPX4
Speaker Functions:
Bluetooth, FM Radio, MicroSD Slot,
True Wireless Connectivity
Frequency Range: 20Hz-20KHz
Frequency Response: 80Hz-15KHz
FM Radio Frequency: 87.5-108MHz
Type C Cable Included: Rechargeable
Material: ABS + Fabric
Product Size: 330 x 133 x 173mm

SO VERWENDEN SIE
DEN LAUTSPRECHER:
LADEN und EINSCHALTEN:

- 1. Verwenden Sie das mitgelieferte USB-Kabel, um es vollständig zu verwendenLaden Sie den Lautsprecher mindestens auf 4 Stunden vor dem ersten Gebrauch. Beim Aufladen, Die LED-Anzeigeleuchte leuchtet. Einmal Wenn der Akku vollständig aufgeladen ist, leuchtet die LED-Anzeige abschalten
- 2. Halten Sie die EIN/AUS-Taste gedrückt 3 Sekunden lang, um den Lautsprecher ein- oder auszuschalten.

BLUETOOTH-PAIRING
MIT IHREM GERÄT

- 1. Sobald der Lautsprecher eingeschaltet ist, funktioniert er automatisch in den PAIRING-MODUS wechseln.
- 2. Der Kopplungsmodus dauert 5 Minuten. Schalten Sie im Pairing-Modus das ein Bluetooth-Verbindung auf Ihrem Gerät. Scannen/suchen und wählen Sie „CRUISIN XL SPEAKER“.
- 3. Nach erfolgreicher Kopplung funktioniert der Lautsprecher Sprachansage „VERBUNDEN“.

ECHTER WIRELESS-MODUS
VERBINDUNG ZWEI CRUISIN' XL -LAUTSPRECHER

- 1. Schalten Sie beide Lautsprecher gleichzeitig ein Zeit und bleiben Sie im Standard-Bluetooth-Modus.
- 2. Drücken und halten Sie die Taste „LED-LEUCHTEN“. Einer der Redner zum Eintreten Echter Wireless-Modus.
- 3. Die Lautsprecher geben dann eine Sprachansage aus dass sie miteinander verbunden warenanderen und synchronisiert den abgespielten Ton.

FREISPRECHFUNKTION

HINWEIS: Im Bluetooth-Modus läuft die Musik automatisch pausieren, wenn es eine gibt eingehender Anruf.
Sobald der Anruf beendet ist, ertönt die Musik automatisch fortfahren.

FM-RADIO-MODUS

Das Ladekabel muss während des Gebrauchs an den Ladeanschluss des Lautsprechers angeschlossen sein. Drücken Sie einmal die Taste „M“, um in den Radiomodus zu wechseln. Sobald der Radiomodus ausgewählt ist, halten Sie die Taste „Pause“ 2 Sekunden lang gedrückt, um die verfügbaren FM-Radiosender zu scannen (bitte warten Sie 1-2 Minuten, bis der anfängliche Suchlauf abgeschlossen ist; der Suchlauf ist abgeschlossen, sobald er auf einem Radiosender verbleibt), und verwenden Sie dann die Tasten „+“ und „-“, um durch die verfügbaren FM-Radiosender zu blättern.

VORHERIGE LIED

2 Sekunden lang gedrückt halten

NÄCHSTE LIED

2 Sekunden lang gedrückt halten

SPIELEN/ PAUSE

Einmal drücken

MODUS

Einmal drücken

POWER ON/OFF

3 Sekunden lang gedrückt halten

FM-MODUS

2 Sekunden lang gedrückt halten

LED-LEUCHTEN

Einmal drücken

LAUTSTÄRKE AB

Einmal drücken

LAUTSTÄRKE AUF

Einmal drücken

ANTWORT ANRUF

Einmal drücken

ENDE ANRUF

Einmal drücken

ANRUF ABWEISEN

2 Sekunden lang gedrückt halten

WIEDERWAHL DES LETZTEN ANRUFES

Zweimal drücken

FCC ID: 2BKTL-XLCRU01



FCC-ERKLÄRUNG :

Dieses Gerät erfüllt die Anforderungen von Teil 15 der FCC-Vorschriften. Der Betrieb unterliegt den folgenden zwei Bedingungen:
(1) Dieses Gerät darf keine schädlichen Interferenzen verursachen, und
(2) Dieses Gerät muss alle empfangenen Interferenzen akzeptieren, einschließlich Interferenzen, die einen unerwünschten Betrieb verursachen können.
Warnung: Änderungen oder Modifikationen, die nicht ausdrücklich von der für die Konformität verantwortlichen Partei genehmigt wurden, können dazu führen, dass der Benutzer die Berechtigung zum Betrieb des Geräts verliert.

HINWEIS: Dieses Gerät wurde getestet und entspricht den Grenzwerten für ein digitales Gerät der Klasse B gemäß Teil 15 der FCC-Vorschriften. Diese Grenzwerte sind so ausgelegt, dass sie einen angemessenen Schutz gegen schädliche Störungen bei der Installation in Wohngebieten bieten. Dieses Gerät erzeugt und verwendet Hochfrequenzenergie und kann diese ausstrahlen.

Wenn es nicht gemäß den Anweisungen installiert und verwendet wird, kann es schädliche Störungen des Funkverkehrs verursachen. Es kann jedoch nicht garantiert werden, dass bei einer bestimmten Installation keine Störungen auftreten. Wenn dieses Gerät Störungen des Radio- oder Fernsehempfangs verursacht, was durch Ein- und Ausschalten des Geräts festgestellt werden kann, sollte der Benutzer versuchen, die Störungen durch eine oder mehrere der folgenden Maßnahmen zu beheben:
Richten Sie die Empfangsantenne neu aus oder stellen Sie sie anders auf.
Vergrößern Sie den Abstand zwischen dem Gerät und dem Empfänger.
Schließen Sie das Gerät an eine Steckdose an, die nicht mit dem Stromkreis des Empfängers verbunden ist.
Wenden Sie sich an den Händler oder einen erfahrenen Radio-/Fernsehtechniker, um Hilfe zu erhalten.

RF-Warnhinweis:
Das Gerät wurde so bewertet, dass es die allgemeinen RF-Expositionsanforderungen erfüllt. Das Gerät kann unter tragbaren Expositionsbedingungen ohne Einschränkungen verwendet werden.

TECHNISCHE HILFE &
GARANTIENINFORMATIONEN

Für dieses Produkt gilt eine einjährige Garantie auf jegliche Mängel. Für Garantieleistungen, Fragen oder wenn Sie Probleme mit diesem Produkt haben, kontaktieren Sie uns unter help@SimplyTechCorp.com.
SimplyTech Electronics Inc. erklärt, dass das Funkgerät mit den Richtlinien 2011/65/EU, 2014/53/EU & 2012/19/EU konform ist.
Die EU-Konformitätserklärung für dieses Produkt kann unter www.SimplyTechCorp.com/docs eingesehen werden.
VERTRIEBEN VON: SimplyTech Electronics, Inc. 1407 Broadway New York, NY 10018
HERGESTELLT IN CHINA
Bitte lesen Sie das Handbuch vor der Verwendung dieses Produkts und bewahren Sie es zum späteren Nachschlagen auf.