

1	Charging/Notification light
2	NFC
3	Power key
4	Fingerprint sensor
5	Volume/Zoom key
6	USB port/Charger

To insert SIM and memory cards



1 Drag out the SIM card tray.
2 Insert the memory card in the correct orientation into the memory card slot.
3 Place the main SIM card (SIM1) securely in the SIM card tray.
4 Place the second SIM card (SIM2) securely in the SIM card tray.
5 Gently push the SIM card tray back into the slot until it fits into place.

To turn on your device

1 Long press the power key until the device vibrates.
2 Wait a moment for the device to start.

To activate the screen

- Briefly press the power key.

Transferring content

For transferring content from an old device to your new device, log in with your Google account and sync your data using services provided by Google. For details visit support.google.com.

For more information

Visit support.sonymobile.com or tap ? to launch the Support app.

! The Support app is not available in all countries and regions.

To view the CE marking and the FCC ID



1 Drag out the SIM card tray.
2 Remove the memory card from its slot.
3 Drag out the label strips simultaneously, as shown in the illustration. To see the full text of the EU declaration of conformity, visit: http://www.compliance.sony.de/.
4 To view the FCC ID, turn over your device. The FCC ID is displayed on the other side of the label strips.

To view the regulatory compliance mark

- Open the phone dialer, then enter *#07#.

Warranty, SAR and usage guidelines

For information about warranty, SAR (Specific Absorption Rate) and safety guidelines, please read the Important information provided under **Settings** > **System** > **About phone** > **Legal information** on your device.

Legal information

Publication number: 1318-1994.1
This Startup guide is published by Sony Mobile Communications Inc. or its local affiliated company, without any warranty. Improvements and changes to this Startup guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications Inc. at any time and without notice. Such changes will, however, be incorporated into new editions of this Startup guide. All illustrations are for illustration only and may not accurately depict the actual device.
See regulatory information such as the device CE marking in the relevant label strip in the device.
All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved. Visit https://www.sonymobile.com/global-en/legal/ for more information.
Manufacturer: Sony Mobile Communications Inc., 4-12-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo 140-0002, Japan. For EU product compliance: Sony Belgium, bijkantoor van Sony Europe Limited, Da Vincilaan 7-D1, 1935 Zaventem, Belgium.
Note: Sony Mobile advises users to backup their personal data and information.
Some services are network- or subscription-dependent. Please contact your network operator or our call centre for details.
©2019 Sony Mobile Communications Inc. All rights reserved.

Supported frequency bands

Some frequency bands might be turned off in certain markets or by certain operators.
You can find your model number under **Settings** > **System** > **About phone**.
I4213
UMTS HSPA+ (Bands 1, 2, 5, 8) GSM GPRS/EDGE 850, 900, 1800, 1900 LTE (Bands 1, 2, 3, 5, 7, 8, 20, 28, 32, 38) WLAN, 2.4G/5G, NFC
I4293
UMTS HSPA+ (Bands 1, 2, 5, 8) GSM GPRS/EDGE 850, 900, 1800, 1900 LTE (Bands 1, 2, 3, 5, 7, 8, 20, 28, 38, 39, 40, 41(CH40340–CH41140)) WLAN, 2.4G/5G, NFC
GSM 850/900 : Power Class 4, DCS(1800)/PCS(1900) : Power Class 1, UMTS : Power Class 3, LTE : Power Class 3, 2.4GHz<100mW, 5.15-5.35GHz<200mW, 5.47-5.725GHz<200mW, NFC 13.56MHz

SONY

Startup guide

Xperia 10 Plus
I4213/I4293

XPERIA

CE

1318-1994.1
Printed in XXX (Printers logotype)