

MINISO

USER MANUAL

使用説明書

ICE BRICK SERIES TWS EARPHONES

SÉRIE BRIQUE DE GLACE ÉCOUTEURS TWS

سماعات TWS سلسلة العيوب الجليدية

SERIE LADRILLO DE HIELO

AURICULARES TWS

小冰磚系列TWS藍牙耳機

PMN : TWS EARPHONES

MODEL: S650

使用產品前請仔細閱讀本使用說明書，並請妥善保管。

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY

Product Structure

1. Earphone Touch Button

2. Sound Output Hole

3. Earphone Charging Contact

4. Charging Case LED Light

5. Type-C Port

Accessories

Device*1, User Manual*1, Type-C Charging Cable*1, Medium Ear Tip*2, Big Ear Tip*2

Parameters

BT Version	5.1	Charging Port	Type-C
BT Name	MINISO-S650	Earphone Battery Capacity	30mAh

Music Playback Time

3.5h

Charging Time

1.5h

Transmission Distance

10m

Charging Case Battery Capacity

230mAh

Functions

Function	Charging Case Instructions
Turn On	Take the earphones out of charging case
Turn Off	Put the earphones into charging case
Pairing Mode	For first time connection, open the upper lid charging case, the earphones enter into pairing mode automatically. Search for MINISO-S650 and choose to connect, there is a prompt after the connection successful. The next time you turn on, the earphones will connect automatically with the last device.
Manual Pairing	If the automatic is not successful (single earphone with no sound or the earphones are disconnected), you can do the manual connection. Press the pairing connection record of the phone with earphones, and turn off the phone's Bluetooth, 2. Take the earphones out after putting them into the charging case for 10 seconds, and wait for 5 seconds. 3. Turn on the phone's Bluetooth, and search for MINISO-S650 to connect.
Earphones Instructions	
Play/Pause	Single press on the button of the left or right earphone
Next Track	Press twice the right earphone

Previous Track

Press twice the left earphone

Answer/End Call

Press the left or right earphone

Reject Call

Press the left or right earphone for 2 seconds

Activate Phone's Voice Assistant

Press the left or right earphone for 3 seconds

Indicator Light

Blinks red when charging case is charging, red light turns constantly on when fully charged

Cautions

1. Reasonable control of the volume and time of usage is required to avoid hearing damage.

2. For your safety, do not use in potentially hazardous condition.

3. Do not listen to music, call up or answer the phone while driving to avoid danger caused by distraction.

4. Keep out of reach of children to avoid danger caused by improper use.

5. Do not throw to avoid damage caused by dropping.

6. Do not store under 0°C or above 40°C to avoid shortening the lifespan of earphones and battery.

7. Do not modify, disassemble and repair the product.

8. Irreplaceable battery, it should be disposed of according to local rules or regulations or be recycled by professional institute. Do not throw away or toss it into fire.

9. When not in use for a long time, charge the earphones once every 3 months to extend its service life.

Troubleshooting

1. Wireless earphones fail to be paired with the phone.
Solution: Check if the earphones are in pairing mode, and whether the phone has BT function on. Check the list on your phone, remove earphones from the list, follow the instructions of user manual to pair the earphones with your phone again.

2. Cannot turn on the wireless earphones.
Solution: Check the battery to see if it is low.

3. Can the battery of the wireless earphones be replaced?
Answer: No. The lithium polymer battery in the earphones is irreplaceable.

4. The wireless earphones got disconnected with the phone within 10 meters.
Solution: BT is wireless signal, so it is very sensitive to the surrounding objects that may affect the connection within the effective distance.

5. Cannot hear audio playing when the earphones are connected to the computer or phone.
Solution: Check whether the computer's audio output is already connected to wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.

6. Can I operate the Apps of my phone through the earphones after connecting the wireless earphones to the phone?
Answer: Some apps may not support being operated through the earphones due to their settings.

FCC Warning

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.
FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC Warning

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's radio frequency licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device. The digital apparatus complies with Canadian.

FCC Warning

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Accessoires

Appareil*1, Manuel d'utilisation*1, Câble de Chargement Type-C*1, Embout Moyen*2, Embout Grand*2

Paramètres

Versión BT	5,1	Port de chargement	Type-C
Nom BT	MINISO-S650	Capacité de la batterie de l'écouteur	30mAh
Durée de lecture de la musique	3,5h	Temps de chargement	1,5h
Distance de transmission	10m	Capacité de la batterie de l'étui de chargement	230mAh

Fonctions

Fonction	Instructions sur le Boîtier de Chargement
Activer l'Assistant Vocal du Téléphone	Appuyez sur l'écouteur droit ou gauche pendant 3 secondes
Indicateur Lumineux	Le voyant rouge clignote lorsque le boîtier est en cours de chargement. Le voyant rouge reste allumé en permanence une fois le chargement terminé.

Attention

1. Un contrôle raisonnable du volume et du temps d'utilisation est nécessaire pour éviter les dommages auditifs.

2. Pour votre sécurité, ne l'utilisez pas dans des conditions potentiellement dangereuses.

3. N'écoutez pas de musique, n'appellez pas ou ne répondez pas au téléphone en conduisant pour éviter tout danger dû à une distraction.

4. Maintenez hors de portée des enfants pour éviter tout danger dû à une utilisation incorrecte.

5. Ne le jetez pas pour éviter tout dommage dû à une chute.

6. Ne pas conserver à une température inférieure à 0°C ou supérieure à 40°C pour éviter de réduire la durée de vie des écouteurs et de la batterie.

7. Ne pas modifier, démonter ou réparer le produit.

8. Batterie irremplaçable. Elle doit être mise au rebut conformément aux règles et réglementations locales ou être recyclée par un institut professionnel. Ne la jetez pas et ne le jetez pas au feu.

9. Si vous n'utilisez pas les écouteurs pendant une longue période, rechargez-les tous les 3 mois pour prolonger leur durée de vie.

Résolution des problèmes

1. Les écouteurs sans fil ne peuvent pas être appairés au téléphone.
Solution : Vérifiez si les écouteurs sont en mode d'appairage et si la fonction BT du téléphone est activée. Vérifiez la liste sur votre téléphone, retirez les écouteurs de la liste, suivez les instructions du manuel d'utilisation pour appairer à nouveau les écouteurs avec votre téléphone.

2. Impossible d'allumer les écouteurs sans fil.
Solution : Vérifiez la batterie pour voir si elle est faible.

3. La batterie des écouteurs sans fil peut-elle être remplacée ?
Réponse : Non : Non. La batterie au lithium polymère des écouteurs est irremplaçable. This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.
Cet équipement doit être installé et utilisé à une distance minimale de 0 cm entre le radiateur et votre corps.

الملاحظات

المنفذ 1. "دليل المستخدم" 1. كابل شحن Type-C، طرف سماعة وسط*2

المواصفات

نوع المنتج	5.1	نوع الشحن	TYPE-C
اسم الشركة	MINISO-S650	سعة بطارية السماعة	30 مللي أمبير

وصف المنتج

1. مضاعف قوة السماعة

2. مدخل الصوت

3. منطقة شحن السماعة

الملاحظات

المنفذ 1. "دليل المستخدم" 1. كابل شحن Type-C، طرف سماعة وسط*2

المواصفات

نوع المنتج	5.1	نوع الشحن	TYPE-C
اسم الشركة	MINISO-S650	سعة بطارية السماعة	30 مللي أمبير

Appareil*1, Manuel d'utilisation*1, Câble de Chargement Type-C*1, Embout Moyen*2, Embout Grand*2

Accessoires

Appareil*1, Manuel d'utilisation*1, Câble de Chargement Type-C*1, Embout Moyen*2, Embout Grand*2

Paramètres

Versión BT	5,1	Port de chargement	Type-C
Nom BT	MINISO-S650	Capacité de la batterie de l'écouteur	30mAh
Durée de lecture de la musique	3,5h	Temps de chargement	1,5h
Distance de transmission	10m	Capacité de la batterie de l'étui de chargement	230mAh

Fonctions

Fonction	Instructions sur le Boîtier de Chargement
Activer l'Assistant Vocal du Téléphone	Appuyez sur l'écouteur droit ou gauche pendant 3 secondes
Indicateur Lumineux	Le voyant rouge clignote lorsque le boîtier est en cours de chargement. Le voyant rouge reste allumé en permanence une fois le chargement terminé.

Appareil*1, Manuel d'utilisation*1, Câble de Chargement Type-C*1, Embout Moyen*2, Embout Grand*2

Accessoires

Appareil*1, Manuel d'utilisation*1, Câble de Chargement Type-C*1, Embout Moyen*2, Embout Grand*2

Paramètres

Versión BT	5,1	Port de chargement	Type-C
Nom BT	MINISO-S650	Capacité de la batterie de l'écouteur	30mAh
Durée de lecture de la musique	3,5h	Temps de chargement	1,5h
Distance de transmission	10m	Capacité de la batterie de l'étui de chargement	230mAh

Fonctions

Fonction	Instructions sur le Boîtier de Chargement
Activer l'Assistant Vocal du Téléphone	

[illegible]