TECHNICAL SUPPORT

Monoprice is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website **www.monoprice.com** during regular business hours, 7 days a week. You can also get assistance through email by sending a message to **tech@monoprice.com**

SPECIFICATIONS

Model	1444
Frequency Response	90Hz ~ 20kHz
Bluetooth® Version	2.1
Bluetooth Range	Up to 30 feet
Built-in Battery	400mAh Lithium-ion
Charging Source	Micro USB (5 VDC, 1A)

REGULATORY COMPLIANCE

Radio Notice for FCC

Caution

This FCC Part 15 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Monoprice, including the use of non-approved antennas, could void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radio Notice for Industry Canada

Caution

This IC RSS-210 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Monoprice, including the use of non-approved antennas, could void the user's authority to operate this device.

This device complies with IC RSS-210. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The Bluetooth word mark and logos are registered trademarks of Bluetooth SIG, Inc.

Cables
Computers & Networking
TV Wall Mounts
Audio & Video
Mobile
Camera & Security
Pro Audio & Instruments
Maker & Learning
Gaming

www.monoprice.com

• Product pictures are for reference only.
• Specifications described herein are subject to change without prior notification.
• All trademarks are the sole property of their respective companies.
Copyright © 2016 Monoprice, Inc. All rights reserved.

MONOPRICE

Deep Blue 5 Waterproof 5-Watt Bluetooth® Speaker (IPX4)

P/N 14445

User's Manual

SAFETY WARNINGS AND GUIDELINES

- This speaker is waterproof with an ingress protection rating of IPX4. This means that speaker can withstand the application of "splashing water", consisting of a flow rate of 10 liters per minute, for 5 minutes, at pressures between 50-150kPa (7 to 22 psi). While this means that the speaker is protected from water splashing or rain, it is not protected from more prolonged exposure or from being immersed in water. Do not immerse this product in water.
- Note that this product is only waterproof when the cover for the auxiliary and charging ports is properly secured. Water or moisture getting into either port can cause damage to the product.
- After this device has been exposed to water, it should be thoroughly dried before continued use.
- The device has a protective silicone sleeve, however this does not mean that it is indestructible or drop-proof. Please take care to avoid physical damage to the product.
- Do not subject the product to extreme force, shock, or fluctuations in temperature or humidity.
- Clean using a soft, dry cloth only. Do not use chemical cleaners, solvents, or detergents. For stubborn deposits, moisten the cloth with warm water.
- This device has no user serviceable parts. Do not attempt to open, service, or modify this device.
- Keep away from corrosive materials.
- Charge the battery before first use and at least once every three months.
- This device contains a Lithium-ion battery. Dispose of this device only in accordance with local, state, or federal regulations for electronic waste.

INTRODUCTION

Thank you for purchasing this Deep Blue 5 Waterproof Bluetooth® Speaker!

This speaker features a Bluetooth radio, allowing for wireless connections with your mobile devices. It is waterproof with an IPx4 rating, making it safe for use in all weather conditions.

FEATURES

- Waterproof with an IPX4 rating
- Bluetooth version 2.1 radio
- Up to 30 feet wireless range
- 3.5mm auxiliary input for wired connections
- Built-in rechargeable Lithium-ion battery
- 90Hz ~ 20kHz frequency response

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problem with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website **www.monoprice.com** during normal business hours (Mon-Fri: 5am-7pm PT, Sat-Sun: 9am-6pm PT) or via email at **support@monoprice.com**

PACKAGE CONTENTS

Please take an inventory of the package contents to ensure you have all the items listed below. If anything is missing or damaged, please contact Monoprice Customer Service for a replacement.

1x Deep Blue Waterproof Bluetooth® Speaker

1x Micro USB Charging Cable

1x 3.5mm TRS Stereo Audio Cable

1x User's Manual

CHARGING

This device contains a rechargeable Lithium-ion battery. The battery should be fully charged prior to initial use and at least once every 3 months. Perform the following steps to charge the battery in this speaker.

1. Open the cover seal on the side to reveal the charging port.
2. Using the included Micro USB cable, plug one end into the Micro USB port on the speaker, then plug the other end into a USB power source, such as a computer port or wall charger.
3. An LED next to the charging port will glow red while charging is in progress. When charging is complete, the LED will turn off.
4. When charging is complete, remove the Micro USB charging cable and close the cover seal. Ensure that the seal is fully closed and properly seated to restore the waterproof status.

POWER

- To power the speaker ON, press and hold the Power button for about 3 seconds. The speaker will emit an ascending series of notes.
- To power the speaker OFF, press and hold the Power button for about 3 seconds. The speaker will emit a descending series of notes.

BLUETOOTH® PAIRING

Perform the following steps to pair this speaker with your Bluetooth® enabled mobile device.

1. Press and hold the Power button for about 3 seconds to power the speaker on. The speaker will emit an ascending series of notes.
2. Open the settings on your mobile device, ensure Bluetooth is turned on, then perform a search for nearby Bluetooth devices.
3. When the search is completed, select the MP1554 entry. If you are prompted for a passcode, enter 0000 (four zeroes). A chime will sound, indicating that pairing is successful.

AUXILIARY INPUT

To use the speaker with non-Bluetooth® enabled devices, you can use the included audio cable to connect the headphone output of your device to the auxiliary input on the speaker. Perform the following steps to use a wired connection.

1. Open the cover seal on the side to reveal the 3.5mm auxiliary input.
2. Using the included 3.5mm audio cable, plug one end into the auxiliary input on the speaker, then plug the other end into the headphone output on your mobile device. The Bluetooth radio is disabled whenever a cable is plugged into the speaker's auxiliary input.
3. When you are finished, unplug the audio cable from the speaker and close the cover seal. Ensure that the seal is fully closed and properly seated to restore the waterproof status.