HeimVision

CUSTOMER SUPPORT

North America	support-us@heimvision.com
United Kingdom	support-uk@heimvision.com
Deutschland	support-de@heimvision.com
France	support-fr@heimvision.com
Italia	support-it@heimvision.com
España	support-es@heimvision.com
日本	support-jp@heimvision.com

HeimVision

A805 Smart Wake-Up Light
User Manual

ENGLISH 01-18
日本語 19-35

Please read this manual carefully before use and keep it for your future reference.

Front

ENGLISH

WARNING

To reduce the risk of Fire, Electric Shock, or Injury to Persons:
1. This appliance is only intended for household use, including similar use in hotels.
2. Place this appliance on a stable, level and non-slippery surface.
3. Do not use this appliance in an unsafe surrounding (e.g. in the bathroom or near a shower or swimming pool.)
4. Do not use this appliance outdoors.
5. Do not let water run into the appliance or spill water onto the appliance.
6. Only use the original adapter. Do not use the other adapter if they are damaged.
7. Unplug the power cord from the switch. To disconnect the appliance from the power source, remove the the plug from the wall socket.
8. Do not use this appliance as a means to reduce your hours of sleep. The purpose of the appliance is to help you wake up more easily. It does not diminish your need for sleep.

STORAGE

1. Clean the appliance with a silk cloth.
2. Do not use abrasive cleaning agents, acids or cleaning solvents like alcohol, acetone, etc., as this might damage the surface of the appliance.
3. If the appliance will not be used for an extended period of time, remove the power cord from the wall outlet and store the appliance in a safe, dry surroundings where it will not be crushed, banged, or subject to damage.

OVERVIEW

① Alarm Clock 1
② Alarm Clock 1
③ Snooze Button
④ LED Light
⑤ Up Button
⑥ Snooze Button
⑦ Volume +
⑧ Radio
⑨ Volume -
⑩ Sleep Timer
⑪ Setting Button
⑫ USB Output
⑬ FM Antenna
⑭ Micro USB Input
⑮ Speaker
⑯ Button Battery

OPERATION GUIDE

First use: setting the clock time
You have to set the clock time when you plug in the appliance for the first time.

Set the time

Plug in the power and start setting.

Press ⏻ for 3 seconds to set the hour. Hour flashes to indicate the hour time begins to blink.

Press ⏻ again to confirm the hour and move to the minutes.

Use ◀◀ or ▶▶ to adjust the hour.

Use ◀◀ or ▶▶ to adjust the minutes.

Press the ⏻ again to confirm the minutes and move to the time format.

Note: When the 12-hour time format is selected, PM or AM will be displayed.

Setting Alarm Clock

You can set the alarm clock for the wake-up light. (Note: clock 1 & clock 4 can only be set on APP). Take clock 1 setting as an example.

1. In time mode, press ⏻ to enter on alarm, the alarm symbol appears on the display and the alarm hour is set. And brightness when you turn off the alarm.

2. Press ⏻ for 3 seconds and the time hour begins to blink, and use ◀◀ or ▶▶ to adjust the hour time.

3. Press ⏻ again to confirm the hour and move to the minutes, and use ◀◀ or ▶▶ to adjust the minutes.

4. Press ⏻ again to confirm the minutes and move to the alarm mode, and use ◀◀ or ▶▶ to adjust your choice. You can choose between 7 pre-set sounds or FM radio as a wake-up sound.

5. Press ⏻ to confirm and return to the clock mode.

6. Press ⏻ touch once to confirm the alarm sound and move to set the wake-up sound volume, and press ◀◀ or ▶▶ to adjust the volume.

7. Press ⏻ for 3 seconds and return to the clock mode. Alarm symbol appears on the display when the alarm is set.

Note: When the alarm is set, the light will turn on by the preset brightness level 30% more during off-night. Set the light time to OFF when you do not need a light to wake up.

SWITCHING THE LIGHT ON/OFF

You can adjust the display type: Sunrise Light OR Colorful Light

Sunrise Light:



Press ⏻ to turn on/turn off Sunrise Light.

Press ◀◀ or ▶▶ to adjust the light intensity.

Colorful Lights:
Double-click ⏻ to turn on/turn off colorful lights, and six automatic modes.
Press ◀◀ or ▶▶ switch manual modes.
Long press ◀◀ or ▶▶ switch to automatic mode again.

SWITCHING THE FM RADIO ON/OFF

Press ⏻ for 3 seconds to turn on automatic search mode in your first use, the radio will automatically scan radio frequencies and save the frequency of P1, P02...

SNOOZING

When alarm clock goes off, press ⏻ to enter snooze state, you can go on more 9 minutes of sleep time.
Note: snooze up to 5 times.

*When alarm clock goes off (or snooze state), press the corresponding alarm clock button to turn off light and sound.
*When alarm clock goes off, if there aren't any operations within 10 minutes, it will turn off lights and sound automatically.

OPERATION GUIDE

Turn on radio
In time mode, press ◀◀ or ▶▶ to switch to clock off FM radio. Long press ◀◀ or ▶▶ for three seconds to set FM automatic search, press ◀◀ or ▶▶ to set radio volume.
Turn off radio
In radio mode, press ⏻ to turn off FM radio.
Note: To get a good radio signal, fully extend antenna and move it around until you receive the best reception.

SETTING THE SLEEP TIMER

Press ⏻ to enter sleep time

Long press ◀◀ or ▶▶ to set the sleeping light, and press ⏻ to confirm the sleeping light.

Press ◀◀ or ▶▶ to set the sleeping time, and press ⏻ to confirm the sleeping time.

Press ⏻ 60 min to set for sleeping music and press ⏻ to confirm. Sleeping music will be turned on by the FM radio as a sleeping sound. FM radio will automatically turn off after 60 minutes.

Press ⏻ 30 min time to set the sleeping light, the light will slowly turn from the preset brightness level to dark, and the light will turn off at the end of the preset time.
Leave for about 10 seconds to confirm selected option.

CONNECTING YOUR MOBILE DEVICE

1. Download Smart Life into your mobile device from App Store/ Google Play or by scanning QR code.



Android 8.0+ or iOS 11.0+ Scan for Video Instruction

2. Create an Account and Log in

3. Add Device & Connect WIFI

Tap the + in the upper right corner or Add Device

Power on the light and hold for 3 Seconds rapidly

Tap the Confirm indicator rapidly has been switched quickly, and then tap Next

Select your own 2.4 GHz WiFi and input password

Wait for connecting

Create a name for your wake-up light

4. How to Operate the Light via Smart Life

APP Operation Panel

A. Click ⏻ to set the time of the wake-up light and home display brightness

Please make sure you have setup the Network, sync time, otherwise alarm settings might not trans-unite.

B. Click ⏻ to set the four alarm clocks

5. Click ⏻ to choose the light display type and adjust the light intensity

6. Click ⏻ to turn on/turn off the FM radio, and choose the frequency you want.

7. Click ⏻ to set the snoozing duration.

8. Click ⏻ to set the snooze mode and create your Sleep Aid.

HOW TO CONNECT WITH AMAZON ALEXA

1.Download Amazon Alexa and sign in your Amazon account.

2. Select **Skills & Games**, search **Smart Life**, and **ENABLE TO USE** it.

3. Login your "Smart Life" account, then **Authorize** and close the **successfully linked** page after it is connected successfully to enter **Discover Devices** page.



3. Discover Devices

This wake-up light works with Alexa, through this skill, Amazon Alexa will find and list devices you originally added in Smart Life App.

Note:
If your Smart Life account was linked to Alexa before and find devices by following steps:

HOW TO CONNECT WITH GOOGLE HOME

1.Download **Google Home** and sign in your google account.

2. Login your "Smart Life" account, then **Authorize** and close the **Accounts now linked** page after it is connected successfully to enter **Choose Device** page. Then you can control the wake-up light via Google Home after complete setting.

TROUBLE SHOOTING

You cannot activate the most common problems you could encounter with the **Wake-Up Light**. If you are unable to solve the problem with the information below, please feel free to contact **support@heimvision.com** for assistance.

Q1. The appliance does not work at all.
- Check if the power cord is correctly connected to the wall outlet. Plug the adapter properly in the wall outlet.
- Perhaps there is a power failure. Check if the power supply works by connecting another appliance.

Q2. What should I do when I cannot link the Wake-Up Light with the Smart Life App?
- Check if the **Wake-Up Light** is powered on.
- Make sure your mobile device is connected to the 2.4GHz Wi-Fi Network.
- Make sure the password of your Wi-Fi network entered in **Smart Life App** correct when linking **Wake-Up Light**.
- Make sure the **Wake-Up Light** is ready for linking. Use the Wi-Fi indicator flashes quickly. If not, please press the Snooze button (about 10 seconds) until the Wi-Fi indicator begins to flashes rapidly.

Q3. Why did I fail to set the alarm clock to ring only on weekdays?
- Please turn on the **Network auto-time** in the setting interface of **Smart Life App**. Make you can set the alarm clock according to your needs.

Q4. The radio produces a crackling sound.
- Perhaps the broad.cast signal is weak. please fully extend antenna and move it around until you receive the best reception.

Q5. How can I set the alarm 2 and alarm 3?
- Alarm 2 & Alarm 3 can only be set in **Smart Life App**

Q6. Could I completely turn off the time display?
- Yes,you could turn it off in the setting interface in **Smart Life App**

Q7. The light wakes up too early.
- Please adjust the wake-up time with a test appropriate for you. You can try a lower light level.

Q8. The light wakes up too late.
- Please adjust the wake-up time with a test appropriate for you. You can try a lower light level.
- Make sure the **Wake-Up Light** is located at a height at which the light is not blocked by your bed, comforter, pillows or any other things.

WARRANTY

30-Day Money-Back Guarantee for Any Reason
If you're not satisfied with your purchase within 30 days of purchase to receive a FULL REFUND for any reason. But if the reason for return isn't quality related, the customer must pay for the return shipping.

24-Month Warranty for Quality-Related Issues
HeimVision warrants its products to be free from defects in material and workmanship, under normal use, during the warranty period. Within 24 months, HeimVision will provide a replacement unit (new) any return shipping costs for products that fail in normal use.

日本語

警告

火災、感電または人身への傷害の危険を減らすために:
1.本製品は、屋内使用のみを目的としています。
2.本製品は、安定した水平な滑り止めのある表面に置いてください。
3.この製品を危険な環境で使用しないでください。(浴室やプールの近くなど)
4.アダプターが傷んでいるときは使用しないでください。
5.アダプターに水をこぼしたり、水をかけたりしないでください。
6.付属の純正アダプターのみを使用してください。
7.電源コードをスイッチからアンプラグしてください。電源から本製品を完全に切り離すには、壁のコンセントからプラグを抜いてください。
8.本製品は睡眠時間を減らす機能ではありません。本製品の目的は、より簡単に目覚めるのを助けることです。本製品は睡眠の必要性を減らすものではありません。

お手入れ

- 柔らかい布で本製品を拭きます。
- 上物用そうな研磨剤、酸は、アルコール等の溶剤は使用しないでください。また本製品に強力な洗浄剤などをかけないでください。
- 上物は本来用途で長い期間は、電源コードをコンセントから抜いて、乾いた、物理を与えない、破損しないように、安全で乾燥した場所に保管してください。

概観



① 時計 1 アラーム
② 時計 2 アラーム
③ スヌーズ
④ ライト
⑤ ダウン
⑥ スヌーズ
⑦ ボリューム +
⑧ ラジオ
⑨ ボリューム -
⑩ スリープ
⑪ 設定ボタン
⑫ USB出力ポート
⑬ FMアンテナ
⑭ Micro USB入力ポート
⑮ スピーカー
⑯ ボタン電池

*ボタン電池について
- アプリの初期設定には電池が必要です。電池を取り出さないでください。
- アラーム1&4は、アプリでのみ設定可能です。
- アラーム2&3は、音楽のみ、時間は1分単位で設定できます。

操作ガイド

最初の使用 – 時刻表示設定
電源プラグを差し込んだ後、時刻を設定する必要があります。アプリ本体のみで本機の全時間の設定が可能です。最初の設定

時刻表示設定

電源を入れて設定を開始します。

⏻ を 3 秒間押して時刻設定モードに入ります。時間が点滅します。

⏻ を1回押して時刻を確定し、分の設定へ移ります。

◀◀ または ▶▶ で時間を設定します。

◀◀ または ▶▶ で分を設定します。

⏻ を1回押して確定し、12時間表示モードを設定します。

注意: 12時間制を選択した場合は、PMまたはAMが表示されます。

目覚し時間の設定

⏻ を3秒間押して、アラーム1の設定モードに入ります。時間が点滅します。

⏻ を1回押して時刻を確定し、分の設定へ移ります。

◀◀ または ▶▶ で時間を設定します。

◀◀ または ▶▶ で分を設定します。

⏻ を1回押して確定し、アラーム音の設定へ移ります。

◀◀ または ▶▶ でアラーム音を選択します。

⏻ を1回押して確定し、音量の設定へ移ります。

◀◀ または ▶▶ で音量を調整します。

⏻ を1回押して確定し、アラーム1の設定を終了します。

アラーム1を解除するには、もう一度 ⏻ を3秒間押します。

アラーム2&3の設定は、アプリでのみ可能です。

スヌーズ

アラーム音が鳴っているときに ⏻ を1回押すと、スヌーズモードに入ります。9分間の睡眠時間を追加できます。
スヌーズは最大5回まで使用できます。

*アラーム音が鳴っているとき(またはスヌーズモード中)、対応するアラーム音ボタンを押すと、アラームが停止します。

*アラーム音が鳴っているとき、10分間操作がない場合、ライトとアラーム音は自動的にオフになります。

点灯・消灯の設定

日常起こすライトの種類: 日の出の光をカラフルなライトモード

⏻ を押して日の出の光をカラフルなライトモードに切り替えます。

◀◀ または ▶▶ で明るさを調節します。

カラフルなライトモード
⏻ を2回押すと、カラフルなライトモードに切り替えます。
◀◀ または ▶▶ で6つのモードを選択します。

FMラジオ

初めてご使用する際は、⏻ を3秒間長押しすると、FMモードが自動的に起動し、オートサーチを開始します。周波数P1、P02...

操作ガイド

ライトを消す
⏻ を2回押すと、カラフルなライトモードを消すことができます。ライトモードの点灯を維持する場合は、何もせずに放置してください。

ご注意:
正しい時刻を表示するにはアプリでタイムゾーンと、最新の現在時刻を設定する必要があります。

スリープタイマーの設定

⏻ を3秒間長押しすると、スリープタイマーの設定モードに入ります。

◀◀ または ▶▶ で時間を設定します。

⏻ を1回押して確定し、音楽の設定へ移ります。

◀◀ または ▶▶ で音楽を選択します。

⏻ を1回押して確定し、音量の設定へ移ります。

◀◀ または ▶▶ で音量を調整します。

⏻ を1回押して確定し、スリープタイマーの設定を終了します。

スリープタイマーを解除するには、もう一度 ⏻ を3秒間長押しします。

設定中は何の操作も行わない場合、自動的に確定され、設定終了となります。

モバイルデバイスと接続

1. APP Store または Google Play で「Smart Life」をインストールするか、右のQRコードをスキャンします。

2. 登録します。

3. デバイスの追加&Wifiの接続

⏻ を5秒以上長押しすると、ライトがWi-Fiの高速点滅モードに入ります。

Wi-Fiの高速点滅を確認したら、次へをタップします。

2.4GHz Wi-Fiネットワークを選択し、パスワードを入力します。

ライトが点滅している間に、次へをタップします。

デバイスが追加されるまでお待ちください。

デバイスに名前を付けます。

4. 「Smart Life」アプリで自在まとライトを制御

APP操作パネル

A. ⏻ をタップして時刻と明るさの調整をします。

B. ⏻ をタップして4つのアラームを設定します。

C. ⏻ をタップしてライトの種類と明るさを調整します。

D. ⏻ をタップしてFMラジオのON/OFFを切り替えます。

E. ⏻ をタップしてスヌーズモードを設定します。

F. ⏻ をタップしてスリープモードを設定します。

G. ⏻ をタップしてスリープ時間を設定します。

H. ⏻ をタップしてスリープ音楽を設定します。

ご注意: 自動ロックボタンを押すとロックされます。

AMAZON ALEXAと接続

1. Amazon Alexaをダウンロードして、お持ちのアマゾンアカウントを登録します。

2. 「スキル&ゲーム」を探し、「Smart Life」を検索して選び「ENABLE TO USE」を選びます。

3. 「Smart Life」に登録して**許可**を選びます。**接続成功**のページが出ますまで、完了と表示してDiscover Devicesページに入ります。

3. デバイスを追加(DISCOVER DEVICES)

Alexa Smart Life スキルが正常にリンクされました。Alexaアプリで検出して、Alexaは「Smart Wi-Fi ライト」を検出しました。

GOOGLE HOMEと接続

ご注意:
Google Homeアプリは2.56以降のバージョンをお使いください。

1. Google Homeをダウンロードしてログインします。

ホームをタップしてからあなたの接続にを選択します。

一致度できるホームページに戻り、「設定」>「その他の設定」にスクロールします。

Wi-Fiを2.4GHzに接続してください。

2.アシスタントタブで「ホーム」を選び、「+」をタップしてデバイスを追加します。「Smart Life」アプリを検索します。

初めてGOOGLE HOMEを利用する場合

1. Google Homeをダウンロードし、ログインします。

ホームをタップしてからあなたの接続にを選択します。

一致度できるホームページに戻り、「設定」>「その他の設定」にスクロールします。

「Google に接続」をタップします。

1. 「Smart Life」アプリで自在まとライトを追加します。

接続成功のページが出ますまで、完了と表示してDiscover Devicesページに入ります。

メーカー保証

30日間の返金保証
ご購入から30日以内にご満足いただけない場合、全額返金いたします。

2年保証
2年以内に、ハードウェアに問題があるユーザーの不具合がございましたらメーカーまでご連絡ください。

トラブルシューティング

以下のトラブルの問題点がライトを使用されるときに発生することがあります。以下の情報で問題を解決できない場合は、**support@heimvision.com** までお問い合わせください。

Q1. デバイスが動作しない。
- 電源コードが壁のコンセントに正しく挿入されているか確認してください。アダプターを壁のコンセントに正しくセットしてください。
- 停電による可能性があります。他の電気機器を接続して電源が供給されているか確認してください。

Q2. Smart Life アプリと接続できない。
- ライトを正しくセットしてください。ライトが点滅していることを確認してください。
- 接続する際に使用するWi-Fiネットワークに接続されていることを確認してください。
- Wi-Fiネットワークの暗号化設定は2.4GHzに設定されていることを確認してください。
- 接続する際に使用するWi-Fiネットワークの暗号化設定は2.4GHzに設定されていることを確認してください。

Q3. 時刻表示を完全に消すことはできますか?
- はい、設定インターフェイスのSmart Life アプリケーションでそれができます。ボタンをオンまたはオフに、切り替えてください。

Q4. ラジオから雑音が聞こえます。
- 電波受信状態が悪い場合は、アンテナを完全に伸ばして、アンテナの向きを調整して受信してください。

Q5. 設定できる時間はいくつまでありますか。
- 最大5つまで設定できます。

Q6. 設定されている時間にならないことがあります。
- 時刻表示を消すことはできません。
- 時刻表示は常に表示されています。

Q7. ライトが早く点灯しすぎます。
- 時刻表示を消すことはできません。
- 時刻表示は常に表示されています。

Q8. ライトが遅く点灯しすぎます。
- 時刻表示を消すことはできません。
- 時刻表示は常に表示されています。

FCC CAUTION

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED/IC WARNING

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
The device is compliance with IC exposure guidelines, users can obtain Canadian information on RF exposure and compliance.The minimum distance from body to use the device is 20cm.
Le présent appareil est conforme
Les utilisateurs peuvent trouver une conformité au aux limites d' intensité du champ RF, les utilisateurs peuvent (sur l'exposition aux radiofréquences et la conformité) and (acceptance of a greater) les informations correspondantes. La distance minimale du corps à utiliser le dispositif est de 20cm.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

- The symbol indicates DC voltage
- WEEE-Disposal

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European Directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.
User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.